ENKCF·1.4

VAX 11/730 IDC
PART 1 MICRO

EP-ENKCF-DL-1.4
FICHE 1 OF 4

MAY 1983
COPYRIGHT© 82-83
MADE IN USA



ENKCF·1.4

VAX 11/730 IDC
PART 1 MICRO

EP-ENKCF-DL-1.4
FICHE 2 OF 4

MAY 1983
COPYRIGHT® 82-83
MADE IN USA

d i g i t a l

ENKCF·1.4

VAX 11/730 IDC
PART 1 MICRO

EP-ENKCF-DL-1.4
FICHE 3 OF 4

MAY 1983
COPYRIGHT© 82-83
MADE IN USA

ENKCF-1.4 VAX 11/730 IDC EP-ENKCF-DL-1.4 MAY 1983
PART 1 MICRO FICHE 4 OF 4 COPYRIGHT® 82-83
MADE IN USA

IDENTIFICATION

Product code: ZZ-ENKCF VERSION 1.40

Product name: MICRO-DIAGNOSTIC FOR VAX-11/730 IDC MODULE

Product date: 28-APRIL-1982

Maintainer: BASE SYSTEMS DIAGNOSTIC ENGINEERING

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital or its affiliated companies.

Copyright (c) 1982 by Digital Equipment Corporation. All Rights Reserved.

The following are trademarks of Digital Equipment Corporation.

DEC	DECsystem-10	DECSYSTEM-20
DECUS	MASSBUS	PDP
UNIBUS	VAX	VMS

digital

Table of Contents

1.0 ABSTRACT 3

2.0 HARDWARE REQUIREMENTS 3

3.0 SOFTWARE REQUIREMENTS 3

4.0 PREREQUISITES 3

5.0 OPERATING INSTRUCTIONS 4
5.1 Event Flags 4
5.2 APT Setup 4

6.0 PROGRAM FUNCTIONAL DESCRIPTION 5
6.1 Program Overview 5
6.2 Program Size 5
6.3 Program Run Times 5
6.4 Fault Detection 5
6.5 Performance During Hardware Failures 6
6.6 Program Applications 6
6.7 Test Descriptions 6

7.0 MAINTENANCE HISTORY 6

1.0 ABSTRACT

This program is a micro-diagnostic designed to test the hardware on the IDC (Integrated Disk Controller) module of the VAX-11/730 processor.

2.0 HARDWARE REQUIREMENTS

This program will run with the minimum hardware configuration of a WCS, CPU, MCT, IDC, and array module.

Maximum main memory allowed is 5 one meg boards, for a total of 5 megabytes of main memory storage.

Other options may be installed without affecting the diagnostic's performance.

The IDC PROMS must contain V19.0 or later.

3.0 SOFTWARE REQUIREMENTS

This diagnostic must be run under the VAX-11/730 micro monitor (ENKAA) in a standalone environment. The micro-diagnostic is written into WCS RAM, wiping out any system micro-code that may have been resident. Some Diagnostic micorocde is also located in the IDC control store. The micro-diagnostic monitor takes up the area where the console software is normally present.

4.0 PREREQUISITES

The WCS, DAP, and MCT modules are assumed to have been tested and known to be good before this diagnostic is run. The programs ENKBA through ENKBE, ENKCA through ENKCD will perform this testing.

5.0 OPERATING INSTRUCTIONS

This program may be executed by typing DI SE ENKCF after the micro-monitor has been loaded and the MIC> prompt has been printed at the terminal. Both the micro-monitor and this program are loaded from a TU58 cassette or downline loaded through the APT-RD port. See the OVERVIEW MANUAL for more information.

5.1 Event Flags

Not applicable

5.2 APT Setup

A Field Test Version (V0.0) of this diagnostic will not recognize when APT is present and will always size for the IDC module. If no IDC is found a message is printed and this diagnostic will not be run.

Version 1.0 of this diagnostic, will recognize when APT is present, and will report an error if the diagnostic does not find an IDC on the system.

The micro-monitor knows when APT is present by the position of the keyswitch and the state of a line connected to the APT-RD port. It sets a flag in the CPU Local Store which can be read by Version 1.0 and above of this diagnostic. When APT is present, the diagnostic will:

1. Size for the IDC. If no IDC is found, an error will be reported, and if there is an IDC, ENKCF will be run.

Under APT, the diagnostic will halt on error and report error information to APT via the mailbox in 8085 RAM.

The following describes the APT parameters needed to execute this diagnostic:

The Hardware Configuration Register must be loaded with the following information when running ENKCF: If an R80 is on Drive 0 and is powered up, Hardware Config Reg = 00000001 (01) If an R80 is on Drive 1 and is powered up, Hardware Config Reg = 00000010 (02) If an R80 is on Drive 2 and is powered up, Hardware Config Reg = 00000100 (04) If an R80 is on Drive 3 and is powered up, Hardware Config Reg = 00001000 (08) If there are no R80s powered up, Hardware Config Reg = 00000000 (00)

6.0 PROGRAM FUNCTIONAL DESCRIPTION

6.1 Program Overview

This program is designed to detect stuck-at faults and provide a repair tool which helps isolate the failing component. A bottom up diagnostic strategy is utilized which builds on previous tests. The tests should be run in consecutive order, to gain the best isolation of a failing component.

6.2 Program Size

This program runs in WCS RAM memory and is approximately 20K bytes long (utilizing about 6000 micro-words in WCS).

6.3 Program Run Times

This program will take approximately 29 seconds to run, including initialization.

6.4 Fault Detection

The diagnostic will report errors with the following header:

```
SECT  TST ERR   EXP   REC  OTHER  MSK  MODULE
```

1. SECT is the program name (ENKCF)
2. TST is the test number that failed.
3. ERR is the error number that failed.
4. EXP is the expected (correct) data.
5. REC is the received (actual) data.
6. OTHER is any other pertinent data (such as an address). This field is not always used. N/A will be printed under OTHER when not in use. The ERRORS section in the listing will describe the contents of this field when it is used.
7. MASK is the error mask used to check the result. Bits set to a 1 in this mask correspond to bits in the result that are not checked.

8. MODULE is the suspected module that caused the failure.

6.5 Performance During Hardware Failures

A power fail will cause a rebooting of the system. Other failures, such as a timeout or a WCS parity error, will print an error message and return to the MIC> prompt. The operator can then issue other commands, including a continue if desired.

6.6 Program Applications

This program can be used by field service to determine which module should be replaced and to verify that the replacement eliminated the failure. It can also be used as a repair tool to help isolate a failing component by manufacturing, field service or engineering. The Version 1.0 of the program is APT compatable.

Customers may used the program to verify the basic integrity of the IDC.

6.7 Test Descriptions

See the actual test in the listing for detailed descriptions and error analyses. A brief description of the logic being tested by each test can be found in the table of contents of the listing.

7.0 MAINTENANCE HISTORY

DATE	VERSION	DESCRIPTION
25-Mar-82	1.10	Test 19 timed-out if an R80 was on drive 0.
28-Apr-82	1.20	Tests 3C and 3D failed during system clock margining.
22-NOV-82	1.30	Addition of 3 error reports for fault insertion enhancement in test 39.
15-MAR-83	1.40	Test 2 masked bits 20-31 of the IDAR for clock margining.

;
; Table of Contents

; 727 FIELD DEFINITIONS FOR MAIN MICRO WORD VER 00.08
; 1733 MACRO DEFINITIONS VER 00.02
; 2389 FIELD DEFINTITIONS FOR DATA PATH CONTROL MICRO WORD VER 00.01
; 2442 CONTROL ROM CONTENTS VER 00.01
; 3191 DIAGNOSTIC MACROS AND DEFINITIONS
; 3850 COMMON LS ASSIGNMENTS (TO REGISTERS)
; 4010 Microinstruction Formats
; 4393 Tables
; 4524 2901 ALU Control Description
; 4628 DIAGNOSTIC MACROS
; 4656 TEST POINTERS
; 4766 DIAGNOSTIC POINTERS
; 4856 LS DATA SECTION
; 5247 PROGRAM SPECIFIC DATA SECTION (LS 80-F7)
; 5619 WCS SUBROUTINES FOR CONSOLE USE
; 5620 GENERATE TRANSFER DATA
; 5665 DEPOSIT MCT CSR ROUTINE
; 5731 EXAMINE MCT CSR ROUTINE
; 5818 DEPOSIT MCT TRANSLATION BUFFER ROUTINE
; 5934 EXAMINE TRANSLATION BUFFER ROUTINE
; 5997 DEPOSIT UNIBUS MAP ROUTINE
; 6095 EXAMINE UNIBUS MAP ROUTINE
; 6158 DEPOSIT MAIN MEMORY ROUTINE
; 6216 EXAMINE MAIN MEMORY ROUTINE
; 6278 EXAMINE IDC ROUTINES
; 6344 DEPOSIT IDC ROUTINES
; 6416 SAVE WR ROUTINE
; 6467 RESTORE WR ROUTINE
; 6518 WCS SUBROUTINES FOR CPU USE
; 6519 ERROR ROUTINE
; 6686 START TRANSFER ROUTINE
; 6785 SUBROUTINES FOR IDC MICRODIAGNOSTIC
; 6786 DISK DRIVE SIZING ROUTINE
; 6920 INIT IDC AND GO TO DIAG.IDLE ROUTINE
; 6996 WRITE..READ BYTE USING DISKLESS LOOP
; 7223 CLEANUP ROUTINE
; 7268 Test 1 Y BUS VERIFICATION TEST (M8388 IDC MODULE OR M8390 CPU MODULE)
; 7393 Test 2 IDC SIZING TEST (M8388 IDC MODULE OR M8390 CPU MODULE)
; 7566 Test 3 CRDY & XFER.REQ INIT TEST (M8388 IDC OR M8390 CPU MODULE)
; 7734 Test 4 DISK ADDRESS REGISTER TEST (M8388 IDC MODULE)
; 8007 Test 5 CONTROL STATUS REGISTER TEST (M8388 IDC MODULE)
; 8309 Test 6 CRDY & IDC DIAGNOSTIC MICROCODE ACCESS TEST (M8388 IDC MODULE)
; 8634 Test 7 CSR BITS <F0><F1><F2> BRANCH TEST (M8388 IDC MODULE)
; 8931 Test 8 XFER.REQ-XFER GRANT TEST(M8388 IDC MODULE OR M8390 CPU MODULE)
; 9139 Test 9 UINCREMENT DAR TEST (M8388 IDC MODULE)
; 9373 Test A BEN0/CRDY AND BEN2/MAINT BRANCH TEST (M8388 IDC MODULE)
; 9753 Test B CSR WRITE INHIBIT BIT <28> TEST (M8388 IDC MODULE)
; 9864 Test C DRIVE READY BRANCH TEST (M8388 IDC MODULE)
; 10125 Test D XFER.REQ BRANCH TEST (M8388 IDC MODULE)
; 10432 TEST E DISK DRIVE SIZING TEST (M8388 IDC MODULE)
; 10761 Test F FIFO A ADRS CNTR MAX L BRANCH TEST 1 (M8388 IDC MODULE)
; 11226 Test 10 FIFO A ADRS CNTR MAX L BRANCH TEST 2 (M8388 IDC MODULE)
; 11721 Test 11 FIFO B ADRS CNTR MAX L BRANCH TEST 1 (M8388 IDC MODULE)
; 12282 Test 12 FIFO B ADRS CNTR MAX L BRANCH TEST 2 (M8388 IDC MODULE)
; 12863 Test 13 FIFO A ADRS CNTR OVFLW L BRANCH TEST 1 (M8388 IDC MODULE)

```
; 13476 Test 14  FIFO A ADRS CNTR OVFLW L BRANCH TEST 2 (M8388 IDC MODULE)
; 14117 Test 15  FIFO B ADRS CNTR OVFLW L BRANCH TEST 1 (M8388 IDC MODULE)
; 14823 Test 16  FIFO B ADRS CNTR OVFLW  L BRANCH TEST 2 (M8388 IDC MODULE)
; 15541 Test 17  LOOP COUNTER TEST (M8388 IDC MODULE)
; 16312 Test 18  R80 BRANCH TEST (M8388 IDC MODULE)
; 16735 Test 19  R80 FORMAT BRANCH  TEST (M8388 IDC MODULE)
; 17122 Test  1A AUTOMATIC SKIP SECTOR INHIBIT BRANCH TEST (M8388 IDC MODULE)
; 17501 Test 1B  ONLINE PAL & BRANCH TEST, DR SEL CSR<9:8> (M8388 IDC MODULE)
; 18693 Test 1C  ONLINE PAL & BRANCH TEST WITH USEL.DRV (M8388 IDC MODULE)
; 19340 Test 1D  DATA BUS IN AND DATA BUS OUT TEST (M8388 IDC MODULE)
; 19666 Test 1E  FIFO A DATA INTEGRITY TEST (M8388 IDC MODULE)
; 19920 Test 1F  FIFO B DATA INTEGRITY TEST (M8388 IDC MODULE)
; 20175 Test 20  I/O BUS IN AND OUT LATCHES TEST (M8388 IDC MODULE)
; 20397 Test 21  FIFO A AND FIFO B UNIQUENESS TEST (M8388 IDC MODULE)
; 20665 Test 22  FIFO A ADDRESSING TEST (M8388 IDC MODULE)
; 20940 Test 23  FIFO B ADDRESSING TEST (M8388 IDC MODULE)
; 21216 Test 24  PARALLEL IN/OUT DATA SHIFT REGISTER TEST (M8388 IDC MODULE)
; 21649 Test 25  SERIAL SHIFT OUT FUNCTION OF DSR TEST (M8388 IDC MODULE)
; 21887 Test 26  RL02 DATA PATH TEST 1 (M8388 IDC MODULE)
; 22265 Test 27  RL02 DATA PATH TEST 2 (M8388 IDC MODULE)
; 22467 Test 28  ECC STAT<1:0> LINES TEST (M8388 IDC MODULE)
; 22838 Test 29  DC007 INTERNAL SHIFT REGISTER INIT TEST (M8388 IDC MODULE)
; 23214 Test 2A  DC007 PATTERN REGISTER TEST (M8388 IDC MODULE)
; 23625 Test 2B  DC007 POSITION REGISTER TEST(M8388 IDC MODULE)
; 24314 Test 2C  DC007 WRITE CLK AND CRC MODE TEST (M8388 IDC MODULE)
; 24850 Test 2D  CORRECTABLE ECC ERROR TEST (M8388 IDC MODULE)
; 25429 Test 2E  HEADER MATCH TEST (M8388 IDC MODULE)
; 26074 Test 2F  CLEAR MATCH TEST (M8388 IDC MODULE)
; 26580 Test 30  MISMATCH LOGIC TEST (M8388 IDC MODULE)
; 27591 Test 31  DAR SERIALIZER AND RL02 HEADER MATCH TEST (M8388 IDC MODULE)
; 28250 Test 32  WRITE CHECK TEST (M8388 IDC MODULE)
; 28945 Test 33  ATTENTION REGISTER TEST 1 (M8388 IDC MODULE)
; 29452 Test 34  ATTENTION REGISTER TEST 2 (M8388 IDC MODULE)
; 29880 Test 35  CSR OPERATION INCOMPLETE (OPI)  BITS TEST (M8388 IDC MODULE)
; 30428 Test 36  OPERATION INCOMPLETE BRANCH TEST (M8388 IDC MODULE)
; 30821 Test 37  CSR DATA LATE (DLT) BITS TEST (M8388 IDC MODULE)
; 31270 Test 38  SKIP SECTOR ERROR FLAG TEST (M8388 IDC MODULE)
; 31662 Test 39 INTERRUPT REQUEST TEST 1 (M8388 IDC MODULE)
; 32403 Test 3A  INTERRUPT REQUEST TEST 2 (M8388 IDC MODULE)
; 32843 Test 3B  AUTOMODE TEST (M8388 IDC MODULE)
; 33082 Test 3C  TIMEOUT TEST 1 (M8388 IDC MODULE)
; 33339 Test 3D  TIMEOUT TEST 2 (M8388 IDC MODULE)
```

```
                ;1      .TITLE  "ENKCF Micro-diagnostic for IDC module  Rev 01.40"
                ;2      ;
                ;3      ;
                ;4      ;                       COPYRIGHT (c) 1982 BY
                ;5      ;               DIGITAL EQUIPMENT CORPORATION, MAYNARD,
                ;6      ;                MASSACHUSETTS.  ALL RIGHTS RESERVED.
                ;7      ;
                ;8      ; THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY  BE  USED  AND  COPIED
                ;9      ; ONLY  IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION
                ;10     ; OF THE ABOVE COPYRIGHT NOTICE.  THIS SOFTWARE OR ANY OTHER COPIES THEREOF
                ;11     ; MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER  PERSON.  NO
                ;12     ; TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERRED.
                ;13     ;
                ;14     ; THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE, AND
                ;15     ; SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.
                ;16     ;
                ;17     ; DIGITAL  ASSUMES  NO  RESPONSIBILITY  FOR  THE  USE OR RELIABILITY OF ITS
                ;18     ; SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.
                ;19     ;
                ;20
                ;21     ;++
                ;22     ; FACILITY:     VAX-11/730 MICRO-DIAGNOSTIC.
                ;23     ;
                ;24     ; ABSTRACT:     This micro-diagnostic tests the hardware of the IDC  module
                ;25     ;               in the VAX-11/730 processor.
                ;26     ;
                ;27     ; ENVIRONMENT:  ENKAA  Micro-diagnostic Monitor
                ;28     ;
                ;29     ; AUTHOR:       Vickie Hayes    24-MARCH-82     VERSION 1.1
                ;30     ;
                ;31     ; MODIFIED BY:
                ;32     ;       REV. 1.1    VICKIE HAYES    24-MARCH-82
                ;33     ;
                ;34     ;       REV. 1.2    DAVID MAYO      28-APRIL-82
                ;35     ;                   Changes to Tests 3C and 3D due to accomadate system clock
                ;36     ;                   margining.
                ;37     ;
                ;38     ;       REV. 1.3    GEORGE HO       22-NOV-82
                ;39     ;                   Addition of 3 error reports for fault insertion enhancement
                ;40     ;                   in test 39.
                ;41     ;
                ;42     ;       REV. 1.4    PETER GREEN     15-MAR-83
                ;43     ;                   MANUFACTURING PROBLEM W/SLOW CLOCK IDC NOT FOUND
                ;44     ;                   (INTERMITTANT) BITS 25 & 27 BEING SET. SET UP ERROR MASK
                ;45     ;                   TO ONLY CHECK BITS <20:0> ON THE IDAR.
                ;46     ;
                ;47     ;--
                ;48     .nolist
                ;52     .list
                ;53     .NOCREF
;54     .NOBIN
;55     .SEQUENTIAL
```

```
;56      .RTOL
;57      .HEXADECIMAL
;58      ; REVISION HISTORY
;59      ;
;60      ; VER 02.24     9-SEP-80        SCS
;61      ;
;62      ;       ADD THE BIC WR[] WITH WR[] TO Q MACRO.
;63      ;
;64      ; VER 02.23     16-JUL-80       SCS
;65      ;
;66      ;       FIX MINC INSTRUCTION TO CALL INC INSTEAD OF DEC
;67      ;
;68      ; VER 02.22     15-JUL-80       SCS
;69      ;
;70      ;       ADD SAVED.MDT TO LOCAL STORE.
;71      ;
;72      ; VER 02.21     7-JUL-80        SCS
;73      ;
;74      ;       REMAP ALL OF THE CONSTANTS TO THE LOCAL STORE LOCATIONS
;75      ;       REQUIRED BY THE 8085 TO BUILD THEM DURING POWER-UP.
;76      ;
;77      ;       THIS ALLOWS US TO RECOVER FROM POWER FAIL CORRECTLY.
;78      ;
;79      ;       THE CHANGES BASICALLY REQUIRED A RESHUFFLING OF THE CONSTANTS
;80      ;       ACCORDING TO SIZE OF THE NUMBER.
;81      ;
;82      ; VER 02.20     13-JUN-80       SCS
;83      ;
;84      ;       FIX VALIDITY CHECKS TO ALLOW LEGAL SKIP CONDITIONS ON
;85      ;       THE PAGE BOUNDARY CONSISTING OF:
;86      ;
;87      ;       RETURN
;88      ;       RETURN+1
;89      ;       RET.NOERR
;90      ;       POP.USTACK
;91      ;
;92      ; VER 02.19     04-JUN-80       SCS
;93      ;
;94      ;       ADD VALIDITY CONDITIONS TO THE SKIP AND JUMP CONTROL
;95      ;       FIELDS TO CHECK FOR THE PAGE PROBLEM CREATED BY THE SEQUENCER.  THIS
;96      ;       LIMITATION ONLY ALLOWS CARRIES TO BE PROPAGATED FOR 10 BITS WHEN
;97      ;       THE ADDRESS IS INCREMENTED BY TWO.  THE NORMAL SEQUENCING OF INSTRUCTIONS
;98      ;       CAN WALK ACROSS THESE 1K BOUNDARIES.
;99      ;
;100     ;       THIS REQUIRES ADDITION OF THE FOLLOWING VALIDITY CHECKS AND CHANGES
;101     ;       TO THE SCTL AND JCTL FIELD'S VALIDITY CHECKS.
;102     ;
;103     ;       PAGE.PROB
;104     ;       SKIP.PAGE.VAL
;105     ;       JUMP.CHECK
;106     ;       JUMP.PAGE.VAL
;107     ;
;108     ; VER 02.18     02-JUN-80       SCS
;109     ;
;110     ;       REMOVE THE MACRO BIC WR[] WITH LS[] TO Q
```

```
;111     ;       SINCE IT IS NOT IMPLEMENTED ANYMORE.
;112     ;
;113     ; VER 02.17     13-MAY-80       SCS
;114     ;
;115     ;       ADD BIT TO LS[CONSOLE.CSR.IES]
;116     ;
;117     ;       <5> - CRD RETRY IN PROGRESS.
;118     ;
;119     ;       ADD LS LOCATION CRD.LOG
;120     ;
;121     ; VER 02.16     18-APR-80       SCS
;122     ;
;123     ;       CHANGE MEM.FUNC FIELD TO CONTAIN:
;124     ;
;125     ;       READ.MAINT.BRANCH.CHECK
;126     ;       READ.MAINT.UBS
;127     ;
;128     ;       UPDATE MOV FPA TO LS[] TO REMOVE CC SETTING.
;129     ;
;130     ; VER 02.15     14-APR-80       SCS
;131     ;
;132     ;       ADD THE FOLLOWING FIELD VALUES TO THE MEM.FUNC FIELD:
;133     ;
;134     ;       READ.MAINT.VAR.INC
;135     ;       OCTA.WRITE.P
;136     ;       MAINT.ECC.DATA
;137     ;       OCTA.READ.P
;138     ;
;139     ;       CHANGE THE DATA PATH CONTROL ROM TO MATCH THE PRESENT HARDWARE
;140     ;       IMPLEMENTATION.  REMOVE THE PARWORD AND PAR2 FIELDS.  CHANGE
;141     ;       FIELD VALUES FOR THE SRC FIELD.
;142     ;
;143     ;       CHANGE SRC FIELDS OF THE COND.ADD&SHIFT AND COND.SUB&SHIFT MACROS
;144     ;       TO USE A.B AND NOT THE NEW DEFAULT MUL FIELD VALUE.  THE HARDWARE
;145     ;       NOW OVERRIDES WHATEVER IS IN THE FIELD.
;146     ;
;147     ; VER 02.14     19-MAR-80       SCS
;148     ;
;149     ;       ADD SUPPORT FOR THE IDC.!!.
;150     ;
;151     ;       THE FOLLOWING FIELDS HAVE BEEN ADDED WITH THEIR ASSOCIATED
;152     ;       VALUES:
;153     ;
;154     ;       PORT.SELECT
;155     ;       PORT.FUNC
;156     ;       R.W.FUNC
;157     ;       CNTL.FUNC
;158     ;
;159     ;       THE FOLLOWING MACROS HAVE BEEN ADDED:
;160     ;
;161     ;       PORT.CONTROL
;162     ;       PORT.WRITE PORT.ADRS[] WITH WR[]
;163     ;       PORT.READ PORT.ADRS[]
;164     ;
;165     ; VER 02.13     13-MAR-80       SCS
```

```
;166     ;
;167     ;       ADD THE FOLLOWING CONSTANTS TO THE LOCAL STORE:
;168     ;
;169     ;       #40A10
;170     ;
;171     ;       ADD LOCATION IN LOCAL STORE:
;172     ;
;173     ;       MEMORY.SIZE
;174     ;
;175     ; VER 02.12     23-FEB-80       SCS
;176     ;
;177     ;       ADD THE FOLLOWING NEW LABELS TO OLD LOCAL STORE
;178     ;       LOCATIONS:
;179     ;
;180     ;       CONSOLE.COMMAND
;181     ;       CONSOLE.MODIFIER
;182     ;       CONSOLE.ADDRESS
;183     ;       CONSOLE.STATUS
;184     ;       CONSOLE.DATA
;185     ;
;186     ; VER 02.11     11-FEB-80       SCS
;187     ;
;188     ;       UPDATE COMMENTS TO SWAP AND MEM FUNCTION.
;189     ;
;190     ; VER 02.10     7-FEB-80        SCS
;191     ;
;192     ;       CHANGED CM.EXEC ADRS[] TO LOAD THE OS REGISTER.
;193     ;
;194     ; VER 02.09     17-DEC-79       SCS
;195     ;
;196     ;       ADD THE CROSS REFERENCE LISTING TO OUTPUT.
;197     ;
;198     ;       BUILD THE FOLLOWING MEMORY CODES FOR THE MEM.FUNC FIELD:
;199     ;
;200     ;               WRITE.TB.STEP=11
;201     ;               OCTA.READ.V.RCHK=1A
;202     ;               READ.MAINT.UBS.DATA=1B
;203     ;               OCTA.WR.V.WCHK=1D
;204     ;               QUAD.READ.V.RCHK=1E
;205     ;
;206     ; VER 02.08     12-NOV-79       SCS
;207     ;
;208     ;       CREATE BACKUP LOCATION FOR COMPATIBILITY MODE PC.
;209     ;
;210     ;               BACKUP.CM.PC
;211     ;
;212     ;       ADD THE FOLLOWING CONSTANTS:
;213     ;
;214     ;               #FF80
;215     ;               #FFF0
;216     ;               #40211
;217     ;               #66
;218     ;
;219     ; VER 02.07     30-OCT-79       SCS
;220     ;
```

```
;221     ;       CHANGE LS LOCATIONS
;222     ;
;223     ;               #2D40
;224     ;               #C00000E0
;225     ;               #FFFFFF1F
;226     ;       TO
;227     ;               #2D20
;228     ;               #C0000E0
;229     ;               #FFFFFF10
;230     ;
;231     ; VER 02.06     29-OCT-79       SCS
;232     ;
;233     ;       CHANGE LS LOCATION
;234     ;
;235     ;               #FFFFFF8F
;236     ;       TO
;237     ;               #FFFFFF1F
;238     ;
;239     ; VER 02.05     26-OCT-79       SCS
;240     ;
;241     ;       CHANGE LS LOCATIONS
;242     ;               #5F
;243     ;               #5F40
;244     ;       TO
;245     ;               #2D
;246     ;               #2D40
;247     ;
;248     ; VER 02.04     26-OCT-79       SCS
;249     ;
;250     ;       FIX THE FOLLOWING MACROS CALL TO DATA PATH CONTROL ROM.
;251     ;
;252     ;       ADD Q TO WR[] XCHG TO LS[]
;253     ;
;254     ; VER 02.03     11-OCT-79       SCS
;255     ;
;256     ;       ADD
;257     ;               SAVED.2ND.REQUEST
;258     ;               PSEUDO.NICR
;259     ;               PSEUDO.ICR
;260     ;       TO LS LOCATIONS.
;261     ;
;262     ;       FIX ERROR IN
;263     ;               MOV FPA TO LS[].
;264     ;
;265     ; VER 02.02     04-OCT-79       SCS
;266     ;
;267     ;       FIX DEFAULT FOR BIT <18> TO BE 1 FOR DECODE INSTRUCTIONS AND
;268     ;       0 FOR ALL OTHERS.
;269     ;
;270     ; VER 02.01     27-SEP-79       SCS
;271     ;
;272     ;       FIX THE BPC FIELD DEFAULT.
;273     ;
;274     ; VER 02.00     13-SEP-79       SCS
;275     ;
```

```
;276     ;       THIS IS THE VERSION WHICH PROVIDES COMPATIBILITY BETWEEN
;277     ;       BREADBOARD ONE AND BREADBOARD TWO.
;278
;279     ;
;280     ;       VALUES OF THE BIC FIELD ARE COMPLEMENTED.
;281     ;
;282     ;       MISC.2 FIELD VALUES ARE RE-ARRANGED.
;283     ;
;284     ;       MISC.4 FIELD REMOVED.
;285     ;
;286     ;       CHANGES TO THE FOLLOWING MACROS:
;287     ;
;288     ;       MOV WR[] TO WR[]
;289     ;       MOV WR[] TO Q
;290     ;       CLR Q
;291     ;       CLR WR[]
;292     ;       NEG WR[]
;293     ;       INC WR[]
;294     ;       DEC WR[]
;295     ;       COM WR[]
;296     ;       TST WR[]
;297     ;
;298     ;       ADD THE FOLLOWING MACROS
;299     ;
;300     ;       MCOM WR[] TO WR[]
;301     ;       MINC WR[] TO WR[]
;302     ;       MDEC WR[] TO WR[]
;303     ;
;304     ; VER 01.23     11-SEP-79       SCS
;305     ;
;306     ;       ADD THE FOLLOWING CONSTANTS
;307     ;
;308     ;       #F0
;309     ;       #A0
;310     ;       #30
;311     ;       #5F
;312     ;       #5F40
;313     ;
;314     ;       UPDATE TO FIELD VALUE:
;315     ;
;316     ;       ASSERT.DA.AND.PASS.WR
;317     ;
;318     ;       RENAME NEW FIELDS:
;319     ;
;320     ;       MISC.WRL
;321     ;       MISC.WRR
;322     ;
;323     ;       ADD NEW MACROS:
;324     ;
;325     ;       MOV FPA TO LS[]
;326     ;       MOV PORT TO LS[]
;327     ;       ASSERT.DA.AND.PASS.WR0
;328     ;       ASSERT.DA.AND.PASS.WR1
;329     ;       ADD Q TO WR[] XCHG TO LS[]
;330     ;
```

```
;331     ;       CHANGE MACROS:
;332     ;
;333     ;       MISC[] WR[]
;334     ;       MISC2[] WR[]
;335     ;
;336     ;       REMOVE MACROS:
;337     ;       (ALL PRIORITY ENCODE FUNCTIONS)
;338     ;
;339     ;       RENAME MACRO TO
;340     ;
;341     ;       LOOP.IF(NO INTERRUPT AND NO SYNC) ELSE SKIP.IF(SYNC)
;342     ;
;343     ; VER 01.22     02-AUG-79       SCS
;344     ;
;345     ;       ADD HARDWARE INDEXES TO PORT REGISTERS.
;346     ;
;347     ; VER 01.21     31-JUL-79       SCS
;348     ;
;349     ;       CHANGED CONSTANT #F03000 TO #F27000
;350     ;       ADDED NEW MACROS
;351     ;               MISC[] WR[]
;352     ;               MISC2[] WR[]
;353     ;
;354     ; VER 01.20     20-JUL-79       SCS
;355     ;
;356     ;       ADD FUNCTION
;357     ;
;358     ;               MISC2[MASK.INTERRUPTS]
;359     ;
;360     ; VER 01.19     16-JUL-79       SCS
;361     ;
;362     ;       ADD NEW MACRO
;363     ;
;364     ;               MOV CM.IB.DATA TO OS
;365     ;
;366     ;       ADD TRUE LSS TO SCTL FIELD.
;367     ;       RENAME FALSE LSS TO N.CLR
;368     ;                    GEQ TO N.SET
;369     ;       IN BOTH THE SCTL FIELD AND JCTL FIELD.
;370     ;       THERE ARE NOW NO FREE SKIP CONDITIONS!!
;371     ;
;372     ; VER 01.18     13-JUL-79       SCS
;373     ;
;374     ;       FIX ERROR WITH VALIDITY ON XCHG.BIT
;375     ;
;376     ; VER 01.17     07-JUL-79       SCS
;377     ;
;378     ;       CHANGED #3A3000 TO #F03000
;379     ;       INSERT ROTATE.BYTE.RIGHT INTO MEM.FUNC FIELD.
;380     ;
;381     ;       ADD SYMMETRIC MACROS:
;382     ;
;383     ;               SWAP WR[] WITH LS[]
;384     ;               ADD LS[] PLUS WR[] TO Q
;385     ;               BIS LS[] WITH WR[] TO Q
```

```
;386     ;               AND LS[] WITH WR[] TO Q
;387     ;               XOR LS[] WITH WR[] TO Q
;388     ;
;389     ;       ADD MNEG Q TO LS[]
;390     ;
;391     ; VER 01.16     08-JUN-79       SCS
;392     ;
;393     ;       DEFINE THE FOLLOWING LOCATIONS:
;394     ;
;395     ;               IE.TEMP1
;396     ;               IE.TEMP2
;397     ;               IE.TEMP3
;398     ;               IE.TEMP4
;399     ;
;400     ;               #B020FF00
;401     ;               #C00000E0
;402     ;
;403     ;       RENAME SKIP CONDITION IN SCTL FIELD TO:
;404     ;
;405     ;               NO.FAST.INTERRUPT
;406     ;
;407     ; VER 01.15     16-MAY-79       SCS
;408     ;
;409     ;       ADD LD.OS/LOAD.OS TO
;410     ;       DECODE.CM.OPC ADRS[]
;411     ;
;412     ; VER 01.14     14-MAY-79       SCS
;413     ;
;414     ;       ADD A ZERO LOCATION TO LOCAL STORE.
;415     ;
;416     ; VER 01.13     08-MAY-79       SCS
;417     ;
;418     ;       DEFINE TWO NEW FUNCTIONS FOR SI FIELD.
;419     ;
;420     ;       UMUL.SHF
;421     ;       SHF.WR.Q
;422     ;
;423     ;       ADD THE FOLLOWING MACROS:
;424     ;
;425     ;       UNSIGNED.MUL WR[] TO WR[].Q
;426     ;       SHR WR[]
;427     ;       SHL WR[]
;428     ;       SHRC WR[].Q
;429     ;       SHLC WR[].Q
;430     ;
;431     ; VER 01.12     01-MAY-79       SCS
;432     ;
;433     ;       INSERT LS[CONSOLE.CSR.IES]
;434     ;
;435     ; VER 01.11     19-APR-79       SCS
;436     ;
;437     ;       ADDITION OF EQL PNEUMONIC TO THE JCTL FIELD.  CHANGE
;438     ;       TO DPCROM TO FIX THE FOLLOWING MACROS:
;439     ;
;440     ;       ADD Q PLUS LS[] TO WR[]
```

```
;441     ;       COND.ADD&SHIFT WR[] TO WR[].Q
;442     ;
;443     ; VER 01.10     10-APR-79       SCS
;444     ;
;445     ;       ADDITION OF .SET/UPC=000 TO THE DEFINITION FILE SO THAT ALL
;446     ;       MICRO ASSEMBLERS CAN USE .CHANGE/UPC=<.+1> IN THEIR CODE.
;447     ;
;448     ; VER 01.09     04-APR-79       SCS
;449     ;
;450     ;       FIX DECODE.CM.DST ADRS[]
;451     ;
;452     ;       ADD SAVE.CM.PC WR0
;453     ;
;454     ;       UPDATE MOV IB.DATA TO OS
;455     ;
;456     ;       SWITCH JCTL FIELDS
;457     ;               NO.JUMP.TST
;458     ;               JUMP.VALID
;459     ;
;460     ; VER 01.08     30-MAR-79       SCS
;461     ;
;462     ;       ADD IN OS.BAK
;463     ;
;464     ;       ADD IN TST Q
;465     ;
;466     ; VER 01.07     21-MAR-79       SCS
;467     ;
;468     ;       REMOVE THE FOLLOWING IMPOSSIBLE MACROS:
;469     ;
;470     ;       BIC Q TO LS[]
;471     ;       BIC WR[] TO LS[]
;472     ;       BIC Q TO WR[]
;473     ;       BIC WR[] WITH LS[[ TO Q
;474     ;
;475     ;       UPDATE THE FOLLOWING MACROS TO WORK:
;476     ;
;477     ;       OPR Q TO WR[]
;478     ;
;479     ;       ADD THE FOLLOWING MACRO:
;480     ;
;481     ;       ADD Q PLUS LS[] TO WR[]
;482     ;
;483     ; VER 01.06     19-MAR-79       SCS
;484     ;
;485     ;       ADD NEW LOCATIONS TO LOCAL STORE FOR MEMORY MANAGEMENT
;486     ;       ADD TWO NEW TEMPORARY LOCATIONS.
;487     ;       FIX UP DPCROM FOR
;488     ;
;489     ;       PRI.ENC WR0 R.TO.L TO OS AND CLEAR BIT
;490     ;
;491     ;       ADD THE FOLLOWING CONSTANTS:
;492     ;
;493     ;       #FF
;494     ;       #FFFFFFFF
;495     ;       #3A3000
```

```
;496     ;       #7FFFFE00
;497     ;       #3FFFFE00
;498     ;       #3B
;499     ;       #3F
;500     ;       #3000
;501     ;       #FFFFF000
;502     ;       #FFE0
;503     ;       #FFF
;504     ;       #0FFF0000
;505     ;       #FFFFFF8F
;506     ;
;507     ;       ADD THE FOLLOWING MACROS:
;508     ;
;509     ;       ADD Q PLUS WR[] TO LS[]
;510     ;       SUB Q FROM WR[] TO LS[]
;511     ;
;512     ;       FIX UP ERROR IN MACRO:
;513     ;
;514     ;       MOV XWR[] TO Q
;515     ;       CMP Q WITH WR[]
;516     ;
;517     ; VER 01.05     13-MAR-79       SCS
;518     ;
;519     ;       FIX MEM.FUNC FIELD TO MATCH HARDWARE.
;520     ;
;521     ;       FIX ERROR IN PRI.ENC MACRO IN DATA PATH CONTROL ROM.
;522     ;
;523     ;       FIX ERROR IN MISC.2 FIELD
;524     ;
;525     ; VER 01.04     07-MAR-79       SCS
;526     ;
;527     ;       FIX ERROR IN THE LABEL IN DATA PATCH CONTROL ROM
;528     ;       CORRESPONDING TO THE FOLLOWING MACRO:
;529     ;
;530     ;       BIS WR[] WITH LS[] TO Q
;531     ;
;532     ;       CHANGE TST WR[] MACRO TO USE NEW DATA PATH CONTROL ROM FUNCTION
;533     ;       WHICH WILL CLEAR THE V AND C CONDITION CODES IF DT(SIZE)&SET.ALU.CC
;534     ;       IS INVOKED.
;535     ;
;536     ;       INSERT NEW MACROS FOR COMPATIBILITY MODE DECODE MACROS:
;537     ;
;538     ;       JMP.TO []
;539     ;       JSR.TO []
;540     ;
;541     ;       FIX ERROR IN:
;542     ;
;543     ;       DECODE.CM.SINGLE ADRS[]
;544     ;
;545     ; VER 01.03     05-MAR-79       SCS
;546     ;
;547     ;       FIX ERROR IN THE FOLOWING MACROS:
;548     ;
;549     ;       SET.STATE.ZERO&CLR.STATE.ONE
;550     ;       SET.STATE.ONE&CLR.STATE.ZERO
```

```
;551     ;
;552     ;       INSERT CM.PC LOCATION OF THE LOCAL STORE.
;553     ;
;554     ;       INSERT THE FOLLOWING MACROS:
;555     ;
;556     ;       LOOP.IF(NO INTERRUPT AND NO SYNC)
;557     ;
;558     ; VER 01.02     01-MAR-79       SCS
;559     ;
;560     ;       IMPLEMENT NEW PRIORITY ENCODE FUNCTIONS AND DOCUMENT:
;561     ;
;562     ;       PRI.ENC WR0 R.TO.L TO OS
;563     ;       PRI.ENC WR0 L.TO.R TO OS
;564     ;       PRI.ENC WR0 R.TO.L TO OS AND CLEAR BIT
;565     ;       PRI.ENC WR0 L.TO.R TO OS AND CLEAR BIT
;566     ;
;567     ;       COMPLEMENT ALL FIELD VALUES OF THE MISC.1 FIELD.
;568     ;       ADD VAR FIELD VALUE FOR WR[5].
;569     ;       PUT THE FOLLOWING LOCATIONS INTO THE HIGH HALF OF LS:
;570     ;               P0BR
;571     ;               P0LR
;572     ;               P1BR
;573     ;               P1LR
;574     ;               SBR
;575     ;               SLR
;576     ;
;577     ;       RESERVE LOCATIONS A0-BF FOR THE PORT. (PORT0-PORT31)
;578     ;       REMOVE TEMPORARY LOCATIONS T22-T28 LEAVING T0-T15 AS
;579     ;       THE TEMPORARY LOCATIONS AVAILABLE.
;580     ;       INSERT .PAGE 'S FOR READABILITY.
;581     ;
;582     ; VER 01.01     01-MAR-79       SCS
;583     ;
;584     ;       FIX THE SUB LS[] FROM WR[] TO Q MACRO.
;585     ;
;586     ; VER 01.00     23-FEB-79       SCS
;587     ;
;588     ;       THIS VERSION REPRESENTS THE CHANGES TO MATCH THE HARDWARE CHANGES
;589     ;       TO BE IMPLEMENTED BEFORE MARCH 1,1979.
;590     ;
;591     ;       DP.SMALL AND XCHG.BIT FIELDS CREATED TO HELP EXCHANGE FUNCTION.
;592     ;       SCTL VALUES CHANGED.
;593     ;       JCTL VALUES CHANGED.
;594     ;       IFUNC VALUES CHANGED AND CREATION OF OPC.SPEC FIELD.
;595     ;       MISC.PORT FIELD CREATED.
;596     ;       MISC.1 AND MISC.2 VALUES CHANGED.
;597     ;       MISC.4 VALUES CREATED.
;598     ;       MEM.FUNC VALUES CHANGED.
;599     ;       CREATION OF MISC2[] MACRO AND UPDATE OF ALL MISCELLANEOUS MACROS.
;600     ;       RESHUFFLING OF CONTROL ROM TO MATCH HARDWARE CHANGES AND
;601     ;       ADDITION OF ENTRIES TO CONTROL ROM FOR NEW MACROS.
;602     ;
;603     ;       ADDITIONAL COMMENTS TO EXPLAIN OPERATION OF ALU CC'S FOR
;604     ;       ALL OPERATIONS.
;605     ;
```

```
;606     ;       ADDITION OF THE FOLLOWING MACROS:
;607     ;
;608     ;               XCHG
;609     ;               SWAP LS[] WITH WR[]
;610     ;               MOV MEM.DATA TO WR[] XCHG TO LS[]
;611     ;               SET.BACKUP.MASK.VALID
;612     ;               PRIORITY ENCODE WR0 R.TO.L TO 0S
;613     ;               PRIORITY ENCODE WR0 L.TO.R TO 0S
;614     ;
;615     ;       CONVERT ALL Q.WR[] MACROS TO WR[].Q
;616     ;       ADD TIMER ENTRY TO LOCAL STORE.
;617     ;
;618     ; VER 00.17     13-FEB-79       SCS
;619     ;
;620     ;       SWITCH READ CHECK AND WRITE CHECK FUNCTIONS FOR THE MEMORY.
;621     ;
;622     ; VER 00.16     12-FEB-79       SCS
;623     ;
;624     ;       CHANGED MDT VALUES TO CORRECT ONES.
;625     ;       CHANGE MEMORY FUNCTION VALUES TO MATCH HARDWARE.
;626     ;
;627     ; VER 00.15     31-JAN-79       SCS
;628     ;
;629     ;       SPLIT SOURCE OF DEF.MIC INTO THREE FILES:
;630     ;               DEFPREFIX.MIC
;631     ;               DEFDEF.MIC
;632     ;               DPCROM.MIC
;633     ;
;634     ;       ADD CORRECT VALUES AND NAMES OF ALL MEMORY FUNCTIONS.
;635     ;
;636     ; VER 00.14     29-JAN-79       SCS
;637     ;
;638     ;       UPDATE COMMENTS ABOUT PSL STATE.
;639     ;
;640     ; VER 00.13     15-JAN-79       SCS
;641     ;
;642     ;       ADD MACROS FOR RORC Q.WR[] AND ROLC Q.WR[]
;643     ;
;644     ; VER 00.12     12-JAN-79       SCS
;645     ;
;646     ;       FIX SHL2, ASHRC, ASHLC
;647     ;       DEFINED DEBUGGER LOCAL STORE LOCATIONS
;648     ;       DEFINED ALL MEMORY FUNCTION NAMES  (VALUES NOT FINAL)
;649     ;
;650     ;
;651     ; VER 00.00
;652     ;
;653     ;       INITIAL RELEASE TO LIBRARY
;654     ;
;655     ; VER 00.01
;656     ;
;657     ;       REDEFINE OPCODE BITS PER HARDWARE IMPLEMENTATION
;658     ;
;659     ; VER 00.02     19-SEPT-78
;660     ;
```

```
;661     ;       ADD MACROS FOR STATE REGISTER CONTROL
;662     ;       UPDATE SKIP CONTROL FIELD FOR NEW ITERATION CONTROL FUNCTIONS
;663     ;       ADD MISC FUNCTIONS FOR MASKING TP AND CONSOLE HALT
;664     ;       ADD MISC FUNCTION FOR MEMORY RESET
;665     ;       ASSIGN LOCAL STORE ADDRESS FOR SOFT PSL
;666     ;       ASSIGN MEMORY MANAGEMENT REGISTERS
;667     ;       ASSIGN EXTENDED TEMP LOCATIONS FOR STACK POINTERS CONTROL BLOCK BASE
;668     ;       ADD NEW CONSTANTS
;669     ;
;670     ; VER 00.03     22-SEPT-78
;671     ;
;672     ;       ADD EXTENDED B ADDRESS MACRO
;673     ;       ADD STATUS REGISTER NAMES
;674     ;       ADD ALTERNATE NAMES FOR CONSTANTS
;675     ;       FIX MISC [] MACRO
;676     ;       ADD CONSTANT 1F
;677     ;       ADD ABILITY TO SKIP ON BOTH POLARITIES OF THE STATE REGISTER
;678     ;
;679     ; VER 00.04     4-OCT-78
;680     ;
;681     ;       UPDATE 2901 CONTROL PER HARDWARE IMPLSPEC
;682     ;       ADD CS PARITY GENERATION
;683     ;       CHANGE ADDRESS OF MACRO PC IN LS
;684     ;       UPDATE SKIP AND JUMP CONTROL ASSIGNMENTS
;685     ;       ADD CONSTANTS
;686     ;       FIX XWR MOVES
;687     ;
;688     ; VER 00.05     11-OCT-78
;689     ;
;690     ;       REVISE SYNTAX FROM DESIGN REVIEW
;691     ;
;692     ; VER 00.06     13-OCT-78
;693     ;
;694     ;       FIX MEM.REQ MACRO
;695     ;       ADD XD CONSTANTS
;696     ;
;697     ; VER 00.07     16-OCT-78
;698     ;
;699     ;       FIX SCTL AND JCTL CODES FOR Z AND C BITS
;700     ;
;701     ; VER 00.08     20-OCT-78
;702     ;
;703     ;       ADD MEMORY FUNCTION FOR READ CONTROL REGISTER
;704     ;       FIX LOOP CONTROL MACRO FOR GEQU
;705     ;       ADD BACKUP GPR ADDRESSES
;706     ;       ADD CONSTANTS
;707     ;
;708     ; VER 00.09     27-OCT-78
;709     ;
;710     ;       UPDATE CONTROL FIELDS TO REFLECT NEW HARDWARE SPEC
;711     ;       ADD SHIFT FIELD CODES
;712     ;
;713     ; VER 00.10     20-DEC-78
;714     ;
;715     ; Add shift and rotate macros
```

```
;716     ; Change all CLR macros to "R.AND.S" from R.XNOR.S
;717     ;
;718     ; VER 00.11     4-JAN-79
;719     ;
;720     ; Eliminate redundant macros for shift & rotate
;721     ; Add MNEG WR[] WR[]
;722     ; Fill in gaps between groups of macros for ROM sake
;723     ;
;724     ;
;725     ;
```

```
;726     .PAGE
;727     .TOC    "FIELD DEFINITIONS FOR MAIN MICRO WORD                  VER 00.08"
;728     .SET/UPC=<000>
;729
;730     ; THE FOLLOWING EXPRESSIONS ARE VALIDITY CHECKS FOR FIELD COMBINATIONS
;731
;732     .SET/A.VAL=<.CASE[<OPC2/>]OF[0,0,0,0,1,1,0,0,0,0,0,0,0,0,0,0]>
;733     .SET/B.VAL=<.CASE[<OPC2/>]OF[0,0,0,0,1,1,1,1,1,1,1,1,1,1,1,1]>
;734     .SET/D.VAL=<.CASE[<OPC2/>]OF[0,0,0,1,0,0,0,0,1,1,1,1,1,1,1,1]>
;735     .SET/XD.VAL=<.EQL[<OPC1/>,<OPC1/MOVE>]>
;736     .SET/CC.VAL=<.CASE[<OPC2/>]OF[0,0,0,0,1,1,1,1,1,1,1,1,1,1,1,1]>
;737     .SET/DT.VAL=<.EQL[<OPC2/>,<OPC2/MEM.REQ>]>
;738     .SET/SCTL.VAL=<.CASE[<OPC2/>]OF[0,0,1,1,1,1,1,1,1,1,1,1,1,1,1,1]>
;739     .SET/JCTL.VAL=<.CASE[<OPC2/>]OF[1,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0]>
;740     .SET/JUMP.VAL=<.EQL[<OPC2/>,<OPC2/JUMP>]>
;741     .SET/DECODE.VAL=<.EQL[<OPC2/>,<OPC2/DECODE>]>
;742     .SET/MISC.VAL=<.EQL[<OPC2/>,<OPC2/MISC>]>
;743     .SET/DP.VAL=<.EQL[<OPC/>,<OPC/BASIC>]>
;744     ;
;745     ;       THE FOLLOWING VALIDITY CHECKS ARE USE FOR THE PAGE BOUNDARY PROBLEM.
;746     ;
;747     .SET/PAGE.PROB=<.EQL[<.AND[<7FF>,<.>]>,<7FE>]>
;748     .SET/SKIP.LEGAL2=<.OR[<.EQL[<SCTL/>,<SCTL/RET.NOERR>]>,<.EQL[<SCTL/>,
;749     <SCTL/POP.USTACK>]>]>
;750     .SET/SKIP.LEGAL=<.OR[<.EQL[<SCTL/>,<SCTL/NO.SKIP>]>,<.EQL[<SCTL/>,
;751     <SCTL/RETURN>]>,<.EQL[<SCTL/>,<SCTL/RETURN+1>]>,<SKIP.LEGAL2>]>
;752     .SET/SKIP.PAGE.VAL=<.CASE[<PAGE.PROB>]OF[1,<SKIP.LEGAL>]>
;753     .SET/JUMP.CHECK=<.OR[<.EQL[<JCTL/>,<JCTL/JSR>]>,<.EQL[<JCTL/>,
;754     <JCTL/JSR.VALID>]>]>
;755     .SET/JUMP.PAGE.VAL=<.CASE[<PAGE.PROB>]OF[1,<.XOR[1,<JUMP.CHECK>]>]>
;756
;757
;758     ; MICRO INSTRUCTION OPCODE DEFINITIONS
;759     ;
;760     OPC/=<22>,.DEFAULT=<OPC/BASIC>  ; MICRO OPCODE FIELD FOR SINGLE BIT OPCODE.
;761
;762             BASIC=1                 ; OPCODE FOR 'BASIC' MICRO INSTRUCTION
;763
;764     OPC1/=<22:20>                   ; MICRO OPCODE FIELD FOR THREE BIT OPCODES.
;765
;766             EXTENDED=2              ; OPCODE FOR 'EXTENDED' MICRO INSTRUCTION
;767             MOVE=3                  ; OPCODE FOR 'MOVE' MICRO INSTRUCTION
;768
;769     OPC2/=<22:19>                   ; MICRO OPCODE FIELD FOR FOUR BIT OPCODES
;770
;771             MEM.REQ=3               ; OPCODE FOR 'MEM.REQ' MICRO INSTRUCTION
;772             MISC=2                  ; OPCODE FOR 'MISC' MICRO INSTRUCTION
;773             JUMP=1                  ; OPCODE FOR 'JUMP' MICRO INSTRUCTION
;774             DECODE=0                ; OPCODE FOR 'DECODE' MICRO INSTRUCTION
;775
;776
;777     ; THE FOLLOWING FOUR FIELDS ARE RELATED TO ADDRESSING
;778     ; VARIOUS RAM MEMORIES WITHIN THE DATA PATH.
;779     ;
;780     ; THE A.ADRS  REFERS TO THE 2901 INTERNAL RAM 'A-PORT'
```

```
;781     ; THE B.ADRS  REFERS TO THE 2901 INTERNAL RAM 'B-PORT'
;782     ; THE XB.ADRS REFERS TO THE 2901 INTERNAL RAM 'B-PORT'
;783     ; THE D.ADRS  REFERS TO THE LOWER 128 LOCATIONS OF THE LOCAL STORE RAM
;784     ; THE XD.ADRS REFERS TO   ALL     256 LOCATIONS OF THE LOCAL STORE RAM
;785     ;
;786     ; THE VALIDITY STATEMENTS ALLOW USAGE OF THESE FIELDS IN THE FOLLOWING MANNER
;787     ;
;788     ;       A.ADRS          EXTENDED  MICRO INSTRUCTION
;789     ;
;790     ;       B.ADRS          BASIC     MICRO INSTRUCTION
;791     ;                       EXTENDED  MICRO INSTRUCTION
;792     ;                       MOVE      MICRO INSTRUCTION
;793     ;                       DECODE.IS MICRO INSTRUCTION
;794     ;
;795     ;       XB.ADRS         MOVE XWR  MICRO INSTRUCTION
;796     ;
;797     ;       D.ADRS          BASIC     MICRO INSTRUCTION
;798     ;                       MEM.REQ   MICRO INSTRUCTION
;799     ;
;800     ;       XD.ADRS         MOVE      MICRO INSTRUCTION
;801     ;
;802     A.ADRS/=<10:9>,.VALIDITY=<A.VAL>
;803
;804             MASK=3                  ; REGISTER BACKUP MASK
;805
;806     B.ADRS/=<8:7>,.VALIDITY=<B.VAL>,.DEFAULT=0
;807
;808             MASK=3                  ; REGISTER BACKUP MASK
;809
;810     ; THIS ADDRESS FIELD WILL CONTAIN THE LOW TWO BITS OF THE 2901 B ADDRESS
;811     ; THE THIRD BIT WILL BE FORCED BY HARDWARE.
;812     ;
;813     XB.ADRS/=<8:7>,.VALIDITY=<.EQL[<OPC1/>,<OPC1/MOVE>]>
;814
;815             BPC=0                   ; ADDRESS OF BEGINNING PC     WR[4]
;816             VA=1                    ; ADDRESS OF MEMORY REFERENCE WR[5]
;817             VAR=1                   ; ADDRESS OF LAST MEMORY REFERENCE. (WR[5] IN 2901).
;818
;819     ;D.ADRS/=<15:9>,.VALIDITY=<D.VAL>,.DEFAULT=0
;820
;821
;822     ;       SAVED.2ND.REQUEST=0     ; MM SAVED STATE FOR REQUEST.
;823     ;       T1=1                    ; TEMP LOCATION 1
;824     ;       T2=2                    ; TEMP LOCATION 2
;825     ;       T3=3                    ; TEMP LOCATION 3
;826     ;       T4=4                    ; TEMP LOCATION 4
;827     ;       T5=5                    ; TEMP LOCATION 5
;828     ;       T6=6                    ; TEMP LOCATION 6
;829     ;       T7=7                    ; TEMP LOCATION 7
;830     ;       T8=8                    ; TEMP LOCATION 8
;831     ;       T9=9                    ; TEMP LOCATION 9
;832     ;       T10=0A                  ; TEMP LOCATION 10
;833     ;       BACKUP.CM.PC=0A         ;COMPATIBILITY MODE KEEPS ORIGINAL PC HERE.
;834     ;
;835     ;       T11=0B                  ; TEMP LOCATION 11
```

```
;836     ;       T12=0C                  ; TEMP LOCATION 12
;837     ;       T13=0D                  ; TEMP LOCATION 13
;838     ;       T14=0E                  ; TEMP LOCATION 14
;839     ;       T15=0F                  ; TEMP LOCATION 15
;840     ;       PC=10                   ; MACRO PROGRAM COUNTER
;841     ;       WR.BACKUP=11            ; BACKUP WORKING REGISTER FOR MOV MEM.DATA TO WR[]
;842     ;       SAVED.VAR=12            ; MM SAVED STATE FOR VAR
;843     ;       SAVED.DATA=13           ; MM SAVED STATE FOR DATA
;844     ;       SAVED.PTE.ADDRESS=14    ; MM SAVED STATE FOR PAGE TABLE ENTRIES ADDRESS
;845     ;       SAVED.PTE=15            ; MM SAVED STATE FOR PAGE TABLE ENTRIES
;846     ;       T16=16                  ; TEMP LOCATION 16
;847     ;       T17=17                  ; TEMP LOCATION 17
;848     ;       IE.TEMP4=18             ; INTERRUPTS AND EXCEPTIONS TEMPORARY LOCATION FOUR.
;849     ;       #FFFFF000=19                    ; CONSTANT
;850     ;       #FFFFFF00=1A                    ; CONSTANT
;851     ;       #FFFFFFFC=1B                    ; CONSTANT
;852     ;       #FFFFFFFF=1C                    ; CONSTANT
;853     ;
;854     ;       THIS LOCATION CONTAINS THE SOFT COPY OF THE PSL.  WHENEVER THE
;855     ;       HARDWARE VERSION OF THE PSL IS CHANGED (PSL.HW), THEN THIS
;856     ;       CHANGE IS ALSO REPORTED HERE BY THE MICROCODE.  ALL BITS OF
;857     ;       THE PSL ARE REALLY LIKE THOSE IN THIS WORD EXCEPT FOR THE
;858     ;       CONDITION CODES WHICH MUST BE OBTAINED FROM PSL.CC
;859     ;
;860     ;       PSL=1D                  ; SOFT COPY OF VAX PSL
;861     ;       VAR=1E                  ; VIRTUAL ADDRESS REGISTER
;862     ;       VAR2=1F                 ; VIRTUAL ADDRESS REGISTER
;863     ;
;864     ;
;865     ;       #1=20                   ; MASK 00000001 (HEX)
;866     ;       #2=21                   ; MASK 00000002
;867     ;       #4=22                   ; MASK 00000004
;868     ;       #8=23                   ; MASK 00000008
;869     ;       #10=24                  ; MASK 00000010
;870     ;       #20=25                  ; MASK 00000020
;871     ;       #40=26                  ; MASK 00000040
;872     ;       #80=27                  ; MASK 00000080
;873     ;       #100=28                 ; MASK 00000100
;874     ;       #200=29                 ; MASK 00000200
;875     ;       #400=2A                 ; MASK 00000400
;876     ;       #800=2B                 ; MASK 00000800
;877     ;       #1000=2C                ; MASK 00001000
;878     ;       #2000=2D                ; MASK 00002000
;879     ;       #4000=2E                ; MASK 00004000
;880     ;       #8000=2F                ; MASK 00008000
;881     ;       #10000=30               ; MASK 00010000
;882     ;       #20000=31               ; MASK 00020000
;883     ;       #40000=32               ; MASK 00040000
;884     ;       #80000=33               ; MASK 00080000
;885     ;       #100000=34              ; MASK 00100000
;886     ;       #200000=35              ; MASK 00200000
;887     ;       #400000=36              ; MASK 00400000
;888     ;       #800000=37              ; MASK 00800000
;889     ;       #1000000=38             ; MASK 01000000
;890     ;       #2000000=39             ; MASK 02000000
```

```
;891     ;       #4000000=3A             ; MASK 04000000
;892     ;       #8000000=3B             ; MASK 08000000
;893     ;       #10000000=3C            ; MASK 10000000
;894     ;       #20000000=3D            ; MASK 20000000
;895     ;       #40000000=3E            ; MASK 40000000
;896     ;       #80000000=3F            ; MASK 80000000
;897     ;
;898     ;       BIT0=20                 ; MASK 00000001
;899     ;       BIT1=21                 ; MASK 00000002
;900     ;       BIT2=22                 ; MASK 00000004
;901     ;       BIT3=23                 ; MASK 00000008
;902     ;       BIT4=24                 ; MASK 00000010
;903     ;       BIT5=25                 ; MASK 00000020
;904     ;       BIT6=26                 ; MASK 00000040
;905     ;       BIT7=27                 ; MASK 00000080
;906     ;       BIT8=28                 ; MASK 00000100
;907     ;       BIT9=29                 ; MASK 00000200
;908     ;       BIT10=2A                ; MASK 00000400
;909     ;       BIT11=2B                ; MASK 00000800
;910     ;       BIT12=2C                ; MASK 00001000
;911     ;       BIT13=2D                ; MASK 00002000
;912     ;       BIT14=2E                ; MASK 00004000
;913     ;       BIT15=2F                ; MASK 00008000
;914     ;       BIT16=30                ; MASK 00010000
;915     ;       BIT17=31                ; MASK 00020000
;916     ;       BIT18=32                ; MASK 00040000
;917     ;       BIT19=33                ; MASK 00080000
;918     ;       BIT20=34                ; MASK 00100000
;919     ;       BIT21=35                ; MASK 00200000
;920     ;       BIT22=36                ; MASK 00400000
;921     ;       BIT23=37                ; MASK 00800000
;922     ;       BIT24=38                ; MASK 01000000
;923     ;       BIT25=39                ; MASK 02000000
;924     ;       BIT26=3A                ; MASK 04000000
;925     ;       BIT27=3B                ; MASK 08000000
;926     ;       BIT28=3C                ; MASK 10000000
;927     ;       BIT29=3D                ; MASK 20000000
;928     ;       BIT30=3E                ; MASK 40000000
;929     ;       BIT31=3F                ; MASK 80000000
;930     ;
;931     ;       GPR0=40                 ; GPR 0
;932     ;       GPR1=41                 ; GPR 1
;933     ;       GPR2=42                 ; GPR 2
;934     ;       GPR3=43                 ; GPR 3
;935     ;       GPR4=44                 ; GPR 4
;936     ;       GPR5=45                 ; GPR 5
;937     ;       GPR6=46                 ; GPR 6
;938     ;       CM.SP=46                ; IN COMPATIBILITY THIS IS THE STACK POINTER.
;939     ;       GPR7=47                 ; GPR 7
;940     ;       CM.PC=47                ; IN COMPATIBILITY MODE THIS IS THE PC.
;941     ;       GPR8=48                 ; GPR 8
;942     ;       GPR9=49                 ; GPR 9
;943     ;       GPR10=4A                ; GPR 10
;944     ;       GPR11=4B                ; GPR 11
;945     ;       GPR12=4C                ; GPR 12
```

```
;946     ;       AP=4C                   ; ARGUMENT POINTER
;947     ;       GPR13=4D                ; GPR 13
;948     ;       FP=4D                   ; FRAME POINTER
;949     ;       SP=4E                   ; GPR 14
;950     ;       T0=4F                   ; TEMP LOCATION 0
;951     ;
;952     ;       ZERO=50                 ; ZERO CONSTANT
;953     ;       #3=51           ; CONSTANT
;954     ;       #5=52           ; CONSTANT
;955     ;       #6=53           ; CONSTANT
;956     ;       #7=54           ; CONSTANT
;957     ;       #9=55           ; CONSTANT
;958     ;       #B=56           ; CONSTANT
;959     ;       #C=57           ; CONSTANT
;960     ;       #D=58           ; CONSTANT
;961     ;       #E=59           ; CONSTANT
;962     ;       #F=5A           ; CONSTANT
;963     ;       #13=5B          ; CONSTANT
;964     ;       #1F=5C          ; CONSTANT
;965     ;       #34=5D          ; CONSTANT
;966     ;       #3B=5E          ; CONSTANT
;967     ;       #3F=5F          ; CONSTANT
;968     ;       #4B=60          ; CONSTANT
;969     ;       #66=61          ; CONSTANT
;970     ;       #A0=62          ; CONSTANT
;971     ;       #F0=63          ; CONSTANT
;972     ;       #FF=64          ; CONSTANT
;973     ;       #1FF=65         ; CONSTANT
;974     ;       #FFF=66         ; CONSTANT
;975     ;       #2001=67                ; CONSTANT
;976     ;       #3000=68                ; CONSTANT
;977     ;       #7F80=69                ; CONSTANT
;978     ;       #C000=6A                ; CONSTANT
;979     ;       #FFE0=6B                ; CONSTANT
;980     ;       #FFFF=6C                ; CONSTANT
;981     ;       #1F0000=6D              ; CONSTANT
;982     ;       #200001=6E              ; CONSTANT
;983     ;       #F27000=6F              ; CONSTANT
;984     ;       #3000000=70             ; CONSTANT
;985     ;       #41F0000=71             ; CONSTANT
;986     ;       #7000000=72             ; CONSTANT
;987     ;       #3FFFFE00=73            ; CONSTANT
;988     ;       #7F800000=74            ; CONSTANT
;989     ;       #7FFFFE00=75            ; CONSTANT
;990     ;       #7FFFFF0E=76            ; CONSTANT
;991     ;       #BF800001=77            ; CONSTANT
;992     ;
;993     ;       GPR.OS=78               ; HARDWARE INDEX TO GPRS
;994     ;       BIT.OS(3-0)=79          ; 16 LOCATION HARDWARE INDEX TO BIT MASKS
;995     ;       BIT.OS(4-0)=7B          ; 32 LOCATION HARDWARE INDEX TO BIT MASKS
;996     ;       OS=7C                   ; OS REGISTER
;997     ;       DEC.CON=7D              ; DECIMAL CARRIES
;998     ;       SIZE=7E                 ; SIZE REGISTER
;999     ;       MDT= 7E                 ; MEMORY REFERENCE DATA SIZE
;1000    ;       INTERRUPT.VEC=7E        ; HARDWARE INTERRUPT VECTOR
```

```
;1001    ;
;1002    ;       THIS WORD IS THE HARDWARE CONDITION CODES.  THE CC'S CAN BE READ
;1003    ;       OR ARE WRITTEN HERE.  NO OTHER BITS IN THE PSL ARE EFFECTED.
;1004    ;
;1005    ;       PSL.CC=7F               ; PSL CONDITION CODES
;1006    ;
;1007    ;XD.ADRS/=<16:9>,.VALIDITY=<XD.VAL>
;1008    ;
;1009    ;       SAVED.2ND.REQUEST=0     ; MM SAVED STATE FOR REQUEST.
;1010    ;       T1=1                    ; TEMP LOCATION 1
;1011    ;       T2=2                    ; TEMP LOCATION 2
;1012    ;       T3=3                    ; TEMP LOCATION 3
;1013    ;       T4=4                    ; TEMP LOCATION 4
;1014    ;       T5=5                    ; TEMP LOCATION 5
;1015    ;       T6=6                    ; TEMP LOCATION 6
;1016    ;       T7=7                    ; TEMP LOCATION 7
;1017    ;       T8=8                    ; TEMP LOCATION 8
;1018    ;       T9=9                    ; TEMP LOCATION 9
;1019    ;       T10=0A                  ; TEMP LOCATION 10
;1020    ;       BACKUP.CM.PC=0A         ;COMPATIBILITY MODE KEEPS ORIGINAL PC HERE.
;1021    ;       T11=0B                  ; TEMP LOCATION 11
;1022    ;       T12=0C                  ; TEMP LOCATION 12
;1023    ;       T13=0D                  ; TEMP LOCATION 13
;1024    ;       T14=0E                  ; TEMP LOCATION 14
;1025    ;       T15=0F                  ; TEMP LOCATION 15
;1026    ;       PC=10                   ; MACRO INSTRUCTION PC
;1027    ;       WR.BACKUP=11            ; BACKUP WORKING REGISTER FOR MOV MEM.DATA TO WR[].
;1028    ;       SAVED.VAR=12            ; MM SAVED VAR LOCATION
;1029    ;       SAVED.DATA=13           ; MM SAVED DATA LOCATION
;1030    ;       SAVED.PTE.ADDRESS=14    ; MM SAVED PAGE TABLE ENTRY ADDRESS
;1031    ;       SAVED.PTE=15            ; MM SAVED PAGE TABLE ENTRY
;1032    ;       T16=16                  ; TEMP LOCATION 16
;1033    ;       T17=17                  ; TEMP LOCATION 17
;1034    ;       IE.TEMP4=18             ; INTERRUPTS AND EXCEPTIONS TEMPORARY LOCATION FOUR.
;1035    ;       #FFFFF000=19                    ; CONSTANT
;1036    ;       #FFFFFF00=1A                    ; CONSTANT
;1037    ;       #FFFFFFFC=1B                    ; CONSTANT
;1038    ;       #FFFFFFFF=1C                    ; CONSTANT
;1039    ;
;1040    ;       THIS LOCATION CONTAINS THE SOFT COPY OF THE PSL.  WHENEVER THE HARDWARE
;1041    ;       VERSION OF THE PSL IS CHANGED (PSL.HW) THEN THIS CHANGE IS
;1042    ;       REPORTED HERE.  ALL BITS OF THE PSL ARE REALLY LIKE THOSE HERE
;1043    ;       EXCEPT FOR THE CONDITION CODES WHICH MUST BE OBTAINED
;1044    ;       FROM PSL.CC.
;1045    ;
;1046    ;       PSL=1D                  ; SOFT COPY OF VAX PSL
;1047    ;       VAR=1E                  ; VIRTUAL ADDRESS REGISTER
;1048    ;       VAR2=1F                 ; VIRTUAL ADDRESS REGISTER
;1049    ;
;1050    ;
;1051    ;       #1=20                   ; MASK 00000001 (HEX)
;1052    ;       #2=21                   ; MASK 00000002
;1053    ;       #4=22                   ; MASK 00000004
;1054    ;       #8=23                   ; MASK 00000008
;1055    ;       #10=24                  ; MASK 00000010
```

```
;1056    ;       #20=25                  ; MASK 00000020
;1057    ;       #40=26                  ; MASK 00000040
;1058    ;       #80=27                  ; MASK 00000080
;1059    ;       #100=28                 ; MASK 00000100
;1060    ;       #200=29                 ; MASK 00000200
;1061    ;       #400=2A                 ; MASK 00000400
;1062    ;       #800=2B                 ; MASK 00000800
;1063    ;       #1000=2C                ; MASK 00001000
;1064    ;       #2000=2D                ; MASK 00002000
;1065    ;       #4000=2E                ; MASK 00004000
;1066    ;       #8000=2F                ; MASK 00008000
;1067    ;       #10000=30               ; MASK 00010000
;1068    ;       #20000=31               ; MASK 00020000
;1069    ;       #40000=32               ; MASK 00040000
;1070    ;       #80000=33               ; MASK 00080000
;1071    ;       #100000=34              ; MASK 00100000
;1072    ;       #200000=35              ; MASK 00200000
;1073    ;       #400000=36              ; MASK 00400000
;1074    ;       #800000=37              ; MASK 00800000
;1075    ;       #1000000=38             ; MASK 01000000
;1076    ;       #2000000=39             ; MASK 02000000
;1077    ;       #4000000=3A             ; MASK 04000000
;1078    ;       #8000000=3B             ; MASK 08000000
;1079    ;       #10000000=3C            ; MASK 10000000
;1080    ;       #20000000=3D            ; MASK 20000000
;1081    ;       #40000000=3E            ; MASK 40000000
;1082    ;       #80000000=3F            ; MASK 80000000
;1083    ;
;1084    ;       BIT0=20                 ; MASK 00000001
;1085    ;       BIT1=21                 ; MASK 00000002
;1086    ;       BIT2=22                 ; MASK 00000004
;1087    ;       BIT3=23                 ; MASK 00000008
;1088    ;       BIT4=24                 ; MASK 00000010
;1089    ;       BIT5=25                 ; MASK 00000020
;1090    ;       BIT6=26                 ; MASK 00000040
;1091    ;       BIT7=27                 ; MASK 00000080
;1092    ;       BIT8=28                 ; MASK 00000100
;1093    ;       BIT9=29                 ; MASK 00000200
;1094    ;       BIT10=2A                ; MASK 00000400
;1095    ;       BIT11=2B                ; MASK 00000800
;1096    ;       BIT12=2C                ; MASK 00001000
;1097    ;       BIT13=2D                ; MASK 00002000
;1098    ;       BIT14=2E                ; MASK 00004000
;1099    ;       BIT15=2F                ; MASK 00008000
;1100    ;       BIT16=30                ; MASK 00010000
;1101    ;       BIT17=31                ; MASK 00020000
;1102    ;       BIT18=32                ; MASK 00040000
;1103    ;       BIT19=33                ; MASK 00080000
;1104    ;       BIT20=34                ; MASK 00100000
;1105    ;       BIT21=35                ; MASK 00200000
;1106    ;       BIT22=36                ; MASK 00400000
;1107    ;       BIT23=37                ; MASK 00800000
;1108    ;       BIT24=38                ; MASK 01000000
;1109    ;       BIT25=39                ; MASK 02000000
;1110    ;       BIT26=3A                ; MASK 04000000
```

```
;1111    ;       BIT27=3B                ; MASK 08000000
;1112    ;       BIT28=3C                ; MASK 10000000
;1113    ;       BIT29=3D                ; MASK 20000000
;1114    ;       BIT30=3E                ; MASK 40000000
;1115    ;       BIT31=3F                ; MASK 80000000
;1116    ;
;1117    ;       GPR0=40                 ; GPR 0
;1118    ;       GPR1=41                 ; GPR 1
;1119    ;       GPR2=42                 ; GPR 2
;1120    ;       GPR3=43                 ; GPR 3
;1121    ;       GPR4=44                 ; GPR 4
;1122    ;       GPR5=45                 ; GPR 5
;1123    ;       GPR6=46                 ; GPR 6
;1124    ;       CM.SP=46                ; IN COMPATIBILITY MODE THIS IS THE STACK POINTER.
;1125    ;       GPR7=47                 ; GPR 7
;1126    ;       CM.PC=47                ; IN COMPATIBILITY MODE THIS IS THE PC.
;1127    ;       GPR8=48                 ; GPR 8
;1128    ;       GPR9=49                 ; GPR 9
;1129    ;       GPR10=4A                ; GPR 10
;1130    ;       GPR11=4B                ; GPR 11
;1131    ;       GPR12=4C                ; GPR 12
;1132    ;       AP=4C                   ; ARGUMENT POINTER
;1133    ;       GPR13=4D                ; GPR 13
;1134    ;       FP=4D                   ; FRAME POINTER
;1135    ;       SP=4E                   ; GPR 14
;1136    ;       T0=4F                   ; TEMP LOCATION 0
;1137    ;
;1138    ;       ZERO=50                 ; ZERO CONSTANT
;1139    ;       #3=51           ; CONSTANT
;1140    ;       #5=52           ; CONSTANT
;1141    ;       #6=53           ; CONSTANT
;1142    ;       #7=54           ; CONSTANT
;1143    ;       #9=55           ; CONSTANT
;1144    ;       #B=56           ; CONSTANT
;1145    ;       #C=57           ; CONSTANT
;1146    ;       #D=58           ; CONSTANT
;1147    ;       #E=59           ; CONSTANT
;1148    ;       #F=5A           ; CONSTANT
;1149    ;       #13=5B          ; CONSTANT
;1150    ;       #1F=5C          ; CONSTANT
;1151    ;       #34=5D          ; CONSTANT
;1152    ;       #3B=5E          ; CONSTANT
;1153    ;       #3F=5F          ; CONSTANT
;1154    ;       #4B=60          ; CONSTANT
;1155    ;       #66=61          ; CONSTANT
;1156    ;       #A0=62          ; CONSTANT
;1157    ;       #F0=63          ; CONSTANT
;1158    ;       #FF=64          ; CONSTANT
;1159    ;       #1FF=65         ; CONSTANT
;1160    ;       #FFF=66         ; CONSTANT
;1161    ;       #2001=67                ; CONSTANT
;1162    ;       #3000=68                ; CONSTANT
;1163    ;       #7F80=69                ; CONSTANT
;1164    ;       #C000=6A                ; CONSTANT
;1165    ;       #FFE0=6B                ; CONSTANT
```

```
;1166    ;       #FFFF=6C                ; CONSTANT
;1167    ;       #1F0000=6D              ; CONSTANT
;1168    ;       #200001=6E              ; CONSTANT
;1169    ;       #F27000=6F              ; CONSTANT
;1170    ;       #3000000=70             ; CONSTANT
;1171    ;       #41F0000=71             ; CONSTANT
;1172    ;       #7000000=72             ; CONSTANT
;1173    ;       #3FFFFE00=73            ; CONSTANT
;1174    ;       #7F800000=74            ; CONSTANT
;1175    ;       #7FFFFE00=75            ; CONSTANT
;1176    ;       #7FFFFF0E=76            ; CONSTANT
;1177    ;       #BF800001=77            ; CONSTANT
;1178    ;
;1179    ;       GPR.OS=78               ; HARDWARE INDEX TO GPRS
;1180    ;       BIT.OS(3-0)=79          ; 16 LOCATION HARDWARE INDEX TO BIT MASKS
;1181    ;       BIT.OS(4-0)=7B          ; 32 LOCATION HARDWARE INDEX TO BIT MASKS
;1182    ;       OS=7C                   ; OS REGISTER
;1183    ;       DEC.CON=7D              ; DECIMAL CARRIES
;1184    ;       SIZE=7E                 ; SIZE REGISTER
;1185    ;       MDT= 7E                 ; MEMORY REFERENCE DATA SIZE
;1186    ;       INTERRUPT.VEC=7E        ; HARDWARE INTERRUPT VECTOR
;1187    ;
;1188    ;       THIS LOCATION IS THE HARDWARE CONDITION CODES.  THE CC'S CAN BE
;1189    ;       READ OR ARE WRITTEN HERE.  NO OTHER BITS IN THE PSL ARE EFFECTED.
;1190    ;
;1191    ;       PSL.CC=7F               ; PSL CONDITION CODES
;1192
;1193    ; THESE ADDRESSES ARE ONLY ACCESSIBLE WITH THE MOV MICRO INSTRUCTION.
;1194
;1195    ;       KSP=80                  ; KERNEL STACK POINTER
;1196    ;       ESP=81                  ; EXECUTIVE STACK POINTER
;1197    ;       SSP=82                  ; SUPERVISOR STACK POINTER
;1198    ;       USP=83                  ; USER STACK POINTER
;1199    ;       ISP=84                  ; INTERRUPT STACK POINTER
;1200    ;       ASTLVL=85               ; AST LEVEL
;1201    ;       PCBB=86                 ; PROCESS CONTROL BLOCK BASE
;1202    ;       SCBB=87                 ; SYSTEM CONTROL BLOCK BASE
;1203    ;       SISR=88                 ; SOFTWARE INTERRUPT SUMMARY REGISTER
;1204    ;
;1205    ;       CONSOLE.COMMAND=89      ; ONE BYTE COMMAND.
;1206    ;       CONSOLE.MODIFIER=8A     ; ONE BYTE MODIFIER.
;1207    ;       CONSOLE.ADDRESS=8B      ; FOUR BYTES OF ADDRESS.
;1208    ;       CONSOLE.DATA=8C         ; FOUR BYTES OF DATA.
;1209    ;       CONSOLE.STATUS=8D       ; ONE BYTE OF STATUS.
;1210    ;       PSEUDO.NICR=8E          ; COPY OF NICR THAT 8085 HAS.
;1211    ;       PSEUDO.ICR=8F           ; COPY OF ICR THAT 8085 HAS.
;1212    ;       DEBUG.SAVE.WR0=90       ; TEMPORARY SAVE WR0.
;1213    ;       DEBUG.SAVE.WR1=91       ; TEMPORARY SAVE WR1.
;1214    ;       DEBUG.SAVE.ALU.CC=92    ; TEMPORARY SAVE CONDITION CODES.
;1215    ;       MEMORY.SIZE=93          ; MEMORY SIZE OF THE MACHINE.
;1216    ;       CRD.LOG=94              ; INFORMATION ABOUT LAST SOFT MEMORY ERROR.
;1217    ;       PACKET.A=95             ; TOP OF PACKET.
;1218    ;       PACKET.B=96             ; BOTTOM OF PACKET.
;1219    ;       DEBUG.SAVE.ADDRESS=97   ; ADDRESS FOR EXAMINE/DEPOSIT.
;1220    ;
```

```
;1221    ;       SAVED.MDT=99            ; SAVED ADDRESS OF MDT FOR MMIE OPTIMIZATION.
;1222    ;       P0BR=9A                 ; P0 BASE REGISTER
;1223    ;       P0LR=9B                 ; P0 LENGTH REGISTER
;1224    ;       P1BR=9C                 ; P1 BASE REGISTER
;1225    ;       P1LR=9D                 ; P1 LENGTH REGISTER
;1226    ;       SBR=9E                  ; SYSTEM BASE REGISTER
;1227    ;       SLR=9F                  ; SYSTEM LENGTH REGISTER
;1228    ;
;1229    ;       PORT0=0A0       ; RESERVED FOR PORT.
;1230    ;       PORT1=0A1       ; RESERVED FOR PORT.
;1231    ;       PORT2=0A2       ; RESERVED FOR PORT.
;1232    ;       PORT3=0A3       ; RESERVED FOR PORT.
;1233    ;       PORT4=0A4       ; RESERVED FOR PORT.
;1234    ;       PORT5=0A5       ; RESERVED FOR PORT.
;1235    ;       PORT6=0A6       ; RESERVED FOR PORT.
;1236    ;       PORT7=0A7       ; RESERVED FOR PORT.
;1237    ;       PORT8=0A8       ; RESERVED FOR PORT.
;1238    ;       PORT9=0A9       ; RESERVED FOR PORT.
;1239    ;       PORT10=0AA      ; RESERVED FOR PORT.
;1240    ;       PORT11=0AB      ; RESERVED FOR PORT.
;1241    ;       PORT12=0AC      ; RESERVED FOR PORT.
;1242    ;       PORT13=0AD      ; RESERVED FOR PORT.
;1243    ;       PORT14=0AE      ; RESERVED FOR PORT.
;1244    ;       PORT15=0AF      ; RESERVED FOR PORT.
;1245    ;       PORT16=0B0      ; RESERVED FOR PORT.
;1246    ;       PORT17=0B1      ; RESERVED FOR PORT.
;1247    ;       PORT18=0B2      ; RESERVED FOR PORT.
;1248    ;       PORT19=0B3      ; RESERVED FOR PORT.
;1249    ;       PORT20=0B4      ; RESERVED FOR PORT.
;1250    ;       PORT21=0B5      ; RESERVED FOR PORT.
;1251    ;       PORT22=0B6      ; RESERVED FOR PORT.
;1252    ;       PORT23=0B7      ; RESERVED FOR PORT.
;1253    ;       PORT24=0B8      ; RESERVED FOR PORT.
;1254    ;       PORT25=0B9      ; RESERVED FOR PORT.
;1255    ;       PORT26=0BA      ; RESERVED FOR PORT.
;1256    ;       PORT27=0BB      ; RESERVED FOR PORT.
;1257    ;       PORT28=0BC      ; RESERVED FOR PORT.
;1258    ;       PORT29=0BD      ; RESERVED FOR PORT.
;1259    ;       PORT30=0BE      ; RESERVED FOR PORT.
;1260    ;       PORT31=0BF      ; RESERVED FOR PORT.
;1261    ;
;1262    ;       XGPR0=0C0               ; BACKUP COPY OF GPR 0
;1263    ;       XGPR1=0C1               ; BACKUP COPY OF GPR 1
;1264    ;       XGPR2=0C2               ; BACKUP COPY OF GPR 2
;1265    ;       XGPR3=0C3               ; BACKUP COPY OF GPR 3
;1266    ;       XGPR4=0C4               ; BACKUP COPY OF GPR 4
;1267    ;       XGPR5=0C5               ; BACKUP COPY OF GPR 5
;1268    ;       XGPR6=0C6               ; BACKUP COPY OF GPR 6
;1269    ;       XGPR7=0C7               ; BACKUP COPY OF GPR 7
;1270    ;       XGPR8=0C8               ; BACKUP COPY OF GPR 8
;1271    ;       XGPR9=0C9               ; BACKUP COPY OF GPR 9
;1272    ;       XGPR10=0CA              ; BACKUP COPY OF GPR 10
;1273    ;       XGPR11=0CB              ; BACKUP COPY OF GPR 11
;1274    ;       XGPR12=0CC              ; BACKUP COPY OF GPR 12
;1275    ;       XGPR13=0CD              ; BACKUP COPY OF GPR 13
```

```
;1276    ;       XSP=0CE                 ; BACKUP COPY OF GPR 14
;1277    ;
;1278    ;       #14=0D0                 ; CONSTANT
;1279    ;       #18=0D1                 ; CONSTANT
;1280    ;       #1C=0D2                 ; CONSTANT
;1281    ;       #24=0D3                 ; CONSTANT
;1282    ;       #28=0D4                 ; CONSTANT
;1283    ;       #2C=0D5                 ; CONSTANT
;1284    ;       #2D=0D6                 ; CONSTANT
;1285    ;       #30=0D7                 ; CONSTANT
;1286    ;       #F8=0D8                 ; CONSTANT
;1287    ;       #FC=0D9                 ; CONSTANT
;1288    ;       #2D20=0DA                       ; CONSTANT
;1289    ;       #140000=0DB                     ; CONSTANT
;1290    ;       #150000=0DC                     ; CONSTANT
;1291    ;       #160000=0DD                     ; CONSTANT
;1292    ;       #170000=0DE                     ; CONSTANT
;1293    ;       #180000=0DF                     ; CONSTANT
;1294    ;       #1E0000=0E0                     ; CONSTANT
;1295    ;       #40A10=0E1                      ; CONSTANT
;1296    ;       #C0000E0=0E2                    ; CONSTANT
;1297    ;       #0FFF0000=0E3                   ; CONSTANT
;1298    ;       #B020FF00=0E4                   ; CONSTANT
;1299    ;       #FFFFFF10=0E5                   ; CONSTANT
;1300    ;       DEBUG.SAVE.T1=0E6       ; TEMPORARY SAVE T1.
;1301    ;       DEBUG.SAVE.OS=0E7       ; TEMPORARY SAVE OS.
;1302    ;       DEBUG.SAVE.SIZE=0E8     ; TEMPORARY SAVE SIZE VALUE.
;1303    ;       SAVED.WR0=0E9           ; MM SAVED WR0
;1304    ;       SAVED.WR1=0EA           ; MM SAVED WR1
;1305    ;       SAVED.2ND.VAR=0EB       ; MM SAVED VAR 2
;1306    ;       SAVED.ALU.CC=0EC                ; MM SAVED ALU CONDITION CODES
;1307    ;       SAVED.SIZE=0ED          ; MM SAVED LS[SIZE]
;1308    ;       SAVED.OS=0EE            ; MM SAVED LS[OS]
;1309    ;       SAVED.REQUEST=0EF       ; MM SAVED REQUEST DATA
;1310    ;       SAVED.CRD.LOG=0F0       ; MM SAVED LOCATION
;1311    ;       OS.BAK=0F1              ; USED BY WARM FLOATING POINT.
;1312    ;
;1313    ;       THIS LOCATION IS FOR USE BY THE MFPR AND MTPR TO THE CONSOLE AND
;1314    ;       TU58 CSR'S.  ALL OF THE INTERRUPT ENABLE BITS ARE HEREIN.
;1315    ;
;1316    ;       CONSOLE/PROGRAM I/O MODE FLAG - BIT<31> 0 - CONSOLE 1 - PROGRAM I/O MODE
;1317
;1318    ;       CRD RETRY IN PROGRESS - BIT<5>  0 - NOTHING DOING 1 - IN PROGRESS
;1319    ;       MACHINE CHECK IN PROGRESS - BIT<4>
;1320    ;       TU58 TRANSMIT CSR IE - BIT<3>
;1321    ;       TU58 RECEIVER CSR IE - BIT<2>
;1322    ;       CONSOLE TRANSMIT CSR IE - BIT<1>
;1323    ;       CONSOLE TRANSMIT CSR IE - BIT<0>
;1324    ;
;1325    ;       CONSOLE.CSR.IES=0F2     ; CONSOLE CSR IE'S AND CONSOLE/PROGRAM I/O MODE FLAG.
;1326    ;       IE.TEMP1=0F3            ; INTERRUPTS AND EXCEPTIONS TEMPORARY LOCATION ONE
;1327    ;       IE.TEMP2=0F4            ; INTERRUPTS AND EXCEPTIONS TEMPORARY LOCATION TWO
;1328    ;       IE.TEMP3=0F5            ; INTERRUPTS AND EXCEPTIONS TEMPORARY LOCATION THREE
;1329    ;
;1330    ;       XGPR.OS=0F8             ; HARDWARE INDEX TO XGPRS
```

```
;1331    ;       PORT(3-0)=0F9           ; 16 LOCATION HARDWARE INDEX TO PORT REGISTERS.
;1332    ;       PORT(4-0)=0FB           ; 32 LOCATION HARDWARE INDEX TO PORT REGISTERS.
;1333    ;       CCR=0FC                 ; CONSOLE READ REGISTER
;1334    ;       TIMER=0FD               ; INTERVAL TIMER VALUE.
;1335    ;       ALU.CC=0FE              ; ALU CONDITION CODES
;1336    ;
;1337    ;       THIS LOCATION IS A WRITE ONLY REGISTER.  THE FOLLOWING BITS IN THE
;1338    ;       PSL ARE AFFECTED:
;1339    ;
;1340    ;       COMPATIBILITY MODE - BIT<31>
;1341    ;       CURRENT MODE - BITS<25:24>
;1342    ;       INTERRUPT PRIORITY LEVEL (IPL) - BITS<20:16>
;1343    ;       TRACE TRAP ENABLE (REALLY T OR TP) - BIT<4>
;1344    ;       NEGATIVE CONDITION CODE - BIT<3>
;1345    ;       ZERO CONDITION CODE - BIT<2>
;1346    ;       OVERFLOW CONDITION CODE - BIT<1>
;1347    ;       CARRY CONDITION CODE - BIT<0>
;1348    ;
;1349    ;       PSL.HW=0FF              ; HARDWARE PSL BITS
;1350
;1351
;1352    ; DATA PATH CONTROL
;1353    ;
;1354    ; THIS FIELD IS BUILT FROM AN ADDRESS IN THE CCODE MEMORY.  THE CCODE MEMORY
;1355    ; CONTAINS DATA PATH MICRO INSTRUCTIONS TO PRODUCE THE DESIRED OPERATION
;1356    ; FOR THE UCODE MACROS.
;1357
;1358    ; DATA PATH CONTROL FIELD FOR THE 'BASIC' MICRO INSTRUCTION
;1359    ;
;1360    DP/=<21:16>,.VALIDITY=<DP.VAL>,.DEFAULT=<.SHIFT[.AND[<SDP/Q.CMP.LS>,0FF],-2]>
;1361    ;
;1362    ; THIS FIELD IS ONLY USED WITH THE INSTRUCTIONS WHICH CAN HAVE
;1363    ; XCHG ATTACHED.
;1364    ;
;1365    DP.SMALL/=<20:16>,.VALIDITY=<DP.VAL>
;1366    ;
;1367    ; EXCHANGE ORIGINAL WR TO LS
;1368    ;
;1369    XCHG.BIT/=<21>,.DEFAULT=<0>
;1370
;1371            YES=1
;1372            NO=0
;1373
;1374    ; DATA PATH CONTROL FIELD FOR  THE 'EXTENDED' MICRO INSTRUCTION
;1375    ;
;1376    XDP/=<19:14>,.VALIDITY=<A.VAL>
;1377
;1378    ; DATA PATH CONTROL FOR THE 'MOVE' MICRO INSTRUCTION
;1379    ;
;1380    MDP/=<19:17>,.VALIDITY=<XD.VAL>
;1381
```

```
;1382    .PAGE
;1383    ; CONDITION CODE FIELD / DATA PATH CONTEXT
;1384    ;
;1385    CC/=<6:5>,.VALIDITY=<CC.VAL>,.DEFAULT=<CC/DT(LONG)&HOLD.ALU.CC>
;1386
;1387            DT(LONG)&HOLD.ALU.CC=0          ; USE LONG CONTEXT(32 BITS) AND HOLD ALU CONDITION CODES
;1388            DT(LONG)&SET.ALU.CC=1           ; USE LONG CONTEXT(32 BITS) AND  SET ALU CONDITION CODES
;1389            DT(SIZE)&SET.ALU.CC=2           ; USE CONTEXT IN THE SIZE REGISTER AND SET ALU CONDITION CODES
;1390            DT(SIZE)&MAP.ALU.CC.TO.PSL=3    ; TRANSFER ALU CONDITION CODES TO PSL CONDITION CODES HARDWARE DEPENDENT
;1391
;1392
;1393    ; MEMORY DATA TYPE FIELD
;1394    ;
;1395    MDT/=<6:5>,.VALIDITY=<DT.VAL>
;1396
;1397            BYTE=0                  ; SIZE = BYTE
;1398            WORD=1                  ; SIZE = WORD
;1399            SIZE=2                  ; SIZE = CONTENTS OF SIZE REGISTER
;1400            LONG=3                  ; SIZE = LONG
;1401
;1402
;1403    ; SHIFT INPUT FIELD
;1404    ;
;1405    ; THIS CONTROL FIELD DETERMINES THE SHIFT INPUTS FOR THE FOLLOWING OPERATIONS.
;1406    ; THE DIRECTION OF THE SHIFT IS DETERMINED BY THE 2901 DESTINATION CODE.
;1407    ;
;1408    SI/=<13:11>,.VALIDITY=<A.VAL>
;1409
;1410            ROT.WR=0                ; ROTATE WR
;1411            ROT.WR.Q=1              ; ROTATE WR AND Q
;1412            ASH.WR=2                ; ARITHMETIC SHIFT OF WR
;1413            ASH.WR.Q=3              ; ARITHMETIC SHIFT OF WR AND Q
;1414            MUL.SHF=4               ; SIGNED MULTIPLY SHIFT OPERATION
;1415            UMUL.SHF=5              ; UNSIGNED MULTIPLY SHIFT OPERATION
;1416            SHF.WR.Q=6              ; LOGICAL SHIFT WR AND Q
;1417
;1418
;1419    ; SKIP MICRO CONTROL FIELD
;1420    ;
;1421    ; THIS FIELD IS VALID FOR ALL INSTRUCTIONS EXCEPT
;1422    ;
;1423    ;               JUMP   MICRO INSTRUCTION
;1424    ;               DECODE MICRO INSTRUCTION
;1425    ;
;1426    SCTL/=<4:0>,.VALIDITY=<.AND[<SCTL.VAL>,<SKIP.PAGE.VAL>]>,.DEFAULT=<SCTL/NO.SKIP>
;1427
;1428            N.CLR=0                 ; ALU N-BIT EQUAL ZERO
;1429            NEQ=1                   ; ALU Z-BIT EQUAL ZERO
;1430            BIT.SET=1               ; ALU Z-BIT EQUAL ZERO
;1431            V.CLR=2                 ; ALU V-BIT EQUAL ZERO
;1432            C.SET=3                 ; ALU C-BIT EQUAL ONE
;1433            GEQU=3                  ; ALU C-BIT EQUAL ONE
;1434            NOT.PSL.C=4             ; PSL C EQUAL ZERO
;1435            BR.FALSE=5              ; BRANCH INSTRUCTION FALSE
;1436            R.DST=6                 ; REGISTER MODE FLAG
```

```
;1437            NO.INTERRUPT=7          ; NO INTERRUPT PENDING
;1438            N.SET=8                 ; ALU N-BIT EQUAL ONE
;1439            EQL=9                   ; ALU Z-BIT EQUAL ONE
;1440            BITS.CLR=9              ; ALU Z-BIT EQUAL ONE
;1441            V.SET=0A                ; ALU V-BIT EQUAL ONE
;1442            C.CLR=0B                ; ALU C-BIT EQUAL ZERO
;1443            LSSU=0B                 ; ALU C-BIT EQUAL ZERO
;1444            STATE.ZERO.SET=0C       ; STATE REGISTER BIT ZERO TRUE
;1445            STATE.ONE.SET=0D        ; STATE REGISTER BIT ONE TRUE
;1446            STATE.ZERO.CLR=0E       ; STATE REGISTER BIT ZERO FALSE
;1447            STATE.ONE.CLR=0F        ; STATE REGISTER BIT ONE FALSE
;1448            RET.NOERR=10            ; RETURN+1 IF NO MEMORY ERROR
;1449            JMP.Z.CLR=11            ; JUMP TO (STACK) IF ALU Z = 0
;1450            POP.USTACK=12           ; DISCARD TOP STACK ENTRY
;1451            JMP.C.SET=13            ; JUMP TO (STACK) IF ALU C=1
;1452            RETURN=14               ; RETURN TO (USTACK)
;1453            NO.SKIP=15              ; EXECUTE NEXT INSTRUCTION
;1454            RETURN+1=16             ; RETURN TO (USTACK)+1
;1455            LOOP.IF.NO.I.AND.SYNC=17; JUMP TO (STACK) IF NO INTERRUPT AND NO ACCELERATOR SYNC.
;1456            CONSOLE.ATTN=18         ; CONSOLE ATTENTION
;1457            CONSOLE.ACK=19          ; CONSOLE ACKNOWLEDGE
;1458            NO.FAST.INTERRUPT=1A    ; NO FAST INTERRUPTS PENDING
;1459            BACKUP.MASK.VALID=1B    ; REGISTER BACKUP MASK VALID.
;1460            LSS=1C                  ; SIGNED LESS THAN.
;1461            MEM.REF.OK=1D           ; NO MEMORY ERROR TRUE
;1462            SKIP=1E                 ; EXECUTE ADDRESS PLUS ONE
;1463            SYNC=1F                 ; ACCELERATOR SYNCHRONIZATION
;1464
;1465
;1466    ; JUMP MICRO CONTROL FIELD
;1467    ;
;1468    ; THIS FIELD IS VALID FOR THE FOLLOWING INSTRUCTIONS
;1469    ;
;1470    ;               JUMP    MICRO INSTRUCTION
;1471    ;               DECODE  MICRO INSTRUCTION
;1472    ;
;1473    JCTL/=<3:0>,.VALIDITY=<.AND[<JCTL.VAL>,<JUMP.PAGE.VAL>]>,.DEFAULT=<JCTL/JUMP.VALID>
;1474
;1475            N.CLR=0                 ; ALU N-BIT EQUAL ZERO
;1476            NEQ=1                   ; ALU Z-BIT EQUAL ZERO
;1477            BIT.SET=1               ; ALU Z-BIT EQUAL ZERO
;1478            V.CLR=2                 ; ALU V-BIT EQUAL ZERO
;1479            C.SET=3                 ; ALU C-BIT EQUAL ONE
;1480            GEQU=3                  ; ALU C-BIT EQUAL ONE
;1481            JUMP=4                  ; JUMP UNCONDITIONALLY
;1482            BR.FALSE=5              ; BRANCH INSTRUCTION FALSE
;1483            R.DST=6                 ; REGISTER MODE FLAG
;1484            NO.INTERRUPT=7          ; NO INTERRUPT PENDING
;1485            N.SET=8                 ; ALU N-BIT EQUAL ONE
;1486            EQL=9                   ; ALU Z-BIT EQUAL ONE
;1487            BITS.CLR=9              ; ALU Z-BIT EQUAL ONE
;1488            V.SET=0A                ; ALU V-BIT EQUAL ONE
;1489            C.CLR=0B                ; ALU C-BIT EQUAL ZERO
;1490            LSSU=0B                 ; ALU C-BIT EQUAL ZERO
;1491            JSR=0C                  ; UNCONDITIONAL JUMP AND PUSH USTACK
```

```
;1492            JSR.VALID=0D            ; JUMP AND PUSH USTACK IF IB VALID=1
;1493            NO.JUMP.TST=0E          ; DO NOT JUMP AND SKIP IF IB VALID=0
;1494            JUMP.VALID=0F           ; JUMP IF IB VALID=1
;1495
;1496
;1497    ; JUMP ADDRESS FIELD
;1498    ;
;1499    JUMP.ADRS/=<17:4>,.ADDRESS,.VALIDITY=<JUMP.VAL>
;1500
;1501
;1502    ; OS ENABLE
;1503    ;
;1504    OS/=<18>,.VALIDITY=<JUMP.VAL>
;1505
;1506            NOP=0
;1507            WITH.OS=1               ; CONCATENATE OS REGISTER TO JUMP ADDRESS
;1508
;1509
```

```
;1510    .PAGE
;1511    ; BACKUP PC
;1512    ;
;1513    BPC/=<18>,.VALIDITY=<DECODE.VAL>,.DEFAULT=<.CASE[<.EQL[<OPC2/>,<OPC2/DECODE>]>]OF[0,1]>
;1514
;1515            NOP=1
;1516            SAVE.PC=0               ; WRITE ALU DATA INTO WR[B]   (PC+1)
;1517
;1518
;1519    ; DECODE ADDRESS FIELD
;1520    ;
;1521    DEC.ADRS/=<17:12>,.VALIDITY=<DECODE.VAL>
;1522
;1523
;1524    ; IR FUNCTION
;1525    ;
;1526    IFUNC/=<11:9>,.VALIDITY=<DECODE.VAL>
;1527
;1528            CM.EXEC=0               ; COMPATIBILITY MODE EXECUTION DISPATCH WHEN UPPER BYTE = ZERO
;1529            SPEC=0                  ; SPECIFIER DISPATCH
;1530            CM.IRD=1                ; COMPATIBILITY MODE INSTRUCTION DECODE DISPATCH
;1531            FLOAT=1                 ; SPECIFIER FLOAT TYPE DISPATCH
;1532            VAX.EXEC=2              ; VAX EXECUTION DISPATCH
;1533            ASRC=2                  ; ADDRESS SPECIFIER DISPATCH
;1534            VAX.IRD=3               ; VAX OPCODE DISPATCH
;1535            VSRC=4                  ; ADDRESS SPECIFIER DISPATCH FOR BIT FIELD INSTRUCTIONS
;1536            ESRC=5                  ; SPECIFIER DISPATCH IN INDEX MODE
;1537            CM.DST=6                ; COMPATIBILITY MODE DESTINATION DISPATCH
;1538            CM.SINGLE=7             ; COMPATIBILITY MODE SOP DISPATCH
;1539
;1540
;1541    ; INSTRUCTION BUFFER REQUEST
;1542    ;
;1543    IB.REQ/=<8>,.VALIDITY=<DECODE.VAL>,.DEFAULT=0
;1544
;1545            NOP=0
;1546            IB.REQ=1                ; ENABLE HARDWARE DEPENDENT MEMORY REQUEST
;1547    ;
;1548    ; COMPATIBILITY MODE OPCODE SELECT
;1549    ;
;1550    CM.HI/=<7>,.VALIDITY=<DECODE.VAL>,.DEFAULT=0
;1551
;1552            LOW.BYTE=0              ; DECODE IR BITS<7:0>
;1553            HI.BYTE=1               ; DECODE IR BITS <15:6>
;1554
;1555
;1556    ; LOAD OS REGISTER
;1557    ;
;1558    LD.OS/=<6>,.VALIDITY=<DECODE.VAL>,.DEFAULT=0
;1559
;1560            NOP=0
;1561            LOAD.OS=1               ; LOAD OS REGISTER FROM I-BUFFER
;1562
;1563
;1564    ; REGISTER DESTINATION FLAG ENABLE
```

```
;1565    ;
;1566    R.DST/=<5>,.VALIDITY=<DECODE.VAL>,.DEFAULT=0
;1567
;1568            NOP=0
;1569            ENAB=1
;1570    ;
;1571    ; OPCODE SPECIFIER BIT
;1572    ;
;1573    OPC.SPEC/=<4>,.VALIDITY=<DECODE.VAL>
;1574
;1575            CM.EXEC=1               ; COMPATIBILITY MODE EXECUTION DISPATCH
;1576            SPEC=0                  ; SPECIFIER DISPATCH
;1577            CM.IRD=1                ; COMPATIBILITY MODE INSTRUCTION DECODE DISPATCH
;1578            FLOAT=0                 ; SPECIFIER FLOAT TYPE DISPATCH
;1579            VAX.EXEC=1              ; VAX EXECUTION DISPATCH
;1580            ASRC=0                  ; ADDRESS SPECIFIER DISPATCH
;1581            VAX.IRD=1               ; VAX OPCODE DISPATCH
;1582            VSRC=0                  ; ADDRESS SPECIFIER DISPATCH FOR BIT FIELD INSTRUCTIONS
;1583            ESRC=0                  ; SPECIFIER DISPATCH IN INDEX MODE
;1584            CM.DST=0                ; COMPATIBILITY MODE DESTINATION DISPATCH
;1585            CM.SINGLE=0             ; COMPATIBILITY MODE SOP DISPATCH
```

```
;1586    .PAGE
;1587    ; MISCELLANEOUS FUNCTIONS
;1588    ;
;1589    ;
;1590    ; THIS FIELD IS A FLAG FOR STEERING THE MICROWORD AS A MISCELLANEOUS
;1591    ; INSTRUCTION OR AS A PORT INSTRUCTION.
;1592    ;
;1593    MISC.PORT/=<18>
;1594
;1595            MISC=0
;1596            PORT=1
;1597
;1598    MISC.0/=<17>,.VALIDITY=<MISC.VAL>
;1599
;1600            NOP=0                       ; NO OPERATION IN ALU OR CONDITION CODES.
;1601
;1602    MISC.1/=<15:12>,.VALIDITY=<MISC.VAL>
;1603
;1604            NOP=0F                      ; NO OPERATION
;1605            SET.CP.ATTN=0E              ; SET CPU ATTENTION FOR CONSOLE
;1606            SET.CP.ACK=0D               ; SET CPU ACKNOWLEDGE FOR CONSOLE
;1607            CLR.CP.ATTN.AND.ACK=0C      ; CLEAR CPU ATTENTION AND CPU ACKNOWLEDGE
;1608            SET.HIGH.PAGE=0B            ; SET BIT FOR HIGH HALF OF WCS.
;1609            CLR.HIGH.PAGE=0A            ; CLEAR BIT FOR LOW HALF OF WCS.
;1610            SET.PORT.I.O=9              ; SET PORT I/O MODE
;1611            SET.ACC.I.O=8               ; SET ACCELERATOR I/O MODE
;1612            SET.BACKUP.MASK.VALID=7     ; SET REGISTER BACKUP MASK FLAG
;1613            SET.S1=6                    ; SET STATE ONE BIT
;1614            SET.S0=5                    ; SET STATE ZERO BIT
;1615            CLR.S1=4                    ; CLEAR STATE ONE BIT
;1616            CLR.S0=3                    ; CLEAR STATE ZERO BIT
;1617            SET.S1&CLR.S0=2             ; SET STATE ONE BIT AND CLEAR STATE ZERO BIT
;1618            CLR.S1&SET.S0=1             ; CLEAR STATE ONE AND SET STATE ZERO
;1619            CLR=0                       ; CLEAR STATE ONE AND STATE ZERO BITS.
;1620
;1621
;1622    MISC.2/=<11:9>,.VALIDITY=<MISC.VAL>
;1623
;1624            NOP=0                       ; NO OPERATION
;1625            MASK.INTERRUPTS=1           ; MASK ALL INTERRUPTS (FOR DECODE NEXT CYCLE).
;1626            ASSERT.DA.AND.PASS.WR=2;    ASSERT DATA AVAILABLE AND PASS WR[0] TO THE ACCELERATOR OR PORT.
;1627            TRAP.ACC=3                  ; TRAP ACCELERATOR
;1628            READ.ACC.UPC=4              ; READ ACCELERATOR PROGRAM COUNTER
;1629            TRANSFER.GRANT=5            ; RECOGNIZE PORT REQUEST.
;1630            MASK.HALT.AND.T.BIT=6       ; MASK HALT AND T-BIT TRAPS (FOR DECODE TWO CYCLES LATER)
;1631            WRITE.WR.TO.CONSOLE.REGISTER=7  ; SEND BITS <7:0> TO 8085.
;1632
;1633    MISC.WR/=<8:7>
;1634
;1635    MISC.WRL/=<8>
;1636    MISC.WRR/=<7>
;1637
;1638    PORT.SELECT/=<17:15>
;1639
;1640            IDC=7
```

```
;1641
;1642    PORT.FUNC/=<14:13>
;1643
;1644            READ=0
;1645            WRITE=1
;1646            CONTROL=2
;1647
;1648    R.W.FUNC/=<12:10>
;1649
;1650            CSR=0
;1651            DAR=1
;1652            DATA.BYTE=2
;1653            DATA.WORD=3
;1654            PATTERN=4
;1655            POSITION=5
;1656
;1657    CNTL.FUNC/=<12:10>
;1658
;1659            CLEAR.FIFO.CNTR=0
;1660            RESET.BR=1
;1661            CLEAR.IDC=3
;1662            SET.AUTO=4
;1663            CLEAR.AUTO=5
;1664            SEL.FIFO.A=6
;1665            SEL.FIFO.B=7
;1666
```

```
;1667    .PAGE
;1668    ; MEMORY REQUEST FIELD
;1669    ;
;1670    ; THIS FIELD IS USED TO INDICATE THE DESIRED OPERATION TO THE MEMORY CONTROL.
;1671    ; NOTE THAT THIS IS A DUMMY FIELD. IT IS ACTUALLY MADE UP OF TWO FIELDS.
;1672    ; M.FUNC1 AND M.FUNC2
;1673    ;
;1674    ; THE FOLLOWING SPECIAL CONSIDERATIONS MUST BE MADE:
;1675    ;
;1676    ; ROTATE.BYTE.RIGHT - PERFORMS 9-BIT ROTATE AND THEREFORE THE
;1677    ; ANSWER MUST BE CLEANED UP WITH A ROL WR[].
;1678    ;
;1679    ; WORD.SWAP - PERFORMS A 15-BIT ROTATE AND THERE FORE
;1680    ; THE ANSWER MUST BE CLEANED UP WITH A ROL WR[].
;1681    ;
;1682    ; OCTA.WRITE.P - MUST BE LONGWORD ALLIGNED.
;1683    ;
;1684    ; OCTA.WR.V.WCHK - MUST BE LONGWORD ALLIGNED.  THIS DATA CAN
;1685    ; CROSS PAGE BOUNDARIES
;1686    ;
;1687    MEM.FUNC/=<7>,.VALIDITY=0
;1688
;1689    ;       PREFETCH=0              ; USED TO TAKE VAR AND ADD ONE BEFORE REFERENCE.
;1690            WRITE.TB=01             ; WRITE TRANSLATION BUFFER
;1691            TEST.V.RCHK=2           ; TEST WITH VIRTUAL ADDRESS AND READ ACCESS CHECK
;1692            READ.P=3                ; READ WITH PHYSICAL ADDRESS
;1693            WRITE.P=4               ; WRITE WITH PHYSICAL ADDRESS
;1694            TEST.V.WCHK=5           ; WRITE WITH VIRTUAL ADDRESS AND WRITE ACCESS CHECK
;1695            ROTATE.BYTE.RIGHT=6     ; ROTATE ADDRESS DATA 9 BITS RIGHT AND RETURN
;1696            WORD.SWAP=7             ; ROTATE ADDRESS DATA 15 BITS LEFT AND RETURN
;1697            READ.V.NOCHK=8          ; READ WITH VIRTUAL ADDRESS AND READ ACCESS CHECK
;1698            READ.V.WCHK=9           ; READ WITH VIRTUAL ADDRESS AND WRITE ACCESS CHECK
;1699            READ.V.RCHK=0A          ; READ WITH VIRTUAL ADDRESS AND READ ACCESS CHECK
;1700            READ.MAINT.VAR.INC=0B   ; TEST VAR INCREMENTING.
;1701            WRITE.V.NOCHK=0C        ; WRITE WITH VIRTUAL ADDRESS AND NO ACCESS CHECK
;1702            WRITE.V.WCHK=0D         ; WRITE WITH VIRTUAL ADDRESS AND WRITE ACCESS CHECK
;1703            IB.FILL=0E              ; READ WITH VIRTUAL ADDRESS AND READ ACCESS CHECK AND FILL IB
;1704            READ.V.RCHK.IFILL=0E    ; READ WITH VIRTUAL ADDRESS AND READ ACCESS CHECK AND FILL IB
;1705            WRITE.UBS.MAP=0F        ; WRITE TO THE UNIBUS MAP.
;1706
;1707            OCTA.WRITE.P=10         ; WRITE OCTA DATA WITH PHYSICAL ADDRESS.
;1708            WRITE.TB.STEP=11        ; WRITE TO TWO TB ENTRIES(WITH CORRECT ADDRESS)
;1709            READ.UBS.MAP=12         ; READ UNIBUS MAP
;1710            READ.TB=13              ; READ TRANSLATION BUFFER
;1711            READ.MAINT.ADRS=14      ; RPUTS VA ON UNIBUS LINES AND READS THIS DATA
;1712            MAINT.ECC.DATA=15       ; TEST ALL ECC FUNCTIONS.
;1713            READ.CSR=16             ; READ CONTROL REGISTER
;1714            READ.CNTRL.REG=16       ; READ CONTROL REGISTER
;1715            WRITE.CNTRL.REG=17      ; WRITE CONTROL REGISTER
;1716            WRITE.CSR=17            ; WRITE CONTROL REGISTER
;1717            OCTA.READ.P=18          ; READ OCTA DATA WITH PHYSICAL ADDRESS.
;1718            READ.V.WCHK.LOCKED=19   ; READ VIRTUAL ADDRESS AND WRITE ACCESS CHECK AND LOCKED
;1719            OCTA.READ.V.RCHK=1A     ; READ OCTA WITH VIRTUAL ADDRESS AND READ ACCESS CHECK.
;1720            READ.MAINT.BR.CHECK=1B ; TESTS BRANCHING FUNCTION.
;1721            ISSUE.BG=1C             ; ISSUES BUS GRANT (4+ADDRESS<1:0>)
```

```
;1722            OCTA.WR.V.WCHK=1D       ; WRITE OCTA WITH VIRTUAL ADDRESS AND WRITE ACCESS CHECK.
;1723            QUAD.READ.V.RCHK=1E     ; READ QUAD WITH VIRTUAL ADDRESS AND READ ACCESS CHECK.
;1724            READ.MAINT.UBS=1F       ; PUTS VA ON UNIBUS LINES AND READS THIS AS DATA.
;1725
;1726
;1727    M.FUNC2/=<18:16>,.VALIDITY=<DT.VAL>
;1728
;1729    M.FUNC1/=<8:7>,.VALIDITY=<DT.VAL>
;1730
;1731    PAR/=<23>,.DEFAULT=<.PARITY[<OPC2/>,<OS/>,<JUMP.ADRS/>,<JCTL/>]>
;1732    .UCODE
```

```
;1733    .PAGE   'MACRO DEFINITIONS                                          VER 00.02'
;1734
;1735    ;       THE FORMAT FOR THIS GROUP IS TWO ADDRESS WITH A MODIFY DESTINATION.
;1736    ;       THE FIRST OPERAND IS COMBINED WITH THE SECOND OPERAND AND THE
;1737    ;       RESULT WRITTEN TO THE SECOND OPERAND.  CMP AND BIT INSTRUCTIONS ARE
;1738    ;       READ ONLY.
;1739    ;
;1740    ;       DURING ALL ARITHMETIC AND LOGICAL INSTRUCTIONS THE ALU CC'S
;1741    ;       CAN BE LOADED BY ADDING THE
;1742    ;
;1743    ;               DT(SIZE)&SET.ALU.CC
;1744    ;
;1745    ;       MACRO TO THE MICROWORD.  THIS SPECIFIES THAT ALU CC'S ARE LOADED
;1746    ;       WITH THE 2901 CONDITIONS.  NO EXTERNAL MUNGING IS DONE.  IF THE
;1747    ;       DATA OPERATION IS WITH BYTES THEN THE CC'S ARE SET
;1748    ;       ACCORDING TO BITS 7-0. WORD USES BITS 15-0 AND LONGWORD USES BITS
;1749    ;       31-0.  THE FOLLOWING IS A DESCRIPTION OF THE ALU CC'S VALUE
;1750    ;       FOR EACH FUNCTION:
;1751    ;
;1752    ;       ADD -- BINARY ADDITION OF THE TWO OPERANDS
;1753    ;
;1754    ;       N - SIGN BIT
;1755    ;       Z - SET IF ANSWER IS ZERO.
;1756    ;       V - ARITHMETIC OVERFLOW
;1757    ;       C - CARRY
;1758    ;
;1759    ;       SUB -- BINARY ADDITION OF FIRST OPERAND AND TWO'S COMPLEMENT OF THE SECOND OPERAND.
;1760    ;
;1761    ;       N - SIGN BIT
;1762    ;       Z - SET IF ANSWER IS ZERO.
;1763    ;       V - ARITHMETIC OVERFLOW
;1764    ;       C - COMPLEMENT OF THE BORROW.
;1765    ;
;1766    ;       BIS -- LOGICAL OR OF THE TWO OPERANDS.
;1767    ;
;1768    ;       N - SIGN BIT
;1769    ;       Z - SET IF ANSWER IS ZERO
;1770    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1771    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1772    ;
;1773    ;       BIC -- ONE'S COMPLEMENT OF FIRST OPERAND ANDED WITH SECOND OPERAND.
;1774    ;
;1775    ;       N - SIGN BIT
;1776    ;       Z - SET IF ANSWER IS ZERO
;1777    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1778    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1779    ;
;1780    ;       AND -- LOGICAL AND OF THE TWO OPERANDS.
;1781    ;
;1782    ;       N - SIGN BIT
;1783    ;       Z - SET IF ANSWER IS ZERO
;1784    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1785    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1786    ;
;1787    ;       XOR -- LOGICAL EXCLUSIVE OR OF THE TWO OPERANDS.
```

```
;1788    ;
;1789    ;       N - SIGN BIT
;1790    ;       Z - SET IF ANSWER IS ZERO
;1791    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1792    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1793    ;
;1794    ;       CMP -- PERFORM BINARY ADDITION OF FIRST OPERAND AND TWO'S COMPLEMENT OF SECOND OPERAND BUT DO NOT STORE.
;1795    ;
;1796    ;       N - SIGN BIT
;1797    ;       Z - SET IF ANSWER IS ZERO.
;1798    ;       V - ARITHMETIC OVERFLOW
;1799    ;       C - CARRY
;1800    ;
;1801    ;       BIT -- PERFORM LOGICAL AND OF THE TWO OPERANDS BUT DO NOT STORE.
;1802    ;
;1803    ;       N - SIGN BIT
;1804    ;       Z - SET IF ANSWER IS ZERO
;1805    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1806    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1807    ;
;1808    ;       SWAP -- SWITCH THE TWO VALUES.
;1809    ;
;1810    ;       N - SIGN BIT OF VALUE TO WR.
;1811    ;       Z - SET IF ANSWER IS ZERO OF VALUE TO WR.
;1812    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1813    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
```

```
;1814    .PAGE
;1815    ;
;1816    ;       MACROS FOR THE FORM OF WR[B]<-- WR[B] OPERATE LS[D]
;1817    ;
;1818    ADD  LS[] TO   WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP.SMALL/<.SHIFT[<.AND[<SDP/LS.PLUS.WR>,07F]>,-2]>"
;1819    SUB  LS[] FROM WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP.SMALL/<.SHIFT[<.AND[<SDP/LS.FROM.WR>,07F]>,-2]>"
;1820    BIS  LS[] TO   WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.OR.WR>,0FF]>,-2]>"
;1821    BIC  LS[] TO   WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.MASK.WR>,0FF]>,-2]>"
;1822    AND  LS[] TO   WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP.SMALL/<.SHIFT[<.AND[<SDP/LS.AND.WR>,07F]>,-2]>"
;1823    XOR  LS[] TO   WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP.SMALL/<.SHIFT[<.AND[<SDP/LS.XOR.WR>,07F]>,-2]>"
;1824
;1825    CMP  LS[] WITH WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.CMP.WR>,0FF]>,-2]>"
;1826    BIT  LS[] WITH WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.BIT.LS>,0FF]>,-2]>"
;1827    SWAP LS[] WITH WR[]              "OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/SWAP.LS.WR>,0FF]>,-2]>"
;1828    ;
;1829    ;       THE FOLLOWING MACROS IS TO BE USED WITH ADD,SUB,
;1830    ;       AND,XOR LS[] TO WR[]
;1831    ;
;1832    ;       IT WILL TAKE THE ORIGINAL CONTENTS OF WR[]
;1833    ;       AND PUT IT IN LS[].
;1834    ;
;1835    XCHG                             "XCHG.BIT/YES"
;1836    ;
;1837    ;       MACROS FOR THE FORM OF LS[D]<-- LS[D] OPERATE Q-REGISTER
;1838    ;
;1839    ADD   Q TO   LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.PLUS.LS>,0FF]>,-2]>"
;1840    SUB   Q FROM LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.FROM.LS>,0FF]>,-2]>"
;1841    BIS   Q TO   LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.OR.LS>,0FF]>,-2]>"
;1842    AND   Q TO   LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.AND.LS>,0FF]>,-2]>"
;1843    XOR   Q TO   LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.XOR.LS>,0FF]>,-2]>"
;1844
;1845    CMP   Q WITH LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.CMP.LS>,0FF]>,-2]>"
;1846    BIT   Q WITH LS[]                "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.BIT.Q>,0FF]>,-2]>"
;1847    ;
;1848    ;       MACROS FOR THE FORM OF Q-REGISTER<-- Q-REGISTER OPERATE LS[D]
;1849    ;
;1850    ADD  LS[] TO   Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.PLUS.Q>,0FF]>,-2]>"
;1851    SUB  LS[] FROM Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.FROM.Q>,0FF]>,-2]>"
;1852    BIS  LS[] TO   Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.OR.Q>,0FF]>,-2]>"
;1853    BIC  LS[] TO   Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.MASK.Q>,0FF]>,-2]>"
;1854    AND  LS[] TO   Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.AND.Q>,0FF]>,-2]>"
;1855    XOR  LS[] TO   Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.XOR.Q>,0FF]>,-2]>"
;1856
;1857    CMP  LS[] WITH Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.CMP.Q>,0FF]>,-2]>"
;1858    BIT  LS[] WITH Q                 "OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.BIT.Q>,0FF]>,-2]>"
;1859    ;
;1860    ;       MACROS FOR THE FORM OF LS[D]<-- LS[D] OPERATE WR[B]
;1861    ;
;1862    ADD  WR[] TO   LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.PLUS.LS>,0FF]>,-2]>"
;1863    SUB  WR[] FROM LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.FROM.LS>,0FF]>,-2]>"
;1864    BIS  WR[] TO   LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.OR.LS>,0FF]>,-2]>"
;1865    AND  WR[] TO   LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.AND.LS>,0FF]>,-2]>"
;1866    XOR  WR[] TO   LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.XOR.LS>,0FF]>,-2]>"
;1867
;1868    CMP  WR[] WITH LS[]              "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.CMP.LS>,0FF]>,-2]>"
```

```
;1869    BIT  WR[] WITH LS[]             "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.BIT.LS>,0FF]>,-2]>"
;1870    SWAP WR[] WITH LS[]             "SWAP LS[a2] WITH WR[a1]"
;1871    ;
;1872    ;       MACROS FOR THE FORM OF WR[B]<-- WR[B] OPERATE WR[A]
;1873    ;
;1874    ADD  WR[] TO   WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.PLUS.WR>,03F]>"
;1875    SUB  WR[] FROM WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.FROM.WR>,03F]>"
;1876    BIS  WR[] TO   WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.OR.WR>,03F]>"
;1877    BIC  WR[] TO   WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.MASK.WR>,03F]>"
;1878    AND  WR[] TO   WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.AND.WR>,03F]>"
;1879    XOR  WR[] TO   WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.XOR.WR>,03F]>"
;1880
;1881    CMP  WR[] WITH WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.CMP.WR>,03F]>"
;1882    BIT  WR[] WITH WR[]             "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.BIT.WR>,03F]>"
;1883    ;
;1884    ;       MACROS FOR THE FORM OF WR[B]<-- WR[B] OPERATE Q-REGISTER
;1885    ;
;1886    ADD  Q TO   WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.PLUS.WR>,03F]>"
;1887    SUB  Q FROM WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.FROM.WR>,03F]>"
;1888    BIS  Q TO   WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.OR.WR>,03F]>"
;1889    AND  Q TO   WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.AND.WR>,03F]>"
;1890    XOR  Q TO   WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.XOR.WR>,03F]>"
;1891
;1892    CMP  Q WITH WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.CMP.WR>,03F]>"
;1893    BIT  Q WITH WR[]                "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a1,XDP/<.AND[<SDP/Q.BIT.WR>,03F]>"
;1894    ;
;1895    ;       MACROS FOR THE FORM OF Q-REGISTER<-- Q-REGISTER OPERATE WR[B]
;1896    ;
;1897    ADD  WR[] TO   Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.PLUS.Q>,03F]>"
;1898    SUB  WR[] FROM Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.FROM.Q>,03F]>"
;1899    BIS  WR[] TO   Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.OR.Q>,03F]>"
;1900    BIC  WR[] TO   Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.MASK.Q>,03F]>"
;1901    AND  WR[] TO   Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.AND.Q>,03F]>"
;1902    XOR  WR[] TO   Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.XOR.Q>,03F]>"
;1903
;1904    CMP  WR[] WITH Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/WR.CMP.Q>,03F]>"
;1905    BIT  WR[] WITH Q                "OPC1/EXTENDED,A.ADRS/a1,XDP/<.AND[<SDP/Q.BIT.WR>,03F]>"
```

```
;1906    .PAGE
;1907    ;
;1908    ;       THE FORMAT OF THIS GROUP IS THREE ADDRESS TYPE. THE FIRST AND SECOND
;1909    ;       OPERANDS ARE READ AND THE RESULT IS WRITTEN INTO THE THIRD OPERAND.
;1910    ;
;1911    ;       MACROS FOR THE FORM OF Q-REGISTER<-- WR[B] OPERATE WR[A]
;1912    ;
;1913    ADD  WR[] PLUS WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.PLUS.WR.Q>,03F]>"
;1914    SUB  WR[] FROM WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.FROM.WR.Q>,03F]>"
;1915    BIS  WR[] WITH WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.OR.WR.Q>,03F]>"
;1916    BIC  WR[] WITH WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.MASK.WR.Q>,03F]>"
;1917    AND  WR[] WITH WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.AND.WR.Q>,03F]>"
;1918    XOR  WR[] WITH WR[] TO Q        "OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.XOR.WR.Q>,03F]>"
;1919    ;
;1920    ;       MACROS FOR THE FORM OF Q-REGISTER<-- WR[B] OPERATE LS[D]
;1921    ;
;1922    ADD  WR[] PLUS LS[] TO Q        "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.PLUS.LS.Q>,0FF]>,-2]>"
;1923    SUB  WR[] FROM LS[] TO Q        "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.FROM.LS.Q>,0FF]>,-2]>"
;1924    BIS  WR[] WITH LS[] TO Q        "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.OR.LS.Q>,0FF]>,-2]>"
;1925    AND  WR[] WITH LS[] TO Q        "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.AND.LS.Q>,0FF]>,-2]>"
;1926    XOR  WR[] WITH LS[] TO Q        "OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.XOR.LS.Q>,0FF]>,-2]>"
;1927    ;
;1928    ;       MACROS FOR THE FORM OF Q-REGISTER <-- LS[D] OPERATE WR[B]
;1929    ;
;1930    ADD LS[] PLUS WR[] TO Q "ADD WR[a2] PLUS LS[a1] TO Q"
;1931    SUB  LS[] FROM WR[] TO Q        "OPC/BASIC,B.ADRS/a2,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.FROM.WR.Q>,0FF]>,-2]>"
;1932    BIS LS[] WITH WR[] TO Q "BIS WR[a2] WITH LS[a1] TO Q"
;1933    AND LS[] WITH WR[] TO Q         "AND WR[a2] WITH LS[a1] TO Q"
;1934    XOR LS[] WITH WR[] TO Q         "XOR WR[a2] WITH LS[a1] TO Q"
;1935
;1936
```

```
;1937    .PAGE
;1938    ; SPECIAL FUNCTION ADD/SUB OPERATIONS
;1939
;1940    ADD (WR[] TO WR[])+1            'OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.PLUS.WR+1>,03F]>'
;1941    ADD (LS[] TO WR[])+1            'OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.PLUS.WR+1>,0FF]>,-2]>'
;1942    ADD (WR[] TO LS[])+1            'OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.PLUS.LS+1>,0FF]>,-2]>'
;1943
;1944    ADD OS PLUS WR[] TO LS[]        'OPC1/MOVE,B.ADRS/a1,XD.ADRS/a2,MDP/<.SHIFT[<.AND[<SDP/WR.PLUS.OS>,3F]>,-3]>'
;1945
;1946    SUB (WR[] FROM WR[])-1          'OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.FROM.WR-1>,03F]>'
;1947    SUB (LS[] FROM WR[])-1          'OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.FROM.WR-1>,0FF]>,-2]>'
;1948    SUB (WR[] FROM LS[])-1          'OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WR.FROM.LS-1>,0FF]>,-2]>'
;1949
;1950
;1951    SUB  WRB[] FROM WRA[] TO WRB[]  'OPC1/EXTENDED,B.ADRS/a1,A.ADRS/a2,XDP/<.AND[<SDP/WR.FROM.WR.WR>,03F]>'
;1952    SUB  LS[]  FROM WR[]  TO LS     'OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/LS.FROM.WR.LS>,0FF]>,-2]>'
;1953    SUB  WR[] FROM LS[]  TO WR      'OPC/BASIC,B.ADRS/a1,D.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/WRA.FROM.LS.WRB>,0FF]>,-2]>'
;1954
;1955    SUB  WRA[] FROM Q    TO WRB[]   'OPC1/EXTENDED,A.ADRS/a1,B.ADRS/a2,XDP/<.AND[<SDP/WR.FROM.Q.WR>,03F]>'
;1956    SUB  LS[]  FROM Q    TO LS[]    'OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/LS.FROM.Q.LS>,0FF]>,-2]>'
;1957    SUB  Q     FROM WR[] TO Q       'OPC1/EXTENDED,B.ADRS/a1,XDP/<.AND[<SDP/Q.FROM.WR.Q>,03F]>'
;1958    SUB  Q     FROM LS[] TO Q       'OPC/BASIC,D.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.FROM.LS.Q>,0FF]>,-2]>'
;1959
;1960    ADD Q PLUS WR[] TO LS[]         'OPC/BASIC,D.ADRS/a2,B.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.PLUS.WR.TO.LS>,0FF]>,-2]>'
;1961    SUB Q FROM WR[] TO LS[]         'OPC/BASIC,D.ADRS/a2,B.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/Q.FROM.WR.TO.LS>,0FF]>,-2]>'
;1962    ADD Q PLUS LS[] TO WR[] 'OPC/BASIC,D.ADRS/a1,B.ADRS/a2,DP/<.SHIFT[<.AND[<SDP/Q.PLUS.LS.TO.WR>,0FF]>,-2]>'
;1963
;1964    ADD Q TO WR[] XCHG TO LS[]      'OPC/BASIC,D.ADRS/a2,B.ADRS/a1,DP/<.SHIFT[<.AND[<SDP/WR.PLUS.Q.XCHG>,0FF]>,-2]>'
;1965
```

```
;1966    .PAGE
;1967    ; MOVE MACRO INSTRUCTIONS
;1968    ;
;1969    ;       DURING THE MOVE INSTRUCTIONS THE ALU CC'S CAN BE LOADED BY
;1970    ;       ADDING THE
;1971    ;
;1972    ;               DT(SIZE)&SET.ALU.CC
;1973    ;
;1974    ;       MACRO TO THE MICROWORD.  THE FOLLOWING IS A DESCRIPTION OF THE ALU
;1975    ;       CC'S VALUE FOR EACH FUNCTION:
;1976    ;
;1977    ;       MOV -- PUT FIRST OPERAND ON TOP OF THE SECOND OPERAND.
;1978    ;
;1979    ;       N - SIGN BIT
;1980    ;       Z - SET IF ANSWER IS ZERO
;1981    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1982    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1983    ;
;1984    ;       MCOM -- PUT ONE'S COMPLEMENT OF THE FIRST OPERAND ON TOP OF THE SECOND OPERAND.
;1985    ;
;1986    ;       N - SIGN BIT
;1987    ;       Z - SET IF ANSWER IS ZERO
;1988    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1989    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;1990    ;
;1991    ;       MNEG -- PUT TWO'S COMPLEMENT OF THE FIRST OPERAND ON TOP OF THE SECOND OPERAND.
;1992    ;
;1993    ;       N - SIGN BIT
;1994    ;       Z - SET IF ANSWER IS ZERO.
;1995    ;       V - ARITHMETIC OVERFLOW
;1996    ;       C - CARRY
;1997    MOV Q     TO LS[]                   'OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/MOV.Q.LS>,0FF]>,-2]>"
;1998    MOV Q     TO WR[]                   'OPC1/EXTENDED,B.ADRS/@1,XDP/<.AND[<SDP/MOV.Q.WR>,03F]>"
;1999    MOV LS[] TO Q                       'OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/MOV.LS.Q>,0FF]>,-2]>"
;2000    MOV Q TO WR[] XCHG TO LS[]          'OPC/BASIC,D.ADRS/@2,B.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/MOV.Q.WR&WR.LS>,0FF]>,-2]>"
;2001
;2002    MOV IB.DATA TO OS                   'OPC2/DECODE,IFUNC/SPEC,R.DST/NOP,IB.REQ/IB.REQ,JCTL/NO.JUMP.TST,LD.OS/LOAD.OS"
;2003    MOV CM.IB.DATA TO OS                'OPC2/DECODE,IFUNC/SPEC,R.DST/NOP,IB.REQ/NOP,JCTL/NO.JUMP.TST,LD.OS/LOAD.OS"
;2004
;2005    MOV MEM.DATA TO WR[]                'OPC1/MOVE,B.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.MEM.WR>,3F]>,-3]>,XD.ADRS/WR.BACKUP"
;2006    MOV MEM.DATA TO WR[] XCHG TO LS[]       'OPC1/MOVE,B.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.MEM.WR>,3F]>,-3]>,XD.ADRS/@2"
;2007    MOV MEM.DATA TO LS[]                'OPC1/MOVE,XD.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.MEM.LS>,3F]>,-3]>"
;2008    MOV LS[]     TO WR[]                'OPC1/MOVE,XD.ADRS/@1,B.ADRS/@2,MDP/<.SHIFT[<.AND[<SDP/MOV.LS.WR>,3F]>,-3]>"
;2009    MOV WR[]     TO LS[]                'OPC1/MOVE,B.ADRS/@1,XD.ADRS/@2,MDP/<.SHIFT[<.AND[<SDP/MOV.WR.LS>,3F]>,-3]>"
;2010    MOV WR[]     TO WR[]                'OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,XDP/<.AND[<SDP/WR.PLUS.0.TO.WR>,03F]>"
;2011    MOV WR[]     TO Q                   'OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.OR.WR.Q>,03F]>"
;2012    MOV XWR[]    TO  Q                  'OPC1/MOVE,XB.ADRS/@1,XD.ADRS/0,MDP/<.SHIFT[<.AND[<SDP/MOV.XWR.Q>,3F]>,-3]>"
;2013
;2014    MOV FPA TO LS[]                     'OPC1/MOVE,XD.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.ACC.LS>,3F]>,-3]>"
;2015    MOV PORT TO LS[]                    'OPC1/MOVE,XD.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.ACC.LS>,3F]>,-3]>,CC/DT(LONG)&HOLD.ALU.CC"
;2016
;2017    MCOM WR[] TO LS[]                   'OPC/BASIC,B.ADRS/@1,D.ADRS/@2,DP/<.SHIFT[<.AND[<SDP/WR.COM.LS>,0FF]>,-2]>"
;2018    MCOM LS[] TO WR[]                   'OPC/BASIC,D.ADRS/@1,B.ADRS/@2,DP/<.SHIFT[<.AND[<SDP/LS.COM.WR>,0FF]>,-2]>"
;2019    MNEG WR[] TO LS[]                   'OPC/BASIC,B.ADRS/@1,D.ADRS/@2,DP/<.SHIFT[<.AND[<SDP/WR.NEG.LS>,0FF]>,-2]>"
;2020    MNEG LS[] TO WR[]                   'OPC/BASIC,D.ADRS/@1,B.ADRS/@2,DP/<.SHIFT[<.AND[<SDP/LS.NEG.WR>,0FF]>,-2]>"
```

```
;2021   MNEG WR[] TO WR[]              "OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,XDP/<.AND[<SDP/WR.NEG.WR>,03F]>"
;2022   MCOM WR[] TO WR[]          "OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,XDP/<.AND[<SDP/WR.COM.WR>,03F]>"
;2023   MINC WR[] TO WR[]          "OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,XDP/<.AND[<SDP/WR.INC.WR>,03F]>"
;2024   MDEC WR[] TO WR[]          "OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,XDP/<.AND[<SDP/WR.DEC.WR>,03F]>"
;2025   MNEG Q TO LS[]             "OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/Q.NEG.LS>,0FF]>,-2]>"
```

```
;2026    .PAGE
;2027    ;
;2028    ; SINGLE OPERAND OPERATIONS
;2029    ;
;2030    ;       THIS FORM OF INSTRUCTION PERFORMS THE DESIRED OPERATION ON THE OPERAND
;2031    ;       SPECIFIED.
;2032    ;
;2033    ;               CLEAR
;2034    ;               NEGATE
;2035    ;               INCREMENT
;2036    ;               DECREMENT
;2037    ;               COMPLEMENT
;2038    ;               TEST
;2039    ;
;2040    ;       DURING THE SINGLE OPERAND INSTRUCTIONS THE ALU CC'S CAN BE
;2041    ;       LOADING USING THE
;2042    ;
;2043    ;               DT(SIZE)&SET.ALU.CC
;2044    ;
;2045    ;       MACRO IN THE MICROWORD.  THE FOLLOWING IS A DESCRIPTION OF THE
;2046    ;       ALU CC'S FOR EACH FUNCTION:
;2047    ;
;2048    ;       CLR -- STORE A ZERO IN THE OPERAND.
;2049    ;
;2050    ;       N - SIGN BIT
;2051    ;       Z - SET IF ANSWER IS ZERO
;2052    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2053    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2054    ;
;2055    ;       NEG -- PERFORM TWO'S COMPLEMENT OF THE OPERAND.
;2056    ;
;2057    ;       N - SIGN BIT
;2058    ;       Z - SET IF ANSWER IS ZERO.
;2059    ;       V - ARITHMETIC OVERFLOW
;2060    ;       C - CARRY
;2061    ;
;2062    ;       INC -- ADD ONE TO THE OPERAND.
;2063    ;
;2064    ;       N - SIGN BIT
;2065    ;       Z - SET IF ANSWER IS ZERO.
;2066    ;       V - ARITHMETIC OVERFLOW
;2067    ;       C - CARRY
;2068    ;
;2069    ;       DEC -- SUBTRACT ONE FROM THE OPERAND.
;2070    ;
;2071    ;       N - SIGN BIT
;2072    ;       Z - SET IF ANSWER IS ZERO.
;2073    ;       V - ARITHMETIC OVERFLOW
;2074    ;       C - CARRY
;2075    ;
;2076    ;       COM -- PERFORM ONE'S COMPLEMENT OF THE OPERAND (XNOR WITH ZERO).
;2077    ;
;2078    ;       N - SIGN BIT
;2079    ;       Z - SET IF ANSWER IS ZERO.
;2080    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
```

```
;2081    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2082    ;
;2083    ;       TST -- ADD ZERO TO THE OPERAND TO SET THE CONDITION CODES.
;2084    ;
;2085    ;       N - SIGN BIT
;2086    ;       Z - SET IF ANSWER IS ZERO
;2087    ;       V - ARITHMETIC OVERFLOW (IN THIS CASE ALWAYS ZERO)
;2088    ;       C - CARRY (IN THIS CASE ZERO)
;2089    ;
;2090
;2091    CLR Q                           ''OPC1/EXTENDED,A.ADRS/0,B.ADRS/0,XDP/<.AND[<SDP/WR.XOR.WR.Q>,03F]>''
;2092    CLR LS[]                        ''OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/CLR.LS>,0FF]>,-2]>''
;2093    CLR WR[]                        ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.XOR.WR>,03F]>''
;2094
;2095    NEG  Q                          ''OPC1/EXTENDED,XDP/<.AND[<SDP/NEG.Q>,03F]>''
;2096    NEG  LS[]                       ''OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/NEG.LS>,0FF]>,-2]>''
;2097    NEG  WR[]                       ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.NEG.WR>,03F]>''
;2098
;2099    INC  Q                          ''OPC1/EXTENDED,XDP/<.AND[<SDP/INC.Q>,03F]>''
;2100    INC  LS[]                       ''OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/INC.LS>,0FF]>,-2]>''
;2101    INC  WR[]                       ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.INC.WR>,03F]>''
;2102
;2103    DEC  Q                          ''OPC1/EXTENDED,XDP/<.AND[<SDP/DEC.Q>,03F]>''
;2104    DEC  LS[]                       ''OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/DEC.LS>,0FF]>,-2]>''
;2105    DEC  WR[]                       ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.DEC.WR>,03F]>''
;2106
;2107    COM  Q                          ''OPC1/EXTENDED,XDP/<.AND[<SDP/COM.Q>,03F]>''
;2108    COM  LS[]                       ''OPC/BASIC,D.ADRS/@1,DP/<.SHIFT[<.AND[<SDP/COM.LS>,0FF]>,-2]>''
;2109    COM  WR[]                       ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.COM.WR>,03F]>''
;2110
;2111    TST WR[]                        ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,XDP/<.AND[<SDP/WR.PLUS.0.TO.WR>,03F]>''
;2112    TST Q                           ''OPC1/EXTENDED,XDP/<.AND[<SDP/Q.PLUS.0>,03F]>''
;2113
;2114    NOP                             ''OPC/BASIC,D.ADRS/0,B.ADRS/0,DP/<.SHIFT[<.AND[<SDP/Q.CMP.LS>,0FF]>,-2]>''
```

```
;2115    .PAGE
;2116    ;
;2117    ; MACROS FOR SHIFT OPERATION ON WR[B] AND/OR Q-REGISTER
;2118    ;
;2119    ;       DURING THE SHIFT OPERATIONS THE ALU CC'S CAN BE LOADED BY
;2120    ;       USING THE
;2121    ;
;2122    ;               DT(SIZE)&SET.ALU.CC
;2123    ;
;2124    ;       MACRO WITH THE MICROWORD.  THE FOLLOWING IS A DESCRIPTION OF THE
;2125    ;       ALU CC'S WITH EACH FUNCTION.
;2126    ;
;2127    ;       ROR WR[] -- ROTATE 32 BIT VALUE ONE POSITION RIGHT.
;2128    ;
;2129    ;       N - SIGN OF INPUT
;2130    ;       Z - SET IF INPUT IS ZERO
;2131    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2132    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2133    ;
;2134    ;       ROL WR[] -- ROTATE 32 BIT VALUE ONE POSITION LEFT.
;2135    ;
;2136    ;       N - SIGN OF INPUT
;2137    ;       Z - SET IF INPUT IS ZERO
;2138    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2139    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2140    ;
;2141    ;       ASHR WR[] -- SHIFT 32 BIT VALUE RIGHT ONE POSITION AND SIGN EXTEND.
;2142    ;
;2143    ;       N - SIGN OF INPUT
;2144    ;       Z - SET IF INPUT IS ZERO
;2145    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2146    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2147    ;
;2148    ;       ASHL WR[] -- SHIFT 32 BIT VALUE LEFT ONE POSITION AND INSERT A ZERO IN BOTTOM BIT.
;2149    ;
;2150    ;       N - SIGN OF INPUT
;2151    ;       Z - SET IF INPUT IS ZERO
;2152    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2153    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2154    ;
;2155    ;       ASHRC WR[].Q -- SHIFT 64 BIT WR.Q ONE POSITION LEFT AND SIGN EXTEND.
;2156    ;
;2157    ;       N - SIGN OF INPUT WR[]
;2158    ;       Z - SET IF INPUT WR[] IS ZERO
;2159    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2160    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2161    ;
;2162    ;       RORC WR[].Q -- ROTATE 64 BIT WR.Q ONE POSITION RIGHT.
;2163    ;
;2164    ;       N - SIGN OF INPUT WR[]
;2165    ;       Z - SET IF INPUT WR[] IS ZERO
;2166    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2167    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2168    ;
;2169    ;       ASHLC WR[].Q -- SHIFT 64 BIT WR.Q ONE POSITION LEFT AND INSERT ZERO.
```

```
;2170    ;
;2171    ;       N - SIGN OF INPUT WR[]
;2172    ;       Z - SET IF INPUT WR[] IS ZERO
;2173    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2174    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2175    ;
;2176    ;       ROLC WR[].Q -- ROTATE 64 BIT WR.Q ONE POSITION LEFT.
;2177    ;
;2178    ;       N - SIGN OF INPUT WR[]
;2179    ;       Z - SET IF INPUT WR[] IS ZERO
;2180    ;       V - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2181    ;       C - RANDOM GARBAGE (DO NOT ASSUME ANY FUNCTION)
;2182    ;
;2183    ;       SHL2 WR[] -- SHIFT 32 BIT VALUE TWO POSITIONS LEFT INSERTING ZEROES IN THE BOTTOM BITS.
;2184    ;
;2185    ;       N - SIGN OF INPUT WR[]+WR[]
;2186    ;       Z - SET IF INPUT WR[]+WR[] IS ZERO
;2187    ;       V - OVERFLOW OF INPUT WR[]+WR[]
;2188    ;       C - CARRY OF INPUT WR[]+WR[]
;2189    ;
;2190    ROR  WR[]                       ''OPC1/EXTENDED,B.ADRS/@1,SI/ROT.WR,XDP/<.AND[<SDP/ASHR>,03F]>''
;2191
;2192    ROL  WR[]                       ''OPC1/EXTENDED,B.ADRS/@1,SI/ROT.WR,XDP/<.AND[<SDP/ASHL>,03F]>''
;2193
;2194
;2195    ASHR  WR[]                      ''OPC1/EXTENDED,B.ADRS/@1,SI/ASH.WR,XDP/<.AND[<SDP/ASHR>,03F]>''
;2196
;2197    ASHL  WR[]                      ''OPC1/EXTENDED,B.ADRS/@1,SI/ASH.WR,XDP/<.AND[<SDP/ASHL>,03F]>''
;2198
;2199    ASHRC  WR[].Q                   ''OPC1/EXTENDED,B.ADRS/@1,SI/ASH.WR.Q,XDP/<.AND[<SDP/ASHRC>,03F]>''
;2200
;2201    RORC WR[].Q                     ''OPC1/EXTENDED,B.ADRS/@1,SI/ROT.WR.Q,XDP/<.AND[<SDP/ASHRC>,03F]>''
;2202
;2203    ASHLC  WR[].Q                   ''OPC1/EXTENDED,B.ADRS/@1,SI/ASH.WR.Q,XDP/<.AND[<SDP/ASHLC>,03F]>''
;2204
;2205    ROLC WR[].Q                     ''OPC1/EXTENDED,B.ADRS/@1,SI/ROT.WR.Q,XDP/<.AND[<SDP/ASHLC>,03F]>''
;2206
;2207    SHL2  WR[]                      ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@1,SI/2,XDP/<.AND[<SDP/SHL2>,03F]>''
;2208
;2209    COND.ADD&SHIFT  WR[] TO WR[].Q  ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,SI/MUL.SHF,XDP/<.AND[<SDP/COND.ADD&SHIFT>,03F]>''
;2210
;2211    COND.SUB&SHIFT  WR[] FROM WR[].Q ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,SI/MUL.SHF,XDP/<.AND[<SDP/COND.SUB&SHIFT>,03F]>''
;2212
;2213    UNSIGNED.MUL WR[] TO WR[].Q     ''OPC1/EXTENDED,A.ADRS/@1,B.ADRS/@2,SI/UMUL.SHF,XDP/<.AND[<SDP/COND.ADD&SHIFT>,03F]>''
;2214    SHR WR[]                        ''OPC1/EXTENDED,B.ADRS/@1,SI/SHF.WR.Q,XDP/<.AND[<SDP/ASHR>,03F]>''
;2215    SHL WR[]                        ''ASHL WR[@1]''
;2216    SHRC WR[].Q                     ''OPC1/EXTENDED,B.ADRS/@1,SI/SHF.WR.Q,XDP/<.AND[<SDP/ASHRC>,03F]>''
;2217    SHLC WR[].Q                     ''ASHLC WR[].Q''
;2218
;2219
;2220    ; MEMORY REQUEST MACRO
;2221
;2222    ; *      THIS MACRO IS NOT FOR GENERAL USE!!!            *
;2223    ; *      THIS IS ONLY FOR USE IN THE FOLLOWING MACRO     *
;2224    MEM.FUNC[]                      ''M.FUNC2/<.SHIFT[<MEM.FUNC/@1>,-2]>,M.FUNC1/<.AND[<MEM.FUNC/@1>,3]>''
```

```
;2225
;2226   MEM.REQ[] ADRS[] DT[]          ''OPC2/MEM.REQ,MEM.FUNC[@1],D.ADRS/@2,MDT/@3''
;2227   WRITE.MEM LS[]                 ''OPC1/MOVE,XD.ADRS/@1,MDP/<.SHIFT[<.AND[<SDP/MOV.LS.MEM>,3F]>,-3]>''
```

```
;2228    .PAGE
;2229    ;
;2230    ; MACROS FOR MISCELLANEOUS OPERATIONS
;2231    ;
;2232    ;       IN THE NEBULA MICROPROGRAMMING LANGUAGE THERE IS A NEED FOR
;2233    ;       VARIOUS UNIQUE FUNCTIONAL OPERATIONS.  THESE ARE FOUND IN THE
;2234    ;       MISC INSTRUCTIONS.  MOST FUNCTIONS ARE EXECUTED BY INSERTING
;2235    ;       THE REQUEST INSIDE THE MISC[] AND MISC2[] MACROS.
;2236    ;
;2237    MISC []                         "OPC2/MISC,MISC.1/@1,MISC.2/NOP,MISC.PORT/MISC"
;2238    MISC2 []                        "OPC2/MISC,MISC.1/NOP,MISC.2/@1,MISC.PORT/MISC"
;2239    MISC [] WR[]                    "MISC [@1],MISC.WRL/0,MISC.WRR/@2"
;2240    MISC2 [] WR[]                   "MISC2 [@1],MISC.WRL/0,MISC.WRR/@2"
;2241
;2242    PORT.CONTROL []                 "OPC2/MISC,MISC.PORT/PORT,CNTL.FUNC/@1,PORT.SELECT/IDC,PORT.FUNC/CONTROL"
;2243    PORT.WRITE PORT.ADRS[] WITH WR[]        "OPC2/MISC,MISC.PORT/PORT,R.W.FUNC/@1,PORT.SELECT/IDC,PORT.FUNC/WRITE,MISC.WRL/0,MIS
;2244    PORT.READ PORT.ADRS[]   "OPC2/MISC,MISC.PORT/PORT,R.W.FUNC/@1,PORT.SELECT/IDC,PORT.FUNC/READ"
;2245    ;
;2246    ;       A FEW CASES OF THE MISCELLANEOUS FUNCTIONS HAVE BEEN CALLED OUT AS
;2247    ;       UNIQUE FUNCTIONS IN THE MICROPROGRAMMING LANGUAGE SET.  THESE
;2248    ;       ARE LISTED BELOW.
;2249    ;
;2250    ;       THE FOLLOWING TO MACROS SEND DATA TO EXTERNAL ACCELLERATORS.
;2251    ;
;2252    ASSERT.DA.AND.PASS.WR0          "MISC2 [ASSERT.DA.AND.PASS.WR] WR[0]"
;2253    ASSERT.DA.AND.PASS.WR1          "MISC2 [ASSERT.DA.AND.PASS.WR] WR[1]"
;2254    ;
;2255    ;       STATE REGISTER MACROS - THE POSSIBLE CHANGES TO THE STATE
;2256    ;       BITS ARE SPECIFIED AS INDIVIDUAL FUNCTIONS.
;2257    ;
;2258    CLR.STATE.ZERO                  "OPC2/MISC,MISC.1/CLR.S0,MISC.2/NOP,MISC.PORT/MISC"
;2259    CLR.STATE.ONE                   "OPC2/MISC,MISC.1/CLR.S1,MISC.2/NOP,MISC.PORT/MISC"
;2260    SET.STATE.ZERO                  "OPC2/MISC,MISC.1/SET.S0,MISC.2/NOP,MISC.PORT/MISC"
;2261    SET.STATE.ONE                   "OPC2/MISC,MISC.1/SET.S1,MISC.2/NOP,MISC.PORT/MISC"
;2262    SET.STATE.ZERO&CLR.STATE.ONE    "OPC2/MISC,MISC.1/CLR.S1&SET.S0,MISC.2/NOP,MISC.PORT/MISC"
;2263    SET.STATE.ONE&CLR.STATE.ZERO    "OPC2/MISC,MISC.1/SET.S1&CLR.S0,MISC.2/NOP,MISC.PORT/MISC"
;2264    CLR.STATE.ONE&CLR.STATE.ZERO    "OPC2/MISC,MISC.1/CLR,MISC.2/NOP,MISC.PORT/MISC"
;2265    SET.BACKUP.MASK.VALID           "OPC2/MISC,MISC.1/SET.BACKUP.MASK.VALID,MISC.2/NOP,MISC.PORT/MISC"
;2266
;2267
;2268    ; CONTEXT SIZE AND CONDITION CODE MACROS
;2269
;2270    DT(SIZE)&MAP.ALU.CC.TO.PSL      "CC/DT(SIZE)&MAP.ALU.CC.TO.PSL"
;2271    DT(LONG)&SET.ALU.CC             "CC/DT(LONG)&SET.ALU.CC"
;2272    DT(SIZE)&SET.ALU.CC             "CC/DT(SIZE)&SET.ALU.CC"
;2273
```

```
;2274    .PAGE
;2275    ; JUMP AND MICRO SEQUENCER CONTROL MACROS
;2276    ;
;2277    ;       THE FOLLOWING MACROS ARE USED TO CONTROL THE PROGRAMS FLOW OF
;2278    ;       CONTROL.
;2279    ;
;2280    ;       JMP [] -- TRANSFER TO NEW ADDRESS UNCONDITIONALLY.
;2281    ;
;2282    ;       JMP.OS [] -- TRANSFER TO RESULTANT ADDRESS OF LOGICAL OR OF ADDRESS
;2283    ;               IN THE INSTRUCTION AND THE OS REGISTER UNCONDITIONALLY.
;2284    ;
;2285    ;       JMP.IF[] TO [] -- TRANSFER TO NEW ADDRESS ONLY IF JUMP
;2286    ;               CONDITION IS MET.
;2287    ;
;2288    ;       JSR [] -- TRANSFER TO NEW ADDRESS UNCONDITIONALLY AND PUT
;2289    ;               RETURN ADDRESS ON THE SEQUENCER STACK.
;2290    ;
;2291    ;       JSR.OS [] -- TRANSFER TO RESULTANT ADDRESS OF LOGICAL OR OF
;2292    ;               ADDRESS IN THE INSTRUCTION AND THE OS REGISTER.
;2293    ;               THE RETURN ADDRESS IS ALSO PUSHED ON THE SEQUENCER STACK.
;2294    ;
;2295    ;       RETURN -- TRANSFER TO ADDRESS ON TOP OF THE SEQUENCER STACK AND
;2296    ;                POP THE STACK.
;2297    ;
;2298    ;       RETURN+1 -- TRANSFER TO ADDRESS ON TOP OF THE SEQUENCER
;2299    ;               STACK PLUS ONE AND POP THE STACK.
;2300    ;
;2301    ;       RETURN+1.IF(MEM.REF.OK) -- IF THE MOST RECENT MEMORY REQUEST HAD
;2302    ;               NO ERROR THEN TRANSFER TO ADDRESS ON TOP OF THE SEQUENCER
;2303    ;               STACK PLUS ONE AND POP THE STACK.  IF THERE WAS AN
;2304    ;               ERROR THEN SKIP OVER THE ENEXT INSTRUCTION.
;2305    ;
;2306    ;       LOOP.IF(NEQ) -- IF THE ALU Z-BIT IS ZERO (LAST VALUE CALCULATED
;2307    ;               WHEN THE ALU.CC'S WERE SET DID NOT RESULT AS ZERO)
;2308    ;               THEN TRANSFER TO THE ADDRESS ON TOP OF THE SEQUENCER
;2309    ;               STACK.  THE STACK IS NOT POPPED.  IF THE ALU Z-BIT
;2310    ;               IS ONE THEN CONTINUE WITH THE NEXT INSTRUCTION.
;2311    ;               (UPC+1) AND THE STACK IS POPPED.
;2312    ;
;2313    ;       LOOP.IF(GEQU) -- IF THE ALU C-BIT IS ONE (LAST VALUE CALCULATED WHEN
;2314    ;               THE ALU.CC'S WERE SET WAS GREATER THAN OR EQUAL TO ZERO)
;2315    ;               THEN TRANSFER TO THE ADDRESS ON TOP OF THE SEQUENCER
;2316    ;               STACK.  THE STACK IS NOT POPPED.  IF THE ALU C-BIT
;2317    ;               IS ZERO THEN CONTINUE WITH THE NEXT INSTRUCTION
;2318    ;               (UPC+1) AND THE STACK IS POPPED.
;2319    ;
;2320    ;       LOOP.IF(NO INTERRUPT AND NO SYNC) -- IF THE INTERRUPT CONDITION
;2321    ;               IS NOT TRUE AND THE ACCELERATOR SYNC CONDITION IS NOT
;2322    ;               TRUE THEN TRANSFER TO THE ADDRESS ON THE TOP OF THE SEQUENCER
;2323    ;               STACK.  THE STACK IS NOT POPPED.  IF THE INTERRUPT
;2324    ;               CONDITION IS TRUE THEN CONTINUE WITH THE NEXT INSTRUCTION
;2325    ;               (UPC+1) AND THE SEQUENCER STACK IS NOT POPPED.  IF THE ACCELERATOR
;2326    ;               SYNC IS TRUE THEN CONTINUE WITH THE NEXT INSTRUCTION
;2327    ;               (UPC+1) AND THE SEQUENCER STACK IS POPPED.
;2328    ;
```

```
;2329    ;       SKIP.IF[] -- IF THE SKIP CONDITION IS SATISFIED THEN TRANSFER
;2330    ;               TO UPC+2 ELSE TRANSFER TO UPC+1.
;2331    ;
;2332
;2333    JMP []                                  "OPC2/JUMP,JUMP.ADRS/@1,JCTL/JUMP"
;2334    JMP.OS []                               "OPC2/JUMP,JUMP.ADRS/@1,OS/WITH.OS,JCTL/JUMP"
;2335    JMP.IF[] TO []                          "OPC2/JUMP,JCTL/@1,JUMP.ADRS/@2"
;2336    JSR []                                  "OPC2/JUMP,JCTL/JSR,JUMP.ADRS/@1"
;2337    JSR.OS []                               "OPC2/JUMP,JCTL/JSR,JUMP.ADRS/@1,OS/WITH.OS"
;2338
;2339    RETURN                                  "SCTL/RETURN"
;2340    RETURN+1                                "SCTL/RETURN+1"
;2341    RETURN+1.IF(MEM.REF.OK)                 "SCTL/RET.NOERR"
;2342
;2343    LOOP.IF(NEQ)                            "SCTL/JMP.Z.CLR"
;2344    LOOP.IF(GEQU)                           "SCTL/JMP.C.SET"
;2345    LOOP.IF(NO INTERRUPT AND NO SYNC) ELSE SKIP.IF(SYNC)    "SCTL/LOOP.IF.NO.I.AND.SYNC"
;2346
;2347    SKIP.IF[]                               "SCTL/@1"
;2348    SKIP                                    "SCTL/SKIP"
```

```
;2349    .PAGE
;2350    ;
;2351    ; INSTRUCTION STREAM MACROS
;2352    ;
;2353    ; *      THIS MACRO IS NOT FOR GENERAL USE!!!              *
;2354    ; *      THIS IS ONLY FOR USE IN THE FOLLOWING MACROS      *
;2355    DEC[]                           'OPC2/DECODE,DEC.ADRS/<.SHIFT[<JUMP.ADRS/@1>,-8]>''
;2356
;2357    DECODE.SPEC ADRS[]              'DEC[@1],IFUNC/SPEC,BPC/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,LD.OS/LOAD.OS,R.DST/ENAB,OPC.SPEC/S
;2358    DECODE.ASRC ADRS[]              'DEC[@1],IFUNC/ASRC,BPC/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,LD.OS/LOAD.OS,R.DST/ENAB,OPC.SPEC/A
;2359    DECODE.ESRC ADRS[]              'DEC[@1],IFUNC/ESRC,BPC/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,LD.OS/LOAD.OS,R.DST/ENAB,OPC.SPEC/E
;2360    DECODE.VSRC ADRS[]              'DEC[@1],IFUNC/VSRC,BPC/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,LD.OS/LOAD.OS,R.DST/ENAB,OPC.SPEC/V
;2361    DECODE.FLOAT ADRS[]             'DEC[@1],IFUNC/FLOAT,BPC/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,LD.OS/LOAD.OS,R.DST/ENAB,OPC.SPEC/
;2362    DECODE.OPC1 ADRS[]              'DEC[@1],IFUNC/VAX.IRD,R.DST/NOP,CM.HI/LOW.BYTE,IB.REQ/IB.REQ,OPC.SPEC/VAX.IRD''
;2363    EXEC.DISPATCH ADRS[]            'DEC[@1],IFUNC/VAX.EXEC,IB.REQ/NOP,R.DST/NOP,CM.HI/LOW.BYTE,JCTL/JSR,OPC.SPEC/VAX.EXEC''
;2364
;2365    DECODE.CM.OPC ADRS[]            'DEC[@1],IFUNC/CM.IRD,CM.HI/HI.BYTE,OPC.SPEC/CM.IRD,LD.OS/LOAD.OS''
;2366    DECODE.CM.DST ADRS[]            'DEC[@1],IFUNC/CM.DST,OPC.SPEC/CM.DST,LD.OS/LOAD.OS,R.DST/ENAB''
;2367    DECODE.CM.SINGLE ADRS[]         'DEC[@1],IFUNC/CM.SINGLE,OPC.SPEC/CM.SINGLE''
;2368    CM.EXEC ADRS[]                  'DEC[@1],IFUNC/CM.EXEC,JCTL/JUMP,OPC.SPEC/CM.EXEC,LD.OS/LOAD.OS''
;2369
;2370    SAVE.PC WR0                     'BPC/SAVE.PC''
;2371    SAVE.PC WR4                     'BPC/SAVE.PC''
;2372    SAVE.CM.PC WR0                  'BPC/SAVE.PC''
;2373    SAVE.CM.PC WR4                  'BPC/SAVE.PC''
;2374
;2375
;2376    ; THESE SKIP CONDITIONS ARE USED FOR THE DECODE MICRO INSTRUCTION
;2377    ;
;2378    SKIP.IF(IB VALID)               ''JCTL/NO.JUMP.TST''
;2379    JMP.IF(IB VALID)                ''JCTL/JUMP.VALID''
;2380    JSR.IF(IB VALID)                ''JCTL/JSR.VALID''
;2381    ;
;2382    ;       THESE SKIP CONDITIONS ARE TO BE USED WITH THE COMPATIBILITY MODE DECODE
;2383    ;       MACROS.
;2384    ;
;2385    JMP.TO []                       ''JCTL/JUMP,DEC[@1]''
;2386    JSR.TO []                       ''JCTL/JSR,DEC[@1]''
;2387    .BIN
```

```
;2388    .PAGE
;2389    .TOC    "FIELD DEFINTITIONS FOR DATA PATH CONTROL MICRO WORD    VER 00.01"
;2390
;2391    ; THIS SECTION IS FOR THE DATA PATH CONTROL ROMS
;2392    ;
;2393
;2394    .CCODE
;2395    SDP/=<8:0>,.ADDRESS,.VALIDITY=0
;2396    ;
;2397    ; THIS FIELD CORRESPONDS TO THE 2901 ALU FUNCTION CONTROL PINS ... I5,I4,I3
;2398    ;
;2399    ALU/=<2:0>,.DEFAULT=<ALU/R.OR.S>
;2400
;2401            R.PLUS.S=0              ; ADD R WITH S
;2402            S.MINUS.R=1             ; SUBTRACT R FROM S
;2403            R.MINUS.S=2             ; SUBTRACT S FROM R
;2404            R.OR.S=3                ; OR R WITH S
;2405            R.AND.S=4               ; AND R WITH S
;2406            NOTR.AND.S=5            ; COMPLEMENT R THEN AND WITH S
;2407            R.XOR.S=6               ; XOR R WITH S
;2408            R.XNOR.S=7              ; XOR R WITH S THEN COMPLEMENT THE RESULT
;2409    SRC/=<8:6>,.DEFAULT=<SRC/D.0>
;2410
;2411            0.Q=2                   ; RMX=0         SMX=Q
;2412            0.B=3                   ; RMX=0         SMX=B
;2413            A.Q=0                   ; RMX=A         SMX=Q
;2414            A.B=01                  ; RMX=A         SMX=B
;2415            D.Q=06                  ; RMX=D         SMX=Q
;2416            D.0=7                   ; RMX=D         SMX=0
;2417            0.A=4                   ; RMX=0         SMX=A
;2418            D.A=5                   ; RMX=D         SMX=A
;2419    ;
;2420    ; THIS FIELD CORRESPONDES TO THE 2901 ALU DESTINATION
;2421    ; CONTROL PINS I8, I7 AND I6.
;2422    ;
;2423    DST/=<5:3>,.DEFAULT=<DST/NOP>
;2424
;2425            LOAD.Q=0                ; LOAD Q-REGISTER
;2426            NOP=1                   ; HOLD ALL REGISTERS
;2427            WRITE.B.A=2             ; WRITE RAM B-PORT AND OUTPUT RAM A-PORT
;2428            WRITE.B.F=3             ; WRITE RAM B-PORT AND OUTPUT ALU
;2429            RSHF.RAM.Q=4            ; RIGHT SHIFT RAM AND Q
;2430            RSHF.RAM=5              ; RIGHT SHIFT RAM
;2431            LSHF.RAM.Q=6            ; LEFT SHIFT RAM AND Q
;2432            LSHF.RAM=7              ; LEFT SHIFT RAM
;2433
;2434    CIN/=<9>,.DEFAULT=0
;2435
;2436            NO.CIN=0                ; NO CARRY IN TO ALU
;2437            CIN=1                   ; CARRY IN TO ALU
;2438
;2439
;2440
```

```
                    ;2441   .PAGE
                    ;2442   .TOC    "CONTROL ROM CONTENTS                                   VER 00.01"
                    ;2443   .SEQUENTIAL
                    ;2444   ; THESE ARE THE DATA PATH CONTROL ROM CONTENTS
                    ;2445   ;
                    ;2446   ; THE FOLLOWING LOCATIONS ARE USED BY THE DECODE.IS MICRO INSTRUCTION
                    ;2447   ;
                    ;2448   ; THIS INSTRUCTION WILL DO PC+1 OPERATIONS
                    ;2449   ;
                    ;2450   ;               BACK UP PC IN 2901 RAM
                    ;2451   000:
                    ;2452   DECODE.IS:
C 0000, 3D8         ;2453           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0001, 3D8         ;2454           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0002, 3D8         ;2455           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0003, 3D8         ;2456           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0004, 3D8         ;2457           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0005, 3D8         ;2458           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0006, 3D8         ;2459           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0007, 3D8         ;2460           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0008, 3D8         ;2461           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0009, 3D8         ;2462           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000A, 3D8         ;2463           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000B, 3D8         ;2464           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000C, 3D8         ;2465           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000D, 3D8         ;2466           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000E, 3D8         ;2467           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 000F, 3D8         ;2468           SRC/D.0,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
                    ;2469   ;
                    ;2470   ;               DON'T BACK UP PC
                    ;2471   ;
C 0010, 3C8         ;2472           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0011, 3C8         ;2473           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0012, 3C8         ;2474           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0013, 3C8         ;2475           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0014, 3C8         ;2476           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0015, 3C8         ;2477           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0016, 3C8         ;2478           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0017, 3C8         ;2479           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0018, 3C8         ;2480           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 0019, 3C8         ;2481           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001A, 3C8         ;2482           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001B, 3C8         ;2483           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001C, 3C8         ;2484           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001D, 3C8         ;2485           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001E, 3C8         ;2486           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 001F, 3C8         ;2487           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
```

```
                ;2488   .PAGE
                ;2489   ;  THESE ADDRESSES ARE USED BY THE 'JUMP' MICRO INSTRUCTION
                ;2490   ;
                ;2491   ; THE FOLLOWING CONTROL CODES WILL INSURE THAT NO DATA IS DESTROYED WITHIN
                ;2492   ; THE 2901 DURING JUMP OR JSR OPERATIONS.
                ;2493   ;
                ;2494   020:
                ;2495   JUMP:
C 0020, 3CB     ;2496           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0021, 3CB     ;2497           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0022, 3CB     ;2498           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0023, 3CB     ;2499           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0024, 3CB     ;2500           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0025, 3CB     ;2501           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0026, 3CB     ;2502           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0027, 3CB     ;2503           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0028, 3CB     ;2504           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0029, 3CB     ;2505           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002A, 3CB     ;2506           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002B, 3CB     ;2507           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002C, 3CB     ;2508           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002D, 3CB     ;2509           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002E, 3CB     ;2510           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 002F, 3CB     ;2511           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0030, 3CB     ;2512           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0031, 3CB     ;2513           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0032, 3CB     ;2514           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0033, 3CB     ;2515           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0034, 3CB     ;2516           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0035, 3CB     ;2517           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0036, 3CB     ;2518           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0037, 3CB     ;2519           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0038, 3CB     ;2520           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 0039, 3CB     ;2521           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003A, 3CB     ;2522           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003B, 3CB     ;2523           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003C, 3CB     ;2524           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003D, 3CB     ;2525           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003E, 3CB     ;2526           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
C 003F, 3CB     ;2527           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/CIN
```

```
                    ;2528   .PAGE
                    ;2529   ; THESE LOCATIONS ARE USED BY THE MISC' MICRO INSTRUCTION
                    ;2530   ;
                    ;2531   ; THE FOLLOWING CONTROL CODES WILL INSURE THAT NO DATA IS DESTROYED WITHIN
                    ;2532   ; THE 2901 DURING MISC INSTRUCTION EXECUTION.
                    ;2533   ;
                    ;2534   040:
                    ;2535   MISC:
C 0040, 313         ;2536           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0041, 313         ;2537           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0042, 313         ;2538           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0043, 313         ;2539           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0044, 313         ;2540           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0045, 313         ;2541           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0046, 313         ;2542           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0047, 313         ;2543           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0048, 313         ;2544           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0049, 313         ;2545           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004A, 313         ;2546           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004B, 313         ;2547           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004C, 313         ;2548           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004D, 313         ;2549           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004E, 313         ;2550           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 004F, 313         ;2551           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0050, 313         ;2552           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0051, 313         ;2553           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0052, 313         ;2554           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0053, 313         ;2555           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0054, 313         ;2556           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0055, 313         ;2557           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0056, 313         ;2558           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0057, 313         ;2559           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0058, 313         ;2560           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0059, 313         ;2561           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005A, 313         ;2562           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005B, 313         ;2563           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005C, 313         ;2564           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005D, 313         ;2565           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005E, 313         ;2566           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 005F, 313         ;2567           SRC/0.A,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
```

```
                ;2568   .PAGE
                ;2569   ; THESE ADDRESSES ARE USED BY THE MEM.REQ MICRO INSTRUCTION
                ;2570   ;
                ;2571   ; THIS INSTRUCTION CAUSES WR[5] TO BE LOADED WITH THE VIRTUAL ADDRESS
                ;2572   ; OF THE MEMORY REFERENCE.
                ;2573   060:
                ;2574   MEM.REQ:
C 0060, 3DB     ;2575           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0061, 3DB     ;2576           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0062, 3DB     ;2577           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0063, 3DB     ;2578           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0064, 3DB     ;2579           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0065, 3DB     ;2580           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0066, 3DB     ;2581           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0067, 3DB     ;2582           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0068, 3DB     ;2583           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0069, 3DB     ;2584           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006A, 3DB     ;2585           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006B, 3DB     ;2586           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006C, 3DB     ;2587           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006D, 3DB     ;2588           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006E, 3DB     ;2589           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 006F, 3DB     ;2590           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0070, 3DB     ;2591           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0071, 3DB     ;2592           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0072, 3DB     ;2593           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0073, 3DB     ;2594           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0074, 3DB     ;2595           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0075, 3DB     ;2596           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0076, 3DB     ;2597           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0077, 3DB     ;2598           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0078, 3DB     ;2599           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 0079, 3DB     ;2600           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007A, 3DB     ;2601           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007B, 3DB     ;2602           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007C, 3DB     ;2603           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007D, 3DB     ;2604           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007E, 3DB     ;2605           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 007F, 3DB     ;2606           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
```

```
                    ;2607   .PAGE
                    ;2608   ; THESE ARE THE ADDRESSES FOR THE EXTENDED MICRO INSTRUCTION
                    ;2609   ; ADDRESSES START AT 80-FF
                    ;2610   080:
                    ;2611
                    ;2612   WR.PLUS.0.TO.WR:
C 0080, 118         ;2613           SRC/0.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
                    ;2614   WR.INC.WR:
C 0081, 318         ;2615           SRC/0.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
                    ;2616   WR.NEG.WR:
C 0082, 31A         ;2617           SRC/0.A,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
                    ;2618   WR.COM.WR:
C 0083, 31F         ;2619           SRC/0.A,ALU/R.XNOR.S,DST/WRITE.B.F,CIN/CIN
                    ;2620
                    ;2621   WR.DEC.WR:
C 0084, 119         ;2622           SRC/0.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
                    ;2623   FILL85:
C 0085, 10B         ;2624           SRC/0.A
                    ;2625   MOV.Q.WR:
C 0086, 29B         ;2626           SRC/0.Q,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
                    ;2627   FILL87:
C 0087, 08B         ;2628           SRC/0.Q
                    ;2629
                    ;2630   COND.ADD&SHIFT:
C 0088, 060         ;2631           SRC/A.B,ALU/R.PLUS.S,DST/RSHF.RAM.Q,CIN/NO.CIN
                    ;2632   COND.SUB&SHIFT:
C 0089, 261         ;2633           SRC/A.B,ALU/S.MINUS.R,DST/RSHF.RAM.Q,CIN/CIN
                    ;2634   FILL8A:
C 008A, 04B         ;2635           SRC/A.B
                    ;2636   SHL2:
C 008B, 078         ;2637           SRC/A.B,ALU/R.PLUS.S,DST/LSHF.RAM,CIN/NO.CIN
                    ;2638
                    ;2639   ASHRC:
C 008C, 0E3         ;2640           SRC/0.B,ALU/R.OR.S,DST/RSHF.RAM.Q,CIN/NO.CIN
                    ;2641   ASHR:
C 008D, 2EB         ;2642           SRC/0.B,ALU/R.OR.S,DST/RSHF.RAM,CIN/CIN
                    ;2643   ASHLC:
C 008E, 2F3         ;2644           SRC/0.B,ALU/R.OR.S,DST/LSHF.RAM.Q,CIN/CIN
                    ;2645   ASHL:
C 008F, 2FB         ;2646           SRC/0.B,ALU/R.OR.S,DST/LSHF.RAM,CIN/CIN
                    ;2647
                    ;2648   Q.PLUS.0:
C 0090, 088         ;2649           SRC/0.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
                    ;2650   FILL91:
C 0091, 08B         ;2651           SRC/0.Q
                    ;2652   WR.CMP.Q:
C 0092, 20A         ;2653           SRC/A.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                    ;2654   Q.CMP.WR:
C 0093, 209         ;2655           SRC/A.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                    ;2656
                    ;2657   DEC.Q:
C 0094, 081         ;2658           SRC/0.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/NO.CIN
                    ;2659   INC.Q:
C 0095, 280         ;2660           SRC/0.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/CIN
                    ;2661   NEG.Q:
```

```
C 0096, 282     ;2662           SRC/0.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
                ;2663   COM.Q:
C 0097, 287     ;2664           SRC/0.Q,ALU/R.XNOR.S,DST/LOAD.Q,CIN/CIN
                ;2665
                ;2666   WR.BIT.WR:
C 0098, 04C     ;2667           SRC/A.B,ALU/R.AND.S,DST/NOP,CIN/NO.CIN
                ;2668   WR.CMP.WR:
C 0099, 24A     ;2669           SRC/A.B,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;2670   FILL9A:
C 009A, 04B     ;2671           SRC/A.B
                ;2672   WR.PLUS.WR+1:
C 009B, 258     ;2673           SRC/A.B,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
                ;2674
                ;2675   FILL9C:
C 009C, 04B     ;2676           SRC/A.B
                ;2677   FILL9D:
C 009D, 04B     ;2678           SRC/A.B
                ;2679   FILL9E:
C 009E, 0CB     ;2680           SRC/0.B
                ;2681   FILL9F:
C 009F, 0CB     ;2682           SRC/0.B
                ;2683
                ;2684   WR.PLUS.Q:
C 00A0, 000     ;2685           SRC/A.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
                ;2686   WR.FROM.Q:
C 00A1, 201     ;2687           SRC/A.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
                ;2688   Q.FROM.WR.Q:
C 00A2, 202     ;2689           SRC/A.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
                ;2690   WR.OR.Q:
C 00A3, 203     ;2691           SRC/A.Q,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
                ;2692
                ;2693   WR.AND.Q:
C 00A4, 004     ;2694           SRC/A.Q,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
                ;2695   WR.MASK.Q:
C 00A5, 205     ;2696           SRC/A.Q,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/CIN
                ;2697   WR.XOR.Q:
C 00A6, 206     ;2698           SRC/A.Q,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
                ;2699   FILLA7:
C 00A7, 00B     ;2700           SRC/A.Q
                ;2701
                ;2702   WR.PLUS.WR.Q:
C 00A8, 040     ;2703           SRC/A.B,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
                ;2704   WR.FROM.WR.Q:
C 00A9, 241     ;2705           SRC/A.B,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
                ;2706   FILLAA:
C 00AA, 04B     ;2707           SRC/A.B
                ;2708   WR.OR.WR.Q:
C 00AB, 243     ;2709           SRC/A.B,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
                ;2710
                ;2711   WR.AND.WR.Q:
C 00AC, 044     ;2712           SRC/A.B,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
                ;2713   WR.MASK.WR.Q:
C 00AD, 245     ;2714           SRC/A.B,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/CIN
                ;2715   WR.XOR.WR.Q:
C 00AE, 246     ;2716           SRC/A.B,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
```

```
                ;2717   FILLAF:
C 00AF, 04B     ;2718           SRC/A.B
                ;2719
                ;2720   Q.PLUS.WR:
C 00B0, 018     ;2721           SRC/A.Q,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
                ;2722   WR.FROM.Q.WR:
C 00B1, 219     ;2723           SRC/A.Q,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
                ;2724   Q.FROM.WR:
C 00B2, 21A     ;2725           SRC/A.Q,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
                ;2726   Q.OR.WR:
C 00B3, 21B     ;2727           SRC/A.Q,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
                ;2728
                ;2729   Q.AND.WR:
C 00B4, 01C     ;2730           SRC/A.Q,ALU/R.AND.S,DST/WRITE.B.F,CIN/NO.CIN
                ;2731   FILLB5:
C 00B5, 00B     ;2732           SRC/A.Q
                ;2733   Q.XOR.WR:
C 00B6, 21E     ;2734           SRC/A.Q,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
                ;2735   Q.BIT.WR:
C 00B7, 20C     ;2736           SRC/A.Q,ALU/R.AND.S,DST/NOP,CIN/CIN
                ;2737
                ;2738   WR.PLUS.WR:
C 00B8, 058     ;2739           SRC/A.B,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
                ;2740   WR.FROM.WR:
C 00B9, 259     ;2741           SRC/A.B,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
                ;2742   WR.FROM.WR.WR:
C 00BA, 25A     ;2743           SRC/A.B,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
                ;2744   WR.OR.WR:
C 00BB, 25B     ;2745           SRC/A.B,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
                ;2746
                ;2747   WR.FROM.WR-1:
C 00BC, 059     ;2748           SRC/A.B,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
                ;2749   WR.MASK.WR:
C 00BD, 25D     ;2750           SRC/A.B,ALU/NOTR.AND.S,DST/WRITE.B.F,CIN/CIN
                ;2751   WR.XOR.WR:
C 00BE, 25E     ;2752           SRC/A.B,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
                ;2753   WR.AND.WR:
C 00BF, 25C     ;2754           SRC/A.B,ALU/R.AND.S,DST/WRITE.B.F,CIN/CIN
                ;2755
```

```
                    ;2756   .PAGE
                    ;2757   ; THIS IS THE DP CODES FOR THE 'MOVE' MICRO INSTRUCTION
                    ;2758   ;
                    ;2759   0C0:
                    ;2760
                    ;2761   MOV.MEM.WR:
C 00C0, 1D3         ;2762           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C1, 1D3         ;2763           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C2, 1D3         ;2764           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C3, 1D3         ;2765           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C4, 1D3         ;2766           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C5, 1D3         ;2767           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C6, 1D3         ;2768           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 00C7, 1D3         ;2769           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
                    ;2770
                    ;2771   MOV.LS.MEM:
C 00C8, 1CB         ;2772           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00C9, 1CB         ;2773           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CA, 1CB         ;2774           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CB, 1CB         ;2775           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CC, 1CB         ;2776           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CD, 1CB         ;2777           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CE, 1CB         ;2778           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00CF, 1CB         ;2779           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
                    ;2780
                    ;2781   MOV.XWR.Q:
C 00D0, 0C3         ;2782           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D1, 0C3         ;2783           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D2, 0C3         ;2784           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D3, 0C3         ;2785           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D4, 0C3         ;2786           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D5, 0C3         ;2787           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D6, 0C3         ;2788           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 00D7, 0C3         ;2789           SRC/0.B,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
                    ;2790
                    ;2791   MOV.LS.WR:
C 00D8, 1DB         ;2792           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00D9, 1DB         ;2793           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DA, 1DB         ;2794           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DB, 1DB         ;2795           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DC, 1DB         ;2796           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DD, 1DB         ;2797           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DE, 1DB         ;2798           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
C 00DF, 1DB         ;2799           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.F,CIN/NO.CIN
                    ;2800
```

```
                    ;2801   .PAGE
                    ;2802   MOV.MEM.LS:
C 00E0, 1CB         ;2803           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E1, 1CB         ;2804           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E2, 1CB         ;2805           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E3, 1CB         ;2806           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E4, 1CB         ;2807           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E5, 1CB         ;2808           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E6, 1CB         ;2809           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E7, 1CB         ;2810           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
                    ;2811   MOV.ACC.LS:
C 00E8, 1CB         ;2812           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00E9, 1CB         ;2813           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00EA, 1CB         ;2814           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00EB, 1CB         ;2815           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00EC, 1CB         ;2816           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00ED, 1CB         ;2817           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00EE, 1CB         ;2818           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00EF, 1CB         ;2819           SRC/D.0,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
                    ;2820
                    ;2821
                    ;2822   WR.PLUS.OS:
C 00F0, 148         ;2823           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F1, 148         ;2824           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F2, 148         ;2825           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F3, 148         ;2826           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F4, 148         ;2827           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F5, 148         ;2828           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F6, 148         ;2829           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 00F7, 148         ;2830           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
                    ;2831
                    ;2832   MOV.WR.LS:
C 00F8, 10B         ;2833           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00F9, 10B         ;2834           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FA, 10B         ;2835           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FB, 10B         ;2836           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FC, 10B         ;2837           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FD, 10B         ;2838           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FE, 10B         ;2839           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
C 00FF, 10B         ;2840           SRC/0.A,ALU/R.OR.S,DST/NOP,CIN/NO.CIN
                    ;2841
```

```
                ;2842   .PAGE
                ;2843   ; THIS GROUP OF INSTRUCTIONS IS FOR THE 'BASIC' MICRO INSTRUCTION
                ;2844   ; THIS USES ADDRESSES 100-1FF
                ;2845
                ;2846   100:
                ;2847   LS.PLUS.WR:
C 0100, 158     ;2848           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0101, 158     ;2849           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0102, 158     ;2850           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0103, 158     ;2851           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
                ;2852   LS.FROM.WR:
C 0104, 359     ;2853           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
C 0105, 359     ;2854           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
C 0106, 359     ;2855           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
C 0107, 359     ;2856           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
                ;2857   LS.AND.WR:
C 0108, 35C     ;2858           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.F,CIN/CIN
C 0109, 35C     ;2859           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.F,CIN/CIN
C 010A, 35C     ;2860           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.F,CIN/CIN
C 010B, 35C     ;2861           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.F,CIN/CIN
                ;2862   LS.XOR.WR:
C 010C, 35E     ;2863           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
C 010D, 35E     ;2864           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
C 010E, 35E     ;2865           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
C 010F, 35E     ;2866           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.F,CIN/CIN
                ;2867
                ;2868   LS.FROM.WR-1:
C 0110, 159     ;2869           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
C 0111, 159     ;2870           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
C 0112, 159     ;2871           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
C 0113, 159     ;2872           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/NO.CIN
                ;2873   LS.MASK.WR:
C 0114, 35D     ;2874           SRC/D.A,ALU/NOTR.AND.S,DST/WRITE.B.F,CIN/CIN
C 0115, 35D     ;2875           SRC/D.A,ALU/NOTR.AND.S,DST/WRITE.B.F,CIN/CIN
C 0116, 35D     ;2876           SRC/D.A,ALU/NOTR.AND.S,DST/WRITE.B.F,CIN/CIN
C 0117, 35D     ;2877           SRC/D.A,ALU/NOTR.AND.S,DST/WRITE.B.F,CIN/CIN
                ;2878   LS.PLUS.WR+1:
C 0118, 358     ;2879           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 0119, 358     ;2880           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 011A, 358     ;2881           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
C 011B, 358     ;2882           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/CIN
                ;2883   LS.OR.WR:
C 011C, 35B     ;2884           SRC/D.A,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 011D, 35B     ;2885           SRC/D.A,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 011E, 35B     ;2886           SRC/D.A,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
C 011F, 35B     ;2887           SRC/D.A,ALU/R.OR.S,DST/WRITE.B.F,CIN/CIN
                ;2888
                ;2889   WR.PLUS.LS.Q:
C 0120, 140     ;2890           SRC/D.A,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0121, 140     ;2891           SRC/D.A,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0122, 140     ;2892           SRC/D.A,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0123, 140     ;2893           SRC/D.A,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
                ;2894   LS.FROM.WR.Q:
C 0124, 341     ;2895           SRC/D.A,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
C 0125, 341     ;2896           SRC/D.A,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
```

```
C 0126, 341     ;2897           SRC/D.A,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
C 0127, 341     ;2898           SRC/D.A,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
                ;2899   WR.FROM.LS.Q:
C 0128, 342     ;2900           SRC/D.A,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 0129, 342     ;2901           SRC/D.A,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 012A, 342     ;2902           SRC/D.A,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 012B, 342     ;2903           SRC/D.A,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
                ;2904   WR.OR.LS.Q:
C 012C, 343     ;2905           SRC/D.A,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 012D, 343     ;2906           SRC/D.A,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 012E, 343     ;2907           SRC/D.A,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 012F, 343     ;2908           SRC/D.A,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
                ;2909
                ;2910   WR.AND.LS.Q:
C 0130, 144     ;2911           SRC/D.A,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0131, 144     ;2912           SRC/D.A,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0132, 144     ;2913           SRC/D.A,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0133, 144     ;2914           SRC/D.A,ALU/R.AND.S,DST/LOAD.Q,CIN/NO.CIN
                ;2915   WR.XOR.LS.Q:
C 0134, 346     ;2916           SRC/D.A,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0135, 346     ;2917           SRC/D.A,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0136, 346     ;2918           SRC/D.A,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0137, 346     ;2919           SRC/D.A,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
                ;2920   LS.CMP.WR:
C 0138, 34A     ;2921           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 0139, 34A     ;2922           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 013A, 34A     ;2923           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 013B, 34A     ;2924           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;2925   WR.CMP.LS:
C 013C, 349     ;2926           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 013D, 349     ;2927           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 013E, 349     ;2928           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 013F, 349     ;2929           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                ;2930
                ;2931   LS.PLUS.Q:
C 0140, 180     ;2932           SRC/D.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0141, 180     ;2933           SRC/D.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0142, 180     ;2934           SRC/D.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
C 0143, 180     ;2935           SRC/D.Q,ALU/R.PLUS.S,DST/LOAD.Q,CIN/NO.CIN
                ;2936   LS.FROM.Q:
C 0144, 381     ;2937           SRC/D.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
C 0145, 381     ;2938           SRC/D.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
C 0146, 381     ;2939           SRC/D.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
C 0147, 381     ;2940           SRC/D.Q,ALU/S.MINUS.R,DST/LOAD.Q,CIN/CIN
                ;2941   Q.FROM.LS.Q:
C 0148, 382     ;2942           SRC/D.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 0149, 382     ;2943           SRC/D.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 014A, 382     ;2944           SRC/D.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
C 014B, 382     ;2945           SRC/D.Q,ALU/R.MINUS.S,DST/LOAD.Q,CIN/CIN
                ;2946   LS.OR.Q:
C 014C, 383     ;2947           SRC/D.Q,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 014D, 383     ;2948           SRC/D.Q,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 014E, 383     ;2949           SRC/D.Q,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
C 014F, 383     ;2950           SRC/D.Q,ALU/R.OR.S,DST/LOAD.Q,CIN/CIN
                ;2951
```

```
                    ;2952   LS.MASK.Q:
C 0150, 185         ;2953           SRC/D.Q,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0151, 185         ;2954           SRC/D.Q,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0152, 185         ;2955           SRC/D.Q,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/NO.CIN
C 0153, 185         ;2956           SRC/D.Q,ALU/NOTR.AND.S,DST/LOAD.Q,CIN/NO.CIN
                    ;2957   LS.XOR.Q:
C 0154, 386         ;2958           SRC/D.Q,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0155, 386         ;2959           SRC/D.Q,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0156, 386         ;2960           SRC/D.Q,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
C 0157, 386         ;2961           SRC/D.Q,ALU/R.XOR.S,DST/LOAD.Q,CIN/CIN
                    ;2962   LS.AND.Q:
C 0158, 384         ;2963           SRC/D.Q,ALU/R.AND.S,DST/LOAD.Q,CIN/CIN
C 0159, 384         ;2964           SRC/D.Q,ALU/R.AND.S,DST/LOAD.Q,CIN/CIN
C 015A, 384         ;2965           SRC/D.Q,ALU/R.AND.S,DST/LOAD.Q,CIN/CIN
C 015B, 384         ;2966           SRC/D.Q,ALU/R.AND.S,DST/LOAD.Q,CIN/CIN
                    ;2967   LS.BIT.Q:
C 015C, 38C         ;2968           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/CIN
C 015D, 38C         ;2969           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/CIN
C 015E, 38C         ;2970           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/CIN
C 015F, 38C         ;2971           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/CIN
                    ;2972
                    ;2973   MOV.LS.Q:
C 0160, 1C3         ;2974           SRC/D.0,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 0161, 1C3         ;2975           SRC/D.0,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 0162, 1C3         ;2976           SRC/D.0,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
C 0163, 1C3         ;2977           SRC/D.0,ALU/R.OR.S,DST/LOAD.Q,CIN/NO.CIN
                    ;2978   WR.BIT.LS:
C 0164, 34C         ;2979           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0165, 34C         ;2980           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0166, 34C         ;2981           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0167, 34C         ;2982           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
                    ;2983   LS.CMP.Q:
C 0168, 38A         ;2984           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 0169, 38A         ;2985           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 016A, 38A         ;2986           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 016B, 38A         ;2987           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                    ;2988   Q.CMP.LS:
C 016C, 389         ;2989           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 016D, 389         ;2990           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 016E, 389         ;2991           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 016F, 389         ;2992           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                    ;2993
                    ;2994   Q.PLUS.LS.TO.WR:
C 0170, 198         ;2995           SRC/D.Q,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0171, 198         ;2996           SRC/D.Q,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0172, 198         ;2997           SRC/D.Q,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
C 0173, 198         ;2998           SRC/D.Q,ALU/R.PLUS.S,DST/WRITE.B.F,CIN/NO.CIN
                    ;2999   WRA.FROM.LS.WRB:
C 0174, 35A         ;3000           SRC/D.A,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
C 0175, 35A         ;3001           SRC/D.A,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
C 0176, 35A         ;3002           SRC/D.A,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
C 0177, 35A         ;3003           SRC/D.A,ALU/R.MINUS.S,DST/WRITE.B.F,CIN/CIN
                    ;3004   LS.NEG.WR:
C 0178, 3D9         ;3005           SRC/D.0,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
C 0179, 3D9         ;3006           SRC/D.0,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
```

```
C 017A, 3D9     ;3007           SRC/D.0,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
C 017B, 3D9     ;3008           SRC/D.0,ALU/S.MINUS.R,DST/WRITE.B.F,CIN/CIN
                ;3009   LS.COM.WR:
C 017C, 3DF     ;3010           SRC/D.0,ALU/R.XNOR.S,DST/WRITE.B.F,CIN/CIN
C 017D, 3DF     ;3011           SRC/D.0,ALU/R.XNOR.S,DST/WRITE.B.F,CIN/CIN
C 017E, 3DF     ;3012           SRC/D.0,ALU/R.XNOR.S,DST/WRITE.B.F,CIN/CIN
C 017F, 3DF     ;3013           SRC/D.0,ALU/R.XNOR.S,DST/WRITE.B.F,CIN/CIN
```

```
                    ;3014   .PAGE
                    ;3015   ;
                    ;3016   ; THE FOLLOWING LOCATIONS HAVE THE LOCAL STORE AS THEIR DESTINATION.
                    ;3017   ;
                    ;3018   ; THIS FACT IS USED BY HARDWARE TO GENERATE LOCAL STORE WRITE  PULSES
                    ;3019
                    ;3020   180:
                    ;3021
                    ;3022   LS.PLUS.WR.XCHG:
C 0180, 150         ;3023           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 0181, 150         ;3024           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 0182, 150         ;3025           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 0183, 150         ;3026           SRC/D.A,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
                    ;3027   LS.FROM.WR.XCHG:
C 0184, 351         ;3028           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.A,CIN/CIN
C 0185, 351         ;3029           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.A,CIN/CIN
C 0186, 351         ;3030           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.A,CIN/CIN
C 0187, 351         ;3031           SRC/D.A,ALU/S.MINUS.R,DST/WRITE.B.A,CIN/CIN
                    ;3032   LS.AND.WR.XCHG:
C 0188, 354         ;3033           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.A,CIN/CIN
C 0189, 354         ;3034           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.A,CIN/CIN
C 018A, 354         ;3035           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.A,CIN/CIN
C 018B, 354         ;3036           SRC/D.A,ALU/R.AND.S,DST/WRITE.B.A,CIN/CIN
                    ;3037   LS.XOR.WR.XCHG:
C 018C, 356         ;3038           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.A,CIN/CIN
C 018D, 356         ;3039           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.A,CIN/CIN
C 018E, 356         ;3040           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.A,CIN/CIN
C 018F, 356         ;3041           SRC/D.A,ALU/R.XOR.S,DST/WRITE.B.A,CIN/CIN
                    ;3042
                    ;3043   SWAP.LS.WR:
C 0190, 1D3         ;3044           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 0191, 1D3         ;3045           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 0192, 1D3         ;3046           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
C 0193, 1D3         ;3047           SRC/D.0,ALU/R.OR.S,DST/WRITE.B.A,CIN/NO.CIN
                    ;3048   CLR.LS:
C 0194, 3CC         ;3049           SRC/D.0,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0195, 3CC         ;3050           SRC/D.0,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0196, 3CC         ;3051           SRC/D.0,ALU/R.AND.S,DST/NOP,CIN/CIN
C 0197, 3CC         ;3052           SRC/D.0,ALU/R.AND.S,DST/NOP,CIN/CIN
                    ;3053   MOV.Q.WR&WR.LS:
C 0198, 293         ;3054           SRC/0.Q,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 0199, 293         ;3055           SRC/0.Q,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 019A, 293         ;3056           SRC/0.Q,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
C 019B, 293         ;3057           SRC/0.Q,ALU/R.OR.S,DST/WRITE.B.A,CIN/CIN
                    ;3058   WR.PLUS.Q.XCHG:
C 019C, 010         ;3059           SRC/A.Q,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 019D, 010         ;3060           SRC/A.Q,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 019E, 010         ;3061           SRC/A.Q,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
C 019F, 010         ;3062           SRC/A.Q,ALU/R.PLUS.S,DST/WRITE.B.A,CIN/NO.CIN
                    ;3063
                    ;3064   WR.FROM.LS-1:
C 01A0, 14A         ;3065           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01A1, 14A         ;3066           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01A2, 14A         ;3067           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01A3, 14A         ;3068           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
```

```
                ;3069   LS.FROM.WR.LS:
C 01A4, 349     ;3070           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01A5, 349     ;3071           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01A6, 349     ;3072           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01A7, 349     ;3073           SRC/D.A,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                ;3074   WR.PLUS.LS+1:
C 01A8, 348     ;3075           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01A9, 348     ;3076           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01AA, 348     ;3077           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01AB, 348     ;3078           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/CIN
                ;3079   WR.FROM.LS:
C 01AC, 34A     ;3080           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01AD, 34A     ;3081           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01AE, 34A     ;3082           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01AF, 34A     ;3083           SRC/D.A,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;3084
                ;3085   WR.PLUS.LS:
C 01B0, 148     ;3086           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01B1, 148     ;3087           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01B2, 148     ;3088           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01B3, 148     ;3089           SRC/D.A,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
                ;3090   WR.OR.LS:
C 01B4, 34B     ;3091           SRC/D.A,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01B5, 34B     ;3092           SRC/D.A,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01B6, 34B     ;3093           SRC/D.A,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01B7, 34B     ;3094           SRC/D.A,ALU/R.OR.S,DST/NOP,CIN/CIN
                ;3095   WR.AND.LS:
C 01B8, 34C     ;3096           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 01B9, 34C     ;3097           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 01BA, 34C     ;3098           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
C 01BB, 34C     ;3099           SRC/D.A,ALU/R.AND.S,DST/NOP,CIN/CIN
                ;3100   WR.XOR.LS:
C 01BC, 34E     ;3101           SRC/D.A,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01BD, 34E     ;3102           SRC/D.A,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01BE, 34E     ;3103           SRC/D.A,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01BF, 34E     ;3104           SRC/D.A,ALU/R.XOR.S,DST/NOP,CIN/CIN
                ;3105
                ;3106   Q.PLUS.LS:
C 01C0, 188     ;3107           SRC/D.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01C1, 188     ;3108           SRC/D.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01C2, 188     ;3109           SRC/D.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01C3, 188     ;3110           SRC/D.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
                ;3111   LS.FROM.Q.LS:
C 01C4, 389     ;3112           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01C5, 389     ;3113           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01C6, 389     ;3114           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01C7, 389     ;3115           SRC/D.Q,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                ;3116   Q.FROM.LS:
C 01C8, 38A     ;3117           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01C9, 38A     ;3118           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01CA, 38A     ;3119           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01CB, 38A     ;3120           SRC/D.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;3121   Q.OR.LS:
C 01CC, 38B     ;3122           SRC/D.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01CD, 38B     ;3123           SRC/D.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
```

```
C 01CE, 38B     ;3124           SRC/D.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01CF, 38B     ;3125           SRC/D.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
                ;3126
                ;3127   Q.AND.LS:
C 01D0, 18C     ;3128           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/NO.CIN
C 01D1, 18C     ;3129           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/NO.CIN
C 01D2, 18C     ;3130           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/NO.CIN
C 01D3, 18C     ;3131           SRC/D.Q,ALU/R.AND.S,DST/NOP,CIN/NO.CIN
                ;3132   Q.XOR.LS:
C 01D4, 38E     ;3133           SRC/D.Q,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01D5, 38E     ;3134           SRC/D.Q,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01D6, 38E     ;3135           SRC/D.Q,ALU/R.XOR.S,DST/NOP,CIN/CIN
C 01D7, 38E     ;3136           SRC/D.Q,ALU/R.XOR.S,DST/NOP,CIN/CIN
                ;3137   MOV.Q.LS:
C 01D8, 28B     ;3138           SRC/0.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01D9, 28B     ;3139           SRC/0.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01DA, 28B     ;3140           SRC/0.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
C 01DB, 28B     ;3141           SRC/0.Q,ALU/R.OR.S,DST/NOP,CIN/CIN
                ;3142   Q.NEG.LS:
C 01DC, 28A     ;3143           SRC/0.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01DD, 28A     ;3144           SRC/0.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01DE, 28A     ;3145           SRC/0.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01DF, 28A     ;3146           SRC/0.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;3147
                ;3148   WR.COM.LS:
C 01E0, 0CF     ;3149           SRC/0.B,ALU/R.XNOR.S,DST/NOP,CIN/NO.CIN
C 01E1, 0CF     ;3150           SRC/0.B,ALU/R.XNOR.S,DST/NOP,CIN/NO.CIN
C 01E2, 0CF     ;3151           SRC/0.B,ALU/R.XNOR.S,DST/NOP,CIN/NO.CIN
C 01E3, 0CF     ;3152           SRC/0.B,ALU/R.XNOR.S,DST/NOP,CIN/NO.CIN
                ;3153   WR.NEG.LS:
C 01E4, 2CA     ;3154           SRC/0.B,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01E5, 2CA     ;3155           SRC/0.B,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01E6, 2CA     ;3156           SRC/0.B,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01E7, 2CA     ;3157           SRC/0.B,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;3158   Q.PLUS.WR.TO.LS:
C 01E8, 008     ;3159           SRC/A.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01E9, 008     ;3160           SRC/A.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01EA, 008     ;3161           SRC/A.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
C 01EB, 008     ;3162           SRC/A.Q,ALU/R.PLUS.S,DST/NOP,CIN/NO.CIN
                ;3163   Q.FROM.WR.TO.LS:
C 01EC, 20A     ;3164           SRC/A.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01ED, 20A     ;3165           SRC/A.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01EE, 20A     ;3166           SRC/A.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
C 01EF, 20A     ;3167           SRC/A.Q,ALU/R.MINUS.S,DST/NOP,CIN/CIN
                ;3168
                ;3169   DEC.LS:
C 01F0, 1CA     ;3170           SRC/D.0,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01F1, 1CA     ;3171           SRC/D.0,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01F2, 1CA     ;3172           SRC/D.0,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
C 01F3, 1CA     ;3173           SRC/D.0,ALU/R.MINUS.S,DST/NOP,CIN/NO.CIN
                ;3174   COM.LS:
C 01F4, 3CF     ;3175           SRC/D.0,ALU/R.XNOR.S,DST/NOP,CIN/CIN
C 01F5, 3CF     ;3176           SRC/D.0,ALU/R.XNOR.S,DST/NOP,CIN/CIN
C 01F6, 3CF     ;3177           SRC/D.0,ALU/R.XNOR.S,DST/NOP,CIN/CIN
C 01F7, 3CF     ;3178           SRC/D.0,ALU/R.XNOR.S,DST/NOP,CIN/CIN
```

```
                    ;3179   NEG.LS:
C 01F8, 3C9         ;3180           SRC/D.0,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01F9, 3C9         ;3181           SRC/D.0,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01FA, 3C9         ;3182           SRC/D.0,ALU/S.MINUS.R,DST/NOP,CIN/CIN
C 01FB, 3C9         ;3183           SRC/D.0,ALU/S.MINUS.R,DST/NOP,CIN/CIN
                    ;3184   INC.LS:
C 01FC, 3C8         ;3185           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01FD, 3C8         ;3186           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01FE, 3C8         ;3187           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
C 01FF, 3C8         ;3188           SRC/D.0,ALU/R.PLUS.S,DST/NOP,CIN/CIN
                    ;3189
                    ;3190   .UCODE
```

```
;3191   .PAGE   "DIAGNOSTIC MACROS AND DEFINITIONS"
;3192
;3193   D.ADRS/=<15:9>,.VALIDITY=<D.VAL>,.DEFAULT=0
;3194
;3195
;3196           SAV.WR0=1               ; STORAGE FOR WR0
;3197           SAV.WR1=2               ; STORAGE FOR WR1
;3198           SAV.WR2=3               ; STORAGE FOR WR2
;3199           SAV.WR3=4               ; STORAGE FOR WR3
;3200           T5.SUB=5                ; RESERVED FOR COMMON SUBROUTINES
;3201           T6.SUB=6                ; RESERVED FOR COMMON SUBROUTINES
;3202           T7.SUB=7                ; RESERVED FOR COMMON SUBROUTINES
;3203           TRANSFER.POINTER=7      ; POINTER FOR TRANSFER ROUTINE
;3204           MEMORY.SIZE=7           ; STORAGE FOR MEMORY SIZE IN 256KB BLOCKS AFTER
;3205                                   ;  SIZING
;3206           FPA.FOUND=7             ; STORAGE FOR RESULT OF SIZING FOR FPA PRESENT
;3207           UBE.FOUND=7             ; STORAGE FOR RESULT OF SIZING FOR UBE PRESENT
;3208           T8=8                    ; TEMP LOCATION 8
;3209           T9=9                    ; TEMP LOCATION 9
;3210           T10=0A                  ; TEMP LOCATION 10
;3211           T11=0B                  ; TEMP LOCATION 11
;3212           T12=0C                  ; TEMP LOCATION 12
;3213           T13=0D                  ; TEMP LOCATION 13
;3214           T14=0E                  ; TEMP LOCATION 14
;3215           T15=0F                  ; TEMP LOCATION 15
;3216           PC=10                   ; MACRO PROGRAM COUNTER
;3217
;3218           WR.BACKUP=11            ; BACKUP WR FOR MOV MEM.DATA TO WR[]
;3219           MM.LASTADDR+1=12        ; STORAGE OF LAST ADDRESS IN MAIN MEMORY PLUS
;3220                                   ;  1 (FIRST NON-EXISTANT MEMORY ADDRESS)
;3221           #FF=13                  ; MASK
;3222           #FFFF=14                ; MASK
;3223           #FF000000=15            ; MASK
;3224           #FFFFFF00=16            ; MASK
;3225           CSR0.MASK=16            ; MASK
;3226           CSR1.MASK=17            ; MASK (01003FFF)
;3227           CSR2.MASK=18            ; MASK (7FFE3FFF)
;3228           #FE7FFFFF=19            ; MASK
;3229           UBS.SET=1A              ; CONSTANT (7FF80000) USED BY UBS ADDRESS TEST
;3230           UBS.DATA=1B             ; MASK (7FFF8000) USED AS ERROR MASK FOR UBS
;3231                                   ; DATA TEST
;3232
;3233           ERR.CON.NA=1E           ; CONSTANT OF 800500(H) BITS 23,10,8 SET FOR
;3234                                   ; LOADING CONTROL AND STATUS REG IN INITIAL
;3235                                   ; TESTS
;3236           ERR.CON=1F              ; CONSTANT OF 500(H) BITS 10 & 8 SET FOR
;3237                                   ; LOADING CONTROL AND STATUS REG IN INITIAL
;3238                                   ; TESTS
;3239
;3240           #1=20                   ; PATTERN 00000001 (HEX)
;3241           #2=21                   ; PATTERN 00000002
;3242           #4=22                   ; PATTERN 00000004
;3243           #8=23                   ; PATTERN 00000008
;3244           #10=24                  ; PATTERN 00000010
;3245           #20=25                  ; PATTERN 00000020
```

```
;3246            #40=26                  ; PATTERN 00000040
;3247            #80=27                  ; PATTERN 00000080
;3248            #100=28                 ; PATTERN 00000100
;3249            #200=29                 ; PATTERN 00000200
;3250            #400=2A                 ; PATTERN 00000400
;3251            #800=2B                 ; PATTERN 00000800
;3252            #1000=2C                ; PATTERN 00001000
;3253            #2000=2D                ; PATTERN 00002000
;3254            #4000=2E                ; PATTERN 00004000
;3255            #8000=2F                ; PATTERN 00008000
;3256            #10000=30               ; PATTERN 00010000
;3257            #20000=31               ; PATTERN 00020000
;3258            #40000=32               ; PATTERN 00040000
;3259            #80000=33               ; PATTERN 00080000
;3260            #100000=34              ; PATTERN 00100000
;3261            #200000=35              ; PATTERN 00200000
;3262            #400000=36              ; PATTERN 00400000
;3263            #800000=37              ; PATTERN 00800000
;3264            #1000000=38             ; PATTERN 01000000
;3265            #2000000=39             ; PATTERN 02000000
;3266            #4000000=3A             ; PATTERN 04000000
;3267            #8000000=3B             ; PATTERN 08000000
;3268            #10000000=3C            ; PATTERN 10000000
;3269            #20000000=3D            ; PATTERN 20000000
;3270            #40000000=3E            ; PATTERN 40000000
;3271            #80000000=3F            ; PATTERN 80000000
;3272
;3273            BIT0=20                 ; PATTERN 00000001
;3274            BIT1=21                 ; PATTERN 00000002
;3275            BIT2=22                 ; PATTERN 00000004
;3276            BIT3=23                 ; PATTERN 00000008
;3277            BIT4=24                 ; PATTERN 00000010
;3278            BIT5=25                 ; PATTERN 00000020
;3279            BIT6=26                 ; PATTERN 00000040
;3280            BIT7=27                 ; PATTERN 00000080
;3281            BIT8=28                 ; PATTERN 00000100
;3282            BIT9=29                 ; PATTERN 00000200
;3283            BIT10=2A                ; PATTERN 00000400
;3284            BIT11=2B                ; PATTERN 00000800
;3285            BIT12=2C                ; PATTERN 00001000
;3286            BIT13=2D                ; PATTERN 00002000
;3287            BIT14=2E                ; PATTERN 00004000
;3288            BIT15=2F                ; PATTERN 00008000
;3289            BIT16=30                ; PATTERN 00010000
;3290            BIT17=31                ; PATTERN 00020000
;3291            BIT18=32                ; PATTERN 00040000
;3292            BIT19=33                ; PATTERN 00080000
;3293            BIT20=34                ; PATTERN 00100000
;3294            BIT21=35                ; PATTERN 00200000
;3295            BIT22=36                ; PATTERN 00400000
;3296            BIT23=37                ; PATTERN 00800000
;3297            BIT24=38                ; PATTERN 01000000
;3298            BIT25=39                ; PATTERN 02000000
;3299            BIT26=3A                ; PATTERN 04000000
;3300            BIT27=3B                ; PATTERN 08000000
```

```
;3301            BIT28=3C                ; PATTERN 10000000
;3302            BIT29=3D                ; PATTERN 20000000
;3303            BIT30=3E                ; PATTERN 40000000
;3304            BIT31=3F                ; PATTERN 80000000
;3305
;3306
;3307    ;CSR ADDRESS MNEMONICS
;3308
;3309            CSR0=4E                 ; ALL BITS CLEAR TO ACCESS CSR 0
;3310            CSR1=22                 ; BIT 2 SET TO ACCESS CSR 1
;3311            CSR2=23                 ; BIT 3 SET TO ACCESS CSR 2
;3312
;3313    ;CONTROL AND STATUS WORD BITS
;3314
;3315            PRINT.UBE=26            ; PRINT IF UBE PRESENT OR NOT PRESENT (BIT 6)
;3316                                    ;  (INDICATOR IN LS 7)
;3317            PRINT.R80=27            ; PRINT IF R80 PRESENT OR NOT PRESENT AND ON
;3318                                    ; WHICH DRIVE (BIT 7).  INDICATOR IN LS 7,
;3319                                    ; DRIVE NUMBER IN LS 6.
;3320            ERROR=28                ; TEST ERROR INDICATION (BIT 8)
;3321            SET.PA.ERR=29           ; TELLS CONSOLE TO CREATE A PARITY ERROR AT WCS
;3322                                    ;  ADDRESS POINTED TO BY LS 7 (BIT 9)
;3323            CONSOLE.LOE=2A          ; INDICATES CONSOLE DOES ERROR LOOPING (BIT 10)
;3324                                    ;  (FOR INITIAL TESTS)
;3325            PRINT.MEM.SIZE=2B       ; PRINT MEMORY SIZE IN 256K BLOCKS (BIT 11)
;3326                                    ;  (SIZE IN LS 7)
;3327            PRINT.FPA=2C            ; PRINT IF FPA PRESENT OR NOT PRESENT (BIT 12)
;3328                                    ;  (INDICATOR IN LS 7)
;3329            XFER.DATA=2D            ; INDICATES A DATA TRANSFER TO LS OR MM (BIT 13)
;3330            EOS=2E                  ; END OF SECTION (BIT 14)
;3331            BEGIN.TEST=2F           ; BEGINNING OF TEST (BIT 15)
;3332            INTERUPT.EN=30          ; ENABLE INTERUPT OR SIGNAL SPECIFIED BY BITS
;3333                                    ;  17 THRU 22 AND 28 THRU 30 (BIT 16)
;3334
;3335             CONSOLE.HALT=31        ;   CONSOLE HALT INTERRUPT (BIT 17)
;3336             PWR.FAIL=32            ;   PWR FAIL INT (BIT 18)
;3337             INTERVAL.TIM=33        ;   INTRVL TIM INT (BIT 19)
;3338             CONSOLE.ATTN=34        ;   CONSOLE ATTN INTERRUPT (BIT 20)
;3339             CONSOLE.ACK=35         ;   CONSOLE ACK INTERRUPT (BIT 21)
;3340             DISABLE.MEM.REF=36     ;   DISABLE MEMORY REFERANCES (BIT 22)
;3341             CINIT=3C               ;   UNIBUS INIT SIGNAL TO THE MCT (BIT 28)
;3342             UBS.DCLO=3D            ;   UNIBUS DC LO INDICATION TO THE MCT (BIT 29)
;3343             UBS.BBSY=3E            ;   UNIBUS BUS BUSY INDICATOR TO MCT (BIT 30)
;3344
;3345            NA.EXP.REC=37           ; PRINT N/A UNDER EXPECTED AND RECEIVED (BIT 23)
;3346            OTHER.DATA=38           ; PRINT A VALUE UNDER OTHER DATA (BIT 24)
;3347            CONSOLE.LOOP=39         ; CONSOLE PERFORMS A LOOP ACCORDING TO LOOP
;3348                                    ; COUNT IN LS (BIT 25)
;3349            PRINT.CRD=3A            ; PRINT NUMBER OF SINGLE BIT ERRORS (BIT 26)
;3350            CLR.PA.ERR=3B           ; TELLS CONSOLE TO CLEAR PARITY ERROR AT WCS
;3351                                    ;  ADDRESS POINTED TO BY LS 7 (BIT 27)
;3352            PRINT.IDC=3F            ; PRINT IF IDC PRESENT OR NOT PRESENT (BIT 31)
;3353                                    ;  (INDICATOR IN LS 7)
;3354
;3355    ;MODULE CODES
```

```
;3356
;3357            WCS=20                  ; MODULE CODE FOR WCS BOARD (BIT 0 SET)
;3358            CPU=21                  ; MODULE CODE FOR CPU BOARD (BIT 1 SET)
;3359            MCT=22                  ; MODULE CODE FOR MCT BOARD (BIT 2 SET)
;3360            FPA=23                  ; MODULE CODE FOR FPA BOARD (BIT 3 SET)
;3361            ARRAY=24                ; MODULE CODE FOR ARRAY BOARD (BIT 4 SET)
;3362            IDC=25                  ; MODULE CODE FOR IDC BOARD (BIT 5 SET)
;3363
;3364    ;CSR 1 ERROR BITS
;3365
;3366            VALID.ERR=2E            ; VALID NOT SET IF 1 (BIT 14)
;3367            TB.PAR.ERR=2F           ; TB PARITY ERROR (BIT 15)
;3368            NXM=30                  ; NON-EXISTANT MEMORY ERROR (BIT 16)
;3369            UB.BSY=31               ; UNIBUS BUSY (BIT 17)
;3370            ADP.REG=32              ; UNIBUS ADAPTER REGISTER SELECT (BIT 18)
;3371            WR.ACROSS.PG=33         ; WRITE ACROSS PAGE BOUNDARY ERROR (BIT 19)
;3372            OP.ERR=34               ; OPERATION ERROR (BIT 20)
;3373            TB.MISS=35              ; TB MISS (VIRTUAL ADDRESS TRANSLATION NOT IN
;3374                                    ;   BUFFER) (BIT 21)
;3375            ACCESS.REFUSED=36       ; PROTECTION ERROR ON ACCESS (BIT 22)
;3376            MODIFY.REFUSED=37       ; PROTECTION ERROR ON WRITE (BIT 23)
;3377
;3378            CRD=3E                  ; SINGLE BIT ERROR CORRECTED (BIT 30)
;3379            RDS=3F                  ; UNCORRECTABLE DATA ERROR (BIT 31)
;3380
;3381
;3382    ;CSR 1 CONTROL BITS
;3383
;3384            ECC.DIS=39              ; CSR1 ECC DISABLE BIT (BIT 25)
;3385            DIAG.CHK=3A             ; CSR1 DIAG CHK BIT (BIT 26)
;3386            MME=3B                  ; CSR1 MEMORY MANAGMENT ENABLE BIT (BIT 27)
;3387            INH.CRD=3C              ; CSR1 INHIBIT REPORT CRD BIT (BIT 28)
;3388            TB.PAR.DIAG=3D          ; CSR1 TB PAR DIAG BIT (FORCE TB PARITY ERR)
;3389                                    ;  (BIT 29)
;3390
;3391
;3392    ;UBE CONTROL REGISTER BITS
;3393
;3394      ;CONTROL REG 1
;3395            GO=20                   ; START UBE (BIT 0)
;3396            BR4=21                  ; ISSUE BUS REQUEST 4 (BIT 1)
;3397            BR5=22                  ; ISSUE BUS REQUEST 5 (BIT 2)
;3398            BR6=23                  ; ISSUE BUS REQUEST 6 (BIT 3)
;3399            BR7=24                  ; ISSUE BUS REQUEST 7 (BIT 4)
;3400            NPR=25                  ; ISSUE NPR (BIT 5)
;3401            INT.ODNE=26             ; INTERRUPT ON DONE (WHEN CCOVF) (BIT 6)
;3402            RDY=27                  ; READY BIT, SET WHEN READY TO BEGIN FUNC (BIT 7)
;3403            C00=28                  ; C0 BIT (BIT 8)
;3404            C01=29                  ; C1 BIT (BIT 9)
;3405            FUNA=2A                 ; FUNCTION BIT A (BIT 10
;3406            FUNB=2B                 ; FUNCTION BIT B (BIT 11)
;3407            CC+DAT=2C               ; DATA FROM CYCLE COUNT IF SET, DATA REG IF CLEAR
;3408            INH.DATIP.ROL=2D        ; INHIBIT ROL ON DATIP (BIT 13)
;3409            DATOB.ON.DATIP=2E       ; DO DATOB AFTER DATIP CYCLE (BIT 14)
;3410            ERR=2F                  ; EXERCISOR OR UNIBUS ERROR (BIT 15)
```

```
;3411
;3412      ;CONTROL REG 2
;3413            EXT.MEM0=20             ; EXTENDED MEMORY BIT 0 (BIT 0)
;3414            EXT.MEM1=21             ; EXTENDED MEMORY BIT 1 (BIT 1)
;3415            INH.INC.ADDR&CC=22      ; INHIBIT INC ON CYCLE COUNT AND ADDR REG (BIT 2)
;3416            INH.SACK=23             ; INHIBIT ASSERING BUS SACK ON BUS GRANT (BIT 3)
;3417            PWR.DWN.SEQ=24          ; ASSERT ACLO (BIT 4)
;3418            WNG.GNT.BCK=25          ; NO BUS GRANT RECV TO HIGEST REQUEST (BIT 5)
;3419            MAX.LATE.ERR=26         ; NPR AND BR LATENCY TIME EXCEEDED (BIT 6)
;3420            NO.SACK.ERR=27          ; NO TIMEOUT AT CPU WHEN NO SACK (BIT 7)
;3421            NO.SSYN.ERR=28          ; NO SSYN RECEIVED AFTER ASSERTING MSYN (BIT 8)
;3422            WRG.A.LINES=29          ; ADDRESS ERR ON SENT & RECEIVED ADDRESS (BIT 9)
;3423            NO.GNT+NOT.ONE.GNT=2A   ; NO GRANT OR MORE THAN 1 GRANT AFTER REQ. (BIT 10)
;3424            INTR.SSYN.ERR=2B        ; NO SSYN RECEIVED AFTER BUS INTR (BIT 11)
;3425            ENB.PB=2C               ; ENABLE PARITY BIT B (BIT 12)
;3426            CCOVF=2D                ; CYCLE COUNT OVERFLOW (BIT 13)
;3427            TM.DLY=2E               ; REQUEST BUS EVERY 10 USEC (BIT 14)
;3428
;3429      ;BG6 MNEMONIC
;3430            BG6=23                  ; BIT 3 SET FOR BG 6 ADDRESS
;3431
;3432      ;ERROR AND CONTROL INFORMATION
;3433
;3434            CONTROL.STATUS=40       ; CONTROL AND STATUS WORD
;3435            ERROR.NUMBER=41         ; ERROR NUMBER OF CURRENT TEST
;3436            EXPECTED.DATA=42        ; EXPECTED RESULT OF CURRENT TEST
;3437            RECEIVED.DATA=43        ; ACTUAL RESULT OF CURRENT TEST
;3438            ADDRESS.DATA=44         ; OTHER PERTINENT DATA
;3439            ERROR.MASK=45           ; BITS TO CHECK IN RESULT
;3440            MODULE.NUM=46           ; STORAGE OF MODULE NUMBER (CODED)
;3441            LOOP.CNT=47             ; STORAGE OF LOOP COUNT FOR CONSOLE LOOP
;3442                                    ; CONTROL.
;3443            ERROR.CONTROL=48        ; STORAGE FOR ERROR CONTROL (LOOP ON ERROR ETC.)
;3444             LOE=20                 ;  LOOP ON ERROR IF SET (BIT0)
;3445             NER=21                 ;  NO ERROR REPORT IF SET (BIT1)
;3446             BELL=22                ;  BELL ON ERROR IF SET (BIT2)
;3447             HOE=23                 ;  HALT ON ERROR IF SET (BIT3)
;3448             SER=24                 ;  ENABLE ERROR REPORT ON CRD ERRORS IF SET
;3449             APT.PRESENT=25         ;  APT PRESENT IF SET (BIT5)
;3450             LOOP.COMMAND=26        ;  LOOP COMMAND TYPED IF SET (BIT 6)
;3451             SPECIAL=27             ;  SPECIAL BIT FOR LOOP ON SIZE TESTS (BIT 7)
;3452
;3453            APT.PARAM=49            ;APT RUN TIME PARAMETER REGS (MEM SIZE, HARD-
;3454                                    ; WARE CONFIG, SOFTWARE CONFIG IN BYTES 0, 1
;3455                                    ; AND 2 RESPECTIVELY. BYTE 3 FOR FUTURE USE)
;3456            APT.RESERVED=4A         ;RESERVED FOR FUTURE APT USE
;3457
;3458      ;MISCELLANEOUS CONSTANTS AND STORAGE
;3459
;3460            #AAAAAAAA=4C            ; CONSTANT
;3461            ALTER.ODD=4C            ; CONSTANT
;3462            #55555555=4D            ; CONSTANT
;3463            ALTER.EVEN=4D           ; CONSTANT
;3464            #0=4E                   ; CONSTANT
;3465            ZERO=4E                 ; CONSTANT
```

```
;3466            #FFFFFFFF=4F            ; CONSTANT
;3467            ONES=4F                 ; CONSTANT
;3468            PREVIOUS.ERROR=50       ; ERROR NUMBER OF LAST ERROR
;3469
;3470            DATA.1=51               ; STORAGE FOR FPA DATA
;3471            DATA.2=52               ; STORAGE FOR FPA DATA
;3472            DATA.3=53               ; STORAGE FOR FPA DATA
;3473            FIRST.FLT=54            ; STORAGE FOR FPA DATA
;3474            SEC.FLT=55              ; STORAGE FOR FPA DATA
;3475            THIRD.FLT=56            ; STORAGE FOR FPA DATA
;3476            T57=57                  ; TEMP LOCATION 57
;3477            T58=58                  ; TEMP LOCATION 58
;3478            T59=59                  ; TEMP LOCATION 59
;3479
;3480            BEDB=5A                 ;UBE (BUS EXERCISOR) DATA BUF REG
;3481            BECC=5B                 ;UBE (BUS EXERCISOR) CYCLE COUNT REG
;3482            BEBA=5C                 ;UBE (BUS EXERCISOR) ADDR REG
;3483            BECR1=5D                ;UBE (BUS EXERCISOR) CONTROL REG 1
;3484            CLEAR.ERR.ADDR=5E       ;UBE CLEAR ERROR REG ADDRESS
;3485            BECR2=5F                ;UBE (BUS EXERCISOR) CONTROL REG 2
;3486
;3487            #3(H)=60                ; CONSTANT
;3488            #12(H)=61               ; CONSTANT
;3489            #33333333=62            ; CONSTANT
;3490            #0F0F0F0F=63            ; CONSTANT
;3491            #00FF00FF=64            ; CONSTANT
;3492            #162(H)=65              ; CONSTANT FOR LS TRANSFER POINTER
;3493            BR7.IDENT=66            ; BR7 IDENTIFIER (1010(B) IN BITS 5-2)
;3494            BG7=67                  ; BG7 ADDRESS (BITS 2 AND 3 SET)
;3495
;3496    ;TEMPS FOR CPU TESTS
;3497            L30=30                  ;LS 30 TEMP (RESTORED TO 10000 AFTER USE)
;3498            L31=31                  ;LS 31 TEMP (RESTORE TO 20000 AFTER USE)
;3499            L53=53                  ;LS 53 TEMP
;3500            L73=73                  ;LS 73 TEMP
;3501
;3502    ;REGISTER ADDRESSES
;3503
;3504            CONTROL.OS=78           ; HARDWARE INDEX TO CONTROL WORDS (LS 40-4F)
;3505            SHIFT.OS(3-0)=79        ; 16 LOCATION HARDWARE INDEX TO SHIFT PATTERN
;3506                                    ;  (LS 20-2F)
;3507            SHIFT.OS(4-0)=7B        ; 32 LOCATION HARDWARE INDEX TO SHIFT PATTERN
;3508                                    ;  (LS 20-3F)
;3509            OS=7C                   ; OS REGISTER
;3510            DEC.CON=7D              ; DECIMAL CARRIES
;3511            SIZE=7E                 ; SIZE REGISTER
;3512            MDT= 7E                 ; MEMORY REFERENCE DATA SIZE
;3513            INTERRUPT.VEC=7E        ; HARDWARE INTERRUPT VECTOR
;3514    ;
;3515    ;       THIS WORD IS THE HARDWARE CONDITION CODES.  THE CC'S CAN BE READ
;3516    ;       OR ARE WRITTEN HERE.  NO OTHER BITS IN THE PSL ARE EFFECTED.
;3517    ;
;3518            PSL.CC=7F               ; PSL CONDITION CODES
```

```
;3519    .PAGE
;3520    XD.ADRS/=<16:9>,.VALIDITY=<XD.VAL>
;3521
;3522
;3523            SAV.WR0=1               ; STORAGE FOR WR0
;3524            SAV.WR1=2               ; STORAGE FOR WR1
;3525            SAV.WR2=3               ; STORAGE FOR WR2
;3526            SAV.WR3=4               ; STORAGE FOR WR3
;3527            T5.SUB=5                ; RESERVED FOR COMMON SUBROUTINES
;3528            T6.SUB=6                ; RESERVED FOR COMMON SUBROUTINES
;3529            T7.SUB=7                ; RESERVED FOR COMMON SUBROUTINES
;3530            TRANSFER.POINTER=7      ; POINTER FOR TRANSFER ROUTINE
;3531            MEMORY.SIZE=7           ; STORAGE FOR MEMORY SIZE IN 256KB BLOCKS AFTER
;3532                                    ;  SIZING
;3533            FPA.FOUND=7             ; STORAGE FOR RESULT OF SIZING FOR FPA PRESENT
;3534            UBE.FOUND=7             ; STORAGE FOR RESULT OF SIZING FOR UBE PRESENT
;3535            T8=8                    ; TEMP LOCATION 8
;3536            T9=9                    ; TEMP LOCATION 9
;3537            T10=0A                  ; TEMP LOCATION 10
;3538            T11=0B                  ; TEMP LOCATION 11
;3539            T12=0C                  ; TEMP LOCATION 12
;3540            T13=0D                  ; TEMP LOCATION 13
;3541            T14=0E                  ; TEMP LOCATION 14
;3542            T15=0F                  ; TEMP LOCATION 15
;3543            PC=10                   ; MACRO PROGRAM COUNTER
;3544
;3545            WR.BACKUP=11            ; BACKUP WR FOR MOV MEM.DATA TO WR[]
;3546            MM.LASTADDR+1=12        ; STORAGE OF LAST ADDRESS IN MAIN MEMORY PLUS
;3547                                    ;  1 (FIRST NON-EXISTANT MEMORY ADDRESS)
;3548            #FF=13                  ; MASK
;3549            #FFFF=14                ; MASK
;3550            #FF000000=15            ; MASK
;3551            #FFFFFF00=16            ; MASK
;3552            CSR0.MASK=16            ; MASK
;3553            CSR1.MASK=17            ; MASK (01003FFF)
;3554            CSR2.MASK=18            ; MASK (FFFE3FFF)
;3555            #FE7FFFFF=19            ; MASK
;3556            UBS.SET=1A              ; CONSTANT (7FF80000) USED BY UBS ADDRESS TEST
;3557            UBS.DATA=1B             ; MASK (7FFF8000) USED AS ERROR MASK FOR UBS
;3558                                    ; DATA TEST
;3559
;3560            ERR.CON.NA=1E           ; CONSTANT OF 800500(H) BITS 23,10,8 SET FOR
;3561                                    ; LOADING CONTROL AND STATUS REG IN INITIAL
;3562                                    ; TESTS
;3563            ERR.CON=1F              ; CONSTANT OF 500(H) BITS 10 & 8 SET FOR
;3564                                    ; LOADING CONTROL AND STATUS REG IN INITIAL
;3565                                    ; TESTS
;3566
;3567            #1=20                   ; PATTERN 00000001 (HEX)
;3568            #2=21                   ; PATTERN 00000002
;3569            #4=22                   ; PATTERN 00000004
;3570            #8=23                   ; PATTERN 00000008
;3571            #10=24                  ; PATTERN 00000010
;3572            #20=25                  ; PATTERN 00000020
;3573            #40=26                  ; PATTERN 00000040
```

```
;3574            #80=27                  ; PATTERN 00000080
;3575            #100=28                 ; PATTERN 00000100
;3576            #200=29                 ; PATTERN 00000200
;3577            #400=2A                 ; PATTERN 00000400
;3578            #800=2B                 ; PATTERN 00000800
;3579            #1000=2C                ; PATTERN 00001000
;3580            #2000=2D                ; PATTERN 00002000
;3581            #4000=2E                ; PATTERN 00004000
;3582            #8000=2F                ; PATTERN 00008000
;3583            #10000=30               ; PATTERN 00010000
;3584            #20000=31               ; PATTERN 00020000
;3585            #40000=32               ; PATTERN 00040000
;3586            #80000=33               ; PATTERN 00080000
;3587            #100000=34              ; PATTERN 00100000
;3588            #200000=35              ; PATTERN 00200000
;3589            #400000=36              ; PATTERN 00400000
;3590            #800000=37              ; PATTERN 00800000
;3591            #1000000=38             ; PATTERN 01000000
;3592            #2000000=39             ; PATTERN 02000000
;3593            #4000000=3A             ; PATTERN 04000000
;3594            #8000000=3B             ; PATTERN 08000000
;3595            #10000000=3C            ; PATTERN 10000000
;3596            #20000000=3D            ; PATTERN 20000000
;3597            #40000000=3E            ; PATTERN 40000000
;3598            #80000000=3F            ; PATTERN 80000000
;3599
;3600            BIT0=20                 ; PATTERN 00000001
;3601            BIT1=21                 ; PATTERN 00000002
;3602            BIT2=22                 ; PATTERN 00000004
;3603            BIT3=23                 ; PATTERN 00000008
;3604            BIT4=24                 ; PATTERN 00000010
;3605            BIT5=25                 ; PATTERN 00000020
;3606            BIT6=26                 ; PATTERN 00000040
;3607            BIT7=27                 ; PATTERN 00000080
;3608            BIT8=28                 ; PATTERN 00000100
;3609            BIT9=29                 ; PATTERN 00000200
;3610            BIT10=2A                ; PATTERN 00000400
;3611            BIT11=2B                ; PATTERN 00000800
;3612            BIT12=2C                ; PATTERN 00001000
;3613            BIT13=2D                ; PATTERN 00002000
;3614            BIT14=2E                ; PATTERN 00004000
;3615            BIT15=2F                ; PATTERN 00008000
;3616            BIT16=30                ; PATTERN 00010000
;3617            BIT17=31                ; PATTERN 00020000
;3618            BIT18=32                ; PATTERN 00040000
;3619            BIT19=33                ; PATTERN 00080000
;3620            BIT20=34                ; PATTERN 00100000
;3621            BIT21=35                ; PATTERN 00200000
;3622            BIT22=36                ; PATTERN 00400000
;3623            BIT23=37                ; PATTERN 00800000
;3624            BIT24=38                ; PATTERN 01000000
;3625            BIT25=39                ; PATTERN 02000000
;3626            BIT26=3A                ; PATTERN 04000000
;3627            BIT27=3B                ; PATTERN 08000000
;3628            BIT28=3C                ; PATTERN 10000000
```

```
;3629            BIT29=3D                ; PATTERN 20000000
;3630            BIT30=3E                ; PATTERN 40000000
;3631            BIT31=3F                ; PATTERN 80000000
;3632
;3633
;3634    ;CSR ADDRESS MNEMONICS
;3635
;3636            CSR0=4E                 ; ALL BITS CLEAR TO ACCESS CSR 0
;3637            CSR1=22                 ; BIT 2 SET TO ACCESS CSR 1
;3638            CSR2=23                 ; BIT 3 SET TO ACCESS CSR 2
;3639
;3640
;3641    ;CONTROL AND STATUS WORD BITS
;3642
;3643            PRINT.UBE=26            ; PRINT IF UBE PRESENT OR NOT PRESENT (BIT 6)
;3644                                    ;  (INDICATOR IN LS 7)
;3645            PRINT.R80=27            ; PRINT IF R80 PRESENT OR NOT PRESENT AND ON
;3646                                    ; WHICH DRIVE (BIT 7).  INDICATOR IN LS 7,
;3647                                    ; DRIVE NUMBER IN LS 6.
;3648            ERROR=28                ; TEST ERROR INDICATION (BIT 8)
;3649            SET.PA.ERR=29           ; TELLS CONSOLE TO CREATE A PARITY ERROR AT WCS
;3650                                    ;  ADDRESS POINTED TO BY LS 7 (BIT 9)
;3651            CONSOLE.LOE=2A          ; INDICATES CONSOLE DOES ERROR LOOPING (BIT 10)
;3652                                    ;  (FOR INITIAL TESTS)
;3653            PRINT.MEM.SIZE=2B       ; PRINT MEMORY SIZE IN 256K BLOCKS (BIT 11)
;3654                                    ;  (SIZE IN LS 7)
;3655            PRINT.FPA=2C            ; PRINT IF FPA PRESENT OR NOT PRESENT (BIT 12)
;3656                                    ;  (INDICATOR IN LS 7)
;3657            XFER.DATA=2D            ; INDICATES A DATA TRANSFER TO LS OR MM (BIT 13)
;3658            EOS=2E                  ; END OF SECTION (BIT 14)
;3659            BEGIN.TEST=2F           ; BEGINNING OF TEST (BIT 15)
;3660            INTERUPT.EN=30          ; ENABLE INTERUPT OR SIGNAL SPECIFIED BY BITS
;3661                                    ;  17 THRU 22 AND 28 THRU 30 (BIT 16)
;3662
;3663             CONSOLE.HALT=31        ;   CONSOLE HALT INTERRUPT (BIT 17)
;3664             PWR.FAIL=32            ;   PWR FAIL INT (BIT 18)
;3665             INTERVAL.TIM=33        ;   INTRVL TIM INT (BIT 19)
;3666             CONSOLE.ATTN=34        ;   CONSOLE ATTN INTERRUPT (BIT 20)
;3667             CONSOLE.ACK=35         ;   CONSOLE ACK INTERRUPT (BIT 21
;3668             DISABLE.MEM.REF=36     ;   DISABLE MEMORY REFERANCES (BIT 22)
;3669             CINIT=3C               ;   UNIBUS INIT SIGNAL TO THE MCT (BIT 28)
;3670             UBS.DCLO=3D            ;   UNIBUS DC LO INDICATION TO THE MCT (BIT 29)
;3671             UBS.BBSY=3E            ;   UNIBUS BUS BUSY INDICATOR TO MCT (BIT 30)
;3672
;3673            NA.EXP.REC=37           ; PRINT N/A UNDER EXPECTED AND RECEIVED (BIT 23)
;3674            OTHER.DATA=38           ; PRINT A VALUE UNDER OTHER DATA (BIT 24)
;3675            CONSOLE.LOOP=39         ; CONSOLE PERFORMS A LOOP ACCORDING TO LOOP
;3676                                    ; COUNT IN LS (BIT 25)
;3677            PRINT.CRD=3A            ; PRINT NUMBER OF SINGLE BIT ERRORS (BIT 26)
;3678            CLR.PA.ERR=3B           ; TELLS CONSOLE TO CLEAR PARITY ERROR AT WCS
;3679                                    ;  ADDRESS POINTED TO BY LS 7 (BIT 27)
;3680            PRINT.IDC=3F            ; PRINT IF IDC PRESENT OR NOT PRESENT (BIT 31)
;3681                                    ;  (INDICATOR IN LS 7)
;3682
;3683
```

```
;3684    ;MODULE CODES
;3685
;3686            WCS=20                  ; MODULE CODE FOR WCS BOARD (BIT 0 SET)
;3687            CPU=21                  ; MODULE CODE FOR CPU BOARD (BIT 1 SET)
;3688            MCT=22                  ; MODULE CODE FOR MCT BOARD (BIT 2 SET)
;3689            FPA=23                  ; MODULE CODE FOR FPA BOARD (BIT 3 SET)
;3690            ARRAY=24                ; MODULE CODE FOR ARRAY BOARD (BIT 4 SET)
;3691            IDC=25                  ; MODULE CODE FOR IDC BOARD (BIT 5 SET)
;3692
;3693    ;CSR 1 ERROR BITS
;3694
;3695            VALID.ERR=2E            ; VALID NOT SET IF 1 (BIT 14)
;3696            TB.PAR.ERR=2F           ; TB PARITY ERROR (BIT 15)
;3697            NXM=30                  ; NON-EXISTANT MEMORY ERROR (BIT 16)
;3698            UB.BSY=31               ; UNIBUS BUSY (BIT 17)
;3699            ADP.REG=32              ; UNIBUS ADAPTER REGISTER SELECT (BIT 18)
;3700            WR.ACROSS.PG=33         ; WRITE ACROSS PAGE BOUNDARY ERROR (BIT 19)
;3701            OP.ERR=34               ; OPERATION ERROR (BIT 20)
;3702            TB.MISS=35              ; TB MISS (VIRTUAL ADDRESS TRANSLATION NOT IN
;3703                                    ;   BUFFER) (BIT 21)
;3704            ACCESS.REFUSED=36       ; PROTECTION ERROR ON ACCESS (BIT 22)
;3705            MODIFY.REFUSED=37       ; PROTECTION ERROR ON WRITE (BIT 23)
;3706
;3707            CRD=3E                  ; SINGLE BIT ERROR CORRECTED (BIT 30)
;3708            RDS=3F                  ; UNCORRECTABLE DATA ERROR (BIT 31)
;3709
;3710
;3711    ;CSR 1 CONTROL BITS
;3712
;3713            ECC.DIS=39              ; CSR1 ECC DISABLE BIT (BIT 25)
;3714            DIAG.CHK=3A             ; CSR1 DIAG CHK BIT (BIT 26)
;3715            MME=3B                  ; CSR1 MEMORY MANAGMENT ENABLE BIT (BIT 27)
;3716            INH.CRD=3C              ; CSR1 INHIBIT REPORT CRD BIT (BIT 28)
;3717            TB.PAR.DIAG=3D          ; CSR1 TB PAR DIAG BIT (FORCE TB PARITY ERR)
;3718                                    ;  (BIT 29)
;3719
;3720
;3721    ;UBE CONTROL REGISTER BITS
;3722
;3723      ;CONTROL REG 1
;3724            GO=20                   ; START UBE (BIT 0)
;3725            BR4=21                  ; ISSUE BUS REQUEST 4 (BIT 1)
;3726            BR5=22                  ; ISSUE BUS REQUEST 5 (BIT 2)
;3727            BR6=23                  ; ISSUE BUS REQUEST 6 (BIT 3)
;3728            BR7=24                  ; ISSUE BUS REQUEST 7 (BIT 4)
;3729            NPR=25                  ; ISSUE NPR (BIT 5)
;3730            INT.ODNE=26             ; INTERRUPT ON DONE (WHEN CCOVF) (BIT 6)
;3731            RDY=27                  ; READY BIT, SET WHEN READY TO BEGIN FUNC (BIT 7)
;3732            C00=28                  ; C0 BIT (BIT 8)
;3733            C01=29                  ; C1 BIT (BIT 9)
;3734            FUNA=2A                 ; FUNCTION BIT A (BIT 10
;3735            FUNB=2B                 ; FUNCTION BIT B (BIT 11)
;3736            CC+DAT=2C               ; DATA FROM CYCLE COUNT IF SET, DATA REG IF CLEAR
;3737            INH.DATIP.ROL=2D        ; INHIBIT ROL ON DATIP (BIT 13)
;3738            DATOB.ON.DATIP=2E       ; DO DATOB AFTER DATIP CYCLE (BIT 14)
```

```
;3739            ERR=2F                      ; EXERCISOR OR UNIBUS ERROR (BIT 15)
;3740
;3741      ;CONTROL REG 2
;3742            EXT.MEM0=20                 ; EXTENDED MEMORY BIT 0 (BIT 0)
;3743            EXT.MEM1=21                 ; EXTENDED MEMORY BIT 1 (BIT 1)
;3744            INH.INC.ADDR&CC=22          ; INHIBIT INC ON CYCLE COUNT AND ADDR REG (BIT 2)
;3745            INH.SACK=23                 ; INHIBIT ASSERING BUS SACK ON BUS GRANT (BIT 3)
;3746            PWR.DWN.SEQ=24              ; ASSERT ACLO (BIT 4)
;3747            WNG.GNT.BCK=25              ; NO BUS GRANT RECV TO HIGEST REQUEST (BIT 5)
;3748            MAX.LATE.ERR=26             ; NPR AND BR LATENCY TIME EXCEEDED (BIT 6)
;3749            NO.SACK.ERR=27              ; NO TIMEOUT AT CPU WHEN NO SACK (BIT 7)
;3750            NO.SSYN.ERR=28              ; NO SSYN RECEIVED AFTER ASSERTING MSYN (BIT 8)
;3751            WRG.A.LINES=29              ; ADDRESS ERR ON SENT & RECEIVED ADDRESS (BIT 9)
;3752            NO.GNT+NOT.ONE.GNT=2A       ; NO GRANT OR MORE THAN 1 GRANT AFTER REQ. (BIT 10)
;3753            INTR.SSYN.ERR=2B            ; NO SSYN RECEIVED AFTER BUS INTR (BIT 11)
;3754            ENB.PB=2C                   ; ENABLE PARITY BIT B (BIT 12)
;3755            CCOVF=2D                    ; CYCLE COUNT OVERFLOW (BIT 13)
;3756            TM.DLY=2E                   ; REQUEST BUS EVERY 10 USEC (BIT 14)
;3757
;3758      ;BG6 MNEMONIC
;3759            BG6=23                      ; BIT 3 SET FOR BG 6 ADDRESS
;3760
;3761      ;ERROR AND CONTROL INFORMATION
;3762
;3763            CONTROL.STATUS=40           ; CONTROL AND STATUS WORD
;3764            ERROR.NUMBER=41             ; ERROR NUMBER OF CURRENT TEST
;3765            EXPECTED.DATA=42            ; EXPECTED RESULT OF CURRENT TEST
;3766            RECEIVED.DATA=43            ; ACTUAL RESULT OF CURRENT TEST
;3767            ADDRESS.DATA=44             ; OTHER PERTINENT DATA
;3768            ERROR.MASK=45               ; BITS TO CHECK IN RESULT
;3769            MODULE.NUM=46               ; STORAGE OF MODULE NUMBER (CODED)
;3770            LOOP.CNT=47                 ; STORAGE OF LOOP COUNT FOR CONSOLE LOOP
;3771                                        ; CONTROL.
;3772            ERROR.CONTROL=48            ; STORAGE FOR ERROR CONTROL (LOOP ON ERROR ETC.)
;3773             LOE=20                     ;  LOOP ON ERROR IF SET (BIT0)
;3774             NER=21                     ;  NO ERROR REPORT IF SET (BIT1)
;3775             BELL=22                    ;  BELL ON ERROR IF SET (BIT2)
;3776             HOE=23                     ;  HALT ON ERROR IF SET (BIT3)
;3777             SER=24                     ;  ENABLE ERROR REPORT ON CRD ERRORS IF SET
;3778             APT.PRESENT=25             ;  APT PRESENT IF SET (BIT5)
;3779             LOOP.COMMAND=26            ;  LOOP COMMAND TYPED IF SET (BIT 6)
;3780             SPECIAL=27                 ;  SPECIAL BIT FOR LOOP ON SIZE TESTS (BIT 7)
;3781
;3782            APT.PARAM=49                ;APT RUN TIME PARAMETER REGS (MEM SIZE, HARD-
;3783                                        ; WARE CONFIG, SOFTWARE CONFIG IN BYTES 0, 1
;3784                                        ; AND 2 RESPECTIVELY. BYTE 3 FOR FUTURE USE)
;3785            APT.RESERVED=4A             ;RESERVED FOR FUTURE APT USE
;3786
;3787      ;MISCELLANEOUS CONSTANTS AND STORAGE
;3788
;3789            #AAAAAAAA=4C                ; CONSTANT
;3790            ALTER.ODD=4C                ; CONSTANT
;3791            #55555555=4D                ; CONSTANT
;3792            ALTER.EVEN=4D               ; CONSTANT
;3793            #0=4E                       ; CONSTANT
```

```
;3794            ZERO=4E                 ; CONSTANT
;3795            #FFFFFFFF=4F            ; CONSTANT
;3796            ONES=4F                 ; CONSTANT
;3797            PREVIOUS.ERROR=50       ; ERROR NUMBER OF LAST ERROR
;3798
;3799            DATA.1=51               ; STORAGE FOR FPA DATA
;3800            DATA.2=52               ; STORAGE FOR FPA DATA
;3801            DATA.3=53               ; STORAGE FOR FPA DATA
;3802            FIRST.FLT=54            ; STORAGE FOR FPA DATA
;3803            SEC.FLT=55              ; STORAGE FOR FPA DATA
;3804            THIRD.FLT=56            ; STORAGE FOR FPA DATA
;3805            T57=57                  ; TEMP LOCATION 57
;3806            T58=58                  ; TEMP LOCATION 58
;3807            T59=59                  ; TEMP LOCATION 59
;3808
;3809            BEDB=5A                 ;UBE (BUS EXERCISOR) DATA BUF REG
;3810            BECC=5B                 ;UBE (BUS EXERCISOR) CYCLE COUNT REG
;3811            BEBA=5C                 ;UBE (BUS EXERCISOR) ADDR REG
;3812            BECR1=5D                ;UBE (BUS EXERCISOR) CONTROL REG 1
;3813            CLEAR.ERR.ADDR=5E       ;UBE CLEAR ERROR REG ADDRESS
;3814            BECR2=5F                ;UBE (BUS EXERCISOR) CONTROL REG 2
;3815
;3816            #3(H)=60                ; CONSTANT
;3817            #12(H)=61               ; CONSTANT
;3818            #33333333=62            ; CONSTANT
;3819            #0F0F0F0F=63            ; CONSTANT
;3820            #00FF00FF=64            ; CONSTANT
;3821            #162(H)=65              ; CONSTANT FOR LS TRANSFER POINTER
;3822            BR7.IDENT=66            ; BR7 IDENTIFIER (1010(B) IN BITS 5-2)
;3823            BG7=67                  ; BG7 ADDRESS (BITS 2 AND 3 SET)
;3824
;3825    ;TEMPS FOR CPU TESTS
;3826            L30=30                  ;LS 30 TEMP (RESTORED TO 10000 AFTER USE)
;3827            L31=31                  ;LS 31 TEMP (RESTORE TO 20000 AFTER USE)
;3828            L53=53                  ;LS 53 TEMP
;3829            L73=73                  ;LS 73 TEMP
;3830
;3831    ;REGISTER ADDRESSES
;3832
;3833            CONTROL.OS=78           ; HARDWARE INDEX TO CONTROL WORDS (LS 40-4F)
;3834            SHIFT.OS(3-0)=79        ; 16 LOCATION HARDWARE INDEX TO SHIFT PATTERN
;3835                                    ;  (LS 20-2F)
;3836            SHIFT.OS(4-0)=7B        ; 32 LOCATION HARDWARE INDEX TO SHIFT PATTERN
;3837                                    ;  (LS 20-3F)
;3838            OS=7C                   ; OS REGISTER
;3839            DEC.CON=7D              ; DECIMAL CARRIES
;3840            SIZE=7E                 ; SIZE REGISTER
;3841            MDT= 7E                 ; MEMORY REFERENCE DATA SIZE
;3842            INTERRUPT.VEC=7E        ; HARDWARE INTERRUPT VECTOR
;3843    ;
;3844    ;       THIS WORD IS THE HARDWARE CONDITION CODES.  THE CC'S CAN BE READ
;3845    ;       OR ARE WRITTEN HERE.  NO OTHER BITS IN THE PSL ARE EFFECTED.
;3846    ;
;3847            PSL.CC=7F               ; PSL CONDITION CODES
;3848
```

```
;3849
;3850    .TOC    "COMMON LS ASSIGNMENTS (TO REGISTERS)"
;3851    ;
;3852    ;UPPER HALF OF LS
;3853    ;
;3854            XGPR.OS=0F8             ; HARDWARE INDEX TO XGPRS
;3855            USER.INDEX(3-0)=0F9     ; 16 LOCATION HARDWARE INDEX TO DIAGNOSTIC DATA
;3856                                    ;   AREA (LS LOCATIONS 0A0 THROUGH 0AF)
;3857            USER.INDEX(4-0)=0FB     ; 32 LOCATION HARDWARE INDEX TO DIAGNOSTIC DATA
;3858                                    ;   AREA (LS LOCATIONS 0A0 THROUGH 0BF)
;3859            CCR=0FC                 ; CONSOLE READ REGISTER
;3860            TIMER=0FD               ; INTERVAL TIMER VALUE.
;3861            ALU.CC=0FE              ; ALU CONDITION CODES
;3862    ;
;3863    ;       THIS LOCATION IS A WRITE ONLY REGISTER.  THE FOLLOWING BITS IN THE
;3864    ;       PSL ARE AFFECTED:
;3865    ;
;3866    ;       COMPATIBILITY MODE - BIT<31>
;3867    ;       CURRENT MODE - BITS<25:24>
;3868    ;       INTERRUPT PRIORITY LEVEL (IPL) - BITS<20:16>
;3869    ;       TRACE TRAP ENABLE (REALLY T OR TP) - BIT<4>
;3870    ;       NEGATIVE CONDITION CODE - BIT<3>
;3871    ;       ZERO CONDITION CODE - BIT<2>
;3872    ;       OVERFLOW CONDITION CODE - BIT<1>
;3873    ;       CARRY CONDITION CODE - BIT<0>
;3874    ;
;3875            PSL.HW=0FF              ; HARDWARE PSL BITS
;3876
;3877
;3878    ; These addresses are only accessible with the MOV micro instruction
;3879    ; starting at address 80(H).
;3880
;3881            SETCSR.F0=80            ;SET IDC CSR FUNCTION BITS =0 & SET WRT INHIBIT
;3882            SETCSR.F1=81            ;SET IDC CSR FUNCTION BITS =1 & SET WRT INHIBIT
;3883            SETCSR.F2=82            ;SET IDC CSR FUNCTION BITS =2 & SET WRT INHIBIT
;3884            SETCSR.F3=83            ;SET IDC CSR FUNCTION BITS =3 & SET WRT INHIBIT
;3885            SETCSR.F4=84            ;SET IDC CSR FUNCTION BITS =4 & SET WRT INHIBIT
;3886            SETCSR.F5=85            ;SET IDC CSR FUNCTION BITS =5 & SET WRT INHIBIT
;3887            SETCSR.F6=86            ;SET IDC CSR FUNCTION BITS =6 & SET WRT INHIBIT
;3888            SETCSR.F7=87            ;SET IDC CSR FUNCTION BITS =7 & SET WRT INHIBIT
;3889            SETCSR.IE=88            ;SET INTERRUPT ENABLE IN THE CSR
;3890            SETCSR.CRDY=89          ;SET BIT <7> CRDY IN THE CSR
;3891            SETCSR.DS0=8A           ;SET CSR DRIVE SELECT BITS = 0
;3892            SETCSR.DS1=8B           ;SET CSR DRIVE SELECT BITS = 1
;3893            SETCSR.DS2=8C           ;SET CSR DRIVE SELECT BITS = 2
;3894            SETCSR.DS3=8D           ;SET CSR DRIVE SELECT BITS = 3
;3895            SETCSR.SSEI=8E          ;SET SKIP SECTOR ERROR INHIBIT IN THE CSR
;3896            SETCSR.SSFLG=8F         ;SET SKIP SECTOR FLAG IN THE CSR
;3897            SETCSR.MAINT=90         ;SET THE MAINTENANCE BIT IN THE CSR
;3898
;3899            CSR.MASK=91
;3900            C53FFC31.MASK=91        ;MASK TO CHECK WRITABLE BITS OF THE CSR
;3901
;3902            SAV.DATA.PAT=92         ;LOCATION TO STORE THE CURRENT DATA PATTERN
;3903
```

```
;3904            CSR.DAT.PAT1=93         ;DATA PATTERN TO TEST THE IDC CSR WRITABLE BITS
;3905            CSR.DAT.PAT2=94         ;DATA PATTERN TO TEST THE IDC CSR WRITABLE BITS
;3906            CSR.DAT.PAT3=95         ;DATA PATTERN TO TEST THE IDC CSR WRITABLE BITS
;3907            CSR.DAT.PAT4=96         ;DATA PATTERN TO TEST THE IDC CSR WRITABLE BITS
;3908            CSR.DAT.PAT5=97         ;DATA PATTERN TO TEST THE IDC CSR WRITABLE BITS
;3909
;3910            #1A=98                  ;CONSTANT
;3911
;3912
;3913            PORT0=99                ;RESERVED FOR PORT DATA
;3914            PORT1=9A                ;RESERVED FOR PORT DATA
;3915            PORT2=9B                ;RESERVED FOR PORT DATA
;3916            PORT3=9C                ;RESERVED FOR PORT DATA
;3917            PORT4=9D                ;RESERVED FOR PORT DATA
;3918            PORT5=9E                ;RESERVED FOR PORT DATA
;3919            PORT6=9F                ;RESERVED FOR PORT DATA
;3920            PORT7=0A0               ;RESERVED FOR PORT DATA
;3921            PORT8=0A1               ;RESERVED FOR PORT DATA
;3922            PORT9=0A2               ;RESERVED FOR PORT DATA
;3923            PORT10=0A3              ;RESERVED FOR PORT DATA
;3924            PORT11=0A4              ;RESERVED FOR PORT DATA
;3925            PORT12=0A5              ;RESERVED FOR PORT DATA
;3926            PORT13=0A6              ;RESERVED FOR PORT DATA
;3927            PORT14=0A7              ;RESERVED FOR PORT DATA
;3928            PORT15=0A8              ;RESERVED FOR PORT DATA
;3929            PORT16=0A9              ;RESERVED FOR PORT DATA
;3930            PORT17=0AA              ;RESERVED FOR PORT DATA
;3931            PORT18=0AB              ;RESERVED FOR PORT DATA
;3932            PORT19=0AC              ;RESERVED FOR PORT DATA
;3933            PORT20=0AD              ;RESERVED FOR PORT DATA
;3934            PORT21=0AE              ;RESERVED FOR PORT DATA
;3935            PORT22=0AF              ;RESERVED FOR PORT DATA
;3936            PORT23=0B0              ;RESERVED FOR PORT DATA
;3937            PORT24=0B1              ;RESERVED FOR PORT DATA
;3938            PORT25=0B2              ;RESERVED FOR PORT DATA
;3939            PORT26=0B3              ;RESERVED FOR PORT DATA
;3940            PORT27=0B4              ;RESERVED FOR PORT DATA
;3941            PORT28=0B5              ;RESERVED FOR PORT DATA
;3942            PORT29=0B6              ;RESERVED FOR PORT DATA
;3943            PORT30=0B7              ;RESERVED FOR PORT DATA
;3944            PORT31=0B8              ;RESERVED FOR PORT DATA
;3945            #0000FFFF=0B9           ;CONSTANT
;3946            FORCE.IDLE=0BA          ;DATA TO FORCE IDC FROM DIAG.IDLE TO IDLE
;3947            #FFF80000=0BB           ;MASK FOR DAR..LOOKS AT BITS <18:0>
;3948            DAR.MASK=0BB
;3949            CSR.PAT.1=0BC           ;DATA PAT 1 TO TEST CSR
;3950            CSR.PAT.2=0BD           ;DATA PAT 2 TO TEST CSR
;3951            CSR.PAT.3=0BE           ;DATA PAT 3 TO TEST CSR
;3952            CSR.PAT.4=0BF           ;DATA PAT 4 TO TEST CSR
;3953            CSR.PAT.5=0C0           ;DATA PAT 5 TO TEST CSR
;3954            BIT7.MASK=0C1           ;MASK TO CHECK ONLY BIT 7
;3955            BIT22.MASK=0C2          ;MASK TO CHECK ONLY BIT 22
;3956            BIT23.MASK=0C3          ;MASK TO CHECK ONLY BIT 23
;3957            #3=0C4                  ;CONSTANT OF 3
;3958            #FE=0C5                 ;CONSTANT OF FE
```

```
;3959            #1FE=0C6                ;CONSTANT OF 1FE
;3960            DRIVE.STATUS=0C7        ;LOCATION CONTAINS DRIVE INFORMATION
;3961            #FFFFFFF0=0C8           ;MASK FOR BITS<3:0>
;3962            #6=0C9                  ;CONSTANT OF 6
;3963            #7FFFF=0CA              ;CONSTANT
;3964            #F=0CB                  ;CONSTANT
;3965            #FFFFFCFF=0CC           ;CONSTANT
;3966            #FFFFFFFC=0CD           ;CONSTANT
;3967            #FFFFFF80=0CE           ;CONSTANT
;3968            SETCSR.R80=0CF          ;SETS BIT 29
;3969            #20100500=0D0           ;CONSTANT
;3970            #A0100500=0D1           ;CONSTANT
;3971            #FFCFFFFF=0D2           ;MASK TO CHECK BITS<21:20>
;3972            #FFFFE000=0D3           ;MASK TO CHECK BITS<12:0>
;3973            #69=0D4                 ;CONSTANT = 105
;3974            #6837=0D5               ;CONSTANT
;3975            #7200=0D6               ;CONSTANT
;3976            #FFFFF800=0D7           ;MASK TO CHECK BITS <10:0>
;3977            #1021=0D8               ;CONSTANT
;3978            #A0010500=0D9           ;CONSTANT
;3979            #20010500=0DA           ;CONSTANT
;3980            #1F=0DB                 ;CONSTANT
;3981            #169=0DC                ;CONSTANT
;3982            #101=0DD                ;CONSTANT
;3983            #FFF0FFFF=0DE           ;MASK TO CHECK BITS <19:16>
;3984            #30000=0DF              ;CONSTANT
;3985            #70000=0E0              ;CONSTANT
;3986            #F0000=0E1              ;CONSTANT
;3987            #FFFFEBFF=0E2           ;MASK TO CHECK BITS <12> <10>
;3988            #FFFF6BFF=0E3           ;MASK TO CHECK BITS <15> <12> <10>
;3989            #9400=0E4               ;CONSTANT
;3990            #FFFF6FFF=0E5           ;MASK TO CHECK BITS <15> <12>
;3991            #9000=0E6               ;CONSTANT
;3992            #FFFFEFFF=0E7           ;MASK TO CHECK BIT <12>
;3993            #11111111=0E8           ;CONSTANT
;3994            #22222222=0E9           ;CONSTANT
;3995            #44444444=0EA           ;CONSTANT
;3996            #000F0000=0EB           ;CONSTANT
;3997            #2D35E=0EC              ;CONSTANT
;3998            #28AEE=0ED              ;CONSTANT
;3999            #5A6BF=0EE              ;CONSTANT
;4000            #5A6C2=0EF              ;CONSTANT
;4001            #FFFFFBFF=0F0           ;MASK TO CHECK BIT <10>
;4002            #FFFFFF7F=0F1           ;MASK TO CHECK BIT <7>
;4003            #10000080=0F2           ;BITS TO DISABLE TIMEOUTS AND SET CSR<CRDY>
;4004            #B4D84=0F3              ;WAIT LOOP TO WAIT 400ms
;4005            #FF3FFFFF=0F4           ;MASK TO CHECK <23:22>
;4006            #FFFFFFE3=0F5           ;MASK TO CHECK <4:2>
;4007            #FEFFFFFF=0F6           ;MASK TO CHECK <24>
;4008
;4009
```

```
;4010    .page "Microinstruction Formats"
;4011    ;
;4012    ;       The following is taken directly from the NEBULA Hardware
;4013    ;       Specification.
;4014    ;
;4015    ;                       MICROINSTRUCTION FORMATS
;4016    ;
;4017    ;
;4018    ;
;4019    ;
;4020    ;                   22 21       16 15          9 8 7 6 5 4       0
;4021    ;                   +-----+-------+-------+-------+-------+-------+
;4022    ;1. BASIC           |1|     DP    |    D ADRS   | B |CC |  SCTL   |
;4023    ;                   +-+-----------+-------------+---+---+---------+
;4024    ;
;4025    ;                   22  20 19 17 16            9 8 7 6 5 4       0
;4026    ;                   +-----+-------+-------+-------+-------+-------+
;4027    ;2. MOVE            |0 1 1| MDP   |    XD ADRS    | B |CC |  SCTL   |
;4028    ;                   +-----+-------+---------------+---+---+---------+
;4029    ;
;4030    ;                   22  20 19       14 13 11   9 8 7 6 5 4       0
;4031    ;                   +-----+-----------+-----+-------+-------+-------+
;4032    ;3. EXTENDED        |0 1 0|    XDP    | SI  | A | B |CC |  SCTL   |
;4033    ;                   +-----+-----------+-----+---+---+---+---------+
;4034    ;
;4035    ;                   22    19 18 16 15          9 8 7 6 5 4       0
;4036    ;                   +-----+-------+-------+-------+-------+-------+
;4037    ;4. MEM.REQ         |0 0 1 1| MF1   |    D ADRS   |MF2|DT |  SCTL   |
;4038    ;                   +-------+-------+-------------+---+---+---------+
;4039    ;
;4040    ;                   22    19 18 16 15   12 11  9 8 7 6 5 4       0
;4041    ;                   +-----+-------+-------+-------+-------+-------+
;4042    ;5. MISC            |0 0 1 0|P|0 0|   M1  | M2  |0|R|0 0|  SCTL   |
;4043    ;                   +-------+-+---+-------+-----+-+-+---+---------+
;4044    ;
;4045    ;                   22    19 18 17                      4 3     0
;4046    ;                   +-----+-------+-------+-------+-------+-------+
;4047    ;6. JUMP            |0 0 0 1|OS|    JUMP ADDRESS             | JCTL  |
;4048    ;                   +-------+--+-----------------------------+-------+
;4049    ;
;4050    ;                   22    19 18 17      12 11  9 8 7 6 5 4 3     0
;4051    ;                   +-----+-------+-------+-------+-------+-------+
;4052    ;7. DECODE          |0 0 0 0| | DEC.ADRS  |IFUNC| | | | | | JCTL  |
;4053    ;                   +-------++----------+-----++-++++++-------+
;4054    ;                           |               |  |  |  |  |  |
;4055    ;                   BACK UP PC        IB REQ---+  |  |  |  +--OPC/SPEC
;4056    ;                                                 |  |  |
;4057    ;                               SEL CM HI IR BYTE---+  |  +--LOAD RDEST
;4058    ;                                                      |
;4059    ;                                           LOAD OS--+
```

```
;4060    .page
;4061    ;
;4062    ;
;4063    ;1. "BASIC" Microinstruction
;4064    ;
;4065    ;    CSR<22> = 1    (OPCODE)
;4066    ;
;4067    ;        This opcode bit causes LS Adrs <7> to be cleared.
;4068    ;
;4069    ;    CSR<21:16>  (Data Path Control)
;4070    ;
;4071    ;        This field controls the data path. It controls the 2901 ALU,
;4072    ;        the ALU data source, the data destination in the 2901 array,
;4073    ;        and the write to the Local Store.
;4074    ;
;4075    ;    CSR<15:9>   (D Adrs <6:0>)
;4076    ;
;4077    ;        This field selects which of the 128 accessable Local Store
;4078    ;        locations to use.
;4079    ;
;4080    ;    CSR<8:7>    (B Adrs)
;4081    ;
;4082    ;        This field selects one of the four Working Registers.
;4083    ;
;4084    ;    CSR<6:5>    (Condition Codes)
;4085    ;
;4086    ;        This field specifies the data type and condition code control.
;4087    ;
;4088    ;    CSR<4:0>    (SCTL)
;4089    ;
;4090    ;        This field specifies the skip condition/micro sequencer
;4091    ;        function.
```

```
;4092    .page
;4093    ;
;4094    ;
;4095    ;2. "MOVE" Microinstruction
;4096    ;
;4097    ;     CSR<22:20> = 011 (OPCODE)
;4098    ;
;4099    ;        This combination of opcode bits allows CSR<16> to control
;4100    ;        LS Adrs <7>. This permits access of LS locations 80 - FF.
;4101    ;
;4102    ;     CSR<19:17> (Data Path Control)
;4103    ;
;4104    ;        This field is decoded to produce some data path control
;4105    ;        information.
;4106    ;
;4107    ;          0 LS[XD] <- WR[B], WR[B] <- MEM DATA* 4 LS[XD] <- MEM DATA*
;4108    ;          1 MEMORY <- LS [XD]*                  5 LS[XD] <- ACC/PORT
;4109    ;          2 Q <- XWR[B]                         6 LS[XD] <- WR[B] + OS
;4110    ;          3 WR[B] <- LS [XD]                    7 LS[XD] <- WR[B]
;4111    ;
;4112    ;     CSR<16:9>  (XD<7:0>)
;4113    ;
;4114    ;        This field specifies which of the 256 Local Store locations to
;4115    ;        use.
;4116    ;
;4117    ;     CSR<8:7>   (B Adrs)
;4118    ;
;4119    ;        This field specifies which of the four Working Registers to
;4120    ;        use. For MDP = 2, this field selects either the Backup PC or
;4121    ;        the VAR.
;4122    ;
;4123    ;     CSR<6:5>   (CC)
;4124    ;
;4125    ;        This field specifies the data type and condition code control.
;4126    ;
;4127    ;     CSR<4:0>   (SCTL)
;4128    ;
;4129    ;        This field specifies the Skip control. See Table 3.
;4130    ;
;4131    ;
;4132    ;* For information on which Working Registers and Local Store locations
;4133    ;  may  be  used for Memory Addresses and data source/destinations, see
;4134    ;  the Memory Management documentation.  Note that  these  restrictions
;4135    ;  are due to microcoding conventions and not hardware.
```

```
;4136   .page
;4137   ;
;4138   ;
;4139   ;3. "EXTENDED" Microinstruction
;4140   ;
;4141   ;    CSR<22:20> = 010    (OPCODE)
;4142   ;
;4143   ;        This opcode causes a function internal to the 2901 array; that
;4144   ;        is, an operation involving only Working Registers and the Q-
;4145   ;        Register.
;4146   ;
;4147   ;    CSR<19:14>  (Data Path Control)
;4148   ;
;4149   ;        This field is decoded to supply the 2901 ALU function code,
;4150   ;        the ALU Source control, the destination code, and the ALU
;4151   ;        Carry-In.
;4152   ;
;4153   ;    CSR<13:11>  (Shift Input)
;4154   ;
;4155   ;        This field selects the data to be shifted into a register,
;4156   ;        when a Shift function is being done.
;4157   ;
;4158   ;    CSR<10:9>   (A Adrs)
;4159   ;
;4160   ;        This field selects which Working Register to use as a source
;4161   ;        of data, when RAM A is selected to the ALU.
;4162   ;
;4163   ;    CSR<8:7>    (B Adrs)
;4164   ;
;4165   ;        This field selects which Working Register to use as a source
;4166   ;        (when RAM B is selected to the ALU) and/or destination (when
;4167   ;        the RAM is written) of data.
;4168   ;
;4169   ;    CSR<6:5>    (CC)
;4170   ;
;4171   ;        This field specifies the data type and condition code control.
;4172   ;
;4173   ;    CSR<4:0>    (SCTL)
;4174   ;
;4175   ;        This field specifies the skip condition/micro sequencer
;4176   ;        function.
```

```
;4177   .page
;4178   ;
;4179   ;
;4180   ;4. 'MEM.REQ'' Microinstruction
;4181   ;
;4182   ;    CSR<22:19> = 0011    (OPCODE)
;4183   ;
;4184   ;        This opcode causes a Memory Request to be started. The Local
;4185   ;        Store is output on on the D-Bus, to be used as the virtual
;4186   ;        address. Working Register 5 is written with this address.
;4187   ;
;4188   ;    CSR<18:16>, <8:7>   (Memory Function)
;4189   ;
;4190   ;        This field specifies to the Memory Controller the type of
;4191   ;        request: physical, virtual, type of access, etc. For the
;4192   ;        list of functions and the codes, see the NEBULA Memery Spec.
;4193   ;
;4194   ;    CSR<15:9>   (D Adrs <6:0>)
;4195   ;
;4196   ;        This field selects which of the 128 accessable Local Store
;4197   ;        locations to use as the virtual address.
;4198   ;
;4199   ;    CSR<6:5>    (Data Type)
;4200   ;
;4201   ;        This field specifies the data type of the request.
;4202   ;
;4203   ;                00:=BYTE
;4204   ;                01:=WORD
;4205   ;                10:=SIZE Reg
;4206   ;                11:=LONG
;4207   ;
;4208   ;    CSR<4:0>    (SCTL)
;4209   ;
;4210   ;        This field specifies the skip condition/micro sequencer
;4211   ;        function.
```

```
;4212    .page
;4213    ;
;4214    ;
;4215    ;5. "MISC" Microinstruction
;4216    ;
;4217    ;    CSR<22:19> = 0010 (OPCODE)
;4218    ;
;4219    ;        This combination of opcode bits causes the data path to no-op,
;4220    ;        and enables the MISC decoders.
;4221    ;
;4222    ;    CSR<18>              (Port/Misc Select)
;4223    ;
;4224    ;        This bit defines the instruction to be either a Misc or a Port
;4225    ;        instruction.   For CSR<18> = 1, CSR<17:10> is the Command Byte
;4226    ;        to the Port, CSR<9:5> must be zero and CSR<4:0>  is  the  SCTL
;4227    ;        field.  For CSR<18> = 0, it is a Misc instruction and the rest
;4228    ;        of the word is defined as follows.
;4229    ;
;4230    ;    CSR<17:16>           (Not Used)
;4231    ;
;4232    ;    CSR<15:12>  (Misc Function 1)
;4233    ;
;4234    ;        These four bits are decoded to do the following functions:
;4235    ;
;4236    ;                0 = CLEAR State Reg<1:0>
;4237    ;                1 = CLEAR State Reg<1>, SET State Reg<0>
;4238    ;                2 = SET State Reg<1>, CLEAR State Reg<0>
;4239    ;                3 = CLEAR State Reg<0>
;4240    ;                4 = CLEAR State Reg<1>
;4241    ;                5 = SET State Reg<0>
;4242    ;                6 = SET State Reg<1>
;4243    ;                7 = SET REGISTER BACKUP MASK FLAG
;4244    ;                8 = SET ACC I/O MODE
;4245    ;                9 = SET PORT I/O MODE
;4246    ;                A = CLEAR WCS HI ADRS
;4247    ;                B = SET WCS HI ADRS
;4248    ;                C = CLEAR CPU ATTN AND CPU ACK
;4249    ;                D = SET CPU ACK
;4250    ;                E = SET CPU ATTN
;4251    ;                F = NOP
;4252    ;
;4253    ;    CSR<11:9>   (Misc Function 2)
;4254    ;
;4255    ;        This field is decoded to do the following functions:
;4256    ;
;4257    ;                0 = NOP
;4258    ;                1 = Mask IRD Interrupt Detection during Next State
;4259    ;                2 = Assert CPU Data Available and pass WR to ACC/Port
;4260    ;                3 = Trap ACC
;4261    ;                4 = Read ACC uPC
;4262    ;                5 = Assert XFER GRANT to Port
;4263    ;                6 = Mask Halt and T-Bit Traps
;4264    ;                7 = Write WR to Console Read Register
```

```
;4265   .page
;4266   ;
;4267   ;    CSR<8>      (MUST BE ZERO)
;4268   ;
;4269   ;    CSR<7>      (WR Address)
;4270   ;
;4271   ;
;4272   ;        This bit selects WR[0] or WR[1] to be put on the Y-Bus.
;4273   ;
;4274   ;    CSR<6:5>            (Not Used)
;4275   ;
;4276   ;    CSR<4:0>    (SCTL)
;4277   ;
;4278   ;        This  field  specifies  the  skip  condition/micro   sequencer
;4279   ;        function.
;4280   ;
```

```
;4281    .page
;4282    ;
;4283    ;
;4284    ;6. "JUMP" Microinstruction
;4285    ;
;4286    ;    CSR<22:19> = 0001    (OPCODE)
;4287    ;
;4288    ;        This opcode causes the data path to no-op, and the micro
;4289    ;        sequencer to execute a JUMP.
;4290    ;
;4291    ;    CSR<18>     (Select OS)
;4292    ;
;4293    ;        This bit, when asserted, causes OS<4:0> to be OR'ed with the
;4294    ;        five low bits of the of the jump microaddress.
;4295    ;
;4296    ;    CSR<17:4>   (Jump Microaddress)
;4297    ;
;4298    ;        If Select OS is CLEAR, this field specifies the fourteen-bit
;4299    ;        jump micro address. If Select OS is SET, CSR<17:9> is Jump
;4300    ;        Adrs<13:5> and OS<4:0> OR'ed with CSR<8:4> is Jump Adrs<4:0>.
;4301    ;
;4302    ;    CSR<3:0>    (JCTL)
;4303    ;
;4304    ;        This field specifies the jump condition/micro sequencer
;4305    ;        function.
```

```
;4306    .page
;4307    ;
;4308    ;
;4309    ;7. "DECODE" Microinstruction
;4310    ;
;4311    ;    A.  DESCRIPTION
;4312    ;
;4313    ;    CSR<22:19> = 0000 (OPCODE)
;4314    ;
;4315    ;        This combination of opcode bits causes the Local Store to
;4316    ;        access location 10 (the PC.) The Local Store drives the D-Bus.
;4317    ;        The 2901 is set up to input the data on the D-Bus, increment
;4318    ;        it, and output to the Y-Bus. Thus, the Y-Bus contains the PC
;4319    ;        + 1.
;4320    ;
;4321    ;    CSR<18>     (BPC [asserted low])
;4322    ;
;4323    ;        If this bit is CLEAR, the incremented PC is written into the
;4324    ;        2901 RAM.  If it is SET, the RAM is not written.
;4325    ;
;4326    ;    CSR<17:12>  (DEC.ADRS <13:8>)
;4327    ;
;4328    ;        This data is taken to be the upper six bits of the next
;4329    ;        microaddress.  The low eight bits are supplied by the IRD ROM.
;4330    ;        The actual JUMP/JSR/NO-OP is determined by the JCTL field.
;4331    ;
;4332    ;    CSR<11:9>   (IFUNC)
;4333    ;
;4334    ;        This is the IFUNC field.  It defines which fork is being
;4335    ;        taken.
;4336    ;
;4337    ;    CSR<8>      (IB.REQ)
;4338    ;
;4339    ;        This is the IB.REQ bit.  When it is CLEAR, the LS is not
;4340    ;        written, no interaction with memory is initiated and the
;4341    ;        instructin buffer is not affected.
;4342    ;
;4343    ;        When it is SET:
;4344    ;
;4345    ;        The incremented PC (valid on the Y-Bus by the end of the
;4346    ;        cycle) is re-written to Local Store location 0.  This
;4347    ;        completes the PC increment function.
;4348    ;
;4349    ;        A Conditional Memory Request is executed.  If the two low bits
;4350    ;        of the PC are not 11, the request is not initiated.  If the
;4351    ;        two low bits are set, an IB PREFETCH is done.  The
;4352    ;        (unincremented) PC is output to the memory and the CPU grant
;4353    ;        (CPUG) signal is examined.  If CPUG is low by T120, the CPU
;4354    ;        will stall until the CPUG signal becomes true.  After the
;4355    ;        request is completed, the next state entered is dependent upon
;4356    ;        the JCTL field.
```

```
;4357    .page
;4358    ;
;4359    ;    CSR<7>      (SEL CM HI IR BYTE)
;4360    ;
;4361    ;        This bit enables the upper  byte  of  the  Compatibility  Mode
;4362    ;        instruction  in the Prefetch register to drive the IB-Bus.  It
;4363    ;        is used only while in Compatibility Mode, when  IRD  is  being
;4364    ;        done.  It must never be asserted in VAX Mode.
;4365    ;
;4366    ;
;4367    ;    CSR<6>      (LD.OS)
;4368    ;
;4369    ;        If this bit is SET, the eight-bit data  on  the  IB  Bus  (the
;4370    ;        output  of  the  instruction  buffer)  is  loaded  into the OS
;4371    ;        register.  This load is dependent upon Compatibility Mode  and
;4372    ;        LD  R  Dest  (If  CM.AND.LD R Dest, OS<3> <- 0.) If the bit is
;4373    ;        CLEAR, OS is not affected.
;4374    ;
;4375    ;    CSR<5>      (LD R DEST)
;4376    ;
;4377    ;        If this bit is SET, the R  Dest  Skip  bit  will  be  SET  for
;4378    ;        Specifier Mode equal to 5 and CLEARED for Mode not equal to 5,
;4379    ;        in VAX mode, or mode 0 while in Compatibility Mode.   If  this
;4380    ;        bit is CLEAR, the R Dest bit will be unaffected.
;4381    ;
;4382    ;    CSR<4>              (OPC/SPEC)
;4383    ;
;4384    ;        This bit (effectively another IFUNC bit) defines the  data  to
;4385    ;        be  decoded;   that is, if it is an Opcode or a Specifier.  In
;4386    ;        hardware, it selects which ROM is to drive the  micro  address
;4387    ;        bus.
;4388    ;
;4389    ;    CSR<3:0>    (JCTL)
;4390    ;
;4391    ;        These four bits are decoded to make one of 16 functions.   See
;4392    ;        Table 3.
```

```
;4393   .page "Tables"
;4394   ;
;4395   ;                                   TABLES
;4396   ;
;4397   ;
;4398   ;
;4399   ;                       Table 1.  2901 Control Decoding
;4400   ;
;4401   ;
;4402   ;           The 2901 control decoder examines CSR<22:14>. This nine-bit
;4403   ;           field  of  the microword changes in meaning for the different
;4404   ;           cases of micro opcode.
;4405   ;
;4406   ;     . . . CSR      22  21  20  19  18  17  16  15  14
;4407   ;                    --  --  --  --  --  --  --  --  --
;4408   ;1. BASIC            1  [Six bit function code]  X   X
;4409   ;2. MOVE             0   1   1  [function]   X   X   X
;4410   ;3. EXTENDED         0   1   0  [Six bit function code]
;4411   ;4. MEM.REQ          0   0   1   1   X   X   X   X   X       WR[5] <- D
;4412   ;5. MISC             0   0   1   0   X   X   X   X   X       Y-Bus <- WR
;4413   ;6. JUMP             0   0   0   1   X   X   X   X   X       NO-OP
;4414   ;7. DECODE           0   0   0   0  BPC* X   X   X   X
;4415   ;
;4416   ;  If BPC = 0, Write WR; else, No-op
;4417   ;
;4418   ;     This decoder is implemented using a ROM and a PAL. 512
;4419   ;     locations are needed for CSR<22:14> to index into. The
;4420   ;     decoding logic supplies 10 control bits:
;4421   ;
;4422   ;                 ALU Source Select   (3)
;4423   ;                 ALU Function   (3)
;4424   ;                 ALU Result Destination   (3)
;4425   ;                 ALU Carry-In   (1)
;4426   ;
;4427   ;     The ROM addresses are therefore allocated in the following way:
;4428   ;
;4429   ;     Location     0 -   F       Incr. D-Bus, Output ALU, No Write.
;4430   ;                 10 -  1F       Incr. D-Bus, Output ALU, Write RAM.
;4431   ;                 20 -  3F       No-Op.
;4432   ;                 40 -  5F       Output WR, bypassing ALU.
;4433   ;                 60 -  7F       Pass D-Bus through ALU and write RAM.
;4434   ;                 80 -  BF       CSR<19:14> indicates 2901 function.
;4435   ;                 C0 -  FF       CSR<19:17> indicates 2901 function.
;4436   ;                100 - 1FF       CSR<21:16> indicates 2901 function.
;4437   ;
;4438   ;     For the detailed function table see the Microcode Listing.
```

```
;4439   .page
;4440   ;
;4441   ;
;4442   ;                          Table 2. Local Store Write
;4443   ;
;4444   ;     The Local Store Write Controller examines CSR<22:17>, CSR<6>, the
;4445   ;     SIZE  register  (SIZE<1:0>)  and the Compatibility Mode bit (CM).
;4446   ;     These eight bits are decoded to determine which parts of  the  LS
;4447   ;     to  write, if any.  The LS is written with data from the 2901 ALU
;4448   ;     (Y-Bus).
;4449   ;
;4450   ;               CSR     22  21  20  19  18  17
;4451   ;                       --  --  --  --  --  --
;4452   ;        1. BASIC        1   0   X   X   X   X    No Write
;4453   ;                        1   1   X   X   X   X    Write *
;4454   ;        2. MOVE         0   1   1   0   X   1    No Write
;4455   ;                        0   1   1   0   1   X    No Write
;4456   ;                        0   1   1   1   X   X    Write *
;4457   ;        3. EXTENDED     0   1   1   X   X   X    No Write
;4458   ;        4. MEM.REQ      0   0   1   1   X   X    No Write
;4459   ;        5. MISC         0   0   1   0   X   X    No Write
;4460   ;        6. JUMP         0   0   0   1   X   X    No Write
;4461   ;        7. DECODE       0   0   0   0   X   X    Conditional Write **
;4462   ;
;4463   ;   * LS Write, Data Type Dependent. These cases now examine CSR<6>.
;4464   ;
;4465   ;     If CSR<6> = 0, and CM = 0   Write LS<31:0>  (Data Type = LONG)
;4466   ;     If CSR<6> = 0, and CM = 1   Write LS<15:0>  (Compatibility
;4467   ;                                                  Mode. DT = WORD)
;4468   ;
;4469   ;     If CSR<6> = 1, the Write is conditional on the SIZE register.
;4470   ;
;4471   ;     If CM = 0   SIZE<1:0> = 00  Write LS<7:0>  (BYTE)
;4472   ;                           = 01  Write LS<15:0> (WORD)
;4473   ;                           = 1X  Write LS<31:0> (LONG)
;4474   ;
;4475   ;     If CM = 1  Write LS<15:0>  (WORD)
;4476   ;
;4477   ;   ** If CSR<8> = 0, No Write
;4478   ;        If CSR<8> = 1, Write LS<31:0>  (Writes incremented PC)
```

```
;4479    .page
;4480    ;
;4481    ;
;4482    ;                   Table 3. SKIP/JUMP Conditions
;4483    ;
;4484    ;This table summarizes the Skip and Jump conditions, and the other
;4485    ;special functions of the micro sequencer.
;4486    ;
;4487    ;SCTL codes 0-F, 17-1F are Skip conditions. The codes 10-17 execute
;4488    ;special functions. JCTL codes 0-B are Jump conditions, and C-F
;4489    ;execute special functions.
;4490    ;
;4491    ;
;4492    ;Sctl    Function                Sctl    Function
;4493    ;----    --------                ----    --------
;4494    ; 00     Not ALU N                10     RTN+1 if No Mem Err
;4495    ; 01     Not ALU Z                11     Loop if Not ALU Z
;4496    ; 02     Not ALU V                12     POP Stack
;4497    ; 03     ALU C                    13     Loop if ALU C
;4498    ; 04     Not PSL C                14     Return
;4499    ; 05     Branch False             15     No Skip (NOP)
;4500    ; 06     RDEST                    16     RTN+1
;4501    ; 07     Not Inter. Req.          17     Loop if No Inter. and No Sync
;4502    ; 08     ALU N                    18     Console ATTN
;4503    ; 09     ALU Z                    19     Console ACK
;4504    ; 0A     ALU V                    1A     Port Interrupt Pending
;4505    ; 0B     Not ALU C                1B     Reg. Backup Mask Flag
;4506    ; 0C     State 0                  1C     ALU N.XOR.ALU V
;4507    ; 0D     State 1                  1D     Not Memory Error
;4508    ; 0E     Not State 0              1E     Skip
;4509    ; 0F     Not State 1              1F     Sync
;4510    ;
;4511    ;
;4512    ;Jctl    Function                Jctl    Function
;4513    ;----    --------                ----    --------
;4514    ; 00     Not ALU N                08     ALU N
;4515    ; 01     Not ALU Z                09     ALU Z
;4516    ; 02     Not ALU V                0A     ALU V
;4517    ; 03     ALU C                    0B     Not ALU C
;4518    ; 04     JUMP                     0C     JSR
;4519    ; 05     Branch False             0D     JSR if IB Valid
;4520    ; 06     RDEST                    0E     No Jump; Skip if IB Valid
;4521    ; 07     Not Interr. Req          0F     IB Valid
;4522    ;
;4523
```

```
;4524   .PAGE  "2901 ALU Control Description"
;4525
;4526   ;
;4527   ;           The 2901 ALU is the heart  of  the  CPU  module.   It  is
;4528   ;       responsible for all CPU calculations.  The control lines going
;4529   ;       to I0 through I8 control the function, input,  and  output  of
;4530   ;       the  2901.   When  a  failure  involving  the 2901 occurs, the
;4531   ;       logical place to start looking  is  the  control  lines.   The
;4532   ;       following  tables  describe what the control signals should be
;4533   ;       for various functions.  Use it whenever the control lines  are
;4534   ;       to  be  checked.  The test descriptions tell the operator what
;4535   ;       function the 2901 is supposed to be doing.
;4536   ;
;4537   ;           The SRC CTL on lines I0 through I2 (pins  12  through  14
;4538   ;       respectively)  control  where  the  inputs to the internal ALU
;4539   ;       within the 2901 come from.  The inputs to the internal ALU are
;4540   ;       labeled R and S.  R is one operand (4 bits) and S is the other
;4541   ;       operand (also 4 bits).  The R input can come  from  a  Working
;4542   ;       Register  (labeled  A), the D bus (direct input), or be forced
;4543   ;       to 0.  The S  input  can  come  from  either  set  of  working
;4544   ;       registers  (labeled  A and B), the Q register, or forced to 0.
;4545   ;       A table of these control signals follow:
;4546   ;
;4547   ;
;4548   ;          ---------------------------
;4549   ;         |                |      | SRC   |
;4550   ;         |                |      |operands|
;4551   ;         |                |octal |--------|
;4552   ;         |  I2  I1  I0    |code  |  R  S  |
;4553   ;         |----------------------------|
;4554   ;         |  L   L   L     |  0   |  A  Q  |
;4555   ;         |  L   L   H     |  1   |  A  B  |
;4556   ;         |  L   H   L     |  2   |  0  Q  |
;4557   ;         |  L   H   H     |  3   |  0  B  |
;4558   ;         |  H   L   L     |  4   |  0  A  |
;4559   ;         |  H   L   H     |  5   |  D  A  |
;4560   ;         |  H   H   L     |  6   |  D  Q  |
;4561   ;         |  H   H   H     |  7   |  D  0  |
;4562   ;          ---------------------------
;4563   ;
;4564   ;         ALU SOURCE OPERAND CONTROL
;4565   ;
;4566   ;
;4567   ;
;4568   ;
;4569   ;           The ALU CTL on lines I3  through  I5  (pins  26,  28,  27
;4570   ;       respectively)  control  what function the ALU is to perform on
;4571   ;       the two operands R and S.  A table follows:
```

```
;4572   .page
;4573   ;
;4574   ;
;4575   ;
;4576   ;
;4577   ;
;4578   ;
;4579   ;
;4580   ;
;4581   ;
;4582   ;
;4583   ;
;4584   ;
;4585   ;
;4586   ;
;4587   ;
;4588   ;
;4589   ;
;4590   ;
;4591   ;
;4592   ;
;4593   ;
;4594   ;
;4595   ;
;4596   ;
;4597   ;
;4598   ;
;4599   ;
;4600   ;
;4601   ;
;4602   ;
;4603   ;
;4604   ;
;4605   ;
;4606   ;
;4607   ;
;4608   ;
;4609   ;
;4610   ;
;4611   ;
;4612   ;
;4613   ;
;4614   ;
;4615   ;
;4616   ;
;4617   ;
;4618   ;
;4619   ;
;4620   ;
;4621   ;
;4622   ;
;4623   ;
;4624   ;
;4625   ;
```

I5	I4	I3	octal code	ALU function
L	L	L	0	R PLUS S
L	L	H	1	S MINUS R
L	H	L	2	R MINUS S
L	H	H	3	R OR S
H	L	L	4	R AND S
H	L	H	5	R NOT AND S
H	H	L	6	R XOR S
H	H	H	7	R XNOR S

ALU FUNCTION CONTROL

The DST CTL on lines I6 through I8 (pins 5, 7, 6 respectively) control what goes out onto the Y bus (either the internal ALU result or a WR directly) and what happens internal to the 2901 (shifting, writing the Q register etc). Internal shifting left or right is accomplished with this control. Below is a table explaining the various destination possibilities. The arrow refers to where the output will end up. B indicates the WR addressed by the B ADDR, F refers to the output of the internal ALU, and A refers to the output of the WR addressed by the A ADDR. Up is toward the MSB, while down is toward the LSB.

nomenclature in listing	I8	I7	I6	octal code	RAM function shift	RAM function load	Q-reg function shift	Q-reg function load	Y output
LOAD Q	L	L	L	0	NONE	NONE	NONE	F->Q	F
NOP	L	L	H	1	NONE	NONE	NONE	NONE	F
WRITE.B.A	L	H	L	2	NONE	F->B	NONE	NONE	A
WRITE.B.F	L	H	H	3	NONE	F->B	NONE	NONE	F
RSHF.RAM.Q	H	L	L	4	DOWN	F/2->B	DOWN	Q/2->Q	F
RSHF.RAM	H	L	H	5	DOWN	F/2->B	NONE	NONE	F
LSHF.RAM.Q	H	H	L	6	UP	2F->B	UP	2Q->Q	F
LSHF.RAM	H	H	H	7	UP	2F->B	NONE	NONE	F

ALU DESTINATION CONTROL

```
                ;4626   .page
```

```
;4627   .PAGE
;4628   .TOC    "DIAGNOSTIC MACROS"
;4629
;4630   LS.DATA.WORD/=<15:0>
;4631   UPPER.BYTE/=<23:16>
;4632
;4633   WORD[]          "UPPER.BYTE/0,LS.DATA.WORD/@1"
;4634   COUNT.LS[]      "UPPER.BYTE/0,LS.DATA.WORD/@1"
;4635   COUNT.MM[]      "UPPER.BYTE/1,LS.DATA.WORD/@1"
;4636   START.ADR[]     "UPPER.BYTE/0,LS.DATA.WORD/@1"
;4637
;4638
;4639
;4640   ASCII.LIT/=<15:0>
;4641
;4642           CA=4341         ;ASCII VALUE FOR FILE NAMES
;4643           CB=4342         ;  |
;4644           CC=4343         ;  |
;4645           CD=4344         ;  |
;4646           CE=4345         ;  V
;4647           CF=4346
;4648           CG=4347
;4649           CH=4348
;4650
;4651
;4652   ASCII []        "UPPER.BYTE/0,ASCII.LIT/@1"
;4653
;4654
;4655   .REGION/0,6F
```

```
                    ;4656   .PAGE   "TEST POINTERS"
                    ;4657   ;
                    ;4658   ;       This portion contains the pointers to all tests in this section.  The
                    ;4659   ;       WCS address of the JUMP instruction corresponds to the test number.
                    ;4660   ;       E.g. WCS 5 contains a JUMP to test 5.  All unused test numbers will
                    ;4661   ;       contain a JUMP to an error routine.  This portion is 80. locations
                    ;4662   ;       long, allowing for up to 80. tests per section, from WCS address 1 to
                    ;4663   ;       WCS address 4F.
                    ;4664   ;
                    ;4665   1:                                      ;TEST POINTERS BEGIN AT WCS ADDRESS 1
                    ;4666
                    ;4667
                    ;4668
U 0001, 8875,74     ;4669           JMP [T.1]                       ;GO TO TEST 1
U 0002, 8878,64     ;4670           JMP [T.2]                       ;GO TO TEST 2
U 0003, 087B,E4     ;4671           JMP [T.3]                       ;GO TO TEST 3
U 0004, 087E,44     ;4672           JMP [T.4]                       ;GO TO TEST 4
U 0005, 0884,84     ;4673           JMP [T.5]                       ;GO TO TEST 5
U 0006, 088A,A4     ;4674           JMP [T.6]                       ;GO TO TEST 6
U 0007, 088F,A4     ;4675           JMP [T.7]                       ;GO TO TEST 7
U 0008, 8893,A4     ;4676           JMP [T.8]                       ;GO TO TEST 8
U 0009, 8896,C4     ;4677           JMP [T.9]                       ;GO TO TEST 9
U 000A, 0899,D4     ;4678           JMP [T.A]                       ;GO TO TEST A
U 000B, 089E,54     ;4679           JMP [T.B]                       ;GO TO TEST B
U 000C, 08A0,24     ;4680           JMP [T.C]                       ;GO TO TEST C
U 000D, 88A3,64     ;4681           JMP [T.D]                       ;GO TO TEST D
U 000E, 88A7,24     ;4682           JMP [T.E]                       ;GO TO TEST E
U 000F, 88AE,D4     ;4683           JMP [T.F]                       ;GO TO TEST F
U 0010, 08B4,B4     ;4684           JMP [T.10]                      ;GO TO TEST 10
U 0011, 08BB,74     ;4685           JMP [T.11]                      ;GO TO TEST 11
U 0012, 08C1,F4     ;4686           JMP [T.12]                      ;GO TO TEST 12
U 0013, 88C9,54     ;4687           JMP [T.13]                      ;GO TO TEST 13
U 0014, 08D0,A4     ;4688           JMP [T.14]                      ;GO TO TEST 14
U 0015, 08D8,D4     ;4689           JMP [T.15]                      ;GO TO TEST 15
U 0016, 88E0,B4     ;4690           JMP [T.16]                      ;GO TO TEST 16
U 0017, 88E9,84     ;4691           JMP [T.17]                      ;GO TO TEST 17
U 0018, 88F1,D4     ;4692           JMP [T.18]                      ;GO TO TEST 18
U 0019, 08F7,64     ;4693           JMP [T.19]                      ;GO TO TEST 19
U 001A, 88FB,B4     ;4694           JMP [T.1A]                      ;GO TO TEST 1A
U 001B, 08FF,44     ;4695           JMP [T.1B]                      ;GO TO TEST 1B
U 001C, 090D,44     ;4696           JMP [T.1C]                      ;GO TO TEST 1C
U 001D, 8913,34     ;4697           JMP [T.1D]                      ;GO TO TEST 1D
U 001E, 0917,C4     ;4698           JMP [T.1E]                      ;GO TO TEST 1E
U 001F, 091E,94     ;4699           JMP [T.1F]                      ;GO TO TEST 1F
U 0020, 8925,54     ;4700           JMP [T.20]                      ;GO TO TEST 20
U 0021, 0928,94     ;4701           JMP [T.21]                      ;GO TO TEST 21
U 0022, 092A,74     ;4702           JMP [T.22]                      ;GO TO TEST 22
U 0023, 892F,C4     ;4703           JMP [T.23]                      ;GO TO TEST 23
U 0024, 8935,14     ;4704           JMP [T.24]                      ;GO TO TEST 24
U 0025, 893A,24     ;4705           JMP [T.25]                      ;GO TO TEST 25
U 0026, 893C,D4     ;4706           JMP [T.26]                      ;GO TO TEST 26
U 0027, 0940,B4     ;4707           JMP [T.27]                      ;GO TO TEST 27
U 0028, 8943,F4     ;4708           JMP [T.28]                      ;GO TO TEST 28
U 0029, 8947,D4     ;4709           JMP [T.29]                      ;GO TO TEST 29
U 002A, 094B,94     ;4710           JMP [T.2A]                      ;GO TO TEST 2A
```

```
U 002B, 8950,44 ;4711          JMP [T.2B]                ;GO TO TEST 2B
U 002C, 0957,D4 ;4712          JMP [T.2C]                ;GO TO TEST 2C
U 002D, 095E,44 ;4713          JMP [T.2D]                ;GO TO TEST 2D
U 002E, 0963,A4 ;4714          JMP [T.2E]                ;GO TO TEST 2E
U 002F, 8968,54 ;4715          JMP [T.2F]                ;GO TO TEST 2F
U 0030, 096C,54 ;4716          JMP [T.30]                ;GO TO TEST 30
U 0031, 0973,84 ;4717          JMP [T.31]                ;GO TO TEST 31
U 0032, 8978,D4 ;4718          JMP [T.32]                ;GO TO TEST 32
U 0033, 897F,04 ;4719          JMP [T.33]                ;GO TO TEST 33
U 0034, 8986,34 ;4720          JMP [T.34]                ;GO TO TEST 34
U 0035, 098C,84 ;4721          JMP [T.35]                ;GO TO TEST 35
U 0036, 8991,F4 ;4722          JMP [T.36]                ;GO TO TEST 36
U 0037, 8995,B4 ;4723          JMP [T.37]                ;GO TO TEST 37
U 0038, 099A,A4 ;4724          JMP [T.38]                ;GO TO TEST 38
U 0039, 899D,F4 ;4725          JMP [T.39]                ;GO TO TEST 39
U 003A, 09AA,A4 ;4726          JMP [T.3A]                ;GO TO TEST 3A
U 003B, 89B1,E4 ;4727          JMP [T.3B]                ;GO TO TEST 3B
U 003C, 09B5,D4 ;4728          JMP [T.3C]                ;GO TO TEST 3C
U 003D, 89B9,F4 ;4729          JMP [T.3D]                ;GO TO TEST 3D
U 003E, 886B,E4 ;4730          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4731                                    ; IN THIS OVERLAY
U 003F, 886B,E4 ;4732          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4733                                    ; IN THIS OVERLAY
U 0040, 886B,E4 ;4734          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4735                                    ; IN THIS OVERLAY
U 0041, 886B,E4 ;4736          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4737                                    ; IN THIS OVERLAY
U 0042, 886B,E4 ;4738          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4739                                    ; IN THIS OVERLAY
U 0043, 886B,E4 ;4740          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4741                                    ; IN THIS OVERLAY
U 0044, 886B,E4 ;4742          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4743                                    ; IN THIS OVERLAY
U 0045, 886B,E4 ;4744          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4745                                    ; IN THIS OVERLAY
U 0046, 886B,E4 ;4746          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4747                                    ; IN THIS OVERLAY
U 0047, 886B,E4 ;4748          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4749                                    ; IN THIS OVERLAY
U 0048, 886B,E4 ;4750          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4751                                    ; IN THIS OVERLAY
U 0049, 886B,E4 ;4752          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4753                                    ; IN THIS OVERLAY
U 004A, 886B,E4 ;4754          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4755                                    ; IN THIS OVERLAY
U 004B, 886B,E4 ;4756          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4757                                    ; IN THIS OVERLAY
U 004C, 886B,E4 ;4758          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4759                                    ; IN THIS OVERLAY
U 004D, 886B,E4 ;4760          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4761                                    ; IN THIS OVERLAY
U 004E, 886B,E4 ;4762          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4763                                    ; IN THIS OVERLAY
U 004F, 886B,E4 ;4764          JMP [ERR.NO.TEST]         ;GO TO ERROR ROUTINE. NO SUCH TEST NUMBER
                ;4765                                    ; IN THIS OVERLAY
```

```
                    ;4766   .PAGE   'DIAGNOSTIC POINTERS"
                    ;4767   ;
                    ;4768   ;       This section contains all the pointers needed for this diagnostic
                    ;4769   ;       overlay.  The first pointer (at WCS location 0) points to a data
                    ;4770   ;       transfer routine.  It is the first location executed after a new
                    ;4771   ;       WCS load.  The insruction here is a JUMP to TRANSFER.POINT which may
                    ;4772   ;       contain instructions to transfer data.  If no data is to be trans-
                    ;4773   ;       ferred, or at the completion of the data transfers, the CPU will
                    ;4774   ;       issue CPU ATTN with all bits of the control and status word clear.
                    ;4775   ;
                    ;4776   ;       The next 80. locations (from WCS location 1 to WCS location 4F)
                    ;4777   ;       contain pointers to each test in this overlay.  The pointers are
                    ;4778   ;       JUMP instructions to the test number corresponding to the location
                    ;4779   ;       number.  E.g. location 5 will contain a JUMP to test 5.  All unused
                    ;4780   ;       test numbers will contain a JUMP to an error routine.  This portion
                    ;4781   ;       appears after the definitions in this listing.
                    ;4782   ;
                    ;4783   ;       Finally the next 32. locations (from WCS location 50 to 6F) contain
                    ;4784   ;       pointers (Jump instructions) to WCS subroutines which are to be used by
                    ;4785   ;       the console diagnostic monitor.
                    ;4786   ;
                    ;4787
U 0000, 086C,24     ;4788   0:      JMP [TRANSFER.POINT]            ;GO TO ROUTINE THAT LOADS LS 7 WITH
                    ;4789                                           ; POINTER TO DATA SECTION AND ISSUES
                    ;4790                                           ; CPU ATTN WITH TRANSFER BIT SET.
                    ;4791
                    ;4792   50:                                     ;START AT WCS LOCATION 50 FOR SUB-
                    ;4793                                           ; ROUTINE POINTERS
                    ;4794   ;
                    ;4795   ; SUBROUTINE POINTERS
                    ;4796   ;
U 0050, 0860,84     ;4797           JMP [DEPOSIT.CSR]               ;GO TO WCS SUBROUTINE WHICH WRITES THE
                    ;4798                                           ; MCT CSR FOR DEPOSIT CSR COMMAND
U 0051, 0860,D4     ;4799           JMP [EXAMINE.CSR]               ;GO TO WCS SUBROUTINE WHICH READS THE
                    ;4800                                           ; MCT CSR FOR EXAMINE CSR COMMAND
U 0052, 0861,F4     ;4801           JMP [DEPOSIT.TB]                ;GO TO WCS SUBROUTINE WHICH WRITES THE
                    ;4802                                           ; MCT TRANSLATION BUFFER FOR DEPOSIT
                    ;4803                                           ; TB COMMAND
U 0053, 8863,A4     ;4804           JMP [EXAMINE.TB]                ;GO TO WCS SUBROUTINE WHICH READS THE
                    ;4805                                           ; MCT TRANSLATION BUFFER FOR EXAMINE
                    ;4806                                           ; TB COMMAND
U 0054, 8865,C4     ;4807           JMP [DEPOSIT.MM]                ;GO TO WCS SUBROUTINE WHICH WRITES MAIN
                    ;4808                                           ; MEMORY FOR DEPOSIT MM COMMAND.  ALSO
                    ;4809                                           ; USED TRANSFERING DATA FROM WCS TO
                    ;4810                                           ; MAIN MEMORY.
U 0055, 0866,24     ;4811           JMP [EXAMINE.MM]                ;GO TO WCS SUBROUTINE WHICH READS MAIN
                    ;4812                                           ; MEMORY FOR EXAMiNE MM COMMAND.
U 0056, 0868,94     ;4813           JMP [SAVE.WR]                   ;GO TO WCS SUBROUTINE WHICH STORES THE
                    ;4814                                           ; CONTENTS OF WR0-WR3 IN LS 0-3
U 0057, 8868,E4     ;4815           JMP [RESTORE.WR]                ;GO TO WCS SUBROUTINE WHICH RESTORES THE
                    ;4816                                           ; CONTENTS OF WR0-WR3 FROM LS 0-3
U 0058, 8864,24     ;4817           JMP [DEPOSIT.UBS]               ;GO TO WCS SUBROUTINE WHICH WRITES THE
                    ;4818                                           ; UNIBUS MAP ON THE MEMORY CONTROLLER
U 0059, 0865,44     ;4819           JMP [EXAMINE.UBS]               ;GO TO WCS SUBROUTINE WHICH READS THE
                    ;4820                                           ; UNIBUS MAP ON THE MEMORY CONTROLLER
```

```
U 005A, 0866,84 ;4821           JMP [EXAMINE.ICSR]              ;GO TO WCS SUBROUTINE WHICH READS THE
                ;4822                                           ; IDC CSR
U 005B, 0866,B4 ;4823           JMP [EXAMINE.IDAR]              ;GO TO WCS SUBROUTINE WHICH READS THE
                ;4824                                           ; IDC DAR
U 005C, 0866,E4 ;4825           JMP [EXAMINE.DBUF]              ;GO TO WCS SUBROUTINE WHICH READS THE
                ;4826                                           ; IDC DBUF
U 005D, 8867,14 ;4827           JMP [EXAMINE.PATT]              ;GO TO WCS SUBROUTINE WHICH READS THE
                ;4828                                           ; IDC ECC PATTERN
U 005E, 8867,44 ;4829           JMP [EXAMINE.POSIT]             ;GO TO WCS SUBROUTINE WHICH READS THE
                ;4830                                           ; IDC ECC POSITION
U 005F, 0867,94 ;4831           JMP [DEPOSIT.ICSR]              ;GO TO WCS SUBROUTINE WHICH WRITES THE
                ;4832                                           ; IDC CSR
U 0060, 0867,C4 ;4833           JMP [DEPOSIT.IDAR]              ;GO TO WCS SUBROUTINE WHICH WRITES THE
                ;4834                                           ; IDC DAR
U 0061, 0867,F4 ;4835           JMP [DEPOSIT.DBUF]              ;GO TO WCS SUBROUTINE WHICH WRITES THE
                ;4836                                           ; IDC DBUF
U 0062, 8868,24 ;4837           JMP [CLEAR.FIFO.ADDR]           ;GO TO WCS SUBROUTINE WHICH CLEARS
                ;4838                                           ; THE IDC FIFO ADDRESS
U 0063, 8868,44 ;4839           JMP [SELECT.FIFO.A]             ;GO TO WCS SUBROUTINE WHICH SELECTS
                ;4840                                           ; FIFO A
U 0064, 0868,64 ;4841           JMP [SELECT.FIFO.B]             ;GO TO WCS SUBROUTINE WHICH SELECTS
                ;4842                                           ; FIFO B
U 0065, DB00,15 ;4843           NOP                             ;NOT USED
U 0066, DB00,15 ;4844           NOP                             ;NOT USED
U 0067, DB00,15 ;4845           NOP                             ;NOT USED
U 0068, DB00,15 ;4846           NOP                             ;NOT USED
U 0069, DB00,15 ;4847           NOP                             ;NOT USED
U 006A, DB00,15 ;4848           NOP                             ;NOT USED
U 006B, DB00,15 ;4849           NOP                             ;NOT USED
U 006C, DB00,15 ;4850           NOP                             ;NOT USED
U 006D, DB00,15 ;4851           NOP                             ;NOT USED
U 006E, DB00,15 ;4852           NOP                             ;NOT USED
U 006F, DB00,15 ;4853           NOP                             ;NOT USED
```

```
                    ;4854   .PAGE
                    ;4855   .REGION/70,5FF
                    ;4856   .TOC    "LS DATA SECTION"
                    ;4857
                    ;4858   ;+++
                    ;4859   ;       This section lists the data that will be transfered to LS by the con-
                    ;4860   ;       sole as part of the initialization performed in test 0.  The TRANSFER
                    ;4861   ;       DATA routine will point to this data area.  LS contains the constants,
                    ;4862   ;       control and status word, and temporary storage locations used by the
                    ;4863   ;       tests and subroutines of the microdiagnostic.
                    ;4864   ;         The LS is 32 bits wide.  Each of these words is 16 bits, so two con-
                    ;4865   ;       secutive words listed here will be loaded into each consecutive LS loc-
                    ;4866   ;       ation.  The first word listed will be bits 0-15 of the LS location, the
                    ;4867   ;       second word listed will be bits 16-31 of the same LS location.
                    ;4868   ;         The locations 78-7F in the first half of LS and F8-FF in the second
                    ;4869   ;       half of LS are not actual LS locations.  They force an access to one of
                    ;4870   ;       several registers in the CPU or force an indexing feature to another LS
                    ;4871   ;       location.  For that reason, they are not written via the transfer rou-
                    ;4872   ;       tine.
                    ;4873   ;         Note:  This table is in hexadecimal format i.e. each digit represents
                    ;4874   ;       four bits, so four digits represnts a full 16 bit word.  The micro-
                    ;4875   ;       assembler requires that a hexidecimal value that starts with a letter
                    ;4876   ;       (e.g. FFFF) be preceeded by a 0 (0FFFF).  So some table values will
                    ;4877   ;       contain 5 hexidecimal digits.  The fifth digit is not actually used.
                    ;4878   ;
                    ;4879   ;---
                    ;4880
                    ;4881   TRANSFER.DATA.LS1:
                    ;4882
U 0070, 0000.78     ;4883           COUNT.LS[0078]          ;LONGWORD COUNT (NUMBER OF LONGWORDS TO TRANS-
                    ;4884                                   ; FER TO LS = 120 DECIMAL) DESTINATION IS LS
U 0071, 0000.00     ;4885           START.ADR[0000]         ;DESTINATION START ADDRESS (START AT LS 0)
                    ;4886
U 0072, 0000.00     ;4887           WORD[0000]              ;LOCATION 0
U 0073, 0000.00     ;4888           WORD[0000]
                    ;4889
U 0074, 0000.00     ;4890           WORD[0000]              ;LOCATION 1
U 0075, 0000.00     ;4891           WORD[0000]
                    ;4892
U 0076, 0000.00     ;4893           WORD[0000]              ;LOCATION 2
U 0077, 0000.00     ;4894           WORD[0000]
                    ;4895
U 0078, 0000.00     ;4896           WORD[0000]              ;LOCATION 3
U 0079, 0000.00     ;4897           WORD[0000]
                    ;4898
U 007A, 0000.00     ;4899           WORD[0000]              ;LOCATION 4
U 007B, 0000.00     ;4900           WORD[0000]
                    ;4901
U 007C, 0000.00     ;4902           WORD[0000]              ;LOCATION 5
U 007D, 0000.00     ;4903           WORD[0000]
                    ;4904
U 007E, 0000.00     ;4905           WORD[0000]              ;LOCATION 6
U 007F, 0000.00     ;4906           WORD[0000]
                    ;4907
U 0080, 0000.00     ;4908           WORD[0000]              ;LOCATION 7
```

```
U 0081, 0000,00 ;4909           WORD[0000]
                ;4910
U 0082, 0000,00 ;4911           WORD[0000]              ;LOCATION 8
U 0083, 0000,00 ;4912           WORD[0000]
                ;4913
U 0084, 0000,00 ;4914           WORD[0000]              ;LOCATION 9
U 0085, 0000,00 ;4915           WORD[0000]
                ;4916
U 0086, 0000,00 ;4917           WORD[0000]              ;LOCATION 0A
U 0087, 0000,00 ;4918           WORD[0000]
                ;4919
U 0088, 0000,00 ;4920           WORD[0000]              ;LOCATION 0B
U 0089, 0000,00 ;4921           WORD[0000]
                ;4922
U 008A, 0000,00 ;4923           WORD[0000]              ;LOCATION 0C
U 008B, 0000,00 ;4924           WORD[0000]
                ;4925
U 008C, 0000,00 ;4926           WORD[0000]              ;LOCATION 0D
U 008D, 0000,00 ;4927           WORD[0000]
                ;4928
U 008E, 0000,00 ;4929           WORD[0000]              ;LOCATION 0E
U 008F, 0000,00 ;4930           WORD[0000]
                ;4931
U 0090, 0000,00 ;4932           WORD[0000]              ;LOCATION 0F
U 0091, 0000,00 ;4933           WORD[0000]
                ;4934
U 0092, 0000,00 ;4935           WORD[0000]              ;LOCATION 10
U 0093, 0000,00 ;4936           WORD[0000]
                ;4937
U 0094, 0000,00 ;4938           WORD[0000]              ;LOCATION 11
U 0095, 0000,00 ;4939           WORD[0000]
                ;4940
U 0096, 0000,00 ;4941           WORD[0000]              ;LOCATION 12
U 0097, 0000,00 ;4942           WORD[0000]
                ;4943
U 0098, 0000,FF ;4944           WORD[00FF]              ;LOCATION 13
U 0099, 0000,00 ;4945           WORD[0000]
                ;4946
U 009A, 00FF,FF ;4947           WORD[0FFFF]             ;LOCATION 14
U 009B, 0000,00 ;4948           WORD[0000]
                ;4949
U 009C, 0000,00 ;4950           WORD[0000]              ;LOCATION 15
U 009D, 00FF,00 ;4951           WORD[0FF00]
                ;4952
U 009E, 00FF,00 ;4953           WORD[0FF00]             ;LOCATION 16
U 009F, 00FF,FF ;4954           WORD[0FFFF]
                ;4955
U 00A0, 003F,FF ;4956           WORD[3FFF]              ;LOCATION 17
U 00A1, 0001,00 ;4957           WORD[0100]
                ;4958
U 00A2, 003F,FF ;4959           WORD[3FFF]              ;LOCATION 18
U 00A3, 007F,FE ;4960           WORD[7FFE]
                ;4961
U 00A4, 00FF,FF ;4962           WORD[0FFFF]             ;LOCATION 19
U 00A5, 00FE,7F ;4963           WORD[0FE7F]
```

```
                    ;4964
U 00A6, 0000,00 ;4965       WORD[0000]          ;LOCATION 1A
U 00A7, 007F,F8 ;4966       WORD[7FF8]
                    ;4967
U 00A8, 0080,00 ;4968       WORD[8000]          ;LOCATION 1B
U 00A9, 007F,FF ;4969       WORD[7FFF]
                    ;4970
U 00AA, 0000,00 ;4971       WORD[0000]          ;LOCATION 1C
U 00AB, 0000,00 ;4972       WORD[0000]
                    ;4973
U 00AC, 0000,00 ;4974       WORD[0000]          ;LOCATION 1D
U 00AD, 0000,00 ;4975       WORD[0000]
                    ;4976
U 00AE, 0005,00 ;4977       WORD[0500]          ;LOCATION 1E
U 00AF, 0000,80 ;4978       WORD[0080]
                    ;4979
U 00B0, 0005,00 ;4980       WORD[0500]          ;LOCATION 1F
U 00B1, 0000,00 ;4981       WORD[0000]
                    ;4982
U 00B2, 0000,01 ;4983       WORD[0001]          ;LOCATION 20
U 00B3, 0000,00 ;4984       WORD[0000]
                    ;4985
U 00B4, 0000,02 ;4986       WORD[0002]          ;LOCATION 21
U 00B5, 0000,00 ;4987       WORD[0000]
                    ;4988
U 00B6, 0000,04 ;4989       WORD[0004]          ;LOCATION 22
U 00B7, 0000,00 ;4990       WORD[0000]
                    ;4991
U 00B8, 0000,08 ;4992       WORD[0008]          ;LOCATION 23
U 00B9, 0000,00 ;4993       WORD[0000]
                    ;4994
U 00BA, 0000,10 ;4995       WORD[0010]          ;LOCATION 24
U 00BB, 0000,00 ;4996       WORD[0000]
                    ;4997
U 00BC, 0000,20 ;4998       WORD[0020]          ;LOCATION 25
U 00BD, 0000,00 ;4999       WORD[0000]
                    ;5000
U 00BE, 0000,40 ;5001       WORD[0040]          ;LOCATION 26
U 00BF, 0000,00 ;5002       WORD[0000]
                    ;5003
U 00C0, 0000,80 ;5004       WORD[0080]          ;LOCATION 27
U 00C1, 0000,00 ;5005       WORD[0000]
                    ;5006
U 00C2, 0001,00 ;5007       WORD[0100]          ;LOCATION 28
U 00C3, 0000,00 ;5008       WORD[0000]
                    ;5009
U 00C4, 0002,00 ;5010       WORD[0200]          ;LOCATION 29
U 00C5, 0000,00 ;5011       WORD[0000]
                    ;5012
U 00C6, 0004,00 ;5013       WORD[0400]          ;LOCATION 2A
U 00C7, 0000,00 ;5014       WORD[0000]
                    ;5015
U 00C8, 0008,00 ;5016       WORD[0800]          ;LOCATION 2B
U 00C9, 0000,00 ;5017       WORD[0000]
                    ;5018
```

```
U 00CA, 0010,00 ;5019          WORD[1000]          ;LOCATION 2C
U 00CB, 0000,00 ;5020          WORD[0000]
                ;5021
U 00CC, 0020,00 ;5022          WORD[2000]          ;LOCATION 2D
U 00CD, 0000,00 ;5023          WORD[0000]
                ;5024
U 00CE, 0040,00 ;5025          WORD[4000]          ;LOCATION 2E
U 00CF, 0000,00 ;5026          WORD[0000]
                ;5027
U 00D0, 0080,00 ;5028          WORD[8000]          ;LOCATION 2F
U 00D1, 0000,00 ;5029          WORD[0000]
                ;5030
U 00D2, 0000,00 ;5031          WORD[0000]          ;LOCATION 30
U 00D3, 0000,01 ;5032          WORD[0001]
                ;5033
U 00D4, 0000,00 ;5034          WORD[0000]          ;LOCATION 31
U 00D5, 0000,02 ;5035          WORD[0002]
                ;5036
U 00D6, 0000,00 ;5037          WORD[0000]          ;LOCATION 32
U 00D7, 0000,04 ;5038          WORD[0004]
                ;5039
U 00D8, 0000,00 ;5040          WORD[0000]          ;LOCATION 33
U 00D9, 0000,08 ;5041          WORD[0008]
                ;5042
U 00DA, 0000,00 ;5043          WORD[0000]          ;LOCATION 34
U 00DB, 0000,10 ;5044          WORD[0010]
                ;5045
U 00DC, 0000,00 ;5046          WORD[0000]          ;LOCATION 35
U 00DD, 0000,20 ;5047          WORD[0020]
                ;5048
U 00DE, 0000,00 ;5049          WORD[0000]          ;LOCATION 36
U 00DF, 0000,40 ;5050          WORD[0040]
                ;5051
U 00E0, 0000,00 ;5052          WORD[0000]          ;LOCATION 37
U 00E1, 0000,80 ;5053          WORD[0080]
                ;5054
U 00E2, 0000,00 ;5055          WORD[0000]          ;LOCATION 38
U 00E3, 0001,00 ;5056          WORD[0100]
                ;5057
U 00E4, 0000,00 ;5058          WORD[0000]          ;LOCATION 39
U 00E5, 0002,00 ;5059          WORD[0200]
                ;5060
U 00E6, 0000,00 ;5061          WORD[0000]          ;LOCATION 3A
U 00E7, 0004,00 ;5062          WORD[0400]
                ;5063
U 00E8, 0000,00 ;5064          WORD[0000]          ;LOCATION 3B
U 00E9, 0008,00 ;5065          WORD[0800]
                ;5066
U 00EA, 0000,00 ;5067          WORD[0000]          ;LOCATION 3C
U 00EB, 0010,00 ;5068          WORD[1000]
                ;5069
U 00EC, 0000,00 ;5070          WORD[0000]          ;LOCATION 3D
U 00ED, 0020,00 ;5071          WORD[2000]
                ;5072
U 00EE, 0000,00 ;5073          WORD[0000]          ;LOCATION 3E
```

```
U 00EF, 0040,00 ;5074           WORD[4000]
                ;5075
U 00F0, 0000,00 ;5076           WORD[0000]              ;LOCATION 3F
U 00F1, 0080,00 ;5077           WORD[8000]
                ;5078
U 00F2, 0000,00 ;5079           WORD[0000]              ;LOCATION 40
U 00F3, 0000,00 ;5080           WORD[0000]
                ;5081
U 00F4, 0000,00 ;5082           WORD[0000]              ;LOCATION 41
U 00F5, 0000,00 ;5083           WORD[0000]
                ;5084
U 00F6, 0000,00 ;5085           WORD[0000]              ;LOCATION 42
U 00F7, 0000,00 ;5086           WORD[0000]
                ;5087
U 00F8, 0000,00 ;5088           WORD[0000]              ;LOCATION 43
U 00F9, 0000,00 ;5089           WORD[0000]
                ;5090
U 00FA, 0000,00 ;5091           WORD[0000]              ;LOCATION 44
U 00FB, 0000,00 ;5092           WORD[0000]
                ;5093
U 00FC, 0000,00 ;5094           WORD[0000]              ;LOCATION 45
U 00FD, 0000,00 ;5095           WORD[0000]
                ;5096
U 00FE, 0000,00 ;5097           WORD[0000]              ;LOCATION 46
U 00FF, 0000,00 ;5098           WORD[0000]
                ;5099
U 0100, 0000,00 ;5100           WORD[0000]              ;LOCATION 47
U 0101, 0000,00 ;5101           WORD[0000]
                ;5102
U 0102, 0000,00 ;5103           WORD[0000]              ;LOCATION 48
U 0103, 0000,00 ;5104           WORD[0000]
                ;5105
U 0104, 0000,00 ;5106           WORD[0000]              ;LOCATION 49
U 0105, 0000,00 ;5107           WORD[0000]
                ;5108
U 0106, 0000,00 ;5109           WORD[0000]              ;LOCATION 4A
U 0107, 0000,00 ;5110           WORD[0000]
                ;5111
U 0108, 0000,00 ;5112           WORD[0000]              ;LOCATION 4B
U 0109, 0000,00 ;5113           WORD[0000]
                ;5114
U 010A, 00AA,AA ;5115           WORD[0AAAA]             ;LOCATION 4C
U 010B, 00AA,AA ;5116           WORD[0AAAA]
                ;5117
U 010C, 0055,55 ;5118           WORD[5555]              ;LOCATION 4D
U 010D, 0055,55 ;5119           WORD[5555]
                ;5120
U 010E, 0000,00 ;5121           WORD[0000]              ;LOCATION 4E
U 010F, 0000,00 ;5122           WORD[0000]
                ;5123
U 0110, 00FF,FF ;5124           WORD[0FFFF]             ;LOCATION 4F
U 0111, 00FF,FF ;5125           WORD[0FFFF]
                ;5126
U 0112, 0000,00 ;5127           WORD[0000]              ;LOCATION 50
U 0113, 0000,00 ;5128           WORD[0000]
```

```
                    ;5129
U 0114, 0000,00     ;5130           WORD[0000]              ;LOCATION 51
U 0115, 0000,00     ;5131           WORD[0000]
                    ;5132
U 0116, 0000,00     ;5133           WORD[0000]              ;LOCATION 52
U 0117, 0000,00     ;5134           WORD[0000]
                    ;5135
U 0118, 0000,00     ;5136           WORD[0000]              ;LOCATION 53
U 0119, 0000,00     ;5137           WORD[0000]
                    ;5138
U 011A, 0000,00     ;5139           WORD[0000]              ;LOCATION 54
U 011B, 0000,00     ;5140           WORD[0000]
                    ;5141
U 011C, 0000,00     ;5142           WORD[0000]              ;LOCATION 55
U 011D, 0000,00     ;5143           WORD[0000]
                    ;5144
U 011E, 0000,00     ;5145           WORD[0000]              ;LOCATION 56
U 011F, 0000,00     ;5146           WORD[0000]
                    ;5147
U 0120, 0000,00     ;5148           WORD[0000]              ;LOCATION 57
U 0121, 0000,00     ;5149           WORD[0000]
                    ;5150
U 0122, 0000,00     ;5151           WORD[0000]              ;LOCATION 58
U 0123, 0000,00     ;5152           WORD[0000]
                    ;5153
U 0124, 0000,00     ;5154           WORD[0000]              ;LOCATION 59
U 0125, 0000,00     ;5155           WORD[0000]
                    ;5156
U 0126, 00F0,00     ;5157           WORD[0F000]             ;LOCATION 5A
U 0127, 00FF,FF     ;5158           WORD[0FFFF]
                    ;5159
U 0128, 00F0,02     ;5160           WORD[0F002]             ;LOCATION 5B
U 0129, 00FF,FF     ;5161           WORD[0FFFF]
                    ;5162
U 012A, 00F0,04     ;5163           WORD[0F004]             ;LOCATION 5C
U 012B, 00FF,FF     ;5164           WORD[0FFFF]
                    ;5165
U 012C, 00F0,06     ;5166           WORD[0F006]             ;LOCATION 5D
U 012D, 00FF,FF     ;5167           WORD[0FFFF]
                    ;5168
U 012E, 00F0,08     ;5169           WORD[0F008]             ;LOCATION 5E
U 012F, 00FF,FF     ;5170           WORD[0FFFF]
                    ;5171
U 0130, 00F0,0E     ;5172           WORD[0F00E]             ;LOCATION 5F
U 0131, 00FF,FF     ;5173           WORD[0FFFF]
                    ;5174
U 0132, 0000,03     ;5175           WORD[0003]              ;LOCATION 60
U 0133, 0000,00     ;5176           WORD[0000]
                    ;5177
U 0134, 0000,12     ;5178           WORD[0012]              ;LOCATION 61
U 0135, 0000,00     ;5179           WORD[0000]
                    ;5180
U 0136, 0033,33     ;5181           WORD[3333]              ;LOCATION 62
U 0137, 0033,33     ;5182           WORD[3333]
                    ;5183
```

```
U 0138, 000F,0F ;5184          WORD[0F0F]              ;LOCATION 63
U 0139, 000F,0F ;5185          WORD[0F0F]
                ;5186
U 013A, 0000,FF ;5187          WORD[00FF]              ;LOCATION 64
U 013B, 0000,FF ;5188          WORD[00FF]
                ;5189
U 013C, 0001,62 ;5190          WORD[0162]              ;LOCATION 65
U 013D, 0000,00 ;5191          WORD[0000]
                ;5192
U 013E, 0000,28 ;5193          WORD[0028]              ;LOCATION 66
U 013F, 0000,00 ;5194          WORD[0000]
                ;5195
U 0140, 0000,0C ;5196          WORD[000C]              ;LOCATION 67
U 0141, 0000,00 ;5197          WORD[0000]
                ;5198
U 0142, 0000,00 ;5199          WORD[0000]              ;LOCATION 68
U 0143, 0000,00 ;5200          WORD[0000]
                ;5201
U 0144, 0000,00 ;5202          WORD[0000]              ;LOCATION 69
U 0145, 0000,00 ;5203          WORD[0000]
                ;5204
U 0146, 0000,00 ;5205          WORD[0000]              ;LOCATION 6A
U 0147, 0000,00 ;5206          WORD[0000]
                ;5207
U 0148, 0000,00 ;5208          WORD[0000]              ;LOCATION 6B
U 0149, 0000,00 ;5209          WORD[0000]
                ;5210
U 014A, 0000,00 ;5211          WORD[0000]              ;LOCATION 6C
U 014B, 0000,00 ;5212          WORD[0000]
                ;5213
U 014C, 0000,00 ;5214          WORD[0000]              ;LOCATION 6D
U 014D, 0000,00 ;5215          WORD[0000]
                ;5216
U 014E, 0000,00 ;5217          WORD[0000]              ;LOCATION 6E
U 014F, 0000,00 ;5218          WORD[0000]
                ;5219
U 0150, 0000,00 ;5220          WORD[0000]              ;LOCATION 6F
U 0151, 0000,00 ;5221          WORD[0000]
                ;5222
U 0152, 0000,00 ;5223          WORD[0000]              ;LOCATION 70
U 0153, 0000,00 ;5224          WORD[0000]
                ;5225
U 0154, 0000,00 ;5226          WORD[0000]              ;LOCATION 71
U 0155, 0000,00 ;5227          WORD[0000]
                ;5228
U 0156, 0000,00 ;5229          WORD[0000]              ;LOCATION 72
U 0157, 0000,00 ;5230          WORD[0000]
                ;5231
U 0158, 0000,00 ;5232          WORD[0000]              ;LOCATION 73
U 0159, 0000,00 ;5233          WORD[0000]
                ;5234
U 015A, 0000,00 ;5235          WORD[0000]              ;LOCATION 74
U 015B, 0000,00 ;5236          WORD[0000]
                ;5237
U 015C, 0000,00 ;5238          WORD[0000]              ;LOCATION 75
```

```
U 015D, 0000,00 ;5239           WORD[0000]
                ;5240
U 015E, 0000,00 ;5241           WORD[0000]              ;LOCATION 76
U 015F, 0000,00 ;5242           WORD[0000]
                ;5243
U 0160, 0000,00 ;5244           WORD[0000]              ;LOCATION 77
U 0161, 0000,00 ;5245           WORD[0000]
                ;5246
                ;5247   .TOC    "PROGRAM SPECIFIC DATA SECTION (LS 80-F7)"
                ;5248   ;
                ;5249   ;       This section represents the second half of LS.  It is only acceseble
                ;5250   ;       with a MOV instruction, or one that uses the MOVE microinstruction for-
                ;5251   ;       mat.  This section will be loaded in a seperate transfer.
                ;5252   ;
                ;5253   TRANSFER.DATA.LS2:
U 0162, 0000,78 ;5254           COUNT.LS[0078]          ;LONGWORD COUNT (NUMBER OF LONGWORDS TO TRANS-
                ;5255                                   ; FER TO LS = 120 DECIMAL) DESTINATION IS LS
U 0163, 0000,80 ;5256           START.ADR[0080]         ;DESTINATION START ADDRESS (START AT LS 80(H))
                ;5257
U 0164, 0000,00 ;5258           WORD[0000]              ;LOCATION 80
U 0165, 0010,00 ;5259           WORD[1000]
                ;5260
U 0166, 0000,02 ;5261           WORD[0002]              ;LOCATION 81
U 0167, 0010,00 ;5262           WORD[1000]
                ;5263
U 0168, 0000,04 ;5264           WORD[0004]              ;LOCATION 82
U 0169, 0010,00 ;5265           WORD[1000]
                ;5266
U 016A, 0000,06 ;5267           WORD[0006]              ;LOCATION 83
U 016B, 0010,00 ;5268           WORD[1000]
                ;5269
U 016C, 0000,08 ;5270           WORD[0008]              ;LOCATION 84
U 016D, 0010,00 ;5271           WORD[1000]
                ;5272
U 016E, 0000,0A ;5273           WORD[000A]              ;LOCATION 85
U 016F, 0010,00 ;5274           WORD[1000]
                ;5275
U 0170, 0000,0C ;5276           WORD[000C]              ;LOCATION 86
U 0171, 0010,00 ;5277           WORD[1000]
                ;5278
U 0172, 0000,0E ;5279           WORD[000E]              ;LOCATION 87
U 0173, 0010,00 ;5280           WORD[1000]
                ;5281
U 0174, 0000,40 ;5282           WORD[0040]              ;LOCATION 88
U 0175, 0000,00 ;5283           WORD[0000]
                ;5284
U 0176, 0000,80 ;5285           WORD[0080]              ;LOCATION 89
U 0177, 0000,00 ;5286           WORD[0000]
                ;5287
U 0178, 0000,00 ;5288           WORD[0000]              ;LOCATION 8A
U 0179, 0000,00 ;5289           WORD[0000]
                ;5290
U 017A, 0001,00 ;5291           WORD[0100]              ;LOCATION 8B
U 017B, 0000,00 ;5292           WORD[0000]
                ;5293
```

```
U 017C, 0002,00 ;5294          WORD[0200]          ;LOCATION 8C
U 017D, 0000,00 ;5295          WORD[0000]
                ;5296
U 017E, 0003,00 ;5297          WORD[0300]          ;LOCATION 8D
U 017F, 0000,00 ;5298          WORD[0000]
                ;5299
U 0180, 0000,00 ;5300          WORD[0000]          ;LOCATION 8E
U 0181, 0000,40 ;5301          WORD[0040]
                ;5302
U 0182, 0000,00 ;5303          WORD[0000]          ;LOCATION 8F
U 0183, 0000,80 ;5304          WORD[0080]
                ;5305
U 0184, 0000,00 ;5306          WORD[0000]          ;LOCATION 90
U 0185, 0002,00 ;5307          WORD[0200]
                ;5308
U 0186, 00FC,31 ;5309          WORD[0FC31]         ;LOCATION 91
U 0187, 00C5,3F ;5310          WORD[0C53F]
                ;5311
U 0188, 0000,00 ;5312          WORD[0000]          ;LOCATION 92
U 0189, 0000,00 ;5313          WORD[0000]
                ;5314
U 018A, 0001,44 ;5315          WORD[0144]          ;LOCATION 93
U 018B, 0002,40 ;5316          WORD[0240]
                ;5317
U 018C, 0002,8A ;5318          WORD[028A]          ;LOCATION 94
U 018D, 0000,80 ;5319          WORD[0080]
                ;5320
U 018E, 0001,86 ;5321          WORD[0186]          ;LOCATION 95
U 018F, 0002,80 ;5322          WORD[0280]
                ;5323
U 0190, 0000,4E ;5324          WORD[004E]          ;LOCATION 96
U 0191, 0002,80 ;5325          WORD[0280]
                ;5326
U 0192, 0003,CE ;5327          WORD[03CE]          ;LOCATION 97
U 0193, 0000,40 ;5328          WORD[0040]
                ;5329
U 0194, 0000,1A ;5330          WORD[001A]          ;LOCATION 98
U 0195, 0000,00 ;5331          WORD[0000]
                ;5332
U 0196, 0000,00 ;5333          WORD[0000]          ;LOCATION 99
U 0197, 0000,00 ;5334          WORD[0000]
                ;5335
U 0198, 0000,00 ;5336          WORD[0000]          ;LOCATION 9A
U 0199, 0000,00 ;5337          WORD[0000]
                ;5338
U 019A, 0000,00 ;5339          WORD[0000]          ;LOCATION 9B
U 019B, 0000,00 ;5340          WORD[0000]
                ;5341
U 019C, 0000,00 ;5342          WORD[0000]          ;LOCATION 9C
U 019D, 0000,00 ;5343          WORD[0000]
                ;5344
U 019E, 0000,00 ;5345          WORD[0000]          ;LOCATION 9D
U 019F, 0000,00 ;5346          WORD[0000]
                ;5347
U 01A0, 0000,00 ;5348          WORD[0000]          ;LOCATION 9E
```

```
U 01A1, 0000,00 ;5349          WORD[0000]
                ;5350
U 01A2, 0000,00 ;5351          WORD[0000]              ;LOCATION 9F
U 01A3, 0000,00 ;5352          WORD[0000]
                ;5353
U 01A4, 0000,00 ;5354          WORD[0000]              ;LOCATION 0AC
U 01A5, 0000,00 ;5355          WORD[0000]
                ;5356
U 01A6, 0000,00 ;5357          WORD[0000]              ;LOCATION 0A1
U 01A7, 0000,00 ;5358          WORD[0000]
                ;5359
U 01A8, 0000,00 ;5360          WORD[0000]              ;LOCATION 0A2
U 01A9, 0000,00 ;5361          WORD[0000]
                ;5362
U 01AA, 0000,00 ;5363          WORD[0000]              ;LOCATION 0A3
U 01AB, 0000,00 ;5364          WORD[0000]
                ;5365
U 01AC, 0000,00 ;5366          WORD[0000]              ;LOCATION 0A4
U 01AD, 0000,00 ;5367          WORD[0000]
                ;5368
U 01AE, 0000,00 ;5369          WORD[0000]              ;LOCATION 0A5
U 01AF, 0000,00 ;5370          WORD[0000]
                ;5371
U 01B0, 0000,00 ;5372          WORD[0000]              ;LOCATION 0A6
U 01B1, 0000,00 ;5373          WORD[0000]
                ;5374
U 01B2, 0000,00 ;5375          WORD[0000]              ;LOCATION 0A7
U 01B3, 0000,00 ;5376          WORD[0000]
                ;5377
U 01B4, 0000,00 ;5378          WORD[0000]              ;LOCATION 0A8
U 01B5, 0000,00 ;5379          WORD[0000]
                ;5380
U 01B6, 0000,00 ;5381          WORD[0000]              ;LOCATION 0A9
U 01B7, 0000,00 ;5382          WORD[0000]
                ;5383
U 01B8, 0000,00 ;5384          WORD[0000]              ;LOCATION 0AA
U 01B9, 0000,00 ;5385          WORD[0000]
                ;5386
U 01BA, 0000,00 ;5387          WORD[0000]              ;LOCATION 0AB
U 01BB, 0000,00 ;5388          WORD[0000]
                ;5389
U 01BC, 0000,00 ;5390          WORD[0000]              ;LOCATION 0AC
U 01BD, 0000,00 ;5391          WORD[0000]
                ;5392
U 01BE, 0000,00 ;5393          WORD[0000]              ;LOCATION 0AD
U 01BF, 0000,00 ;5394          WORD[0000]
                ;5395
U 01C0, 0000,00 ;5396          WORD[0000]              ;LOCATION 0AE
U 01C1, 0000,00 ;5397          WORD[0000]
                ;5398
U 01C2, 0000,00 ;5399          WORD[0000]              ;LOCATION 0AF
U 01C3, 0000,00 ;5400          WORD[0000]
                ;5401
U 01C4, 0000,00 ;5402          WORD[0000]              ;LOCATION 0B0
U 01C5, 0000,00 ;5403          WORD[0000]
```

```
                ;5404
U 01C6, 0000,00 ;5405           WORD[0000]              ;LOCATION 0B1
U 01C7, 0000,00 ;5406           WORD[0000]
                ;5407
U 01C8, 0000,00 ;5408           WORD[0000]              ;LOCATION 0B2
U 01C9, 0000,00 ;5409           WORD[0000]
                ;5410
U 01CA, 0000,00 ;5411           WORD[0000]              ;LOCATION 0B3
U 01CB, 0000,00 ;5412           WORD[0000]
                ;5413
U 01CC, 0000,00 ;5414           WORD[0000]              ;LOCATION 0B4
U 01CD, 0000,00 ;5415           WORD[0000]
                ;5416
U 01CE, 0000,00 ;5417           WORD[0000]              ;LOCATION 0B5
U 01CF, 0000,00 ;5418           WORD[0000]
                ;5419
U 01D0, 0000,00 ;5420           WORD[0000]              ;LOCATION 0B6
U 01D1, 0000,00 ;5421           WORD[0000]
                ;5422
U 01D2, 0000,00 ;5423           WORD[0000]              ;LOCATION 0B7
U 01D3, 0000,00 ;5424           WORD[0000]
                ;5425
U 01D4, 0000,00 ;5426           WORD[0000]              ;LOCATION 0B8
U 01D5, 0000,00 ;5427           WORD[0000]
                ;5428
U 01D6, 00FF,FF ;5429           WORD[0FFFF]             ;LOCATION 0B9
U 01D7, 0000,00 ;5430           WORD[0000]
                ;5431
U 01D8, 0000,86 ;5432           WORD[0086]              ;LOCATION 0BA
U 01D9, 0000,00 ;5433           WORD[0000]
                ;5434
U 01DA, 0000,00 ;5435           WORD[0000]              ;LOCATION 0BB
U 01DB, 00FF,F8 ;5436           WORD[0FFF8]
                ;5437
U 01DC, 0002,C4 ;5438           WORD[02C4]              ;LOCATION 0BC
U 01DD, 0028,80 ;5439           WORD[2880]
                ;5440
U 01DE, 0001,8A ;5441           WORD[018A]              ;LOCATION 0BD
U 01DF, 0012,40 ;5442           WORD[1240]
                ;5443
U 01E0, 0003,86 ;5444           WORD[0386]              ;LOCATION 0BE
U 01E1, 000A,00 ;5445           WORD[0A00]
                ;5446
U 01E2, 0000,CE ;5447           WORD[00CE]              ;LOCATION 0BF
U 01E3, 003A,00 ;5448           WORD[3A00]
                ;5449
U 01E4, 0003,CE ;5450           WORD[03CE]              ;LOCATION 0C0
U 01E5, 0000,40 ;5451           WORD[0040]
                ;5452
U 01E6, 00FF,7F ;5453           WORD[0FF7F]             ;LOCATION 0C1
U 01E7, 00FF,FF ;5454           WORD[0FFFF]
                ;5455
U 01E8, 00FF,FF ;5456           WORD[0FFFF]             ;LOCATION 0C2
U 01E9, 00FF,BF ;5457           WORD[0FFBF]
                ;5458
```

```
U 01EA, 00FF,FF ;5459          WORD[0FFFF]          ;LOCATION 0C3
U 01EB, 00FF,7F ;5460          WORD[0FF7F]
                ;5461
U 01EC, 0000,03 ;5462          WORD[0003]           ;LOCATION 0C4
U 01ED, 0000,00 ;5463          WORD[0000]
                ;5464
U 01EE, 0000,FE ;5465          WORD[00FE]           ;LOCATION 0C5
U 01EF, 0000,00 ;5466          WORD[0000]
                ;5467
U 01F0, 0001,FE ;5468          WORD[01FE]           ;LOCATION 0C6
U 01F1, 0000,00 ;5469          WORD[0000]
                ;5470
U 01F2, 0000,00 ;5471          WORD[0000]           ;LOCATION 0C7
U 01F3, 0000,00 ;5472          WORD[0000]
                ;5473
U 01F4, 00FF,F0 ;5474          WORD[0FFF0]          ;LOCATION 0C8
U 01F5, 00FF,FF ;5475          WORD[0FFFF]
                ;5476
U 01F6, 0000,06 ;5477          WORD[0006]           ;LOCATION 0C9
U 01F7, 0000,00 ;5478          WORD[0000]
                ;5479
U 01F8, 00FF,FF ;5480          WORD[0FFFF]          ;LOCATION 0CA
U 01F9, 0000,07 ;5481          WORD[0007]
                ;5482
U 01FA, 0000,0F ;5483          WORD[000F]           ;LOCATION 0CB
U 01FB, 0000,00 ;5484          WORD[0000]
                ;5485
U 01FC, 00FC,FF ;5486          WORD[0FCFF]          ;LOCATION 0CC
U 01FD, 00FF,FF ;5487          WORD[0FFFF]
                ;5488
U 01FE, 00FF,FC ;5489          WORD[0FFFC]          ;LOCATION 0CD
U 01FF, 00FF,FF ;5490          WORD[0FFFF]
                ;5491
U 0200, 00FF,80 ;5492          WORD[0FF80]          ;LOCATION 0CE
U 0201, 00FF,FF ;5493          WORD[0FFFF]
                ;5494
U 0202, 0000,00 ;5495          WORD[0000]           ;LOCATION 0CF
U 0203, 0020,00 ;5496          WORD[2000]
                ;5497
U 0204, 0005,00 ;5498          WORD[0500]           ;LOCATION 0D0
U 0205, 0020,10 ;5499          WORD[2010]
                ;5500
U 0206, 0005,00 ;5501          WORD[0500]           ;LOCATION 0D1
U 0207, 00A0,10 ;5502          WORD[0A010]
                ;5503
U 0208, 00FF,FF ;5504          WORD[0FFFF]          ;LOCATION 0D2
U 0209, 00FF,CF ;5505          WORD[0FFCF]
                ;5506
U 020A, 00E0,00 ;5507          WORD[0E000]          ;LOCATION 0D3
U 020B, 00FF,FF ;5508          WORD[0FFFF]
                ;5509
U 020C, 0000,69 ;5510          WORD[0069]           ;LOCATION 0D4
U 020D, 0000,00 ;5511          WORD[0000]
                ;5512
U 020E, 0068,37 ;5513          WORD[6837]           ;LOCATION 0D5
```

```
U 020F, 0000,00 ;5514           WORD[0000]
                ;5515
U 0210, 0072,00 ;5516           WORD[7200]              ;LOCATION 0D6
U 0211, 0000,00 ;5517           WORD[0000]
                ;5518
U 0212, 00F8,00 ;5519           WORD[0F800]             ;LOCATION 0D7
U 0213, 00FF,FF ;5520           WORD[0FFFF]
                ;5521
U 0214, 0010,21 ;5522           WORD[1021]              ;LOCATION 0D8
U 0215, 0000,00 ;5523           WORD[0000]
                ;5524
U 0216, 0005,00 ;5525           WORD[0500]              ;LOCATION 0D9
U 0217, 00A0,01 ;5526           WORD[0A001]
                ;5527
U 0218, 0005,00 ;5528           WORD[0500]              ;LOCATION 0DA
U 0219, 0020,01 ;5529           WORD[2001]
                ;5530
U 021A, 0000,1F ;5531           WORD[001F]              ;LOCATION 0DB
U 021B, 0000,00 ;5532           WORD[0000]
                ;5533
U 021C, 0001,69 ;5534           WORD[0169]              ;LOCATION 0DC
U 021D, 0000,00 ;5535           WORD[0000]
                ;5536
U 021E, 0001,01 ;5537           WORD[0101]              ;LOCATION 0DD
U 021F, 0000,00 ;5538           WORD[0000]
                ;5539
U 0220, 00FF,FF ;5540           WORD[0FFFF]             ;LOCATION 0DE
U 0221, 00FF,F0 ;5541           WORD[0FFF0]
                ;5542
U 0222, 0000,00 ;5543           WORD[0000]              ;LOCATION 0DF
U 0223, 0000,03 ;5544           WORD[0003]
                ;5545
U 0224, 0000,00 ;5546           WORD[0000]              ;LOCATION 0E0
U 0225, 0000,07 ;5547           WORD[0007]
                ;5548
U 0226, 0000,00 ;5549           WORD[0000]              ;LOCATION 0E1
U 0227, 0000,0F ;5550           WORD[000F]
                ;5551
U 0228, 00EB,FF ;5552           WORD[0EBFF]             ;LOCATION 0E2
U 0229, 00FF,FF ;5553           WORD[0FFFF]
                ;5554
U 022A, 006B,FF ;5555           WORD[6BFF]              ;LOCATION 0E3
U 022B, 00FF,FF ;5556           WORD[0FFFF]
                ;5557
U 022C, 0094,00 ;5558           WORD[9400]              ;LOCATION 0E4
U 022D, 0000,00 ;5559           WORD[0000]
                ;5560
U 022E, 006F,FF ;5561           WORD[6FFF]              ;LOCATION 0E5
U 022F, 00FF,FF ;5562           WORD[0FFFF]
                ;5563
U 0230, 0090,00 ;5564           WORD[9000]              ;LOCATION 0E6
U 0231, 0000,00 ;5565           WORD[0000]
                ;5566
U 0232, 00EF,FF ;5567           WORD[0EFFF]             ;LOCATION 0E7
U 0233, 00FF,FF ;5568           WORD[0FFFF]
```

```
                    ;5569
U 0234, 0011,11     ;5570           WORD[1111]              ;LOCATION 0E8
U 0235, 0011,11     ;5571           WORD[1111]
                    ;5572
U 0236, 0022,22     ;5573           WORD[2222]              ;LOCATION 0E9
U 0237, 0022,22     ;5574           WORD[2222]
                    ;5575
U 0238, 0044,44     ;5576           WORD[4444]              ;LOCATION 0EA
U 0239, 0044,44     ;5577           WORD[4444]
                    ;5578
U 023A, 0000,00     ;5579           WORD[0000]              ;LOCATION 0EB
U 023B, 0000,0F     ;5580           WORD[000F]
                    ;5581
U 023C, 00D3,5E     ;5582           WORD[0D35E]             ;LOCATION 0EC
U 023D, 0000,02     ;5583           WORD[0002]
                    ;5584
U 023E, 008A,EE     ;5585           WORD[8AEE]              ;LOCATION 0ED
U 023F, 0000,02     ;5586           WORD[0002]
                    ;5587
U 0240, 00A6,BF     ;5588           WORD[0A6BF]             ;LOCATION 0EE
U 0241, 0000,05     ;5589           WORD[0005]
                    ;5590
U 0242, 00A6,C2     ;5591           WORD[0A6C2]             ;LOCATION 0EF
U 0243, 0000,05     ;5592           WORD[0005]
                    ;5593
U 0244, 00FB,FF     ;5594           WORD[0FBFF]             ;LOCATION 0F0
U 0245, 00FF,FF     ;5595           WORD[0FFFF]
                    ;5596
U 0246, 00FF,7F     ;5597           WORD[0FF7F]             ;LOCATION 0F1
U 0247, 00FF,FF     ;5598           WORD[0FFFF]
                    ;5599
U 0248, 0000,80     ;5600           WORD[0080]              ;LOCATION 0F2
U 0249, 0010,00     ;5601           WORD[1000]
                    ;5602
U 024A, 004D,84     ;5603           WORD[4D84]              ;LOCATION 0F3
U 024B, 0000,0B     ;5604           WORD[000B]
                    ;5605
U 024C, 00FF,FF     ;5606           WORD[0FFFF]             ;LOCATION 0F4
U 024D, 00FF,3F     ;5607           WORD[0FF3F]
                    ;5608
U 024E, 00FF,E3     ;5609           WORD[0FFE3]             ;LOCATION 0F5
U 024F, 00FF,FF     ;5610           WORD[0FFFF]
                    ;5611
U 0250, 00FF,FF     ;5612           WORD[0FFFF]             ;LOCATION 0F6
U 0251, 00FE,FF     ;5613           WORD[0FEFF]
                    ;5614
U 0252, 0000,00     ;5615           WORD[0000]              ;LOCATION 0F7
U 0253, 0000,00     ;5616           WORD[0000]
                    ;5617
                    ;5618   .REGION/600,6FF
```

```
                ;5619   .PAGE   "WCS SUBROUTINES FOR CONSOLE USE"
                ;5620   .TOC    "  GENERATE TRANSFER DATA"
                ;5621   ;
                ;5622   ;       This routine is used by the diagnostic monitor to load WR 0 with a
                ;5623   ;       data pattern from the console.  The monitor will set CONSOLE ATTN if
                ;5624   ;       a 1 is to be generated, or clear CONSOLE ATTN if a 0 is to be gen-
                ;5625   ;       erated.  It will then single step this routine to shift the data bit
                ;5626   ;       into WR 0.  This routine loads a 32 bit value much more quickly than
                ;5627   ;       shifting each instruction into the CSR from the monitor, and is used
                ;5628   ;       mainly to set up data to load in LS for constants.
                ;5629   ;
                ;5630
                ;5631   ;                                       ***WARNING***
                ;5632   ;
                ;5633   ;       This routine must start at 600 and end at 605.  DO NOT move this
                ;5634   ;       routine to any other area!!
                ;5635   ;
                ;5636   ;
                ;5637
                ;5638   GEN.XFER.DATA:
U 0600, 2F80,15 ;5639           CLR WR[0]                       ;CLEAR A WORKING REG
U 0601, A0C0,15 ;5640           COM WR[0]                       ;NOW WR 0 IS ALL ONES
                ;5641   LOOP.XFER:
U 0602, 5B00,18 ;5642           SKIP.IF[CONSOLE.ATTN]           ;SKIP NEXT INSTRUCTION IS CONSOLE ATTN
                ;5643                                           ; IS SET (GENERATING A 1)
                ;5644           ASHL WR[0],                     ;SHIFT A 0 INTO BIT 0 OF WR 0
U 0603, A3D0,1E ;5645            SKIP                           ; AND SKIP ROL
U 0604, A3C0,15 ;5646           ROL WR[0]                       ;SHIFT A 1 INTO BIT 0 OF WR 0
U 0605, 0860,24 ;5647           JMP [LOOP.XFER]                 ;REPEAT
                ;5648
                ;5649
                ;5650   ;
                ;5651   ;       DIAGNOSTIC VERSION NUMBER IS STORED HERE
                ;5652   ;
                ;5653
                ;5654   ;                                       ***WARNING***
                ;5655   ;
                ;5656   ;       These words must be at location 606 and 607.  DO NOT move this word
                ;5657   ;       to any other area!!
                ;5658   ;
                ;5659   ;
                ;5660
U 0606, 0001,40 ;5661           WORD[0140]                      ;VERSION 01.40
U 0607, 0043,46 ;5662           ASCII [CF]                      ;LAST 2 LETTERS OF FILE NAME [ENKCF]
                ;5663
                ;5664
```

```
;5665    .PAGE   "  DEPOSIT MCT CSR ROUTINE"
;5666    ;+++
;5667    ;
;5668    ; FUNCTIONAL DESCRIPTION:
;5669    ;
;5670    ;       The deposit to CSR routine is used to write the memory controller's
;5671    ;       control and status register.  The memory controller has three CSRs
;5672    ;       named CSR 0, CSR 1, and CSR 2.
;5673    ;         CSR 0 contains checkbits or syndrome bits returned from the ECC logic
;5674    ;       after certain diagnostic routines.  It is NOT writable directly with
;5675    ;       this routine.
;5676    ;         CSR 1 contains error bits set if an error occurs on a memory access.
;5677    ;       It does contain five maintenance bits (bits 29-25) which are writable.
;5678    ;       There are also seven checkbits (bits 6-0) which are writable, but not
;5679    ;       readable.  These bits are used to write checkbits into the ECC chips.
;5680    ;         CSR 2 contains error bits set if a UNIBUS error occurs on a UNIBUS
;5681    ;       access.  These are read only bits and are NOT writable by this routine.
;5682    ;         Therefore, CSR 1 is the only writable CSR, and only bits 29-25 can be
;5683    ;       both written and read back.  This routine will thus force CSR 1 on a
;5684    ;       deposit to CSR.
;5685    ;         This routine will write LS 5 with data to access CSR 1, then write
;5686    ;       the data residing in LS 6 into the CSR.  It will then issue CPU ATTN
;5687    ;       to inform the console that it has completed the function.
;5688    ;         NOTE:  The error bits of CSR 1 are cleared on any write to CSR 1.
;5689    ;       These are bits 31, 30 and 23-14.Bits 13-0 and bit 24 are unused.
;5690    ;
;5691    ; CALLING SEQUENCE:
;5692    ;
;5693    ;       The console loads the address of a pointer to this routine (a JMP in-
;5694    ;       struction at WCS location 50) into the UPC and starts the CPU.
;5695    ;
;5696    ; INPUT PARAMETERS:
;5697    ;
;5698    ;       LS location 6 must have been written by the console with the desired
;5699    ;       data to be deposited in CSR 1 previous to executing this routine.
;5700    ;
;5701    ; IMPLICIT INPUTS:
;5702    ;
;5703    ;       None
;5704    ;
;5705    ; OUTPUT PARAMATERS:
;5706    ;
;5707    ;       CSR 1 bits 29-25 and 6-0 are written with data from LS 6.
;5708    ;
;5709    ; IMPLICIT OUTPUTS:
;5710    ;
;5711    ;       None
;5712    ;
;5713    ; SIDE EFFECTS:
;5714    ;
;5715    ;       WR 0 will be modified by this routine.
;5716    ;       LS 5 will be modified by this routine.
;5717    ;       CSR 1 bits 31, 30 and 23-14 are cleared.
;5718    ;
;5719    ;---
```

```
                    ;5720
                    ;5721   DEPOSIT.CSR:
                    ;5722
U 0608, 3644,15     ;5723           MOV LS[CSR1] TO WR[0]           ;SET BIT 2 IN WR 0 AS CSR NUMBER TO
                    ;5724                                           ; WRITE (BITS 2 AND 3 ARE CSR NUMBER)
U 0609, BE0A,15     ;5725           MOV WR[0] TO LS[T5.SUB]         ;PUT CSR NUMBER IN LS LOCATION 5 (CSR
                    ;5726                                           ; 1)
U 060A, 1D0B,F5     ;5727           MEM.REQ[WRITE.CSR] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO
                    ;5728                                           ; ACCESS CSR 1
U 060B, B20C,15     ;5729           WRITE.MEM LS[T6.SUB]            ;SEND DATA IN LS LOCATION 6 TO CSR 1
U 060C, 8868,74     ;5730           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
```

```
                ;5731   .PAGE   "  EXAMINE MCT CSR ROUTINE"
                ;5732   ;+++
                ;5733   ;
                ;5734   ; FUNCTIONAL DESCRIPTION:
                ;5735   ;
                ;5736   ;       The examine CSR routine reads the memory controller's control and
                ;5737   ;       status register.  There are 3 CSRs labeled CSR 0, CSR 1 and CSR 2.
                ;5738   ;         CSR 0 contains checkbits or syndrome bits from the ECC logic.
                ;5739   ;       These are contained in bits 6-0 of the CSR.  Other bits are UNPRE-
                ;5740   ;       DICTABLE.  Bits 6-0 are only written by special diagnostic routines
                ;5741   ;       (they are not writtable by the DEPOSIT CSR command).
                ;5742   ;         CSR 1 contains error bits and maintenance bits.  The error bits are
                ;5743   ;       31, 30, and 23-14.  Maintenance bits are 29-25.  The other bits are
                ;5744   ;       UNPREDICTABLE.  The error bits are written during memory functions
                ;5745   ;       only and are not writable via the DEPOSIT CSR command. The maintenance
                ;5746   ;       bits are writable.  Note that a DEPOSIT CSR command will write the
                ;5747   ;       maintenance bits and clear all error bits.
                ;5748   ;         CSR 2 contains three bits (bits 16-14) which are readable.  These are
                ;5749   ;       set when a UNIBUS error occurs on a UNIBUS access.  They are not
                ;5750   ;       directly writable with the DEPOSIT CSR command.
                ;5751   ;         The console loads LS 5 with the CSR number (0, 1, or 2) to be read.
                ;5752   ;       This routine rotates LS 5 two places left to position it correctly.
                ;5753   ;       It then executes a read CSR and places the data in LS 6 for the console
                ;5754   ;       to read.
                ;5755   ;
                ;5756   ; CALLING SEQUENCE:
                ;5757   ;
                ;5758   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;5759   ;       struction at WCS location 51) into the UPC and starts the CPU.
                ;5760   ;
                ;5761   ; INPUT PARAMETERS:
                ;5762   ;
                ;5763   ;       LS 5 contains the CSR number to be read.
                ;5764   ;
                ;5765   ; IMPLICIT INPUTS:
                ;5766   ;
                ;5767   ;       None
                ;5768   ;
                ;5769   ; OUTPUT PARAMATERS:
                ;5770   ;
                ;5771   ;       LS 6 - Data read from CSR selected.
                ;5772   ;
                ;5773   ; IMPLICIT OUTPUTS:
                ;5774   ;
                ;5775   ;       None
                ;5776   ;
                ;5777   ; SIDE EFFECTS:
                ;5778   ;
                ;5779   ;       LS 5 is rotated 2 places left.
                ;5780   ;
                ;5781   ;---
                ;5782
                ;5783   EXAMINE.CSR:
                ;5784
U 060D, 360A,15 ;5785           MOV LS[T5.SUB] TO WR[0]         ;GET CSR NUMBER FROM LS 5
```

```
U 060E, A2D0,15 ;5786           SHL2 WR[0]                          ;SHIFT NUMBER 2 PLACES LEFT TO GET
                ;5787                                               ; CSR NUMBER IN BITS 2 AND 3
U 060F, BE0A,15 ;5788           MOV WR[0] TO LS[T5.SUB]             ;PUT SHIFTED NUMBER IN LS 5
                ;5789
U 0610, 9D0B,75 ;5790           MEM.REQ[READ.CSR] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO
                ;5791                                               ; ACCESS CSR SPECIFIED
U 0611, 3022,15 ;5792           MOV MEM.DATA TO WR[0]               ;READ CSR SELECTED
                ;5793
                ;5794   CHECK.CSR2:
U 0612, B60A,95 ;5795           MOV LS[T5.SUB] TO WR[1]             ;GET SHIFTED CSR NUMBER
                ;5796           CMP LS[#8] WITH WR[1],              ;SEE IF CSR 2 WAS SELECTED
U 0613, CE46,B5 ;5797            DT(LONG)&SET.ALU.CC                ; SET UP CONDITION CODES
U 0614, 0861,61 ;5798           JMP.IF[NEQ] TO [CHECK.CSR1]         ;JUMP IF CSR 2 WAS NOT SELECTED
U 0615, C530,15 ;5799           BIC LS[CSR2.MASK] TO WR[0]          ;CLEAR UNUSED (UNPREDICTABLE) BITS IN
                ;5800                                               ; CSR 2.
                ;5801   CHECK.CSR1:
                ;5802           CMP LS[#4] WITH WR[1],              ;SEE IF CSR 1 WAS SELECTED
U 0616, 4E44,B5 ;5803            DT(LONG)&SET.ALU.CC                ; SET UP CONDITION CODES
U 0617, 0861,91 ;5804           JMP.IF[NEQ] TO [CHECK.CSR0]         ;JUMP IF CSR 1 WAS NOT SELECTED
U 0618, C52E,15 ;5805           BIC LS[CSR1.MASK] TO WR[0]          ;CLEAR UNUSED (UNPREDICTABLE) BITS IN
                ;5806                                               ; CSR 1.
                ;5807   CHECK.CSR0:
                ;5808           CMP LS[#0] WITH WR[1],              ;SEE IF CSR 0 WAS SELECTED
U 0619, 4E9C,B5 ;5809            DT(LONG)&SET.ALU.CC                ; SET UP CONDITION CODES
U 061A, 8861,D1 ;5810           JMP.IF[NEQ] TO [LOAD.LS6]           ;JUMP IF CSR 0 WAS NOT SELECTED
U 061B, 452C,15 ;5811           BIC LS[CSR0.MASK] TO WR[0]          ;CLEAR UNUSED (UNPREDICTABLE) BITS IN
                ;5812                                               ; CSR 0.
U 061C, C54E,15 ;5813           BIC LS[BIT7] TO WR[0]               ;BIT 7 IS ALSO UNUSED
                ;5814
                ;5815   LOAD.LS6:
U 061D, BE0C,15 ;5816           MOV WR[0] TO LS[T6.SUB]             ;LOAD CSR DATA INTO LS 6 FOR PRINTOUT
U 061E, 8868,74 ;5817           JMP [WAIT.SUB]                      ;ISSUE CPU ATTN AND WAIT FOR RESPONSE
```

```
                ;5818   .page   '' DEPOSIT MCT TRANSLATION BUFFER ROUTINE''
                ;5819   ;+++
                ;5820   ;
                ;5821   ; FUNCTIONAL DESCRIPTION:
                ;5822   ;
                ;5823   ;       This routine allows a write to the translation buffer portion of the
                ;5824   ;       memory controller.  The buffer area contains 128 decimal locations
                ;5825   ;       addressed from 0-7F(H).  The remainder of the TB RAM is either unused
                ;5826   ;       or contains the UNIBUS MAP.  The DEPOSIT UB command is used to write
                ;5827   ;       the UNIBUS map portion of the TB RAMs.  The address specified with the
                ;5828   ;       DEPOSIT command will be the actual RAM address accessed.  This routine
                ;5829   ;       will do any shifting necessary on the address specified to position it
                ;5830   ;       correctly.  The address specified has been loaded by the console in LS
                ;5831   ;       location 5 prior to executing this routine.  The address must be in HEX
                ;5832   ;       format.
                ;5833   ;         The data specified has been placed in LS 6 by the console prior to
                ;5834   ;       executing this routine.  Bits 07-01 will be the Valid, Prot, Modify,
                ;5835   ;       and Byte Offset bits (there are four Prot bits).  Bits 22-08 will
                ;5836   ;       contain the PA bits from PA 23 through PA 09 respectively.  Bits 31
                ;5837   ;       through 23 and bit 0 are unused. This routine will do any shifting nec-
                ;5838   ;       essary to write the bits in TB as described.  The data specified must
                ;5839   ;       be in HEX format.
                ;5840   ;
                ;5841   ; CALLING SEQUENCE:
                ;5842   ;
                ;5843   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;5844   ;       struction at WCS location 52) into the UPC and starts the CPU.
                ;5845   ;
                ;5846   ; INPUT PARAMETERS:
                ;5847   ;
                ;5848   ;       LS 5 - TB address to be written (range 0-7F)
                ;5849   ;       LS 6 - TB data to write (22 bits, from 1-22).  Bits 0 and 23-31 are
                ;5850   ;              ignored.
                ;5851   ;
                ;5852   ; IMPLICIT INPUTS:
                ;5853   ;
                ;5854   ;       None
                ;5855   ;
                ;5856   ; OUTPUT PARAMATERS:
                ;5857   ;
                ;5858   ;       TB will be written with specified data at specified address
                ;5859   ;
                ;5860   ; IMPLICIT OUTPUTS:
                ;5861   ;
                ;5862   ;       None
                ;5863   ;
                ;5864   ; SIDE EFFECTS:
                ;5865   ;
                ;5866   ;       WR 0 will be modified
                ;5867   ;       WR 1 will be modified
                ;5868   ;
                ;5869   ;---
                ;5870
                ;5871   DEPOSIT.TB:
U 061F, 8862,FC ;5872           JSR [SHIFT.TB.ADR]              ;GO TO SUBROUTINE TO POSITION TB AD-
```

```
                    ;5873                                   ; DRESS CORRECTLY
U 0620, 360C,15     ;5874           MOV LS[T6.SUB] TO WR[0]  ;GET DATA FROM LS 6
U 0621, 4526,15     ;5875           BIC LS[#FF] TO WR[0]     ;CLEAR LOW BYTE OF DATA SPECIFIED.
                    ;5876                                   ; LOW BYTE WILL BE PUT IN BITS 24-31
                    ;5877                                   ; LATER
U 0622, 8862,AC     ;5878           JSR [SHIFT.LOOP]         ;GO TO SUBROUTINE TO SHIFT WR 0 EIGHT
                    ;5879                                   ; PLACES RIGHT
U 0623, E40C,15     ;5880           SWAP LS[T6.SUB] WITH WR[0] ;SWAP ORIGINAL DATA SPECIFIED WITH MOD-
                    ;5881                                   ; IFIED DATA.  NOW LS 6 CONTAINS BITS
                    ;5882                                   ; 8-22 IN BITS 0-14 AS REQUIRED.  WR 0
                    ;5883                                   ; CONTAINS ORIGINAL DATA SPECIFIED
U 0624, 452C,15     ;5884           BIC LS[#FFFFFF00] TO WR[0] ;CLEAR ALL BUT LOW BYTE OF ORIGINAL
                    ;5885                                   ; DATA SPECIFIED
U 0625, 8862,AC     ;5886           JSR [SHIFT.LOOP]         ;GO TO SUBROUTINE TO SHIFT WR 0 EIGHT
                    ;5887                                   ; PLACES RIGHT.  ON RETURN, WR 0 WILL
                    ;5888                                   ; HAVE BITS 0-7 IN BITS 24-31, OTHER
                    ;5889                                   ; BITS ARE CLEAR
U 0626, EDOC,15     ;5890           BIS WR[0] TO LS[T6.SUB]  ;NOW LS 6 CONTAINS DATA TO WRITE IN
                    ;5891                                   ; TB IN CORRECT FORMAT  I.E. PA BITS
                    ;5892                                   ; IN BITS 00-14 AND BYTE OFFSET, MODIFY
                    ;5893                                   ; PROT A THROUGH PROT D, AND VALID IN
                    ;5894                                   ; BITS 25-31.
                    ;5895
U 0627, 980A,F5     ;5896           MEM.REQ[WRITE.TB] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO WRITE
                    ;5897                                   ; THE TB
U 0628, B20C,15     ;5898           WRITE.MEM LS[T6.SUB]     ;WRITE DATA FROM LS 6 IN TB
U 0629, 8868,74     ;5899           JMP [WAIT.SUB]           ;JUMP TO SET ATTN AND WAIT
                    ;5900
                    ;5901   ;
                    ;5902   ;       SUBROUTINE TO SHIFT WR 0 TO THE RIGHT 8 PLACES
                    ;5903   ;
                    ;5904   SHIFT.LOOP:
U 062A, 3646,95     ;5905           MOV LS[#8] TO WR[1]      ;COUNTER IN WR 1 TO SHIFT 8 PLACES
                    ;5906   SHIFT.LOOP.1:
U 062B, 2340,15     ;5907           ROR WR[0]                ;SHIFT WR 0 ONE PLACE RIGHT
                    ;5908           DEC WR[1],               ;DECREMENT COUNTER
U 062C, A102,B5     ;5909            DT(LONG)&SET.ALU.CC     ; AND SET CONDITION CODES
U 062D, 8862,B1     ;5910           JMP.IF[NEQ] TO [SHIFT.LOOP.1] ;REPEAT UNTIL 8 SHIFTS HAVE OCCURRED
U 062E, 5B00,14     ;5911           RETURN                   ;THEN RETURN
                    ;5912   ;
                    ;5913   ;       SUBROUTINE TO POSITION TB ADDRESS IN BITS 9-14 AND BIT 31 (TB ADDRESS
                    ;5914   ;       BIT 0 MUST BE IN BIT 31).
                    ;5915   ;
                    ;5916   SHIFT.TB.ADR:
U 062F, 360A,15     ;5917           MOV LS[T5.SUB] TO WR[0]  ;GET TB ADDRESS FROM LS 5
U 0630, 452C,15     ;5918           BIC LS[#FFFFFF00] TO WR[0] ;CLEAR ALL BUT LOW BYTE (8 BIT ADDRESS)
U 0631, A2D0,15     ;5919           SHL2 WR[0]               ;SHIFT 2 PLACES LEFT TO POSITION ADDRESS
U 0632, A2D0,15     ;5920           SHL2 WR[0]               ;SHIFT 2 PLACES LEFT TO POSITION ADDRESS
U 0633, A2D0,15     ;5921           SHL2 WR[0]               ;SHIFT 2 PLACES LEFT TO POSITION ADDRESS
U 0634, A2D0,15     ;5922           SHL2 WR[0]               ;SHIFT 2 PLACES LEFT TO POSITION ADDRESS
U 0635, 23D0,15     ;5923           ASHL WR[0]               ;SHIFT ONE MORE PLACE
                    ;5924                                   ; NOW BITS 0-6 IN BITS 9-15
                    ;5925           BIT LS[BIT15] WITH WR[0], ;SEE IF BIT 15 (MSB) IS SET OR CLEAR.
U 0636, 595E,35     ;5926            DT(LONG)&SET.ALU.CC     ; MSB MUST GO IN BIT 31 IN ORDER TO AD-
                    ;5927                                   ; DRESS TB CORRECTLY
```

```
U 0637, 5B00,09 ;5928          SKIP.IF[EQL]                    ;SKIP NEXT INSTRUCTION IF MSB IS 0
U 0638, 477E,15 ;5929          BIS LS[BIT31] TO WR[0]          ;ELSE SET BIT 31 FOR MSB
                ;5930
                ;5931          MOV WR[0] TO LS[T5.SUB],        ;NOW TB ADDRESS IS IN CORRECT FORM IN
                ;5932                                          ; LS LOCATION 5
U 0639, 3E0A,14 ;5933           RETURN                         ; THEN RETURN TO MAIN CODE
```

```
                ;5934   .PAGE   "  EXAMINE TRANSLATION BUFFER ROUTINE"
                ;5935   ;+++
                ;5936   ;
                ;5937   ; FUNCTIONAL DESCRIPTION:
                ;5938   ;
                ;5939   ;       This routine will read the translation buffer of the memory controller.
                ;5940   ;       The TB will be returned with the byte offset, modify, prot A through
                ;5941   ;       prot D, and valid in bits 01-07 respectively.  PA bits 09-23 are re-
                ;5942   ;       turned in bits 08-22 respectively.  Bits 23-31 and bit 0 are not used
                ;5943   ;       and so will be cleared before printing the result.  The result will be
                ;5944   ;       put in LS 6 for the console to print.
                ;5945   ;         The routine will issue a memory request with memory function=READ.TB
                ;5946   ;       and data type=LONGWORD.  The console will load LS 5 with the address
                ;5947   ;       specified before executing this routine.  The routine will shift the
                ;5948   ;       address around as required to address the TB location specified.  The
                ;5949   ;       address specified must be in HEX format.
                ;5950   ;         The TB consists of 128 decimal locations (addresses from 0-7F).  The
                ;5951   ;       remaining locations in the TB RAM are either unused or used by the
                ;5952   ;       UNIBUS map.  UNIBUS map addresses are read via the EXAMINE UB routine.
                ;5953   ;
                ;5954   ; CALLING SEQUENCE:
                ;5955   ;
                ;5956   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;5957   ;       struction at WCS location 53) into the UPC and starts the CPU.
                ;5958   ;
                ;5959   ; INPUT PARAMETERS:
                ;5960   ;
                ;5961   ;       LS 5 - TB address (0-7F) in hex format
                ;5962   ;
                ;5963   ; IMPLICIT INPUTS:
                ;5964   ;
                ;5965   ;       None
                ;5966   ;
                ;5967   ; OUTPUT PARAMATERS:
                ;5968   ;
                ;5969   ;       LS 6 - TB data from address specified
                ;5970   ;
                ;5971   ; IMPLICIT OUTPUTS:
                ;5972   ;
                ;5973   ;       None
                ;5974   ;
                ;5975   ; SIDE EFFECTS:
                ;5976   ;
                ;5977   ;       LS 5 is modified
                ;5978   ;       WR 0 is modified
                ;5979   ;
                ;5980   ;---
                ;5981
                ;5982   EXAMINE.TB:
U 063A, 8862,FC ;5983           JSR [SHIFT.TB.ADR]              ;SHIFT ADDRESS SPECIFIED FROM LS 5 INTO
                ;5984                                           ; CORRECT POSITION AND REPLACE IN LS 5
U 063B, 9C0B,F5 ;5985           MEM.REQ[READ.TB] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO READ
                ;5986                                           ; THE TB AT ADDRESS CONTAINED IN LS 5
U 063C, 3022,15 ;5987           MOV MEM.DATA TO WR[0]           ;PLACE RESULT IN WR 0
                ;5988
```

```
U 063D, 452A,15 ;5989          BIC LS[#FF000000] TO WR[0]      ;CLEAR UPPER BYTE OF RESULT (UPPER BYTE
                ;5990                                          ; IS NOT PART OF TB AND IS UNPREDICT-
                ;5991                                          ; ABLE)
U 063E, 456E,15 ;5992          BIC LS[BIT23] TO WR[0]          ;DITTO FOR BIT 23
U 063F, 4540,15 ;5993          BIC LS[BIT0] TO WR[0]           ;DITTO FOR BIT 0.  WR 0 NOW CONTAINS
                ;5994                                          ; RESULT TO PRINT
U 0640, BE0C,15 ;5995          MOV WR[0] TO LS[T6.SUB]         ;RESULT NOW IN LS 6
U 0641, 8868,74 ;5996          JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
```

```
                ;5997   .PAGE   "  DEPOSIT UNIBUS MAP ROUTINE"
                ;5998   ;+++
                ;5999   ;
                ;6000   ; FUNCTIONAL DESCRIPTION:
                ;6001   ;
                ;6002   ;       This routine allows a write to the UNIBUS map portion of the TB on the
                ;6003   ;       memory controller.  The map area contains 512 decimal locations
                ;6004   ;       addressed from 200-3FF.  The remainder of the TB RAM is either unused
                ;6005   ;       or contains the Translation Buffer information.  The DEPOSIT TB command
                ;6006   ;       is used to write the TB portion of the TB RAMs.  The address specified
                ;6007   ;       with the DEPOSIT command will be the actual RAM address accessed.  This
                ;6008   ;       routine will do any shifting necessary on the address specified to pos-
                ;6009   ;       ition it correctly.  The address specified has been loaded by the con-
                ;6010   ;       sole in LS location 5 prior to executing this routine.  The address
                ;6011   ;       must be in HEX format.
                ;6012   ;         The data specified has been placed in LS 6 by the console prior to
                ;6013   ;       executing this routine.  Bits 07-01 will be the Valid, Prot, Modify,
                ;6014   ;       and Byte Offset bits (there are four Prot bits).  Bits 22-08 will
                ;6015   ;       contain the PA bits from PA 23 through PA 09 respectively.  Bits 31
                ;6016   ;       through 23 and bit 0 are unused. This routine will do any shifting nec-
                ;6017   ;       essary to write the bits in TB as described.  The data specified must
                ;6018   ;       be in HEX format.
                ;6019   ;
                ;6020   ; CALLING SEQUENCE:
                ;6021   ;
                ;6022   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6023   ;       struction at WCS location 58) into the UPC and starts the CPU.
                ;6024   ;
                ;6025   ; INPUT PARAMETERS:
                ;6026   ;
                ;6027   ;       LS 5 - UNIBUS Map address in TB (must be in range 200-3FF HEX).
                ;6028   ;       LS 6 - Contains the data to write into the UNIBUS Map in bits 1-22.
                ;6029   ;
                ;6030   ; IMPLICIT INPUTS:
                ;6031   ;
                ;6032   ;       None
                ;6033   ;
                ;6034   ; OUTPUT PARAMATERS:
                ;6035   ;
                ;6036   ;       The UNIBUS map portion of the TB RAMs gets written with the data from
                ;6037   ;       LS 6 at the address specified in LS 5.
                ;6038   ;
                ;6039   ; IMPLICIT OUTPUTS:
                ;6040   ;
                ;6041   ;       None
                ;6042   ;
                ;6043   ; SIDE EFFECTS:
                ;6044   ;
                ;6045   ;       WR 0 will be modified
                ;6046   ;       WR 1 will be modified
                ;6047   ;
                ;6048   ;---
                ;6049
                ;6050   DEPOSIT.UBS:
U 0642, 0864,DC ;6051           JSR [SHIFT.UB.ADR]              ;GO TO SUBROUTINE TO ARRANGE UNIBUS
```

```
                    ;6052                                   ; MAP ADDRESS CORRECTLY
U 0643, 360C,15     ;6053           MOV LS[T6.SUB] TO WR[0]  ;GET DATA FROM LS 6
U 0644, 4526,15     ;6054           BIC LS[#FF] TO WR[0]     ;CLEAR LOW BYTE OF DATA SPECIFIED.
                    ;6055                                   ; LOW BYTE WILL BE PUT IN BITS 24-31
                    ;6056                                   ; LATER
U 0645, 8862,AC     ;6057           JSR [SHIFT.LOOP]         ;GO TO SUBROUTINE TO SHIFT WR 0 EIGHT
                    ;6058                                   ; PLACES RIGHT
U 0646, E40C,15     ;6059           SWAP LS[T6.SUB] WITH WR[0] ;SWAP ORIGINAL DATA SPECIFIED WITH MOD-
                    ;6060                                   ; IFIED DATA.  NOW LS 6 CONTAINS BITS
                    ;6061                                   ; 8-22 IN BITS 0-14 AS REQUIRED.  WR 0
                    ;6062                                   ; CONTAINS ORIGINAL DATA SPECIFIED
U 0647, 452C,15     ;6063           BIC LS[#FFFFFF00] TO WR[0] ;CLEAR ALL BUT LOW BYTE OF ORIGINAL
                    ;6064                                   ; DATA SPECIFIED
U 0648, 8862,AC     ;6065           JSR [SHIFT.LOOP]         ;GO TO SUBROUTINE TO SHIFT WR 0 EIGHT
                    ;6066                                   ; PLACES RIGHT.  ON RETURN, WR 0 WILL
                    ;6067                                   ; HAVE BITS 0-7 IN BITS 24-31, OTHER
                    ;6068                                   ; BITS ARE CLEAR
U 0649, ED0C,15     ;6069           BIS WR[0] TO LS[T6.SUB]  ;NOW LS 6 CONTAINS DATA TO WRITE IN
                    ;6070                                   ; TB IN CORRECT FORMAT  I.E. PA BITS
                    ;6071                                   ; IN BITS 00-14 AND BYTE OFFSET, MODIFY
                    ;6072                                   ; PROT A THROUGH PROT D, AND VALID IN
                    ;6073                                   ; BITS 25-31.
                    ;6074
U 064A, 1B0B,F5     ;6075           MEM.REQ[WRITE.UBS.MAP] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO
                    ;6076                                   ; WRITE THE UNIBUS MAP
U 064B, B20C,15     ;6077           WRITE.MEM LS[T6.SUB]     ;WRITE DATA FROM LS 6 IN UNIBUS MAP
U 064C, 8868,74     ;6078           JMP [WAIT.SUB]           ;JUMP TO SET ATTN AND WAIT
                    ;6079   ;
                    ;6080   ;       SUBROUTINE TO POSITION ADDRESS SPECIFIED CORRECTLY TO ADDRESS THE
                    ;6081   ;       UNIBUS MAP.
                    ;6082   ;
                    ;6083   SHIFT.UB.ADR:
U 064D, 360A,15     ;6084           MOV LS[T5.SUB] TO WR[0]  ;GET ADDRESS SPECIFIED IN WR 0
U 064E, A2D0,15     ;6085           SHL2 WR[0]               ;SHIFT ADDRESS 2 PLACES LEFT
U 064F, A2D0,15     ;6086           SHL2 WR[0]               ;SHIFT ADDRESS 2 PLACES LEFT
U 0650, A2D0,15     ;6087           SHL2 WR[0]               ;SHIFT ADDRESS 2 PLACES LEFT
U 0651, A2D0,15     ;6088           SHL2 WR[0]               ;SHIFT ADDRESS 2 PLACES LEFT
U 0652, 23D0,15     ;6089           ASHL WR[0]               ;SHIFT LEFT ONE MORE PLACE
                    ;6090                                   ; NOW ADDRESS IS IN BITS 9-17 OF WR 0
                    ;6091           MOV WR[0] TO LS[T5.SUB], ;NOW LS 5 CONTAINS CORRECT ADDRESS.
U 0653, 3E0A,14     ;6092            RETURN                  ; RETURN TO MAIN
                    ;6093
                    ;6094
```

```
                ;6095   .PAGE   "  EXAMINE UNIBUS MAP ROUTINE"
                ;6096   ;+++
                ;6097   ;       This routine will read the UNIBUS map portion of the memory controller.
                ;6098   ;       The UNIBUS MAP contencs will be returned with the byte offset, modify,
                ;6099   ;       prot A through prot D, and valid in bits 01-07 respectively.  PA bits
                ;6100   ;       09-23 are returned in bits 08-22 respectively.  Bits 23-31 and bit 0
                ;6101   ;       are not used and so will be cleared before printing the result.  The
                ;6102   ;       result will be put in LS 6 for the console to print.
                ;6103   ;         The routine will issue a memory request with memory function=READ.UBS
                ;6104   ;       .MAP and data type=LONGWORD.  The console will load LS 5 with the ad-
                ;6105   ;       dress specified before executing this routine.  The routine will shift
                ;6106   ;       the address around as required to address the UNIBUS map location spec-
                ;6107   ;       ified.  The address specified must be in HEX format.
                ;6108   ;         The UNIBUS map consists of 512 decimal locations (addresses from 200-
                ;6109   ;       3FF)  The remaining locations in the TB RAM are either unused or used
                ;6110   ;       by the translation buffer.  TB contents are read via the EXAMINE TB
                ;6111   ;       routine.
                ;6112   ;
                ;6113   ; CALLING SEQUENCE:
                ;6114   ;
                ;6115   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6116   ;       struction at WCS location 59) into the UPC and starts the CPU.
                ;6117   ;
                ;6118   ; INPUT PARAMETERS:
                ;6119   ;
                ;6120   ;       LS 5 - TB address in hex format
                ;6121   ;
                ;6122   ; IMPLICIT INPUTS:
                ;6123   ;
                ;6124   ;       None
                ;6125   ;
                ;6126   ; OUTPUT PARAMATERS:
                ;6127   ;
                ;6128   ;       LS 6 - UNIBUS map data from address specified
                ;6129   ;
                ;6130   ; IMPLICIT OUTPUTS:
                ;6131   ;
                ;6132   ;       None
                ;6133   ;
                ;6134   ; SIDE EFFECTS:
                ;6135   ;
                ;6136   ;       LS 5 is modified
                ;6137   ;       WR 0 will be modified
                ;6138   ;
                ;6139   ;---
                ;6140
                ;6141   EXAMINE.UBS:
U 0654, 0864,DC ;6142           JSR [SHIFT.UB.ADR]                  ;SHIFT ADDRESS SPECIFIED FROM LS 5 INTO
                ;6143                                               ; CORRECT POSITION AND REPLACE IN LS 5
U 0655, 1C0B,75 ;6144           MEM.REQ[READ.UBS.MAP] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO
                ;6145                                               ; READ THE UBS MAP AT ADDRESS CONTAINED
                ;6146                                               ; IN LS 5
U 0656, 3022,15 ;6147           MOV MEM.DATA TO WR[0]               ;PLACE RESULT IN WR 0
                ;6148
U 0657, 452A,15 ;6149           BIC LS[#FF000000] TO WR[0]          ;CLEAR UPPER BYTE OF RESULT (UPPER BYTE
```

```
                    ;6150                                   ; IS NOT PART OF TB AND IS UNPREDICT-
                    ;6151                                   ; ABLE)
U 0658, 456E,15     ;6152           BIC LS[BIT23] TO WR[0]  ;DITTO FOR BIT 23
U 0659, 4540,15     ;6153           BIC LS[BIT0] TO WR[0]   ;DITTO FOR BIT 0.  WR 0 NOW CONTAINS
                    ;6154                                   ; RESULT TO PRINT
U 065A, BE0C,15     ;6155           MOV WR[0] TO LS[T6.SUB] ;RESULT NOW IN LS 6
U 065B, 8868,74     ;6156           JMP [WAIT.SUB]         ;JUMP TO SET ATTN AND WAIT
                    ;6157                                   ; CONTROL
```

```
                ;6158   .PAGE   "  DEPOSIT MAIN MEMORY ROUTINE"
                ;6159   ;+++
                ;6160   ;
                ;6161   ; FUNCTIONAL DESCRIPTION:
                ;6162   ;
                ;6163   ;       This routine write a longword of data into main memory at the Physical
                ;6164   ;       address specified.  This address need not be on a longword boundary.
                ;6165   ;       The console will use this routine for data transfers to main memory as
                ;6166   ;       well as for the DEPOSIT MM command.  The console will have loaded the
                ;6167   ;       address into LS 5 and the data into LS 6 before executing this routine.
                ;6168   ;         The routine issues a memory request with the memory function=WRITE.P
                ;6169   ;       and the data type=longword.  It then issues a WRITE.MEM LS[6] instruc-
                ;6170   ;       tion to write the data into memory.  A check on ERROR SUM is made to
                ;6171   ;       assure that the write occured without an error.  If ERROR SUM is as-
                ;6172   ;       serted, the CPU will issue a CPU ACK before asserting CPU ATTN to in-
                ;6173   ;       form the console that an error occurred.
                ;6174   ;
                ;6175   ; CALLING SEQUENCE:
                ;6176   ;
                ;6177   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6178   ;       struction at WCS location 54) into the UPC and starts the CPU.
                ;6179   ;
                ;6180   ; INPUT PARAMETERS:
                ;6181   ;
                ;6182   ;       LS 5 - Main memory physical address
                ;6183   ;       LS 6 - Main memory longword data
                ;6184   ;
                ;6185   ; IMPLICIT INPUTS:
                ;6186   ;
                ;6187   ;       None
                ;6188   ;
                ;6189   ; OUTPUT PARAMATERS:
                ;6190   ;
                ;6191   ;       Main Memory address specified is written with data from LS 6.
                ;6192   ;
                ;6193   ; IMPLICIT OUTPUTS:
                ;6194   ;
                ;6195   ;       A memory error asserts CPU ACK to inform the console of a write error.
                ;6196   ;
                ;6197   ; SIDE EFFECTS:
                ;6198   ;
                ;6199   ;       None
                ;6200   ;
                ;6201   ;---
                ;6202
                ;6203   DEPOSIT.MM:
U 065C, 990A,75 ;6204           MEM.REQ[WRITE.P] ADRS[T5.SUB] DT[LONG]  ;SET UP FOR WRITE TO MAIN
                ;6205                                                   ; MEMORY USING THE PHYSICAL ADDRESS
                ;6206                                                   ; STORED IN LS 5
                ;6207           WRITE.MEM LS[T6.SUB],                   ;WRITE THE DATA FROM LS 6 INTO MAIN
                ;6208                                                   ; MEMORY
U 065D, 320C,1D ;6209            SKIP.IF[MEM.REF.OK]                    ;SKIP NEXT INSTRUCTION IF NO MEMORY
                ;6210                                                   ; ERROR (NO ERR SUM)
U 065E, 10D0,15 ;6211           MISC [SET.CP.ACK]                       ;SET CPU ACK IF ERROR SUM ASSERTED
                ;6212
```

```
U 065F, 3644,15 ;6213          MOV LS[#4] TO WR[0]          ;PUT A 4 IN WR 0
U 0660, 6C0A,15 ;6214          ADD WR[0] TO LS[T5.SUB]      ;INCREMENT LS 5 FOR NEXT LONGWORD DEP
U 0661, 8868,74 ;6215          JMP [WAIT.SUB]               ;JUMP TO SET ATTN AND WAIT
```

```
                ;6216   .PAGE   "  EXAMINE MAIN MEMORY ROUTINE"
                ;6217   ;+++
                ;6218   ;
                ;6219   ; FUNCTIONAL DESCRIPTION:
                ;6220   ;
                ;6221   ;       This routine is used to read a longword form main memory at the Phy-
                ;6222   ;       sical address specified.  The address need not be on a longword bound-
                ;6223   ;       ary.  This routine is used by the console on an EXAMINE.MM command.
                ;6224   ;       The console will have loaded LS 5 with the physical address specified
                ;6225   ;       before executing this routine.
                ;6226   ;         The routine will first write CSR 1 to set the INH REP CRD (inhibit
                ;6227   ;       report correctable read data) bit to prevent an error sum from occuring
                ;6228   ;       on a single bit error which has been corrected.  Then the routine is-
                ;6229   ;       sues a memory request with memory function=READ.P and DT=longword.  It
                ;6230   ;       then reads the memory location and puts the result in LS 6.  It also
                ;6231   ;       checks for an ERROR SUM and issues a CPU ACK if an error occurred (sin-
                ;6232   ;       gle bit errors that have been corrected will not cause an ERR SUM).  If
                ;6233   ;       an error occurred, CPU ACK will be set before issueing CPU ATTN to in-
                ;6234   ;       form the console that an error occurred.
                ;6235   ;
                ;6236   ; CALLING SEQUENCE:
                ;6237   ;
                ;6238   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6239   ;       struction at WCS location 55) into the UPC and starts the CPU.
                ;6240   ;
                ;6241   ; INPUT PARAMETERS:
                ;6242   ;
                ;6243   ;       LS 5 - Physical address in main memory to read.
                ;6244   ;
                ;6245   ; IMPLICIT INPUTS:
                ;6246   ;
                ;6247   ;       LS[INH.CRD] - Data to write into CSR 1 to inhibit error sum on a CRD.
                ;6248   ;       LS[CSR1]  - Address for writing CSR 1.
                ;6249   ;
                ;6250   ; OUTPUT PARAMATERS:
                ;6251   ;
                ;6252   ;       LS 6 - Longword data from physical memory address specified.
                ;6253   ;
                ;6254   ; IMPLICIT OUTPUTS:
                ;6255   ;
                ;6256   ;       CPU ACK if an error sum occurs.
                ;6257   ;
                ;6258   ; SIDE EFFECTS:
                ;6259   ;
                ;6260   ;       None
                ;6261   ;
                ;6262   ;---
                ;6263
                ;6264   EXAMINE.MM:
U 0662, 1D45,F5 ;6265           MEM.REQ[WRITE.CSR] ADRS[CSR1] DT[LONG]  ;ISSUE MEMORY REQUEST TO
                ;6266                                                   ; WRITE CSR 1
U 0663, B278,15 ;6267           WRITE.MEM LS[INH.CRD]                   ;SET INH REP CRD IN CSR 1 AND CLEAR
                ;6268                                                   ; ECC DISABLE
                ;6269
U 0664, 180B,F5 ;6270           MEM.REQ[READ.P] ADRS[T5.SUB] DT[LONG]  ;ISSUE MEMORY REQUEST TO
```

```
                 ;6271                                          ; READ LONGWORD DATA FROM MAIN MEMORY
                 ;6272                                          ; PHYSICAL ADDRESS IN LS 5
                 ;6273          MOV MEM.DATA TO LS[T6.SUB],     ;READ DATA AND PUT IN LS 6
U 0665, 380C,1D  ;6274           SKIP.IF[MEM.REF.OK]           ; SKIP NEXT INSTRUCTION IF NO MEMORY
                 ;6275                                          ; ERROR (NO ERROR SUM)
U 0666, 10D0,15  ;6276          MISC [SET.CP.ACK]              ;SET CPU ACK IF AN ERROR OCCURRED
U 0667, 8868,74  ;6277          JMP [WAIT.SUB]                 ;JUMP TO SET ATTN AND WAIT
```

```
                ;6278   .page   "  EXAMINE IDC ROUTINES"
                ;6279   ;+++
                ;6280   ;
                ;6281   ; FUNCTIONAL DESCRIPTION:
                ;6282   ;
                ;6283   ;       The following routines are used to read data from the optional IDC
                ;6284   ;       module's registers.  The result is put in LS 6 for the console to
                ;6285   ;       print out.
                ;6286   ;
                ;6287   ; CALLING SEQUENCE:
                ;6288   ;
                ;6289   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6290   ;       struction at WCS location 5A through 5E) into the UPC and starts the
                ;6291   ;       CPU.
                ;6292   ;
                ;6293   ; INPUT PARAMETERS:
                ;6294   ;
                ;6295   ;       None
                ;6296   ;
                ;6297   ; IMPLICIT INPUTS:
                ;6298   ;
                ;6299   ;       None
                ;6300   ;
                ;6301   ; OUTPUT PARAMATERS:
                ;6302   ;
                ;6303   ;       LS 6 - Data from IDC register specified.
                ;6304   ;
                ;6305   ; IMPLICIT OUTPUTS:
                ;6306   ;
                ;6307   ;       None
                ;6308   ;
                ;6309   ; SIDE EFFECTS:
                ;6310   ;
                ;6311   ;       None
                ;6312   ;
                ;6313   ;---
                ;6314
                ;6315   EXAMINE.ICSR:
U 0668, 9090,15 ;6316           MISC [SET.PORT.I.O]             ;SELECT PORT TO BUS
U 0669, 9780,15 ;6317           PORT.READ PORT.ADRS[CSR]        ;SEND THE READ COMMAND
U 066A, 0867,64 ;6318           JMP [READ.IDC]                  ;READ THE DATA
                ;6319
                ;6320   EXAMINE.IDAR:
U 066B, 9090,15 ;6321           MISC [SET.PORT.I.O]             ;SELECT PORT TO BUS
U 066C, 1784,15 ;6322           PORT.READ PORT.ADRS[DAR]        ;SEND THE READ COMMAND
U 066D, 0867,64 ;6323           JMP [READ.IDC]                  ;READ THE DATA
                ;6324
                ;6325   EXAMINE.DBUF:
U 066E, 9090,15 ;6326           MISC [SET.PORT.I.O]             ;SELECT PORT TO BUS
U 066F, 978C,15 ;6327           PORT.READ PORT.ADRS[DATA.WORD]  ;SEND THE READ COMMAND
U 0670, 0867,64 ;6328           JMP [READ.IDC]                  ;READ THE DATA
                ;6329
                ;6330   EXAMINE.PATT:
U 0671, 9090,15 ;6331           MISC [SET.PORT.I.O]             ;SELECT PORT TO BUS
U 0672, 1790,15 ;6332           PORT.READ PORT.ADRS[PATTERN]    ;SEND THE READ COMMAND
```

```
U 0673, 0867,64 ;6333           JMP [READ.IDC]                  ;READ THE DATA
                ;6334
                ;6335   EXAMINE.POSIT:
U 0674, 9090,15 ;6336           MISC [SET.PORT.I.0]             ;SELECT PORT TO BUS
U 0675, 9794,15 ;6337           PORT.READ PORT.ADRS[POSITION]   ;SEND THE READ COMMAND
                ;6338
                ;6339
                ;6340   READ.IDC:
U 0676, 3A0C,15 ;6341           MOV PORT TO LS[T6.SUB]          ;READ DATA AND PUT IN LS 6
U 0677, 1080,15 ;6342           MISC [SET.ACC.I.0]              ;RETURN SELECT TO ACCELERATOR
U 0678, 8868,74 ;6343           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
```

```
                    ;6344   .page   "  DEPOSIT IDC ROUTINES"
                    ;6345   ;+++
                    ;6346   ;
                    ;6347   ; FUNCTIONAL DESCRIPTION:
                    ;6348   ;
                    ;6349   ;       The following routines are used to write data to the optional IDC
                    ;6350   ;       module's registers.  The data is taken from LS 6 which is previously
                    ;6351   ;       loaded by the monitor when the DEPOSIT command is executed.
                    ;6352   ;
                    ;6353   ; CALLING SEQUENCE:
                    ;6354   ;
                    ;6355   ;       The console loads the address of a pointer to this routine (a JMP in-
                    ;6356   ;       struction at WCS location 5F through 61) into the UPC and starts the
                    ;6357   ;       CPU.
                    ;6358   ;
                    ;6359   ; INPUT PARAMETERS:
                    ;6360   ;
                    ;6361   ;       LS 6 - Data pattern to write.
                    ;6362   ;
                    ;6363   ; IMPLICIT INPUTS:
                    ;6364   ;
                    ;6365   ;       None
                    ;6366   ;
                    ;6367   ; OUTPUT PARAMATERS:
                    ;6368   ;
                    ;6369   ;       None
                    ;6370   ;
                    ;6371   ; IMPLICIT OUTPUTS:
                    ;6372   ;
                    ;6373   ;       None
                    ;6374   ;
                    ;6375   ; SIDE EFFECTS:
                    ;6376   ;
                    ;6377   ;       None
                    ;6378   ;
                    ;6379   ;---
                    ;6380
                    ;6381   DEPOSIT.ICSR:
U 0679, 360C,15     ;6382           MOV LS[T6.SUB] TO WR[0]          ;GET DATA PATTERN TO WRITE
U 067A, 17A0,15     ;6383           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE TO IDC
U 067B, 8868,74     ;6384           JMP [WAIT.SUB]                   ;JUMP TO SET ATTN AND WAIT
                    ;6385
                    ;6386
                    ;6387   DEPOSIT.IDAR:
U 067C, 360C,15     ;6388           MOV LS[T6.SUB] TO WR[0]          ;GET DATA PATTERN TO WRITE
U 067D, 97A4,15     ;6389           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE TO IDC
U 067E, 8868,74     ;6390           JMP [WAIT.SUB]                   ;JUMP TO SET ATTN AND WAIT
                    ;6391
                    ;6392
                    ;6393   DEPOSIT.DBUF:
U 067F, 360C,15     ;6394           MOV LS[T6.SUB] TO WR[0]          ;GET DATA PATTERN TO WRITE
U 0680, 17AC,15     ;6395           PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]      ;WRITE TO IDC
U 0681, 8868,74     ;6396           JMP [WAIT.SUB]                   ;JUMP TO SET ATTN AND WAIT
                    ;6397
                    ;6398
```

```
                    ;6399   CLEAR.FIFO.ADDR:
U 0682, 17C0,15     ;6400           PORT.CONTROL [CLEAR.FIFO.CNTR]  ;CLEAR ADDRESS IN FIFO A OR FIFO B
U 0683, 8868,74     ;6401           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
                    ;6402
                    ;6403
                    ;6404   SELECT.FIFO.A:
U 0684, 17D8,15     ;6405           PORT.CONTROL [SEL.FIFO.A]       ;SELECT FIFO A
U 0685, 8868,74     ;6406           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
                    ;6407
                    ;6408
                    ;6409   SELECT.FIFO.B:
U 0686, 97DC,15     ;6410           PORT.CONTROL [SEL.FIFO.B]       ;SELECT FIFO B
                    ;6411
                    ;6412   WAIT.SUB:
U 0687, 10E0,15     ;6413           MISC [SET.CP.ATTN]              ;ISSUE CPU ATTN TO CONSOLE
                    ;6414   WAIT.DE.EX:
U 0688, 8868,84     ;6415           JMP [WAIT.DE.EX]                ;LOOP SELF UNTIL CONSOLE TAKES CONTROL
```

```
                ;6416   .PAGE   "  SAVE WR ROUTINE"
                ;6417   ;+++
                ;6418   ;
                ;6419   ; FUNCTIONAL DESCRIPTION:
                ;6420   ;
                ;6421   ;       This routine saves WRs 0-3 in LS locations 1-4.  When the console takes
                ;6422   ;       control of the CPU, it calls this routine so that the working registers
                ;6423   ;       can be used by the console.  The WRs are restored by another routine
                ;6424   ;       called by the console before the CPU resumes execution (on a COntinue
                ;6425   ;       command, for example).
                ;6426   ;         This routine simply moves data from WR 0-3 to LS locations 1-4 and
                ;6427   ;       then issues a CPU ATTN to the console.  It then loops on a JMP self
                ;6428   ;       until the console takes over.
                ;6429   ;
                ;6430   ; CALLING SEQUENCE:
                ;6431   ;
                ;6432   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6433   ;       struction at WCS location 46) into the UPC and starts the CPU.
                ;6434   ;
                ;6435   ; INPUT PARAMETERS:
                ;6436   ;
                ;6437   ;       None
                ;6438   ;
                ;6439   ; IMPLICIT INPUTS:
                ;6440   ;
                ;6441   ;       None
                ;6442   ;
                ;6443   ; OUTPUT PARAMATERS:
                ;6444   ;
                ;6445   ;       LS 1 - Contents of WR 0
                ;6446   ;       LS 2 - Contents of WR 1
                ;6447   ;       LS 3 - Contents of WR 2
                ;6448   ;       LS 4 - Contents of WR 3
                ;6449   ;
                ;6450   ; IMPLICIT OUTPUTS:
                ;6451   ;
                ;6452   ;       None
                ;6453   ;
                ;6454   ; SIDE EFFECTS:
                ;6455   ;
                ;6456   ;       None
                ;6457   ;
                ;6458   ;---
                ;6459
                ;6460   SAVE.WR:
                ;6461
U 0689, 3E02,15 ;6462           MOV WR[0] TO LS[SAV.WR0]        ;SAVE WR 0 IN LS LOCATION 1
U 068A, BE04,95 ;6463           MOV WR[1] TO LS[SAV.WR1]        ;SAVE WR 1 IN LS LOCATION 2
U 068B, 3E07,15 ;6464           MOV WR[2] TO LS[SAV.WR2]        ;SAVE WR 2 IN LS LOCATION 3
U 068C, 3EC9,95 ;6465           MOV WR[3] TO LS[SAV.WR3]        ;SAVE WR 3 IN LS LOCATION 4
U 068D, 8868,74 ;6466           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
```

```
                ;6467   .PAGE   "  RESTORE WR ROUTINE"
                ;6468   ;+++
                ;6469   ;
                ;6470   ; FUNCTIONAL DESCRIPTION:
                ;6471   ;
                ;6472   ;       This routine restores the 2901 working registers save in LS 1-4.  The
                ;6473   ;       console calls this routine before the CPU is restarted after it has
                ;6474   ;       been halted by the console.
                ;6475   ;         The routine simply moves the data from LS locations 1-4 to WRs 0-3
                ;6476   ;       and then issues a CPU ATTN to the console.  A JMP self is executed next
                ;6477   ;       waiting for the console to take control.
                ;6478   ;
                ;6479   ; CALLING SEQUENCE:
                ;6480   ;
                ;6481   ;       The console loads the address of a pointer to this routine (a JMP in-
                ;6482   ;       struction at WCS location 47) into the UPC and starts the CPU.
                ;6483   ;
                ;6484   ; INPUT PARAMETERS:
                ;6485   ;
                ;6486   ;       LS 1 contains the data to be restored in WR 0.
                ;6487   ;       LS 2 contains the data to be restored in WR 1.
                ;6488   ;       LS 3 contains the data to be restored in WR 2.
                ;6489   ;       LS 4 contains the data to be restored in WR 3.
                ;6490   ;
                ;6491   ; IMPLICIT INPUTS:
                ;6492   ;
                ;6493   ;       None
                ;6494   ;
                ;6495   ; OUTPUT PARAMATERS:
                ;6496   ;
                ;6497   ;       WR 0 gets data from LS 1.
                ;6498   ;       WR 1 gets data from LS 2.
                ;6499   ;       WR 2 gets data from LS 3.
                ;6500   ;       WR 3 gets data from LS 4.
                ;6501   ;
                ;6502   ; IMPLICIT OUTPUTS:
                ;6503   ;
                ;6504   ;       None
                ;6505   ;
                ;6506   ; SIDE EFFECTS:
                ;6507   ;
                ;6508   ;       None
                ;6509   ;
                ;6510   ;---
                ;6511
                ;6512   RESTORE.WR:
U 068E, B602,15 ;6513           MOV LS[SAV.WR0] TO WR[0]        ;RESTORE WR 0
U 068F, 3604,95 ;6514           MOV LS[SAV.WR1] TO WR[1]        ;RESTORE WR 1
U 0690, B607,15 ;6515           MOV LS[SAV.WR2] TO WR[2]        ;RESTORE WR 2
U 0691, B609,95 ;6516           MOV LS[SAV.WR3] TO WR[3]        ;RESTORE WR 3
U 0692, 8868,74 ;6517           JMP [WAIT.SUB]                  ;JUMP TO SET ATTN AND WAIT
```

```
;6518    .PAGE   "WCS SUBROUTINES FOR CPU USE"
;6519    .TOC    "  ERROR ROUTINE"
;6520    ;+++
;6521    ;
;6522    ; FUNCTIONAL DESCRIPTION:
;6523    ;
;6524    ;       This routine is used to detect and report diagnostic errors occurring
;6525    ;       during WCS based micro-diagnostics.  The WCS micro-code sets up the
;6526    ;       parameters listed below and calls this routine.  The routine compares
;6527    ;       WR 1 (expected data) and WR 0 (received data) according to the error
;6528    ;       mask.  Bits set in the mask indicate bits that are not checked for
;6529    ;       errors.
;6530    ;        If WR 0 and WR 1 are equal (no error) the routine executes a return+1
;6531    ;       to the calling point.  The only exception to this is if loop on error
;6532    ;       is set.  In that case, the error number is checked to see if that error
;6533    ;       occurred previously.  If so, then the error loop is forced by doing a
;6534    ;       return.  This will lock an error loop in on intermittent errors.
;6535    ;        If WR 0 and WR 1 are not equal (an error) then bit 8 is set in the
;6536    ;       CONTROL AND STATUS word, expected and received data is set up in LS for
;6537    ;       printout, and flags are checked in the ERROR CONTROL word.  This con-
;6538    ;       trols whether printouts are disabled, loop on error is enabled, etc.
;6539    ;       After printing the error, a return+1 is made to the calling point.
;6540    ;        Loop on error causes a return rather than return+1 to cause an error
;6541    ;       loop.  Also CPU ACKNOWLEDGE is toggled at the end of the routine for
;6542    ;       a scope sync point.
;6543    ;
;6544    ; CALLING SEQUENCE:
;6545    ;
;6546    ;       JSR [CHECK.RESULT]
;6547    ;
;6548    ; INPUT PARAMETERS:
;6549    ;
;6550    ;       WR[0] = Received data i.e. the actual result of the test
;6551    ;       WR[1] = Expected data i.e. what the result should have been
;6552    ;
;6553    ; IMPLICIT INPUTS:
;6554    ;
;6555    ;       LS[ERROR.MASK] = Used to mask out bits that are not to be tested
;6556    ;       LS[ERROR.NUMBER] = Current error number
;6557    ;       LS[PREVIOUS.ERROR] = Error number of previous data
;6558    ;       LS[CONTROL.STATUS] = Control and Status word.  Contains information
;6559    ;           written by the CPU to inform the monitor what to do.
;6560    ;       LS[ERROR.CONTROL] = Information such as loop-on-error, bell-on-error,
;6561    ;           no error report, and halt on error.
;6562    ;
;6563    ; OUTPUT PARAMATERS:
;6564    ;
;6565    ;       NONE
;6566    ;
;6567    ; IMPLICIT OUTPUTS:
;6568    ;
;6569    ;       LS[CONTROL.STATUS] = Control and Status with new status information
;6570    ;       LS[PREVIOUS.ERROR] = Last error number (modified only if error and
;6571    ;           loop on error is enabled)
;6572    ;       LS[EXPECTED.DATA] = Expected result if an error was detected
```

```
                ;6573   ;       LS[RECEIVED.DATA] = Actual result if an error was detected
                ;6574   ;
                ;6575   ; SIDE EFFECTS:
                ;6576   ;
                ;6577   ;       WR[0], WR[1], and the Q reg are modified and are not restored before
                ;6578   ;           returning.
                ;6579   ;       If loop-on-error is enabled and an error loop is to be executed, CPU
                ;6580   ;           ACKNOWLEDGE will be toggled for a scope sync.
                ;6581   ;
                ;6582   ;---
                ;6583
                ;6584   CHECK.RESULT:
U 0693, 458A,15 ;6585           BIC LS[ERROR.MASK] TO WR[0]     ;MASK OFF NOT TESTED BITS (CLEAR THEM)
                ;6586                                           ; FOR RECEIVED DATA
U 0694, C58A,95 ;6587           BIC LS[ERROR.MASK] TO WR[1]     ;DITTO FOR EXPECTED DATA
                ;6588
                ;6589           XOR WR[0] WITH WR[1] TO Q,      ;CMP RECEIVED DATA IN WR[0] WITH
U 0695, AB80,B5 ;6590            DT(LONG)&SET.ALU.CC            ; EXPECTED DATA IN WR[1] FOR ERROR
U 0696, 8869,F1 ;6591           JMP.IF[NEQ] TO [ERROR]          ;JUMP IF ERROR
                ;6592
U 0697, 3690,15 ;6593           MOV LS[ERROR.CONTROL] TO WR[0]  ;GET ERROR CONTROL WORD FROM LS
                ;6594           BIT WR[0] WITH LS[LOE],         ;SEE IF LOOP ON ERROR IS ENABLED
U 0698, 5940,35 ;6595            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 0699, DB00,01 ;6596           SKIP.IF[BIT.SET]                ;SKIP IF IT IS
U 069A, DB00,16 ;6597           RETURN+1                        ;ELSE RETURN+1 (NO ERROR AND NO LOOP)
                ;6598
U 069B, 36A0,15 ;6599           MOV LS[PREVIOUS.ERROR] TO WR[0] ;IF NO ERROR BUT LOOP ON ERROR IS
                ;6600                                           ; ENABLED, SEE IF THERE WAS A
                ;6601                                           ; PREVIOUS ERROR
                ;6602           XOR WR[0] WITH LS[ERROR.NUMBER] TO Q,
U 069C, CD82,35 ;6603            DT(LONG)&SET.ALU.CC            ;IS THIS THE SAME SPOT THAT HAD AN
                ;6604                                           ; ERROR BEFORE? (INTERMITTANT ERROR)
U 069D, 086B,91 ;6605           JMP.IF[NEQ] TO [RET+1]          ;JUMP IF NOT TO RETURN WITHOUT ERROR
                ;6606                                           ; LOOPING (RETURN+1)
U 069E, 086B,C4 ;6607           JMP [RET]                       ;ELSE CONTINUE TO LOOP (WE WILL LOOP
                ;6608                                           ; ON ERROR EVEN IF IT GOES AWAY)
                ;6609
                ;6610   ERROR:
U 069F, 3E86,15 ;6611           MOV WR[0] TO LS[RECEIVED.DATA]  ;PUT RESULT OF TEST IN LS FOR PRINTOUT
U 06A0, 3690,15 ;6612           MOV LS[ERROR.CONTROL] TO WR[0]  ;GET ERROR CONROL BITS TO CHECK FOR
                ;6613                                           ; LOOP COMMAND
                ;6614           BIT WR[0] WITH LS[LOOP.COMMAND],;SEE IF BIT 6 SET
U 06A1, 594C,35 ;6615            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 06A2, 086B,C1 ;6616           JMP.IF[BIT.SET] TO [RET]        ;GO LOOP IF SET (FAST LOOP)
                ;6617
U 06A3, 3E84,95 ;6618           MOV WR[1] TO LS[EXPECTED.DATA]  ;PUT EXPECTED DATA IN LS FOR PRINTOUT
                ;6619
U 06A4, 3680,95 ;6620           MOV LS[CONTROL.STATUS] TO WR[1] ;GET CONTROL AND STATUS WORD FROM LS
U 06A5, C532,95 ;6621           BIC LS[#FE7FFFFF] TO WR[1]      ;CLEAR ALL BUT BITS 23&24 IN CONTROL
                ;6622                                           ; AND STATUS WORD
U 06A6, C750,95 ;6623           BIS LS[ERROR] TO WR[1]          ;SET BIT 8 IN CONTROL AND STATUS WORD
                ;6624                                           ; (INDICATES AN ERROR WAS DETECTED)
U 06A7, BE80,95 ;6625           MOV WR[1] TO LS[CONTROL.STATUS] ;WRITE UPDATED CONTROL AND STATUS WORD
                ;6626                                           ; BACK TO LS[40]
                ;6627
```

```
                ;6628           BIT WR[0] WITH LS[BELL],        ;SEE IF BELL ON ERROR IS SET (WR 0 STILL
                ;6629                                           ; CONTAINS ERROR CONTROL WORD)
U 06A8, D944,35 ;6630            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 06A9, 886A,D9 ;6631           JMP.IF[BITS.CLR] TO [CHECK.NER] ;IF BELL ON ERROR IS NOT SET, JUMP TO
                ;6632                                           ; SEE IF ERROR REPORTING IS INHIBITED
U 06AA, 10E0,15 ;6633           MISC [SET.CP.ATTN]              ;ELSE SET CPU ATTN (RING MY BELL)
                ;6634
U 06AB, 086A,B4 ;6635   WAIT.1: JMP [WAIT.1]                    ;WAIT FOR CONSOLE TO STOP ME
U 06AC, 086B,64 ;6636           JMP [LOOP]                      ;GO TO CHECK LOOP-ON-ERROR AFTER
                ;6637                                           ; CONSOLE HAS FINISHED
                ;6638
                ;6639   CHECK.NER:
                ;6640           BIT WR[0] WITH LS[NER],         ;IF NO BELL SEE IF ERROR REPORT IS
                ;6641                                           ; INHIBITED
U 06AD, D942,35 ;6642            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 06AE, 886B,21 ;6643           JMP.IF[BIT.SET] TO [CHECK.HALT] ;JUMP IF ERROR REPORT IS INHIBITED TO
                ;6644                                           ; CHECK FOR HALT ON ERROR
                ;6645
U 06AF, 10E0,15 ;6646           MISC [SET.CP.ATTN]              ;SET CPU ATTN (REPORT ERROR)
U 06B0, 086B,04 ;6647   WAIT.2: JMP [WAIT.2]                    ;WAIT FOR CONSOLE TO STOP ME
U 06B1, 086B,64 ;6648           JMP [LOOP]                      ;GO TO CHECK LOOP-ON-ERROR AFTER
                ;6649                                           ; CONSOLE HAS FINISHED
                ;6650
                ;6651   CHECK.HALT:
                ;6652           BIT WR[0] WITH LS[HOE],         ;SEE IF HALT ON ERROR IS ENABLED
U 06B2, 5946,35 ;6653            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 06B3, 886B,69 ;6654           JMP.IF[BITS.CLR] TO [LOOP]      ;JUMP IF NOT TO CHECK LOOP-ON-ERROR
                ;6655
U 06B4, 10E0,15 ;6656           MISC [SET.CP.ATTN]              ;ELSE SET CPU ATTN (HALT ON ERROR)
U 06B5, 086B,54 ;6657   WAIT.3: JMP [WAIT.3]                    ;WAIT FOR CONSOLE TO STOP ME
                ;6658
U 06B6, 3690,15 ;6659   LOOP:   MOV LS[ERROR.CONTROL] TO WR[0]   ;GET ERROR CONTROL BITS (NER, HOE ETC.)
                ;6660           BIT WR[0] WITH LS[LOE],         ;SEE IF LOOP-ON-ERROR
U 06B7, 5940,35 ;6661            DT(LONG)&SET.ALU.CC            ; SET CONDITION CODES
U 06B8, DB00,01 ;6662           SKIP.IF[BIT.SET]                ; SKIP IF LOOP ON ERROR IS ENABLED
                ;6663
U 06B9, DB00,16 ;6664   RET+1:  RETURN+1                        ;ELSE RETURN+1 FOR NO ERROR LOOP
                ;6665
U 06BA, 3682,15 ;6666           MOV LS[ERROR.NUMBER] TO WR[0]   ;GET ERROR NUMBER IF LOOPING
                ;6667
U 06BB, BEA0,15 ;6668           MOV WR[0] TO LS[PREVIOUS.ERROR] ;AND SAVE IT IN PREVIOUS ERROR
                ;6669
U 06BC, 10D0,15 ;6670   RET:    MISC [SET.CP.ACK]               ;SET CPU ACKNOWLEDGE FOR SCOPE SYNC
                ;6671           MISC [CLR.CP.ATTN.AND.ACK],     ;AND THEN CLEAR IT
U 06BD, 10C0,14 ;6672            RETURN                         ; RETURN TO TEST AND LOOP ON ERROR
                ;6673
```

```
                ;6674   .PAGE
                ;6675   ;
                ;6676   ;
                ;6677   ;
                ;6678   ERR.NO.TEST:
U 06BE, DB00,15 ;6679           NOP                                 ;NOP WILL CAUSE A SEQUENCE ERROR
U 06BF, B65E,15 ;6680           MOV LS[BEGIN.TEST] TO WR[0]         ;SET BIT 15 IN WR[0] FOR CONTROL AND
                ;6681                                               ; STATUS WORD
U 06C0, 3E80,15 ;6682           MOV WR[0] TO LS[CONTROL.STATUS]     ;SET BIT 15 IN CONTROL AND STATUS WORD
                ;6683                                               ; BIT 15 INDICATES START OF TEST TO
                ;6684                                               ; CONSOLE
U 06C1, 8868,74 ;6685           JMP [WAIT.SUB]                      ;JUMP TO SET ATTN AND WAIT
                ;6686   .TOC    "START TRANSFER ROUTINE"
                ;6687   ;+++
                ;6688   ;       This routine loads the LS with information neccesary for these tests
                ;6689   ;       to run.  It will then issue a CPU ATTN with the control and status word
                ;6690   ;       clear to indicate that all transfers are complete.
                ;6691   ;
                ;6692   ;       RESULT: LS LOADED WITH CONSTANTS. MONITOR INFORMED TRANSFERS OVER.
                ;6693   ;---
                ;6694
                ;6695   TRANSFER.POINT:
                ;6696
                ;6697
U 06C2, 2F80,15 ;6698           CLR WR[0]                           ;START WITH 0 IN WR[0]
U 06C3, BFFE,15 ;6699           MOV WR[0] TO LS[PSL.HW]              ;MAKE SURE COMPAT MODE IS CLEAR
                ;6700
U 06C4, 2040,15 ;6701           INC WR[0]                           ;NOW HAVE 1 IN WR[0]
U 06C5, 23D0,15 ;6702           ASHL WR[0]                          ;10(B)
U 06C6, 2040,15 ;6703           INC WR[0]                           ;11(B)
U 06C7, 23D0,15 ;6704           ASHL WR[0]                          ;110(B)
U 06C8, 2040,15 ;6705           INC WR[0]                           ;111(B)
U 06C9, 23D0,15 ;6706           ASHL WR[0]                          ;1110(B)
U 06CA, 23D0,15 ;6707           ASHL WR[0]                          ;1 1100(B)
U 06CB, 23D0,15 ;6708           ASHL WR[0]                          ;11 1000(B)
U 06CC, 23D0,15 ;6709           ASHL WR[0]                          ;111 0000(B)  NOW HAVE 70(H) IN WR 0.
                ;6710                                               ; THIS IS CORRECT START ADDRESS OF DATA
                ;6711                                               ; SECTION (INCLUDING LONGWORD COUNT,
                ;6712                                               ; DESTINATION, AND DESTINATION ADDRESS)
U 06CD, 3E0E,15 ;6713           MOV WR[0] TO LS[TRANSFER.POINTER]   ;LOAD LS 7 WITH POINTER TO TRANSFER
                ;6714                                               ; DATA SECTION.
                ;6715
U 06CE, 2F80,15 ;6716           CLR WR[0]                           ;0 IN WR 0
U 06CF, 2040,15 ;6717           INC WR[0]                           ;1 IN WR 0
U 06D0, 23D0,15 ;6718           ASHL WR[0]                          ;10(B)
U 06D1, 23D0,15 ;6719           ASHL WR[0]                          ;100(B)
U 06D2, 23D0,15 ;6720           ASHL WR[0]                          ;1000(B)
U 06D3, 23D0,15 ;6721           ASHL WR[0]                          ;1 0000(B)
U 06D4, 23D0,15 ;6722           ASHL WR[0]                          ;10 0000(B)
U 06D5, 23D0,15 ;6723           ASHL WR[0]                          ;100 0000(B)
U 06D6, 23D0,15 ;6724           ASHL WR[0]                          ;1000 0000(B)
U 06D7, 23DC,15 ;6725           ASHL WR[0]                          ;1 0000 0000(B)
U 06D8, 23D0,15 ;6726           ASHL WR[0]                          ;10 0000 0000(B)
U 06D9, 23D0,15 ;6727           ASHL WR[0]                          ;100 0000 0000(B)
U 06DA, 23D0,15 ;6728           ASHL WR[0]                          ;1000 0000 0000(B)
```

```
U 06DB, 23D0,15 ;6729          ASHL WR[0]                          ;1 0000 0000 0000(B)
U 06DC, 23D0,15 ;6730          ASHL WR[0]                          ;10 0000 0000 0000(B)
U 06DD, 3E80,15 ;6731          MOV WR[0] TO LS[CONTROL.STATUS]      ;SET BIT 13 IN LS CONTROL AND STATUS
                ;6732                                              ; WORD (BIT 13 INDICATES CONSOLE MUST
                ;6733                                              ; PERFORM A DATA TRANSFER)
U 06DE, 10E0,15 ;6734          MISC [SET.CP.ATTN]                  ;ISSUE CPU ATTN TO CONSOLE (DO FIRST LS
                ;6735                                              ; TRANSFER TO LOCATIONS 0 THROUGH 77(H))
                ;6736    WAIT.XFER1:
U 06DF, 086D,F4 ;6737          JMP [WAIT.XFER1]                    ;LOOP HERE WAITING FOR CONSOLE TO RE-
                ;6738                                              ; SPOND
                ;6739
U 06E0, 36CA,15 ;6740          MOV LS[#162(H)] TO WR[0]            ;GET START ADDRESS OF SECOND HALF OF LS
                ;6741                                              ; TRANSFER
U 06E1, 3E0E,15 ;6742          MOV WR[0] TO LS[TRANSFER.POINTER]   ;LOAD START ADDRESS IN LS FOR CONSOLE
U 06E2, 365A,15 ;6743          MOV LS[XFER.DATA] TO WR[0]          ;BIT 13 INDICATES TO DO DATA TRANSFER
U 06E3, 3E80,15 ;6744          MOV WR[0] TO LS[CONTROL.STATUS]     ;SET UP CONTROL AND STATUS WORD
U 06E4, 10E0,15 ;6745          MISC [SET.CP.ATTN]                  ;ISSUE CPU ATTN TO CONSOLE (DO SECOND LS
                ;6746                                              ; TRANSFER TO LOCATIONS 80 THROUGH F7(H))
                ;6747    WAIT.XFER2:
U 06E5, 086E,54 ;6748          JMP [WAIT.XFER2]                    ;LOOP HERE WAITING FOR CONSOLE TO RE-
                ;6749                                              ; SPOND
                ;6750
U 06E6, 9B9D,75 ;6751          MEM.REQ[READ.V.RCHK.IFILL] ADRS[ZERO] DT[LONG]
                ;6752                                              ;THIS INSTRUCTION USED TO FREE MEMORY
                ;6753                                              ; IF HUNG WAITING FOR A DATA RCVD.
U 06E7, 3022,15 ;6754          MOV MEM.DATA TO WR[0]               ;THIS INSTRUCTION USED TO FREE MEMORY
                ;6755                                              ; IF HUNG IN A OCTA FLOW
U 06E8, 3022,15 ;6756          MOV MEM.DATA TO WR[0]               ;NEEDS 4 OF THESE
U 06E9, 3022,15 ;6757          MOV MEM.DATA TO WR[0]
U 06EA, 3022,15 ;6758          MOV MEM.DATA TO WR[0]               ;DONE WITH MEMORY INITIALIZATION
                ;6759
U 06EB, 17CC,15 ;6760          PORT.CONTROL [CLEAR.IDC]            ;INITIALIZE IDC TO IDLE LOOP
U 06EC, 17CC,15 ;6761          PORT.CONTROL [CLEAR.IDC]
U 06ED, 17CC,15 ;6762          PORT.CONTROL [CLEAR.IDC]
                ;6763
U 06EE, 17D4,15 ;6764          PORT.CONTROL [CLEAR.AUTO]           ;CLEAR AUTOMODE
                ;6765
U 06EF, 3678,15 ;6766          MOV LS[BIT28] TO WR[0]
U 06F0, B64E,95 ;6767          MOV LS[BIT7] TO WR[1]
U 06F1, AEC2,15 ;6768          BIS WR[1] TO WR[0]
U 06F2, 17A0,15 ;6769          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;SET WRITE INHIBIT IN IDC CSR
                ;6770                                                ; AND SET CRDY
                ;6771
U 06F3, 3660,15 ;6772          MOV LS[INTERUPT.EN] TO WR[0]        ;SET BIT 16 IN WR
U 06F4, 3E80,15 ;6773          MOV WR[0] TO LS[CONTROL.STATUS]     ;SET BIT 16 TO CLEAR ANY INTERRUPTS
                ;6774                                              ; AND INFORM CONSOLE THAT XFERS ARE
                ;6775                                              ; DONE
U 06F5, 10E0,15 ;6776          MISC [SET.CP.ATTN]                  ;CALL CONSOLE
                ;6777    WAIT.XFER:
U 06F6, 886F,64 ;6778          JMP [WAIT.XFER]                     ;WAIT FOR CONSOLE TO RESPOND
U 06F7, 5B00,14 ;6779          RETURN                              ;USED WHEN TRANSFER IS CALLED FROM
                ;6780                                              ; MICRO-DIAGNOSTIC ONLY
                ;6781
```

```
                ;6782   .PAGE
                ;6783   .REGION/700,3FFF
                ;6784
```

```
                ;6785   .PAGE   "SUBROUTINES FOR IDC MICRODIAGNOSTIC"
                ;6786   .TOC    " DISK DRIVE SIZING ROUTINE "
                ;6787   ;+++
                ;6788   ;
                ;6789   ; FUNCTIONAL DESCRIPTION:
                ;6790   ;
                ;6791   ;       This subroutine will check each drive <3:0> and determine by looking
                ;6792   ;       at bit <26> of the CSR whether the drive attached is an RL02 or an R80.
                ;6793   ;       If no disk drive is attached, then CSR bit <26>, RL02 is asserted.
                ;6794   ;       When an R80 is found, no further sizing is done because it is assumed
                ;6795   ;       that the other drives are RL02s. When the sizing has been completed,
                ;6796   ;       a message will be printed indicating what was found by this subroutine.
                ;6797   ;       If this information is incorrect, then THE  DISK SIZING TEST should
                ;6798   ;       be run to find the error.
                ;6799   ;
                ;6800   ; CALLING SEQUENCE:
                ;6801   ;
                ;6802   ;       JSR [DRIVE.SIZE]
                ;6803   ;
                ;6804   ; INPUT PARAMETERS:
                ;6805   ;
                ;6806   ;       NONE
                ;6807   ;
                ;6808   ; IMPLICIT INPUTS:
                ;6809   ;
                ;6810   ;       NONE
                ;6811   ;
                ;6812   ; OUTPUT PARAMATERS:
                ;6813   ;
                ;6814   ;       NONE
                ;6815   ;
                ;6816   ; IMPLICIT OUTPUTS:
                ;6817   ;
                ;6818   ;       The drive information will be stored in LS[DRIVE.STATUS] BITS <3:0>.
                ;6819   ;       A one in any bit position indicates that an R80 was found on that
                ;6820   ;       drive number. Example: LS[DRIVE.STATUS] = 00000001 indicates that an
                ;6821   ;       R80 was found on DRIVE 0.
                ;6822   ;
                ;6823   ; SIDE EFFECTS:
                ;6824   ;
                ;6825   ;       WR[0] and WR[1] will be modified
                ;6826   ;       LS[T6.SUB] and LS[T7.SUB] will be modified
                ;6827   ;       LS[CONTROL.STATUS will be modified
                ;6828   ;---
                ;6829   ;*****************************************************************************
                ;6830   DRIVE.SIZE:
                ;6831
U 0700, 650C,15 ;6832           CLR LS[T6.SUB]                          ;DRV NUM FOR PRINTOUT
U 0701, E50E,15 ;6833           CLR LS[T7.SUB]                          ;USED IF R80 FOUND FOR PRINTOUT
                ;6834
                ;6835   TEST.DRIVE:
U 0702, 360C,15 ;6836           MOV LS[T6.SUB] TO WR[0]                 ;GET THE DRIVE NUMBER
U 0703, 3646,95 ;6837           MOV LS[#8] TO WR[1]                     ;SHIFT THE DRIVE NUMBER INTO
                ;6838   SHIFT:
U 0704, 23D0,15 ;6839           ASHL WR[0]                              ; BITS <9:8> FOR THE WRITE TO
```

```
                    ;6840           DEC WR[1],                                  ; THE CSR
U 0705, A102,B5     ;6841             DT(LONG)&SET.ALU.CC
U 0706, 8870,41     ;6842           JMP.IF[NEQ] TO [SHIFT]
                    ;6843                                                       ;DRIVE NUM IS NOW IN BITS<9:8>
                    ;6844
U 0707, 4778,15     ;6845           BIS LS[BIT28] TO WR[0]                      ;SET THE TIMEOUT INHIBIT BIT
U 0708, 17A0,15     ;6846           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                    ;6847
U 0709, 9090,15     ;6848           MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 070A, 9780,15     ;6849           PORT.READ PORT.ADRS[CSR]                    ;SET UP TO READ THE CSR
U 070B, 3B32,15     ;6850           MOV PORT TO LS[PORT0]                       ;READ THE CSR,SAVE IN LS
U 070C, 3732,15     ;6851           MOV LS[PORT0] TO WR[0]
                    ;6852
                    ;6853           BIT LS[BIT26] WITH WR[0],                   ;WAS THE DRIVE AN R80?
U 070D, D974,35     ;6854             DT(LONG)&SET.ALU.CC
U 070E, 8871,A1     ;6855           JMP.IF[BIT.SET] TO [R80.FOUND]              ;JUMP IF  DRIVE IS AN R80
                    ;6856
U 070F, B788,15     ;6857           MOV LS[#3] TO WR[0]                         ;LAST DRIVE BEEN TESTED?
                    ;6858           CMP WR[0] WITH LS[T6.SUB],
U 0710, 4F0C,35     ;6859             DT(LONG)&SET.ALU.CC
U 0711, 8871,49     ;6860           JMP.IF[EQL] TO [DONE]                       ;JMP IF ALL DRVS BEEN TESTED
                    ;6861
U 0712, FF0C,15     ;6862           INC LS[T6.SUB]                              ;INCREMENT THE DRIVE NUMBER
U 0713, 8870,24     ;6863           JMP [TEST.DRIVE]                            ;GO TEST NEXT DRIVE NUMBER
                    ;6864
                    ;6865   DONE:
                    ;6866
U 0714, 364E,15     ;6867           MOV LS[PRINT.R80] TO WR[0]                  ;SET UP TO PRINT NO R80s
U 0715, 3E80,15     ;6868           MOV WR[0] TO LS[CONTROL.STATUS]
U 0716, 10E0,15     ;6869           MISC [SET.CP.ATTN]                          ;ISSUE CPU ATTN TO CONSOLE
                    ;6870   WAIT.DRIVE.SIZE.1:
U 0717, 0871,74     ;6871           JMP [WAIT.DRIVE.SIZE.1]                     ;LOOP HERE WAITING FOR
                    ;6872
U 0718, 2F82,95     ;6873           CLR WR[1]                                   ;SAVE NO R80 FOUND
                    ;6874
U 0719, 0872,B4     ;6875           JMP [SAVE.INFO]                             ;SAVE THE INFO THAT WAS FOUND
                    ;6876
                    ;6877
                    ;6878
                    ;6879   R80.FOUND:
U 071A, B640,15     ;6880           MOV LS[#1] TO WR[0]
U 071B, 3E0E,15     ;6881           MOV WR[0] TO LS[T7.SUB]                     ;INDICATES AN R80 FOUND TO THE
                    ;6882                                                       ; PRINT ROUTINE
                    ;6883                                                       ; DRV NUM IS IN LS[T6.SUB]
U 071C, 364E,15     ;6884           MOV LS[PRINT.R80] TO WR[0]                  ;SET UP TO PRINT THAT AN
U 071D, 3E80,15     ;6885           MOV WR[0] TO LS[CONTROL.STATUS]             ; R80 WAS FOUND
                    ;6886
U 071E, 10E0,15     ;6887           MISC [SET.CP.ATTN]                          ;ISSUE CPU ATTN TO CONSOLE
                    ;6888   WAIT.DRIVE.SIZE.2:                                  ; TO GO PRINT MESSAGE
U 071F, 8871,F4     ;6889           JMP [WAIT.DRIVE.SIZE.2]                     ;LOOP HERE WAITING FOR
                    ;6890                                                       ; CONSOLE TO RESPOND
                    ;6891
U 0720, 3640,95     ;6892           MOV  LS[BIT0] TO WR[1]                      ;SAVE DRIVE 0 IN WR[1]
U 0721, 360C,15     ;6893           MOV LS[T6.SUB] TO WR[0]                     ;GET THE DRIVE NUM
                    ;6894           CMP LS[ZERO] WITH WR[0],                    ;DRV NUM = 0?
```

```
U 0722, CE9C,35 ;6895            DT(LONG)&SET.ALU.CC
U 0723, 8872,B9 ;6896            JMP.IF[EQL] TO [SAVE.INFO]              ;JMP IF DRIVE 0
                ;6897
U 0724, B642,95 ;6898            MOV LS[BIT1] TO WR[1]                   ;SAVE DRIVE 1 IN WR[1]
                ;6899            CMP LS[#1] WITH WR[0],                  ;DRV NUM = 1?
U 0725, 4E40,35 ;6900             DT(LONG)&SET.ALU.CC
U 0726, 8872,B9 ;6901            JMP.IF[EQL] TO [SAVE.INFO]              ;JMP IF DRIVE 1
                ;6902
U 0727, B644,95 ;6903            MOV LS[BIT2] TO WR[1]                   ;SAVE DRIVE 2 IN WR[1]
                ;6904            CMP LS[#2] WITH WR[0],                  ;DRV NUM = 2?
U 0728, CE42,35 ;6905             DT(LONG)&SET.ALU.CC
U 0729, 8872,B9 ;6906            JMP.IF[EQL] TO [SAVE.INFO]              ;JMP IF DRIVE 2
                ;6907
U 072A, 3646,95 ;6908            MOV LS[BIT3] TO WR[1]                   ;SAVE DRIVE 3 IN WR[1]
                ;6909
                ;6910
                ;6911    SAVE.INFO:
U 072B, C74E,95 ;6912            BIS LS[BIT7] TO WR[1]                   ;SET BIT 7 TO INDICATE THAT
                ;6913                                                    ; THIS TEST HAS BEEN RUN
U 072C, BF8E,95 ;6914            MOV WR[1] TO LS[DRIVE.STATUS]           ;SAVE DRIVE INFO IN LS
                ;6915
U 072D, 5B00,14 ;6916            RETURN
                ;6917
                ;6918
```

```
                ;6919   .PAGE
                ;6920   .TOC    " INIT IDC AND GO TO DIAG.IDLE ROUTINE "
                ;6921   ;+++
                ;6922   ;
                ;6923   ; FUNCTIONAL DESCRIPTION:
                ;6924   ;
                ;6925   ;       This routine is used to force the IDC microcode to the Diagnostic
                ;6926   ;       Idle Loop (DIAG.IDLE) which is where all tests that use IDC
                ;6927   ;       Diagnostic Microcode must start from.
                ;6928   ;       This routine will INIT the IDC to force it to the IDC IDLE LOOP.
                ;6929   ;       The CSR will then be set up to force the microcode to branch to
                ;6930   ;       DIAG.IDLE which is the DIAGNOSTIC IDLE LOOP.
                ;6931   ;       This routine will then clear the DAR which is modified when the IDC
                ;6932   ;       Microcode branches to DIAG.IDLE.
                ;6933   ;
                ;6934   ;       AUTOMODE MODE will then be cleared before returning.
                ;6935   ;
                ;6936   ; CALLING SEQUENCE:
                ;6937   ;
                ;6938   ;       JSR [DIAG.CODE]
                ;6939   ;
                ;6940   ; INPUT PARAMETERS:
                ;6941   ;
                ;6942   ;       NONE
                ;6943   ;
                ;6944   ; IMPLICIT INPUTS:
                ;6945   ;
                ;6946   ;       NONE
                ;6947   ;
                ;6948   ; OUTPUT PARAMATERS:
                ;6949   ;
                ;6950   ;       NONE
                ;6951   ;
                ;6952   ; IMPLICIT OUTPUTS:
                ;6953   ;
                ;6954   ;       AUTOMODE will be cleared.
                ;6955   ;       The DAR will be cleared.
                ;6956   ;       The IDC Microcode will be looping at DIAG.IDLE.
                ;6957   ;
                ;6958   ; SIDE EFFECTS:
                ;6959   ;
                ;6960   ;       The IDC CSR will be modified.
                ;6961   ;
                ;6962   ;---
                ;6963   ;*****************************************************************************
                ;6964   DIAG.CODE:
                ;6965
U 072E, 17CC,15 ;6966           PORT.CONTROL [CLEAR.IDC]                ;SEND IDC MICROCODE TO IDLE
U 072F, 17CC,15 ;6967           PORT.CONTROL [CLEAR.IDC]
U 0730, 17CC,15 ;6968           PORT.CONTROL [CLEAR.IDC]
U 0731, 2F80,15 ;6969           CLR WR[0]
U 0732, 3720,15 ;6970           MOV LS[SETCSR.MAINT] TO WR[0]           ;GET DATA TO SET CSR MAINT BIT
                ;6971                                                   ; CRDY = 0 AND MAINT = 1
U 0733, 4778,15 ;6972           BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 0734, 17A0,15 ;6973           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE TO THE IDC CSR
```

```
                    ;6974
U 0735, B730,15     ;6975           MOV LS[#1A] TO WR[0]                        ;SET UP A COUNTER TO NOP TO
                    ;6976                                                       ; ALLOW TIME TO BRANCH FROM
                    ;6977                                                       ; IDLE TO DIAG.IDLE
                    ;6978   NOP.DIAG.CODE:
                    ;6979
U 0736, 2100,15     ;6980           DEC WR[0]                                   ; IDC COMPLETES ITS OPERATION
                    ;6981           CMP WR[0] WITH LS[ZERO],
U 0737, 4F9C,35     ;6982            DT(LONG)&SET.ALU.CC
U 0738, 0873,61     ;6983           JMP.IF[NEQ] TO [NOP.DIAG.CODE]
U 0739, 2F80,15     ;6984           CLR WR[0]                                   ;CLEAR THE DAR BECAUSE IT WILL
U 073A, 97A4,15     ;6985           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ; BE INCREMENTED BETWEEN IDLE
                    ;6986                                                       ; AND DIAG.IDLE
U 073B, 17D4,15     ;6987           PORT.CONTROL [CLEAR.AUTO]                   ;CLEAR AUTOMODE BECAUSE
                    ;6988                                                       ; AUTOMODE IS NOT CLEARED BY
                    ;6989                                                       ; INIT
                    ;6990
U 073C, 5B00,14     ;6991           RETURN
                    ;6992
                    ;6993
                    ;6994
```

```
                ;6995   .PAGE
                ;6996   .TOC    " WRITE..READ BYTE USING DISKLESS LOOP"
                ;6997   ;+++
                ;6998   ;
                ;6999   ; FUNCTIONAL DESCRIPTION:
                ;7000   ;
                ;7001   ;       This routine is used to route a byte of data from FIFO A, thru
                ;7002   ;       the diskless loop and is then written back into FIFO A.
                ;7003   ;       The data pattern is first written into FIFO A address 0.
                ;7004   ;       The CSR is then set up to branch to the IDC diskless loop routine.
                ;7005   ;       The byte of data goes thru the diskless loop and is then loaded
                ;7006   ;       into FIFO A address 1. The expected data is put in WR[1] and
                ;7007   ;       the received data is put in WR[0].
                ;7008   ;
                ;7009   ; CALLING SEQUENCE:
                ;7010   ;
                ;7011   ;       JSR [WRITE.READ.BYTE]
                ;7012   ;
                ;7013   ; INPUT PARAMETERS:
                ;7014   ;
                ;7015   ;       The write data must be in LS[SAV.DATA.PAT].
                ;7016   ;       WR[2] must contain the drive number of an RL02 or a line with no
                ;7017   ;       disk drive attached, in bits <9:8>.
                ;7018   ;
                ;7019   ; IMPLICIT INPUTS:
                ;7020   ;
                ;7021   ;       NONE
                ;7022   ;
                ;7023   ; OUTPUT PARAMATERS:
                ;7024   ;
                ;7025   ;       EXPECTED DATA IS IN WR[1]
                ;7026   ;       RECEIVED DATA IS IN WR[0]
                ;7027   ;
                ;7028   ; IMPLICIT OUTPUTS:
                ;7029   ;
                ;7030   ;       NONE
                ;7031   ;
                ;7032   ; SIDE EFFECTS:
                ;7033   ;
                ;7034   ;       FIFO A will be modified.
                ;7035   ;       The IDC CSR will be modified.
                ;7036   ;
                ;7037   ;---
                ;7038   ;*****************************************************************************
                ;7039   WRITE.READ.BYTE:
U 073D, 17D8,15 ;7040           PORT.CONTROL [SEL.FIFO.A]                       ;SELECT FIFO A FOR WRITE
U 073E, 17C0,15 ;7041           PORT.CONTROL [CLEAR.FIFO.CNTR]                  ;SET FIFO TO ADDRESS 0
U 073F, B724,15 ;7042           MOV LS[SAV.DATA.PAT] TO WR[0]                   ;DATA PATT
U 0740, 97A8,15 ;7043           PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]
                ;7044
U 0741, 17D8,15 ;7045           PORT.CONTROL [SEL.FIFO.A]                       ;SELECT FIFO A
U 0742, 17C0,15 ;7046           PORT.CONTROL [CLEAR.FIFO.CNTR]                  ;SET FIFO TO ADDRESS 0
U 0743, 3708,15 ;7047           MOV LS[SETCSR.F4] TO WR[0]                      ;SET CSR F<2:0>=100 TO BRANCH
                ;7048                                                           ; AND CLR CRDY
U 0744, AEC4,15 ;7049           BIS WR[2] TO WR[0]                              ;INCLUDE THE RL02 DRV SELECT
```

```
U 0745, 17A0,15 ;7050           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WRITE THE DATA TO IDC CSR
                ;7051
                ;7052   ;-------------------------------------------------------------------------------
                ;7053   ;-------------------------------------------------------------------------------
                ;7054   ;                                *******
                ;7055   ;                                * IDC *
                ;7056   ;                                *******
                ;7057   ;-------------------------------------------------------------------------------
                ;7058   ;018:
                ;7059   ;=000
                ;7060   ;DIAG.IDLE:
                ;7061   ;
                ;7062   ;       BEN0/F0,
                ;7063   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;7064   ;       BEN2/F2,
                ;7065   ;       NAD/DIAG.IDLE
                ;7066   ;-------------------------------------------------------------------------
                ;7067   ;01C:
                ;7068   ;=100
                ;7069   ;
                ;7070   ;       BEN0/CRDY.L,
                ;7071   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;7072   ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;7073   ;-------------------------------------------------------------------------
                ;7074   ;06B:
                ;7075   ;=0*1
                ;7076   ;DISKLESS.DIAG.0:
                ;7077   ;
                ;7078   ;       UMAINT/ON,
                ;7079   ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
                ;7080   ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
                ;7081   ;       LOAD.LOOP.CNTR.[0E0],
                ;7082   ;       NAD/DISKLESS.DIAG.1
                ;7083   ;-------------------------------------------------------------------------
                ;7084   ;184:
                ;7085   ;=0
                ;7086   ;DISKLESS.DIAG.1:
                ;7087   ;
                ;7088   ;       UMAINT/ON,
                ;7089   ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
                ;7090   ;       DISK.WRITE/ON,          ; DATA SEPARATOR
                ;7091   ;       UCMD/SET.FIFOA,
                ;7092   ;       INCR.LPCNTR/ON,
                ;7093   ;       BEN0/CNTR.OVFLW,
                ;7094   ;       NAD/DISKLESS.DIAG.1
                ;7095   ;-------------------------------------------------------------------------
                ;7096   ;185:
                ;7097   ;=1
                ;7098   ;DISKLESS.DIAG.2:
                ;7099   ;
                ;7100   ;       UMAINT/ON,
                ;7101   ;       LOOP.LOCK/ON,
                ;7102   ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
                ;7103   ;       ENB.DSK.CLK,
                ;7104   ;       NAD/DISKLESS.DIAG.3A
```

```
;7105   ;-------------------------------------------------------------------------------
;7106   ;1D9:
;7107   ;DISKLESS.DIAG.3A:
;7108   ;
;7109   ;       UMAINT/ON,
;7110   ;       LOOP.LOCK/ON,
;7111   ;       DISK.WRITE/ON,
;7112   ;       NAD/DISKLESS.DIAG.3B
;7113   ;-------------------------------------------------------------------------------
;7114   ;1DA:
;7115   ;DISKLESS.DIAG.3B:
;7116   ;
;7117   ;       UMAINT/ON,
;7118   ;       LOOP.LOCK/ON,
;7119   ;       DISK.WRITE/ON,
;7120   ;       NAD/DISKLESS.DIAG.3
;7121   ;-------------------------------------------------------------------------------
;7122   ;1DB:
;7123   ;DISKLESS.DIAG.3:
;7124   ;
;7125   ;       UMAINT/ON,
;7126   ;       LOOP.LOCK/ON,
;7127   ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;7128   ;       ENB.FIFO/ON,
;7129   ;       LOAD.DSR/ON,
;7130   ;       NAD/DISKLESS.DIAG.4A
;7131   ;-------------------------------------------------------------------------------
;7132   ;1DC:
;7133   ;DISKLESS.DIAG.4A:
;7134   ;
;7135   ;       UMAINT/ON,
;7136   ;       LOOP.LOCK/ON,           ;INCREMENT THE FIFO ADDRESS COUNTER
;7137   ;       DISK.WRITE/ON,
;7138   ;       INCR.FIFO.CNTR/ON,
;7139   ;       LOAD.LOOP.CNTR.[0F5],
;7140   ;       NAD/DISKLESS.DIAG.4
;7141   ;-------------------------------------------------------------------------------
;7142   ;188:
;7143   ;=0
;7144   ;DISKLESS.DIAG.4:
;7145   ;
;7146   ;       UMAINT/ON,
;7147   ;       LOOP.LOCK/ON,
;7148   ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;7149   ;       INCR.LPCNTR/ON,                 ; LOOP
;7150   ;       BEN0/CNTR.OVFLW,
;7151   ;       NAD/DISKLESS.DIAG.4
;7152   ;-------------------------------------------------------------------------------
;7153   ;189:
;7154   ;=1
;7155   ;DISKLESS.DIAG.5:
;7156   ;
;7157   ;       UMAINT/ON,
;7158   ;       LOOP.LOCK/ON,
;7159   ;       ENB.DSR/ON,                     ;LOAD THE DATA INTO FIFO A
```

```
                ;7160   ;       WRT.FIFO/ON,
                ;7161   ;       DISK.WRITE/ON,
                ;7162   ;       NAD/DISKLESS.DIAG.6
                ;7163   ;-------------------------------------------------------------------------------
                ;7164   ;1DD:
                ;7165   ;DISKLESS.DIAG.6:
                ;7166   ;
                ;7167   ;       UMAINT/ON,
                ;7168   ;       LOOP.LOCK/ON,
                ;7169   ;       DISK.WRITE/ON,
                ;7170   ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
                ;7171   ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;7172   ;-------------------------------------------------------------------------------
                ;7173   ;1D8:
                ;7174   ;XFER.REQ:
                ;7175   ;
                ;7176   ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;7177   ;       NAD/DIAG.WAIT
                ;7178   ;-------------------------------------------------------------------------------
                ;7179   ;1D7:
                ;7180   ;DIAG.WAIT:
                ;7181   ;
                ;7182   ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;7183   ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;7184   ;-------------------------------------------------------------------------------
                ;7185   ;159:
                ;7186   ;=*0*
                ;7187   ;DIAG.WAIT1:
                ;7188   ;
                ;7189   ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;7190   ;                               ; COMMAND FROM THE CPU
                ;7191   ;-------------------------------------------------------------------------------
                ;7192   ;15B:
                ;7193   ;=*1*
                ;7194   ;DIAG.WAIT2:
                ;7195   ;
                ;7196   ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;7197   ;                               ; WAIT SOME MORE
                ;7198   ;-------------------------------------------------------------------------------
                ;7199
                ;7200   WAIT.IDC.TSUB:
U 0746, DB00,1A ;7201           SKIP.IF[NO.FAST.INTERRUPT]              ;SKIP UNTIL IDC DONE
U 0747, 8874,94 ;7202           JMP [IDC.DONE.TSUB]                     ;EXIT LOOP WHEN IDC IS DONE
U 0748, 8874,64 ;7203           JMP [WAIT.IDC.TSUB]                     ;WAIT UNTIL IDC IS DONE
                ;7204
                ;7205
                ;7206   IDC.DONE.TSUB:
                ;7207
U 0749, B700,15 ;7208           MOV LS[SETCSR.F0] TO WR[0]      ;CLEAR THE FUNC BITS
U 074A, 17A0,15 ;7209           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WRITE THE DATA TO IDC CSR
U 074B, 90FA,15 ;7210           MISC2 [TRANSFER.GRANT]                  ;SEND TRANSFER GRANT
U 074C, 17D8,15 ;7211           PORT.CONTROL [SEL.FIFO.A]       ;SEL FIFOA TO READ RECEIVED DATA
U 074D, 9090,15 ;7212           MISC [SET.PORT.I.O]             ;SEL THE PORT TO BUS
U 074E, 1788,15 ;7213           PORT.READ PORT.ADRS[DATA.BYTE]  ;READ THE RETURNED BYTE OF DATA
U 074F, 3B32,15 ;7214           MOV PORT TO LS[PORT0]           ;SAVE THE RECEIVED DATA IN LS
```

```
U 0750, 3732,15 ;7215          MOV LS[PORT0] TO WR[0]          ;SAVE THE DATA IN WR[0] FOR CMP
U 0751, 3724,95 ;7216          MOV LS[SAV.DATA.PAT] TO WR[1]   ;GET THE EXPECTED DATA
U 0752, 5B00,14 ;7217          RETURN                          ;RETURN TO MAIN ROUTINE
                ;7218
                ;7219
                ;7220
                ;7221
```

```
                    ;7222   .PAGE
                    ;7223   .TOC    " CLEANUP ROUTINE "
                    ;7224   ;+++
                    ;7225   ;
                    ;7226   ; FUNCTIONAL DESCRIPTION:
                    ;7227   ;
                    ;7228   ;       This routine should be used at the end of tests to INIT the
                    ;7229   ;       IDC to cleanup any special cinditions that were set by a test
                    ;7230   ;       and to JAM to IDC microcode into the IDC IDLE LOOP.
                    ;7231   ;
                    ;7232   ; CALLING SEQUENCE:
                    ;7233   ;
                    ;7234   ;       JSR [CLEANUP]
                    ;7235   ;
                    ;7236   ; INPUT PARAMETERS:
                    ;7237   ;
                    ;7238   ;       NONE
                    ;7239   ;
                    ;7240   ; IMPLICIT INPUTS:
                    ;7241   ;
                    ;7242   ;       NONE
                    ;7243   ;
                    ;7244   ; OUTPUT PARAMATERS:
                    ;7245   ;
                    ;7246   ;       NONE
                    ;7247   ;
                    ;7248   ; IMPLICIT OUTPUTS:
                    ;7249   ;
                    ;7250   ;       NONE
                    ;7251   ;
                    ;7252   ; SIDE EFFECTS:
                    ;7253   ;
                    ;7254   ;       The IDC will be INITED and the IDC microcode will JAM to the
                    ;7255   ;       IDC IDLE LOOP.
                    ;7256   ;
                    ;7257   ;---
                    ;7258   ;*****************************************************************************
                    ;7259   CLEANUP:
U 0753, 17CC,15     ;7260           PORT.CONTROL [CLEAR.IDC]        ;INITIALIZE IDC AND SEND MICROCODE TO
                    ;7261                                           ; IDLE
U 0754, 17CC,15     ;7262           PORT.CONTROL [CLEAR.IDC]
U 0755, 17CC,15     ;7263           PORT.CONTROL [CLEAR.IDC]
U 0756, 5B00,14     ;7264           RETURN                          ;RETURN TO TEST
                    ;7265
                    ;7266
                    ;7267
```

```
                ;7268   .PAGE  "Test 1  Y BUS VERIFICATION TEST (M8388 IDC MODULE OR M8390 CPU MODULE)"
                ;7269   ;++
                ;7270   ;
                ;7271   ; Test Description:
                ;7272   ;
                ;7273   ;       This test will insure that the Y bus is fully operational as seen by
                ;7274   ;       the CPU. The test will move data from local store to a working
                ;7275   ;       register and then use the Y Bus to move the data back to a temporary
                ;7276   ;       location in local store.
                ;7277   ;       The data patterns that will be used are:
                ;7278   ;               1. AAAAAAAA
                ;7279   ;               2. 55555555
                ;7280   ;               3. 33333333
                ;7281   ;               4. 0F0F0F0F
                ;7282   ;               5. 00FF00FF
                ;7283   ;               6. 0000FFFF
                ;7284   ;
                ;7285   ;
                ;7286   ; Assumptions:
                ;7287   ;
                ;7288   ;       It is assumed that the CPU has been tested and was found to
                ;7289   ;       be fully operational without an IDC module installed.
                ;7290   ;
                ;7291   ; Test Steps:
                ;7292   ;
                ;7293   ;       1. Set up error mask, error number,and module number in LS
                ;7294   ;          (for error printouts) and clear previous error number in LS.
                ;7295   ;       2. MOV data pattern from LS to WR[1].
                ;7296   ;       3. MOV WR[1] to a temporary LS location.
                ;7297   ;       4. MOV the temporary LS location to WR[0] and check.
                ;7298   ;       5. Repeat test steps 1-4 until all data patterns have been tested.
                ;7299   ;
                ;7300   ; Error:
                ;7301   ;
                ;7302   ;       ERROR 1 - Y Bus failed.
                ;7303   ;
                ;7304   ;               Printout:
                ;7305   ;                       EXPECTED        RECEIVED
                ;7306   ;                        WR[0]           WR[0]
                ;7307   ; Debug:
                ;7308   ;
                ;7309   ;  ERROR 1:
                ;7310   ;
                ;7311   ;       If the CPU Micro Diagnostic was run with no errors prior to the
                ;7312   ;       addition of the IDC module to the system, then the Y Bus is most
                ;7313   ;       likely being corrupted by the IDC module.
                ;7314   ;
                ;7315   ;       If the CPU Micro Diagnostics were not run prior to beginning
                ;7316   ;       this test then either the CPU or the FPA Module (if one exists) or
                ;7317   ;       the IDC module could be at fault.
                ;7318   ;
                ;7319   ;--
                ;7320   ;*****************************************************************************
                ;7321   T.1:
U 0757, B65E,15 ;7322           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
```

```
                ;7323                                          ; CONTROL AND STATUS WORD
U 0758, 3E80,15 ;7324           MOV WR[0] TO LS[CONTROL.STATUS] ;SET BIT 15 IN CONTROL AND
                ;7325                                          ; STATUS WORD - BIT 15
                ;7326                                          ; INDICATES START OF TEST TO
                ;7327                                          ; CONSOLE
U 0759, 10E0,15 ;7328           MISC [SET.CP.ATTN]             ;ISSUE CPU ATTN TO CONSOLE
                ;7329   WAIT.T1.0:
U 075A, 0875,A4 ;7330           JMP [WAIT.T1.0]                ;LOOP HERE WAITING FOR CONSOLE
                ;7331                                          ; TO RESPOND
U 075B, 65A0,15 ;7332           CLR LS[PREVIOUS.ERROR]         ;CLEAR PREVIOUS ERROR NUMBER
                ;7333                                          ; IN LS
                ;7334
U 075C, 3642,15 ;7335           MOV LS[CPU] TO WR[0]           ;STORE MODULE CODE IN LS TO
U 075D, C74A,15 ;7336           BIS LS[IDC] TO WR[0]           ; INDICATE IDC AND CPU
U 075E, 3E8C,15 ;7337           MOV WR[0] TO LS[MODULE.NUM]    ; MODULES
                ;7338
U 075F, B640,15 ;7339           MOV LS[#1] TO WR[0]            ;SET WR0 = 1
U 0760, BE82,15 ;7340           MOV WR[0] TO LS[ERROR.NUMBER]  ;SET UP ERROR NUMBER = 1 IN LS
                ;7341
U 0761, E58A,15 ;7342           CLR LS[ERROR.MASK]             ;SET UP ERROR MASK TO CHECK
                ;7343                                          ; ALL BITS
                ;7344
                ;7345   LOOP.T1.1:
U 0762, B698,15 ;7346           MOV LS[#AAAAAAAA] TO WR[0]     ;LOAD THE WORKING REGISTER
U 0763, BE14,15 ;7347           MOV WR[0] TO LS[T10]           ;MOV THE DATA OVER THE Y BUS
U 0764, 3614,15 ;7348           MOV LS[T10] TO WR[0]           ;GET THE RECEIVED DATA
U 0765, 3698,95 ;7349           MOV LS[#AAAAAAAA] TO WR[1]     ;GET THE EXPECTED DATA
U 0766, 0869,3C ;7350           JSR [CHECK.RESULT]             ;CHECK THE RESULT
U 0767, 8876,24 ;7351           JMP [LOOP.T1.1]                ;ERROR LOOP
                ;7352   LOOP.T1.2:
U 0768, 369A,15 ;7353           MOV LS[#55555555] TO WR[0]
U 0769, BE14,15 ;7354           MOV WR[0] TO LS[T10]           ;MOV THE DATA OVER THE Y BUS
U 076A, 3614,15 ;7355           MOV LS[T10] TO WR[0]           ;GET THE RECEIVED DATA
U 076B, B69A,95 ;7356           MOV LS[#55555555] TO WR[1]     ;GET THE EXPECTED DATA
U 076C, 0869,3C ;7357           JSR [CHECK.RESULT]             ;CHECK THE RESULT
U 076D, 8876,84 ;7358           JMP [LOOP.T1.2]                ;ERROR LOOP
                ;7359   LOOP.T1.3:
U 076E, B6C4,15 ;7360           MOV LS[#33333333] TO WR[0]
U 076F, BE14,15 ;7361           MOV WR[0] TO LS[T10]           ;MOV THE DATA OVER THE Y BUS
U 0770, 3614,15 ;7362           MOV LS[T10] TO WR[0]           ;GET THE RECEIVED DATA
U 0771, 36C4,95 ;7363           MOV LS[#33333333] TO WR[1]     ;GET THE EXPECTED DATA
U 0772, 0869,3C ;7364           JSR [CHECK.RESULT]             ;CHECK THE RESULT
U 0773, 8876,E4 ;7365           JMP [LOOP.T1.3]                ;ERROR LOOP
                ;7366   LOOP.T1.4:
U 0774, 36C6,15 ;7367           MOV LS[#0F0F0F0F] TO WR[0]
U 0775, BE14,15 ;7368           MOV WR[0] TO LS[T10]           ;MOV THE DATA OVER THE Y BUS
U 0776, 3614,15 ;7369           MOV LS[T10] TO WR[0]           ;GET THE RECEIVED DATA
U 0777, B6C6,95 ;7370           MOV LS[#0F0F0F0F] TO WR[1]     ;GET THE EXPECTED DATA
U 0778, 0869,3C ;7371           JSR [CHECK.RESULT]             ;CHECK THE RESULT
U 0779, 0877,44 ;7372           JMP [LOOP.T1.4]                ;ERROR LOOP
                ;7373   LOOP.T1.5:
U 077A, B6C8,15 ;7374           MOV LS[#00FF00FF] TO WR[0]
U 077B, BE14,15 ;7375           MOV WR[0] TO LS[T10]           ;MOV THE DATA OVER THE Y BUS
U 077C, 3614,15 ;7376           MOV LS[T10] TO WR[0]           ;GET THE RECEIVED DATA
U 077D, 36C8,95 ;7377           MOV LS[#00FF00FF] TO WR[1]     ;GET THE EXPECTED DATA
```

```
U 077E, 0869,3C ;7378            JSR [CHECK.RESULT]                    ;CHECK THE RESULT
U 077F, 8877,A4 ;7379            JMP [LOOP.T1.5]                       ;ERROR LOOP
                ;7380    LOOP.T1.6:
U 0780, B772,15 ;7381            MOV LS[#0000FFFF] TO wR[0]
U 0781, BE14,15 ;7382            MOV WR[0] TO LS[T10]                  ;MOV THE DATA OVER THE Y BUS
U 0782, 3614,15 ;7383            MOV LS[T10] TO WR[0]                  ;GET THE RECEIVED DATA
U 0783, 3772,95 ;7384            MOV LS[#0000FFFF] TO WR[1]            ;GET THE EXPECTED DATA
U 0784, 0869,3C ;7385            JSR [CHECK.RESULT]                    ;CHECK THE RESULT
U 0785, 8878,04 ;7386            JMP [LOOP.T1.6]                       ;ERROR LOOP
                ;7387    END.T1:                                       ;END TEST
                ;7388
                ;7389
                ;7390
                ;7391
                ;7392
```

```
;7393   .PAGE  "Test 2  IDC SIZING TEST (M8388 IDC MODULE OR M8390 CPU MODULE)"
;7394   ;++
;7395   ;
;7396   ; Test Description:
;7397   ;
;7398   ;       If this diagnostic is being run under APT and an IDC is not found
;7399   ;       then an error will be reported.
;7400   ;       This test will size for the IDC Module by writing and then reading
;7401   ;       Bit <0> of the Disk Address Register (DAR). If this cannot be
;7402   ;       accomplished successfully, then the message "IDC NOT PRESENT" will
;7403   ;       be printed and the IDC microdiagnostic will not be executed. Otherwise
;7404   ;       "IDC PRESENT" will be printed and test execution will continue.
;7405   ;
;7406   ; Assumptions:
;7407   ;
;7408   ;       It is assumed that the CPU and the Y bus are fully operational.
;7409   ;
;7410   ; Test Steps:
;7411   ;
;7412   ;       1. Move zero to WR[0].
;7413   ;       2. Move #1 to WR [1].
;7414   ;       3. Write a one to DAR <0>.
;7415   ;       4. Move WR[0] to a temporary LS location to change the data on the
;7416   ;          Y BUS.
;7417   ;       5. Read DAR <0>.
;7418   ;       6. Check result. If incorrect data, print message "IDC NOT PRESENT" and
;7419   ;          go to Step 12.
;7420   ;       7. Write a zero to DAR <0>.
;7421   ;       8. Move WR[1] to a temporary LS location to change the data on the
;7422   ;          Y BUS.
;7423   ;       9. Read DAR <0>.
;7424   ;      10. Check result.
;7425   ;      11. If data is incorrect, print message "IDC NOT PRESENT".
;7426   ;      12. If APT is present then force an error because IDC was not found.
;7427   ;      13. Go to end of section.
;7428   ;      14. Else print "IDC PRESENT" and continue IDC microdiagnostic execution.
;7429   ;
;7430   ; Errors:
;7431   ;
;7432   ;  ERROR 1 - The diagnostic was being run under APT and no IDC was found.
;7433   ;
;7434   ;                  Printout:
;7435   ;                          EXPECTED        RECEIVED
;7436   ;                            N/A             N/A
;7437   ;
;7438   ; Debug:
;7439   ;
;7440   ;       If an IDC is not found by this test and one is known to exist, then
;7441   ;       TEST 4 DISK ADDRESS REGISTER TEST should be run to allow looping on
;7442   ;       error. A more detailed debug section is also available in TEST 4.
;7443   ;
;7444   ;       If the IDC is not found and one is known to exist then the fault could
;7445   ;       be in one of the following:
;7446   ;
;7447   ;       1. The STATE REG, MISC DECODER PAL on the CPU module which generates
```

```
                    ;7448   ;          the PORT INSTR H signal.
                    ;7449   ;       2. The A,B ADRS GEN PAL on the CPU module which generates the
                    ;7450   ;          READ PORT L signal.
                    ;7451   ;       3. Bit <0> of the data bus transceiver
                    ;7452   ;       4. Bit <0> of the IDC I/O bus
                    ;7453   ;       5. Bit <0> of the DAR
                    ;7454   ;       6. The DAR control signals, WRITE DAR or SEL DAR which are decoded from
                    ;7455   ;          the Port instruction through the PORT INTERFACE REG PAL, the PORT
                    ;7456   ;          RD/WR DECODE PAL and the Port instruction decoder.
                    ;7457   ;
                    ;7458   ;--
                    ;7459   ;*****************************************************************************
                    ;7460   T.2:
U 0786, B65E,15     ;7461           MOV LS[BEGIN.TEST] TO WR[0]                 ;SET BIT 15 IN WR[0] FOR
                    ;7462                                                       ; CONTROL AND STATUS WORD
U 0787, 3E80,15     ;7463           MOV WR[0] TO LS[CONTROL.STATUS]             ;SET BIT 15 IN CONTROL AND
                    ;7464                                                       ; STATUS WORD - BIT 15
                    ;7465                                                       ; INDICATES START OF TEST TO
                    ;7466                                                       ; CONSOLE
U 0788, 10E0,15     ;7467           MISC [SET.CP.ATTN]                          ;ISSUE CPU ATTN TO CONSOLE
                    ;7468   WAIT.T2.0:
U 0789, 8878,94     ;7469           JMP [WAIT.T2.0]                             ;LOOP HERE WAITING FOR CONSOLE
                    ;7470                                                       ; TO RESPOND
                    ;7471
U 078A, E50E,15     ;7472           CLR LS[T7.SUB]                              ;SET UP FOR MESSAGE PRINTOUT
U 078B, B640,15     ;7473           MOV LS[#1] TO WR[0]
U 078C, BE82,15     ;7474           MOV WR[0] TO LS[ERROR.NUMBER]               ;SET ERROR NUMBER =1
                    ;7475                                                       ;****************************
U 078D, 3776,15     ;7476           MOV LS[DAR.MASK] TO WR[0]                   ;CHANGE MAR 15,83 PETER GREEN
U 078E, C566,15     ;7477           BIC LS[BIT19] TO WR[0]                      ;MANUFACT PROB W/SLOW CLOCK
U 078F, 4568,15     ;7478           BIC LS[BIT20] TO WR[0]                      ;IDC NOT FOUND (INTERMITTANT)
U 0790, 3E8A,15     ;7479           MOV WR[0] TO LS[ERROR.MASK]                 ;BITS 25 & 27 BEING SET
                    ;7480                                                       ;SET UP ERROR MASK TO CHECK
                    ;7481                                                       ; BITS <20:0> IDAR
                    ;7482                                                       ;****************************
                    ;7483   LOOP.T2.1:
                    ;7484   WRITE1.DAR.T2:
U 0791, B640,15     ;7485           MOV LS[#1] TO WR[0]                         ;GET DATA TO WRITE TO DAR
U 0792, 97A4,15     ;7486           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;WRITE A ONE TO IDC DISK
                    ;7487                                                       ; ADDRESS REGISTER
                    ;7488
U 0793, 369C,15     ;7489           MOV LS[ZERO] TO WR[0]                       ;CHANGE THE DATA IN WR[0]
U 0794, 3F32,95     ;7490           MOV WR[1] TO LS[PORT0]                      ; AND IN LS[PORT0]
                    ;7491
U 0795, 9090,15     ;7492           MISC [SET.PORT.I.0]                         ;SELECT THE PORT TO BUS
U 0796, 1784,15     ;7493           PORT.READ PORT.ADRS[DAR]                    ;READ BACK THE IDC DAR
U 0797, 3B32,15     ;7494           MOV PORT TO LS[PORT0]                       ;MOV THE RECEIVED DATA TO LS
U 0798, 3732,15     ;7495           MOV LS[PORT0] TO WR[0]                      ;MOV RECEIVED DATA FOR COMPARE
U 0799, 3640,95     ;7496           MOV LS[#1] TO WR[1]                         ;GET EXPECTED DATA
                    ;7497                                                       ;
U 079A, 458A,15     ;7498           BIC LS[ERROR.MASK] TO WR[0]                 ;CHANGE 3/15 P. G.
                    ;7499                                                       ;MASK BITS 20-31 FIX
U 079B, C58A,95     ;7500           BIC LS[ERROR.MASK] TO WR[1]                 ;CLOCK MARGINS
                    ;7501                                                       ;
                    ;7502           CMP WR[0] WITH WR[1],                       ;CMP THE EXP AND REC DATA
```

```
U 079C, 2640,B5 ;7503            DT(LONG)&SET.ALU.CC
U 079D, 887A,B1 ;7504            JMP.IF[NEQ] TO [NO.IDC.T2]              ;GO PRINT NO IDC
                ;7505
                ;7506   WRITE0.DAR.T2:
U 079E, 369C,15 ;7507            MOV LS[#0] TO WR[0]                     ;GET DATA TO WRITE TO DAR
U 079F, 97A4,15 ;7508            PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE A ZERO TO IDC DISK
                ;7509                                                    ; ADDRESS REGISTER
                ;7510
U 07A0, B640,15 ;7511            MOV LS[#1] TO WR[0]                     ;CHANGE THE DATA IN WR[0]
U 07A1, 3F32,95 ;7512            MOV WR[1] TO LS[PORT0]                  ; AND LS[PORT0]
                ;7513
U 07A2, 9090,15 ;7514            MISC [SET.PORT.I.0]                     ;SELECT THE PORT TO BUS
U 07A3, 1784,15 ;7515            PORT.READ PORT.ADRS[DAR]                ;READ BACK THE IDC DAR
U 07A4, 3B32,15 ;7516            MOV PORT TO LS[PORT0]                   ;MOV THE RECEIVED DATA TO LS
U 07A5, 3732,15 ;7517            MOV LS[PORT0] TO WR[0]                  ;MOV RECEIVED DATA FOR COMPARE
U 07A6, B69C,95 ;7518            MOV LS[#0] TO WR[1]                     ;GET EXPECTED DATA
                ;7519                                                    ;
U 07A7, 458A,15 ;7520            BIC LS[ERROR.MASK] TO WR[0]             ;CHANGE 3/15 P. G.
                ;7521                                                    ;MASK BITS 20-31 FIX
U 07A8, C58A,95 ;7522            BIC LS[ERROR.MASK] TO WR[1]             ;CLOCK MARGINS
                ;7523                                                    ;
                ;7524            CMP WR[0] WITH WR[1],                   ;CMP THE EXP AND REC DATA
U 07A9, 2640,B5 ;7525             DT(LONG)&SET.ALU.CC
U 07AA, 087B,99 ;7526            JMP.IF[EQL] TO [IDC.FOUND.T2]           ;GO PRINT IDC FOUND
                ;7527
                ;7528   NO.IDC.T2:
U 07AB, 367E,15 ;7529            MOV LS[PRINT.IDC] TO WR[0]              ;SET UP CONTROL STATUS WORD TO
U 07AC, 3E80,15 ;7530            MOV WR[0] TO LS[CONTROL.STATUS]         ; PRINT NO IDC FOUND
U 07AD, 10E0,15 ;7531            MISC [SET.CP.ATTN]                      ;SET ATTENTION TO THE CONSOLE
                ;7532   WAIT.T2.1:
U 07AE, 887A,E4 ;7533            JMP [WAIT.T2.1]                         ;WAIT FOR CONSOLE TO RETURN
                ;7534                                                    ; CONTROL
                ;7535
U 07AF, 3690,15 ;7536            MOV LS[ERROR.CONTROL] TO WR[0]          ;RUNNING UNDER APT?
                ;7537            BIT LS[APT.PRESENT] WITH WR[0],
U 07B0, 594A,35 ;7538             DT(LONG)&SET.ALU.CC
U 07B1, 09BE,E9 ;7539            JMP.IF[BITS.CLR] TO [END.SECTION]       ;IF APT NOT PRESENT THEN DO
                ;7540                                                    ; NOT RUN DIAGNOSTIC
U 07B2, B66E,15 ;7541            MOV LS[NA.EXP.REC] TO WR[0]
U 07B3, 3E80,15 ;7542            MOV WR[0] TO LS[CONTROL.STATUS]         ;SET UP TO FORCE AN ERROR
U 07B4, 2F80,15 ;7543            CLR WR[0]
U 07B5, 3640,95 ;7544            MOV LS[#1] TO WR[1]
U 07B6, 0869,3C ;7545            JSR [CHECK.RESULT]                      ;GO FORCE THE ERROR
U 07B7, 8879,14 ;7546            JMP [LOOP.T2.1]                         ;LOOP HERE IF ERR & LOE
                ;7547
U 07B8, 89BE,E4 ;7548            JMP [END.SECTION]                       ;NO IDC AVAILABLE, GO TO END
                ;7549                                                    ; OF SECTION
                ;7550
                ;7551   IDC.FOUND.T2:
U 07B9, 7F0E,15 ;7552            INC LS[T7.SUB]                          ;SET TO PRINT IDC FOUND
U 07BA, 367E,15 ;7553            MOV LS[PRINT.IDC] TO WR[0]              ;SET CONTROL STATUS WORD TO
U 07BB, 3E80,15 ;7554            MOV WR[0] TO LS[CONTROL.STATUS]         ; PRINT MESSAGE
U 07BC, 10E0,15 ;7555            MISC [SET.CP.ATTN]                      ;SET ATTENTION TO THE CONSOLE
                ;7556   WAIT.T2.2:
U 07BD, 087B,D4 ;7557            JMP [WAIT.T2.2]                         ;WAIT FOR CONSOLE TO RETURN
```

```
;7558
;7559   END.T2:                                          ;END TEST
;7560
;7561
;7562
;7563
;7564
;7565
```

ZZ
;
;
U
U
U

```
;7566    .PAGE  "Test 3  CRDY & XFER.REQ INIT TEST (M8388 IDC OR M8390 CPU MODULE)"
;7567    ;++
;7568    ;
;7569    ; Test Description:
;7570    ;
;7571    ;       This test is designed to insure that the IDC initializes certain
;7572    ;       important signals properly when a CLEAR.IDC is issued by the
;7573    ;       CPU. CRDY and XFER.REQ must initialize properly for the IDC
;7574    ;       microcode branching to work correctly. CRDY should be set
;7575    ;       and XFER.REQ should be cleared by a CLEAR.IDC instruction.
;7576    ;
;7577    ; Assumptions:
;7578    ;
;7579    ;       It is assumed that the CPU and the Y Bus are fully operational.
;7580    ;
;7581    ; Test Steps:
;7582    ;
;7583    ;       1. Set up error mask, error number and module number in LS
;7584    ;          (for error printouts) and clear the previous error number in LS.
;7585    ;       2. Issue a CLEAR.IDC.
;7586    ;       3. Allow time for IDC to initialize.
;7587    ;       4. Check CSR bit <7> (CRDY).
;7588    ;       5. Increment the error number.
;7589    ;       6. Check XFER.REQ (FAST INTERRUPT) to be clear.
;7590    ;       7. End test.
;7591    ;
;7592    ; Errors:
;7593    ;
;7594    ;       ERROR 1 - CSR <7> (CDRY) did not set.
;7595    ;                 Printout:
;7596    ;                          EXPECTED       RECEIVED
;7597    ;                            CSR            CSR
;7598    ;
;7599    ;
;7600    ;       ERROR 2 - XFER.REQ did not clear when CLEAR.IDC was issued.
;7601    ;                 Printout:
;7602    ;                          EXPECTED       RECEIVED
;7603    ;                           WR[0]          WR[0]
;7604    ; Debug:
;7605    ;
;7606    ; ERROR 1:
;7607    ;
;7608    ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
;7609    ;       PAL. The inputs will be:
;7610    ;                CSR 17 H = H
;7611    ;                CSR 14 H = H
;7612    ;                CSR 12 H = L
;7613    ;                CSR 11 H = H
;7614    ;                CSR 10 H = H
;7615    ;                PORT INSTR H = H
;7616    ;       This combination of inputs will assert CLEAR IDC L. This signal is
;7617    ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
;7618    ;       assert. This signal is inverted to INIT L. INIT L is an input to the
;7619    ;       CONTROL STATUS REG PAL. At the next P2 CLOCK L, CRDY L will assert.
;7620    ;       CRDY L is an input to the CSR LINE DRIVERS and will be read when a
```

```
                ;7621   ;       PORT.READ PORT.ADRS[CSR] is issued.
                ;7622   ;
                ;7623   ;   READ.CSR:
                ;7624   ;       To read the CSR, the PORT INTERFACE REG PAL and the Port Instruction
                ;7625   ;       Decoder must operate correctly.
                ;7626   ;       The CPU first issues a MISC [SET.PORT.I.O] which will assert
                ;7627   ;       SEL IDC L.
                ;7628   ;       The inputs to the PORT INTERFACE REGISTER PAL on the
                ;7629   ;       PORT.READ PORT.ADRS[CSR] instruction will be as follows:
                ;7630   ;               CSR 17 H = H
                ;7631   ;               CSR 14 H = L
                ;7632   ;               CSR 12 H = L
                ;7633   ;               CSR 11 H = L
                ;7634   ;               CSR 10 H = L
                ;7635   ;               PORT INSTR H = H
                ;7636   ;               CPU P2 H = H
                ;7637   ;       The resultant outputs will be:
                ;7638   ;               R2 L = H
                ;7639   ;               R1 L = H
                ;7640   ;               R0 L = H
                ;7641   ;       The CPU then issues a MOV PORT TO LS[] which asserts READ PORT L which
                ;7642   ;       is an input to the PORT INTERFACE REG PAL. This input will cause
                ;7643   ;       READ PORT H to assert. READ PORT H is ANDED with SEL IDC H = H and
                ;7644   ;       SEL ACC L = H and will assert READ IDC L.
                ;7645   ;       READ IDC L and READ PORT H are the enables for the decoder of R<2:0>.
                ;7646   ;       R<2:0> will be decoded and will assert SEL CSR L which enables the
                ;7647   ;       CSR onto the I/O Bus. READ IDC L also changes the direction of the
                ;7648   ;       BUS TRANCEIVERS thus enabling the data from the I/O BUS onto the
                ;7649   ;       Y BUS.
                ;7650   ;
                ;7651   ; ERROR 2:
                ;7652   ;
                ;7653   ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
                ;7654   ;       PAL. The inputs will be:
                ;7655   ;               CSR 17 H = H
                ;7656   ;               CSR 14 H = H
                ;7657   ;               CSR 12 H = L
                ;7658   ;               CSR 11 H = H
                ;7659   ;               CSR 10 H = H
                ;7660   ;               PORT INSTR H = H
                ;7661   ;       This combination of inputs will assert CLEAR IDC L. This signal is
                ;7662   ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
                ;7663   ;       assert. This signal is inverted to INIT L. INIT L is an input to the
                ;7664   ;       CONTROL STATUS REG PAL. At the next P2 CLOCK L, XFER REQ H will clear.
                ;7665   ;       XFER REG H = L is driven off the board as PORT REQ L = H.
                ;7666   ;       The CPU will execute a SKIP.IF[NO.FAST.INTERRUPT] instruction to
                ;7667   ;       determine the state of PORT REG L.
                ;7668   ;--
                ;7669   ;*****************************************************************************
                ;7670   T.3:
U 07BE, B65E,15 ;7671           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;7672                                                   ; CONTROL AND STATUS WORD
U 07BF, 3E80,15 ;7673           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;7674                                                   ; STATUS WORD - BIT 15
                ;7675                                                   ; INDICATES START OF TEST TO
```

```
                    ;7676                                          ; CONSOLE
U 07C0, 10E0,15     ;7677           MISC [SET.CP.ATTN]             ;ISSUE CPU ATTN TO CONSOLE
                    ;7678   WAIT.T3.0:
U 07C1, 887C,14     ;7679           JMP [WAIT.T3.0]                ;LOOP HERE WAITING FOR
                    ;7680                                          ; CONSOLE TO RESPOND
                    ;7681
U 07C2, 65A0,15     ;7682           CLR LS[PREVIOUS.ERROR]         ;CLEAR PREVIOUS ERROR NUMBER
                    ;7683                                          ; IN LS
                    ;7684
U 07C3, 3642,15     ;7685           MOV LS[CPU] TO WR[0]           ;STORE MODULE CODE IN LS TO
U 07C4, C74A,15     ;7686           BIS LS[IDC] TO WR[0]           ; INDICATE IDC AND CPU
U 07C5, 3E8C,15     ;7687           MOV WR[0] TO LS[MODULE.NUM]    ; MODULES
                    ;7688
                    ;7689
U 07C6, B640,15     ;7690           MOV LS[#1] TO WR[0]            ;SET WR0 = 1
U 07C7, BE82,15     ;7691           MOV WR[0] TO LS[ERROR.NUMBER]  ;SET UP ERROR NUMBER = 1 IN LS
                    ;7692
U 07C8, B782,15     ;7693           MOV LS[BIT7.MASK] TO WR[0]     ;SET MASK TO CHECK ONLY BIT 7
U 07C9, 3E8A,15     ;7694           MOV WR[0] TO LS[ERROR.MASK]
                    ;7695
                    ;7696   LOOP.T3.1:
U 07CA, 17CC,15     ;7697           PORT.CONTROL [CLEAR.IDC]       ;ISSUE INIT TO THE IDC
U 07CB, 17CC,15     ;7698           PORT.CONTROL [CLEAR.IDC]
U 07CC, 17CC,15     ;7699           PORT.CONTROL [CLEAR.IDC]
U 07CD, 9090,15     ;7700           MISC [SET.PORT.I.O]            ;SELECT THE IDC
U 07CE, 9780,15     ;7701           PORT.READ PORT.ADRS[CSR]       ;READ THE CSR
U 07CF, 3B32,15     ;7702           MOV PORT TO LS[PORT0]          ;SAVE THE DATA IN LS
U 07D0, 3732,15     ;7703           MOV LS[PORT0] TO WR[0]         ;SAVE THE RECEIVED DATA
U 07D1, B64E,95     ;7704           MOV LS[BIT7] TO WR[1]          ;SET THE EXPECTED DATA
U 07D2, 0869,3C     ;7705           JSR [CHECK.RESULT]             ;COMPARE THE DATA
U 07D3, 087C,A4     ;7706           JMP [LOOP.T3.1]                ;LOOP HERE IF ERR & LOE IS SET
                    ;7707
                    ;7708   CHECK.XFER.REQ.T3:
                    ;7709   LOOP.T3.2:
U 07D4, 3642,15     ;7710           MOV LS[#2] TO WR[0]            ;SET UP FOR ERROR 2
U 07D5, BE82,15     ;7711           MOV WR[0] TO LS[ERROR.NUMBER]
U 07D6, E58A,15     ;7712           CLR LS[ERROR.MASK]             ;SET TO CHECK ALL BITS
U 07D7, 17CC,15     ;7713           PORT.CONTROL [CLEAR.IDC]       ;ISSUE INIT TO THE IDC
U 07D8, 17CC,15     ;7714           PORT.CONTROL [CLEAR.IDC]
U 07D9, 17CC,15     ;7715           PORT.CONTROL [CLEAR.IDC]
U 07DA, 2F80,15     ;7716           CLR WR[0]                      ;CLR WR 0 FOR FUTURE USE
U 07DB, DB00,15     ;7717           NOP                            ;ALLOW TIME FOR XFER REQ
U 07DC, DB00,15     ;7718           NOP                            ; TO BE RECOGNIZED BY THE
U 07DD, DB00,15     ;7719           NOP                            ; CPU
U 07DE, DB00,1A     ;7720           SKIP.IF[NO.FAST.INTERRUPT]
U 07DF, 2040,15     ;7721           INC WR[0]                      ;INCR WR 0 IF FAST INTERRUPT
                    ;7722                                          ; IS ASSERTED
U 07E0, 2F82,95     ;7723           CLR WR[1]                      ;GET THE EXPECTED DATA
U 07E1, 0869,3C     ;7724           JSR [CHECK.RESULT]             ;COMPARE THE DATA
U 07E2, 087D,44     ;7725           JMP [LOOP.T3.2]                ;LOOP HERE IF ERR & LOE IS SET
U 07E3, 8875,3C     ;7726           JSR [CLEANUP]                  ;CLEANUP CONDITIONS SET BY THIS
                    ;7727                                          ; TEST
                    ;7728   END.T3:                                ;END TEST
                    ;7729
                    ;7730
```

```
                ;7731
                ;7732
                ;7733
```

```
;7734    .PAGE  "Test 4  DISK ADDRESS REGISTER TEST (M8388 IDC MODULE)"
;7735    ;++
;7736    ;
;7737    ; Test Description:
;7738    ;
;7739    ;       This test is designed to verify the integrity of the Disk Address
;7740    ;       Register (DAR).
;7741    ;       The following patterns will be used:
;7742    ;               1. 2AAAA
;7743    ;               2. 55555
;7744    ;               3. 33333
;7745    ;               4. 70F0F
;7746    ;               5. 700FF
;7747    ;               6. 0FFFF
;7748    ;
;7749    ;       The DAR will then be written with 7FFFF. A CLEAR.IDC will then be
;7750    ;       be issued and the DAR checked to insure that all bits cleared.
;7751    ;
;7752    ; Assumptions:
;7753    ;
;7754    ;       It is assumed that the CPU and the Y Bus are fully operational.
;7755    ;
;7756    ; Test Steps:
;7757    ;
;7758    ;       1. Set up error mask, error number and module number in LS
;7759    ;          (for error printouts) and clear the previous error number in LS.
;7760    ;       2. CLEAR.IDC to force the IDC microcode to IDLE.
;7761    ;       3. Move the data pattern from LS to WR 0.
;7762    ;       4. Write the data pattern to the DAR.
;7763    ;       5. Read the DAR.
;7764    ;       6. Check the data.
;7765    ;       7. Get next data pattern and GO TO Step 2 until all data patterns
;7766    ;          have been tested.
;7767    ;       8. Increment the error number.
;7768    ;       9. Write the DAR with 7FFFF.
;7769    ;      10. Issue a CLEAR.IDC and wait for initialize.
;7770    ;      11. Check that the DAR cleared.
;7771    ;      12. End test.
;7772    ;
;7773    ; Errors:
;7774    ;
;7775    ;       ERROR 1 - The DAR failed.
;7776    ;
;7777    ;                 Printout:
;7778    ;                         EXPECTED          RECEIVED
;7779    ;                           DAR               DAR
;7780    ;
;7781    ;       ERROR 2 - The DAR did not clear on a CLEAR.IDC.
;7782    ;                 Printout:
;7783    ;                         EXPECTED          RECEIVED
;7784    ;                           DAR               DAR
;7785    ; Debug:
;7786    ;
;7787    ;  ERROR 1:
;7788    ;
```

```
;7789    ;    WRITE.DAR:
;7790    ;       To allow the data pattern to be written into the DAR, the inputs to
;7791    ;       the PORT RD/WR DECODE PAL will be:
;7792    ;               CSR 17 H = H
;7793    ;               CSR 14 H = L
;7794    ;               CSR 13 H = H
;7795    ;               CSR 12 H = L
;7796    ;               CSR 11 H = L
;7797    ;               CSR 10 H = H
;7798    ;               PORT INSTR H = H
;7799    ;       These inputs will assert WRITE DAR L = L, which will load the
;7800    ;       DAR on the next Current Clk pulse with the data which is on the I/O
;7801    ;       BUS.
;7802    ;
;7803    ;    READ.DAR:
;7804    ;       To read the DAR, the PORT INTERFACE REG PAL and the Port Instruction
;7805    ;       Decoder must operate correctly.
;7806    ;       The CPU first issues a MISC [SET.PORT.I.O] which will assert
;7807    ;       SEL IDC L.
;7808    ;       The inputs to the PORT INTERFACE REGISTER PAL on the
;7809    ;       PORT.READ PORT.ADRS[DAR] instruction will be as follows:
;7810    ;               CSR 17 H = H
;7811    ;               CSR 14 H = L
;7812    ;               CSR 12 H = L
;7813    ;               CSR 11 H = L
;7814    ;               CSR 10 H = H
;7815    ;               PORT INSTR H = H
;7816    ;               CPU P2 H = H
;7817    ;       The resultant outputs will be:
;7818    ;               R2 L = H
;7819    ;               R1 L = H
;7820    ;               R0 L = L
;7821    ;       The CPU then issues a MOV PORT TO LS[] which asserts READ PORT L which
;7822    ;       is an input to the PORT INTERFACE REG PAL. This input will cause
;7823    ;       READ PORT H to assert. READ PORT H is ANDED with SEL IDC H = H and
;7824    ;       SEL ACC L = H and will assert READ IDC L.
;7825    ;       READ IDC L and READ PORT H are the enables for the decoder of R<2:0>.
;7826    ;       R<2:0> will be decoded and will assert SEL DAR L which enables the
;7827    ;       DAR onto the I/O Bus. READ IDC L also changes the direction of the
;7828    ;       BUS TRANCEIVERS thus enabling the data from the I/O BUS onto the
;7829    ;       Y BUS.
;7830    ;
;7831    ;  ERROR 2:
;7832    ;
;7833    ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
;7834    ;       PAL. The inputs will be:
;7835    ;               CSR 17 H = H
;7836    ;               CSR 14 H = H
;7837    ;               CSR 12 H = L
;7838    ;               CSR 11 H = H
;7839    ;               CSR 10 H = H
;7840    ;               PORT INSTR H = H
;7841    ;       This combination of inputs will assert CLEAR IDC L. This signal is
;7842    ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
;7843    ;       assert. INIT H is the RESET input to the Disk Address Register and
```

```
                    ;7844   ;       when asserted will clear all bits in the DAR.
                    ;7845   ;
                    ;7846   ;--
                    ;7847   ;*****************************************************************************
                    ;7848   T.4:
U 07E4, B65E,15     ;7849           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;7850                                                   ; CONTROL AND STATUS WORD
U 07E5, 3E80,15     ;7851           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;7852                                                   ; STATUS WORD - BIT 15
                    ;7853                                                   ; INDICATES START OF TEST TO
                    ;7854                                                   ; CONSOLE
U 07E6, 10E0,15     ;7855           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;7856   WAIT.T4.0:
U 07E7, 087E,74     ;7857           JMP [WAIT.T4.0]                         ;LOOP HERE WAITING FOR
                    ;7858                                                   ; CONSOLE TO RESPOND
                    ;7859
U 07E8, 65A0,15     ;7860           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;7861                                                   ; IN LS
                    ;7862
U 07E9, B64A,15     ;7863           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 07EA, 3E8C,15     ;7864           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;7865
U 07EB, B640,15     ;7866           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 07EC, BE82,15     ;7867           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;7868
U 07ED, 3776,15     ;7869           MOV LS[DAR.MASK] TO WR[0]               ;GET THE ERROR MASK
U 07EE, 3E8A,15     ;7870           MOV WR[0] TO LS[ERROR.MASK]             ;SET UP ERROR MASK TO CHECK
                    ;7871                                                   ; BITS <18:0> DAR
                    ;7872
U 07EF, 17CC,15     ;7873           PORT.CONTROL [CLEAR.IDC]                ;FORCE THE IDC MICROCODE TO
                    ;7874                                                   ; THE IDLE LOOP
U 07F0, 17CC,15     ;7875           PORT.CONTROL [CLEAR.IDC]
U 07F1, 17CC,15     ;7876           PORT.CONTROL [CLEAR.IDC]
                    ;7877   WRITE.DAR.T4.1:
                    ;7878   LOOP.T4.1:
U 07F2, B698,15     ;7879           MOV LS[#AAAAAAAA] TO WR[0]              ;GET THE DATA PATTERN TO WRITE
U 07F3, B776,95     ;7880           MOV LS[#FFF80000] TO WR[1]              ;MASK FOR UPPER BITS
U 07F4, AF42,15     ;7881           BIC WR[1] TO WR[0]                      ;MASK OFF BITS <31:19>
U 07F5, 3F24,15     ;7882           MOV WR[0] TO LS[SAV.DATA.PAT]           ;SAVE THE EXPECTED DATA
U 07F6, 97A4,15     ;7883           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DATA PAT TO THE DAR
                    ;7884
                    ;7885   READ.DAR.T4.1:
U 07F7, 9090,15     ;7886           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 07F8, 1784,15     ;7887           PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 07F9, 3B32,15     ;7888           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;7889                                                   ; SAVE IT IN LS
U 07FA, 3732,15     ;7890           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 07FB, 3724,95     ;7891           MOV LS[SAV.DATA.PAT] TO WR[1]           ;SET UP EXPECTED DATA
U 07FC, 0869,3C     ;7892           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 07FD, 887F,24     ;7893           JMP [LOOP.T4.1]                         ;LOOP HERE IF ERR & LOE IS SET
                    ;7894
                    ;7895   WRITE.DAR.T4.2:
                    ;7896   LOOP.T4.2:
U 07FE, 369A,15     ;7897           MOV LS[#55555555] TO WR[0]              ;GET THE DATA PATTERN TO WRITE
U 07FF, B776,95     ;7898           MOV LS[#FFF80000] TO WR[1]              ;MASK FOR UPPER BITS
```

```
U 0800, AF42,15 ;7899           BIC WR[1] TO WR[0]                          ;MASK OFF BITS <31:19>
U 0801, 3F24,15 ;7900           MOV WR[0] TO LS[SAV.DATA.PAT]               ;SAVE THE EXPECTED DATA
U 0802, 97A4,15 ;7901           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;WRITE THE DATA PAT TO THE DAR
                ;7902
                ;7903   READ.DAR.T4.2:
U 0803, 9090,15 ;7904           MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 0804, 1784,15 ;7905           PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 0805, 3B32,15 ;7906           MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;7907                                                       ; SAVE IT IN LS
U 0806, 3732,15 ;7908           MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 0807, 3724,95 ;7909           MOV LS[SAV.DATA.PAT] TO WR[1]               ;SET UP EXPECTED DATA
U 0808, 0869,3C ;7910           JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 0809, 887F,E4 ;7911           JMP [LOOP.T4.2]                             ;LOOP HERE IF ERR & LOE IS SET
                ;7912
                ;7913   WRITE.DAR.T4.3:
                ;7914   LOOP.T4.3:
U 080A, B6C4,15 ;7915           MOV LS[#33333333] TO WR[0]                  ;GET THE DATA PATTERN TO WRITE
U 080B, B776,95 ;7916           MOV LS[#FFF80000] TO WR[1]                  ;MASK FOR UPPER BITS
U 080C, AF42,15 ;7917           BIC WR[1] TO WR[0]                          ;MASK OFF BITS <31:19>
U 080D, 3F24,15 ;7918           MOV WR[0] TO LS[SAV.DATA.PAT]               ;SAVE THE EXPECTED DATA
U 080E, 97A4,15 ;7919           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;WRITE THE DATA PAT TO THE DAR
                ;7920
                ;7921   READ.DAR.T4.3:
U 080F, 9090,15 ;7922           MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 0810, 1784,15 ;7923           PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 0811, 3B32,15 ;7924           MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;7925                                                       ; SAVE IT IN LS
U 0812, 3732,15 ;7926           MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 0813, 3724,95 ;7927           MOV LS[SAV.DATA.PAT] TO WR[1]               ;SET UP EXPECTED DATA
U 0814, 0869,3C ;7928           JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 0815, 0880,A4 ;7929           JMP [LOOP.T4.3]                             ;LOOP HERE IF ERR & LOE IS SET
                ;7930
                ;7931   WRITE.DAR.T4.4:
                ;7932   LOOP.T4.4:
U 0816, 36C6,15 ;7933           MOV LS[#0F0F0F0F] TO WR[0]                  ;GET THE DATA PATTERN TO WRITE
U 0817, B776,95 ;7934           MOV LS[#FFF80000] TO WR[1]                  ;MASK FOR UPPER BITS
U 0818, AF42,15 ;7935           BIC WR[1] TO WR[0]                          ;MASK OFF BITS <31:19>
U 0819, 3F24,15 ;7936           MOV WR[0] TO LS[SAV.DATA.PAT]               ;SAVE THE EXPECTED DATA
U 081A, 97A4,15 ;7937           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;WRITE THE DATA PAT TO THE DAR
                ;7938
                ;7939   READ.DAR.T4.4:
U 081B, 9090,15 ;7940           MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 081C, 1784,15 ;7941           PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 081D, 3B32,15 ;7942           MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;7943                                                       ; SAVE IT IN LS
U 081E, 3732,15 ;7944           MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 081F, 3724,95 ;7945           MOV LS[SAV.DATA.PAT] TO WR[1]               ;SET UP EXPECTED DATA
U 0820, 0869,3C ;7946           JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 0821, 8881,64 ;7947           JMP [LOOP.T4.4]                             ;LOOP HERE IF ERR & LOE IS SET
                ;7948
                ;7949   WRITE.DAR.T4.5:
                ;7950   LOOP.T4.5:
U 0822, B6C8,15 ;7951           MOV LS[#00FF00FF] TO WR[0]                  ;GET THE DATA PATTERN TO WRITE
U 0823, B776,95 ;7952           MOV LS[#FFF80000] TO WR[1]                  ;MASK FOR UPPER BITS
U 0824, AF42,15 ;7953           BIC WR[1] TO WR[0]                          ;MASK OFF BITS <31:19>
```

```
U 0825, 3F24,15 ;7954           MOV WR[0] TO LS[SAV.DATA.PAT]          ;SAVE THE EXPECTED DATA
U 0826, 97A4,15 ;7955           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]   ;WRITE THE DATA PAT TO THE DAR
                ;7956
                ;7957   READ.DAR.T4.5:
U 0827, 9090,15 ;7958           MISC [SET.PORT.I.O]                    ;SELECT THE IDC
U 0828, 1784,15 ;7959           PORT.READ PORT.ADRS[DAR]               ;SET UP TO READ THE DAR
U 0829, 3B32,15 ;7960           MOV PORT TO LS[PORT0]                  ;READ THE DATA FROM DAR AND
                ;7961                                                  ; SAVE IT IN LS
U 082A, 3732,15 ;7962           MOV LS[PORT0] TO WR[0]                 ;SET UP RECEIVED DATA
U 082B, 3724,95 ;7963           MOV LS[SAV.DATA.PAT] TO WR[1]          ;SET UP EXPECTED DATA
U 082C, 0869,3C ;7964           JSR [CHECK.RESULT]                     ;CHECK THE DATA
U 082D, 0882,24 ;7965           JMP [LOOP.T4.5]                        ;LOOP HERE IF ERR & LOE IS SET
                ;7966
                ;7967   WRITE.DAR.T4.6:
                ;7968   LOOP.T4.6:
U 082E, B772,15 ;7969           MOV LS[#0000FFFF] TO WR[0]             ;GET THE DATA PATTERN TO WRITE
U 082F, B776,95 ;7970           MOV LS[#FFF80000] TO WR[1]             ;MASK FOR UPPER BITS
U 0830, AF42,15 ;7971           BIC WR[1] TO WR[0]                     ;MASK OFF BITS <31:19>
U 0831, 3F24,15 ;7972           MOV WR[0] TO LS[SAV.DATA.PAT]          ;SAVE THE EXPECTED DATA
U 0832, 97A4,15 ;7973           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]   ;WRITE THE DATA PAT TO THE DAR
                ;7974
                ;7975   READ.DAR.T4.6:
U 0833, 9090,15 ;7976           MISC [SET.PORT.I.O]                    ;SELECT THE IDC
U 0834, 1784,15 ;7977           PORT.READ PORT.ADRS[DAR]               ;SET UP TO READ THE DAR
U 0835, 3B32,15 ;7978           MOV PORT TO LS[PORT0]                  ;READ THE DATA FROM DAR AND
                ;7979                                                  ; SAVE IT IN LS
U 0836, 3732,15 ;7980           MOV LS[PORT0] TO WR[0]                 ;SET UP RECEIVED DATA
U 0837, 3724,95 ;7981           MOV LS[SAV.DATA.PAT] TO WR[1]          ;SET UP EXPECTED DATA
U 0838, 0869,3C ;7982           JSR [CHECK.RESULT]                     ;CHECK THE DATA
U 0839, 0882,E4 ;7983           JMP [LOOP.T4.6]                        ;LOOP HERE IF ERR & LOE IS SET
                ;7984
                ;7985   CHECK.CLEAR.IDC:
U 083A, FF82,15 ;7986           INC LS[ERROR.NUMBER]                   ;ERROR 2
                ;7987
                ;7988   LOOP.T4.7:
U 083B, B69E,15 ;7989           MOV LS[#FFFFFFFF] TO WR[0]             ;GET ALL ONES TO WRITE
U 083C, 97A4,15 ;7990           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]   ;WRITE TO THE DAR
U 083D, 17CC,15 ;7991           PORT.CONTROL [CLEAR.IDC]               ;ISSUE INIT TO THE IDC
U 083E, 17CC,15 ;7992           PORT.CONTROL [CLEAR.IDC]
U 083F, 17CC,15 ;7993           PORT.CONTROL [CLEAR.IDC]
U 0840, 9090,15 ;7994           MISC [SET.PORT.I.O]                    ;SELECT THE IDC
U 0841, 1784,15 ;7995           PORT.READ PORT.ADRS[DAR]               ;SET UP TO READ THE DAR
U 0842, 3B32,15 ;7996           MOV PORT TO LS[PORT0]                  ;READ THE DATA FROM DAR AND
                ;7997                                                  ; SAVE IT IN LS
U 0843, 3732,15 ;7998           MOV LS[PORT0] TO WR[0]                 ;SET UP RECEIVED DATA
U 0844, 2F82,95 ;7999           CLR WR[1]                              ;SET UP THE EXPECTED DATA
U 0845, 0869,3C ;8000           JSR [CHECK.RESULT]                     ;COMPARE THE DATA
U 0846, 8883,B4 ;8001           JMP [LOOP.T4.7]                        ;LOOP HERE IF ERR & LOE IS SET
U 0847, 8875,3C ;8002           JSR [CLEANUP]                          ;CLEAN UP CONDITIONS SET BY
                ;8003                                                  ; THIS TEST
                ;8004   END.T4:                                        ;END TEST
                ;8005
                ;8006
```

```
;8007   .PAGE  "Test 5  CONTROL STATUS REGISTER TEST (M8388 IDC MODULE)"
;8008   ;++
;8009   ;
;8010   ; Test Description:
;8011   ;
;8012   ;       This test is designed to test the writable bits of the Control Status
;8013   ;       Register (CSR). The bits that tested are <3:1>,<6>,<8>,<9>,<22>,<23>,
;8014   ;       and <25>, <29:27>. The data patterns that will be used are designed
;8015   ;       such that every writable bit changes with respect to every other
;8016   ;       writable bit.
;8017   ;       Bit <7>, CRDY, is set in every data pattern so that the  IDC microcode
;8018   ;       will remain in the IDLE LOOP.
;8019   ;       The data patterns are as follows:
;8020   ;               1. 288002C4
;8021   ;               2. 1240018A
;8022   ;               3. 0A000386
;8023   ;               4. 3A0000CE
;8024   ;               5. 004003CE
;8025   ;
;8026   ;       This test will then verify that CSR bits <23:22> are cleared when
;8027   ;       a CLEAR.IDC is executed. Each bit must be tested independently
;8028   ;       because CSR bit <22> is an inhibit for CSR bit <23>. CSR <CRDY>
;8029   ;       must be set during this testing to insure that the IDC microcode
;8030   ;       remains in the IDLE LOOP.
;8031   ;
;8032   ;
;8033   ; Assumptions:
;8034   ;
;8035   ;       It is assumed that the CPU and the Y Bus are fully operational.
;8036   ;
;8037   ; Test Steps:
;8038   ;
;8039   ;       1. Set up error mask, error number and module number in LS
;8040   ;          (for error printouts) and clear the previous error number in LS.
;8041   ;       2. Move the data pattern from LS to WR 0.
;8042   ;       3. Write the data pattern to the CSR.
;8043   ;       4. Read the CSR.
;8044   ;       5. Check the data.
;8045   ;       6. Get next data pattern and GO TO Step 2 until all data patterns
;8046   ;          have been tested.
;8047   ;       7. Increment the error number.
;8048   ;       8. Write a one to CSR bit <22>.
;8049   ;       9. Issue a CLEAR.IDC.
;8050   ;      10. Read CSR bit <22> to insure that it cleared.
;8051   ;      11. Increment the error number.
;8052   ;      12. Write a one to CSR bit <23>.
;8053   ;      13. Issue a CLEAR.IDC.
;8054   ;      14. Read CSR bit <23> to insure that it cleared.
;8055   ;      15. End test.
;8056   ;
;8057   ; Errors:
;8058   ;
;8059   ;               Printout:
;8060   ;                       EXPECTED        RECEIVED
;8061   ;                         CSR             CSR
```

```
;8062    ;
;8063    ;       ERROR 1 - The CSR failed.
;8064    ;
;8065    ;       ERROR 2 - CSR bit <22> did not clear when a CLEAR.IDC was executed.
;8066    ;
;8067    ;       ERROR 3 - CSR bit <23> did not clear when a CLEAR.IDC was executed.
;8068    ;
;8069    ; Debug:
;8070    ;
;8071    ;  ERROR 1:
;8072    ;
;8073    ;   WRITE.CSR:
;8074    ;       To allow the data pattern to be written into the CSR, the inputs to
;8075    ;       the PORT RD/WR DECODE PAL will be:
;8076    ;               CSR 17 H = H
;8077    ;               CSR 14 H = L
;8078    ;               CSR 13 H = H
;8079    ;               CSR 12 H = L
;8080    ;               CSR 11 H = L
;8081    ;               CSR 10 H = L
;8082    ;               PORT INSTR H = H
;8083    ;       These inputs will assert WRITE CSR L = L, which will load the
;8084    ;       CSR on the next P2 CLOCK pulse with the data which is on the I/O Bus.
;8085    ;
;8086    ;   READ.CSR:
;8087    ;       To read the CSR, the PORT INTERFACE REG PAL and the Port Instruction
;8088    ;       Decoder must operate correctly.
;8089    ;       The CPU first issues a MISC [SET.PORT.I.O] which will assert
;8090    ;       SEL IDC L.
;8091    ;       The inputs to the PORT INTERFACE REGISTER PAL on the
;8092    ;       PORT.READ PORT.ADRS[CSR] instruction will be as follows:
;8093    ;               CSR 17 H = H
;8094    ;               CSR 14 H = L
;8095    ;               CSR 12 H = L
;8096    ;               CSR 11 H = L
;8097    ;               CSR 10 H = L
;8098    ;               PORT INSTR H = H
;8099    ;               CPU P2 H = H
;8100    ;       The resultant outputs will be:
;8101    ;               R2 L = H
;8102    ;               R1 L = H
;8103    ;               R0 L = H
;8104    ;       The CPU then issues a MOV PORT TO LS[] which asserts READ PORT L which
;8105    ;       is an input to the PORT INTERFACE REG PAL. This input will cause
;8106    ;       READ PORT H to assert. READ PORT H is ANDED with SEL IDC H = H and
;8107    ;       SEL ACC L = H and will assert READ IDC L.
;8108    ;       READ IDC L and READ PORT H are the enables for the decoder of R<2:0>.
;8109    ;       R<2:0> will be decoded and will assert SEL CSR L which enables the
;8110    ;       CSR onto the I/O Bus. READ IDC L also changes the direction of the
;8111    ;       BUS TRANCEIVERS thus enabling the data from the I/O BUS onto the
;8112    ;       Y BUS.
;8113    ;
;8114    ;  ERROR 2:
;8115    ;
;8116    ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
```

```
                ;8117   ;       PAL. The inputs will be:
                ;8118   ;               CSR 17 H = H
                ;8119   ;               CSR 14 H = H
                ;8120   ;               CSR 12 H = L
                ;8121   ;               CSR 11 H = H
                ;8122   ;               CSR 10 H = H
                ;8123   ;               PORT INSTR H = H
                ;8124   ;       This combination of inputs will assert CLEAR IDC L. This signal is
                ;8125   ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
                ;8126   ;       assert. INIT H is an input to the ONLINE REG PAL and when asserted
                ;8127   ;       will clear CSR <22> (INH SSE).
                ;8128   ;
                ;8129   ;  ERROR 3:
                ;8130   ;
                ;8131   ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
                ;8132   ;       PAL. The inputs will be:
                ;8133   ;               CSR 17 H = H
                ;8134   ;               CSR 14 H = H
                ;8135   ;               CSR 12 H = L
                ;8136   ;               CSR 11 H = H
                ;8137   ;               CSR 10 H = H
                ;8138   ;               PORT INSTR H = H
                ;8139   ;       This combination of inputs will assert CLEAR IDC L. This signal is
                ;8140   ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
                ;8141   ;       assert. INIT H is an input to the ONLINE REG PAL and when asserted
                ;8142   ;       will clear CSR <23> (SSE FLAG).
                ;8143   ;--
                ;8144   ;*******************************************************************************
                ;8145   T.5:
U 0848, B65E,15 ;8146           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;8147                                                   ; CONTROL AND STATUS WORD
U 0849, 3E80,15 ;8148           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;8149                                                   ; STATUS WORD - BIT 15
                ;8150                                                   ; INDICATES START OF TEST TO
                ;8151                                                   ; CONSOLE
U 084A, 10E0,15 ;8152           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;8153   WAIT.T5.0:
U 084B, 0884,B4 ;8154           JMP [WAIT.T5.0]                         ;LOOP HERE WAITING FOR
                ;8155                                                   ; CONSOLE TO RESPOND
                ;8156
U 084C, 65A0,15 ;8157           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;8158                                                   ; IN LS
                ;8159
U 084D, B64A,15 ;8160           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 084E, 3E8C,15 ;8161           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;8162
U 084F, B640,15 ;8163           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0850, BE82,15 ;8164           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;8165
U 0851, B722,15 ;8166           MOV LS[CSR.MASK] TO WR[0]               ;GET THE ERROR MASK
U 0852, 3E8A,15 ;8167           MOV WR[0] TO LS[ERROR.MASK]             ;SET UP ERROR MASK TO CHECK
                ;8168                                                   ; ALL WRITABLE BITS IN THE CSR
                ;8169
U 0853, 17CC,15 ;8170           PORT.CONTROL [CLEAR.IDC]                ;FORCE THE IDC MICROCODE TO
                ;8171                                                   ; THE IDLE LOOP
```

```
U 0854, 17CC,15 ;8172           PORT.CONTROL [CLEAR.IDC]
U 0855, 17CC,15 ;8173           PORT.CONTROL [CLEAR.IDC]
                ;8174   LOOP.T5.1:
U 0856, B778,15 ;8175           MOV LS[CSR.PAT.1] TO WR[0]              ;GET THE DATA PATTERN
                ;8176
                ;8177   WRITE.CSR.T5.1:
U 0857, 17A0,15 ;8178           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE DATA TO THE CSR
                ;8179
                ;8180   READ.CSR.T5.1:
U 0858, 9090,15 ;8181           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 0859, 9780,15 ;8182           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 085A, 3B32,15 ;8183           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8184                                                   ; SAVE IT IN LS
U 085B, 3732,15 ;8185           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 085C, 3778,95 ;8186           MOV LS[CSR.PAT.1] TO WR[1]              ;SET UP EXPECTED DATA
U 085D, 0869,3C ;8187           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 085E, 0885,64 ;8188           JMP [LOOP.T5.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8189
                ;8190   LOOP.T5.2:
U 085F, 377A,15 ;8191           MOV LS[CSR.PAT.2] TO WR[0]              ;GET THE DATA PATTERN
                ;8192
                ;8193   WRITE.CSR.T5.2:
U 0860, 17A0,15 ;8194           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE DATA TO THE CSR
                ;8195
                ;8196   READ.CSR.T5.2:
U 0861, 9090,15 ;8197           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 0862, 9780,15 ;8198           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 0863, 3B32,15 ;8199           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8200                                                   ; SAVE IT IN LS
U 0864, 3732,15 ;8201           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0865, B77A,95 ;8202           MOV LS[CSR.PAT.2] TO WR[1]              ;SET UP EXPECTED DATA
U 0866, 0869,3C ;8203           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0867, 0885,F4 ;8204           JMP [LOOP.T5.2]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8205
                ;8206   LOOP.T5.3:
U 0868, 377C,15 ;8207           MOV LS[CSR.PAT.3] TO WR[0]              ;GET THE DATA PATTERN
                ;8208
                ;8209   WRITE.CSR.T5.3:
U 0869, 17A0,15 ;8210           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE DATA TO THE CSR
                ;8211
                ;8212   READ.CSR.T5.3:
U 086A, 9090,15 ;8213           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 086B, 9780,15 ;8214           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 086C, 3B32,15 ;8215           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8216                                                   ; SAVE IT IN LS
U 086D, 3732,15 ;8217           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 086E, B77C,95 ;8218           MOV LS[CSR.PAT.3] TO WR[1]              ;SET UP EXPECTED DATA
U 086F, 0869,3C ;8219           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0870, 8886,84 ;8220           JMP [LOOP.T5.3]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8221
                ;8222   LOOP.T5.4:
U 0871, B77E,15 ;8223           MOV LS[CSR.PAT.4] TO WR[0]              ;GET THE DATA PATTERN
                ;8224
                ;8225   WRITE.CSR.T5.4:
U 0872, 17A0,15 ;8226           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE DATA TO THE CSR
```

```
                ;8227
                ;8228   READ.CSR.T5.4:
U 0873, 9090,15 ;8229           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 0874, 9780,15 ;8230           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 0875, 3B32,15 ;8231           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8232                                                   ; SAVE IT IN LS
U 0876, 3732,15 ;8233           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0877, 377E,95 ;8234           MOV LS[CSR.PAT.4] TO WR[1]              ;SET UP EXPECTED DATA
U 0878, 0869,3C ;8235           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0879, 0887,14 ;8236           JMP [LOOP.T5.4]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8237
                ;8238   LOOP.T5.5:
U 087A, 3780,15 ;8239           MOV LS[CSR.PAT.5] TO WR[0]              ;GET THE DATA PATTERN
                ;8240
                ;8241   WRITE.CSR.T5.5:
U 087B, 17A0,15 ;8242           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE DATA TO THE CSR
                ;8243
                ;8244   READ.CSR.T5.5:
U 087C, 9090,15 ;8245           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 087D, 9780,15 ;8246           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 087E, 3B32,15 ;8247           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8248                                                   ; SAVE IT IN LS
U 087F, 3732,15 ;8249           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0880, B780,95 ;8250           MOV LS[CSR.PAT.5] TO WR[1]              ;SET UP EXPECTED DATA
U 0881, 0869,3C ;8251           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0882, 8887,A4 ;8252           JMP [LOOP.T5.5]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8253
                ;8254   CHECK.CLEAR22.T5:
U 0883, B784,15 ;8255           MOV LS[BIT22.MASK] TO WR[0]             ;GET MASK TO CHECK BIT 22
U 0884, 3E8A,15 ;8256           MOV WR[0] TO LS[ERROR.MASK]             ;SET IT
U 0885, FF82,15 ;8257           INC LS[ERROR.NUMBER]                    ;INCREMENT TO ERROR 2
                ;8258
                ;8259   LOOP.T5.6:
U 0886, B712,15 ;8260           MOV LS[SETCSR.CRDY] TO WR[0]            ;CRDY MUST BE SET
U 0887, 476C,15 ;8261           BIS LS[BIT22] TO WR[0]                  ;DATA TO WRITE IN WR 0
U 0888, 4778,15 ;8262           BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 0889, 17A0,15 ;8263           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE TO THE CSR
U 088A, 17CC,15 ;8264           PORT.CONTROL [CLEAR.IDC]                ;ISSUE INIT TO THE IDC
U 088B, 17CC,15 ;8265           PORT.CONTROL [CLEAR.IDC]
U 088C, 17CC,15 ;8266           PORT.CONTROL [CLEAR.IDC]
U 088D, 9090,15 ;8267           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 088E, 9780,15 ;8268           PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 088F, 3B32,15 ;8269           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;8270                                                   ; SAVE IT IN LS
U 0890, 3732,15 ;8271           MOV LS[PORT0] TO WR[0]                  ;SET UP THE RECEIVED DATA
U 0891, B69C,95 ;8272           MOV LS[ZERO] TO WR[1]                   ;SET THE EXPECTED DATA
U 0892, 0869,3C ;8273           JSR [CHECK.RESULT]                      ;COMPARE THE DATA
U 0893, 8888,64 ;8274           JMP [LOOP.T5.6]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8275
                ;8276   CHECK.CLEAR23.T5:
U 0894, 3786,15 ;8277           MOV LS[BIT23.MASK] TO WR[0]             ;GET MASK TO CHECK BIT 23
U 0895, 3E8A,15 ;8278           MOV WR[0] TO LS[ERROR.MASK]             ;SET IT
U 0896, FF82,15 ;8279           INC LS[ERROR.NUMBER]                    ;INCREMENT TO ERROR 3
                ;8280
                ;8281   LOOP.T5.7:
```

```
U 0897, B712,15 ;8282          MOV LS[SETCSR.CRDY] TO WR[0]          ;CRDY MUST BE SET
U 0898, C76E,15 ;8283          BIS LS[BIT23] TO WR[0]                ;DATA TO WRITE IN WR 0
U 0899, 4778,15 ;8284          BIS LS[BIT28] TO WR[0]                ;SET THE TIMEOUT INHIBIT BIT
U 089A, 17A0,15 ;8285          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;WRITE TO THE CSR
U 089B, 17CC,15 ;8286          PORT.CONTROL [CLEAR.IDC]              ;ISSUE INIT TO THE IDC
U 089C, 17CC,15 ;8287          PORT.CONTROL [CLEAR.IDC]
U 089D, 17CC,15 ;8288          PORT.CONTROL [CLEAR.IDC]
U 089E, 9090,15 ;8289          MISC [SET.PORT.I.O]                   ;SELECT THE IDC
U 089F, 9780,15 ;8290          PORT.READ PORT.ADRS[CSR]              ;SET UP TO READ THE CSR
U 08A0, 3B32,15 ;8291          MOV PORT TO LS[PORT0]                 ;READ THE DATA FROM CSR AND
                ;8292                                                ; SAVE IT IN LS
U 08A1, 3732,15 ;8293          MOV LS[PORT0] TO WR[0]                ;SET UP THE RECEIVED DATA
U 08A2, 2F82,95 ;8294          CLR WR[1]                             ;SET THE EXPECTED DATA
U 08A3, 0869,3C ;8295          JSR [CHECK.RESULT]                    ;COMPARE THE DATA
U 08A4, 8889,74 ;8296          JMP [LOOP.T5.7]                       ;LOOP HERE IF ERR & LOE IS SET
                ;8297
U 08A5, 3678,15 ;8298          MOV LS[BIT28] TO WR[0]
U 08A6, B64E,95 ;8299          MOV LS[BIT7] TO WR[1]
U 08A7, AEC2,15 ;8300          BIS WR[1] TO WR[0]
U 08A8, 17A0,15 ;8301          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;SET WRITE INHIBIT
                ;8302                                                ; AND CRDY
                ;8303
U 08A9, 8875,3C ;8304          JSR [CLEANUP]                         ;CLEANUP THE CONDITIONS SET
                ;8305                                                ; BY THIS TEST
                ;8306  END.T5:                                       ;END TEST
                ;8307
                ;8308
```

```
;8309    .PAGE  "Test 6  CRDY & IDC DIAGNOSTIC MICROCODE ACCESS TEST (M8388 IDC MODULE)"
;8310    ;++
;8311    ;
;8312    ; Test Description:
;8313    ;
;8314    ;       This test is designed to ensure that the IDC microcode will branch
;8315    ;       out of the IDC Idle Loop and into the diagnostic microcode correctly.
;8316    ;       This is done by first setting Bit <MAINT> of the CSR and then
;8317    ;       clearing Bit <CRDY> of the CSR. This should cause the IDC microcode to
;8318    ;       branch to the first IDC Diagnostic microword which will contain a
;8319    ;       micro-instruction with INCR.DAR/ON which will assert UINCR DAR L
;8320    ;       which increments the DAR. The IDC microcode should then jump to the
;8321    ;       diagnostic idle loop. The CPU will then read the DAR to insure
;8322    ;       that it was incremented.
;8323    ;
;8324    ;       This test will verify that CSR <CRDY> can be written and read back
;8325    ;       correctly and that a CLEAR.IDC instruction will set CSR <CRDY>.
;8326    ;
;8327    ;       This test will also verify that the BEN0/CRDY L branch condition and
;8328    ;       the BEN2/MAINT H branch condition work correctly when asserted.
;8329    ;
;8330    ;
;8331    ; Assumptions:
;8332    ;
;8333    ;       It is assumed that the IDC microcode is looping correctly in the
;8334    ;       IDC Idle Loop before this test is executed.
;8335    ;
;8336    ; Test Steps:
;8337    ;
;8338    ;       1. Set up error mask, error number and module number in LS
;8339    ;          (for error printouts) and clear the previous error number in LS.
;8340    ;       2. Clear IDC to force the microcode to IDLE.
;8341    ;       3. Write 0 to DAR to clear.
;8342    ;       4. Set CSR Bit <MAINT> = 1.
;8343    ;       5. Clear CSR <CRDY> and F<2:0>.
;8344    ;       6. NOP until IDC completes microinstruction.
;8345    ;
;8346    ;                                       *******
;8347    ;                                       * IDC *
;8348    ;                                       *******
;8349    ;
;8350    ;               IDC1. Execute an instruction with INCR.DAR/ON.
;8351    ;               IDC2. Jump to diagnostic idle loop (DIAG.IDLE).
;8352    ;
;8353    ;       7. Check CSR <CRDY> = 0.
;8354    ;       8. Increment the error number.
;8355    ;       9. Check result in DAR.
;8356    ;      10. Increment the error number.
;8357    ;      11. Set CSR <CRDY>.
;8358    ;      12. Check CSR <CRDY>.
;8359    ;      13. Increment the error number.
;8360    ;      14. Clear CSR <CRDY>.
;8361    ;      15. Check CSR <CRDY>.
;8362    ;      16. Increment the error number.
;8363    ;      17. Issue a CLEAR.IDC.
```

```
;8364    ;       18. Check that CSR <CRDY> is set.
;8365    ;       19. End test.
;8366    ;
;8367    ; Errors:
;8368    ;
;8369    ;       ERROR 1 - CSR <CRDY> did not clear.
;8370    ;                 Printout:
;8371    ;                         EXPECTED          RECEIVED
;8372    ;                           CSR               CSR
;8373    ;
;8374    ;       ERROR 2 - DAR failed to increment correctly when an IDC microword
;8375    ;                 with INCR.DAR/ON was executed or the microcode did not
;8376    ;                 branch correctly.
;8377    ;
;8378    ;                  Printout:
;8379    ;                         EXPECTED          RECEIVED
;8380    ;                           DAR               DAR
;8381    ;
;8382    ;       ERROR 3 - CSR <CRDY> did not set.
;8383    ;                 Printout:
;8384    ;                         EXPECTED          RECEIVED
;8385    ;                           CSR               CSR
;8386    ;
;8387    ;       ERROR 4 - CSR <CRDY> did not clear.
;8388    ;                 Printout:
;8389    ;                         EXPECTED          RECEIVED
;8390    ;                           CSR               CSR
;8391    ;
;8392    ;       ERROR 5 - CSR <CRDY> did not set when a CLEAR.IDC was issued.
;8393    ;                 Printout:
;8394    ;                         EXPECTED          RECEIVED
;8395    ;                           CSR               CSR
;8396    ;
;8397    ; Debug:
;8398    ;
;8399    ;  ERROR 1:
;8400    ;
;8401    ;       The PORT.WRITE PORT.ADRS[CSR] instruction will be decoded by the
;8402    ;       PORT RD/WR DECODE PAL and will assert WRITE CSR L. This signal
;8403    ;       and BUS IO 07 H are inputs to the CONTROL STATUS REG PAL. BUS IO 07 H
;8404    ;       will be L and when P2 CLOCK L clocks, output CRDY L will be L.
;8405    ;
;8406    ;       When the CSR is read, CRDY is fed through a driver that is enabled by
;8407    ;       SEL CSR L which will be asserted on the decode of the READ CSR
;8408    ;       instruction. This will output CRDY L onto BUS IO 07 H.
;8409    ;
;8410    ;  ERROR 2:
;8411    ;
;8412    ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
;8413    ;       PAL. The inputs will be:
;8414    ;                 CSR 17 H = H
;8415    ;                 CSR 14 H = H
;8416    ;                 CSR 12 H = L
;8417    ;                 CSR 11 H = H
;8418    ;                 CSR 10 H = H
```

```
;8419    ;                PORT INSTR H = H
;8420    ;
;8421    ;       This combination of inputs will assert CLEAR IDC L. This signal is
;8422    ;       an input to the INIT rlip Flop. After 2 P2 CLOCKs, INIT H will
;8423    ;       assert. This signal is an input to the DAR and when asserted will
;8424    ;       reset the DAR = 0.
;8425    ;       When the INCR.DAR/ON microword is executed, UINCR DAR L will assert.
;8426    ;       This will increment the DAR.
;8427    ;
;8428    ;       If the IDC microcode is not at DIAG.IDLE,then either the BEN0/CRDY L
;8429    ;       or the BEN2/MAINT H branch did not execute correctly.
;8430    ;
;8431    ;  ERROR 3:
;8432    ;
;8433    ;       The PORT.WRITE PORT.ADRS[CSR] instruction will be decoded by the
;8434    ;       PORT RD/WR DECODE PAL and will assert WRITE CSR L. This signal
;8435    ;       and BUS IO 07 H are inputs to the CONTROL STATUS REG PAL. BUS IO 07 H
;8436    ;       will be H and when P2 CLOCK L clocks, output CRDY L will be H.
;8437    ;
;8438    ;       When the CSR is read, CRDY is fed through a driver that is enabled by
;8439    ;       SEL CSR L which will be asserted on the decode of the READ CSR
;8440    ;       instruction. This will output CRDY L onto BUS IO 07 H.
;8441    ;
;8442    ;  ERROR 4:
;8443    ;
;8444    ;       The PORT.WRITE PORT.ADRS[CSR] instruction will be decoded by the
;8445    ;       PORT RD/WR DECODE PAL and will assert WRITE CSR L. This signal
;8446    ;       and BUS IO 07 H are inputs to the CONTROL STATUS REG PAL. BUS IO 07 H
;8447    ;       will be L and when P2 CLOCK L clocks, output CRDY L will be L.
;8448    ;
;8449    ;       When the CSR is read, CRDY is fed through a driver that is enabled by
;8450    ;       SEL CSR L which will be asserted on the decode of the READ CSR
;8451    ;       instruction. This will output CRDY L onto BUS IO 07 H.
;8452    ;
;8453    ;  ERROR 5:
;8454    ;
;8455    ;
;8456    ;       The CLEAR.IDC instruction will be decoded in the PORT RD/WR DECODE
;8457    ;       PAL. The inputs will be:
;8458    ;               CSR 17 H = H
;8459    ;               CSR 14 H = H
;8460    ;               CSR 12 H = L
;8461    ;               CSR 11 H = H
;8462    ;               CSR 10 H = H
;8463    ;               PORT INSTR H = H
;8464    ;
;8465    ;       This combination of inputs will assert CLEAR IDC L. This signal is
;8466    ;       an input to the INIT Flip Flop. After 2 P2 CLOCKs, INIT H will
;8467    ;       assert. INIT H is inverted and becomed INIT L. This signal is an input
;8468    ;       to the CONTROL STATUS REG PAL and when asserted will set CRDY L = H.
;8469    ;
;8470    ;       When the CSR is read, CRDY is fed through a driver that is enabled by
;8471    ;       SEL CSR L which will be asserted on the decode of the READ CSR
;8472    ;       instruction. This will output CRDY L onto BUS IO 07 H.
;8473    ;
```

```
                ;8474   ;--
                ;8475   ;*************************************************************************
                ;8476   T.6:
U 08AA, B65E,15 ;8477           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;8478                                                   ; CONTROL AND STATUS WORD
U 08AB, 3E80,15 ;8479           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;8480                                                   ; STATUS WORD - BIT 15
                ;8481                                                   ; INDICATES START OF TEST TO
                ;8482                                                   ; CONSOLE
U 08AC, 10E0,15 ;8483           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;8484   WAIT.T6.0:
U 08AD, 888A,D4 ;8485           JMP [WAIT.T6.0]                         ;LOOP HERE WAITING FOR
                ;8486                                                   ; CONSOLE TO RESPOND
U 08AE, 65A0,15 ;8487           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;8488
U 08AF, B64A,15 ;8489           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 08B0, 3E8C,15 ;8490           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;8491
                ;8492   LOOP.T6.1:
U 08B1, B640,15 ;8493           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 08B2, BE82,15 ;8494           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;8495
U 08B3, B782,15 ;8496           MOV LS[BIT7.MASK] TO WR[0]              ;GET THE ERROR MASK TO CHECK
                ;8497                                                   ; BIT <7>
U 08B4, 3E8A,15 ;8498           MOV WR[0] TO LS[ERROR.MASK]             ;SET UP THE ERROR MASK TO CHECK
                ;8499                                                   ; TO CHECK CSR<CRDY>
                ;8500
U 08B5, 17CC,15 ;8501           PORT.CONTROL [CLEAR.IDC]                ;FORCE THE IDC TO JAM AND THEN
                ;8502                                                   ; ENTER IDLE
U 08B6, 17CC,15 ;8503           PORT.CONTROL [CLEAR.IDC]
U 08B7, 17CC,15 ;8504           PORT.CONTROL [CLEAR.IDC]                ;DAR WILL BE CLEARED
                ;8505
U 08B8, 2F80,15 ;8506           CLR WR[0]
U 08B9, 3720,15 ;8507           MOV LS[SETCSR.MAINT] TO WR[0]           ;GET DATA TO SET CSR MAINT BIT
                ;8508                                                   ; CRDY = 0 AND MAINT = 1
U 08BA, 4778,15 ;8509           BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 08BB, 17A0,15 ;8510           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE TO THE IDC CSR
                ;8511
U 08BC, B730,15 ;8512           MOV LS[#1A] TO WR[0]                    ;SET UP A COUNTER TO NOP UNTIL
                ;8513   NOP.T6:
U 08BD, 2100,15 ;8514           DEC WR[0]                               ; IDC COMPLETES ITS OPERATION
                ;8515           CMP WR[0] WITH LS[ZERO],
U 08BE, 4F9C,35 ;8516            DT(LONG)&SET.ALU.CC
U 08BF, 088B,D1 ;8517           JMP.IF[NEQ] TO [NOP.T6]
                ;8518
                ;8519   ;-------------------------------------------------------------------------
                ;8520   ;-------------------------------------------------------------------------
                ;8521   ;                                *******
                ;8522   ;                                * IDC *
                ;8523   ;                                *******
                ;8524   ;-------------------------------------------------------------------------
                ;8525   ;
                ;8526   ; The IDC should be looping in the IDLE LOOP at this time. When the WRITE to
                ;8527   ;       IDC CSR is issued with CRDY clear and MAINT set, the IDC should branch
                ;8528   ;       out of the IDLE LOOP and then increment the DAR and then go to the
```

```
                ;8529   ;       diagnostic idle loop DIAG.IDLE and remain there because CSR F<2:0> = 0.
                ;8530   ;-------------------------------------------------------------------------------
                ;8531   ;=1
                ;8532   ;TEST.OR.RUN:
                ;8533   ;
                ;8534   ;       BEN2/MAINT,
                ;8535   ;       NAD/DRIVE.TYPE
                ;8536   ;-------------------------------------------------------------------------------
                ;8537   ;=1**
                ;8538   ;UDIAGNOSTICS:
                ;8539   ;
                ;8540   ;       INCR.DAR/ON,                    ;INCREMENT THE DAR AND THEN JUMP TO
                ;8541   ;       NAD/DIAG.IDLE                   ;  THE DIAGNOSTIC IDLE LOOP
                ;8542   ;-------------------------------------------------------------------------------
                ;8543   ;018:
                ;8544   ;=000
                ;8545   ;DIAG.IDLE:
                ;8546   ;
                ;8547   ;       BEN0/F0,
                ;8548   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;8549   ;       BEN2/F2,
                ;8550   ;       NAD/DIAG.IDLE
                ;8551   ;-------------------------------------------------------------------------------
                ;8552   ;-------------------------------------------------------------------------------
                ;8553
U 08C0, 9090,15 ;8554           MISC [SET.PORT.I.0]                     ;SELECT THE PORT TO BUS
U 08C1, 9780,15 ;8555           PORT.READ PORT.ADRS[CSR]                ;READ THE CSR
U 08C2, 3B32,15 ;8556           MOV PORT TO LS[PORT0]                   ;MOV THE DATA TO LS
U 08C3, 3732,15 ;8557           MOV LS[PORT0] TO WR[0]                  ;SAVE THE RECEIVED DATA
U 08C4, 2F82,95 ;8558           CLR WR[1]                               ;GET THE EXPECTED DATA
U 08C5, 0869,3C ;8559           JSR [CHECK.RESULT]                      ;COMPARE
U 08C6, 088B,14 ;8560           JMP [LOOP.T6.1]                         ;LOOP HERE IF ERR & LOE IS SET
U 08C7, 3642,15 ;8561           MOV LS[#2] TO WR[0]                     ;SET UP FOR ERROR 2
U 08C8, BE82,15 ;8562           MOV WR[0] TO  LS[ERROR.NUMBER]
                ;8563
U 08C9, 3776,15 ;8564           MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK BITS
U 08CA, 3E8A,15 ;8565           MOV WR[0] TO LS[ERROR.MASK]             ; <18:0> OF THE DAR
                ;8566
U 08CB, 9090,15 ;8567           MISC [SET.PORT.I.0]                     ;SELECT PORT TO BUS
U 08CC, 1784,15 ;8568           PORT.READ PORT.ADRS[DAR]                ;READ THE DISK ADDRS REG
U 08CD, 3B32,15 ;8569           MOV PORT TO LS[PORT0]                   ;PUT THE REC DATA IN LS
U 08CE, 3732,15 ;8570           MOV LS[PORT0] TO WR[0]                  ;SET UP TO PASS REC DATA
U 08CF, 3640,95 ;8571           MOV LS[#1] TO WR[1]                     ;SET EXP DATA
U 08D0, 0869,3C ;8572           JSR [CHECK.RESULT]                      ;GO CHECK THE DATA
U 08D1, 088B,14 ;8573           JMP [LOOP.T6.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8574
                ;8575   CHECK.CRDYSET.T6:
U 08D2, FF82,15 ;8576           INC LS[ERROR.NUMBER]
U 08D3, B782,15 ;8577           MOV LS[BIT7.MASK] TO WR[0]              ;GET THE MASK TO CHECK ONLY
U 08D4, 3E8A,15 ;8578           MOV WR[0] TO LS[ERROR.MASK]             ; BIT 7
                ;8579
                ;8580   LOOP.T6.2:
U 08D5, 364E,15 ;8581           MOV LS[BIT7] TO WR[0]                   ;BIT 7 <CRDY> SET
U 08D6, 4778,15 ;8582           BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 08D7, 17A0,15 ;8583           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;SET CSR <CRDY>
```

```
U 08D8, 9090,15 ;8584            MISC [SET.PORT.I.0]                    ;SELECT THE PORT TO BUS
U 08D9, 9780,15 ;8585            PORT.READ PORT.ADRS[CSR]               ;READ THE CSR
U 08DA, 3B32,15 ;8586            MOV PORT TO LS[PORT0]                  ;MOV THE DATA TO LS
U 08DB, 3732,15 ;8587            MOV LS[PORT0] TO WR[0]                 ;SAVE THE RECEIVED DATA
U 08DC, B64E,95 ;8588            MOV LS[BIT7] TO WR[1]                  ;SET BIT 7 IN EXPECTED DATA
U 08DD, 0869,3C ;8589            JSR [CHECK.RESULT]                     ;COMPARE THE DATA
U 08DE, 888D,54 ;8590            JMP [LOOP.T6.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;8591
                ;8592    CHECK.CRDYCLR.T6:
U 08DF, FF82,15 ;8593            INC  LS[ERROR.NUMBER]                  ;SET UP FOR ERROR 4
U 08E0, B782,15 ;8594            MOV LS[BIT7.MASK] TO WR[0]             ;GET THE MASK TO CHECK ONLY
U 08E1, 3E8A,15 ;8595            MOV WR[0] TO LS[ERROR.MASK]            ; BIT 7
                ;8596
                ;8597    LOOP.T6.3:
U 08E2, 2F80,15 ;8598            CLR WR[0]                              ;CLR BIT 7
U 08E3, 4778,15 ;8599            BIS LS[BIT28] TO WR[0]                 ;SET THE TIMEOUT INHIBIT BIT
U 08E4, 17A0,15 ;8600            PORT.WRITE PORT.ADRS[CSR] WITH WR[0]   ;CLEAR CSR <CRDY>
U 08E5, 9090,15 ;8601            MISC [SET.PORT.I.0]                    ;SELECT THE PORT TO BUS
U 08E6, 9780,15 ;8602            PORT.READ PORT.ADRS[CSR]               ;READ THE CSR
U 08E7, 3B32,15 ;8603            MOV PORT TO LS[PORT0]                  ;MOV THE DATA TO LS
U 08E8, 3732,15 ;8604            MOV LS[PORT0] TO WR[0]                 ;SAVE THE RECEIVED DATA
U 08E9, 2F82,95 ;8605            CLR WR[1]                              ;GET THE EXPECTED DATA
U 08EA, 0869,3C ;8606            JSR [CHECK.RESULT]                     ;COMPARE THE DATA
U 08EB, 088E,24 ;8607            JMP [LOOP.T6.3]                        ;LOOP HERE IF ERR & LOE IS SET
                ;8608
                ;8609    CHECK.CLEARIDC.T6:
U 08EC, FF82,15 ;8610            INC LS[ERROR.NUMBER]                   ;SET UP FOR ERROR 5
U 08ED, B782,15 ;8611            MOV LS[BIT7.MASK] TO WR[0]             ;GET THE MASK TO CHECK ONLY
U 08EE, 3E8A,15 ;8612            MOV WR[0] TO LS[ERROR.MASK]            ; BIT 7
                ;8613
                ;8614    LOOP.T6.4:
U 08EF, 17CC,15 ;8615            PORT.CONTROL [CLEAR.IDC]               ;INITIALIZE THE IDC
U 08F0, 17CC,15 ;8616            PORT.CONTROL [CLEAR.IDC]
U 08F1, 17CC,15 ;8617            PORT.CONTROL [CLEAR.IDC]
U 08F2, 9090,15 ;8618            MISC [SET.PORT.I.0]                    ;SELECT THE PORT TO BUS
U 08F3, 9780,15 ;8619            PORT.READ PORT.ADRS[CSR]               ;READ THE CSR
U 08F4, 3B32,15 ;8620            MOV PORT TO LS[PORT0]                  ;MOV THE DATA TO LS
U 08F5, 3732,15 ;8621            MOV LS[PORT0] TO WR[0]                 ;SAVE THE RECEIVED DATA
U 08F6, B64E,95 ;8622            MOV LS[BIT7] TO WR[1]                  ;GET THE EXPECTED DATA
U 08F7, 0869,3C ;8623            JSR [CHECK.RESULT]                     ;COMPARE THE DATA
U 08F8, 888E,F4 ;8624            JMP [LOOP.T6.4]                        ;LOOP HERE IF ERR & LOE IS SET
                ;8625
U 08F9, 8875,3C ;8626            JSR [CLEANUP]                          ;CLEANUP CONDITIONS SET BY THIS
                ;8627                                                   ; TEST
                ;8628
                ;8629    END.T6:                                        ;END TEST
                ;8630
                ;8631
                ;8632
                ;8633
```

```
;8634    .PAGE  "Test 7  CSR BITS <F0><F1><F2> BRANCH TEST (M8388 IDC MODULE)"
;8635    ;++
;8636    ;
;8637    ; Test Description:
;8638    ;
;8639    ;       This test will verify BEN0/F0 H, BEN1/F1 H and BEN2/F2 H branch
;8640    ;       conditions. The INCR.DAR function will be used to verify that the
;8641    ;       microcode branches correctly.
;8642    ;
;8643    ;       The data patterns that will be used are:
;8644    ;               CSR F<2:0> = 001
;8645    ;               CSR F<2:0> = 010
;8646    ;               CSR F<2:0> = 100
;8647    ;
;8648    ;
;8649    ; Assumptions:
;8650    ;
;8651    ;       It is assumed that the INCR.DAR function works correctly.
;8652    ;       It is also assumed that the IDC microcode is looping in DIAG.IDLE.
;8653    ;       DIAG.IDLE is defined as follows:
;8654    ;               BEN0/F0 H
;8655    ;               BEN1/F1 H
;8656    ;               BEN2/F2 H
;8657    ;
;8658    ; Test Steps:
;8659    ;
;8660    ;       1. Set up error mask, error number and module number in LS
;8661    ;          (for error printouts) and clear the previous error number in LS.
;8662    ;       2. Force the IDC microcode to DIAG.IDLE.
;8663    ;       3. Clear the DAR.
;8664    ;       4. Load the data pattern into CSR F<2:0>.
;8665    ;       5. Set up CSR bits <CRDY> and <MAINT> to branch to the correct
;8666    ;          microcode routine.
;8667    ;
;8668    ;
;8669    ;                                       *******
;8670    ;                                       * IDC *
;8671    ;                                       *******
;8672    ;
;8673    ;                   IDC1. Execute an instruction with INCR.DAR/ON.
;8674    ;                   IDC2. Return to DIAG.IDLE after the CPU has cleared CSR F<2:0>.
;8675    ;
;8676    ;       6. NOP to allow IDC microcode to execute.
;8677    ;       7. Clear CSR F<2:0>.
;8678    ;       8. Check the DAR = 1.
;8679    ;       9. Increment the error number.
;8680    ;      10. Get the next data pattern and go to step 2 until all data patterns
;8681    ;          have been tested.
;8682    ;      11. Clear IDC.
;8683    ;      12. End test.
;8684    ;
;8685    ; Errors:
;8686    ;
;8687    ;                   Printout:
;8688    ;                           EXPECTED            RECEIVED
```

```
                    ;8689   ;                               DAR                 DAR
                    ;8690   ;
                    ;8691   ;       ERROR 1 - The microcode did not branch correctly with CSR F<2:0> = 001.
                    ;8692   ;
                    ;8693   ;       ERROR 2 - The microcode did not branch correctly with CSR F<2:0> = 010.
                    ;8694   ;
                    ;8695   ;       ERROR 3 - The microcode did not branch correctly with CSR F<2:0> = 100.
                    ;8696   ;
                    ;8697   ;
                    ;8698   ; Debug:
                    ;8699   ;
                    ;8700   ;       The IDC microcode will be looping at DIAG.IDLE which is defined as
                    ;8701   ;       BEN0/F0 H, BEN1/F1 H and BEN2/F2 H. CSR F<2:0> will be clear so the
                    ;8702   ;       microcode will remain at DIAG.IDLE until any of the function bits are
                    ;8703   ;       changed.
                    ;8704   ;
                    ;8705   ;  ERROR 1:
                    ;8706   ;
                    ;8707   ;       The CSR is written with the data pattern, F<2:0>=001.
                    ;8708   ;       BEN0/F0 H will be selected. F0 H will be asserted which will cause the
                    ;8709   ;       microcode to branch to a word which contains INCR.DAR/ON. This will
                    ;8710   ;       assert UINCR DAR L which will increment the DAR.
                    ;8711   ;       The IDC microcode will then jump to DIAG.IDLE.
                    ;8712   ;
                    ;8713   ;  ERROR 2:
                    ;8714   ;
                    ;8715   ;       Same as ERROR 1 except the data pattern is CSR F<2:0>= 010.
                    ;8716   ;       BEN1/F1 H will be selected and F1 H will be asserted.
                    ;8717   ;
                    ;8718   ;  ERROR 3:
                    ;8719   ;
                    ;8720   ;       Same as ERROR 1 except the data pattern is CSR F<2:0>= 100.
                    ;8721   ;       BEN2/F2 H will be selected and F2 H will be asserted.
                    ;8722   ;--
                    ;8723   ;*******************************************************************************
                    ;8724   T.7:
U 08FA, B65E,15     ;8725           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;8726                                                   ; CONTROL AND STATUS WORD
U 08FB, 3E80,15     ;8727           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;8728                                                   ; STATUS WORD - BIT 15
                    ;8729                                                   ; INDICATES START OF TEST TO
                    ;8730                                                   ; CONSOLE
U 08FC, 10E0,15     ;8731           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;8732   WAIT.T7.0:
U 08FD, 888F,D4     ;8733           JMP [WAIT.T7.0]                         ;LOOP HERE WAITING FOR
                    ;8734                                                   ; CONSOLE TO RESPOND
                    ;8735
U 08FE, 65A0,15     ;8736           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;8737                                                   ; IN LS
                    ;8738
U 08FF, B64A,15     ;8739           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0900, 3E8C,15     ;8740           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;8741
                    ;8742
U 0901, B640,15     ;8743           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
```

```
U 0902, BE82,15 ;8744           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;8745
U 0903, 3776,15 ;8746           MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK
U 0904, 3E8A,15 ;8747           MOV WR[0] TO LS[ERROR.MASK]             ; BITS <18:0> OF THE DAR
                ;8748
                ;8749
                ;8750
                ;8751   LOOP.T7.1:
U 0905, 8872,EC ;8752           JSR [DIAG.CODE]                         ;FORCE THE IDC MICROCODE TO
                ;8753                                                   ; THE DIAGNOSTIC IDLE LOOP
                ;8754                                                   ; (DIAG.IDLE)
                ;8755
U 0906, 2F80,15 ;8756           CLR WR[0]                               ;SET UP DATA TO CLR DAR
U 0907, 97A4,15 ;8757           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;8758
U 0908, 3720,15 ;8759           MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
                ;8760                                                   ; THE CORRECT IDC MICRO ROUTINE
U 0909, B702,95 ;8761           MOV LS[SETCSR.F1] TO WR[1]              ;SET FUNC BITS = 1 TO TEST
U 090A, AEC2,15 ;8762           BIS WR[1] TO WR[0]                      ;PUT DATA IN WR 0 FOR WRITE
U 090B, 17A0,15 ;8763           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;8764                                                   ;MAINT=1,CRDY=0,F<2:0>=001
                ;8765
                ;8766   ;-------------------------------------------------------------------------
                ;8767   ;-------------------------------------------------------------------------
                ;8768   ;                               *******
                ;8769   ;                               * IDC *
                ;8770   ;                               *******
                ;8771   ;-------------------------------------------------------------------------
                ;8772   ;018:
                ;8773   ;=000
                ;8774   ;DIAG.IDLE:
                ;8775   ;
                ;8776   ;       BEN0/F0,
                ;8777   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;8778   ;       BEN2/F2,
                ;8779   ;       NAD/DIAG.IDLE
                ;8780   ;-------------------------------------------------------------------------
                ;8781   ;019:
                ;8782   ;=001
                ;8783   ;
                ;8784   ;       BEN0/CRDY.L,
                ;8785   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;8786   ;       NAD/TEST.FUNC1          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;8787   ;-------------------------------------------------------------------------
                ;8788   ;065:
                ;8789   ;=1*1
                ;8790   ;TEST.F1:
                ;8791   ;       INCR.DAR/ON,            ;INCREMENT THE DAR
                ;8792   ;       NAD/XFER.REQ            ;SEND XFER.REQ
                ;8793   ;-------------------------------------------------------------------------
                ;8794
                ;8795
U 090C, B700,15 ;8796           MOV LS[SETCSR.F0] TO WR[0]              ;SET UP THE CLEAR CSR FUNC BITS
U 090D, 17A0,15 ;8797           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 090E, DB00,15 ;8798           NOP                                     ;WAIT FOR IDC TO COMPLETE
```

```
                ;8799
U 090F, 9090,15 ;8800           MISC [SET.PORT.I.0]                     ;SELECT THE PORT TO BUS
U 0910, 1784,15 ;8801           PORT.READ PORT.ADRS[DAR]                ;READ THE DAR
U 0911, 3B32,15 ;8802           MOV PORT TO LS[PORT0]                   ;BRING IN THE DATA
U 0912, 3732,15 ;8803           MOV LS[PORT0] TO WR[0]                  ;SAVE THE RECEIVED DATA
U 0913, 3640,95 ;8804           MOV LS[#1] TO WR[1]                     ;GET THE EXPECTED DATA
U 0914, 0869,3C ;8805           JSR [CHECK.RESULT]                      ;COMPARE THE DATA
U 0915, 8890,54 ;8806           JMP [LOOP.T7.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8807
U 0916, FF82,15 ;8808           INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;8809
                ;8810   LOOP.T7.2:
U 0917, 8872,EC ;8811           JSR [DIAG.CODE]                         ;FORCE THE IDC MICROCODE TO
                ;8812                                                   ; THE DIAGNOSTIC IDLE LOOP
                ;8813                                                   ; (DIAG.IDLE)
                ;8814
U 0918, 2F80,15 ;8815           CLR WR[0]                               ;SET UP DATA TO CLR DAR
U 0919, 97A4,15 ;8816           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;8817
U 091A, 3720,15 ;8818           MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
                ;8819                                                   ; THE CORRECT IDC MICRO ROUTINE
U 091B, B704,95 ;8820           MOV LS[SETCSR.F2] TO WR[1]              ;SET FUNC BITS = 2 TO TEST
U 091C, AEC2,15 ;8821           BIS WR[1] TO WR[0]                      ;SET BITS IN WR[0] FOR WRITE
U 091D, 17A0,15 ;8822           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;8823                                                   ;MAINT=1,CRDY=0,F<2:0>=010
                ;8824   ;-------------------------------------------------------------------------
                ;8825   ;-------------------------------------------------------------------------
                ;8826   ;                               *******
                ;8827   ;                               * IDC *
                ;8828   ;                               *******
                ;8829   ;-------------------------------------------------------------------------
                ;8830   ;018:
                ;8831   ;=000
                ;8832   ;DIAG.IDLE:
                ;8833   ;
                ;8834   ;       BEN0/F0,
                ;8835   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;8836   ;       BEN2/F2,
                ;8837   ;       NAD/DIAG.IDLE
                ;8838   ;-------------------------------------------------------------------------
                ;8839   ;01A:
                ;8840   ;=010
                ;8841   ;
                ;8842   ;       BEN0/CRDY.L,
                ;8843   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;8844   ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;8845   ;-------------------------------------------------------------------------
                ;8846   ;067:
                ;8847   ;=1*1
                ;8848   ;
                ;8849   ;TEST.F2:
                ;8850   ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;8851   ;       NAD/DIAG.IDLE                   ;AND RETURN TO DIAG.IDLE
                ;8852   ;-------------------------------------------------------------------------
                ;8853
```

```
U 091E, B700,15 ;8854          MOV LS[SETCSR.F0] TO WR[0]                ;SET UP THE CLEAR CSR FUNC BITS
U 091F, 17A0,15 ;8855          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
U 0920, D000,15 ;8856          NOP                                       ;WAIT FOR IDC TO COMPLETE
                ;8857
U 0921, 9090,15 ;8858          MISC [SET.PORT.I.0]                       ;SELECT THE PORT TO BUS
U 0922, 1784,15 ;8859          PORT.READ PORT.ADRS[DAR]                  ;READ THE DAR
U 0923, 3B32,15 ;8860          MOV PORT TO LS[PORT0]                     ;BRING IN THE DATA
U 0924, 3732,15 ;8861          MOV LS[PORT0] TO WR[0]                    ;SAVE THE RECEIVED DATA
U 0925, 3640,95 ;8862          MOV LS[#1] TO WR[1]                       ;GET THE EXPECTED DATA
                ;8863
U 0926, 0869,3C ;8864          JSR [CHECK.RESULT]                        ;CHECK THE DATA
U 0927, 8891,74 ;8865          JMP [LOOP.T7.2]                           ;LOOP HERE IF ERR & LOE IS SET
                ;8866
U 0928, FF82,15 ;8867          INC LS[ERROR.NUMBER]                      ;SET UP FOR ERROR 3
                ;8868  LOOP.T7.3:
U 0929, 8872,EC ;8869          JSR [DIAG.CODE]                           ;FORCE THE IDC MICROCODE TO
                ;8870                                                    ; THE DIAGNOSTIC IDLE LOOP
                ;8871                                                    ; (DIAG.IDLE)
                ;8872
U 092A, 2F80,15 ;8873          CLR WR[0]                                 ;SET UP DATA TO CLR DAR
U 092B, 97A4,15 ;8874          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]      ;CLR THE DAR
                ;8875
U 092C, 3720,15 ;8876          MOV LS[SETCSR.MAINT] TO WR[0]             ;SET UP THE CSR TO BRANCH TO
                ;8877                                                    ; THE CORRECT IDC MICRO ROUTINE
U 092D, B708,95 ;8878          MOV LS[SETCSR.F4] TO WR[1]                ;SET FUNC BITS = 4 TO TEST
U 092E, AEC2,15 ;8879          BIS WR[1] TO WR[0]                        ;SET BITS IN WR[0] FOR WRITE
U 092F, 17A0,15 ;8880          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
                ;8881                                                    ;MAINT=1,CRDY=0,F<2:0>=100
                ;8882  ;-----------------------------------------------------------------------------
                ;8883  ;-----------------------------------------------------------------------------
                ;8884  ;                                 *******
                ;8885  ;                                 * IDC *
                ;8886  ;                                 *******
                ;8887  ;-----------------------------------------------------------------------------
                ;8888  ;018:
                ;8889  ;=000
                ;8890  ;DIAG.IDLE:
                ;8891  ;
                ;8892  ;       BEN0/F0,
                ;8893  ;       BEN1/F1,                  ;BRANCH ON THE CSR F<2:0> BITS
                ;8894  ;       BEN2/F2,
                ;8895  ;       NAD/DIAG.IDLE
                ;8896  ;-------------------------------------------------------------------------
                ;8897  ;01C:
                ;8898  ;=100
                ;8899  ;
                ;8900  ;       BEN0/CRDY.L,
                ;8901  ;       BEN2/MAINT,               ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;8902  ;       NAD/TEST.FUNC4            ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;8903  ;-------------------------------------------------------------------------
                ;8904  ;06F:
                ;8905  ;=1*1
                ;8906  ;TEST.F4:
                ;8907  ;       UCMD/CHG.FIFO,                  ;CHANGE FIFO TO USEL FIFO B
                ;8908  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
```

```
                ;8909   ;       NAD/XFER.REQ                    ;SEND XFER REQ
                ;8910   ;-------------------------------------------------------------------------
                ;8911
                ;8912
U 0930, B700,15 ;8913           MOV LS[SETCSR.F0] TO WR[0]              ;SET UP THE CLR THE FUNC BITS
U 0931, 17A0,15 ;8914           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;8915
U 0932, 9090,15 ;8916           MISC [SET.PORT.I.0]                     ;SELECT THE PORT TO BUS
U 0933, 1784,15 ;8917           PORT.READ PORT.ADRS[DAR]                ;READ THE DAR
U 0934, 3B32,15 ;8918           MOV PORT TO LS[PORT0]                   ;BRING IN THE DATA
U 0935, 3732,15 ;8919           MOV LS[PORT0] TO WR[0]                  ;SAVE THE RECEIVED DATA
U 0936, 3640,95 ;8920           MOV LS[#1] TO WR[1]                     ;GET THE EXPECTED DATA
                ;8921
U 0937, 0869,3C ;8922           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0938, 0892,94 ;8923           JMP [LOOP.T7.3]                         ;LOOP HERE IF ERR & LOE IS SET
                ;8924
U 0939, 8875,3C ;8925           JSR [CLEANUP]                           ;GO CLEANUP
                ;8926   END.T7:                                        ;END TEST
                ;8927
                ;8928
                ;8929
                ;8930
```

```
;8931    .PAGE  "Test 8  XFER.REQ-XFER GRANT TEST(M8388 IDC MODULE OR M8390 CPU MODULE)"
;8932    ;++
;8933    ;
;8934    ; Test Description:
;8935    ;
;8936    ;       This test will verify that the XFER REQUEST - XFER GRANT signals
;8937    ;       between the IDC and the CPU operate correctly. The CPU will first set
;8938    ;       up the CSR to cause the IDC microcode to branch to an instruction
;8939    ;       that will issue an XFER.REQ. The CPU will then NOP to allow the IDC
;8940    ;       time to set XFER.REQ. The CPU will then execute a
;8941    ;       SKIP.IF[NO.FAST.INTERRUPT] instruction to check that XFER.REQ is
;8942    ;       asserted.
;8943    ;       The CPU then will issue XFER GRANT which should clear the XFER.REQ.
;8944    ;       The CPU will execute a SKIP.IF[NO.FAST.INTERRUPT] instruction
;8945    ;       to check that the XFER.REQ was cleared.
;8946    ;
;8947    ; Assumptions:
;8948    ;
;8949    ;       It is assumed that the CSR F<2:0> BRANCH TEST has run successfully.
;8950    ;
;8951    ; Test Steps:
;8952    ;
;8953    ;       1. Set up error mask, error number and module number in LS
;8954    ;          (for error printouts) and clear the previous error number in LS.
;8955    ;       2. Force the IDC microcode to DIAG.IDLE.
;8956    ;       3. Set the CSR to branch to the correct IDC microcode routine.
;8957    ;
;8958    ;                                       *******
;8959    ;                                       * IDC *
;8960    ;                                       *******
;8961    ;
;8962    ;                   IDC1. Execute a micro-instruction with UCM = 4 (SET.XFER.REQ)
;8963    ;                         and go to DIAG.WAIT.
;8964    ;
;8965    ;       4. NOP to allow time for IDC to set XFER.REQ.
;8966    ;       5. Clear CSR F<2:0>.
;8967    ;       6. Execute a SKIP.IF[NO.FAST.INTERRRUPT] and check that XFER.REQ
;8968    ;          is asserted.
;8969    ;       7. Increment the error number.
;8970    ;       8. Send XFER.GRANT.
;8971    ;       9. NOP to allow time for XFER.REQ to clear.
;8972    ;      10. Execute a SKIP.IF[NO.FAST.INTERRUPT] and check that XFER.REQ
;8973    ;          was cleared.
;8974    ;      11. Clear IDC.
;8975    ;      12. End test.
;8976    ;
;8977    ;
;8978    ; Errors:
;8979    ;
;8980    ;                   Printout:
;8981    ;                           EXPECTED            RECEIVED
;8982    ;                             N/A                 N/A
;8983    ;
;8984    ;       ERROR 1 - The IDC micro-instruction sequence did not properly execute
;8985    ;                 to cause XFER REQ  to set.
```

```
                ;8986   ;
                ;8987   ;       ERROR 2 - A MISC2 [TRANSFER.GRANT] did not clear the XFER REQ.
                ;8988   ;
                ;8989   ; Debug:
                ;8990   ;
                ;8991   ;  ERROR 1:
                ;8992   ;
                ;8993   ;       At test step IDC1 time, UCM <20:18> = 0100. These bits are then decoded
                ;8994   ;       in the  CONTROL STATUS REG PAL. The inputs to the CONTROL STATUS
                ;8995   ;       REG PAL will be:
                ;8996   ;               UCMD 2 H = H
                ;8997   ;               UCMD 1 H = L
                ;8998   ;               UCMD 0 H = L
                ;8999   ;               INIT L = H
                ;9000   ;               XFER GRANT L = H
                ;9001   ;       When the CONTROL STATUS REG PAL is clocked with P2 CLOCK,
                ;9002   ;       XFER REQ H will assert.
                ;9003   ;       This signal is then driven off the IDC module as PORT XFER REQ.
                ;9004   ;
                ;9005   ;       PORT XFER REQ L is gated through a Flip-Flop on the CPU module and
                ;9006   ;       becomes PORT INT L. This signal is an input to the MUX & INCR CTL PAL
                ;9007   ;       on the CPU module. When decoded, the CPU should not SKIP when
                ;9008   ;       PORT INT L is asserted.
                ;9009   ;
                ;9010   ; ERROR 2 -
                ;9011   ;       The CPU will then clear CSR F<2:0> to cause the IDC microcode to remain
                ;9012   ;       at DIAG.IDLE when the GRANT is issued. A MISC2 [TRANSFER.GRANT]
                ;9013   ;       instruction is then executed. This instruction will be decoded
                ;9014   ;       on the CPU module by the MISC INST DECODER and will assert
                ;9015   ;       XFER GRANT L.
                ;9016   ;
                ;9017   ;       XFER GRANT is an input to the CONTROL STATUS REG PAL.
                ;9018   ;       At the next P2 CLOCK, the output XFER REQ H will deassert which
                ;9019   ;       will cause PORT INT L (an input to the MUX & INCR CTL PAL) on the CPU
                ;9020   ;       module to deassert.
                ;9021   ;       The CPU will then execute a SKIP.IF[NO.FAST.INTERRUPT] instruction
                ;9022   ;       and the instruction will SKIP.
                ;9023   ;--
                ;9024   ;*******************************************************************************
                ;9025   T.8:
U 093A, B65E,15 ;9026           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;9027                                                   ; CONTROL AND STATUS WORD
U 093B, 3E80,15 ;9028           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;9029                                                   ; STATUS WORD - BIT 15
                ;9030                                                   ; INDICATES START OF TEST TO
                ;9031                                                   ; CONSOLE
U 093C, 10E0,15 ;9032           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;9033   WAIT.T8.0:
U 093D, 0893,D4 ;9034           JMP [WAIT.T8.0]                         ;LOOP HERE WAITING FOR
                ;9035                                                   ; CONSOLE TO RESPOND
                ;9036
U 093E, 65A0,15 ;9037           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;9038                                                   ; IN LS
                ;9039
U 093F, 3642,15 ;9040           MOV LS[CPU] TO WR[0]                    ;STORE MODULE CODE IN LS TO
```

```
U 0940, C74A,15 ;9041           BIS LS[IDC] TO WR[0]                    ; INDICATE IDC AND CPU
U 0941, 3E8C,15 ;9042           MOV WR[0] TO LS[MODULE.NUM]             ; MODULES
                ;9043
                ;9044
U 0942, B640,15 ;9045           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0943, BE82,15 ;9046           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;9047
U 0944, E58A,15 ;9048           CLR LS[ERROR.MASK]
U 0945, B66E,15 ;9049           MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0946, 3E80,15 ;9050           MOV WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;9051
U 0947, 8872,EC ;9052           JSR [DIAG.CODE]                         ;FORCE THE IDC MICROCODE TO
                ;9053                                                   ; DIAG.IDLE
                ;9054   LOOP.T8.1:
U 0948, B720,95 ;9055           MOV LS[SETCSR.MAINT] TO WR[1]           ;SET UP THE CSR TO BRANCH
U 0949, B706,15 ;9056           MOV LS[SETCSR.F3] TO WR[0]              ; TO THE CORRECT IDC ROUTINE
U 094A, AEC2,15 ;9057           BIS WR[1] TO WR[0]
U 094B, 17A0,15 ;9058           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;9059                                                   ;MAINT=1,CRDY=0,F<2:0>=011
                ;9060   ;-------------------------------------------------------------------------------
                ;9061   ;-------------------------------------------------------------------------------
                ;9062   ;                               *******
                ;9063   ;                               * IDC *
                ;9064   ;                               *******
                ;9065   ;-------------------------------------------------------------------------------
                ;9066   ;018:
                ;9067   ;=000
                ;9068   ;DIAG.IDLE:
                ;9069   ;
                ;9070   ;       BEN0/F0,
                ;9071   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;9072   ;       BEN2/F2,
                ;9073   ;       NAD/DIAG.IDLE
                ;9074   ;-------------------------------------------------------------------------
                ;9075   ;01B:
                ;9076   ;=011
                ;9077   ;       BEN0/CRDY.L,
                ;9078   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;9079   ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;9080   ;-------------------------------------------------------------------------
                ;9081   ;06D:
                ;9082   ;=1*1
                ;9083   ;TEST.F3:
                ;9084   ;
                ;9085   ;                               ;MUST NOT INCR DAR BETWEEN HERE AND
                ;9086   ;                               ; WHEN RETURNS TO DIAG.WAIT
                ;9087   ;       NAD/XFER.REQ            ;GO SET XFER REQ REQ-GRANT TEST
                ;9088   ;-------------------------------------------------------------------------
                ;9089
U 094C, DB00,15 ;9090           NOP                                     ;WAIT FOR THE IDC
U 094D, DB00,15 ;9091           NOP
U 094E, DB00,15 ;9092           NOP
U 094F, DB00,15 ;9093           NOP
U 0950, DB00,15 ;9094           NOP
U 0951, DB00,1A ;9095           SKIP.IF[NO.FAST.INTERRUPT]              ;CHECK TO SEE IF XFER REQ
```

```
                ;9096                                                   ; ASSERTED
U 0952, 0895,74 ;9097           JMP [XFER.REQ.OK]                       ;XFER REQ ASSERTED
                ;9098
U 0953, 3640,95 ;9099           MOV LS[#1] TO WR[1]                     ;XFER REQ DID NOT ASSERT
U 0954, 369C,15 ;9100           MOV LS[#0] TO WR[0]                     ; FORCE AN ERROR
U 0955, 0869,3C ;9101           JSR [CHECK.RESULT]
U 0956, 8894,84 ;9102           JMP [LOOP.T8.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;9103
                ;9104   XFER.REQ.OK:
U 0957, 2F80,15 ;9105           CLR WR[0]                               ;GO TO CHECK RESULT WITH GOOD
U 0958, 2F82,95 ;9106           CLR WR[1]                               ; DATA TO LOCK IN INTERMITTENT
U 0959, 0869,3C ;9107           JSR [CHECK.RESULT]                      ; ERRORS
U 095A, 8894,84 ;9108           JMP [LOOP.T8.1]                         ;LOOP HERE IF LOOP IS SET
                ;9109
U 095B, FF82,15 ;9110           INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
U 095C, B700,15 ;9111           MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNC BITS
U 095D, 17A0,15 ;9112           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR FNC=0
                ;9113   LOOP.T8.2:
U 095E, 90FA,15 ;9114           MISC2 [TRANSFER.GRANT]                  ;SEND TRANSFER GRANT TO CLR
                ;9115                                                   ; THE XFER REQ
U 095F, DB00,15 ;9116           NOP                                     ;ALLOW TIME FOR XFER REQ TO CLR
U 0960, DB00,1A ;9117           SKIP.IF[NO.FAST.INTERRUPT]              ;XFER REQ STILL ASSERTED?
U 0961, 8896,34 ;9118           JMP [ERROR2.T8]                         ;XFER REQ DID NOT CLEAR
U 0962, 0896,74 ;9119           JMP [XFER.REQ.OK.T8.2]                  ;XFER REQ CLEARED OK
                ;9120
                ;9121   ERROR2.T8:
U 0963, 3640,95 ;9122           MOV LS[#1] TO WR[1]                     ;XFER REQ DID NOT CLR
U 0964, 369C,15 ;9123           MOV LS[#0] TO WR[0]                     ; FORCE AN ERROR
U 0965, 0869,3C ;9124           JSR [CHECK.RESULT]
U 0966, 0895,E4 ;9125           JMP [LOOP.T8.2]                         ;LOOP HERE IF LOOP IS SET
                ;9126
                ;9127   XFER.REQ.OK.T8.2:
U 0967, 2F80,15 ;9128           CLR WR[0]                               ;GO TO CHECK RESULT TO LOCK IN
U 0968, 2F82,95 ;9129           CLR WR[1]                               ;INTERMITTENT ERRORS
U 0969, 0869,3C ;9130           JSR [CHECK.RESULT]
U 096A, 0895,E4 ;9131           JMP [LOOP.T8.2]                         ;LOOP HERE IF LOOP IS SET
                ;9132
                ;9133   CLEANUP.T8:
U 096B, 8875,3C ;9134           JSR [CLEANUP]                           ;GO CLEANUP CONDITIONS SET BY
                ;9135                                                   ; THIS TEST
                ;9136   END.T8:                                         ;END TEST
                ;9137
                ;9138
```

```
;9139    .PAGE  "Test 9  UINCREMENT DAR TEST (M8388 IDC MODULE)"
;9140    ;+++
;9141    ;
;9142    ; Test Description:
;9143    ;
;9144    ;       This test is designed to insure that the DAR increments correctly
;9145    ;       when a UINCR.DAR function is executed. The register will first be
;9146    ;       loaded with zero and checked.  Then the DAR will be incremented once
;9147    ;       and the contents checked until the entire register has been tested.
;9148    ;
;9149    ; Assumptions:
;9150    ;
;9151    ;       It is assumed that the DAR REGISTER TEST, the XFER.REQ - XFER GRANT
;9152    ;       TEST and the CSR F<2:0> BRANCH TEST have run successfully.
;9153    ;
;9154    ; Test Steps:
;9155    ;
;9156    ;       1. Set up error mask, error number and module number in LS
;9157    ;          (for error printouts) and clear the previous error number in LS.
;9158    ;       2. Force the IDC microcode to DIAG.IDLE.
;9159    ;       3. Clear LS[T8]. Used to hold the expected data.
;9160    ;       4. Load the DAR with zero.
;9161    ;       5. Check the DAR = 0.
;9162    ;       6. Increment the error number.
;9163    ;       7. Set up the CSR the branch to the correct IDC microcode routine.
;9164    ;
;9165    ;                                       *******
;9166    ;                                       * IDC *
;9167    ;                                       *******
;9168    ;
;9169    ;
;9170    ;                       IDC1. Execute an instruction with INCR.DAR/ON and issue
;9171    ;                             XFER.REQ to flag the CPU.
;9172    ;
;9173    ;       8. Wait for a XFER.REQ from IDC.
;9174    ;       9. Clear CSR F<2:0> and send XFER GRANT to clear the XFER.REQ.
;9175    ;      10. Check the contents of the DAR.
;9176    ;      11. Repeat steps 7 - 11 until the entire register has been checked.
;9177    ;      12. Clear IDC.
;9178    ;      13. End test.
;9179    ;
;9180    ; Errors:
;9181    ;
;9182    ;
;9183    ;                         Printout:
;9184    ;                                 EXPECTED          RECEIVED
;9185    ;                                   DAR               DAR
;9186    ;
;9187    ;       ERROR 1 - The DAR did not clear.
;9188    ;
;9189    ;       ERROR 2 - The DAR did not increment correctly.
;9190    ;
;9191    ; Debug:
;9192    ;
;9193    ; ERROR 1 -
```

```
                ;9194   ;     WRITE.DAR:
                ;9195   ;        To allow the data pattern to be written into the DAR, the inputs to
                ;9196   ;        the PORT RD/WR DECODE PAL will be:
                ;9197   ;                CSR 17 H = H
                ;9198   ;                CSR 14 H = L
                ;9199   ;                CSR 13 H = H
                ;9200   ;                CSR 12 H = L
                ;9201   ;                CSR 11 H = L
                ;9202   ;                CSR 10 H = H
                ;9203   ;                PORT INSTR H = H
                ;9204   ;        These inputs will assert WRITE DAR L = L, which will load the
                ;9205   ;        DAR on the next Current Clk pulse with the data which is on the I/O
                ;9206   ;        BUS.
                ;9207   ;
                ;9208   ;     READ.DAR:
                ;9209   ;        To read the DAR, the PORT INTERFACE REG PAL and the Port Instruction
                ;9210   ;        Decoder must operate correctly.
                ;9211   ;        The CPU first issues a MISC [SET.PORT.I.O] which will assert
                ;9212   ;        SEL IDC L.
                ;9213   ;        The inputs to the PORT INTERFACE REGISTER PAL on the
                ;9214   ;        PORT.READ PORT.ADRS[DAR] instruction will be as follows:
                ;9215   ;                CSR 17 H = H
                ;9216   ;                CSR 14 H = L
                ;9217   ;                CSR 12 H = L
                ;9218   ;                CSR 11 H = L
                ;9219   ;                CSR 10 H = H
                ;9220   ;                PORT INSTR H = H
                ;9221   ;                CPU P2 H = H
                ;9222   ;        The resultant outputs will be:
                ;9223   ;                R2 L = H
                ;9224   ;                R1 L = H
                ;9225   ;                R0 L = L
                ;9226   ;        The CPU then issues a MOV PORT TO LS[] which asserts READ PORT L which
                ;9227   ;        is an input to the PORT INTERFACE REG PAL. This input will cause
                ;9228   ;        READ PORT H to assert. READ PORT H is ANDED with SEL IDC H = H and
                ;9229   ;        SEL ACC L = H and will assert READ IDC L.
                ;9230   ;        READ IDC L and READ PORT H are the enables for the decoder of R<2:0>.
                ;9231   ;        R<2:0> will be decoded and will assert SEL DAR L which enables the
                ;9232   ;        DAR onto the I/O Bus. READ IDC L also changes the direction of the
                ;9233   ;        BUS TRANCEIVERS thus enabling the data from the I/O BUS onto the
                ;9234   ;        Y BUS.
                ;9235   ;
                ;9236   ; ERROR 2 -
                ;9237   ;
                ;9238   ;        The IDC microcode will branch to instruction 065 which will assert
                ;9239   ;        UINCR DAR L. UINCR DAR L is an input to the DAR and will increment the
                ;9240   ;        DAR on the next P2 CLOCK L.
                ;9241   ;        The CPU will then read the DAR and check the contents.
                ;9242   ;
                ;9243   ;--
                ;9244   ;*****************************************************************************
                ;9245   T.9:
U 096C, B65E,15 ;9246           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;9247                                                   ; CONTROL AND STATUS WORD
U 096D, 3E80,15 ;9248           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
```

```
                ;9249                                   ; STATUS WORD - BIT 15
                ;9250                                   ; INDICATES START OF TEST TO
                ;9251                                   ; CONSOLE
U 096E, 10E0,15 ;9252           MISC [SET.CP.ATTN]      ;ISSUE CPU ATTN TO CONSOLE
                ;9253   WAIT.T9.0:
U 096F, 8896,F4 ;9254           JMP [WAIT.T9.0]         ;LOOP HERE WAITING FOR
                ;9255                                   ; CONSOLE TO RESPOND
                ;9256
U 0970, 65A0,15 ;9257           CLR LS[PREVIOUS.ERROR]  ;CLEAR PREVIOUS ERROR NUMBER
                ;9258                                   ; IN LS
                ;9259
U 0971, B64A,15 ;9260           MOV LS[IDC] TO WR[0]    ;STORE MODULE CODE IN LS TO
U 0972, 3E8C,15 ;9261           MOV WR[0] TO LS[MODULE.NUM] ; INDICATE IDC MODULE
                ;9262
                ;9263
                ;9264
U 0973, 3776,15 ;9265           MOV LS[DAR.MASK] TO WR[0] ;GET THE ERROR MASK TO CHECK
U 0974, 3E8A,15 ;9266           MOV WR[0] TO LS[ERROR.MASK] ; BITS <18:0> OF THE DAR
                ;9267
U 0975, 8872,EC ;9268           JSR [DIAG.CODE]         ;FORCE THE IDC MICROCODE TO
                ;9269                                   ; DIAG.IDLE
U 0976, B795,15 ;9270           MOV LS[#7FFFF] TO WR[2] ;FINAL LOOP COUNT
                ;9271
                ;9272
U 0977, B640,15 ;9273           MOV LS[#1] TO WR[0]     ;SET WR0 = 1
U 0978, BE82,15 ;9274           MOV WR[0] TO LS[ERROR.NUMBER] ;SET UP ERROR NUMBER = 1 IN LS
                ;9275
U 0979, E510,15 ;9276           CLR LS[T8]              ;USE LS[T8] FOR EXPECTED DATA
                ;9277                                   ; AND LOOP COUNTER
                ;9278   LOOP.T9.1:
U 097A, 2F80,15 ;9279           CLR WR[0]               ;GET THE DATA TO CLR THE DAR
U 097B, 97A4,15 ;9280           PORT.WRITE PORT.ADRS[DAR] WITH WR[0] ;CLEAR THE DAR
                ;9281
U 097C, 9090,15 ;9282           MISC [SET.PORT.I.0]     ;SELECT THE IDC
U 097D, 1784,15 ;9283           PORT.READ PORT.ADRS[DAR] ;SET UP TO READ THE DAR
U 097E, 3B32,15 ;9284           MOV PORT TO LS[PORT0]   ;READ THE DATA FROM DAR AND
                ;9285                                   ; SAVE IT IN LS
U 097F, 3732,15 ;9286           MOV LS[PORT0] TO WR[0]  ;SET UP RECEIVED DATA
U 0980, 3610,95 ;9287           MOV LS[T8] TO WR[1]     ;SET UP EXPECTED DATA
U 0981, 0869,3C ;9288           JSR [CHECK.RESULT]      ;CHECK THE DATA
U 0982, 0897,A4 ;9289           JMP [LOOP.T9.1]         ;LOOP HERE IF ERR & LOE IS SET
                ;9290
U 0983, FF82,15 ;9291           INC LS[ERROR.NUMBER]    ;SET UP FOR ERROR 2
                ;9292
U 0984, 8898,84 ;9293           JMP [INCR.DAR.T9.1]
                ;9294   LOOP.T9.2:
U 0985, 7C10,15 ;9295           DEC LS[T8]              ;IF ERROR GO BACK ONE COUNT AND
U 0986, B610,15 ;9296           MOV LS[T8] TO WR[0]     ; LOAD IT INTO THE DAR
U 0987, 97A4,15 ;9297           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]
                ;9298
                ;9299   INCR.DAR.T9.1:
U 0988, 7F10,15 ;9300           INC LS[T8]              ;INCREMENT THE CPU COUNTER
                ;9301
U 0989, B720,95 ;9302           MOV LS[SETCSR.MAINT] TO WR[1] ;SET UP THE CSR TO BRANCH TO
U 098A, 3702,15 ;9303           MOV LS[SETCSR.F1] TO WR[0] ; THE CORRECT ROUTINE
```

```
U 098B, AEC2,15 ;9304          BIS WR[1] TO WR[0]                          ;CSR F<2:0>=001 MAINT=1
U 098C, 17A0,15 ;9305          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;9306                                                      ;MAINT=1,CRDY=0,F<2:0>=001
                ;9307  ;-------------------------------------------------------------------------------
                ;9308  ;-------------------------------------------------------------------------------
                ;9309  ;                                 *******
                ;9310  ;                                 * IDC *
                ;9311  ;                                 *******
                ;9312  ;-------------------------------------------------------------------------------
                ;9313  ;018:
                ;9314  ;=000
                ;9315  ;DIAG.IDLE:
                ;9316  ;
                ;9317  ;       BEN0/F0,
                ;9318  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;9319  ;       BEN2/F2,
                ;9320  ;       NAD/DIAG.IDLE
                ;9321  ;
                ;9322  ;-------------------------------------------------------------------------------
                ;9323  ;019:
                ;9324  ;=001
                ;9325  ;
                ;9326  ;       BEN0/CRDY.L,
                ;9327  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;9328  ;       NAD/TEST.FUNC1          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;9329  ;
                ;9330  ;-------------------------------------------------------------------------------
                ;9331  ;065:
                ;9332  ;=1*1
                ;9333  ;
                ;9334  ;TEST.F1:
                ;9335  ;       INCR.DAR/ON,            ;INCREMENT THE DAR
                ;9336  ;       NAD/XFER.REQ            ;SEND XFER.REQ
                ;9337  ;
                ;9338  ;-------------------------------------------------------------------------------
                ;9339
                ;9340  WAIT.IDC.T9.1:
U 098D, DB00,1A ;9341          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 098E, 8899,04 ;9342          JMP [IDC.DONE.T9.1]                         ;XFER REQ IS ASSERTED
U 098F, 8898,D4 ;9343          JMP [WAIT.IDC.T9.1]                         ;WAIT SOME MORE
                ;9344  IDC.DONE.T9.1:
U 0990, B700,15 ;9345          MOV LS[SETCSR.F0] TO WR[0]                  ;SET UP TO CLR CSR F<2:0>
U 0991, 17A0,15 ;9346          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 0992, 90FA,15 ;9347          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;9348
                ;9349                                                      ; AND FORCE IDC TO DIAG.IDLE
                ;9350  READ.DAR.T9.1:
U 0993, 9090,15 ;9351          MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 0994, 1784,15 ;9352          PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 0995, 3B32,15 ;9353          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;9354                                                      ; SAVE IT IN LS
U 0996, 3732,15 ;9355          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 0997, 3610,95 ;9356          MOV LS[T8] TO WR[1]                         ;SET UP EXPECTED DATA
U 0998, 0869,3C ;9357          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 0999, 0898,54 ;9358          JMP [LOOP.T9.2]                             ;LOOP HERE IF ERR & LOE IS SET
```

```
                    ;9359
                    ;9360           CMP LS[T8] WITH WR[2],                  ;CHECK IF LAST INCREMENT
U 099A, CE11,35     ;9361             DT(LONG)&SET.ALU.CC
U 099B, 8898,81     ;9362           JMP.IF[NEQ] TO [INCR.DAR.T9.1]          ;NOT LAST,GO TO INCR.DAR.T9.1
                    ;9363
U 099C, 8875,3C     ;9364           JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                    ;9365                                                   ; BY THIS TEST
                    ;9366   END.T9:                                         ;END TEST
                    ;9367
                    ;9368
                    ;9369
                    ;9370
                    ;9371
                    ;9372
```

```
;9373    .PAGE  "Test A  BEN0/CRDY AND BEN2/MAINT BRANCH TEST (M8388 IDC MODULE)"
;9374    ;++
;9375    ;
;9376    ; Test Description:
;9377    ;
;9378    ;       This test is designed to verify that the BEN0/CRDY and BEN2/MAINT
;9379    ;       branches function correctly. If the branch executes correctly, the
;9380    ;       DAR will be incremented. The CPU will then read the DAR to verify that
;9381    ;       it was incremented correctly. To verify that the branch incremented
;9382    ;       correctly the DAR will be incremented a different number of times for
;9383    ;       each data pattern:
;9384    ;               Data pattern 1 - increment the DAR 2 times
;9385    ;               Data pattern 2 - increment the DAR 3 times
;9386    ;               Data pattern 3 - increment the DAR 4 times
;9387    ;
;9388    ;       The data patterns are as follows:
;9389    ;
;9390    ;               1. CSR <CRDY> = 0, CSR <MAINT> = 0
;9391    ;               2. CSR <CRDY> = 1, CSR <MAINT> = 1
;9392    ;               3. CSR <CRDY> = 1, CSR <MAINT> = 0
;9393    ;
;9394    ;
;9395    ; Assumptions:
;9396    ;
;9397    ;       It is assumed that the UINCR.DAR function works correctly.
;9398    ;
;9399    ; Test Steps:
;9400    ;
;9401    ;       1. Set up error mask, error number and module number in LS
;9402    ;          (for error printouts) and clear the previous error number in LS.
;9403    ;       2. Force the IDC microcode to DIAG.IDLE.
;9404    ;       3. Get the data pattern for CSR <CRDY> <MAINT>.
;9405    ;       4. Clear the DAR.
;9406    ;       5. Set up the CSR with the data pattern.
;9407    ;
;9408    ;                                       *******
;9409    ;                                       * IDC *
;9410    ;                                       *******
;9411    ;
;9412    ;               IDC1. Increment the DAR (X) number of times depending on the
;9413    ;                     data pattern.
;9414    ;               IDC2. Send XFER REQ to flag the CPU.
;9415    ;
;9416    ;       6. Wait for XFER.REQ from IDC.
;9417    ;       7. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;9418    ;       8. Check the DAR.
;9419    ;       9. Increment the error number.
;9420    ;      10. Get the next data pattern and go to Step 3 until all data patterns
;9421    ;          have been tested.
;9422    ;      11. Clear IDC.
;9423    ;      12. End test.
;9424    ;
;9425    ;
;9426    ;
;9427    ;
```

```
;9428    ; Errors:
;9429    ;
;9430    ;                 Printout:
;9431    ;                         EXPECTED          RECEIVED
;9432    ;                           DAR               DAR
;9433    ;
;9434    ;       ERROR 1 - The microcode did not branch correctly using data pattern 1.
;9435    ;
;9436    ;       ERROR 2 - The microcode did not branch correctly using data pattern 2.
;9437    ;
;9438    ;       ERROR 3 - The microcode did not branch correctly using data pattern 3.
;9439    ;
;9440    ; Debug:
;9441    ;
;9442    ;  ERROR 1:
;9443    ;
;9444    ;       The CSR F<2:0> bits will cause the IDC microcode to branch
;9445    ;       to a word with BEN0/CRDY L and BEN2/MAINT H selected. During
;9446    ;       this microword the inputs to the branch logic will be as follows:
;9447    ;
;9448    ;               The inputs to the BEN0 branch MUX will be:
;9449    ;                       BEN0 S0 H = H
;9450    ;                       BEN1 S1 H = H
;9451    ;                       BEN2 S2 H = L
;9452    ;                       CRDY L = L
;9453    ;               The inputs to the BEN2 branch MUX will be:
;9454    ;                       BEN2 S0 H = H
;9455    ;                       BEN2 S1 H = L
;9456    ;                       BEN2 S2 H = H
;9457    ;                       MAINT H = L
;9458    ;               These conditions will cause the microcode to branch to a
;9459    ;               routine that will increment the DAR 2 times.
;9460    ;
;9461    ; ERROR 2:
;9462    ;
;9463    ;       The CSR F<2:0> bits will cause the IDC microcode to branch
;9464    ;       to a word with BEN0/CRDY L and BEN2/MAINT H selected. During
;9465    ;       this microword the inputs to the branch logic will be as follows:
;9466    ;
;9467    ;               The inputs to the BEN0 branch MUX will be:
;9468    ;                       BEN0 S0 H = H
;9469    ;                       BEN1 S1 H = H
;9470    ;                       BEN2 S2 H = L
;9471    ;                       CRDY L = H
;9472    ;               The inputs to the BEN2 branch MUX will be:
;9473    ;                       BEN2 S0 H = H
;9474    ;                       BEN2 S1 H = L
;9475    ;                       BEN2 S2 H = H
;9476    ;                       MAINT H = L
;9477    ;               These conditions will cause the microcode to branch to a
;9478    ;               routine that will increment the DAR 3 times.
;9479    ;
;9480    ;
;9481    ; ERROR 3:
;9482    ;
```

```
                ;9483   ;       The CSR F<2:0> bits will cause the IDC microcode to branch
                ;9484   ;       to a word with BEN0/CRDY L and BEN2/MAINT H selected. During
                ;9485   ;       this microword the inputs to the branch logic will be as follows:
                ;9486   ;
                ;9487   ;               The inputs to the BEN0 branch MUX wil be:
                ;9488   ;                       BEN0 S0 H = H
                ;9489   ;                       BEN1 S1 H = H
                ;9490   ;                       BEN2 S2 H = L
                ;9491   ;                       CRDY L = L
                ;9492   ;               The inputs to the BEN2 branch MUX will be:
                ;9493   ;                       BEN2 S0 H = H
                ;9494   ;                       BEN2 S1 H = L
                ;9495   ;                       BEN2 S2 H = H
                ;9496   ;                       MAINT H = H
                ;9497   ;               These conditions will cause the microcode to branch to a
                ;9498   ;               routine that will increment the DAR 4 times.
                ;9499   ;--
                ;9500   ;*******************************************************************************
                ;9501   T.A:
U 099D, B65E,15 ;9502           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;9503                                                   ; CONTROL AND STATUS WORD
U 099E, 3E80,15 ;9504           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;9505                                                   ; STATUS WORD - BIT 15
                ;9506                                                   ; INDICATES START OF TEST TO
                ;9507                                                   ; CONSOLE
U 099F, 10E0,15 ;9508           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;9509   WAIT.TA.0:
U 09A0, 889A,04 ;9510           JMP [WAIT.TA.0]                         ;LOOP HERE WAITING FOR
                ;9511                                                   ; CONSOLE TO RESPOND
                ;9512
U 09A1, 65A0,15 ;9513           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;9514                                                   ; IN LS
                ;9515
U 09A2, B64A,15 ;9516           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 09A3, 3E8C,15 ;9517           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;9518
                ;9519
U 09A4, B640,15 ;9520           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 09A5, BE82,15 ;9521           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;9522
U 09A6, 3776,15 ;9523           MOV LS[DAR.MASK] TO WR[0]               ;ERROR MASK TO CHECK BITS
U 09A7, 3E8A,15 ;9524           MOV WR[0] TO LS[ERROR.MASK]             ; <18:0> OF THE DAR
                ;9525
U 09A8, 8872,EC ;9526           JSR [DIAG.CODE]                         ;FORCE THE IDC MICROCODE
                ;9527                                                   ; TO DIAG.IDLE
                ;9528   LOOP.TA.1:
U 09A9, 2F80,15 ;9529           CLR WR[0]                               ;DATA TO CLR THE DAR
U 09AA, 97A4,15 ;9530           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE IT
                ;9531
U 09AB, 3702,15 ;9532           MOV LS[SETCSR.F1] TO WR[0]              ;CLR CSR <CRDY> & <MAINT>
                ;9533                                                   ; AND SET THE FNC BITS TO
                ;9534                                                   ; BRANCH TO THE CORRECT ROUTINE
U 09AC, 17A0,15 ;9535           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;9536                                                   ;MAINT=0,CRDY=0,F<2:0>=001
                ;9537
```

```
                ;9538   ;-------------------------------------------------------------------------------
                ;9539   ;-------------------------------------------------------------------------------
                ;9540   ;                               *******
                ;9541   ;                               * IDC *
                ;9542   ;                               *******
                ;9543   ;-------------------------------------------------------------------------------
                ;9544   ;018:
                ;9545   ;=000
                ;9546   ;DIAG.IDLE:
                ;9547   ;
                ;9548   ;       BEN0/F0,
                ;9549   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;9550   ;       BEN2/F2,
                ;9551   ;       NAD/DIAG.IDLE
                ;9552   ;-------------------------------------------------------------------------------
                ;9553   ;019:
                ;9554   ;=001
                ;9555   ;
                ;9556   ;       BEN0/CRDY.L,
                ;9557   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;9558   ;       NAD/TEST.FUNC1          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;9559   ;
                ;9560   ;-------------------------------------------------------------------------------
                ;9561   ;061:
                ;9562   ;=0*1
                ;9563   ;TEST.INCR.DAR2:
                ;9564   ;       INCR.DAR/ON,            ;INCREMENT THE DAR 2 TIMES BEFORE
                ;9565   ;       NAD/TEST.F1             ; ISSUE XFER REQ
                ;9566   ;-------------------------------------------------------------------------------
                ;9567   ;065:
                ;9568   ;=1*1
                ;9569   ;TEST.F1:
                ;9570   ;       INCR.DAR/ON,            ;INCREMENT THE DAR
                ;9571   ;       NAD/XFER.REQ            ;SET XFER.REQ
                ;9572   ;-------------------------------------------------------------------------------
                ;9573   WAIT.IDC.TA.1:
U 09AD, DB00,1A ;9574           SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 09AE, 089B,04 ;9575           JMP [IDC.DONE.TA.1]                     ;XFER REQ ASSERTED
U 09AF, 089A,D4 ;9576           JMP [WAIT.IDC.TA.1]                     ;WAIT SOME MORE
                ;9577   IDC.DONE.TA.1:
U 09B0, B700,15 ;9578           MOV LS[SETCSR.F0] TO WR[0]              ;GET THE DATA TO CLR FNC BITS
U 09B1, 17A0,15 ;9579           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 09B2, 90FA,15 ;9580           MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;9581   READ.DAR.TA.1:
U 09B3, 9090,15 ;9582           MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 09B4, 1784,15 ;9583           PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 09B5, 3B32,15 ;9584           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;9585                                                   ; SAVE IT IN LS
U 09B6, 3732,15 ;9586           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 09B7, B642,95 ;9587           MOV LS[#2] TO WR[1]                     ;EXPECTED DATA
U 09B8, 0869,3C ;9588           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 09B9, 889A,94 ;9589           JMP [LOOP.TA.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;9590
U 09BA, FF82,15 ;9591           INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;9592
```

```
                ;9593   LOOP.TA.2:
U 09BB, 2F80,15 ;9594           CLR WR[0]                               ;DATA TO CLR THE DAR
U 09BC, 97A4,15 ;9595           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE IT
                ;9596
U 09BD, B712,15 ;9597           MOV LS[SETCSR.CRDY] TO WR[0]            ;GET THE DATA TO SET <CRDY>
U 09BE, B720,95 ;9598           MOV LS[SETCSR.MAINT] TO WR[1]           ;GET THE DATA TO SET <MAINT>
U 09BF, AEC2,15 ;9599           BIS WR[1] TO WR[0]                      ;PUT THE DATA IN WR[0]
U 09C0, B702,95 ;9600           MOV LS[SETCSR.F1] TO WR[1]              ;GET THE DATA TO SET CSR
                ;9601                                                   ; F<2:0> = 001
U 09C1, AEC2,15 ;9602           BIS WR[1] TO WR[0]                      ;PUT THE DATA IN WR[0]
U 09C2, 17A0,15 ;9603           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;9604                                                   ;MAINT=1,CRDY=1,F<2:0>=001
                ;9605   ;-------------------------------------------------------------------------------
                ;9606   ;-------------------------------------------------------------------------------
                ;9607   ;                               *******
                ;9608   ;                               * IDC *
                ;9609   ;                               *******
                ;9610   ;-------------------------------------------------------------------------------
                ;9611   ;018:
                ;9612   ;=000
                ;9613   ;DIAG.IDLE:
                ;9614   ;
                ;9615   ;       BEN0/F0,
                ;9616   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;9617   ;       BEN2/F2,
                ;9618   ;       NAD/DIAG.IDLE
                ;9619   ;-------------------------------------------------------------------------
                ;9620   ;019:
                ;9621   ;=001
                ;9622   ;
                ;9623   ;       BEN0/CRDY.L,
                ;9624   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;9625   ;       NAD/TEST.FUNC1          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;9626   ;-------------------------------------------------------------------------
                ;9627   ;064:
                ;9628   ;=1*0
                ;9629   ;
                ;9630   ;TEST.INCR.DAR3:
                ;9631   ;       INCR.DAR/ON,            ;INCREMENT DAR 3 TIMES BEFORE
                ;9632   ;       NAD/TEST.INCR.DAR2      ; ISSUE XFER REQ
                ;9633   ;-------------------------------------------------------------------------
                ;9634   ;061:
                ;9635   ;=0*1
                ;9636   ;TEST.INCR.DAR2:
                ;9637   ;       INCR.DAR/ON,
                ;9638   ;       NAD/TEST.F1
                ;9639   ;-------------------------------------------------------------------------
                ;9640   ;065:
                ;9641   ;=1*1
                ;9642   ;TEST.F1:
                ;9643   ;       INCR.DAR/ON,
                ;9644   ;       NAD/XFER.REQ            ;SEND XFER.REQ
                ;9645   ;-------------------------------------------------------------------------
                ;9646
                ;9647
```

```
                ;9648   WAIT.IDC.TA.2:
U 09C3, DB00,1A ;9649           SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 09C4, 889C,64 ;9650           JMP [IDC.DONE.TA.2]                     ;XFER REQ ASSERTED
U 09C5, 889C,34 ;9651           JMP [WAIT.IDC.TA.2]                     ;WAIT SOME MORE
                ;9652   IDC.DONE.TA.2:
U 09C6, B700,15 ;9653           MOV LS[SETCSR.F0] TO WR[0]              ;GET THE DATA TO CLR FNC BITS
U 09C7, 17A0,15 ;9654           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 09C8, 90FA,15 ;9655           MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;9656
                ;9657   READ.DAR.TA.2:
U 09C9, 9090,15 ;9658           MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 09CA, 1784,15 ;9659           PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 09CB, 3B32,15 ;9660           MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;9661                                                   ; SAVE IT IN LS
U 09CC, 3732,15 ;9662           MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 09CD, 3788,95 ;9663           MOV LS[#3] TO WR[1]                     ;EXPECTED DATA
U 09CE, 0869,3C ;9664           JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 09CF, 889B,B4 ;9665           JMP [LOOP.TA.2]                         ;LOOP HERE IF ERR & LOE IS SET
                ;9666
U 09D0, FF82,15 ;9667           INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 3
                ;9668
                ;9669   LOOP.TA.3:
U 09D1, 2F80,15 ;9670           CLR WR[0]                               ;DATA TO CLR THE DAR
U 09D2, 97A4,15 ;9671           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE IT
                ;9672
U 09D3, 3712,95 ;9673           MOV LS[SETCSR.CRDY] TO WR[1]            ;GET THE DATA TO SET <CRDY>
U 09D4, 3702,15 ;9674           MOV LS[SETCSR.F1] TO WR[0]              ;GET THE DATA TO SET CSR
                ;9675                                                   ; F<2:0> = 001
U 09D5, AEC2,15 ;9676           BIS WR[1] TO WR[0]                      ;PUT THE DATA IN WR[0]
U 09D6, 17A0,15 ;9677           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;9678                                                   ;CRDY=1,MAINT=0,F<2:0>=001
                ;9679   ;-------------------------------------------------------------------------------
                ;9680   ;-------------------------------------------------------------------------------
                ;9681   ;                               *******
                ;9682   ;                               * IDC *
                ;9683   ;                               *******
                ;9684   ;-------------------------------------------------------------------------
                ;9685   ;018:
                ;9686   ;=000
                ;9687   ;DIAG.IDLE:
                ;9688   ;
                ;9689   ;       BEN0/F0,
                ;9690   ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;9691   ;       BEN2/F2,
                ;9692   ;       NAD/DIAG.IDLE
                ;9693   ;-------------------------------------------------------------------------
                ;9694   ;019:
                ;9695   ;=001
                ;9696   ;
                ;9697   ;       BEN0/CRDY.L,
                ;9698   ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;9699   ;       NAD/TEST.FUNC1          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;9700   ;-------------------------------------------------------------------------
                ;9701   ;060:
                ;9702   ;=0*0
```

```
                ;9703   ;TEST.FUNC1:
                ;9704   ;
                ;9705   ;TEST.INCR.DAR4:
                ;9706   ;       INCR.DAR/ON,            ;INCREMENT DAR 4 TIMES BEFORE ISSUE
                ;9707   ;       NAD/TEST.INCR.DAR3      ; XFER REQ
                ;9708   ;-----------------------------------------------------------------------
                ;9709   ;064:
                ;9710   ;=1*0
                ;9711   ;TEST.INCR.DAR3:
                ;9712   ;       INCR.DAR/ON,
                ;9713   ;       NAD/TEST.INCR.DAR2
                ;9714   ;-----------------------------------------------------------------------
                ;9715   ;061:
                ;9716   ;=0*1
                ;9717   ;TEST.INCR.DAR2:
                ;9718   ;       INCR.DAR/ON,
                ;9719   ;       NAD/TEST.F1
                ;9720   ;-----------------------------------------------------------------------
                ;9721   ;065:
                ;9722   ;=1*1
                ;9723   ;TEST.F1:
                ;9724   ;       INCR.DAR/ON,
                ;9725   ;       NAD/XFER.REQ            ;SET XFER.REQ
                ;9726   ;-----------------------------------------------------------------------
                ;9727
                ;9728   WAIT.IDC.TA.3:
U 09D7, DB00,1A ;9729           SKIP.IF[NO.FAST.INTERRUPT]          ;WAIT FOR XFER REQ FROM IDC
U 09D8, 089D,A4 ;9730           JMP [IDC.DONE.TA.3]                 ;XFER REQ ASSERTED
U 09D9, 889D,74 ;9731           JMP [WAIT.IDC.TA.3]                 ;WAIT SOME MORE
                ;9732   IDC.DONE.TA.3:
U 09DA, B700,15 ;9733           MOV LS[SETCSR.F0] TO WR[0]          ;GET THE DATA TO CLR FNC BITS
U 09DB, 17A0,15 ;9734           PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;WRITE THE CSR
U 09DC, 90FA,15 ;9735           MISC2 [TRANSFER.GRANT]              ;SEND GRANT TO CLR THE XFER REQ
                ;9736   READ.DAR.TA.3:
U 09DD, 9090,15 ;9737           MISC [SET.PORT.I.O]                 ;SELECT THE IDC
U 09DE, 1784,15 ;9738           PORT.READ PORT.ADRS[DAR]            ;SET UP TO READ THE DAR
U 09DF, 3B32,15 ;9739           MOV PORT TO LS[PORT0]               ;READ THE DATA FROM DAR AND
                ;9740                                               ; SAVE IT IN LS
U 09E0, 3732,15 ;9741           MOV LS[PORT0] TO WR[0]              ;SET UP RECEIVED DATA
U 09E1, B644,95 ;9742           MOV LS[#4] TO WR[1]                 ;EXPECTED DATA
U 09E2, 0869,3C ;9743           JSR [CHECK.RESULT]                  ;CHECK THE DATA
U 09E3, 889D,14 ;9744           JMP [LOOP.TA.3]                     ;LOOP HERE IF ERR & LOE IS SET
                ;9745
U 09E4, 8875,3C ;9746           JSR [CLEANUP]                       ;CLEANUP THE CONDITIONS SET BY
                ;9747                                               ; THIS TEST
                ;9748   END.TA:                                     ;END TEST
                ;9749
                ;9750
                ;9751
                ;9752
```

```
                ;9753   .PAGE  "Test B  CSR WRITE INHIBIT BIT <28>  TEST (M8388 IDC MODULE)"
                ;9754   ;++
                ;9755   ; Test Description:
                ;9756   ;
                ;9757   ;       CSR WRITE INHIBIT BIT <28> is also used to disable timeouts on the
                ;9758   ;       IDC module. This test is designed to insure the bit does indeed
                ;9759   ;       disable timeouts. This will done by setting up the conditions that
                ;9760   ;       would normally cause a timeout with the timeout inhibit bit (CSR <28>)
                ;9761   ;       set.The CPU will then check that a timeout does not occur.
                ;9762   ;       Timeouts on the IDC need to be disabled to allow single stepping.
                ;9763   ;
                ;9764   ; Assumptions:
                ;9765   ;
                ;9766   ;       It is assumed that all previous tests have been run successfully.
                ;9767   ;
                ;9768   ; Test Steps:
                ;9769   ;
                ;9770   ;       1. Set up error mask, error number and module number in LS
                ;9771   ;          (for error printouts) and clear the previous error number in LS.
                ;9772   ;       2. Force the IDC to DIAG.IDLE.
                ;9773   ;       3. Set CSR <28> to inhibit timeouts, set CSR <MAINT> so the IDC
                ;9774   ;          microcode will branch to DIAG.IDLE and clear CSR <CRDY> to start
                ;9775   ;          the timer.
                ;9776   ;       4. Set up a loop to wait 400ms.
                ;9777   ;       5. Check CSR <CRDY> = 0. (If the IDC timed out, the IDC will JAM and
                ;9778   ;          the microcode will set CSR <CRDY>.)
                ;9779   ;       6. Clear IDC.
                ;9780   ;       7. End test.
                ;9781   ;
                ;9782   ; Errors:
                ;9783   ;
                ;9784   ;                   Printout:
                ;9785   ;                           EXPECTED          RECEIVED
                ;9786   ;                             CSR               CSR
                ;9787   ;
                ;9788   ;       ERROR 1 - The IDC timed out with CSR <28> WRITE and TIMEOUT INHIBIT
                ;9789   ;                 set.
                ;9790   ;
                ;9791   ; Debug:
                ;9792   ;
                ;9793   ;       CSR <CRDY> is cleared with CSR <MAINT> set which will cause the IDC
                ;9794   ;       microcode to branch to DIAG.IDLE. Clearing CSR <CRDY> also will start
                ;9795   ;       the TIMEOUT timer. CSR <28> is set. CSR <28> is gated with the output
                ;9796   ;       of the TIMER one-shot and will prohibit the IDC from JAMMING when the
                ;9797   ;       one-shot is fired. If the IDC does JAM, the IDC microcode will set
                ;9798   ;       CSR <CRDY>.
                ;9799   ;--
                ;9800   ;*******************************************************************************
                ;9801   T.B:
U 09E5, B65E,15 ;9802           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;9803                                                   ; CONTROL AND STATUS WORD
U 09E6, 3E80,15 ;9804           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;9805                                                   ; STATUS WORD - BIT 15
                ;9806                                                   ; INDICATES START OF TEST TO
                ;9807                                                   ; CONSOLE
```

```
U 09E7, 10E0,15 ;9808            MISC [SET.CP.ATTN]                          ;ISSUE CPU ATTN TO CONSOLE
                ;9809    WAIT.TB.0:
U 09E8, 889E,84 ;9810            JMP [WAIT.TB.0]                             ;LOOP HERE WAITING FOR
                ;9811                                                        ; CONSOLE TO RESPOND
                ;9812
U 09E9, 65A0,15 ;9813            CLR LS[PREVIOUS.ERROR]                      ;CLEAR PREVIOUS ERROR NUMBER
                ;9814                                                        ; IN LS
                ;9815
U 09EA, B64A,15 ;9816            MOV LS[IDC] TO WR[0]                        ;STORE MODULE CODE IN LS TO
U 09EB, 3E8C,15 ;9817            MOV WR[0] TO LS[MODULE.NUM]                 ; INDICATE IDC MODULE
                ;9818
                ;9819
U 09EC, B640,15 ;9820            MOV LS[#1] TO WR[0]                         ;SET WR0 = 1
U 09ED, BE82,15 ;9821            MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP ERROR NUMBER = 1 IN LS
                ;9822
U 09EE, B782,15 ;9823            MOV LS[BIT7.MASK] TO WR[0]
U 09EF, 3E8A,15 ;9824            MOV WR[0] TO LS[ERROR.MASK]                 ;SET UP MASK TO CHECK BIT <7>
                ;9825
                ;9826
                ;9827    LOOP.TB.1:
U 09F0, 17CC,15 ;9828            PORT.CONTROL [CLEAR.IDC]                    ;JAM THE IDC TO IDLE
U 09F1, 17CC,15 ;9829            PORT.CONTROL [CLEAR.IDC]
U 09F2, 17CC,15 ;9830            PORT.CONTROL [CLEAR.IDC]
                ;9831
U 09F3, 3720,15 ;9832            MOV LS[SETCSR.MAINT] TO WR[0]               ;SET UP THE CSR..SET MAINT,
                ;9833                                                        ; CLEAR CRDY
U 09F4, B678,95 ;9834            MOV LS[BIT28] TO WR[1]                      ;SET WRITE INHIBIT
                ;9835
U 09F5, AEC2,15 ;9836            BIS WR[1] TO WR[0]
U 09F6, 17A0,15 ;9837            PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;MAINT=1,CRDY=0,INHIBIT=1
                ;9838    ;-----------------------------------------------------------------------------
                ;9839    ;THE IDC MICROCODE WILL BRANCH FROM THE IDLE LOOP TO DIAG.IDLE AND WILL
                ;9840    ;REMAIN AT DIAG.IDLE UNTIL THE CLEANUP ROUITNE IS EXECUTED
                ;9841    ;-----------------------------------------------------------------------------
U 09F7, 37E6,15 ;9842            MOV LS[#B4D84] TO WR[0]                     ;SET UP A LOOP TO WAIT 400ms
                ;9843    WAIT.LOOP.TB:
                ;9844            DEC WR[0],
U 09F8, A100,35 ;9845             DT(LONG)&SET.ALU.CC
U 09F9, 089F,81 ;9846            JMP.IF[NEQ] TO [WAIT.LOOP.TB]               ;WAIT 400ms
                ;9847
                ;9848    READ.CSR.TB.1:
U 09FA, 9090,15 ;9849            MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 09FB, 9780,15 ;9850            PORT.READ PORT.ADRS[CSR]                    ;SET UP TO READ THE CSR
U 09FC, 3B32,15 ;9851            MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM CSR AND
                ;9852                                                        ; SAVE IT IN  LS
U 09FD, 3732,15 ;9853            MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 09FE, 2F82,95 ;9854            CLR WR[1]                                   ;SET UP EXPECTED DATA
U 09FF, 0869,3C ;9855            JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 0A00, 889F,04 ;9856            JMP [LOOP.TB.1]                             ;LOOP HERE IF ERR & LOE IS SET
                ;9857
U 0A01, 8875,3C ;9858            JSR [CLEANUP]                               ;CLEANUP THE CONDITIONS SET BY
                ;9859                                                        ; THIS TEST
                ;9860
                ;9861    END.TB:                                             ;END TEST
                ;9862
```

;9863

```
;9864    .PAGE  "Test C  DRIVE READY BRANCH TEST (M8388 IDC MODULE)"
;9865    ;++
;9866    ;
;9867    ; Test Description:
;9868    ;
;9869    ;       This test is designed to verify the BEN0/DRIVE RDY H branch condition.
;9870    ;       Drive 0 will be selected from the CSR bits <9:8>. BEN0/DRIVE RDY will
;9871    ;       be selected from the IDC microcode and if the branch condition is
;9872    ;       asserted, then the DAR will be incremented. The CSR and the DAR will
;9873    ;       then be read. If the drive is ready, CSR <0> (DRV RDY) will = 1 and
;9874    ;       the DAR should = 1. If the drive is not ready then CSR <0> (DRV RDY)
;9875    ;       will = 0 and DAR should = 0. The next drive will then be selected and
;9876    ;       the above sequence repeated for drives <3:0>.
;9877    ;
;9878    ; Assumptions:
;9879    ;
;9880    ;       It is assumed that the UINCR.DAR function works properly and the CSR
;9881    ;       branch conditions, F<2:0>, <CRDY> AND <MAINT> that will allow the
;9882    ;       microcode to branch to the correct routine, work properly.
;9883    ;
;9884    ; Test Steps:
;9885    ;
;9886    ;       1. Set up error mask, error number and module number in LS
;9887    ;          (for error printouts) and clear the previous error number in LS.
;9888    ;       2. Force the IDC microcode to DIAG.IDLE.
;9889    ;       3. Select Drive 0 from the CSR <9:8>.
;9890    ;       4. Clear the DAR.
;9891    ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;9892    ;
;9893    ;                                       *******
;9894    ;                                       * IDC *
;9895    ;                                       *******
;9896    ;
;9897    ;                   IDC1. Select BEN0/DRIVE RDY H.
;9898    ;                   IDC2. If DRIVE RDY H is asserted, then increment the DAR.
;9899    ;                   IDC3. Send XFER REQ to flag the CPU.
;9900    ;
;9901    ;       6. Wait for a XFER.REQ from the IDC.
;9902    ;       7. Clear CSR FNC <2:0> and issue XFER GRANT to clear the XFER.REQ.
;9903    ;       8. If CSR bit <0> = 1 then check that the DAR = 1.
;9904    ;       9. If CSR bit <0> = 0 then check that the DAR = 0.
;9905    ;      10. Select the next drive from the CSR <9:8> and Repeat Steps 4 - 10
;9906    ;          until drives <3:0> have been tested.
;9907    ;      11. Clear IDC.
;9908    ;      12. End test.
;9909    ;
;9910    ; Errors:
;9911    ;
;9912    ;       ERROR 1 - CSR bit 0 failed or BEN0/DRIVE RDY H failed.
;9913    ;
;9914    ;                 Printout:
;9915    ;                         EXPECTED          RECEIVED        OTHER DATA
;9916    ;                           DAR               DAR           DRIVE NUMBER
;9917    ;                                                            LS[T8]
;9918    ;
```

```
                    ;9919   ;
                    ;9920   ;
                    ;9921   ;
                    ;9922   ; Debug:
                    ;9923   ;
                    ;9924   ;  ERROR 1:
                    ;9925   ;
                    ;9926   ;       The Drive number under test will be selected by CSR <9:8>. These bits
                    ;9927   ;       are inputs to a FF and are latched with P2 CLOCK L when enabled by
                    ;9928   ;       WRITE CSR L = L. These bits are output from the FF as DS1 H and DS0 H.
                    ;9929   ;       DS1 H and DS0 H are inputs to the DR SEL LOG PAL. USEL DRV H will be
                    ;9930   ;       L so DS1 H is output as DRIVE SEL 1 H and DS0 H is output as DRIVE
                    ;9931   ;       SEL 0 H.
                    ;9932   ;       If the drive selected is an RL02, then DRIVE SEL <1:0> are
                    ;9933   ;       driven off the module, to the disk drive. The selected drive will
                    ;9934   ;       return its ready state as RL DRIVE READY H. This signal is input to the
                    ;9935   ;       DR SEL LOG PAL and will be output as DRV RDY when RL02 H = H.
                    ;9936   ;       If the drive selected is an R80, then RL02 H = L. The output DRV RDY H
                    ;9937   ;       in this case is determined by two input signals. If either R80 ON
                    ;9938   ;       CYLINDER H = L or R80 DRIVE READY H = L, then DRV RDY H = L.
                    ;9939   ;       DRV RDY H is latched by P2 CLOCK L in the CSR SELECTED STATUS LATCH
                    ;9940   ;       PAL. When the CSR is read L DRV RDY H is output as BUS IO 00 H.
                    ;9941   ;       DRV RDY H is also an input to the INIT FF and is latched by P2 CLOCK
                    ;9942   ;       L. It is output as DRIVE RDY H.
                    ;9943   ;       In the microstate which selects BEN0/DRIVE.RDY, the outputs of the
                    ;9944   ;       microcode PROMs should be:
                    ;9945   ;               BEN0 S0 H = 1
                    ;9946   ;               BEN0 S1 H = 0
                    ;9947   ;               BEN0 S2 H = 0
                    ;9948   ;       These signals are the selects for the branck logic and will select
                    ;9949   ;       DRIVE RDY H which becomes NUA 0 H. If DRIVE RDY H was asserted, then
                    ;9950   ;       the microcode will branch to an instruction that will increment the
                    ;9951   ;       DAR.
                    ;9952   ;       The CPU will read the CSR and if bit 0 is set, then the expected data
                    ;9953   ;       for the DAR is 1 since this indicates that the branch condition should
                    ;9954   ;       have been asserted.
                    ;9955   ;       If CSR bit 0 is clear, then the expected data for the DAR is 0 since
                    ;9956   ;       this indicates that the branch condition should not have been asserted.
                    ;9957   ;--
                    ;9958   ;*******************************************************************************
                    ;9959   T.C:
U 0A02, B65E,15     ;9960           MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;9961                                                   ; CONTROL AND STATUS WORD
U 0A03, 3E80,15     ;9962           MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;9963                                                   ; STATUS WORD - BIT 15
                    ;9964                                                   ; INDICATES START OF TEST TO
                    ;9965                                                   ; CONSOLE
U 0A04, 10E0,15     ;9966           MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;9967   WAIT.TC.0:
U 0A05, 88A0,54     ;9968           JMP [WAIT.TC.0]                         ;LOOP HERE WAITING FOR
                    ;9969                                                   ; CONSOLE TO RESPOND
                    ;9970
U 0A06, 65A0,15     ;9971           CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;9972                                                   ; IN LS
                    ;9973
```

```
U 0A07, B64A,15 ;9974           MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0A08, 3E8C,15 ;9975           MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;9976
                ;9977
U 0A09, B640,15 ;9978           MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0A0A, BE82,15 ;9979           MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;9980
U 0A0B, 3776,15 ;9981           MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK BITS
U 0A0C, 3E8A,15 ;9982           MOV WR[0] TO LS[ERROR.MASK]             ; <18:0> OF THE DAR
                ;9983
U 0A0D, B670,15 ;9984           MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER.DATA IF
U 0A0E, 3E80,15 ;9985           MOV WR[0] TO LS[CONTROL.STATUS]         ; ERROR
                ;9986
U 0A0F, 8872,EC ;9987           JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;9988
                ;9989
U 0A10, E510,15 ;9990           CLR LS[T8]                              ;USE TO HOLD DRIVE NUMBER FOR
                ;9991                                                   ; PRINTOUT
U 0A11, 2F85,15 ;9992           CLR WR[2]                               ;WR[2] HOLDS THE DRIVE NUMBER
U 0A12, 3645,95 ;9993           MOV LS[#4] TO WR[3]                     ;USE AS A LOOP COUNTER
                ;9994
                ;9995   TEST.DRV.RDY.TC:
                ;9996   LOOP.TC.1:
U 0A13, 2F80,15 ;9997           CLR WR[0]
U 0A14, 97A4,15 ;9998           PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                ;9999
U 0A15, B712,15 ;10000          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 0A16, B704,95 ;10001          MOV LS[SETCSR.F2] TO WR[1]              ; THE CORRECT IDC MICROCODE
U 0A17, AEC2,15 ;10002          BIS WR[1] TO WR[0]                      ; ROUTINE
U 0A18, AEC4,15 ;10003          BIS WR[2] TO WR[0]                      ;SELECT THE DRIVE
U 0A19, 17A0,15 ;10004          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;10005                                                  ;MAINT=0,CRDY=1,F<2:0>=010
                ;10006  ;-------------------------------------------------------------------------
                ;10007  ;-------------------------------------------------------------------------
                ;10008  ;                               *******
                ;10009  ;                               * IDC *
                ;10010  ;                               *******
                ;10011  ;-------------------------------------------------------------------------
                ;10012  ;018:
                ;10013  ;=000
                ;10014  ;DIAG.IDLE:
                ;10015  ;
                ;10016  ;       BEN0/F0,
                ;10017  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;10018  ;       BEN2/F2,
                ;10019  ;       NAD/DIAG.IDLE
                ;10020  ;-------------------------------------------------------------------------
                ;10021  ;01A:
                ;10022  ;=010
                ;10023  ;
                ;10024  ;       BEN0/CRDY.L,
                ;10025  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;10026  ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;10027  ;-------------------------------------------------------------------------
                ;10028  ;062:
```

```
                ;10029  ;=0*0
                ;10030  ;TEST.FUNC2:
                ;10031  ;
                ;10032  ;TEST.DRV.RDY:
                ;10033  ;       BEN0/DRIVE.RDY,         ;IS DRIVE READY ASSERTED?
                ;10034  ;       NAD/BEN0.1
                ;10035  ;-------------------------------------------------------------------------
                ;10036  ;18A:
                ;10037  ;=0
                ;10038  ;BEN0.1:
                ;10039  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 IS NOT ASSERTED
                ;10040  ;-------------------------------------------------------------------------
                ;10041  ;18B:
                ;10042  ;=1
                ;10043  ;BEN0.2:
                ;10044  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;10045  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 WAS ASSERTED
                ;10046  ;                                       ; FLAG THE CPU
                ;10047  ;-------------------------------------------------------------------------
                ;10048  ;1D8:
                ;10049  ;XFER.REQ:
                ;10050  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;10051  ;       NAD/DIAG.WAIT
                ;10052  ;-------------------------------------------------------------------------
                ;10053  ;1D7:
                ;10054  ;DIAG.WAIT:
                ;10055  ;
                ;10056  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;10057  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;10058  ;
                ;10059  ;-------------------------------------------------------------------------
                ;10060  ;159:
                ;10061  ;=*0*
                ;10062  ;DIAG.WAIT1:
                ;10063  ;
                ;10064  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;10065  ;                               ; COMMAND FROM THE CPU
                ;10066  ;
                ;10067  ;-------------------------------------------------------------------------
                ;10068  ;15B:
                ;10069  ;=*1*
                ;10070  ;DIAG.WAIT2:
                ;10071  ;
                ;10072  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;10073  ;                               ; WAIT SOME MORE
                ;10074  ;
                ;10075  ;-------------------------------------------------------------------------
                ;10076  WAIT.IDC.TC.1:
U 0A1A, DB00,1A ;10077          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO SEND XFER REQ
U 0A1B, 88A1,D4 ;10078          JMP [IDC.DONE.TC.1]                     ;XFER REQ ASSERTED
U 0A1C, 08A1,A4 ;10079          JMP [WAIT.IDC.TC.1]                     ;WAIT SOME MORE
                ;10080
                ;10081  IDC.DONE.TC.1:
U 0A1D, B700,15 ;10082          MOV LS[SETCSR.F0] TO WR[0]              ;GET THE DATA TO CLR F<2:0>
U 0A1E, 17A0,15 ;10083          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
```

```
U 0A1F, 90FA,15 ;10084          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;10085
                ;10086  READ.CSR.TC.1:
U 0A20, 9090,15 ;10087          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0A21, 9780,15 ;10088          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 0A22, 3B32,15 ;10089          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;10090                                                  ; SAVE IT IN  LS
U 0A23, 3732,15 ;10091          MOV LS[PORT0] TO WR[0]
                ;10092
U 0A24, 2F82,95 ;10093          CLR WR[1]                               ;CLR THE EXPECTED DATA
                ;10094
                ;10095          BIT LS[BIT0] WITH WR[0],                ;IS DRV RDY SET?
U 0A25, 5940,35 ;10096           DT(LONG)&SET.ALU.CC
U 0A26, 08A2,89 ;10097          JMP.IF[BITS.CLR] TO [READ.DAR.TC.1]     ;JMP IF DRV NOT READY
U 0A27, 3640,95 ;10098          MOV LS[#1] TO WR[1]                     ;SET EXPECTED DATA = 1
                ;10099
                ;10100  READ.DAR.TC.1:
U 0A28, 9090,15 ;10101          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0A29, 1784,15 ;10102          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0A2A, 3B32,15 ;10103          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;10104                                                  ; SAVE IT IN LS
U 0A2B, B610,15 ;10105          MOV LS[T8] TO WR[0]                     ;GET THE DRIVE NUMBER FOR
U 0A2C, BE88,15 ;10106          MOV WR[0] TO LS[ADDRESS.DATA]           ; PRINTOUT
U 0A2D, 3732,15 ;10107          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0A2E, 0869,3C ;10108          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0A2F, 08A1,34 ;10109          JMP [LOOP.TC.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;10110
U 0A30, B668,15 ;10111          MOV LS[#100000] TO WR[0]
U 0A31, AE01,15 ;10112          ADD WR[0] TO WR[2]                      ;INCREMENT THE DRIVE NUMBER
U 0A32, 7F10,15 ;10113          INC LS[T8]                              ;INC THE DRIVE NUMBER FOR
                ;10114                                                  ; PRINTOUTS
                ;10115          DEC WR[3],                              ;DONE?
U 0A33, A107,B5 ;10116           DT(LONG)&SET.ALU.CC
U 0A34, 08A1,31 ;10117          JMP.IF[NEQ] TO [TEST.DRV.RDY.TC]        ;JMP IF NOT DONE
                ;10118
U 0A35, 8875,3C ;10119          JSR [CLEANUP]                           ;CLEAN UP THE CONDITIONS SET
                ;10120                                                  ; BY THIS TEST
                ;10121  END.TC:                                         ;END TEST
                ;10122
                ;10123
                ;10124
```

```
;10125  .PAGE  "Test D  XFER.REQ BRANCH TEST (M8388 IDC MODULE)"
;10126  ;++
;10127  ;
;10128  ; Test Description:
;10129  ;
;10130  ;       This test is designed to insure that BEN1/XFER REQ H branch
;10131  ;       executes correctly. The IDC will first assert XFER REQ. The IDC
;10132  ;       microcode will then execute a BEN1/XFER REQ H and if XFER REQ is
;10133  ;       asserted, an instructon to increment the DAR will be executed.
;10134  ;       The CPU will then check the contents of the DAR.
;10135  ;       The CPU will then issue XFER GRANT to clear the XFER.REQ.
;10136  ;       A BEN1/XFER REQ H branch will then be executed and if XFER REQ has
;10137  ;       not deasserted, the DAR will be incremented. The CPU will then check
;10138  ;       the contents of the DAR.
;10139  ;
;10140  ; Assumptions:
;10141  ;
;10142  ;       It is assumed that the UINCR.DAR function works correctly.
;10143  ;
;10144  ; Test Steps:
;10145  ;
;10146  ;       1. Set up error mask, error number,and module number in LS
;10147  ;          (for error printouts) and clear previous error number in LS.
;10148  ;       2. Force the IDC microcode to DIAG.IDLE.
;10149  ;       3. Clear the DAR.
;10150  ;       4. Set up the CSR to branch to the correct microcode routine.
;10151  ;       5. NOP to allow time for the IDC to complete.
;10152  ;       6. Clear CSR F<2:0>.
;10153  ;
;10154  ;                                       *******
;10155  ;                                       * IDC *
;10156  ;                                       *******
;10157  ;
;10158  ;               IDC1. Execute an instruction with UCM = 4, SET XFER.REQ.
;10159  ;               IDC2. Select BEN1/XFER REQ H.
;10160  ;               IDC3. If XFER REQ H is asserted, then increment the DAR.
;10161  ;               IDC4. Go to DIAG.WAIT.
;10162  ;
;10163  ;       7. Check the contents of the DAR = 1.
;10164  ;       8. Increment the error number.
;10165  ;       9. Clear the DAR.
;10166  ;      10. Send XFER GRANT.
;10167  ;      11. Set up the CSR to branch to the correct microcode routine.
;10168  ;      12. NOP to allow the IDC time to complete.
;10169  ;      13. Clear CSR F<2:0>.
;10170  ;
;10171  ;                                       *******
;10172  ;                                       * IDC *
;10173  ;                                       *******
;10174  ;
;10175  ;               IDC5. Select BEN1/XFER REQ H.
;10176  ;               IDC6. If XFER REQ H is asserted, then increment the DAR.
;10177  ;               IDC7. Go to DIAG.WAIT.
;10178  ;
;10179  ;       14. Check the contents of the DAR = 0.
```

```
                ;10180  ;       15. Clear IDC.
                ;10181  ;       16. End Test.
                ;10182  ;
                ;10183  ; Error:
                ;10184  ;
                ;10185  ;                   Printout:
                ;10186  ;                           EXPECTED          RECEIVED
                ;10187  ;                             DAR               DAR
                ;10188  ;
                ;10189  ;
                ;10190  ;       ERROR 1 - BEN1/XFER REQ H failed asserted.
                ;10191  ;
                ;10192  ;       ERROR 2 - BEN1/XFER REQ H failed unasserted.
                ;10193  ;
                ;10194  ;
                ;10195  ; Debug:
                ;10196  ;
                ;10197  ;       ERROR 1 -
                ;10198  ;       A microinstuction with UCMD/SET.XFER.RQST is executed. This will
                ;10199  ;       assert XFER REQ H. The IDC microcode will select BEN1/XFER.REQ.
                ;10200  ;       The branch select outputs will be:
                ;10201  ;               BEN1 S0 H = L
                ;10202  ;               BEN1 S1 H = H
                ;10203  ;               BEN1 S2 H = L
                ;10204  ;       This will select XFER REQ H = H as NUA 1 H = H. The microcode will
                ;10205  ;       branch to an instruction that will increment the DAR. The CPU will
                ;10206  ;       then read and check the DAR = 1.
                ;10207  ;
                ;10208  ;       ERROR 2 -
                ;10209  ;       A MISC2 [TRANSFER.GRANT] instruction is executed. This instruction
                ;10210  ;       will be decoded on the CPU module by the MISC INST DECODER and will
                ;10211  ;       assert XFER GRANT L.
                ;10212  ;
                ;10213  ;       XFER GRANT L is an input to the CONTROL STATUS REG PAL.
                ;10214  ;       At the next P2 CLOCK, the output XFER REQ H will deassert.
                ;10215  ;       The IDC microcode will select BEN1/XFER.REQ. The branch select
                ;10216  ;       outputs will be:
                ;10217  ;               BEN1 S0 H = L
                ;10218  ;               BEN1 S1 H = H
                ;10219  ;               BEN1 S2 H = L
                ;10220  ;       This will select XFER REQ H = L as NUA 1 H = L. The microcode will
                ;10221  ;       will NOT increment the DAR. The CPU will then read and check the
                ;10222  ;       DAR = 0.
                ;10223  ;--
                ;10224  ;*******************************************************************************
                ;10225  T.D:
U 0A36, B65E,15 ;10226          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;10227                                                  ; CONTROL AND STATUS WORD
U 0A37, 3E80,15 ;10228          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;10229                                                  ; STATUS WORD - BIT 15
                ;10230                                                  ; INDICATES START OF TEST TO
                ;10231                                                  ; CONSOLE
U 0A38, 10E0,15 ;10232          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;10233  WAIT.TD.0:
U 0A39, 88A3,94 ;10234          JMP [WAIT.TD.0]                         ;LOOP HERE WAITING FOR
```

```
                ;10235                                          ; CONSOLE TO RESPOND
                ;10236
U 0A3A, 65A0,15 ;10237          CLR LS[PREVIOUS.ERROR]          ;CLEAR PREVIOUS ERROR NUMBER
                ;10238                                          ; IN LS
                ;10239
U 0A3B, B64A,15 ;10240          MOV LS[IDC] TO WR[0]            ;STORE MODULE CODE IN LS TO
U 0A3C, 3E8C,15 ;10241          MOV WR[0] TO LS[MODULE.NUM]     ; INDICATE IDC MODULE
                ;10242
                ;10243
U 0A3D, B640,15 ;10244          MOV LS[#1] TO WR[0]             ;SET WR0 = 1
U 0A3E, BE82,15 ;10245          MOV WR[0] TO LS[ERROR.NUMBER]   ;SET UP ERROR NUMBER = 1 IN LS
                ;10246
U 0A3F, 3776,15 ;10247          MOV LS[DAR.MASK] TO WR[0]       ;SET UP THE MASK TO CHECK
U 0A40, 3E8A,15 ;10248          MOV WR[0] TO LS[ERROR.MASK]     ; BITS <18:0> OF THE DAR
                ;10249
U 0A41, 8872,EC ;10250          JSR [DIAG.CODE]                 ;FORCE THE IDC TO DIAG.IDLE
                ;10251
                ;10252  LOOP.TD.1:
U 0A42, 2F80,15 ;10253          CLR WR[0]                       ;SET UP TO CLEAR THE DAR
U 0A43, 97A4,15 ;10254          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DAR
U 0A44, 3704,15 ;10255          MOV LS[SETCSR.F2] TO WR[0]      ;SET UP THE CSR TO BRANCH TO
                ;10256                                          ; THE CORRECT ROUTINE
U 0A45, 17A0,15 ;10257          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;10258                                          ;CRDY=0 MAINT=0, F<2:0>=010
                ;10259
                ;10260  ;-------------------------------------------------------------------------
                ;10261  ;-------------------------------------------------------------------------
                ;10262  ;                               *******
                ;10263  ;                               * IDC *
                ;10264  ;                               *******
                ;10265  ;-------------------------------------------------------------------------
                ;10266  ;018:
                ;10267  ;=000
                ;10268  ;DIAG.IDLE:
                ;10269  ;
                ;10270  ;       BEN0/F0,
                ;10271  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;10272  ;       BEN2/F2,
                ;10273  ;       NAD/DIAG.IDLE
                ;10274  ;-------------------------------------------------------------------
                ;10275  ;01A:
                ;10276  ;=010
                ;10277  ;
                ;10278  ;       BEN0/CRDY.L,
                ;10279  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;10280  ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;10281  ;-------------------------------------------------------------------
                ;10282  ;063:
                ;10283  ;=0*1
                ;10284  ;TEST.XFER.REQ:
                ;10285  ;
                ;10286  ;       UCMD/SET.XFER.RQST,             ;SET XFER REQ
                ;10287  ;       NAD/DIAG.IDLE
                ;10288  ;-------------------------------------------------------------------
                ;10289
```

```
U 0A46, B700,15 ;10290          MOV LS[SETCSR.F0] TO WR[0]                ;GET THE DATA TO CLR FUNC BITS
U 0A47, 17A0,15 ;10291          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;CLR FUNC BITS BEFORE RETURN TO
                ;10292                                                    ; DIAG.IDLE
                ;10293
                ;10294
U 0A48, 3713,15 ;10295          MOV LS[SETCSR.CRDY] TO WR[2]
U 0A49, B720,95 ;10296          MOV LS[SETCSR.MAINT] TO WR[1]
U 0A4A, 2EC4,95 ;10297          BIS WR[2] TO WR[1]
U 0A4B, B706,15 ;10298          MOV LS[SETCSR.F3] TO WR[0]                ;SET UP THE CSR TO BRANCH TO
U 0A4C, AEC2,15 ;10299          BIS WR[1] TO WR[0]
U 0A4D, 17A0,15 ;10300          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ; THE CORRECT IDC ROUTINE
                ;10301                                                    ;MAINT=1,CRDY=1,F<2:0>=011
                ;10302
                ;10303  ;-------------------------------------------------------------------------
                ;10304  ;-------------------------------------------------------------------------
                ;10305  ;                                *******
                ;10306  ;                                * IDC *
                ;10307  ;                                *******
                ;10308  ;-------------------------------------------------------------------------
                ;10309  ;018:
                ;10310  ;=000
                ;10311  ;DIAG.IDLE:
                ;10312  ;
                ;10313  ;       BEN0/F0,
                ;10314  ;       BEN1/F1,                  ;BRANCH ON THE CSR F<2:0> BITS
                ;10315  ;       BEN2/F2,
                ;10316  ;       NAD/DIAG.IDLE
                ;10317  ;-------------------------------------------------------------------------
                ;10318  ;01B:
                ;10319  ;=011
                ;10320  ;       BEN0/CRDY.L,
                ;10321  ;       BEN2/MAINT,               ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;10322  ;       NAD/TEST.FUNC3            ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;10323  ;-------------------------------------------------------------------------
                ;10324  ;06C:
                ;10325  ;=1*0
                ;10326  ;       BEN1/XFER.REQ,
                ;10327  ;       NAD/TEST.XFER.REQ.BR.2    ;IS XFER REQ ASSERTED?
                ;10328  ;-------------------------------------------------------------------------
                ;10329  ;18C:
                ;10330  ;=0*
                ;10331  ;TEST.XFER.REQ.BR.2:
                ;10332  ;       NAD/DIAG.IDLE             ;XFER REQ DID NOT ASSERT
                ;10333  ;-------------------------------------------------------------------------
                ;10334  ;18E:
                ;10335  ;=1*
                ;10336  ;TEST.XFER.REQ.BR.3:
                ;10337  ;       INCR.DAR/ON,              ;XFER REQ ASSERTED
                ;10338  ;       NAD/DIAG.IDLE             ;INCR THE DAR
                ;10339  ;-------------------------------------------------------------------------
U 0A4E, B700,15 ;10340          MOV LS[SETCSR.F0] TO WR[0]                ;CLR THE FUNC BITS BEFORE
U 0A4F, 17A0,15 ;10341          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ; RETURN TO DIAG.IDLE
U 0A50, DB00,15 ;10342          NOP
U 0A51, DB00,15 ;10343          NOP
U 0A52, DB00,15 ;10344          NOP
```

```
U 0A53, DB00,15 ;10345          NOP
                ;10346  READ.DAR.TD.1:
U 0A54, 9090,15 ;10347          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 0A55, 1784,15 ;10348          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0A56, 3B32,15 ;10349          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;10350                                                  ; SAVE IT IN LS
U 0A57, 3732,15 ;10351          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0A58, 3640,95 ;10352          MOV LS[#1] TO WR[1]                     ;SET UP THE RECEIVED DATA
U 0A59, 0869,3C ;10353          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0A5A, 88A4,24 ;10354          JMP [LOOP.TD.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;10355
U 0A5B, FF82,15 ;10356          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;10357
                ;10358  LOOP.TD.2:
U 0A5C, 2F80,15 ;10359          CLR WR[0]                               ;SET UP TO CLEAR THE DAR
U 0A5D, 97A4,15 ;10360          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DAR
                ;10361
U 0A5E, 90FA,15 ;10362          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;10363
U 0A5F, 3713,15 ;10364          MOV LS[SETCSR.CRDY] TO WR[2]
U 0A60, B720,95 ;10365          MOV LS[SETCSR.MAINT] TO WR[1]
U 0A61, 2EC4,95 ;10366          BIS WR[2] TO WR[1]
U 0A62, B706,15 ;10367          MOV LS[SETCSR.F3] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 0A63, AEC2,15 ;10368          BIS WR[1] TO WR[0]
U 0A64, 17A0,15 ;10369          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                ;10370                                                  ;MAINT=1,CRDY=1,F<2:0>=011
                ;10371
                ;10372  ;-------------------------------------------------------------------------------
                ;10373  ;-------------------------------------------------------------------------------
                ;10374  ;                               *******
                ;10375  ;                               * IDC *
                ;10376  ;                               *******
                ;10377  ;-------------------------------------------------------------------------------
                ;10378  ;018:
                ;10379  ;=000
                ;10380  ;DIAG.IDLE:
                ;10381  ;
                ;10382  ;       BEN0/F0,
                ;10383  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;10384  ;       BEN2/F2,
                ;10385  ;       NAD/DIAG.IDLE
                ;10386  ;-------------------------------------------------------------------------
                ;10387  ;01B:
                ;10388  ;=011
                ;10389  ;       BEN0/CRDY.L,
                ;10390  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;10391  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;10392  ;-------------------------------------------------------------------------
                ;10393  ;06C:
                ;10394  ;=1*0
                ;10395  ;       BEN1/XFER.REQ,
                ;10396  ;       NAD/TEST.XFER.REQ.BR.2          ;IS XFER REQ ASSERTED?
                ;10397  ;-------------------------------------------------------------------------
                ;10398  ;18C:
                ;10399  ;=0*
```

```
                ;10400  ;TEST.XFER.REQ.BR.2:
                ;10401  ;       NAD/DIAG.IDLE                   ;XFER REQ DID NOT ASSERT
                ;10402  ;-------------------------------------------------------------------
                ;10403  ;18E:
                ;10404  ;=1*
                ;10405  ;TEST.XFER.REQ.BR.3:
                ;10406  ;       INCR.DAR/ON,                    ;XFER REQ ASSERTED
                ;10407  ;       NAD/DIAG.IDLE                   ;INCR THE DAR
                ;10408  ;-------------------------------------------------------------------
U 0A65, B700,15 ;10409          MOV LS[SETCSR.F0] TO WR[0]              ;CLR THE FUNC BITS BEFORE
U 0A66, 17A0,15 ;10410          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; RETURN TO DIAG.IDLE
U 0A67, DB00,15 ;10411          NOP
U 0A68, DB00,15 ;10412          NOP
U 0A69, DB00,15 ;10413          NOP
                ;10414  READ.DAR.TD.2:
U 0A6A, 9090,15 ;10415          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0A6B, 1784,15 ;10416          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0A6C, 3B32,15 ;10417          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;10418                                                  ; SAVE IT IN LS
U 0A6D, 3732,15 ;10419          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0A6E, 2F82,95 ;10420          CLR WR[1]                               ;SET UP EXPECTED DATA
U 0A6F, 0869,3C ;10421          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0A70, 88A5,C4 ;10422          JMP [LOOP.TD.2]                         ;LOOP HERE IF ERR & LOE IS SET
U 0A71, 8875,3C ;10423          JSR [CLEANUP]                           ;CLEAN UP THE CONDITIONS SET
                ;10424                                                  ; BY THIS TEST
                ;10425  END.TD:                                         ;END TEST
                ;10426
                ;10427
                ;10428
                ;10429
                ;10430
                ;10431
```

```
;10432  .PAGE  "TEST E  DISK DRIVE SIZING TEST (M8388 IDC MODULE)"
;10433  ;++
;10434  ;
;10435  ; Test Description:
;10436  ;
;10437  ;       This test is designed determine if any R80 drives are attached.
;10438  ;       If an R80 is found, a message indicating the Drive number of the
;10439  ;       R80 will be printed. If no R80s are found, a message indicating this
;10440  ;       will be printed. This information will be stored in LS[DRIVE.STAUS]
;10441  ;       for use in future tests. Each drive will be selected, and
;10442  ;       CSR bit 26 <RL02> will be checked to see what type of a drive
;10443  ;       was found.
;10444  ;
;10445  ; Assumptions:
;10446  ;
;10447  ;       It is assumed that all previous test have run successfully.
;10448  ;
;10449  ; Test Steps:
;10450  ;
;10451  ;       1. Set up error mask, error number, and module number in LS
;10452  ;          (for error printouts) and clear the previous error number in LS.
;10453  ;       2. Clear LS[T6.SUB] and LS[T7.SUB]. LS[T6.SUB] will be used to save the
;10454  ;          drive number, and LS[T7.SUB] =1 will indicate an R80 was found for
;10455  ;          printouts.
;10456  ;       3. Clear LS[T8] and LS[T9] to save drive information.
;10457  ;       4. Write the CSR with the drive number from LS[T6.SUB].
;10458  ;       5. Read the CSR.
;10459  ;       6. If LS[SPECIAL] is set then force an error for looping purposes.
;10460  ;       7. Increment the error number.
;10461  ;       8. If the drive was not an R80 then go to Step 12.
;10462  ;       9. Print message "R80 PRESENT DRIVE #".
;10463  ;      10. If this was not the first R80 found then issue error.
;10464  ;      11. Save the Drive information in LS[T8] and LS[T9].
;10465  ;      12. If the last drive has not been tested, then increment the error
;10466  ;          number, increment the drive number and go to Step 4.
;10467  ;      13. If no R80s were found then print message, "R80 NOT PRESENT".
;10468  ;      14. If APT configuration is not equal to the  configuration found
;10469  ;          by this test then issue error. Do not validate LS[DRIVE.STATUS].
;10470  ;          Go to end of test.
;10471  ;      15. Validate LS[DRIVE.STATUS] and save the drive information.
;10472  ;      16. End test.
;10473  ;
;10474  ; Errors:
;10475  ;
;10476  ;
;10477  ;       ERROR 1 - Forced error for looping purposes if the configuration
;10478  ;                 found by this test does not match actual configuration.
;10479  ;
;10480  ;                 Printout:
;10481  ;                         EXPECTED      RECEIVED    OTHER DATA
;10482  ;                          WR[1]         WR[0]      DRIVE NUMBER
;10483  ;
;10484  ;       ERROR 2 - More than one R80 was found.
;10485  ;
;10486  ;                 Printout:
```

```
                    ;10487  ;                          EXPECTED      RECEIVED   OTHER DATA
                    ;10488  ;                           WR[1]         LS[T8]    DRIVE NUMBER
                    ;10489  ;
                    ;10490  ;
                    ;10491  ;       ERROR 3 - The configuration found was not the same as the one given
                    ;10492  ;                 by APT.
                    ;10493  ;
                    ;10494  ;                 Printout:
                    ;10495  ;                         EXPECTED     RECEIVED
                    ;10496  ;                       APT CONFIG    CONFIG FOUND
                    ;10497  ;
                    ;10498  ;
                    ;10499  ; Debug:
                    ;10500  ;
                    ;10501  ; LOOPING -
                    ;10502  ;       To loop on a forced error, SET SP(ECIAL) and run the test.
                    ;10503  ;       This will force an error. Continue to the error on which you wish to
                    ;10504  ;       loop, and then type LOOP.
                    ;10505  ;
                    ;10506  ; ERROR 1 -
                    ;10507  ;       The drive number will be selected by CSR <9:8>. These bits are latched
                    ;10508  ;       by P2 CLOCK L and are output as DS1 H and DS0 H. These signals are
                    ;10509  ;       inputs to the DR SEL LOG PAL. If the drive selected is an R80, then
                    ;10510  ;       its address will be on R80 SELECT ADRS 1 H and R80 SELECT ADRS 0 H,
                    ;10511  ;       and PLUG VALID H = H. This will force RL02 H = L.
                    ;10512  ;       If the drive selected is not an R80, RL02 H = H.
                    ;10513  ;       RL02 H is latch by P2 CLOCK L in the CSR SELECTED STATUS LATCH PAL and
                    ;10514  ;       output as L RL02 H.  This signal is output as BUS IO 26 H when the
                    ;10515  ;       CSR is read.
                    ;10516  ;
                    ;10517  ; ERROR 2 -
                    ;10518  ;       Since only one R80 is allowed on an IDC module, if this test finds
                    ;10519  ;       more than one, an error is reported. The Drive number reported as
                    ;10520  ;       OTHER DATA is the number of the second R80 found. First determine
                    ;10521  ;       which drive is being reported incorrectly, and then see LOOPING and
                    ;10522  ;       ERROR 1.
                    ;10523  ;
                    ;10524  ; ERROR 3 -
                    ;10525  ;       APT will report the configuration that it expects to be testing.
                    ;10526  ;       First determine if the APT configuration is wrong or if this test
                    ;10527  ;       found the wrong configuration. If this test reported the wrong
                    ;10528  ;       configuration, then see LOOPING and ERROR 1.
                    ;10529  ;--
                    ;10530  ;*******************************************************************************
                    ;10531  T.E:
U 0A72, B65E,15     ;10532          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;10533                                                  ; CONTROL AND STATUS WORD
U 0A73, 3E80,15     ;10534          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;10535                                                  ; STATUS WORD - BIT 15
                    ;10536                                                  ; INDICATES START OF TEST TO
                    ;10537                                                  ; CONSOLE
U 0A74, 10E0,15     ;10538          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;10539  WAIT.TE.0:
U 0A75, 08A7,54     ;10540          JMP [WAIT.TE.0]                         ;LOOP HERE WAITING FOR
                    ;10541                                                  ; CONSOLE TO RESPOND
```

```
                    ;10542
U 0A76, 65A0,15     ;10543          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;10544                                                  ; IN LS
                    ;10545
U 0A77, B64A,15     ;10546          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0A78, 3E8C,15     ;10547          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;10548
                    ;10549
                    ;10550
                    ;10551
U 0A79, E58A,15     ;10552          CLR LS[ERROR.MASK]                      ;SET UP ERROR MASK TO CHECK
                    ;10553                                                  ; ALL BITS
U 0A7A, 650C,15     ;10554          CLR LS[T6.SUB]                          ;DRV NUM FOR PRINTOUT
U 0A7B, E50E,15     ;10555          CLR LS[T7.SUB]                          ;USED IF R80 FOUND FOR PRINTOUT
U 0A7C, E510,15     ;10556          CLR LS[T8]                              ;STORES R80 INFO
U 0A7D, 6512,15     ;10557          CLR LS[T9]                              ;STORE DRIVE NUM
U 0A7E, 2F85,15     ;10558          CLR WR[2]                               ;STORES THE DRIVE NUMBER
U 0A7F, 2F80,15     ;10559          CLR WR[0]                               ;CLR THE DRIVE STATUS LOCATION
U 0A80, 3F8E,15     ;10560          MOV WR[0] TO LS[DRIVE.STATUS]           ; IN LS
                    ;10561
U 0A81, 8872,EC     ;10562          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                    ;10563
                    ;10564  TEST.DRIVE.TE.1:
                    ;10565  LOOP.TE.1:
U 0A82, B640,15     ;10566          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0A83, BE82,15     ;10567          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;10568
U 0A84, 2004,15     ;10569          MOV WR[2] TO WR[0]                      ;GET THE DRIVE NUMBER
U 0A85, 3646,95     ;10570          MOV LS[#8] TO WR[1]                     ;SHIFT THE DRIVE NUMBER INTO
                    ;10571  SHIFT.TE.1:
U 0A86, 23D0,15     ;10572          ASHL WR[0]                              ; BITS <9:8> FOR THE WRITE TO
                    ;10573          DEC WR[1],                              ; THE CSR
U 0A87, A102,B5     ;10574            DT(LONG)&SET.ALU.CC
U 0A88, 08A8,61     ;10575          JMP.IF[NEQ] TO [SHIFT.TE.1]
                    ;10576                                                  ;DRIVE NUM IS NOW IN BITS<9:8>
                    ;10577
U 0A89, 4778,15     ;10578          BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 0A8A, 17A0,15     ;10579          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;10580
U 0A8B, 9090,15     ;10581          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0A8C, 9780,15     ;10582          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 0A8D, 3B32,15     ;10583          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;10584                                                  ; SAVE IT IN LS
                    ;10585
U 0A8E, 364E,15     ;10586          MOV LS[SPECIAL] TO WR[0]                ;CHECK IF SPECIAL LOOP IS SET
                    ;10587          BIT LS[BIT0] WITH WR[0],
U 0A8F, 5940,35     ;10588           DT(LONG)&SET.ALU.CC
U 0A90, 88A9,89     ;10589          JMP.IF[BITS.CLR] TO [NO.LOOP.TE.1]      ;JUMP IF NOT SET
                    ;10590
U 0A91, B670,15     ;10591          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0A92, 3E80,15     ;10592          MOV WR[0] TO LS[CONTROL.STATUS]         ;
                    ;10593
U 0A93, 3E89,15     ;10594          MOV WR[2] TO LS[ADDRESS.DATA]           ;DRIVE NUMBER UNDER TEST
                    ;10595
U 0A94, B640,15     ;10596          MOV LS[#1] TO WR[0]                     ;FORCE AN ERROR TO ALLOW
```

```
U 0A95, 2F82,95 ;10597          CLR WR[1]                               ; LOOPING
U 0A96, 0869,3C ;10598          JSR [CHECK.RESULT]
U 0A97, 88A8,24 ;10599          JMP [LOOP.TE.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;10600
                ;10601  NO.LOOP.TE.1:
U 0A98, 3642,15 ;10602          MOV LS[#2] TO WR[0]
U 0A99, BE82,15 ;10603          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 2
U 0A9A, 3732,15 ;10604          MOV LS[PORT0] TO WR[0]
                ;10605          BIT LS[BIT26] WITH WR[0],               ;WAS THE DRIVE AN R80?
U 0A9B, D974,35 ;10606           DT(LONG)&SET.ALU.CC
U 0A9C, 08AB,89 ;10607          JMP.IF[BITS.CLR] TO [RL02.TE.1]         ;JUMP IF  DRIVE IS NOT AN R80
                ;10608
U 0A9D, B640,15 ;10609          MOV LS[#1] TO WR[0]
U 0A9E, 3E0E,15 ;10610          MOV WR[0] TO LS[T7.SUB]                 ;INDICATES AN R80 FOUND
U 0A9F, 3E0D,15 ;10611          MOV WR[2] TO LS[T6.SUB]                 ;DRIVE NUMBER FOR PRINTOUT
U 0AA0, 364E,15 ;10612          MOV LS[PRINT.R80] TO WR[0]              ;SET UP TO PRINT THAT AN
U 0AA1, 3E80,15 ;10613          MOV WR[0] TO LS[CONTROL.STATUS]         ; R80 WAS FOUND
                ;10614
U 0AA2, 10E0,15 ;10615          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;10616  WAIT.TE.1:                                      ; TO GO PRINT MESSAGE
U 0AA3, 88AA,34 ;10617          JMP [WAIT.TE.1]                         ;LOOP HERE WAITING FOR
                ;10618                                                  ; CONSOLE TO RESPOND
                ;10619
                ;10620
U 0AA4, B670,15 ;10621          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0AA5, 3E80,15 ;10622          MOV WR[0] TO LS[CONTROL.STATUS]         ;
                ;10623
U 0AA6, 3E89,15 ;10624          MOV WR[2] TO LS[ADDRESS.DATA]           ;DRIVE NUMBER UNDER TEST
                ;10625
U 0AA7, B610,15 ;10626          MOV LS[T8] TO WR[0]                     ;CHECK IF THIS IS FIRST R80
                ;10627                                                  ; FOUND
U 0AA8, 2F82,95 ;10628          CLR WR[1]                               ;EXPECTED DATA
U 0AA9, 0869,3C ;10629          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0AAA, 88A8,24 ;10630          JMP [LOOP.TE.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;10631
U 0AAB, B640,15 ;10632          MOV LS[#1] TO WR[0]
U 0AAC, 3E10,15 ;10633          MOV WR[0] TO LS[T8]                     ;SET FOR FIRST R80 FOUND
                ;10634
U 0AAD, 3640,95 ;10635          MOV LS[BIT0] TO WR[1]                   ;SET DR NUM=0
                ;10636          CMP LS[ZERO] WITH WR[2],                ;R80 ON DR 0?
U 0AAE, 4E9D,35 ;10637           DT(LONG)&SET.ALU.CC
U 0AAF, 08AB,79 ;10638          JMP.IF[EQL] TO [R80.SAV.TE]             ;JMP IF DRIVE 0
                ;10639
U 0AB0, B642,95 ;10640          MOV LS[BIT1] TO WR[1]                   ;SET DR NUM=1
                ;10641          CMP LS[#1] WITH WR[2],                  ;R80 ON DR 1?
U 0AB1, CE41,35 ;10642           DT(LONG)&SET.ALU.CC
U 0AB2, 08AB,79 ;10643          JMP.IF[EQL] TO [R80.SAV.TE]             ;JMP IF DRIVE 1
                ;10644
U 0AB3, B644,95 ;10645          MOV LS[BIT2] TO WR[1]                   ;SET DR NUM=2
                ;10646          CMP LS[#2] WITH WR[2],                  ;R80 ON DR 2?
U 0AB4, 4E43,35 ;10647           DT(LONG)&SET.ALU.CC
U 0AB5, 08AB,79 ;10648          JMP.IF[EQL] TO [R80.SAV.TE]             ;JMP IF DRIVE 2
                ;10649
U 0AB6, 3646,95 ;10650          MOV LS[BIT3] TO WR[1]                   ;SAVE DRIVE 3 IN WR[1]
                ;10651
```

```
                    ;10652  R80.SAV.TE:
U 0AB7, 6D12,95     ;10653          BIS WR[1] TO LS[T9]                      ;SAVE THIS INFO IN LS
                    ;10654
                    ;10655  RL02.TE.1:
U 0AB8, B788,15     ;10656          MOV LS[#3] TO WR[0]                      ;LAST DRIVE BEEN TESTED?
                    ;10657          CMP WR[0] WITH WR[2],
U 0AB9, 2641,35     ;10658           DT(LONG)&SET.ALU.CC
U 0ABA, 88AB,F9     ;10659          JMP.IF[EQL] TO [DONE.TE.1]               ;JMP IF ALL DRVS BEEN TESTED
U 0ABB, B640,15     ;10660          MOV LS[#1] TO WR[0]
U 0ABC, BE82,15     ;10661          MOV WR[0] TO LS[ERROR.NUMBER]            ;ERROR 1
U 0ABD, 2045,15     ;10662          INC WR[2]                                ;INCREMENT THE DRIVE NUMBER
U 0ABE, 88A8,24     ;10663          JMP [TEST.DRIVE.TE.1]
                    ;10664
                    ;10665  DONE.TE.1:
                    ;10666
U 0ABF, B796,15     ;10667          MOV LS[#F] TO WR[0]                      ;ANY R80'S FOUND?
                    ;10668          BIT LS[T9] WITH WR[0],
U 0AC0, D912,35     ;10669           DT(LONG)&SET.ALU.CC
U 0AC1, 08AC,81     ;10670          JMP.IF[BIT.SET] TO [SAVE.INFO.TE.1]      ;JMP IF R80
U 0AC2, 2F80,15     ;10671          CLR WR[0]
U 0AC3, 3E0E,15     ;10672          MOV WR[0] TO LS[T7.SUB]                  ;INDICATES NO R80s
U 0AC4, 364E,15     ;10673          MOV LS[PRINT.R80] TO WR[0]               ;SET UP TO PRINT NO R80s
U 0AC5, 3E80,15     ;10674          MOV WR[0] TO LS[CONTROL.STATUS]
U 0AC6, 10E0,15     ;10675          MISC [SET.CP.ATTN]                       ;ISSUE CPU ATTN TO CONSOLE
                    ;10676  WAIT.TE.2:                                       ; TO GO PRINT MESSAGE
U 0AC7, 08AC,74     ;10677          JMP [WAIT.TE.2]                          ;LOOP HERE WAITING FOR
                    ;10678                                                   ; CONSOLE TO RESPOND
                    ;10679
                    ;10680  SAVE.INFO.TE.1:
                    ;10681
U 0AC8, 3690,15     ;10682          MOV LS[ERROR.CONTROL] TO WR[0]           ;IS APT PRESENT?
                    ;10683          BIT LS[APT.PRESENT] WITH WR[0],
U 0AC9, 594A,35     ;10684           DT(LONG)&SET.ALU.CC
U 0ACA, 08AD,D9     ;10685          JMP.IF[BITS.CLR] TO [R80.CHK.TE]         ;JMP IF NOT UNDER APT
                    ;10686
U 0ACB, 3646,95     ;10687          MOV LS[#8] TO WR[1]                      ;USE WR[1] AS A COUNTER
U 0ACC, B692,15     ;10688          MOV LS[APT.PARAM] TO WR[0]               ;GET THE APT DISK DRIVE CONFIG
                    ;10689  SHFT.TO.BYTE0.TE:
U 0ACD, A350,15     ;10690          ASHR WR[0]                               ;SHFT THE INFO INTO BYTE 0
                    ;10691          DEC WR[1],
U 0ACE, A102,B5     ;10692           DT(LONG)&SET.ALU.CC
                    ;10693
U 0ACF, 08AC,D1     ;10694          JMP.IF[NEQ] TO [SHFT.TO.BYTE0.TE]        ;JMP UNTIL DONE
                    ;10695
U 0AD0, 362C,95     ;10696          MOV LS[#FFFFFF00] TO WR[1]               ;MASK ALL EXCEPT BYTE 0
U 0AD1, AF42,15     ;10697          BIC WR[1] TO WR[0]                       ; OF THE APT INFO
                    ;10698
U 0AD2, A001,95     ;10699          MOV WR[0] TO WR[3]                       ;SAVE INFO IN WR[3]
                    ;10700
                    ;10701          CMP LS[T9] WITH WR[0],                   ;CMP THE CONFIG FOUND BY THIS
U 0AD3, CE12,35     ;10702           DT(LONG)&SET.ALU.CC                     ; TEST AND THE APT CONFIG
                    ;10703
U 0AD4, 88AE,99     ;10704          JMP.IF[EQL] TO [APT.OK.TE]               ;JMP IF SAME TO VALIDATE
                    ;10705                                                   ; LS[DRIVE.STATUS]
                    ;10706
```

```
                    ;10707
U 0AD5, B788,15 ;10708          MOV LS[#3] TO WR[0]
U 0AD6, BE82,15 ;10709          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 3
                    ;10710
U 0AD7, 362C,95 ;10711          MOV LS[#FFFFFF00] TO WR[1]
U 0AD8, BE8A,95 ;10712          MOV WR[1] TO LS[ERROR.MASK]             ;SET MASK FOR BYTE 0
                    ;10713
U 0AD9, A006,15 ;10714          MOV WR[3] TO WR[0]                      ;SET UP APT CONFIG
                    ;10715
U 0ADA, B612,95 ;10716          MOV LS[T9] TO WR[1]                     ;SET UP CONFIG FOUND BY
                    ;10717                                              ; THIS TEST
U 0ADB, 0869,3C ;10718          JSR [CHECK.RESULT]                      ;GO REPORT THE ERROR
                    ;10719
U 0ADC, 88AE,D4 ;10720          JMP [END.TE]                            ;GO TO END OF TEST
                    ;10721
                    ;10722  R80.CHK.TE:
U 0ADD, 3612,15 ;10723          MOV LS[T9] TO WR[0]                     ;CHECK THAT ONLY ONE R80
                    ;10724          CMP LS[ZERO] WITH WR[0],                ; OR NO R80S WERE  FOUND
U 0ADE, CE9C,35 ;10725           DT(LONG)&SET.ALU.CC
U 0ADF, 88AE,99 ;10726          JMP.IF[EQL] TO [R80.OK.TE.1]            ;JUMP IF NO R80S
                    ;10727          CMP LS[#1] WITH WR[0],
U 0AE0, 4E40,35 ;10728           DT(LONG)&SET.ALU.CC
U 0AE1, 88AE,99 ;10729          JMP.IF[EQL] TO [R80.OK.TE.1]            ;JMP IF OK
                    ;10730          CMP LS[#2] WITH WR[0],
U 0AE2, CE42,35 ;10731           DT(LONG)&SET.ALU.CC
U 0AE3, 88AE,99 ;10732          JMP.IF[EQL] TO [R80.OK.TE.1]            ;JMP IF OK
                    ;10733          CMP LS[#4] WITH WR[0],
U 0AE4, CE44,35 ;10734           DT(LONG)&SET.ALU.CC
U 0AE5, 88AE,99 ;10735          JMP.IF[EQL] TO [R80.OK.TE.1]            ;JMP IF OK
                    ;10736          CMP LS[#8] WITH WR[0],
U 0AE6, 4E46,35 ;10737           DT(LONG)&SET.ALU.CC
U 0AE7, 88AE,99 ;10738          JMP.IF[EQL] TO [R80.OK.TE.1]            ;JMP IF OK
                    ;10739
U 0AE8, 08AE,C4 ;10740          JMP [CLEANUP.TE.1]                      ;DO NOT VALIDATE
                    ;10741                                              ; LS[DRIVE.STATUS] BECAUSE
                    ;10742                                              ; TEST WAS NOT COMPLETED
                    ;10743                                              ; SUCCESSFULLY
                    ;10744  APT.OK.TE:
                    ;10745  R80.OK.TE.1:
U 0AE9, 3612,15 ;10746          MOV LS[T9] TO WR[0]
U 0AEA, 474E,15 ;10747          BIS LS[BIT7] TO WR[0]                   ;SET BIT 7 TO INDICATE THAT
                    ;10748                                              ; THIS TEST HAS BEEN RUN
U 0AEB, 3F8E,15 ;10749          MOV WR[0] TO LS[DRIVE.STATUS]           ;SAVE DRIVE INFO IN LS
                    ;10750
                    ;10751  CLEANUP.TE.1:
U 0AEC, 8875,3C ;10752          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS
                    ;10753                                              ; SET BY THIS TEST
                    ;10754  END.TE:                                     ;END TEST
                    ;10755
                    ;10756
                    ;10757
                    ;10758
                    ;10759
                    ;10760
```

```
;10761  .PAGE  "Test F  FIFO A ADRS CNTR MAX L BRANCH TEST 1 (M8388 IDC MODULE)"
;10762  ;++
;10763  ;
;10764  ; Test Description:
;10765  ;
;10766  ;       This test is designed to insure that MAX L asserts on the correct
;10767  ;       FIFO A  address count (FF HEX) for an RL02 disk drive.
;10768  ;       This test will also verify that when a CLEAR.FIFO.CNTR is issued,
;10769  ;       the FIFO address lines all clear.
;10770  ;
;10771  ; Assumptions:
;10772  ;
;10773  ;       It is assumed that XFER.REQ works correctly.
;10774  ;
;10775  ; Test Steps:
;10776  ;
;10777  ;       1. Set up error mask, error number and module number in LS
;10778  ;          (for error printouts) and clear the previous error number in LS.
;10779  ;       2. If the DRIVE SIZING TEST has not been run previously then go run the
;10780  ;          DISK DRIVE SIZING ROUTINE.
;10781  ;       3. Force the IDC microcode to DIAG.IDLE.
;10782  ;       4. PSEL FIFO A.
;10783  ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;10784  ;
;10785  ;                                       *******
;10786  ;                                       * IDC *
;10787  ;                                       *******
;10788  ;
;10789  ;               IDC1. Select FIFO A, UCM = 5.
;10790  ;
;10791  ;       6. Clear the FIFO ADRS CNTR.
;10792  ;       7. Set up the CSR to branch to the correct IDC microcode loop.
;10793  ;
;10794  ;                                       *******
;10795  ;                                       * IDC *
;10796  ;                                       *******
;10797  ;               The IDC microcode  will continue looping on the following
;10798  ;               steps until MAX L asserts or a CLEAR IDC is issued.
;10799  ;
;10800  ;               IDC2. Select BEN1/MAX L.
;10801  ;               IDC3. If MAX L is asserted then assert XFER REQ and go to
;10802  ;                     DIAG.WAIT.
;10803  ;               IDC4. Go to IDC2.
;10804  ;
;10805  ;       8. Check that XFER REQ is unasserted.(XFER REQ will assert if MAX L is
;10806  ;                                                               asserted)
;10807  ;       9. Increment the error number.
;10808  ;      10. Select an RL02 drive or a line with no drive attached.
;10809  ;      11. Set WR[3] = 0 to use as a counter.
;10810  ;      12. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;10811  ;      13. Increment WR[3].
;10812  ;      14. Check that XFER REQ is unasserted.
;10813  ;      15. Repeat Steps 12 - 15 until WR[3] = 254 (FE HEX).
;10814  ;      16. Increment the error number.
;10815  ;      17. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
```

```
;10816  ;       18. Increment WR[3].
;10817  ;       19. Check that XFER REQ is asserted.(XFER REQ asserts if MAX L asserted)
;10818  ;       20. CLEAR IDC.
;10819  ;       21. End test.
;10820  ;
;10821  ;
;10822  ;
;10823  ; Errors:
;10824  ;
;10825  ;                       Printout:
;10826  ;                               EXPECTED            RECEIVED        OTHER DATA
;10827  ;                                 N/A                 N/A             WR[3]
;10828  ;                                                                     LOOP CNT
;10829  ;
;10830  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO MAX L failed unasserted.
;10831  ;
;10832  ;       ERROR 2 - PINCR FIFO CNTR failed or MAX L asserted too soon for an
;10833  ;                 RL02 drive.
;10834  ;
;10835  ;       ERROR 3 - MAX L did not assert at 255 for an RL02 drive.
;10836  ;
;10837  ; Debug:
;10838  ;
;10839  ;       A disk drive that will assert L  RL02 H at the CSR SELECTED
;10840  ;       STAUS LATCH PAL will be selected.
;10841  ;       L RL02 H is inverted to become R80 H = L.
;10842  ;
;10843  ;  ERROR 1:
;10844  ;
;10845  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;10846  ;       be decoded by the PORT INTERFACE REG PAL.
;10847  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;10848  ;
;10849  ;                       CSR 17 H = H
;10850  ;                       CSR 14 H = H
;10851  ;                       CSR 12 H = L
;10852  ;                       CSR 11 H = L
;10853  ;                       CSR 10 H = L
;10854  ;                       PORT INSTR H = H
;10855  ;                       CPU P2 H = H
;10856  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;10857  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;10858  ;       the address lines and deassert FIFO MAX L.
;10859  ;
;10860  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;10861  ;               BEN1 S0 H = H
;10862  ;               BEN1 S1 H = L
;10863  ;               BEN1 S2 H = H
;10864  ;
;10865  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;10866  ;       remain in the loop waiting for FIFO MAX L to assert and will
;10867  ;       not assert XFER REQ H.
;10868  ;       The CPU will then check to insure that XFER REQ H did not
;10869  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;10870  ;
```

```
;10871  ;  ERROR 2:
;10872  ;
;10873  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;10874  ;       instruction so that tne FIFO CNTR can be incremented from the
;10875  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;10876  ;       The inputs will be:
;10877  ;               CSR 17 H = H
;10878  ;               CSR 14 H = H
;10879  ;               CSR 12 H = H
;10880  ;               CSR 11 H = H
;10881  ;               CSR 10 H = L
;10882  ;               PORT INSTR H = H
;10883  ;               CPU P2 H = H
;10884  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;10885  ;
;10886  ;       FIFO A will also be selected by the IDC microcode to allow FIFO A MAX L
;10887  ;       to be asserted. The IDC microcode will issue UCMD/SET.FIFOA. This will
;10888  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;10889  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;10890  ;               UCMD 2 H = H
;10891  ;               UCMD 1 H = L
;10892  ;               UCMD 0 H = H
;10893  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;10894  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;10895  ;
;10896  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;10897  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;10898  ;       The inputs to this PAL should be:
;10899  ;               CSR 17 H = H
;10900  ;               CSR 14 H = L
;10901  ;               CSR 13 H = H
;10902  ;               CSR 12 H = L
;10903  ;               CSR 11 H = H
;10904  ;               CSR 10 H = L
;10905  ;               PORT INSTR H = H
;10906  ;               CPU P2 H = H
;10907  ;       This combination of inputs should assert BYTE L and WRITE DATA L, and
;10908  ;       STROBE DATA H.
;10909  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;10910  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;10911  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO A H = H and
;10912  ;       PORT CLOCK L as the clock input to the FIFO A ADRS CNTR HI
;10913  ;       and LO PALs. When these PALs are clocked, FIFOA ADRS <8:0> H will
;10914  ;       increment.
;10915  ;       R80 H will be = L so FIFO MAX L will not assert until
;10916  ;       FIFOA ADRS<7:4> = H and FIFOA LO FULL H = H and USEL FIFO A H = H.
;10917  ;
;10918  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;10919  ;               BEN1 S0 H = H
;10920  ;               BEN1 S1 H = L
;10921  ;               BEN1 S2 H = H
;10922  ;
;10923  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;10924  ;       remain in the loop waiting for FIFO MAX L to assert and will
;10925  ;       not assert XFER REQ H.
```

```
                    ;10926  ;       The CPU will then check to insure that XFER REQ H did not
                    ;10927  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;10928  ;
                    ;10929  ;  ERROR 3:
                    ;10930  ;       FIFOA ADRS <7:0> will be = 11111110. The FIFOA ADRS CNTR PALs will
                    ;10931  ;       be clocked one more time by writing a byte of data to FIFO A. This
                    ;10932  ;       will increment FIFOA ADRS <7:0> = 11111111.
                    ;10933  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
                    ;10934  ;               R80 H = L
                    ;10935  ;               FIFOA LO FULL H = H
                    ;10936  ;               USEL FIFOA H = H
                    ;10937  ;               FIFOA ADRS <7:4> = H
                    ;10938  ;       This combination of inputs will assert FIFO MAX L.
                    ;10939  ;
                    ;10940  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                    ;10941  ;               BEN1 S0 H = H
                    ;10942  ;               BEN1 S1 H = L
                    ;10943  ;               BEN1 S2 H = H
                    ;10944  ;
                    ;10945  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                    ;10946  ;       branch to an instruction that will assert XFER REQ H.
                    ;10947  ;       The CPU will then check to insure that XFER REQ H asserted by
                    ;10948  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;10949  ;--
                    ;10950  ;*************************************************************************
                    ;10951  T.F:
U 0AED, B65E,15     ;10952          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;10953                                                  ; CONTROL AND STATUS WORD
U 0AEE, 3E80,15     ;10954          MOV WR[0] TO LS[CONTROL.STATUS]          ;SET BIT 15 IN CONTROL AND
                    ;10955                                                  ; STATUS WORD - BIT 15
                    ;10956                                                  ; INDICATES START OF TEST TO
                    ;10957                                                  ; CONSOLE
U 0AEF, 10E0,15     ;10958          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;10959  WAIT.TF.0:
U 0AF0, 88AF,04     ;10960          JMP [WAIT.TF.0]                         ;LOOP HERE WAITING FOR
                    ;10961                                                  ; CONSOLE TO RESPOND
                    ;10962
U 0AF1, 65A0,15     ;10963          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;10964                                                  ; IN LS
                    ;10965
U 0AF2, B64A,15     ;10966          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0AF3, 3E8C,15     ;10967          MOV WR[0] TO LS[MODULE.NUM]              ; INDICATE IDC MODULE
                    ;10968
                    ;10969
                    ;10970
U 0AF4, B670,15     ;10971          MOV LS[OTHER.DATA] TO WR[0]              ;SET UP TO PRINT OTHER DATA
U 0AF5, 3E80,15     ;10972          MOV WR[0] TO LS[CONTROL.STATUS]          ; IF ERROR
                    ;10973
U 0AF6, B66E,15     ;10974          MOV LS[NA.EXP.REC] TO WR[0]              ;SET UP TO PRINT N/A FOR
U 0AF7, 6D80,15     ;10975          BIS WR[0] TO LS[CONTROL.STATUS]          ; EXPECTED & RECEIVED DATA
                    ;10976
U 0AF8, E58A,15     ;10977          CLR LS[ERROR.MASK]
                    ;10978
                    ;10979
U 0AF9, B78E,15     ;10980          MOV LS[DRIVE.STATUS] TO WR[0]            ;HAS THE DRIVE SIZING ROUTINE
```

```
                ;10981          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 0AFA, D94E,35 ;10982           DT(LONG)&SET.ALU.CC
U 0AFB, 08AF,D1 ;10983          JMP.IF[BIT.SET] TO [SIZE.OK.TF.1]       ;IF YES THEN GO RUN TEST
                ;10984
U 0AFC, 8870,0C ;10985          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;10986
                ;10987  SIZE.OK.TF.1:
U 0AFD, 8872,EC ;10988          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;10989
                ;10990          ;SELECT AN RL02 DRIVE
                ;10991
U 0AFE, B78E,15 ;10992          MOV LS[DRIVE.STATUS] TO WR[0]
                ;10993          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0AFF, 5940,35 ;10994           DT(LONG)&SET.ALU.CC
U 0B00, 88B0,39 ;10995          JMP.IF[BITS.CLR] TO [SET.DS0.TF.1]      ;JMP IF DRV 0 IS NOT AN R80
U 0B01, B717,15 ;10996          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 0B02, 88B0,44 ;10997          JMP [TEST.TF.1]
                ;10998  SET.DS0.TF.1:
U 0B03, 3715,15 ;10999          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;11000
                ;11001  TEST.TF.1:
                ;11002
U 0B04, 2F87,95 ;11003          CLR WR[3]                               ;USE AS ADDRESS LOOP COUNTER
U 0B05, 17D8,15 ;11004          PORT.CONTROL [SEL.FIFO.A]               ;SEL FIFO A FROM THE PORT
                ;11005
U 0B06, 3720,15 ;11006          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0B07, 370A,95 ;11007          MOV LS[SETCSR.F5] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 0B08, AEC2,15 ;11008          BIS WR[1] TO WR[0]                      ; TO USEL FIFO A
U 0B09, 17A0,15 ;11009          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;11010                                                  ;MAINT=1, CRDY=0, F<2:0>=101
                ;11011
                ;11012  ;USEL FIFO A
                ;11013  ;-------------------------------------------------------------------------------
                ;11014  ;-------------------------------------------------------------------------------
                ;11015  ;                               *******
                ;11016  ;                               * IDC *
                ;11017  ;                               *******
                ;11018  ;-------------------------------------------------------------------------------
                ;11019  ;018:
                ;11020  ;=000
                ;11021  ;DIAG.IDLE:
                ;11022  ;
                ;11023  ;       BEN0/F0,
                ;11024  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;11025  ;       BEN2/F2,
                ;11026  ;       NAD/DIAG.IDLE
                ;11027  ;-------------------------------------------------------------------
                ;11028  ;01D:
                ;11029  ;=101
                ;11030  ;
                ;11031  ;       BEN0/CRDY.L,
                ;11032  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;11033  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;11034  ;-------------------------------------------------------------------
                ;11035  ;075:
```

```
                ;11036  ;=1*1
                ;11037  ;TEST.F5:
                ;11038  ;
                ;11039  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;11040  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;11041  ;
                ;11042  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;11043  ;                                       ; MUST USEL FIFO A
                ;11044  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;11045  ;                                       ; AND DIAG.IDLE
                ;11046  ;-------------------------------------------------------------------------
                ;11047  ;1D8:
                ;11048  ;XFER.REQ:
                ;11049  ;
                ;11050  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;11051  ;       NAD/DIAG.WAIT
                ;11052  ;-------------------------------------------------------------------------
                ;11053  ;1D7:
                ;11054  ;DIAG.WAIT:
                ;11055  ;
                ;11056  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;11057  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;11058  ;
                ;11059  ;-------------------------------------------------------------------------
                ;11060  ;159:
                ;11061  ;=*0*
                ;11062  ;DIAG.WAIT1:
                ;11063  ;
                ;11064  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;11065  ;                               ; COMMAND FROM THE CPU
                ;11066  ;
                ;11067  ;-------------------------------------------------------------------------
                ;11068  ;15B:
                ;11069  ;=*1*
                ;11070  ;DIAG.WAIT2:
                ;11071  ;
                ;11072  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;11073  ;                               ; WAIT SOME MORE
                ;11074  ;
                ;11075  ;-------------------------------------------------------------------------
                ;11076  WAIT.IDC.TF.1:
U 0B0A, DB00,1A ;11077          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0B0B, 88B0,D4 ;11078          JMP [IDC.DONE.TF.1]                     ;XFER REQ ASSERTED
U 0B0C, 08B0,A4 ;11079          JMP [WAIT.IDC.TF.1]                     ;WAIT SOME MORE
                ;11080
                ;11081  IDC.DONE.TF.1:
U 0B0D, B700,15 ;11082          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0B0E, 17A0,15 ;11083          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0B0F, 90FA,15 ;11084          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;11085
                ;11086  LOOP.TF.1:
U 0B10, B640,15 ;11087          MOV LS[#1] TO WR[0]
U 0B11, BE82,15 ;11088          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                ;11089
U 0B12, 17C0,15 ;11090          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
```

```
                ;11091
U 0B13, 3712,95 ;11092          MOV LS[SETCSR.CRDY] TO WR[1]             ;SET UP THE CSR TO BRANCH TO
U 0B14, 3720,15 ;11093          MOV LS[SETCSR.MAINT] TO WR[0]            ; THE CORRECT IDC ROUTINE
U 0B15, AEC2,15 ;11094          BIS WR[1] TO WR[0]                       ; THAT WILL LOOP UNTIL MAX L
U 0B16, B704,95 ;11095          MOV LS[SETCSR.F2] TO WR[1]               ; ASSERTS
U 0B17, AEC2,15 ;11096          BIS WR[1] TO WR[0]
U 0B18, AEC4,15 ;11097          BIS WR[2]  TO WR[0]                      ;SELECT AN RL02
U 0B19, 17A0,15 ;11098          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;11099                                                   ;MAINT=1, CRDY=1, F<2:0>=010
                ;11100  ;-------------------------------------------------------------------------
                ;11101  ;-------------------------------------------------------------------------
                ;11102  ;                              *******
                ;11103  ;                              * IDC *
                ;11104  ;                              *******
                ;11105  ;-------------------------------------------------------------------------
                ;11106  ;018:
                ;11107  ;=000
                ;11108  ;DIAG.IDLE:
                ;11109  ;
                ;11110  ;       BEN0/F0,
                ;11111  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;11112  ;       BEN2/F2,
                ;11113  ;       NAD/DIAG.IDLE
                ;11114  ;-----------------------------------------------------------------------
                ;11115  ;01A:
                ;11116  ;=010
                ;11117  ;
                ;11118  ;       BEN0/CRDY.L,
                ;11119  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;11120  ;       NAD/TEST.FUNC2           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;11121  ;-----------------------------------------------------------------------
                ;11122  ;066:
                ;11123  ;=1*0
                ;11124  ;TEST.FIFO.MAX.1:
                ;11125  ;       BEN1/FIFO.MAX.L,         ;IS FIFO MAX ASSERTED?
                ;11126  ;       NAD/TEST.FIFO.MAX.2
                ;11127  ;-----------------------------------------------------------------------
                ;11128  ;18D:
                ;11129  ;=0*
                ;11130  ;TEST.FIFO.MAX.2:
                ;11131  ;       NAD/XFER.REQ                     ;MAX ASSERTED
                ;11132  ;-----------------------------------------------------------------------
                ;11133  ;18F:
                ;11134  ;=1*
                ;11135  ;TEST.FIFO.MAX.3:
                ;11136  ;       NAD/TEST.FIFO.MAX.1              ;MAX NOT ASSERTED...LOOP
                ;11137  ;-----------------------------------------------------------------------
                ;11138
U 0B1A, 3792,15 ;11139          MOV LS[#6] TO WR[0]                      ;NOP TO WAIT FOR IDC
                ;11140  NOP.TF.1:
                ;11141          DEC WR[0],
U 0B1B, A100,35 ;11142           DT(LONG)&SET.ALU.CC
U 0B1C, 08B1,B1 ;11143          JMP.IF[NEQ] TO [NOP.TF.1]
                ;11144
U 0B1D, DB00,1A ;11145          SKIP.IF[NO.FAST.INTERRUPT]               ;SEE IF MAX L ASSERTED
```

```
U 0B1E, 88B4,04 ;11146          JMP [ERROR.TF.1]                        ;MAX L ASSERTED WHEN FIFO
                ;11147                                                  ; ADRS WAS CLEAR
                ;11148
U 0B1F, 2F82,95 ;11149          CLR WR[1]                               ;CALL CHECK.RESULT TO LOCK
U 0B20, 2F80,15 ;11150          CLR WR[0]                               ; IN INTERMITTENT ERRORS
U 0B21, BE89,95 ;11151          MOV WR[3] TO LS[ADDRESS.DATA]           ;
U 0B22, 0869,3C ;11152          JSR [CHECK.RESULT]
U 0B23, 88B1,04 ;11153          JMP [LOOP.TF.1]
                ;11154
                ;11155
                ;11156
U 0B24, 3642,15 ;11157          MOV LS[#2] TO WR[0]                     ;ERROR 2
U 0B25, BE82,15 ;11158          MOV WR[0] TO LS[ERROR.NUMBER]
                ;11159
U 0B26, 378A,15 ;11160          MOV LS[#FE] TO WR[0]                    ;ONE BEFORE MAX CNT FOR AN RL02
U 0B27, 3E10,15 ;11161          MOV WR[0] TO LS[T8]
                ;11162
U 0B28, 2F87,95 ;11163          CLR WR[3]                               ;USE TO TRACK FIFO ADRS
                ;11164  INCR.CNTR.TF.1:
U 0B29, 97A8,15 ;11165          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;11166                                                  ; TO FIFO A TO INCR ADRS CNTR
U 0B2A, 2047,95 ;11167          INC WR[3]                               ;INCR ADRS TRACKER
U 0B2B, B788,15 ;11168          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;11169  NOP.TF.2:
                ;11170          DEC WR[0],
U 0B2C, A100,35 ;11171           DT(LONG)&SET.ALU.CC
U 0B2D, 88B2,C1 ;11172          JMP.IF[NEQ] TO [NOP.TF.2]
                ;11173
U 0B2E, DB00,1A ;11174          SKIP.IF[NO.FAST.INTERRUPT]              ;CHECK IF MAX L ASSERTED
U 0B2F, 88B4,04 ;11175          JMP [ERROR.TF.1]                        ;MAX L ASSERTED TOO SOON
                ;11176
U 0B30, 2F82,95 ;11177          CLR WR[1]                               ;CALL CHECK.RESULT TO LOCK
U 0B31, 2F80,15 ;11178          CLR WR[0]                               ; IN INTERMITTENT ERRORS
U 0B32, BE89,95 ;11179          MOV WR[3] TO LS[ADDRESS.DATA]           ;
U 0B33, 0869,3C ;11180          JSR [CHECK.RESULT]
U 0B34, 88B1,04 ;11181          JMP [LOOP.TF.1]
                ;11182
                ;11183
                ;11184
                ;11185          CMP LS[T8] WITH WR[3],                  ;LAST COUNT?
U 0B35, 4E11,B5 ;11186           DT(LONG)&SET.ALU.CC
U 0B36, 88B2,91 ;11187          JMP.IF[NEQ] TO [INCR.CNTR.TF.1]         ;JUMP IF NOT LAST COUNT
                ;11188
U 0B37, B788,15 ;11189          MOV LS[#3] TO WR[0]
U 0B38, BE82,15 ;11190          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 3
U 0B39, 97A8,15 ;11191          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF DATA TO FIFO A
                ;11192                                                  ; TO INCR ADRS CNTR TO MAX (FF)
U 0B3A, 2047,95 ;11193          INC WR[3]                               ;INCR THE ADRS TRACKER
U 0B3B, B788,15 ;11194          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;11195  NOP.TF.3:
                ;11196          DEC WR[0],
U 0B3C, A100,35 ;11197           DT(LONG)&SET.ALU.CC
U 0B3D, 08B3,C1 ;11198          JMP.IF[NEQ] TO [NOP.TF.3]
                ;11199
U 0B3E, DB00,1A ;11200          SKIP.IF[NO.FAST.INTERRUPT]              ;MAX L ASSERTED?
```

```
U 0B3F, 88B4,54 ;11201          JMP [CALL.CH.RESULT.TF.1]                ;MAX L ASSERTED OK
                ;11202  ERROR.TF.1:
U 0B40, 3640,95 ;11203          MOV LS[#1] TO WR[1]                      ;FORCE AN ERROR
U 0B41, 2F80,15 ;11204          CLR WR[0]
U 0B42, BE89,95 ;11205          MOV WR[3] TO LS[ADDRESS.DATA]            ;PRINT OTHER DATA
U 0B43, 0869,3C ;11206          JSR [CHECK.RESULT]
U 0B44, 88B1,04 ;11207          JMP [LOOP.TF.1]                          ;LOOP HERE IF ERR  & LOE IS SET
                ;11208                                                   ;ELSE SKIP OTHER ERRORS AND END
                ;11209                                                   ; TEST
                ;11210  CALL.CH.RESULT.TF.1:
U 0B45, 2F82,95 ;11211          CLR WR[1]                                ;CALL CHECK.RESULT TO LOCK
U 0B46, 2F80,15 ;11212          CLR WR[0]                                ; IN INTERMITTENT ERRORS
U 0B47, BE89,95 ;11213          MOV WR[3] TO LS[ADDRESS.DATA]            ;
U 0B48, 0869,3C ;11214          JSR [CHECK.RESULT]
U 0B49, 88B1,04 ;11215          JMP [LOOP.TF.1]
                ;11216
                ;11217
                ;11218  CLEANUP.TF.1:
U 0B4A, 8875,3C ;11219          JSR [CLEANUP]                            ;CLEANUP THE CONDITIONS SET BY
                ;11220                                                   ; THIS TEST
                ;11221  END.TF:                                          ;END TEST
                ;11222
                ;11223
                ;11224
                ;11225
```

```
;11226  .PAGE  "Test 10  FIFO A ADRS CNTR MAX L BRANCH TEST 2 (M8388 IDC MODULE)"
;11227  ;++
;11228  ;
;11229  ; Test Description:
;11230  ;
;11231  ;       This test will only be run if an R80 is available on the system.
;11232  ;       This test is designed to verify that MAX L asserts on the correct
;11233  ;       address count (1FF HEX) of FIFO A when an R80 is selected.
;11234  ;
;11235  ; Assumptions:
;11236  ;
;11237  ;       It is assumed that XFER.REQ works correctly.
;11238  ;
;11239  ; Test Steps:
;11240  ;
;11241  ;       1. Set up error mask, error number and module number in LS
;11242  ;          (for error printouts) and clear the previous error number in LS.
;11243  ;       2. If the DRIVE SIZING TEST has not been run previously then go run the
;11244  ;          DISK DRIVE SIZING ROUTINE.
;11245  ;       3. If an R80 is not available on the system, print "R80 NOT PRESENT"
;11246  ;          and go to end of test.
;11247  ;       4. Force the IDC microcode to DIAG.IDLE.
;11248  ;       5. PSEL FIFO A.
;11249  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;11250  ;
;11251  ;                                       *******
;11252  ;                                       * IDC *
;11253  ;                                       *******
;11254  ;
;11255  ;               IDC1. Select FIFO A, UCM = 5.
;11256  ;
;11257  ;       7. Set up the CSR to branch to the correct IDC microcode loop.
;11258  ;
;11259  ;                                       *******
;11260  ;                                       * IDC *
;11261  ;                                       *******
;11262  ;               The IDC microcode  will continue looping on the following
;11263  ;               steps until MAX L asserts or a CLEAR IDC is issued.
;11264  ;
;11265  ;               IDC2. Select BEN1/MAX L.
;11266  ;               IDC3. If MAX L is asserted then assert XFER REQ and go to
;11267  ;                     DIAG.WAIT.
;11268  ;               IDC4. Go to IDC2.
;11269  ;
;11270  ;       8. Clear the FIFO ADRS CNTR.
;11271  ;       9. Check that XFER REQ is unasserted.(XFER REQ will assert if MAX L is
;11272  ;                                                               asserted)
;11273  ;      10. Increment the error number.
;11274  ;      11. Select an R80 drive.
;11275  ;      12. Set WR[3] = 0 to use as a counter.
;11276  ;      13. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;11277  ;      14. Increment WR[3].
;11278  ;      15. Check that XFER REQ is unasserted.
;11279  ;      16. Repeat Steps 13 - 16 until WR[3] = 510 (1FE HEX).
;11280  ;      17. Increment the error number.
```

```
;11281  ;       18. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;11282  ;       19. Increment WR[3].
;11283  ;       20. Check that XFER REQ is asserted.(XFER REQ asserts if MAX L asserted)
;11284  ;       21. CLEAR IDC.
;11285  ;       22. End test.
;11286  ;
;11287  ; Errors:
;11288  ;
;11289  ;                   Printout:
;11290  ;                           EXPECTED          RECEIVED        OTHER DATA
;11291  ;                             N/A               N/A             WR[3]
;11292  ;
;11293  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO MAX L failed unasserted.
;11294  ;
;11295  ;       ERROR 2 - PINCR FIFO CNTR failed or MAX L asserted too soon for an
;11296  ;                 R80 drive.
;11297  ;
;11298  ;       ERROR 3 - MAX L did not assert at 511 for an R80 drive.
;11299  ;
;11300  ;
;11301  ; Debug:
;11302  ;       An R80 disk drive will be selected which will deassert L  RL02 H at
;11303  ;       the CSR SELECTED STATUS LATCH PAL.
;11304  ;       L RL02 H = L  is inverted to become R80 H = H.
;11305  ;  ERROR 1:
;11306  ;
;11307  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;11308  ;       be decoded by the PORT INTERFACE REG PAL.
;11309  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;11310  ;
;11311  ;                           CSR 17 H = H
;11312  ;                           CSR 14 H = H
;11313  ;                           CSR 12 H = L
;11314  ;                           CSR 11 H = L
;11315  ;                           CSR 10 H = L
;11316  ;                           PORT INSTR H = H
;11317  ;                           CPU P2 H = H
;11318  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;11319  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;11320  ;       the address lines and deassert FIFO MAX L.
;11321  ;
;11322  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;11323  ;               BEN1 S0 H = H
;11324  ;               BEN1 S1 H = L
;11325  ;               BEN1 S2 H = H
;11326  ;
;11327  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;11328  ;       remain in the loop waiting for FIFO MAX L to assert and will
;11329  ;       not assert XFER REQ H.
;11330  ;       The CPU will then check to insure that XFER REQ H did not
;11331  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;11332  ;
;11333  ; ERROR 2:
;11334  ;
;11335  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
```

```
;11336  ;       instruction so that the FIFO CNTR can be incremented from the
;11337  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;11338  ;       The inputs will be:
;11339  ;               CSR 17 H = H
;11340  ;               CSR 14 H = H
;11341  ;               CSR 12 H = H
;11342  ;               CSR 11 H = H
;11343  ;               CSR 10 H = L
;11344  ;               PORT INSTR H = H
;11345  ;               CPU P2 H = H
;11346  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;11347  ;
;11348  ;       FIFO A will also be selected by the IDC microcode to allow FIFO A MAX L
;11349  ;       to be asserted. The IDC microcode will issue UCMD/SET.FIFOA. This will
;11350  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;11351  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;11352  ;               UCMD 2 H = H
;11353  ;               UCMD 1 H = L
;11354  ;               UCMD 0 H = H
;11355  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;11356  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;11357  ;
;11358  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;11359  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;11360  ;       The inputs to this PAL should be:
;11361  ;               CSR 17 H = H
;11362  ;               CSR 14 H = L
;11363  ;               CSR 13 H = H
;11364  ;               CSR 12 H = L
;11365  ;               CSR 11 H = H
;11366  ;               CSR 10 H = L
;11367  ;               PORT INSTR H = H
;11368  ;               CPU P2 H = H
;11369  ;       This combination of inputs should assert BYTE L and WRITE DATA L, and
;11370  ;       STROBE DATA H.
;11371  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;11372  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;11373  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO A H = H and
;11374  ;       PORT CLOCK L as the clock input to the FIFO A ADRS CNTR HI
;11375  ;       and LO PALs. When these PALs are clocked, FIFOA ADRS <8:0> H will
;11376  ;       increment.
;11377  ;       R80 H will be = H so FIFO MAX L will not assert until
;11378  ;       FIFOA ADRS <8:4> = H and FIFOA LO FULL H = H and USEL FIFO A H = H.
;11379  ;
;11380  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;11381  ;               BEN1 S0 H = H
;11382  ;               BEN1 S1 H = L
;11383  ;               BEN1 S2 H = H
;11384  ;
;11385  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;11386  ;       remain in the loop waiting for FIFO MAX L to assert and will
;11387  ;       not assert XFER REQ H.
;11388  ;       The CPU will then check to insure that XFER REQ H did not
;11389  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;11390  ;
```

```
                ;11391  ;  ERROR 3:
                ;11392  ;       FIFOA ADRS <8:0> will be = 111111110. The FIFOA ADRS CNTR PALs will
                ;11393  ;       be clocked one more time by writing a byte of data to FIFO A. This
                ;11394  ;       will increment FIFOA ADRS <8:0> = 111111111.
                ;11395  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
                ;11396  ;               R80 H = H
                ;11397  ;               FIFOA LO FULL H = H
                ;11398  ;               USEL FIFOA H = H
                ;11399  ;               FIFOA ADRS <8:4> = H
                ;11400  ;       This combination of inputs will assert FIFO MAX L.
                ;11401  ;
                ;11402  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                ;11403  ;               BEN1 S0 H = H
                ;11404  ;               BEN1 S1 H = L
                ;11405  ;               BEN1 S2 H = H
                ;11406  ;
                ;11407  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                ;11408  ;       branch to an instruction that will assert XFER REQ H.
                ;11409  ;       The CPU will then check to insure that XFER REQ H asserted by
                ;11410  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;11411  ;
                ;11412  ;
                ;11413  ;--
                ;11414  ;*******************************************************************************
                ;11415  T.10:
U 0B4B, B65E,15 ;11416          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;11417                                                  ; CONTROL AND STATUS WORD
U 0B4C, 3E80,15 ;11418          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;11419                                                  ; STATUS WORD - BIT 15
                ;11420                                                  ; INDICATES START OF TEST TO
                ;11421                                                  ; CONSOLE
U 0B4D, 10E0,15 ;11422          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;11423  WAIT.T10.0:
U 0B4E, 08B4,E4 ;11424          JMP [WAIT.T10.0]                        ;LOOP HERE WAITING FOR
                ;11425                                                  ; CONSOLE TO RESPOND
                ;11426
U 0B4F, 65A0,15 ;11427          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;11428                                                  ; IN LS
                ;11429
U 0B50, B64A,15 ;11430          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0B51, 3E8C,15 ;11431          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;11432
                ;11433
                ;11434
U 0B52, E58A,15 ;11435          CLR LS[ERROR.MASK]
                ;11436
U 0B53, B670,15 ;11437          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0B54, 3E80,15 ;11438          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                ;11439
U 0B55, B66E,15 ;11440          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0B56, 6D80,15 ;11441          BIS WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;11442
                ;11443
                ;11444
U 0B57, B78E,15 ;11445          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
```

```
                    ;11446          BIT LS[BIT7] WITH WR[0],                    ;  BEEN RUN?
U 0B58, D94E,35     ;11447           DT(LONG)&SET.ALU.CC
U 0B59, 88B5,B1     ;11448          JMP.IF[BIT.SET] TO [SIZE.OK.T10.1]          ;IF YES THEN GO RUN TEST
                    ;11449
U 0B5A, 8870,0C     ;11450          JSR [DRIVE.SIZE]                            ;GO RUN DRIVE SIZING ROUTINE
                    ;11451  SIZE.OK.T10.1:
                    ;11452
U 0B5B, 8872,EC     ;11453          JSR [DIAG.CODE]                             ;FORCE THE IDC TO DIAG.IDLE
                    ;11454
                    ;11455          ;SELECT AN R80 DRIVE IF ONE IS AVAILABLE...ELSE SKIP TEST
                    ;11456
U 0B5C, B78E,15     ;11457          MOV LS[DRIVE.STATUS] TO WR[0]
                    ;11458
U 0B5D, 3790,95     ;11459          MOV LS[#FFFFFFF0] TO WR[1]
U 0B5E, AF42,15     ;11460          BIC WR[1] TO WR[0]                          ;CHECK BITS <3:0>
                    ;11461          CMP LS[ZERO] WITH WR[0],                    ;ANY R80S?
U 0B5F, CE9C,35     ;11462           DT(LONG)&SET.ALU.CC
U 0B60, 08BB,69     ;11463          JMP.IF[EQL] TO [CLEANUP.T10.1]              ;NO R80, CLEANUP AND END TEST
                    ;11464
U 0B61, B78E,15     ;11465          MOV LS[DRIVE.STATUS] TO WR[0]
                    ;11466          BIT LS[BIT0] WITH WR[0],                    ;IS DRIVE 0 AN R80?
U 0B62, 5940,35     ;11467           DT(LONG)&SET.ALU.CC
U 0B63, 08B6,91     ;11468          JMP.IF[BIT.SET] TO [SEL.DR0.T10.1]          ;JMP IF DRV 0 = R80
                    ;11469
                    ;11470          BIT LS[BIT1] WITH WR[0],                    ;IS DRIVE 1 AN R80?
U 0B64, D942,35     ;11471           DT(LONG)&SET.ALU.CC
U 0B65, 88B6,B1     ;11472          JMP.IF[BIT.SET] TO [SEL.DR1.T10.1]          ;JMP IF DRV 1 = R80
                    ;11473
                    ;11474          BIT LS[BIT2] WITH WR[0],                    ;IS DRIVE 2 AN R80?
U 0B66, D944,35     ;11475           DT(LONG)&SET.ALU.CC
U 0B67, 88B6,D1     ;11476          JMP.IF[BIT.SET] TO [SEL.DR2.T10.1]          ;JMP IF DRV 2 = R80
U 0B68, 08B6,F4     ;11477          JMP [SEL.DR3.T10.1]                         ;JMP AND SEL DRV 3
                    ;11478
                    ;11479
                    ;11480  SEL.DR0.T10.1:
U 0B69, 3715,15     ;11481          MOV LS[SETCSR.DS0] TO WR[2]                 ;SAV DRV SEL = 0
U 0B6A, 88B7,04     ;11482          JMP [TEST.T10.1]                            ;GO DO TEST
                    ;11483
                    ;11484  SEL.DR1.T10.1:
U 0B6B, B717,15     ;11485          MOV LS[SETCSR.DS1] TO WR[2]                 ;SAV DRV SEL = 1
U 0B6C, 88B7,04     ;11486          JMP [TEST.T10.1]                            ;GO DO TEST
                    ;11487
                    ;11488  SEL.DR2.T10.1:
U 0B6D, 3719,15     ;11489          MOV LS[SETCSR.DS2] TO WR[2]                 ;SAV DRV SEL = 2
U 0B6E, 88B7,04     ;11490          JMP [TEST.T10.1]                            ;GO DO TEST
                    ;11491
                    ;11492  SEL.DR3.T10.1:
U 0B6F, B71B,15     ;11493          MOV LS[SETCSR.DS3] TO WR[2]                 ;SAV DRV SEL = 3
                    ;11494
                    ;11495  TEST.T10.1:
U 0B70, 2F87,95     ;11496          CLR WR[3]                                   ;USE AS ADDRESS LOOP COUNTER
                    ;11497
U 0B71, 17D8,15     ;11498          PORT.CONTROL [SEL.FIFO.A]                   ;SEL FIFO A FROM THE PORT
U 0B72, 3720,15     ;11499          MOV LS[SETCSR.MAINT] TO WR[0]               ;SET UP THE CSR TO BRANCH TO
U 0B73, 370A,95     ;11500          MOV LS[SETCSR.F5] TO WR[1]                  ; THE CORRECT IDC ROUTINE
```

```
U 0B74, AEC2,15 ;11501          BIS WR[1] TO WR[0]                      ; TO SELECT FIFO A
U 0B75, 17A0,15 ;11502          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;11503                                                  ;MAINT=1, CRDY=0, F<2:0>=101
                ;11504  ;-------------------------------------------------------------------------
                ;11505  ;-------------------------------------------------------------------------
                ;11506  ;                               *******,
                ;11507  ;                               * IDC *
                ;11508  ;                               *******
                ;11509  ;-------------------------------------------------------------------------
                ;11510  ;018:
                ;11511  ;=000
                ;11512  ;DIAG.IDLE:
                ;11513  ;
                ;11514  ;       BEN0/F0,
                ;11515  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;11516  ;       BEN2/F2,
                ;11517  ;       NAD/DIAG.IDLE
                ;11518  ;-------------------------------------------------------------------
                ;11519  ;01D:
                ;11520  ;=101
                ;11521  ;
                ;11522  ;       BEN0/CRDY.L,
                ;11523  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;11524  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;11525  ;-------------------------------------------------------------------
                ;11526  ;075:
                ;11527  ;=1*1
                ;11528  ;TEST.F5:
                ;11529  ;
                ;11530  ;       FUNC/CLR.ONLINE,        ;CLR ONLINE FOR THE DRIVE SELECTED
                ;11531  ;                               ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;11532  ;
                ;11533  ;       UCMD/SET.FIFOA,         ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;11534  ;                               ; MUST USEL FIFO A
                ;11535  ;       NAD/XFER.REQ            ;DO NOT INCR DAR BETWEEN HERE
                ;11536  ;                               ; AND DIAG.IDLE
                ;11537  ;-------------------------------------------------------------------
                ;11538  ;1D8:
                ;11539  ;XFER.REQ:
                ;11540  ;
                ;11541  ;       UCMD/SET.XFER.RQST,     ;SEND XFER REQ TO THE CPU
                ;11542  ;       NAD/DIAG.WAIT
                ;11543  ;-------------------------------------------------------------------------
                ;11544  ;1D7:
                ;11545  ;DIAG.WAIT:
                ;11546  ;
                ;11547  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;11548  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;11549  ;
                ;11550  ;-------------------------------------------------------------------
                ;11551  ;159:
                ;11552  ;=*0*
                ;11553  ;DIAG.WAIT1:
                ;11554  ;
                ;11555  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
```

```
                ;11556  ;                               ; COMMAND FROM THE CPU
                ;11557  ;
                ;11558  ;-------------------------------------------------------------------------
                ;11559  ;15B:
                ;11560  ;=*1*
                ;11561  ;DIAG.WAIT2:
                ;11562  ;
                ;11563  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;11564  ;                               ; WAIT SOME MORE
                ;11565  ;
                ;11566  ;-------------------------------------------------------------------------
                ;11567  WAIT.IDC.T10.1:
U 0B76, DB00,1A ;11568          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0B77, 88B7,94 ;11569          JMP [IDC.DONE.T10.1]                    ;XFER REQ ASSERTED
U 0B78, 88B7,64 ;11570          JMP [WAIT.IDC.T10.1]                    ;WAIT SOME MORE
                ;11571
                ;11572  IDC.DONE.T10.1:
U 0B79, B700,15 ;11573          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0B7A, 17A0,15 ;11574          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0B7B, 90FA,15 ;11575          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;11576
                ;11577  LOOP.T10.1:
U 0B7C, B640,15 ;11578          MOV LS[#1] TO WR[0]
U 0B7D, BE82,15 ;11579          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                ;11580
U 0B7E, 17C0,15 ;11581          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                ;11582
U 0B7F, 3712,95 ;11583          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0B80, 3720,15 ;11584          MOV LS[SETCSR.MAINT] TO WR[0]           ; THE CORRECT IDC ROUTINE
U 0B81, AEC2,15 ;11585          BIS WR[1] TO WR[0]                      ; THAT WILL LOOP UNTIL MAX L
U 0B82, B704,95 ;11586          MOV LS[SETCSR.F2] TO WR[1]              ; ASSERTS
U 0B83, AEC2,15 ;11587          BIS WR[1] TO WR[0]
U 0B84, AEC4,15 ;11588          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0B85, 17A0,15 ;11589          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;11590                                                  ;MAINT=1, CRDY=1, F<2:0>=010
                ;11591  ;-------------------------------------------------------------------------
                ;11592  ;-------------------------------------------------------------------------
                ;11593  ;                               *******
                ;11594  ;                               * IDC *
                ;11595  ;                               *******
                ;11596  ;-------------------------------------------------------------------------
                ;11597  ;018:
                ;11598  ;=000
                ;11599  ;DIAG.IDLE:
                ;11600  ;
                ;11601  ;       BEN0/F0,
                ;11602  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;11603  ;       BEN2/F2,
                ;11604  ;       NAD/DIAG.IDLE
                ;11605  ;-------------------------------------------------------------------------
                ;11606  ;01A:
                ;11607  ;=010
                ;11608  ;
                ;11609  ;       BEN0/CRDY.L,
                ;11610  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
```

```
                    ;11611  ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                    ;11612  ;-------------------------------------------------------------------
                    ;11613  ;066:
                    ;11614  ;=1*0
                    ;11615  ;TEST.FIFO.MAX.1:
                    ;11616  ;       BEN1/FIFO.MAX.L,        ;IS FIFO MAX ASSERTED?
                    ;11617  ;       NAD/TEST.FIFO.MAX.2
                    ;11618  ;-------------------------------------------------------------------
                    ;11619  ;18D:
                    ;11620  ;=0*
                    ;11621  ;TEST.FIFO.MAX.2:
                    ;11622  ;       NAD/XFER.REQ                    ;MAX ASSERTED
                    ;11623  ;-------------------------------------------------------------------
                    ;11624  ;18F:
                    ;11625  ;=1*
                    ;11626  ;TEST.FIFOO.MAX.3:
                    ;11627  ;       NAD/TEST.FIFO.MAX.1                     ;MAX NOT ASSERTED...LOOP
                    ;11628  ;-------------------------------------------------------------------
                    ;11629
U 0B86, 3792,15     ;11630          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                    ;11631  NOP.T10.1:
                    ;11632          DEC WR[0],
U 0B87, A100,35     ;11633           DT(LONG)&SET.ALU.CC
U 0B88, 08B8,71     ;11634          JMP.IF[NEQ] TO [NOP.T10.1]
                    ;11635
U 0B89, DB00,1A     ;11636          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF MAX L ASSERTED
U 0B8A, 08BA,C4     ;11637          JMP [ERROR.T10.1]                       ;MAX L ASSERTED WHEN FIFO
                    ;11638                                                  ; ADRS WAS CLEAR
                    ;11639
U 0B8B, 2F82,95     ;11640          CLR WR[1]                               ;CALL CHECK.RESULT TO LOCK
U 0B8C, 2F80,15     ;11641          CLR WR[0]                               ; IN INTERMITTENT ERRORS
U 0B8D, BE89,95     ;11642          MOV WR[3] TO LS[ADDRESS.DATA]           ;
U 0B8E, 0869,3C     ;11643          JSR [CHECK.RESULT]
U 0B8F, 88B7,C4     ;11644          JMP [LOOP.T10.1]
                    ;11645
                    ;11646
U 0B90, 3642,15     ;11647          MOV LS[#2] TO WR[0]                     ;SET UP FOR ERROR 2
U 0B91, BE82,15     ;11648          MOV WR[0] TO LS[ERROR.NUMBER]
                    ;11649
                    ;11650
U 0B92, 378C,15     ;11651          MOV LS[#1FE] TO WR[0]                   ;ONE BEFORE MAX CNT FOR AN R80
U 0B93, 3E10,15     ;11652          MOV WR[0] TO LS[T8]
                    ;11653
U 0B94, 2F87,95     ;11654          CLR WR[3]                               ;USE TO TRACK FIFO ADRS
                    ;11655  INCR.CNTR.T10.1:
U 0B95, 97A8,15     ;11656          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                    ;11657                                                  ; TO FIFO A TO INCR ADRS CNTR
U 0B96, 2047,95     ;11658          INC WR[3]                               ;INCR ADRS TRACKER
U 0B97, B788,15     ;11659          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                    ;11660  NOP.T10.2:
                    ;11661          DEC WR[0],
U 0B98, A100,35     ;11662           DT(LONG)&SET.ALU.CC
U 0B99, 88B9,81     ;11663          JMP.IF[NEQ] TO [NOP.T10.2]
                    ;11664
U 0B9A, DB00,1A     ;11665          SKIP.IF[NO.FAST.INTERRUPT]              ;CHECK IF MAX L ASSERTED
```

```
U 0B9B, 08BA,C4 ;11666          JMP [ERROR.T10.1]                       ;MAX L ASSERTED TOO SOON
                ;11667
U 0B9C, 2F82,95 ;11668          CLR WR[1]                               ;CALL CHECK.RESULT TO LOCK
U 0B9D, 2F80,15 ;11669          CLR WR[0]                               ; IN INTERMITTENT ERRORS
U 0B9E, BE89,95 ;11670          MOV WR[3] TO LS[ADDRESS.DATA]           ;
U 0B9F, 0869,3C ;11671          JSR [CHECK.RESULT]
U 0BA0, 88B7,C4 ;11672          JMP [LOOP.T10.1]
                ;11673
                ;11674          CMP LS[T8] WITH WR[3],                  ;LAST COUNT?
U 0BA1, 4E11,B5 ;11675           DT(LONG)&SET.ALU.CC
U 0BA2, 08B9,51 ;11676          JMP.IF[NEQ] TO [INCR.CNTR.T10.1]        ;JUMP IF NOT LAST COUNT
                ;11677
U 0BA3, B788,15 ;11678          MOV LS[#3] TO WR[0]
U 0BA4, BE82,15 ;11679          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 3
U 0BA5, 97A8,15 ;11680          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A BYTE OF DATA TO FIFO A
                ;11681                                                  ; TO INCR ADRS CNTR TO MAX (FF)
                ;11682
U 0BA6, 2047,95 ;11683          INC WR[3]                               ;INCR THE ADRS TRACKER
                ;11684
U 0BA7, B788,15 ;11685          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;11686  NOP.T10.3:
                ;11687          DEC WR[0],
U 0BA8, A100,35 ;11688           DT(LONG)&SET.ALU.CC
U 0BA9, 88BA,81 ;11689          JMP.IF[NEQ] TO [NOP.T10.3]
                ;11690
                ;11691
U 0BAA, DB00,1A ;11692          SKIP.IF[NO.FAST.INTERRUPT]              ;MAX L ASSERTED?
U 0BAB, 08BB,14 ;11693          JMP [CALL.CH.RESULT.T10.1]              ;MAX L ASSERTED OK
                ;11694  ERROR.T10.1:                                    ;MAX L DID NOT ASSERT
U 0BAC, 3640,95 ;11695          MOV LS[#1] TO WR[1]                     ;FORCE AN ERROR
U 0BAD, 2F80,15 ;11696          CLR WR[0]
U 0BAE, BE89,95 ;11697          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA
U 0BAF, 0869,3C ;11698          JSR [CHECK.RESULT]
U 0BB0, 88B7,C4 ;11699          JMP [LOOP.T10.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;11700                                                  ;ELSE SKIP OTHER ERRORS AND END
                ;11701                                                  ; TEST
                ;11702  CALL.CH.RESULT.T10.1:
U 0BB1, 2F82,95 ;11703          CLR WR[1]                               ;CALL CHECK.RESULT TO LOCK
U 0BB2, 2F80,15 ;11704          CLR WR[0]                               ; IN INTERMITTENT ERRORS
U 0BB3, BE89,95 ;11705          MOV WR[3] TO LS[ADDRESS.DATA]           ;
U 0BB4, 0869,3C ;11706          JSR [CHECK.RESULT]
U 0BB5, 88B7,C4 ;11707          JMP [LOOP.T10.1]
                ;11708
                ;11709
                ;11710  CLEANUP.T10.1:
U 0BB6, 8875,3C ;11711          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;11712                                                  ; THIS TEST
                ;11713  END.T10:                                        ;END TEST
                ;11714
                ;11715
                ;11716
                ;11717
                ;11718
                ;11719
                ;11720
```

```
;11721  .PAGE  "Test 11  FIFO B ADRS CNTR MAX L BRANCH TEST 1 (M8388 IDC MODULE)"
;11722  ;++
;11723  ; Test Description:
;11724  ;
;11725  ;       This test is designed to insure that MAX L asserts on the correct
;11726  ;       FIFO B  address count (FF HEX) for an RL02 disk drive.
;11727  ;       This test will also verify that MAX L clears when the CPU issues a
;11728  ;       CLEAR.FIFO.CNTR instruction or when the IDC microcode executes a
;11729  ;       UCLR FIFO CNTR.
;11730  ;
;11731  ; Assumptions:
;11732  ;
;11733  ;       It is assumed that XFER.REQ works correctly.
;11734  ;
;11735  ; Test Steps:
;11736  ;
;11737  ;       1. Set up error mask, error number and module number in LS
;11738  ;          (for error printouts) and clear the previous error number in LS.
;11739  ;       2. If the DRIVE SIZING TEST has not been run previously then go run the
;11740  ;          DISK DRIVE SIZING ROUTINE.
;11741  ;       3. Force the IDC microcode to DIAG.IDLE.
;11742  ;       4. PSEL FIFO B.
;11743  ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;11744  ;
;11745  ;                                       *******
;11746  ;                                       * IDC *
;11747  ;                                       *******
;11748  ;
;11749  ;               IDC1. Select FIFO A, UCM = 5.
;11750  ;               IDC2. Change FIFO, UCM = 6. (to USEL FIFO B)
;11751  ;
;11752  ;       6. Set up the CSR to branch to the correct IDC microcode loop.
;11753  ;
;11754  ;                                       *******
;11755  ;                                       * IDC *
;11756  ;                                       *******
;11757  ;               The IDC microcode  will continue looping on the following
;11758  ;               steps until MAX L asserts or a CLEAR IDC is issued.
;11759  ;
;11760  ;               IDC3. Select BEN1/MAX L.
;11761  ;               IDC4. If MAX L is asserted then assert XFER REQ and go to
;11762  ;                     DIAG.WAIT.
;11763  ;               IDC5. Go to IDC3.
;11764  ;
;11765  ;       7. Clear the FIFO ADRS CNTR.
;11766  ;       8. Check that XFER REQ is unasserted.(XFER REQ will assert if MAX L is
;11767  ;                                                               asserted)
;11768  ;       9. Increment the error number.
;11769  ;      10. Select an RL02 drive or a line with no drive attached.
;11770  ;      11. Set WR[3] = 0 to use as a counter.
;11771  ;      12. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;11772  ;      13. Increment WR[3].
;11773  ;      14. Check that XFER REQ is unasserted.
;11774  ;      15. Repeat Steps 12 - 15 until WR[3] = 254 (FE HEX).
;11775  ;      16. Increment the error number.
```

```
;11776  ;       17. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;11777  ;       18. Increment WR[3].
;11778  ;       19. Check that XFER REQ is asserted.(XFER REQ asserts if MAX L asserted)
;11779  ;       20. Clear IDC.
;11780  ;       21. End test.
;11781  ;
;11782  ;
;11783  ; Errors:
;11784  ;
;11785  ;                       Printout:
;11786  ;                               EXPECTED            RECEIVED        OTHER DATA
;11787  ;                                 N/A                 N/A             WR[3]
;11788  ;
;11789  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO MAX L failed unasserted.
;11790  ;
;11791  ;       ERROR 2 - PINCR FIFO CNTR failed or MAX L asserted too soon for an
;11792  ;                 RL02 drive.
;11793  ;
;11794  ;       ERROR 3 - MAX L did not assert at 255 for an RL02 drive.
;11795  ;
;11796  ;
;11797  ; Debug:
;11798  ;
;11799  ;       A disk drive that will assert L  RL02 H at the CSR SELECTED
;11800  ;       STATUS LATCH PAL will be selected.
;11801  ;       L RL02 H is inverted to become R80 H = L.
;11802  ;
;11803  ;  ERROR 1:
;11804  ;
;11805  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;11806  ;       be decoded by the PORT INTERFACE REG PAL.
;11807  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;11808  ;
;11809  ;                       CSR 17 H = H
;11810  ;                       CSR 14 H = H
;11811  ;                       CSR 12 H = L
;11812  ;                       CSR 11 H = L
;11813  ;                       CSR 10 H = L
;11814  ;                       PORT INSTR H = H
;11815  ;                       CPU P2 H = H
;11816  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;11817  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;11818  ;       the address lines and deassert FIFO MAX L.
;11819  ;
;11820  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;11821  ;               BEN1 S0 H = H
;11822  ;               BEN1 S1 H = L
;11823  ;               BEN1 S2 H = H
;11824  ;
;11825  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;11826  ;       remain in the loop waiting for FIFO MAX L to assert and will
;11827  ;       not assert XFER REQ H.
;11828  ;       The CPU will then check to insure that XFER REQ H did not
;11829  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;11830  ;
```

```
;11831  ;  ERROR 2:
;11832  ;
;11833  ;       FIFO B is selected by the port by a PORT.CONTROL [SEL.FIFO.B]
;11834  ;       instruction so that the FIFO CNTR can be incremented from the
;11835  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;11836  ;       The inputs will be:
;11837  ;               CSR 17 H = H
;11838  ;               CSR 14 H = H
;11839  ;               CSR 12 H = H
;11840  ;               CSR 11 H = H
;11841  ;               CSR 10 H = H
;11842  ;               PORT INSTR H = H
;11843  ;               CPU P2 H = H
;11844  ;
;11845  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
;11846  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
;11847  ;
;11848  ;       FIFO B will also be selected by the IDC microcode to allow FIFO B MAX L
;11849  ;       to be asserted. The IDC microcode will issue UCMD/SET.FIFOA. This will
;11850  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;11851  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;11852  ;               UCMD 2 H = H
;11853  ;               UCMD 1 H = L
;11854  ;               UCMD 0 H = H
;11855  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;11856  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;11857  ;       The IDC microcode will execute a UCMD/CHG.FIFO. This will assert
;11858  ;       UCMD 2 H and UCMD 1 H of the IDC microword. These bits are decoded by
;11859  ;       the CONTROL STATUS REG PAL. The inputs will be:
;11860  ;               UCMD 2 H = H
;11861  ;               UCMD 1 H = H
;11862  ;               UCMD 0 H = L
;11863  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOA H = L will be
;11864  ;       inverted to USEL FIFOB H = H.
;11865  ;
;11866  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;11867  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;11868  ;       The inputs to this PAL should be:
;11869  ;               CSR 17 H = H
;11870  ;               CSR 14 H = L
;11871  ;               CSR 13 H = H
;11872  ;               CSR 12 H = L
;11873  ;               CSR 11 H = H
;11874  ;               CSR 10 H = L
;11875  ;               PORT INSTR H = H
;11876  ;               CPU P2 H = H
;11877  ;       This combination of inputs should assert BYTE L and WRITE DATA L, and
;11878  ;       STROBE DATA H.
;11879  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;11880  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;11881  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO B H = H and
;11882  ;       PORT CLOCK L as the clock input to the FIFO B ADRS CNTR HI
;11883  ;       and LO PALs. When these PALs are clocked, FIFOB ADRS<7:4> will
;11884  ;       increment.
;11885  ;
```

```
                ;11886  ;       FIFO MAX L will not asssert because the inputs to FIFOA ADRS CNTR HI
                ;11887  ;       PAL will be USEL FIFOA H = L and FIFOB MAX L = H.
                ;11888  ;       Since R80 H will be = L, FIFOB MAX L at the FIFOB ADRS CNTR HI PAL,
                ;11889  ;       will not assert until FIFOB ADRS<7:4> = H and FIFOB LO FULL H = H
                ;11890  ;       and USEL FIFO B H = H.
                ;11891  ;
                ;11892  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                ;11893  ;               BEN1 S0 H = H
                ;11894  ;               BEN1 S1 H = L
                ;11895  ;               BEN1 S2 H = H
                ;11896  ;
                ;11897  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                ;11898  ;       remain in the loop waiting for FIFO MAX L to assert and will
                ;11899  ;       not assert XFER REQ H.
                ;11900  ;       The CPU will then check to insure that XFER REQ H did not
                ;11901  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;11902  ;
                ;11903  ; ERROR 3:
                ;11904  ;       FIFOB ADRS <7:0> will be = 11111110. The FIFOB ADRS CNTR PALs will
                ;11905  ;       be clocked one more time by writing a byte of data to FIFO B. This
                ;11906  ;       will increment FIFOB ADRS <7:0> = 11111111.
                ;11907  ;       The inputs to the FIFOB ADRS CNTR HI PAL will be:
                ;11908  ;               R80 H = L
                ;11909  ;               USEL FIFOB H = H
                ;11910  ;               FIFOB LO FULL H = H
                ;11911  ;               FIFOB ADRS <7:4> H = 1111
                ;11912  ;       This combination of inputs will assert FIFOB MAX L.
                ;11913  ;
                ;11914  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
                ;11915  ;               FIFOB MAX L = L
                ;11916  ;               USEL FIFO A H = L
                ;11917  ;       This combination of inputs will assert FIFO MAX L.
                ;11918  ;
                ;11919  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                ;11920  ;               BEN1 S0 H = H
                ;11921  ;               BEN1 S1 H = L
                ;11922  ;               BEN1 S2 H = H
                ;11923  ;
                ;11924  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                ;11925  ;       branch to an instruction that will assert XFER REQ H.
                ;11926  ;       The CPU will then check to insure that XFER REQ H asserted by
                ;11927  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;11928  ;
                ;11929  ;--
                ;11930  ;*******************************************************************************
                ;11931  T.11:
U 0BB7, B65E,15 ;11932          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;11933                                                  ; CONTROL AND STATUS WORD
U 0BB8, 3E80,15 ;11934          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;11935                                                  ; STATUS WORD - BIT 15
                ;11936                                                  ; INDICATES START OF TEST TO
                ;11937                                                  ; CONSOLE
U 0BB9, 10E0,15 ;11938          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;11939  WAIT.T11.0:
U 0BBA, 88BB,A4 ;11940          JMP [WAIT.T11.0]                        ;LOOP HERE WAITING FOR
```

```
                ;11941                                          ; CONSOLE TO RESPOND
                ;11942
U 0BBB, 65A0,15 ;11943          CLR LS[PREVIOUS.ERROR]          ;CLEAR PREVIOUS ERROR NUMBER
                ;11944                                          ; IN LS
                ;11945
U 0BBC, B64A,15 ;11946          MOV LS[IDC] TO WR[0]            ;STORE MODULE CODE IN LS TO
U 0BBD, 3E8C,15 ;11947          MOV WR[0] TO LS[MODULE.NUM]     ; INDICATE IDC MODULE
                ;11948
                ;11949
                ;11950
U 0BBE, E58A,15 ;11951          CLR LS[ERROR.MASK]
                ;11952
U 0BBF, B670,15 ;11953          MOV LS[OTHER.DATA] TO WR[0]     ;SET UP TO PRINT OTHER DATA
U 0BC0, 3E80,15 ;11954          MOV WR[0] TO LS[CONTROL.STATUS] ; IF ERROR
                ;11955
U 0BC1, B66E,15 ;11956          MOV LS[NA.EXP.REC] TO WR[0]     ;SET UP TO PRINT N/A FOR
U 0BC2, 6D80,15 ;11957          BIS WR[0] TO LS[CONTROL.STATUS] ; EXPECTED & RECEIVED DATA
                ;11958
                ;11959
                ;11960
U 0BC3, B78E,15 ;11961          MOV LS[DRIVE.STATUS] TO WR[0]   ;HAS THE DRIVE SIZING ROUTINE
                ;11962          BIT LS[BIT7] WITH WR[0],        ; BEEN RUN?
U 0BC4, D94E,35 ;11963           DT(LONG)&SET.ALU.CC
U 0BC5, 88BC,71 ;11964          JMP.IF[BIT.SET] TO [SIZE.OK.T11.1] ;IF YES THEN GO RUN TEST
                ;11965
U 0BC6, 8870,0C ;11966          JSR [DRIVE.SIZE]                ;GO RUN DRIVE SIZING ROUTINE
                ;11967
                ;11968  SIZE.OK.T11.1:
                ;11969
U 0BC7, 8872,EC ;11970          JSR [DIAG.CODE]                 ;FORCE THE IDC TO DIAG.IDLE
                ;11971
                ;11972          ;SELECT AN RL02 DRIVE
                ;11973
U 0BC8, B78E,15 ;11974          MOV LS[DRIVE.STATUS] TO WR[0]
                ;11975          BIT LS[BIT0] WITH WR[0],        ;IS DRIVE 0 AN R80?
U 0BC9, 5940,35 ;11976           DT(LONG)&SET.ALU.CC
U 0BCA, 08BC,D9 ;11977          JMP.IF[BITS.CLR] TO [SET.DS0.T11.1] ;JMP IF DRV 0 IS NOT AN R80
U 0BCB, B717,15 ;11978          MOV LS[SETCSR.DS1] TO WR[2]     ;SAVE THE DATA TO SEL DRIVE 1
U 0BCC, 88BC,E4 ;11979          JMP [TEST.T11.1]
                ;11980  SET.DS0.T11.1:
U 0BCD, 3715,15 ;11981          MOV LS[SETCSR.DS0] TO WR[2]     ;SAVE THE DATA TO SEL DRIVE 0
                ;11982
                ;11983  TEST.T11.1:
                ;11984
U 0BCE, 2F87,95 ;11985          CLR WR[3]                       ;USE AS ADDR LOOP CNTR
U 0BCF, 97DC,15 ;11986          PORT.CONTROL [SEL.FIFO.B]       ;SEL FIFO B FROM THE PORT
                ;11987
U 0BD0, 3720,15 ;11988          MOV LS[SETCSR.MAINT] TO WR[0]   ;SET UP THE CSR TO BRANCH TO
U 0BD1, 370A,95 ;11989          MOV LS[SETCSR.F5] TO WR[1]      ; THE CORRECT IDC ROUTINE
U 0BD2, AEC2,15 ;11990          BIS WR[1] TO WR[0]              ; TO USEL FIFO A
U 0BD3, 17A0,15 ;11991          PORT.WRITE PORT.ADRS[CSR] WITH WR[0] ;WRITE THE CSR
                ;11992                                          ;MAINT=1, CRDY=0, F<2:0>=101
                ;11993  ;-------------------------------------------------------------------------
                ;11994  ;-------------------------------------------------------------------------
                ;11995  ;                               *******
```

```
;11996  ;                                   * IDC *
;11997  ;                                   *******
;11998  ;-------------------------------------------------------------------------
;11999  ;018:
;12000  ;=000
;12001  ;DIAG.IDLE:
;12002  ;
;12003  ;       BEN0/F0,
;12004  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
;12005  ;       BEN2/F2,
;12006  ;       NAD/DIAG.IDLE
;12007  ;-------------------------------------------------------------------------
;12008  ;01D:
;12009  ;=101
;12010  ;
;12011  ;       BEN0/CRDY.L,
;12012  ;       BEN2/MAINT,                 ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;12013  ;       NAD/TEST.FUNC5              ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;12014  ;-------------------------------------------------------------------------
;12015  ;075:
;12016  ;=1*1
;12017  ;TEST.F5:
;12018  ;
;12019  ;       FUNC/CLR.ONLINE,                    ;CLR ONLINE FOR THE DRIVE SELECTED
;12020  ;                                           ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
;12021  ;
;12022  ;       UCMD/SET.FIFOA,                     ;SELECT FIFO A (USED FOR ANT TEST WHICH
;12023  ;                                           ; MUST USEL FIFO A)
;12024  ;       NAD/XFER.REQ                        ;DO NOT INCR DAR BETWEEN HERE
;12025  ;                                           ; AND DIAG.IDLE
;12026  ;-------------------------------------------------------------------------
;12027  ;1D8:
;12028  ;XFER.REQ:
;12029  ;
;12030  ;       UCMD/SET.XFER.RQST,                 ;SEND XFER REQ TO THE CPU
;12031  ;       NAD/DIAG.WAIT
;12032  ;-------------------------------------------------------------------------
;12033  ;1D7:
;12034  ;DIAG.WAIT:
;12035  ;
;12036  ;       BEN1/XFER.REQ,              ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;12037  ;       NAD/DIAG.WAIT1              ; BEFORE RETURNING TO DIAG.IDLE
;12038  ;
;12039  ;-------------------------------------------------------------------------
;12040  ;159:
;12041  ;=*0*
;12042  ;DIAG.WAIT1:
;12043  ;
;12044  ;       NAD/DIAG.IDLE               ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;12045  ;                                   ; COMMAND FROM THE CPU
;12046  ;
;12047  ;-------------------------------------------------------------------------
;12048  ;15B:
;12049  ;=*1*
;12050  ;DIAG.WAIT2:
```

```
                ;12051  ;
                ;12052  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;12053  ;                               ; WAIT SOME MORE
                ;12054  ;
                ;12055  ;-------------------------------------------------------------------------
                ;12056  WAIT.IDC.T11.1:
U 0BD4, DB00,1A ;12057          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0BD5, 08BD,74 ;12058          JMP [IDC.DONE.T11.1]                    ;XFER REQ ASSERTED
U 0BD6, 08BD,44 ;12059          JMP [WAIT.IDC.T11.1]                    ;WAIT SOME MORE
                ;12060
                ;12061  IDC.DONE.T11.1:
U 0BD7, B700,15 ;12062          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0BD8, 17A0,15 ;12063          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0BD9, 90FA,15 ;12064          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;12065
U 0BDA, 3720,15 ;12066          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0BDB, B708,95 ;12067          MOV LS[SETCSR.F4] TO WR[1]              ; THE IDC ROUTINE THAT WILL
U 0BDC, AEC2,15 ;12068          BIS WR[1] TO WR[0]                      ; UCHANGE FIFO TO SEL FIFO B
U 0BDD, 17A0,15 ;12069          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;12070                                                  ;MAINT=1,CRDY=0,F<2:0>=100
                ;12071  ;-------------------------------------------------------------------------
                ;12072  ;-------------------------------------------------------------------------
                ;12073  ;                               *******
                ;12074  ;                               * IDC *
                ;12075  ;                               *******
                ;12076  ;-------------------------------------------------------------------------
                ;12077  ;018:
                ;12078  ;=000
                ;12079  ;DIAG.IDLE:
                ;12080  ;
                ;12081  ;       BEN0/F0,
                ;12082  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;12083  ;       BEN2/F2,
                ;12084  ;       NAD/DIAG.IDLE
                ;12085  ;-------------------------------------------------------------------------
                ;12086  ;01C:
                ;12087  ;=100
                ;12088  ;
                ;12089  ;       BEN0/CRDY.L,
                ;12090  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;12091  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;12092  ;-------------------------------------------------------------------------
                ;12093  ;06F:
                ;12094  ;=1*1
                ;12095  ;TEST.F4:
                ;12096  ;       UCMD/CHG.FIFO,                  ;CHANGE FIFO TO USEL FIFO B
                ;12097  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;12098  ;       NAD/XFER.REQ                    ;AND SET XFER REQ
                ;12099  ;-------------------------------------------------------------------------
                ;12100  ;1D8:
                ;12101  ;XFER.REQ:
                ;12102  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;12103  ;       NAD/DIAG.WAIT
                ;12104  ;-------------------------------------------------------------------------
                ;12105  ;1D7:
```

```
                    ;12106  ;DIAG.WAIT:
                    ;12107  ;
                    ;12108  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                    ;12109  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                    ;12110  ;
                    ;12111  ;-------------------------------------------------------------------------
                    ;12112  ;159:
                    ;12113  ;=*0*
                    ;12114  ;DIAG.WAIT1:
                    ;12115  ;
                    ;12116  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;12117  ;                               ; COMMAND FROM THE CPU
                    ;12118  ;
                    ;12119  ;-------------------------------------------------------------------------
                    ;12120  ;15B:
                    ;12121  ;=*1*
                    ;12122  ;DIAG.WAIT2:
                    ;12123  ;
                    ;12124  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;12125  ;                               ; WAIT SOME MORE
                    ;12126  ;
                    ;12127  ;-------------------------------------------------------------------------
                    ;12128
                    ;12129  WAIT.IDC.T11.2:
U 0BDE, DB00,1A     ;12130          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0BDF, 08BE,14     ;12131          JMP [IDC.DONE.T11.2]                    ;XFER REQ ASSERTED
U 0BE0, 08BD,E4     ;12132          JMP [WAIT.IDC.T11.2]                    ;WAIT SOME MORE
                    ;12133  IDC.DONE.T11.2:
U 0BE1, B700,15     ;12134          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0BE2, 17A0,15     ;12135          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0BE3, 90FA,15     ;12136          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                    ;12137
                    ;12138
                    ;12139  LOOP.T11.1:
                    ;12140
U 0BE4, B640,15     ;12141          MOV LS[#1] TO WR[0]
U 0BE5, BE82,15     ;12142          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                    ;12143
U 0BE6, 17C0,15     ;12144          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                    ;12145
U 0BE7, 3712,95     ;12146          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0BE8, 3720,15     ;12147          MOV LS[SETCSR.MAINT] TO WR[0]           ; THE CORRECT IDC ROUTINE
U 0BE9, AEC2,15     ;12148          BIS WR[1] TO WR[0]                      ; THAT WILL LOOP UNTIL MAX L
U 0BEA, B704,95     ;12149          MOV LS[SETCSR.F2] TO WR[1]              ; ASSERTS
U 0BEB, AEC2,15     ;12150          BIS WR[1] TO WR[0]
U 0BEC, AEC4,15     ;12151          BIS WR[2]  TO WR[0]                     ;SELECT AN RL02
U 0BED, 17A0,15     ;12152          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;12153                                                  ;MAINT=1, CRDY=1, F<2:0>=010
                    ;12154  ;-------------------------------------------------------------------------
                    ;12155  ;-------------------------------------------------------------------------
                    ;12156  ;                               *******
                    ;12157  ;                               * IDC *
                    ;12158  ;                               *******
                    ;12159  ;-------------------------------------------------------------------------
                    ;12160  ;018:
```

```
                    ;12161  ;=000
                    ;12162  ;DIAG.IDLE:
                    ;12163  ;
                    ;12164  ;       BEN0/F0,
                    ;12165  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                    ;12166  ;       BEN2/F2,
                    ;12167  ;       NAD/DIAG.IDLE
                    ;12168  ;-------------------------------------------------------------------------
                    ;12169  ;01A:
                    ;12170  ;=010
                    ;12171  ;
                    ;12172  ;       BEN0/CRDY.L,
                    ;12173  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                    ;12174  ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                    ;12175  ;-------------------------------------------------------------------------
                    ;12176  ;-------------------------------------------------------------------------
                    ;12177  ;066:
                    ;12178  ;=1*0
                    ;12179  ;TEST.FIFO.MAX.1:
                    ;12180  ;       BEN1/FIFO.MAX.L,        ;IS FIFO MAX ASSERTED?
                    ;12181  ;       NAD/TEST.FIFO.MAX.2
                    ;12182  ;-------------------------------------------------------------------------
                    ;12183  ;18D:
                    ;12184  ;=0*
                    ;12185  ;TEST.FIFO.MAX.2:
                    ;12186  ;       NAD/XFER.REQ                    ;MAX ASSERTED
                    ;12187  ;-------------------------------------------------------------------------
                    ;12188  ;18F:
                    ;12189  ;=1*
                    ;12190  ;TEST.FIFOO.MAX.3:
                    ;12191  ;       NAD/TEST.FIFO.MAX.1             ;MAX NOT ASSERTED...LOOP
                    ;12192  ;-------------------------------------------------------------------------
                    ;12193
U 0BEE, 3792,15     ;12194          MOV LS[#6] TO WR[0]             ;NOP TO WAIT FOR IDC
                    ;12195  NOP.T11.1:
                    ;12196          DEC WR[0],
U 0BEF, A100,35     ;12197           DT(LONG)&SET.ALU.CC
U 0BF0, 88BE,F1     ;12198          JMP.IF[NEQ] TO [NOP.T11.1]
                    ;12199
U 0BF1, DB00,1A     ;12200          SKIP.IF[NO.FAST.INTERRUPT]      ;SEE IF MAX L ASSERTED
U 0BF2, 88C1,44     ;12201          JMP [ERROR.T11.1]               ;MAX L ASSERTED WHEN FIFO
                    ;12202                                          ; ADRS WAS CLEAR
U 0BF3, 2F82,95     ;12203          CLR WR[1]                       ;CALL CHECK.RESULT TO LOCK
U 0BF4, 2F80,15     ;12204          CLR WR[0]                       ; IN INTERMITTENT ERRORS
U 0BF5, BE89,95     ;12205          MOV WR[3] TO LS[ADDRESS.DATA]   ;
U 0BF6, 0869,3C     ;12206          JSR [CHECK.RESULT]
U 0BF7, 08BE,44     ;12207          JMP [LOOP.T11.1]
                    ;12208
                    ;12209
                    ;12210
U 0BF8, 3642,15     ;12211          MOV LS[#2] TO WR[0]             ;SET UP FOR ERROR 2
U 0BF9, BE82,15     ;12212          MOV WR[0] TO LS[ERROR.NUMBER]
                    ;12213
                    ;12214
U 0BFA, 378A,15     ;12215          MOV LS[#FE] TO WR[0]            ;ONE BEFORE MAX CNT FOR AN RL02
```

```
U 0BFB, 3E10,15 ;12216          MOV WR[0] TO LS[T8]
                ;12217
U 0BFC, 2F87,95 ;12218          CLR WR[3]                                   ;USE TO TRACK FIFO ADRS
                ;12219  INCR.CNTR.T11.1:
U 0BFD, 97A8,15 ;12220          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;12221                                                      ; TO FIFO A TO INCR ADRS CNTR
U 0BFE, 2047,95 ;12222          INC WR[3]                                   ;INCR ADRS TRACKER
U 0BFF, B788,15 ;12223          MOV LS[#3] TO WR[0]                         ;NOP TO WAIT FOR IDC
                ;12224  NOP.T11.2:
                ;12225          DEC WR[0],
U 0C00, A100,35 ;12226           DT(LONG)&SET.ALU.CC
U 0C01, 88C0,01 ;12227          JMP.IF[NEQ] TO [NOP.T11.2]
                ;12228
U 0C02, DB00,1A ;12229          SKIP.IF[NO.FAST.INTERRUPT]                  ;CHECK IF MAX L ASSERTED
U 0C03, 88C1,44 ;12230          JMP [ERROR.T11.1]                           ;MAX L ASSERTED TOO SOON
                ;12231
U 0C04, 2F82,95 ;12232          CLR WR[1]                                   ;CALL CHECK.RESULT TO LOCK
U 0C05, 2F80,15 ;12233          CLR WR[0]                                   ; IN INTERMITTENT ERRORS
U 0C06, BE89,95 ;12234          MOV WR[3] TO LS[ADDRESS.DATA]               ;
U 0C07, 0869,3C ;12235          JSR [CHECK.RESULT]
U 0C08, 08BE,44 ;12236          JMP [LOOP.T11.1]
                ;12237
                ;12238
                ;12239          CMP LS[T8] WITH WR[3],                      ;LAST COUNT?
U 0C09, 4E11,B5 ;12240           DT(LONG)&SET.ALU.CC
U 0C0A, 88BF,D1 ;12241          JMP.IF[NEQ] TO [INCR.CNTR.T11.1]                    ;JUMP IF NOT LAST COUNT
                ;12242
U 0C0B, B788,15 ;12243          MOV LS[#3] TO WR[0]
U 0C0C, BE82,15 ;12244          MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP FOR ERROR 3
U 0C0D, 97A8,15 ;12245          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF DATA TO FIFO A
                ;12246                                                      ; TO INCR ADRS CNTR TO MAX (FF)
U 0C0E, 2047,95 ;12247          INC WR[3]                                   ;INCR THE ADRS TRACKER
                ;12248
U 0C0F, B788,15 ;12249          MOV LS[#3] TO WR[0]                         ;NOP TO WAIT FOR IDC
                ;12250  NOP.T11.3:
                ;12251          DEC WR[0],
U 0C10, A100,35 ;12252           DT(LONG)&SET.ALU.CC
U 0C11, 08C1,01 ;12253          JMP.IF[NEQ] TO [NOP.T11.3]
                ;12254
                ;12255
U 0C12, DB00,1A ;12256          SKIP.IF[NO.FAST.INTERRUPT]                  ;MAX L ASSERTED?
U 0C13, 08C1,94 ;12257          JMP [CALL.CH.RESULT.T11.1]                  ;MAX L ASSERTED OK
                ;12258  ERROR.T11.1:
U 0C14, 3640,95 ;12259          MOV LS[#1] TO WR[1]                         ;FORCE AN ERROR
U 0C15, 2F80,15 ;12260          CLR WR[0]
U 0C16, BE89,95 ;12261          MOV WR[3] TO LS[ADDRESS.DATA]               ;PRINT OTHER DATA
U 0C17, 0869,3C ;12262          JSR [CHECK.RESULT]
U 0C18, 08BE,44 ;12263          JMP [LOOP.T11.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;12264                                                      ;ELSE SKIP OTHER ERRORS AND END
                ;12265                                                      ; TEST
                ;12266
                ;12267  CALL.CH.RESULT.T11.1:
U 0C19, 2F82,95 ;12268          CLR WR[1]                                   ;CALL CHECK.RESULT TO LOCK
U 0C1A, 2F80,15 ;12269          CLR WR[0]                                   ; IN INTERMITTENT ERRORS
U 0C1B, BE89,95 ;12270          MOV WR[3] TO LS[ADDRESS.DATA]               ;
```

```
U 0C1C, 0869,3C ;12271          JSR [CHECK.RESULT]
U 0C1D, 08BE,44 ;12272          JMP [LOOP.T11.1]
                ;12273
                ;12274
                ;12275  CLEANUP.T11.1:
U 0C1E, 8875,3C ;12276          JSR [CLEANUP]                   ;CLEANUP THE CONDITIONS SET BY
                ;12277                                          ; THIS TEST
                ;12278  END.T11:                                ;END TEST
                ;12279
                ;12280
                ;12281
```

```
;12282  .PAGE  "Test 12  FIFO B ADRS CNTR MAX L BRANCH TEST 2 (M8388 IDC MODULE)"
;12283  ;++
;12284  ;
;12285  ; Test Description:
;12286  ;
;12287  ;       This test will only be run if an R80 is available on the system.
;12288  ;       This test is designed to verify that MAX L asserts on the correct
;12289  ;       address count (1FF HEX) of FIFO B when an R80 is selected.
;12290  ;
;12291  ; Assumptions:
;12292  ;
;12293  ;       It is assumed that XFER.REQ works correctly.
;12294  ;
;12295  ; Test Steps:
;12296  ;
;12297  ;       1. Set up error mask, error number and module number in LS
;12298  ;          (for error printouts) and clear the previous error number in LS.
;12299  ;       2. If the DRIVE SIZING TEST has not been run previously then
;12300  ;          go run the DISK DRIVE SIZING ROUTINE.
;12301  ;       3. If an R80 is not available then print "R80 NOT PRESENT"
;12302  ;          and go to end of test.
;12303  ;       4. Force the IDC microcode to DIAG.IDLE.
;12304  ;       5. PSEL FIFO B.
;12305  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;12306  ;
;12307  ;                                       *******
;12308  ;                                       * IDC *
;12309  ;                                       *******
;12310  ;
;12311  ;               IDC1. Select FIFO A, UCM = 5.
;12312  ;               IDC2. Change FIFO, UCM = 6. (to USEL FIFO B)
;12313  ;
;12314  ;       7. Set up the CSR to branch to the correct IDC microcode loop.
;12315  ;
;12316  ;                                       *******
;12317  ;                                       * IDC *
;12318  ;                                       *******
;12319  ;               The IDC microcode  will continue looping on the following
;12320  ;               steps until MAX L asserts or a CLEAR IDC is issued.
;12321  ;
;12322  ;               IDC3. Select BEN1/MAX L.
;12323  ;               IDC4. If MAX L is asserted then assert XFER REQ and go to
;12324  ;                     DIAG.WAIT.
;12325  ;               IDC5. Go to IDC3.
;12326  ;
;12327  ;       8. Clear the FIFO ADRS CNTR.
;12328  ;       9. Check that XFER REQ is unasserted.(XFER REQ will assert if MAX L is
;12329  ;                                                                   asserted)
;12330  ;      10. Increment the error number.
;12331  ;      11. Select an R80 drive.
;12332  ;      12. Set WR[3] = 0 to use as a counter.
;12333  ;      13. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;12334  ;      14. Increment WR[3].
;12335  ;      15. Check that XFER REQ is unasserted.
;12336  ;      16. Repeat Steps 13 - 16 until WR[3] = 510 (1FE HEX).
```

```
;12337  ;       17. Increment the error number.
;12338  ;       18. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;12339  ;       19. Increment WR[3].
;12340  ;       20. Check that XFER REw is asserted.(XFER REQ asserts if MAX L asserted)
;12341  ;       21. CLEAR IDC.
;12342  ;       22. End test.
;12343  ;
;12344  ;
;12345  ; Errors:
;12346  ;
;12347  ;                       Printout:
;12348  ;                               EXPECTED        RECEIVED        OTHER DATA
;12349  ;                                 N/A             N/A             WR[3]
;12350  ;
;12351  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO MAX L failed unasserted.
;12352  ;
;12353  ;       ERROR 2 - PINCR FIFO CNTR failed or MAX L asserted too soon for an
;12354  ;                 R80 drive.
;12355  ;
;12356  ;       ERROR 3 - MAX L did not assert at 511 for an R80 drive.
;12357  ;
;12358  ;
;12359  ; Debug:
;12360  ;       An R80 disk drive will be selected which will deassert L  RL02 H at
;12361  ;       the CSR SELECTED STATUS LATCH PAL.
;12362  ;       L RL02 H = L  is inverted to become R80 H = H.
;12363  ;  ERROR 1:
;12364  ;
;12365  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;12366  ;       be decoded by the PORT INTERFACE REG PAL.
;12367  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;12368  ;
;12369  ;                       CSR 17 H = H
;12370  ;                       CSR 14 H = H
;12371  ;                       CSR 12 H = L
;12372  ;                       CSR 11 H = L
;12373  ;                       CSR 10 H = L
;12374  ;                       PORT INSTR H = H
;12375  ;                       CPU P2 H = H
;12376  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;12377  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;12378  ;       the address lines and deassert FIFO MAX L.
;12379  ;
;12380  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
;12381  ;               BEN1 S0 H = H
;12382  ;               BEN1 S1 H = L
;12383  ;               BEN1 S2 H = H
;12384  ;
;12385  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
;12386  ;       remain in the loop waiting for FIFO MAX L to assert and will
;12387  ;       not assert XFER REQ H.
;12388  ;       The CPU will then check to insure that XFER REQ H did not
;12389  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;12390  ;
;12391  ;  ERROR 2:
```

```
;12392  ;
;12393  ;       FIFO B is selected by the port by a PORT.CONTROL [SEL.FIFO.B]
;12394  ;       instruction so that the FIFO CNTR can be incremented from the
;12395  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;12396  ;       The inputs will be:
;12397  ;               CSR 17 H = H
;12398  ;               CSR 14 H = H
;12399  ;               CSR 12 H = H
;12400  ;               CSR 11 H = H
;12401  ;               CSR 10 H = H
;12402  ;               PORT INSTR H = H
;12403  ;               CPU P2 H = H
;12404  ;
;12405  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
;12406  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
;12407  ;
;12408  ;       FIFO B will also be selected by the IDC microcode to allow FIFO B MAX L
;12409  ;       to be asserted. The IDC microcode will issue UCMD/SET.FIFOA. This will
;12410  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;12411  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;12412  ;               UCMD 2 H = H
;12413  ;               UCMD 1 H = L
;12414  ;               UCMD 0 H = H
;12415  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;12416  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;12417  ;       The IDC microcode will execute a UCMD/CHG.FIFO. This will assert
;12418  ;       UCMD 2 H and UCMD 1 H of the IDC microword. These bits are decoded by
;12419  ;       the CONTROL STATUS REG PAL. The inputs will be:
;12420  ;               UCMD 2 H = H
;12421  ;               UCMD 1 H = H
;12422  ;               UCMD 0 H = L
;12423  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOA H = L will be
;12424  ;       inverted to USEL FIFOB H = H.
;12425  ;
;12426  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;12427  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;12428  ;       The inputs to this PAL should be:
;12429  ;               CSR 17 H = H
;12430  ;               CSR 14 H = L
;12431  ;               CSR 13 H = H
;12432  ;               CSR 12 H = L
;12433  ;               CSR 11 H = H
;12434  ;               CSR 10 H = L
;12435  ;               PORT INSTR H = H
;12436  ;               CPU P2 H = H
;12437  ;       This combination of inputs should assert BYTE L and WRITE DATA L, and
;12438  ;       STROBE DATA H.
;12439  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;12440  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;12441  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO B H = H and
;12442  ;       PORT CLOCK L as the clock input to the FIFO B ADRS CNTR HI
;12443  ;       and LO PALs. When these PALs are clocked, FIFOB ADRS<8:0> will
;12444  ;       increment.
;12445  ;
;12446  ;       FIFO MAX L will not asssert because the inputs to FIFOA ADRS CNTR HI
```

```
                ;12447  ;       PAL will be USEL FIFOA H = L and FIFOB MAX L = H.
                ;12448  ;       Since R80 H will be = H, FIFOB MAX L at the FIFOB ADRS CNTR HI PAL,
                ;12449  ;       will not assert until FIFOB ADRS<8:4> = H and FIFOB LO FULL H = H
                ;12450  ;       and USEL FIFO B H = H.
                ;12451  ;
                ;12452  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                ;12453  ;               BEN1 S0 H = H
                ;12454  ;               BEN1 S1 H = L
                ;12455  ;               BEN1 S2 H = H
                ;12456  ;
                ;12457  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                ;12458  ;       remain in the loop waiting for FIFO MAX L to assert and will
                ;12459  ;       not assert XFER REQ H.
                ;12460  ;       The CPU will then check to insure that XFER REQ H did not
                ;12461  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;12462  ;
                ;12463  ;  ERROR 3:
                ;12464  ;       FIFOB ADRS <8:0> will be = 111111110. The FIFOB ADRS CNTR PALs will
                ;12465  ;       be clocked one more time by writing a byte of data to FIFO B. This
                ;12466  ;       will increment FIFOB ADRS <8:0> = 111111111.
                ;12467  ;       The inputs to the FIFOB ADRS CNTR HI PAL will be:
                ;12468  ;               R80 H = L
                ;12469  ;               USEL FIFOB H = H
                ;12470  ;               FIFOB LO FULL H = H
                ;12471  ;               FIFOB ADRS <7:4> H = 1111
                ;12472  ;       This combination of inputs will assert FIFOB MAX L.
                ;12473  ;
                ;12474  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
                ;12475  ;               FIFOB MAX L = L
                ;12476  ;               USEL FIFO A H = L
                ;12477  ;       This combination of inputs will assert FIFO MAX L.
                ;12478  ;
                ;12479  ;       When the BEN1/FIFO.MAX.L IDC microinstruction is executed:
                ;12480  ;               BEN1 S0 H = H
                ;12481  ;               BEN1 S1 H = L
                ;12482  ;               BEN1 S2 H = H
                ;12483  ;
                ;12484  ;       This will select FIFO MAX L as NUA 1 H. The IDC microcode will
                ;12485  ;       branch to an instruction that will assert XFER REQ H.
                ;12486  ;       The CPU will then check to insure that XFER REQ H asserted by
                ;12487  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;12488  ;--
                ;12489  ;*******************************************************************************
                ;12490  T.12:
U 0C1F, B65E,15 ;12491          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;12492                                                  ; CONTROL AND STATUS WORD
U 0C20, 3E80,15 ;12493          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;12494                                                  ; STATUS WORD - BIT 15
                ;12495                                                  ; INDICATES START OF TEST TO
                ;12496                                                  ; CONSOLE
U 0C21, 10E0,15 ;12497          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;12498  WAIT.T12.0:
U 0C22, 88C2,24 ;12499          JMP [WAIT.T12.0]                        ;LOOP HERE WAITING FOR
                ;12500                                                  ; CONSOLE TO RESPOND
                ;12501
```

```
U 0C23, 65A0,15 ;12502          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;12503                                                  ; IN LS
                ;12504
U 0C24, B64A,15 ;12505          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0C25, 3E8C,15 ;12506          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;12507
                ;12508
                ;12509
U 0C26, E58A,15 ;12510          CLR LS[ERROR.MASK]
                ;12511
U 0C27, B670,15 ;12512          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0C28, 3E80,15 ;12513          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                ;12514
U 0C29, B66E,15 ;12515          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0C2A, 6D80,15 ;12516          BIS WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;12517
                ;12518
                ;12519
U 0C2B, B78E,15 ;12520          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;12521          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 0C2C, D94E,35 ;12522           DT(LONG)&SET.ALU.CC
U 0C2D, 08C2,F1 ;12523          JMP.IF[BIT.SET] TO [SIZE.OK.T12.1]      ;IF YES THEN GO RUN TEST
                ;12524
U 0C2E, 8870,0C ;12525          JSR [DRIVE.SIZE]                        ;GO RUN DRIVE SIZING ROUTINE
                ;12526
                ;12527  SIZE.OK.T12.1:
                ;12528
U 0C2F, 8872,EC ;12529          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;12530
                ;12531          ;SELECT AN R80 DRIVE IF ONE IS AVAILABLE...ELSE SKIP TEST
                ;12532
U 0C30, B78E,15 ;12533          MOV LS[DRIVE.STATUS] TO WR[0]
U 0C31, 3790,95 ;12534          MOV LS[#FFFFFFF0] TO WR[1]
U 0C32, AF42,15 ;12535          BIC WR[1] TO WR[0]                      ;CHECK BITS <3:0>
                ;12536          CMP LS[ZERO] WITH WR[0],                ;ANY R80S?
U 0C33, CE9C,35 ;12537           DT(LONG)&SET.ALU.CC
U 0C34, 88C9,49 ;12538          JMP.IF[EQL] TO [CLEANUP.T12.1]          ;NO R80, CLEANUP AND END TEST
                ;12539
U 0C35, B78E,15 ;12540          MOV LS[DRIVE.STATUS] TO WR[0]
                ;12541          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0C36, 5940,35 ;12542           DT(LONG)&SET.ALU.CC
U 0C37, 08C3,D1 ;12543          JMP.IF[BIT.SET] TO [SEL.DR0.T12.1]      ;JMP IF DRV 0 = R80
                ;12544
                ;12545          BIT LS[BIT1] WITH WR[0],                ;IS DRIVE 1 AN R80?
U 0C38, D942,35 ;12546           DT(LONG)&SET.ALU.CC
U 0C39, 88C3,F1 ;12547          JMP.IF[BIT.SET] TO [SEL.DR1.T12.1]      ;JMP IF DRV 1 = R80
                ;12548
                ;12549          BIT LS[BIT2] WITH WR[0],                ;IS DRIVE 2 AN R80?
U 0C3A, D944,35 ;12550           DT(LONG)&SET.ALU.CC
U 0C3B, 88C4,11 ;12551          JMP.IF[BIT.SET] TO [SEL.DR2.T12.1]      ;JMP IF DRV 2 = R80
U 0C3C, 08C4,34 ;12552          JMP [SEL.DR3.T12.1]                     ;JMP AND SEL DR 3
                ;12553
                ;12554  SEL.DR0.T12.1:
U 0C3D, 3715,15 ;12555          MOV LS[SETCSR.DS0] TO WR[2]             ;SAV DRV SEL = 0
U 0C3E, 88C4,44 ;12556          JMP [TEST.T12.1]                        ;GO DO TEST
```

```
                ;12557
                ;12558  SEL.DR1.T12.1:
U 0C3F, B717,15 ;12559          MOV LS[SETCSR.DS1] TO WR[2]              ;SAV DRV SEL = 1
U 0C40, 88C4,44 ;12560          JMP [TEST.T12.1]                         ;GO DO TEST
                ;12561
                ;12562  SEL.DR2.T12.1:
U 0C41, 3719,15 ;12563          MOV LS[SETCSR.DS2] TO WR[2]              ;SAV DRV SEL = 2
U 0C42, 88C4,44 ;12564          JMP [TEST.T12.1]                         ;GO DO TEST
                ;12565
                ;12566  SEL.DR3.T12.1:
U 0C43, B71B,15 ;12567          MOV LS[SETCSR.DS3] TO WR[2]              ;SAV DRV SEL = 3
                ;12568
                ;12569  TEST.T12.1:
U 0C44, 2F87,95 ;12570          CLR WR[3]                                ;USE AS ADDR LOOP CNTR
                ;12571
U 0C45, 97DC,15 ;12572          PORT.CONTROL [SEL.FIFO.B]                ;SEL FIFO B FROM THE PORT
U 0C46, 3720,15 ;12573          MOV LS[SETCSR.MAINT] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 0C47, 370A,95 ;12574          MOV LS[SETCSR.F5] TO WR[1]               ; THE CORRECT IDC ROUTINE
U 0C48, AEC2,15 ;12575          BIS WR[1] TO WR[0]                       ; TO SELECT FIFO A
U 0C49, 17A0,15 ;12576          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;12577                                                   ;MAINT=1, CRDY=0, F<2:0>=101
                ;12578  ;-------------------------------------------------------------------------
                ;12579  ;-------------------------------------------------------------------------
                ;12580  ;                              *******
                ;12581  ;                              * IDC *
                ;12582  ;                              *******
                ;12583  ;-------------------------------------------------------------------------
                ;12584  ;018:
                ;12585  ;=000
                ;12586  ;DIAG.IDLE:
                ;12587  ;
                ;12588  ;       BEN0/F0,
                ;12589  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;12590  ;       BEN2/F2,
                ;12591  ;       NAD/DIAG.IDLE
                ;12592  ;-------------------------------------------------------------------------
                ;12593  ;01D:
                ;12594  ;=101
                ;12595  ;
                ;12596  ;       BEN0/CRDY.L,
                ;12597  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;12598  ;       NAD/TEST.FUNC5           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;12599  ;-------------------------------------------------------------------------
                ;12600  ;075:
                ;12601  ;=1*1
                ;12602  ;TEST.F5:
                ;12603  ;
                ;12604  ;       FUNC/CLR.ONLINE,         ;CLR ONLINE FOR THE DRIVE SELECTED
                ;12605  ;                                ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;12606  ;
                ;12607  ;       UCMD/SET.FIFOA,          ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;12608  ;                                ; MUST USEL FIFO A
                ;12609  ;       NAD/XFER.REQ             ;DO NOT INCR DAR BETWEEN HERE
                ;12610  ;                                ; AND DIAG.IDLE
                ;12611  ;-------------------------------------------------------------------------
```

```
                ;12612  ;1D8:
                ;12613  ;XFER.REQ:
                ;12614  ;
                ;12615  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;12616  ;       NAD/DIAG.WAIT
                ;12617  ;-------------------------------------------------------------------------------
                ;12618  ;1D7:
                ;12619  ;DIAG.WAIT:
                ;12620  ;
                ;12621  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;12622  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;12623  ;
                ;12624  ;-------------------------------------------------------------------------------
                ;12625  ;159:
                ;12626  ;=*0*
                ;12627  ;DIAG.WAIT1:
                ;12628  ;
                ;12629  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;12630  ;                               ; COMMAND FROM THE CPU
                ;12631  ;
                ;12632  ;-------------------------------------------------------------------------------
                ;12633  ;15B:
                ;12634  ;=*1*
                ;12635  ;DIAG.WAIT2:
                ;12636  ;
                ;12637  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;12638  ;                               ; WAIT SOME MORE
                ;12639  ;
                ;12640  ;-------------------------------------------------------------------------------
                ;12641
                ;12642  WAIT.IDC.T12.1:
U 0C4A, DB00,1A ;12643          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0C4B, 88C4,D4 ;12644          JMP [IDC.DONE.T12.1]                    ;XFER REQ ASSERTED
U 0C4C, 08C4,A4 ;12645          JMP [WAIT.IDC.T12.1]                    ;WAIT SOME MORE
                ;12646
                ;12647  IDC.DONE.T12.1:
U 0C4D, B700,15 ;12648          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0C4E, 17A0,15 ;12649          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0C4F, 90FA,15 ;12650          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;12651
U 0C50, 3720,15 ;12652          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0C51, B708,95 ;12653          MOV LS[SETCSR.F4] TO WR[1]              ; THE IDC ROUTINE THAT WILL
U 0C52, AEC2,15 ;12654          BIS WR[1] TO WR[0]                      ; UCHANGE FIFO TO SEL FIFO B
U 0C53, 17A0,15 ;12655          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;12656                                                  ;MAINT=1,CRDY=0, F<2:0>=100
                ;12657  ;-------------------------------------------------------------------------------
                ;12658  ;-------------------------------------------------------------------------------
                ;12659  ;                               *******
                ;12660  ;                               * IDC *
                ;12661  ;                               *******
                ;12662  ;-------------------------------------------------------------------------------
                ;12663  ;018:
                ;12664  ;=000
                ;12665  ;DIAG.IDLE:
                ;12666  ;
```

```
                ;12667  ;       BEN0/F0,
                ;12668  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;12669  ;       BEN2/F2,
                ;12670  ;       NAD/DIAG.IDLE
                ;12671  ;-------------------------------------------------------------------------
                ;12672  ;01C:
                ;12673  ;=100
                ;12674  ;
                ;12675  ;       BEN0/CRDY.L,
                ;12676  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;12677  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;12678  ;-------------------------------------------------------------------------
                ;12679  ;06F:
                ;12680  ;=1*1
                ;12681  ;TEST.F4:
                ;12682  ;       UCMD/CHG.FIFO,                  ;CHANGE FIFO TO USEL FIFO B
                ;12683  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;12684  ;       NAD/XFER.REQ                    ;AND SET XFER REQ
                ;12685  ;-------------------------------------------------------------------------
                ;12686  ;1D8:
                ;12687  ;XFER.REQ:
                ;12688  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;12689  ;       NAD/DIAG.WAIT
                ;12690  ;-------------------------------------------------------------------------
                ;12691  ;1D7:
                ;12692  ;DIAG.WAIT:
                ;12693  ;
                ;12694  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;12695  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;12696  ;
                ;12697  ;-------------------------------------------------------------------------
                ;12698  ;159:
                ;12699  ;=*0*
                ;12700  ;DIAG.WAIT1:
                ;12701  ;
                ;12702  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;12703  ;                               ; COMMAND FROM THE CPU
                ;12704  ;
                ;12705  ;-------------------------------------------------------------------------
                ;12706  ;15B:
                ;12707  ;=*1*
                ;12708  ;DIAG.WAIT2:
                ;12709  ;
                ;12710  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;12711  ;                               ; WAIT SOME MORE
                ;12712  ;
                ;12713  ;-------------------------------------------------------------------------
                ;12714  WAIT.IDC.T12.2:
U 0C54, DB00,1A ;12715          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0C55, 08C5,74 ;12716          JMP [IDC.DONE.T12.2]                    ;XFER REQ ASSERTED
U 0C56, 08C5,44 ;12717          JMP [WAIT.IDC.T12.2]                    ;WAIT SOME MORE
                ;12718  IDC.DONE.T12.2:
U 0C57, B700,15 ;12719          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0C58, 17A0,15 ;12720          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0C59, 90FA,15 ;12721          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
```

```
                ;12722
                ;12723  LOOP.T12.1:
                ;12724
U 0C5A, B640,15 ;12725          MOV LS[#1] TO WR[0]                     ;SET UP FOR ERROR 1
U 0C5B, BE82,15 ;12726          MOV WR[0] TO LS[ERROR.NUMBER]
                ;12727
U 0C5C, 17C0,15 ;12728          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                ;12729
U 0C5D, 3712,95 ;12730          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0C5E, 3720,15 ;12731          MOV LS[SETCSR.MAINT] TO WR[0]           ; THE CORRECT IDC ROUTINE
U 0C5F, AEC2,15 ;12732          BIS WR[1] TO WR[0]                      ; THAT WILL LOOP UNTIL MAX L
U 0C60, B704,95 ;12733          MOV LS[SETCSR.F2] TO WR[1]              ; ASSERTS
U 0C61, AEC2,15 ;12734          BIS WR[1] TO WR[0]
U 0C62, AEC4,15 ;12735          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0C63, 17A0,15 ;12736          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;12737                                                  ;MAINT=1, CRDY=1, F<2:0>=010
                ;12738  ;-------------------------------------------------------------------------
                ;12739  ;-------------------------------------------------------------------------
                ;12740  ;                               *******
                ;12741  ;                               * IDC *
                ;12742  ;                               *******
                ;12743  ;-------------------------------------------------------------------------
                ;12744  ;018:
                ;12745  ;=000
                ;12746  ;DIAG.IDLE:
                ;12747  ;
                ;12748  ;       BEN0/F0,
                ;12749  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;12750  ;       BEN2/F2,
                ;12751  ;       NAD/DIAG.IDLE
                ;12752  ;-------------------------------------------------------------------------
                ;12753  ;01A:
                ;12754  ;=010
                ;12755  ;
                ;12756  ;       BEN0/CRDY.L,
                ;12757  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;12758  ;       NAD/TEST.FUNC2          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;12759  ;-------------------------------------------------------------------------
                ;12760  ;066:
                ;12761  ;=1*0
                ;12762  ;TEST.FIFO.MAX.1:
                ;12763  ;       BEN1/FIFO.MAX.L,        ;FIFO MAX ASSERTED?
                ;12764  ;       NAD/TEST.FIFO.MAX.2
                ;12765  ;-------------------------------------------------------------------------
                ;12766  ;18D:
                ;12767  ;=0*
                ;12768  ;TEST.FIFO.MAX.2:
                ;12769  ;       NAD/XFER.REQ                    ;MAX ASSERTED
                ;12770  ;-------------------------------------------------------------------------
                ;12771  ;18F:
                ;12772  ;=1*
                ;12773  ;TEST.FIFO.MAX.3:
                ;12774  ;       NAD/TEST.FIFO.MAX.1                     ;MAX NOT ASSERTED...LOOP
                ;12775  ;-------------------------------------------------------------------------
                ;12776
```

```
U 0C64, 3792,15 ;12777          MOV LS[#6] TO WR[0]                          ;NOP TO WAIT FOR IDC
                ;12778  NOP.T12.1:
                ;12779          DEC WR[0],
U 0C65, A100,35 ;12780           DT(LONG)&SET.ALU.CC
U 0C66, 88C6,51 ;12781          JMP.IF[NEQ] TO [NOP.T12.1]
                ;12782
U 0C67, DB00,1A ;12783          SKIP.IF[NO.FAST.INTERRUPT]                   ;SEE IF MAX L ASSERTED
U 0C68, 08C8,A4 ;12784          JMP [ERROR.T12.1]                            ;MAX L ASSERTED WHEN FIFO
                ;12785                                                       ; ADRS WAS CLEAR
                ;12786
U 0C69, 2F80,15 ;12787          CLR WR[0]
U 0C6A, 2F82,95 ;12788          CLR WR[1]                                    ;CALL CHECK.RESULT TO LOCK
U 0C6B, BE89,95 ;12789          MOV WR[3] TO LS[ADDRESS.DATA]                ; IN INTERMITTENT ERRORS
U 0C6C, 0869,3C ;12790          JSR [CHECK.RESULT]
U 0C6D, 88C5,A4 ;12791          JMP [LOOP.T12.1]
                ;12792
                ;12793
U 0C6E, 3642,15 ;12794          MOV LS[#2] TO WR[0]                          ;SET UP FOR ERROR 2
U 0C6F, BE82,15 ;12795          MOV WR[0] TO LS[ERROR.NUMBER]
                ;12796
                ;12797
U 0C70, 378C,15 ;12798          MOV LS[#1FE] TO WR[0]                        ;ONE BEFORE MAX CNT FOR AN R80
U 0C71, 3E10,15 ;12799          MOV WR[0] TO LS[T8]
                ;12800
U 0C72, 2F87,95 ;12801          CLR WR[3]                                    ;USE TO TRACK FIFO ADRS
                ;12802  INCR.CNTR.T12.1:
U 0C73, 97A8,15 ;12803          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;12804                                                       ; TO FIFO A TO INCR ADRS CNTR
U 0C74, 2047,95 ;12805          INC WR[3]                                    ;INCR ADRS TRACKER
U 0C75, B788,15 ;12806          MOV LS[#3] TO WR[0]                          ;NOP TO WAIT FOR IDC
                ;12807  NOP.T12.2:
                ;12808          DEC WR[0],
U 0C76, A100,35 ;12809           DT(LONG)&SET.ALU.CC
U 0C77, 08C7,61 ;12810          JMP.IF[NEQ] TO [NOP.T12.2]
                ;12811
                ;12812
U 0C78, DB00,1A ;12813          SKIP.IF[NO.FAST.INTERRUPT]                   ;CHECK IF MAX L ASSERTED
U 0C79, 08C8,A4 ;12814          JMP [ERROR.T12.1]                            ;MAX L ASSERTED TOO SOON
                ;12815
U 0C7A, 2F80,15 ;12816          CLR WR[0]                                    ;CALL CHECK.RESULT TO LOCK
U 0C7B, 2F82,95 ;12817          CLR WR[1]                                    ; IN INTERMITTENT ERRORS
U 0C7C, BE89,95 ;12818          MOV WR[3] TO LS[ADDRESS.DATA]
U 0C7D, 0869,3C ;12819          JSR [CHECK.RESULT]
U 0C7E, 88C5,A4 ;12820          JMP [LOOP.T12.1]
                ;12821
                ;12822
                ;12823          CMP LS[T8] WITH WR[3],                       ;LAST COUNT?
U 0C7F, 4E11,B5 ;12824           DT(LONG)&SET.ALU.CC
U 0C80, 08C7,31 ;12825          JMP.IF[NEQ] TO [INCR.CNTR.T12.1]             ;JUMP IF NOT LAST COUNT
                ;12826
U 0C81, B788,15 ;12827          MOV LS[#3] TO WR[0]
U 0C82, BE82,15 ;12828          MOV WR[0] TO LS[ERROR.NUMBER]                ;SET UP FOR ERROR 3
                ;12829
U 0C83, 97A8,15 ;12830          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A BYTE OF DATA TO FIFO A
                ;12831                                                       ; TO INCR ADRS CNTR TO MAX (FF)
```

```
U 0C84, B788,15 ;12832          MOV LS[#3] TO WR[0]                    ;NOP TO WAIT FOR IDC
                ;12833  NOP.T12.3:
                ;12834          DEC WR[0],
U 0C85, A100,35 ;12835           DT(LONG)&SET.ALU.CC
U 0C86, 08C8,51 ;12836          JMP.IF[NEQ] TO [NOP.T12.3]
                ;12837
U 0C87, 2047,95 ;12838          INC WR[3]                              ;INCR THE ADRS TRACKER
U 0C88, DB00,1A ;12839          SKIP.IF[NO.FAST.INTERRUPT]             ;MAX L ASSERTED?
U 0C89, 08C8,F4 ;12840          JMP [CALL.CH.RESULT.T12.1]             ;MAX L ASSERTED OK
                ;12841  ERROR.T12.1:                                   ;MAX L DID NOT ASSERT
U 0C8A, 3640,95 ;12842          MOV LS[#1] TO WR[1]                    ;FORCE AN ERROR
U 0C8B, 2F80,15 ;12843          CLR WR[0]
U 0C8C, BE89,95 ;12844          MOV WR[3] TO LS[ADDRESS.DATA]          ;PRINT OTHER DATA
U 0C8D, 0869,3C ;12845          JSR [CHECK.RESULT]
U 0C8E, 88C5,A4 ;12846          JMP [LOOP.T12.1]                       ;LOOP HERE IF ERR & LOE IS SET
                ;12847                                                 ;ELSE SKIP OTHER ERRORS AND END
                ;12848                                                 ; TEST
                ;12849  CALL.CH.RESULT.T12.1:
U 0C8F, 2F80,15 ;12850          CLR WR[0]                              ;CALL CHECK.RESULT TO LOCK
U 0C90, 2F82,95 ;12851          CLR WR[1]                              ; IN INTERMITTENT ERRORS
U 0C91, BE89,95 ;12852          MOV WR[3] TO LS[ADDRESS.DATA]
U 0C92, 0869,3C ;12853          JSR [CHECK.RESULT]
U 0C93, 88C5,A4 ;12854          JMP [LOOP.T12.1]
                ;12855
                ;12856  CLEANUP.T12.1:
U 0C94, 8875,3C ;12857          JSR [CLEANUP]                          ;CLEANUP THE CONDITIONS SET BY
                ;12858                                                 ; THIS TEST
                ;12859  END.T12:                                       ;END TEST
                ;12860
                ;12861
                ;12862
```

```
;12863  .PAGE  "Test 13  FIFO A ADRS CNTR OVFLW L BRANCH TEST 1 (M8388 IDC MODULE)"
;12864  ;++
;12865  ;
;12866  ; Test Description:
;12867  ;
;12868  ;       This test is designed to insure that OVFLW L asserts on the correct
;12869  ;       FIFO A  address count (100 HEX) for an RL02 disk drive.
;12870  ;       This test will also verify that OVFLW L clears when the CPU issues a
;12871  ;       CLEAR.FIFO.CNTR instruction. BEN1/OVFLW L branch condition will also
;12872  ;       be verified.
;12873  ;       The test will then verify that USET FIFO OVFLW works correctly.
;12874  ;
;12875  ; Assumptions:
;12876  ;
;12877  ;       It is assumed that XFER.REQ works correctly.
;12878  ;
;12879  ; Test Steps:
;12880  ;
;12881  ;       1. Set up error mask, error number and module number in LS
;12882  ;          (for error printouts) and clear the previous error number in LS.
;12883  ;       2. If the DRIVE SIZING TEST has not been run previously then
;12884  ;          go run the DISK DRIVE SIZING ROUTINE.
;12885  ;       3. Force the IDC microcode to DIAG.IDLE.
;12886  ;       4. PSEL FIFO A.
;12887  ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;12888  ;
;12889  ;                                       *******
;12890  ;                                       * IDC *
;12891  ;                                       *******
;12892  ;
;12893  ;               IDC1. Select FIFO A, UCM = 5.
;12894  ;
;12895  ;       6. Set up the CSR to branch to the correct IDC microcode loop.
;12896  ;
;12897  ;                                       *******
;12898  ;                                       * IDC *
;12899  ;                                       *******
;12900  ;               The IDC microcode  will continue looping on the following
;12901  ;               steps until OVFLW L asserts or a CLEAR IDC is issued.
;12902  ;
;12903  ;               IDC2. Select BEN1/OVFLW L.
;12904  ;               IDC3. If OVFLW L is asserted then assert XFER REQ and go to
;12905  ;                     DIAG.WAIT.
;12906  ;               IDC4. Go to IDC2.
;12907  ;
;12908  ;        7. Clear the FIFO ADRS CNTR.
;12909  ;        8. If XFER REQ is asserted (OVFLW asserted) then issue error.
;12910  ;        9. Increment the error number.
;12911  ;       10. Select an RL02 drive or a line with no drive attached.
;12912  ;       11. Set WR[3] = 0 to use as a counter.
;12913  ;       12. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;12914  ;       13. Increment WR[3].
;12915  ;       14. If XFER REQ is asserted (OVFLW asserted) then issue error.
;12916  ;       15. Repeat Steps 12 - 15 until WR[3] = 255 (FF HEX).
;12917  ;       16. Increment the error number.
```

```
;12918  ;       17. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;12919  ;       18. Increment WR[3].
;12920  ;       19. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;12921  ;       20. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;12922  ;       21. Increment the error number.
;12923  ;       22. Force the IDC microcode to DIAG.IDLE.
;12924  ;       23. Clear the FIFO ADRS CNTR.
;12925  ;       24. Set up the CSR to branch to the correct IDC routine.
;12926  ;
;12927  ;                                       *******
;12928  ;                                       * IDC *
;12929  ;                                       *******
;12930  ;
;12931  ;               IDC5. Set FUNC<35:32> = 0E, USET.FIFO OVFLW.
;12932  ;               IDC6. Perform Steps IDC2 - IDC4.
;12933  ;
;12934  ;       25. NOP to allow IDC time to branch.
;12935  ;       26. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;12936  ;       27. CLEAR IDC.
;12937  ;       28. End test.
;12938  ;
;12939  ;
;12940  ;
;12941  ; Errors:
;12942  ;
;12943  ;                   Printout:
;12944  ;                           EXPECTED        RECEIVED        OTHER DATA
;12945  ;                             N/A             N/A             WR[3]
;12946  ;
;12947  ;
;12948  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO OVFLW L failed unasserted.
;12949  ;
;12950  ;       ERROR 2 - PINCR FIFO CNTR failed or OVFLW L asserted too soon for an
;12951  ;                 RL02 drive.
;12952  ;
;12953  ;       ERROR 3 - OVFLW  L did not assert at 256 for an RL02 drive.
;12954  ;
;12955  ;       ERROR 4 - USET FIFO OVFLW did not set OVFLW  L.
;12956  ;
;12957  ;
;12958  ; Debug:
;12959  ;
;12960  ;       A disk drive that will assert L  RL02 H at the CSR SELECTED
;12961  ;       STAUS LATCH PAL will be selected.
;12962  ;       L RL02 H is inverted to become R80 H = L.
;12963  ;
;12964  ;  ERROR 1:
;12965  ;
;12966  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;12967  ;       be decoded by the PORT INTERFACE REG PAL.
;12968  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;12969  ;
;12970  ;                           CSR 17 H = H
;12971  ;                           CSR 14 H = H
;12972  ;                           CSR 12 H = L
```

```
;12973  ;                       CSR 11 H = L
;12974  ;                       CSR 10 H = L
;12975  ;                       PORT INSTR H = H
;12976  ;                       CPU P2 H = H
;12977  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;12978  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear
;12979  ;       FIFO OVFLW L.
;12980  ;
;12981  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;12982  ;               BEN1 S0 H = L
;12983  ;               BEN1 S1 H = L
;12984  ;               BEN1 S2 H = H
;12985  ;
;12986  ;       This will select FIFO OVFLW  L as NUA 1 H. The IDC microcode will
;12987  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;12988  ;       not assert XFER REQ H.
;12989  ;       The CPU will then check to insure that XFER REQ H did not
;12990  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;12991  ;
;12992  ;  ERROR 2:
;12993  ;
;12994  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;12995  ;       instruction so that the FIFO CNTR can be incremented from the
;12996  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;12997  ;       The inputs will be:
;12998  ;               CSR 17 H = H
;12999  ;               CSR 14 H = H
;13000  ;               CSR 12 H = H
;13001  ;               CSR 11 H = H
;13002  ;               CSR 10 H = L
;13003  ;               PORT INSTR H = H
;13004  ;               CPU P2 H = H
;13005  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;13006  ;
;13007  ;       FIFO A will also be selected by the IDC microcode to allow FIFO A
;13008  ;       OVFLW L to be asserted.
;13009  ;       The IDC microcode will issue UCMD/SET.FIFOA. This will
;13010  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;13011  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;13012  ;               UCMD 2 H = H
;13013  ;               UCMD 1 H = L
;13014  ;               UCMD 0 H = H
;13015  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;13016  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;13017  ;
;13018  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;13019  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;13020  ;       The inputs to this PAL should be:
;13021  ;               CSR 17 H = H
;13022  ;               CSR 14 H = L
;13023  ;               CSR 13 H = H
;13024  ;               CSR 12 H = L
;13025  ;               CSR 11 H = H
;13026  ;               CSR 10 H = L
;13027  ;               PORT INSTR H = H
```

```
;13028  ;                CPU P2 H = H
;13029  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;13030  ;       STROBE DATA H.
;13031  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;13032  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;13033  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO A H = H and
;13034  ;       PORT CLOCK L as the clock input to the FIFO A ADRS CNTR HI
;13035  ;       and LO PALs. When these PALs are clocked, FIFOA ADRS <8:0> H will
;13036  ;       increment.
;13037  ;       R80 H will be = L so FIFOA OVFLW L will not assert until
;13038  ;       FIFOA ADRS<7:4> = H and FIFOA LO FULL H = H and USEL FIFO A H = H
;13039  ;       and then the PAL must be clocked on more time by writing one more byte
;13040  ;       of data to FIFO A to assert PINCR FIFO CNTR H. FIFO OVFLW L will assert
;13041  ;       20 ns after FIFOA OVFLW L.
;13042  ;
;13043  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;13044  ;               BEN1 S0 H = L
;13045  ;               BEN1 S1 H = L
;13046  ;               BEN1 S2 H = H
;13047  ;
;13048  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;13049  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;13050  ;       not assert XFER REQ H.
;13051  ;       The CPU will then check to insure that XFER REQ H did not
;13052  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;13053  ;
;13054  ; ERROR 3:
;13055  ;
;13056  ;       FIFOA ADRS <7:0> will be = 11111111. The FIFOA ADRS CNTR PALs will
;13057  ;       be clocked one more time by writing a byte of data to FIFO A. This
;13058  ;       will clock the FIFOA ADRS CNTR HI PAL.
;13059  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
;13060  ;               R80 H = L
;13061  ;               FIFOA LO FULL H = H
;13062  ;               USEL FIFOA H = H
;13063  ;               FIFOA ADRS <7:4> = H
;13064  ;       This combination of inputs will assert FIFOA OVFLW L. Approximately
;13065  ;       20ns later OVFLW L will assert.
;13066  ;
;13067  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;13068  ;               BEN1 S0 H = L
;13069  ;               BEN1 S1 H = L
;13070  ;               BEN1 S2 H = H
;13071  ;
;13072  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;13073  ;       branch to an instruction that will assert XFER REQ H.
;13074  ;       The CPU will then check to insure that XFER REQ H asserted by
;13075  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
;13076  ;
;13077  ;
;13078  ; ERROR 4:
;13079  ;
;13080  ;       The FIFO A ADRS CNTR PAL will be cleared which will insure that
;13081  ;       FIFO OVFLW L is not asserted. The IDC microcode will then branch to
;13082  ;       an instruction of FUNC/SET.FIFO.OVF. The output of the microsequencer
```

```
                    ;13083  ;       will be:
                    ;13084  ;               UFUNC 3 H = H
                    ;13085  ;               UFUNC 2 H = H
                    ;13086  ;               UFUNC 1 H = H
                    ;13087  ;               UFUNC 0 H = L
                    ;13088  ;       These bits will be decoded and USET FIFO OVF L will assert. This
                    ;13089  ;       signal is an input to the FIFOA ADRS CNTR HI PAL. USEL FIFOA H will
                    ;13090  ;       also be asserted. When the PAL is clocked by INCR.FIFO.CNTR/ON,
                    ;13091  ;       FIFOA OVFLW L will assert. Approximately 20ns later, FIFO OVFLW L
                    ;13092  ;       will assert.
                    ;13093  ;
                    ;13094  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
                    ;13095  ;               BEN1 S0 H = L
                    ;13096  ;               BEN1 S1 H = L
                    ;13097  ;               BEN1 S2 H = H
                    ;13098  ;
                    ;13099  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
                    ;13100  ;       branch to an instruction that will assert XFER REQ H.
                    ;13101  ;       The CPU will then check to insure that XFER REQ H asserted by
                    ;13102  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;13103  ;
                    ;13104  ;--
                    ;13105  ;*******************************************************************************
                    ;13106  T.13:
U 0C95, B65E,15     ;13107          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;13108                                                  ; CONTROL AND STATUS WORD
U 0C96, 3E80,15     ;13109          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;13110                                                  ; STATUS WORD - BIT 15
                    ;13111                                                  ; INDICATES START OF TEST TO
                    ;13112                                                  ; CONSOLE
U 0C97, 10E0,15     ;13113          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;13114  WAIT.T13.0:
U 0C98, 08C9,84     ;13115          JMP [WAIT.T13.0]                        ;LOOP HERE WAITING FOR
                    ;13116                                                  ; CONSOLE TO RESPOND
                    ;13117
U 0C99, 65A0,15     ;13118          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;13119                                                  ; IN LS
                    ;13120
U 0C9A, B64A,15     ;13121          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0C9B, 3E8C,15     ;13122          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;13123
                    ;13124
                    ;13125
U 0C9C, E58A,15     ;13126          CLR LS[ERROR.MASK]
                    ;13127
U 0C9D, B670,15     ;13128          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0C9E, 3E80,15     ;13129          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                    ;13130
U 0C9F, B66E,15     ;13131          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0CA0, 6D80,15     ;13132          BIS WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                    ;13133
                    ;13134
                    ;13135
U 0CA1, B78E,15     ;13136          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                    ;13137          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
```

```
U 0CA2, D94E,35 ;13138          DT(LONG)&SET.ALU.CC
U 0CA3, 88CA,51 ;13139          JMP.IF[BIT.SET] TO [SIZE.OK.T13.1]      ;IF YES THEN GO RUN TEST
                ;13140
U 0CA4, 8870,0C ;13141          JSR [DRIVE.SIZE]                        ;GO RUN DRIVE SIZING ROUTINE
                ;13142
                ;13143  SIZE.OK.T13.1:
                ;13144
U 0CA5, 8872,EC ;13145          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;13146
                ;13147          ;SELECT AN RL02 DRIVE
                ;13148
U 0CA6, B78E,15 ;13149          MOV LS[DRIVE.STATUS] TO WR[0]
                ;13150          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0CA7, 5940,35 ;13151           DT(LONG)&SET.ALU.CC
U 0CA8, 88CA,B9 ;13152          JMP.IF[BITS.CLR] TO [SET.DS0.T13.1]     ;JMP IF DRV 0 IS NOT AN R80
U 0CA9, B717,15 ;13153          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 0CAA, 88CA,C4 ;13154          JMP [TEST.T13.1]
                ;13155  SET.DS0.T13.1:
U 0CAB, 3715,15 ;13156          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;13157
                ;13158  TEST.T13.1:
                ;13159
U 0CAC, 2F87,95 ;13160          CLR WR[3]                               ;USE AS ADDR LOOP CNTR
                ;13161
U 0CAD, 17D8,15 ;13162          PORT.CONTROL [SEL.FIFO.A]               ;SEL FIFO A FROM THE PORT
U 0CAE, 3720,15 ;13163          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0CAF, 370A,95 ;13164          MOV LS[SETCSR.F5] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 0CB0, AEC2,15 ;13165          BIS WR[1] TO WR[0]                      ; TO USEL FIFO A
U 0CB1, 17A0,15 ;13166          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;13167                                                  ;MAINT=1, CRDY=0, F<2:0>=101
                ;13168  ;USEL FIFO A
                ;13169  ;-------------------------------------------------------------------------------
                ;13170  ;-------------------------------------------------------------------------------
                ;13171  ;                               *******
                ;13172  ;                               * IDC *
                ;13173  ;                               *******
                ;13174  ;-------------------------------------------------------------------------------
                ;13175  ;018:
                ;13176  ;=000
                ;13177  ;DIAG.IDLE:
                ;13178  ;
                ;13179  ;       BEN0/F0,
                ;13180  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;13181  ;       BEN2/F2,
                ;13182  ;       NAD/DIAG.IDLE
                ;13183  ;-------------------------------------------------------------------
                ;13184  ;01D:
                ;13185  ;=101
                ;13186  ;
                ;13187  ;       BEN0/CRDY.L,
                ;13188  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;13189  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;13190  ;-------------------------------------------------------------------
                ;13191  ;075:
                ;13192  ;=1*1
```

```
                ;13193  ;TEST.F5:
                ;13194  ;
                ;13195  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;13196  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;13197  ;
                ;13198  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;13199  ;                                       ; MUST USEL FIFO A)
                ;13200  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;13201  ;                                       ; AND DIAG.IDLE
                ;13202  ;-------------------------------------------------------------------------
                ;13203  ;1D8:
                ;13204  ;XFER.REQ:
                ;13205  ;
                ;13206  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;13207  ;       NAD/DIAG.WAIT
                ;13208  ;-------------------------------------------------------------------------
                ;13209  ;1D7:
                ;13210  ;DIAG.WAIT:
                ;13211  ;
                ;13212  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;13213  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;13214  ;
                ;13215  ;-------------------------------------------------------------------------
                ;13216  ;159:
                ;13217  ;=*0*
                ;13218  ;DIAG.WAIT1:
                ;13219  ;
                ;13220  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;13221  ;                               ; COMMAND FROM THE CPU
                ;13222  ;
                ;13223  ;-------------------------------------------------------------------------
                ;13224  ;15B:
                ;13225  ;=*1*
                ;13226  ;DIAG.WAIT2:
                ;13227  ;
                ;13228  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;13229  ;                               ; WAIT SOME MORE
                ;13230  ;
                ;13231  ;-------------------------------------------------------------------------
                ;13232
                ;13233  WAIT.IDC.T13.1:
U 0CB2, DB00,1A ;13234          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0CB3, 08CB,54 ;13235          JMP [IDC.DONE.T13.1]                    ;XFER REQ ASSERTED
U 0CB4, 88CB,24 ;13236          JMP [WAIT.IDC.T13.1]                    ;WAIT SOME MORE
                ;13237
                ;13238  IDC.DONE.T13.1:
U 0CB5, B700,15 ;13239          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0CB6, 17A0,15 ;13240          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0CB7, 90FA,15 ;13241          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;13242
                ;13243  LOOP.T13.1:
U 0CB8, B640,15 ;13244          MOV LS[#1] TO WR[0]
U 0CB9, BE82,15 ;13245          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                ;13246
U 0CBA, 17C0,15 ;13247          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
```

```
                ;13248
U 0CBB, 3712,95 ;13249          MOV LS[SETCSR.CRDY] TO WR[1]             ;SET UP THE CSR TO BRANCH TO
U 0CBC, B706,15 ;13250          MOV LS[SETCSR.F3] TO WR[0]               ; THE CORRECT IDC ROUTINE THAT
U 0CBD, AEC2,15 ;13251          BIS WR[1] TO WR[0]                       ; WILL SET XFER REQ WHEN OVFLW
                ;13252                                                   ; ASSERTS
U 0CBE, AEC4,15 ;13253          BIS WR[2] TO WR[0]                       ;SELECT AN RL02
U 0CBF, 17A0,15 ;13254          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;13255                                                   ;MAINT=0, CRDY=1, F<2:0>=011
                ;13256  ;-------------------------------------------------------------------------------
                ;13257  ;-------------------------------------------------------------------------------
                ;13258  ;                               *******
                ;13259  ;                               * IDC *
                ;13260  ;                               *******
                ;13261  ;-------------------------------------------------------------------------------
                ;13262  ;018:
                ;13263  ;=000
                ;13264  ;DIAG.IDLE:
                ;13265  ;
                ;13266  ;       BEN0/F0,
                ;13267  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;13268  ;       BEN2/F2,
                ;13269  ;       NAD/DIAG.IDLE
                ;13270  ;-------------------------------------------------------------------
                ;13271  ;018:
                ;13272  ;=011
                ;13273  ;       BEN0/CRDY.L,
                ;13274  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;13275  ;       NAD/TEST.FUNC3           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;13276  ;-------------------------------------------------------------------
                ;13277  ;068:
                ;13278  ;=0*0
                ;13279  ;TEST.FUNC3:
                ;13280  ;
                ;13281  ;TEST.FIFO.OVLW.0:
                ;13282  ;       BEN1/FIFO.OVFLW.L,       ;IS FIFO OVFLW ASSERTED?
                ;13283  ;       NAD/TEST.FIFO.OVFLW.1
                ;13284  ;-------------------------------------------------------------------
                ;13285  ;190:
                ;13286  ;=0*
                ;13287  ;TEST.FIFO.OVFLW.1:
                ;13288  ;
                ;13289  ;       NAD/XFER.REQ                     ;OVFLW ASSERTED
                ;13290  ;-------------------------------------------------------------------
                ;13291  ;192:
                ;13292  ;=1*
                ;13293  ;
                ;13294  ;       NAD/TEST.FIFO.OVFLW.0            ;OVFLW NOT ASSERTED...LOOP
                ;13295  ;-------------------------------------------------------------------
                ;13296
                ;13297
U 0CC0, 3792,15 ;13298          MOV LS[#6] TO WR[0]                      ;NOP TO WAIT FOR IDC
                ;13299  NOP.T13.1:
                ;13300          DEC WR[0],
U 0CC1, A100,35 ;13301           DT(LONG)&SET.ALU.CC
U 0CC2, 08CC,11 ;13302          JMP.IF[NEQ] TO [NOP.T13.1]
```

```
                    ;13303
U 0CC3, DB00,1A     ;13304          SKIP.IF[NO.FAST.INTERRUPT]                  ;SEE IF OVFLW L ASSERTED
U 0CC4, 88D0,44     ;13305          JMP [ERROR.T13.1]                           ;OVFLW L ASSERTED WHEN FIFO
                    ;13306                                                      ; ADRS WAS CLEAR
U 0CC5, 2F80,15     ;13307          CLR WR[0]                                   ;CALL CHECK.RESULT TO LOCK
U 0CC6, 2F82,95     ;13308          CLR WR[1]                                   ; IN INTERMITTENT ERRORS
U 0CC7, BE89,95     ;13309          MOV WR[3] TO LS[ADDRESS.DATA]
U 0CC8, 0869,3C     ;13310          JSR [CHECK.RESULT]
U 0CC9, 88CB,84     ;13311          JMP [LOOP.T13.1]
                    ;13312
U 0CCA, 3642,15     ;13313          MOV LS[#2] TO WR[0]                         ;SET UP FOR ERROR 2
U 0CCB, BE82,15     ;13314          MOV WR[0] TO LS[ERROR.NUMBER]
                    ;13315
                    ;13316
                    ;13317
U 0CCC, B626,15     ;13318          MOV LS[#FF] TO WR[0]                        ;ONE BEFORE OVFLW FOR AN RL02
U 0CCD, 3E10,15     ;13319          MOV WR[0] TO LS[T8]
                    ;13320
U 0CCE, 2F87,95     ;13321          CLR WR[3]                                   ;USE TO TRACK FIFO ADRS
                    ;13322  INCR.CNTR.T13.1:
U 0CCF, 97A8,15     ;13323          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                    ;13324                                                      ; TO FIFO A TO INCR ADRS CNTR
U 0CD0, 2047,95     ;13325          INC WR[3]                                   ;INCR ADRS TRACKER
                    ;13326
U 0CD1, B788,15     ;13327          MOV LS[#3] TO WR[0]                         ;NOP TO WAIT FOR IDC
                    ;13328  NOP.T13.2:
                    ;13329          DEC WR[0],
U 0CD2, A100,35     ;13330           DT(LONG)&SET.ALU.CC
U 0CD3, 88CD,21     ;13331          JMP.IF[NEQ] TO [NOP.T13.2]
                    ;13332
                    ;13333
U 0CD4, DB00,1A     ;13334          SKIP.IF[NO.FAST.INTERRUPT]                  ;CHECK IF OVFLW L ASSERTED
U 0CD5, 88D0,44     ;13335          JMP [ERROR.T13.1]                           ;OVFLW L ASSERTED TOO SOON
                    ;13336
U 0CD6, 2F80,15     ;13337          CLR WR[0]                                   ;CALL CHECK.RESULT TO LOCK
U 0CD7, 2F82,95     ;13338          CLR WR[1]                                   ; IN INTERMITTENT ERRORS
U 0CD8, BE89,95     ;13339          MOV WR[3] TO LS[ADDRESS.DATA]
U 0CD9, 0869,3C     ;13340          JSR [CHECK.RESULT]
U 0CDA, 88CB,84     ;13341          JMP [LOOP.T13.1]
                    ;13342
                    ;13343
                    ;13344          CMP LS[T8] WITH WR[3],                      ;LAST COUNT?
U 0CDB, 4E11,B5     ;13345           DT(LONG)&SET.ALU.CC
U 0CDC, 88CC,F1     ;13346          JMP.IF[NEQ] TO [INCR.CNTR.T13.1]            ;JUMP IF NOT LAST COUNT
                    ;13347
U 0CDD, B788,15     ;13348          MOV LS[#3] TO WR[0]
U 0CDE, BE82,15     ;13349          MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP FOR ERROR 3
                    ;13350
U 0CDF, 97A8,15     ;13351          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF DATA TO FIFO A
                    ;13352                                                      ; TO INCR ADRS CNTR TO OVFLW
U 0CE0, 2047,95     ;13353          INC WR[3]                                   ;INCR THE ADRS TRACKER
U 0CE1, B788,15     ;13354          MOV LS[#3] TO WR[0]                         ;NOP TO WAIT FOR IDC
                    ;13355  NOP.T13.3:
                    ;13356          DEC WR[0],
U 0CE2, A100,35     ;13357           DT(LONG)&SET.ALU.CC
```

```
U 0CE3, 88CE,21 ;13358          JMP.IF[NEQ] TO [NOP.T13.3]
                ;13359
U 0CE4, DB00,1A ;13360          SKIP.IF[NO.FAST.INTERRUPT]              ;OVFLW L ASSERTED?
U 0CE5, 88CE,74 ;13361          JMP [OVFLW.OK.T13.1]                    ;OK
U 0CE6, 88D0,44 ;13362          JMP [ERROR.T13.1]                       ;OVFLW DID NOT ASSERT
                ;13363
                ;13364  OVFLW.OK.T13.1:
U 0CE7, 2F80,15 ;13365          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0CE8, 2F82,95 ;13366          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0CE9, BE89,95 ;13367          MOV WR[3] TO LS[ADDRESS.DATA]
U 0CEA, 0869,3C ;13368          JSR [CHECK.RESULT]
U 0CEB, 88CB,84 ;13369          JMP [LOOP.T13.1]
                ;13370
U 0CEC, 3644,15 ;13371          MOV LS[#4] TO WR[0]
U 0CED, BE82,15 ;13372          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 4
                ;13373  LOOP.T13.2:
U 0CEE, 8872,EC ;13374          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
U 0CEF, 17C0,15 ;13375          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                ;13376                                                  ; TO DEASSERT OVFLW L
                ;13377
U 0CF0, B706,15 ;13378          MOV LS[SETCSR.F3] TO WR[0]
                ;13379                                                  ;SET UP THE CSR TO BRANCH TO
                ;13380                                                  ; THE CORRECT IDC ROUTINE THAT
                ;13381                                                  ; WILL USET OVFLW AND THEN
                ;13382                                                  ; BRANCH TO SEE IF OVFLW DID
                ;13383                                                  ; ASSERT
U 0CF1, AEC4,15 ;13384          BIS WR[2] TO WR[0]                      ;SELECT AN RL02
U 0CF2, 17A0,15 ;13385          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;13386                                                  ;MAINT=0, CRDY=0, F<2:0>=011
                ;13387  ;-------------------------------------------------------------------------------
                ;13388  ;-------------------------------------------------------------------------------
                ;13389  ;                               *******
                ;13390  ;                               * IDC *
                ;13391  ;                               *******
                ;13392  ;-------------------------------------------------------------------------------
                ;13393  ;018:
                ;13394  ;=000
                ;13395  ;DIAG.IDLE:
                ;13396  ;
                ;13397  ;       BEN0/F0,
                ;13398  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;13399  ;       BEN2/F2,
                ;13400  ;       NAD/DIAG.IDLE
                ;13401  ;-------------------------------------------------------------------------------
                ;13402  ;01B:
                ;13403  ;=011
                ;13404  ;       BEN0/CRDY.L,
                ;13405  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;13406  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;13407  ;-------------------------------------------------------------------------------
                ;13408  ;069:
                ;13409  ;=0*1
                ;13410  ;TEST.USET.OVFLW:
                ;13411  ;
                ;13412  ;       FUNC/SET.FIFO.OVF,                      ;USET OVFLW
```

```
                ;13413  ;       INCR.FIFO.CNTR/ON,                      ;CLK OVFLW
                ;13414  ;       NAD/TEST.FIFO.OVFLW.0
                ;13415  ;-------------------------------------------------------------------------
                ;13416  ;068:
                ;13417  ;=0*0
                ;13418  ;TEST.FIFO.OVFLW.0:
                ;13419  ;
                ;13420  ;       BEN1/FIFO.OVFLW.L,              ;IS FIFO OVERFLOW ASSERTED?
                ;13421  ;       NAD/TEST.FIFO.OVFLW.1
                ;13422  ;-------------------------------------------------------------------------
                ;13423  ;190:
                ;13424  ;=0*
                ;13425  ;TEST.FIFO.OVFLW.1:
                ;13426  ;
                ;13427  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;13428  ;-------------------------------------------------------------------------
                ;13429  ;192:
                ;13430  ;=1*
                ;13431  ;
                ;13432  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;13433  ;-------------------------------------------------------------------------
                ;13434
U OCF3, 3792,15 ;13435          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;13436  NOP.T13.4:
                ;13437          DEC WR[0],
U OCF4, A100,35 ;13438           DT(LONG)&SET.ALU.CC
U OCF5, 08CF,41 ;13439          JMP.IF[NEQ] TO [NOP.T13.4]
                ;13440
U OCF6, DB00,1A ;13441          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF OVFLW L ASSERTED
U OCF7, 08CF,E4 ;13442          JMP [CALL.CH.RESULT.T13.1]              ;OVFLW ASSERTED OK
                ;13443
                ;13444  ERROR.T13.2:
U OCF8, 3640,95 ;13445          MOV LS[#1] TO WR[1]                     ;OVFLW DID NOT ASSERT
U OCF9, 2F80,15 ;13446          CLR WR[0]                               ; FORCE AN ERROR
U OCFA, 6588,15 ;13447          CLR LS[ADDRESS.DATA]                    ;CLR FOR PRINTOUT
U OCFB, 0869,3C ;13448          JSR [CHECK.RESULT]
U OCFC, 88CE,E4 ;13449          JMP [LOOP.T13.2]                        ;LOOP HERE IF ERR & LOE IS SET
U OCFD, 08D0,94 ;13450          JMP [CLEANUP.T13.1]                     ; ELSE END TEST
                ;13451
                ;13452  CALL.CH.RESULT.T13.1:
U OCFE, 2F80,15 ;13453          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U OCFF, 2F82,95 ;13454          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U OD00, 6588,15 ;13455          CLR LS[ADDRESS.DATA]                    ;ADDR=0
U OD01, 0869,3C ;13456          JSR [CHECK.RESULT]
U OD02, 88CE,E4 ;13457          JMP [LOOP.T13.2]
U OD03, 08D0,94 ;13458          JMP [CLEANUP.T13.1]
                ;13459
                ;13460  ERROR.T13.1:
U OD04, 3640,95 ;13461          MOV LS[#1] TO WR[1]                     ;FORCE AN ERROR
U OD05, 2F80,15 ;13462          CLR WR[0]
U OD06, BE89,95 ;13463          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U OD07, 0869,3C ;13464          JSR [CHECK.RESULT]
U OD08, 88CB,84 ;13465          JMP [LOOP.T13.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;13466                                                  ;ELSE SKIP OTHER ERRORS AND END
                ;13467                                                  ; TEST
```

```
                ;13468
                ;13469  CLEANUP.T13.1:
U 0D09, 8875,3C ;13470          JSR [CLEANUP]                   ;CLEANUP THE CONDITIONS SET BY
                ;13471                                          ; THIS TEST
                ;13472  END.T13:                                ;END TEST
                ;13473
                ;13474
                ;13475
```

```
;13476  .PAGE  "Test 14  FIFO A ADRS CNTR OVFLW L BRANCH TEST 2 (M8388 IDC MODULE)"
;13477  ;++
;13478  ;
;13479  ; Test Description:
;13480  ;
;13481  ;       This test will only be run if an R80 is available on the system.
;13482  ;       This test is designed to verify that OVFLW  L asserts on the correct
;13483  ;       address count (200 HEX) of FIFO A when an R80 is selected.
;13484  ;       This test will also verify USET OVFLW.
;13485  ;
;13486  ; Assumptions:
;13487  ;
;13488  ;       It is assumed that XFER.REQ works correctly.
;13489  ;
;13490  ; Test Steps:
;13491  ;
;13492  ;       1. Set up error mask, error number and module number in LS
;13493  ;          (for error printouts) and clear the previous error number in LS.
;13494  ;       2. If the DRIVE SIZING TEST has not been run previously then
;13495  ;          go run the DISK DRIVE SIZING ROUTINE.
;13496  ;       3. If an R80 is not available on the system, then go to end of test.
;13497  ;       4. Force the IDC microcode to DIAG.IDLE.
;13498  ;       5. PSEL FIFO A.
;13499  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;13500  ;
;13501  ;                                       *******
;13502  ;                                       * IDC *
;13503  ;                                       *******
;13504  ;
;13505  ;               IDC1. Select FIFO A, UCM = 5.
;13506  ;
;13507  ;       7. Set up the CSR to branch to the correct IDC microcode loop.
;13508  ;
;13509  ;                                       *******
;13510  ;                                       * IDC *
;13511  ;                                       *******
;13512  ;               The IDC microcode  will continue looping on the following
;13513  ;               steps until OVFLW  L asserts or a CLEAR IDC is issued.
;13514  ;
;13515  ;               IDC2. Select BEN1/OVFLW  L.
;13516  ;               IDC3. If OVFLW  L is asserted then assert XFER REQ and go to
;13517  ;                     DIAG.WAIT.
;13518  ;               IDC4. Go to IDC2.
;13519  ;
;13520  ;       8. Clear the FIFO ADRS CNTR.
;13521  ;       9. If XFER REQ is asserted (OVFLW asserted) then issue error.
;13522  ;      10. Increment the error number.
;13523  ;      11. Select an R80 drive.
;13524  ;      12. Set WR[3] = 0 to use as a counter.
;13525  ;      13. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
;13526  ;      14. Increment WR[3].
;13527  ;      15. Check that XFER REQ is unasserted.
;13528  ;      16. Repeat Steps 13 - 16 until WR[3] = 511 (1FF HEX).
;13529  ;      17. Increment the error number.
;13530  ;      18. Write a byte of data to FIFO A to increment the FIFO ADRS CNTR by 1.
```

```
;13531  ;       19. Increment WR[3].
;13532  ;       20. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;13533  ;       21. Force the IDC microcode to DIAG.IDLE.
;13534  ;       22. Clear the FIFO ADRS CNTR.
;13535  ;       23. Set up the CSR to branch to the correct IDC routine.
;13536  ;
;13537  ;                                       *******
;13538  ;                                       * IDC *
;13539  ;                                       *******
;13540  ;
;13541  ;               IDC5. Set FUNC<35:32> = 0E, USET.FIFO OVFLW.
;13542  ;               IDC6. Perform Steps IDC2 - IDC4.
;13543  ;
;13544  ;       24. NOP to allow IDC time to branch.
;13545  ;       25. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;13546  ;       26. CLEAR IDC.
;13547  ;       27. End test.
;13548  ;
;13549  ; Errors:
;13550  ;
;13551  ;                 Printout:
;13552  ;                         EXPECTED          RECEIVED        OTHER DATA
;13553  ;                           N/A               N/A             WR[3]
;13554  ;
;13555  ;
;13556  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO OVFLW L failed unasserted.
;13557  ;
;13558  ;       ERROR 2 - PINCR FIFO CNTR failed or OVFLW  L asserted too soon for an
;13559  ;                 R80 drive.
;13560  ;
;13561  ;       ERROR 3 - OVFLW  L did not assert at 512 for an R80 drive.
;13562  ;
;13563  ;       ERROR 4 - OVFLW did not set when a USET FIFO OVFLW was executed.
;13564  ;
;13565  ; Debug:
;13566  ;       An R80 disk drive will be selected which will deassert L  RL02 H at
;13567  ;       the CSR SELECTED STATUS LATCH PAL.
;13568  ;       L RL02 H = L  is inverted to become R80 H = H.
;13569  ;
;13570  ;  ERROR 1:
;13571  ;
;13572  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;13573  ;       be decoded by the PORT INTERFACE REG PAL.
;13574  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;13575  ;
;13576  ;                               CSR 17 H = H
;13577  ;                               CSR 14 H = H
;13578  ;                               CSR 12 H = L
;13579  ;                               CSR 11 H = L
;13580  ;                               CSR 10 H = L
;13581  ;                               PORT INSTR H = H
;13582  ;                               CPU P2 H = H
;13583  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;13584  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear
;13585  ;       FIFO OVFLW L.
```

```
;13586  ;
;13587  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;13588  ;               BEN1 S0 H = L
;13589  ;               BEN1 S1 H = L
;13590  ;               BEN1 S2 H = H
;13591  ;
;13592  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;13593  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;13594  ;       not assert XFER REQ H.
;13595  ;       The CPU will then check to insure that XFER REQ H did not
;13596  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;13597  ;
;13598  ;  ERROR 2:
;13599  ;
;13600  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;13601  ;       instruction so that the FIFO CNTR can be incremented from the
;13602  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;13603  ;       The inputs will be:
;13604  ;               CSR 17 H = H
;13605  ;               CSR 14 H = H
;13606  ;               CSR 12 H = H
;13607  ;               CSR 11 H = H
;13608  ;               CSR 10 H = L
;13609  ;               PORT INSTR H = H
;13610  ;               CPU P2 H = H
;13611  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;13612  ;
;13613  ;       FIFO A will also be selected by the IDC microcode to allow FIFO A
;13614  ;       OVFLW L to be asserted.
;13615  ;       The IDC microcode will issue UCMD/SET.FIFOA. This will
;13616  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;13617  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;13618  ;               UCMD 2 H = H
;13619  ;               UCMD 1 H = L
;13620  ;               UCMD 0 H = H
;13621  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;13622  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;13623  ;
;13624  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;13625  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;13626  ;       The inputs to this PAL should be:
;13627  ;               CSR 17 H = H
;13628  ;               CSR 14 H = L
;13629  ;               CSR 13 H = H
;13630  ;               CSR 12 H = L
;13631  ;               CSR 11 H = H
;13632  ;               CSR 10 H = L
;13633  ;               PORT INSTR H = H
;13634  ;               CPU P2 H = H
;13635  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;13636  ;       STROBE DATA H.
;13637  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;13638  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;13639  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO A H = H and
;13640  ;       PORT CLOCK L as the clock input to the FIFO A ADRS CNTR HI
```

```
;13641  ;       and LO PALs. When these PALs are clocked, FIFOA ADRS <8:0> H will
;13642  ;       increment.
;13643  ;
;13644  ;       R80 H will be = H so rIFOA OVFLW L will not assert until
;13645  ;       FIFOA ADRS <8:4> = H and FIFOA LO FULL H = H and USEL FIFO A H = H and
;13646  ;       then the PAL must be clocked one more time by writing a byte of data
;13647  ;       to FIFO A to assert PINCR FIFO CNTR H. FIFO OVFLW L will assert
;13648  ;       20ns after FIFOA OVFLW L.
;13649  ;
;13650  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;13651  ;               BEN1 S0 H = L
;13652  ;               BEN1 S1 H = L
;13653  ;               BEN1 S2 H = H
;13654  ;
;13655  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;13656  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;13657  ;       not assert XFER REQ H.
;13658  ;       The CPU will then check to insure that XFER REQ H did not
;13659  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;13660  ;
;13661  ; ERROR 3:
;13662  ;
;13663  ;       FIFOA ADRS <8:0> will be = 111111111. The FIFOA ADRS CNTR PALs will
;13664  ;       be clocked one more time by writing a byte of data to FIFO A.
;13665  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
;13666  ;               R80 H = H
;13667  ;               FIFOA LO FULL H = H
;13668  ;               USEL FIFOA H = H
;13669  ;               FIFOA ADRS <8:4> = H
;13670  ;
;13671  ;       This combination of inputs will assert FIFOA OVFLW L. Approximately
;13672  ;       20ns later, FIFO OVFLW L will assert.
;13673  ;
;13674  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;13675  ;               BEN1 S0 H = L
;13676  ;               BEN1 S1 H = L
;13677  ;               BEN1 S2 H = H
;13678  ;
;13679  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;13680  ;       branch to an instruction that will assert XFER REQ H.
;13681  ;       The CPU will then check to insure that XFER REQ H asserted by
;13682  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
;13683  ;
;13684  ; ERROR 4:
;13685  ;
;13686  ;       The FIFO A ADRS CNTR PAL will be cleared which will insure that
;13687  ;       FIFO OVFLW L is not asserted. The IDC microcode will then branch to
;13688  ;       an instruction of FUNC/SET.FIFO.OVF. The output of the microsequencer
;13689  ;       will be:
;13690  ;               UFUNC 3 H = H
;13691  ;               UFUNC 2 H = H
;13692  ;               UFUNC 1 H = H
;13693  ;               UFUNC 0 H = L
;13694  ;       These bits will be decoded and USET FIFO OVF L will assert. This
;13695  ;       signal is an input to the FIFOA ADRS CNTR HI PAL. USEL FIFOA H will
```

```
                ;13696  ;       also be asserted. When the PAL is clocked by INCR.FIFO.CNTR/ON,
                ;13697  ;       FIFOA OVFLW L will assert. Approximately 20ns later, FIFO OVFLW L
                ;13698  ;       will assert.
                ;13699  ;
                ;13700  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
                ;13701  ;               BEN1 S0 H = L
                ;13702  ;               BEN1 S1 H = L
                ;13703  ;               BEN1 S2 H = H
                ;13704  ;
                ;13705  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
                ;13706  ;       branch to an instruction that will assert XFER REQ H.
                ;13707  ;       The CPU will then check to insure that XFER REQ H asserted by
                ;13708  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                ;13709  ;--
                ;13710  ;*******************************************************************************
                ;13711  T.14:
U 0D0A, B65E,15 ;13712          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;13713                                                  ; CONTROL AND STATUS WORD
U 0D0B, 3E80,15 ;13714          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;13715                                                  ; STATUS WORD - BIT 15
                ;13716                                                  ; INDICATES START OF TEST TO
                ;13717                                                  ; CONSOLE
U 0D0C, 10E0,15 ;13718          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;13719  WAIT.T14.0:
U 0D0D, 88D0,D4 ;13720          JMP [WAIT.T14.0]                        ;LOOP HERE WAITING FOR
                ;13721                                                  ; CONSOLE TO RESPOND
                ;13722
U 0D0E, 65A0,15 ;13723          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;13724                                                  ; IN LS
                ;13725
U 0D0F, B64A,15 ;13726          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0D10, 3E8C,15 ;13727          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;13728
                ;13729
                ;13730
U 0D11, E58A,15 ;13731          CLR LS[ERROR.MASK]
                ;13732
U 0D12, B670,15 ;13733          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0D13, 3E80,15 ;13734          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                ;13735
U 0D14, B66E,15 ;13736          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0D15, 6D80,15 ;13737          BIS WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;13738
                ;13739
U 0D16, B78E,15 ;13740          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;13741          BIT LS[BIT7] WITH WR[0],                ; RUN?
U 0D17, D94E,35 ;13742           DT(LONG)&SET.ALU.CC
U 0D18, 88D1,A1 ;13743          JMP.IF[BIT.SET] TO [SIZE.OK.T14.1]      ;IF YES THEN GO RUN TEST
                ;13744
U 0D19, 8870,0C ;13745          JSR [DRIVE.SIZE]                        ;GO RUN DRIVE SIZING ROUTINE
                ;13746
                ;13747  SIZE.OK.T14.1:
                ;13748
U 0D1A, 8872,EC ;13749          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;13750
```

```
                ;13751          ;SELECT AN R80 DRIVE IF ONE IS AVAILABLE...ELSE SKIP TEST
                ;13752
U 0D1B, B78E,15 ;13753          MOV LS[DRIVE.STATUS] TO WR[0]
U 0D1C, 3790,95 ;13754          MOV LS[#FFFFFFF0] TO WR[1]
U 0D1D, AF42,15 ;13755          BIC WR[1] TO WR[0]                      ;CHECK BITS <3:0>
                ;13756          CMP LS[ZERO] WITH WR[0],                ;ANY R80S?
U 0D1E, CE9C,35 ;13757           DT(LONG)&SET.ALU.CC
U 0D1F, 08D8,C9 ;13758          JMP.IF[EQL] TO [CLEANUP.T14.1]          ;NO R80, CLEANUP AND END TEST
                ;13759
U 0D20, B78E,15 ;13760          MOV LS[DRIVE.STATUS] TO WR[0]
                ;13761          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0D21, 5940,35 ;13762           DT(LONG)&SET.ALU.CC
U 0D22, 08D2,81 ;13763          JMP.IF[BIT.SET] TO [SEL.DR0.T14.1]      ;JMP IF DRV 0 = R80
                ;13764
                ;13765          BIT LS[BIT1] WITH WR[0],                ;IS DRIVE 1 AN R80?
U 0D23, D942,35 ;13766           DT(LONG)&SET.ALU.CC
U 0D24, 88D2,A1 ;13767          JMP.IF[BIT.SET] TO [SEL.DR1.T14.1]      ;JMP IF DRV 1 = R80
                ;13768
                ;13769          BIT LS[BIT2] WITH WR[0],                ;IS DRIVE 2 AN R80?
U 0D25, D944,35 ;13770           DT(LONG)&SET.ALU.CC
U 0D26, 88D2,C1 ;13771          JMP.IF[BIT.SET] TO [SEL.DR2.T14.1]      ;JMP IF DRV 2 = R80
                ;13772
U 0D27, 08D2,E4 ;13773          JMP [SEL.DR3.T14.1]                     ;JMP ANS SEL DR 3
                ;13774
                ;13775  SEL.DR0.T14.1:
U 0D28, 3715,15 ;13776          MOV LS[SETCSR.DS0] TO WR[2]             ;SAV DRV SEL = 0
U 0D29, 88D2,F4 ;13777          JMP [TEST.T14.1]                        ;GO DO TEST
                ;13778
                ;13779  SEL.DR1.T14.1:
U 0D2A, B717,15 ;13780          MOV LS[SETCSR.DS1] TO WR[2]             ;SAV DRV SEL = 1
U 0D2B, 88D2,F4 ;13781          JMP [TEST.T14.1]                        ;GO DO TEST
                ;13782
                ;13783  SEL.DR2.T14.1:
U 0D2C, 3719,15 ;13784          MOV LS[SETCSR.DS2] TO WR[2]             ;SAV DRV SEL = 2
U 0D2D, 88D2,F4 ;13785          JMP [TEST.T14.1]                        ;GO DO TEST
                ;13786
                ;13787  SEL.DR3.T14.1:
U 0D2E, B71B,15 ;13788          MOV LS[SETCSR.DS3] TO WR[2]             ;SAV DRV SEL = 3
                ;13789
                ;13790  TEST.T14.1:
U 0D2F, 2F87,95 ;13791          CLR WR[3]                               ;USE AS ADDR TRACKER
                ;13792
U 0D30, 17D8,15 ;13793          PORT.CONTROL [SEL.FIFO.A]               ;SEL FIFO A FROM THE PORT
U 0D31, 3720,15 ;13794          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0D32, 370A,95 ;13795          MOV LS[SETCSR.F5] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 0D33, AEC2,15 ;13796          BIS WR[1] TO WR[0]                      ; TO SELECT FIFO A
U 0D34, 17A0,15 ;13797          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;13798                                                  ;MAINT=1, CRDY=0, F<2:0>=101
                ;13799  ;USEL FIFO A
                ;13800  ;-------------------------------------------------------------------------------
                ;13801  ;-------------------------------------------------------------------------------
                ;13802  ;                               *******
                ;13803  ;                               * IDC *
                ;13804  ;                               *******
                ;13805  ;-------------------------------------------------------------------------------
```


U 0D
U 0D
U 0D

```
;13806  ;018:
;13807  ;=000
;13808  ;DIAG.IDLE:
;13809  ;
;13810  ;       BEN0/F0,
;13811  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;13812  ;       BEN2/F2,
;13813  ;       NAD/DIAG.IDLE
;13814  ;-----------------------------------------------------------------------
;13815  ;01D:
;13816  ;=101
;13817  ;
;13818  ;       BEN0/CRDY.L,
;13819  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;13820  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;13821  ;-----------------------------------------------------------------------
;13822  ;075:
;13823  ;=1*1
;13824  ;TEST.F5:
;13825  ;
;13826  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
;13827  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
;13828  ;
;13829  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
;13830  ;                                       ; MUST USEL FIFO A
;13831  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
;13832  ;                                       ; AND DIAG.IDLE
;13833  ;-----------------------------------------------------------------------
;13834  ;1D8:
;13835  ;XFER.REQ:
;13836  ;
;13837  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;13838  ;       NAD/DIAG.WAIT
;13839  ;-----------------------------------------------------------------------
;13840  ;1D7:
;13841  ;DIAG.WAIT:
;13842  ;
;13843  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;13844  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;13845  ;
;13846  ;-----------------------------------------------------------------------
;13847  ;159:
;13848  ;=*0*
;13849  ;DIAG.WAIT1:
;13850  ;
;13851  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;13852  ;                               ; COMMAND FROM THE CPU
;13853  ;
;13854  ;-----------------------------------------------------------------------
;13855  ;15B:
;13856  ;=*1*
;13857  ;DIAG.WAIT2:
;13858  ;
;13859  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
;13860  ;                               ; WAIT SOME MORE
```

```
                ;13861  ;
                ;13862  ;-------------------------------------------------------------------------
                ;13863
                ;13864  WAIT.IDC.T14.1:
U 0D35, DB00,1A ;13865          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0D36, 88D3,84 ;13866          JMP [IDC.DONE.T14.1]                    ;XFER REQ ASSERTED
U 0D37, 08D3,54 ;13867          JMP [WAIT.IDC.T14.1]                    ;WAIT SOME MORE
                ;13868
                ;13869  IDC.DONE.T14.1:
U 0D38, B700,15 ;13870          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0D39, 17A0,15 ;13871          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0D3A, 90FA,15 ;13872          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;13873
                ;13874  LOOP.T14.1:
                ;13875
U 0D3B, B640,15 ;13876          MOV LS[#1] TO WR[0]                     ;SET UP FOR ERROR 1
U 0D3C, BE82,15 ;13877          MOV WR[0] TO LS[ERROR.NUMBER]
                ;13878
U 0D3D, 17C0,15 ;13879          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                ;13880
U 0D3E, 3712,95 ;13881          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0D3F, B706,15 ;13882          MOV LS[SETCSR.F3] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 0D40, AEC2,15 ;13883          BIS WR[1] TO WR[0]                      ; THAT WILL SET XFER REQ WHEN
                ;13884                                                  ; OVFLW L ASSERTS
U 0D41, AEC4,15 ;13885          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0D42, 17A0,15 ;13886          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;13887                                                  ;MAINT=0, CRDY=1, F<2:0>=011
                ;13888  ;-------------------------------------------------------------------------
                ;13889  ;-------------------------------------------------------------------------
                ;13890  ;                               *******
                ;13891  ;                               * IDC *
                ;13892  ;                               *******
                ;13893  ;-------------------------------------------------------------------------
                ;13894  ;018:
                ;13895  ;=000
                ;13896  ;DIAG.IDLE:
                ;13897  ;
                ;13898  ;       BEN0/F0,
                ;13899  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;13900  ;       BEN2/F2,
                ;13901  ;       NAD/DIAG.IDLE
                ;13902  ;-------------------------------------------------------------------------
                ;13903  ;01B:
                ;13904  ;=011
                ;13905  ;       BEN0/CRDY.L,
                ;13906  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;13907  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;13908  ;-------------------------------------------------------------------------
                ;13909  ;068:
                ;13910  ;=0*0
                ;13911  ;TEST.FUNC3:
                ;13912  ;
                ;13913  ;TEST.FIFO.OVLW.0:
                ;13914  ;       BEN1/FIFO.OVFLW.L,      ;IS FIFO OVFLW ASSERTED?
                ;13915  ;       NAD/TEST.FIFO.OVFLW.1
```

```
                ;13916  ;-------------------------------------------------------------------------
                ;13917  ;190:
                ;13918  ;=0*
                ;13919  ;TEST.FIFO.OVFLW.1:
                ;13920  ;
                ;13921  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;13922  ;-------------------------------------------------------------------------
                ;13923  ;192:
                ;13924  ;=1*
                ;13925  ;
                ;13926  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;13927  ;-------------------------------------------------------------------------
                ;13928
U 0D43, 3792,15 ;13929          MOV LS[#6] TO WR[0]             ;NOP TO WAIT FOR IDC
                ;13930  NOP.T14.1:
                ;13931          DEC WR[0],
U 0D44, A100,35 ;13932           DT(LONG)&SET.ALU.CC
U 0D45, 08D4,41 ;13933          JMP.IF[NEQ] TO [NOP.T14.1]
                ;13934
                ;13935
                ;13936
U 0D46, DB00,1A ;13937          SKIP.IF[NO.FAST.INTERRUPT]      ;SEE IF OVFLW L ASSERTED
U 0D47, 08D8,24 ;13938          JMP [ERROR.T14.1]               ;OVFLW L ASSERTED WHEN FIFO
                ;13939                                          ; ADRS WAS CLEAR
                ;13940
U 0D48, 2F80,15 ;13941          CLR WR[0]                       ;CALL CHECK.RESULT TO LOCK
U 0D49, 2F82,95 ;13942          CLR WR[1]                       ; IN INTERMITTENT ERRORS
U 0D4A, BE89,95 ;13943          MOV WR[3] TO LS[ADDRESS.DATA]
U 0D4B, 0869,3C ;13944          JSR [CHECK.RESULT]
U 0D4C, 88D3,B4 ;13945          JMP [LOOP.T14.1]
                ;13946
                ;13947
U 0D4D, 3642,15 ;13948          MOV LS[#2] TO WR[0]             ;SET UP FOR ERROR 2
U 0D4E, BE82,15 ;13949          MOV WR[0] TO LS[ERROR.NUMBER]
                ;13950
                ;13951
                ;13952
U 0D4F, 378C,15 ;13953          MOV LS[#1FE] TO WR[0]
U 0D50, 2040,15 ;13954          INC WR[0]                       ;ONE BEFORE OVFLW FOR AN R80
U 0D51, 3E10,15 ;13955          MOV WR[0] TO LS[T8]
                ;13956
U 0D52, 2F87,95 ;13957          CLR WR[3]                       ;USE TO TRACK FIFO ADRS
                ;13958  INCR.CNTR.T14.1:
U 0D53, 97A8,15 ;13959          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;13960                                          ; TO FIFO A TO INCR ADRS CNTR
U 0D54, 2047,95 ;13961          INC WR[3]                       ;INCR ADRS TRACKER
                ;13962
U 0D55, B788,15 ;13963          MOV LS[#3] TO WR[0]             ;NOP TO WAIT FOR IDC
                ;13964  NOP.T14.2:
                ;13965          DEC WR[0],
U 0D56, A100,35 ;13966           DT(LONG)&SET.ALU.CC
U 0D57, 08D5,61 ;13967          JMP.IF[NEQ] TO [NOP.T14.2]
                ;13968
                ;13969
U 0D58, DB00,1A ;13970          SKIP.IF[NO.FAST.INTERRUPT]      ;CHECK IF OVFLW L ASSERTED
```

```
U 0D59, 08D8,24 ;13971          JMP [ERROR.T14.1]                       ;OVFLW L ASSERTED TOO SOON
                ;13972
U 0D5A, 2F80,15 ;13973          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0D5B, 2F82,95 ;13974          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0D5C, BE89,95 ;13975          MOV WR[3] TO LS[ADDRESS.DATA]
U 0D5D, 0869,3C ;13976          JSR [CHECK.RESULT]
U 0D5E, 88D3,B4 ;13977          JMP [LOOP.T14.1]
                ;13978
                ;13979
                ;13980          CMP LS[T8] WITH WR[3],                  ;LAST COUNT?
U 0D5F, 4E11,B5 ;13981           DT(LONG)&SET.ALU.CC
U 0D60, 08D5,31 ;13982          JMP.IF[NEQ] TO [INCR.CNTR.T14.1]        ;JUMP IF NOT LAST COUNT
                ;13983
U 0D61, B788,15 ;13984          MOV LS[#3] TO WR[0]
U 0D62, BE82,15 ;13985          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 3
                ;13986
U 0D63, 97A8,15 ;13987          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A BYTE OF DATA TO FIFO A
                ;13988                                                  ; TO INCR ADRS CNTR TO OVFLW
U 0D64, 2047,95 ;13989          INC WR[3]                               ;INCR THE ADRS TRACKER
                ;13990
U 0D65, B788,15 ;13991          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;13992  NOP.T14.3:
                ;13993          DEC WR[0],
U 0D66, A100,35 ;13994           DT(LONG)&SET.ALU.CC
U 0D67, 08D6,61 ;13995          JMP.IF[NEQ] TO [NOP.T14.3]
                ;13996
                ;13997
U 0D68, DB00,1A ;13998          SKIP.IF[NO.FAST.INTERRUPT]              ;OVFLW L ASSERTED?
U 0D69, 88D6,B4 ;13999          JMP [OVFLW.OK.T14.1]                    ;OK
U 0D6A, 08D8,24 ;14000          JMP [ERROR.T14.1]                       ;OVFLW DID NOT ASSERT
                ;14001
                ;14002  OVFLW.OK.T14.1:
U 0D6B, 2F80,15 ;14003          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0D6C, 2F82,95 ;14004          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0D6D, BE89,95 ;14005          MOV WR[3] TO LS[ADDRESS.DATA]
U 0D6E, 0869,3C ;14006          JSR [CHECK.RESULT]
U 0D6F, 88D3,B4 ;14007          JMP [LOOP.T14.1]
                ;14008
U 0D70, 3644,15 ;14009          MOV LS[#4] TO WR[0]
U 0D71, BE82,15 ;14010          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 4
                ;14011
                ;14012  LOOP.T14.2:
U 0D72, 8872,EC ;14013          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
U 0D73, 17C0,15 ;14014          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO A ADRS CNTR
                ;14015                                                  ; TO DEASSERT OVFLW L
                ;14016
                ;14017                                                  ;SET UP THE CSR TO BRANCH TO
U 0D74, B706,15 ;14018          MOV LS[SETCSR.F3] TO WR[0]              ; THE CORRECT IDC ROUTINE THAT
                ;14019                                                  ; WILL USET OVFLW AND THEN
                ;14020                                                  ; BRANCH TO SEE IF OVFLW DID
                ;14021                                                  ; ASSERT
U 0D75, AEC4,15 ;14022          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0D76, 17A0,15 ;14023          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;14024                                                  ;MAINT=0, CRDY=0, F<2:0>=011
                ;14025  ;-------------------------------------------------------------------------
```

```
                ;14026  ;-------------------------------------------------------------------------
                ;14027  ;                               *******
                ;14028  ;                               * IDC *
                ;14029  ;                               *******
                ;14030  ;-------------------------------------------------------------------------
                ;14031  ;018:
                ;14032  ;=000
                ;14033  ;DIAG.IDLE:
                ;14034  ;
                ;14035  ;       BEN0/F0,
                ;14036  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;14037  ;       BEN2/F2,
                ;14038  ;       NAD/DIAG.IDLE
                ;14039  ;-------------------------------------------------------------------------
                ;14040  ;01B:
                ;14041  ;=011
                ;14042  ;       BEN0/CRDY.L,
                ;14043  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;14044  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;14045  ;-------------------------------------------------------------------------
                ;14046  ;069:
                ;14047  ;=0*1
                ;14048  ;TEST.USET.OVFLW:
                ;14049  ;
                ;14050  ;       FUNC/SET.FIFO.OVF,                      ;USET OVFLW
                ;14051  ;       INCR.FIFO.CNTR/ON,                      ;CLK OVFLW
                ;14052  ;       NAD/TEST.FIFO.OVFLW.0
                ;14053  ;-------------------------------------------------------------------------
                ;14054  ;068:
                ;14055  ;=0*0
                ;14056  ;TEST.FIFO.OVFLW.0:
                ;14057  ;
                ;14058  ;       BEN1/FIFO.OVFLW.L,              ;IS FIFO OVERFLOW ASSERTED?
                ;14059  ;       NAD/TEST.FIFO.OVFLW.1
                ;14060  ;-------------------------------------------------------------------------
                ;14061  ;190:
                ;14062  ;=0*
                ;14063  ;TEST.FIFO.OVFLW.1:
                ;14064  ;
                ;14065  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;14066  ;-------------------------------------------------------------------------
                ;14067  ;192:
                ;14068  ;=1*
                ;14069  ;
                ;14070  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;14071  ;-------------------------------------------------------------------------
                ;14072
U 0D77, 3792,15 ;14073          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;14074  NOP.T14.4:
                ;14075          DEC WR[0],
U 0D78, A100,35 ;14076           DT(LONG)&SET.ALU.CC
U 0D79, 08D7,81 ;14077          JMP.IF[NEQ] TO [NOP.T14.4]
                ;14078
                ;14079
                ;14080
```

```
U 0D7A, DB00,1A ;14081          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF OVFLW L ASSERTED
U 0D7B, 08D8,74 ;14082          JMP [CALL.CH.RESULT.T14.1]              ;OVFLW ASSERTED OK
                ;14083
                ;14084  ERROR.T14.2:
U 0D7C, 3640,95 ;14085          MOV LS[#1] TO WR[1]                     ;OVFLW DID NOT ASSERT
U 0D7D, 2F80,15 ;14086          CLR WR[0]                               ; FORCE AN ERROR
U 0D7E, 6588,15 ;14087          CLR LS[ADDRESS.DATA]                    ; CLR FOR PRINTOUT
U 0D7F, 0869,3C ;14088          JSR [CHECK.RESULT]
U 0D80, 08D7,24 ;14089          JMP [LOOP.T14.2]                        ;LOOP HERE IF ERR & LOE IS SET
U 0D81, 88D8,C4 ;14090          JMP [CLEANUP.T14.1]                     ; ELSE END TEST
                ;14091
                ;14092
                ;14093  ERROR.T14.1:                                    ;OVFLW L DID NOT ASSERT
U 0D82, 3640,95 ;14094          MOV LS[#1] TO WR[1]                     ;FORCE AN ERROR
U 0D83, 2F80,15 ;14095          CLR WR[0]
U 0D84, BE89,95 ;14096          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U 0D85, 0869,3C ;14097          JSR [CHECK.RESULT]
U 0D86, 88D3,B4 ;14098          JMP [LOOP.T14.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;14099                                                  ;ELSE SKIP OTHER ERRORS AND END
                ;14100  CALL.CH.RESULT.T14.1:
U 0D87, 2F80,15 ;14101          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0D88, 2F82,95 ;14102          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0D89, 6588,15 ;14103          CLR LS[ADDRESS.DATA]
U 0D8A, 0869,3C ;14104          JSR [CHECK.RESULT]
U 0D8B, 08D7,24 ;14105          JMP [LOOP.T14.2]
                ;14106
                ;14107
                ;14108  CLEANUP.T14.1:
U 0D8C, 8875,3C ;14109          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;14110                                                  ; THIS TEST
                ;14111
                ;14112  END.T14:                                        ;END TEST
                ;14113
                ;14114
                ;14115
                ;14116
```

```
;14117  .PAGE  "Test 15  FIFO B ADRS CNTR OVFLW L BRANCH TEST 1 (M8388 IDC MODULE)"
;14118  ;++
;14119  ; Test Description:
;14120  ;
;14121  ;       This test is designed to insure that OVFLW  L asserts on the correct
;14122  ;       FIFO B  address count (100 HEX) for an RL02 disk drive.
;14123  ;       This test will also verify that OVFLW  L clears when the CPU issues a
;14124  ;       CLEAR.FIFO.CNTR instruction.
;14125  ;       USET FIFO OVFLW will also be verified.
;14126  ;
;14127  ; Assumptions:
;14128  ;
;14129  ;       It is assumed that XFER.REQ works correctly.
;14130  ;
;14131  ; Test Steps:
;14132  ;
;14133  ;       1. Set up error mask, error number and module number in LS
;14134  ;          (for error printouts) and clear the previous error number in LS.
;14135  ;       2. If the DRIVE SIZING TEST has not been run previously then
;14136  ;          go run the DISK DRIVE SIZING ROUTINE.
;14137  ;       3. Force the IDC microcode to DIAG.IDLE.
;14138  ;       4. PSEL FIFO B.
;14139  ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;14140  ;
;14141  ;                                       *******
;14142  ;                                       * IDC *
;14143  ;                                       *******
;14144  ;
;14145  ;               IDC1. Select FIFO A, UCM = 5.
;14146  ;               IDC2. Change FIFO, UCM = 6. (to USEL FIFO B)
;14147  ;
;14148  ;       6. Set up the CSR to branch to the correct IDC microcode loop.
;14149  ;
;14150  ;                                       *******
;14151  ;                                       * IDC *
;14152  ;                                       *******
;14153  ;           The IDC microcode  will continue looping on the following
;14154  ;           steps until OVFLW  L asserts or a CLEAR IDC is issued.
;14155  ;
;14156  ;           IDC3. Select BEN1/OVFLW  L.
;14157  ;           IDC4. If OVFLW  L is asserted then assert XFER REQ and go to
;14158  ;                 DIAG.WAIT.
;14159  ;           IDC5. Go to IDC3.
;14160  ;
;14161  ;       7. Clear the FIFO ADRS CNTR.
;14162  ;       8. If XFER REQ is asserted (OVFLW asserted) then issue error.
;14163  ;       9. Increment the error number.
;14164  ;      10. Select an RL02 drive or a line with no drive attached.
;14165  ;      11. Set WR[3], = 0 to use as a counter.
;14166  ;      12. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;14167  ;      13. Increment WR[3].
;14168  ;      14. If XFER REQ is asserted (OVFLW asserted) then issue error.
;14169  ;      15. Repeat Steps 12 - 15 until WR[3] = 255 (FF HEX).
;14170  ;      16. Increment the error number.
;14171  ;      17. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
```

```
;14172  ;       18. Increment WR[3].
;14173  ;       19. If XFER REQ is not asserted (OVFLW L did not assert) then
;14174  ;           issue error.
;14175  ;       20. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;14176  ;       21. Increment the error number.
;14177  ;       22. Force the IDC microcode to DIAG.IDLE.
;14178  ;       23. Clear the FIFO ADRS CNTR.
;14179  ;       24. Set up the CSR to branch to the correct IDC routine.
;14180  ;
;14181  ;                                       *******
;14182  ;                                       * IDC *
;14183  ;                                       *******
;14184  ;
;14185  ;               IDC6. Set FUNC<35:32> = 0E, USET.FIFO OVFLW.
;14186  ;               IDC7. Perform Steps IDC3 - IDC5.
;14187  ;
;14188  ;       25. NOP to allow IDC time to branch.
;14189  ;       26. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;14190  ;       27. CLEAR IDC.
;14191  ;       28. End test.
;14192  ;
;14193  ;
;14194  ;
;14195  ; Errors:
;14196  ;
;14197  ;                   Printout:
;14198  ;                           EXPECTED        RECEIVED        OTHER DATA
;14199  ;                             N/A             N/A             WR[3]
;14200  ;
;14201  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO OVFLW L failed unasserted.
;14202  ;
;14203  ;       ERROR 2 - PINCR FIFO CNTR failed or OVFLW L asserted too soon for an
;14204  ;                 RL02 drive.
;14205  ;
;14206  ;       ERROR 3 - OVFLW L did not assert at 256 for an RL02 drive.
;14207  ;
;14208  ;       ERROR 4 - OVFLW did not set when a USET FIFO OVFLW was executed.
;14209  ;
;14210  ; Debug:
;14211  ;
;14212  ;       A disk drive that will assert L  RL02 H at the CSR SELECTED
;14213  ;       STATUS LATCH PAL will be selected.
;14214  ;       L RL02 H is inverted to become R80 H = L.
;14215  ;
;14216  ;  ERROR 1:
;14217  ;
;14218  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;14219  ;       be decoded by the PORT INTERFACE REG PAL.
;14220  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;14221  ;
;14222  ;                           CSR 17 H = H
;14223  ;                           CSR 14 H = H
;14224  ;                           CSR 12 H = L
;14225  ;                           CSR 11 H = L
;14226  ;                           CSR 10 H = L
```

```
;14227  ;                       PORT INSTR H = H
;14228  ;                       CPU P2 H = H
;14229  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;14230  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear
;14231  ;       FIFO OVFLW L.
;14232  ;
;14233  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;14234  ;               BEN1 S0 H = L
;14235  ;               BEN1 S1 H = L
;14236  ;               BEN1 S2 H = H
;14237  ;
;14238  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;14239  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;14240  ;       not assert XFER REQ H.
;14241  ;       The CPU will then check to insure that XFER REQ H did not
;14242  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;14243  ;
;14244  ;  ERROR 2:
;14245  ;
;14246  ;       FIFO B is selected by the port by a PORT.CONTROL [SEL.FIFO.B]
;14247  ;       instruction so that the FIFO CNTR can be incremented from the
;14248  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;14249  ;       The inputs will be:
;14250  ;               CSR 17 H = H
;14251  ;               CSR 14 H = H
;14252  ;               CSR 12 H = H
;14253  ;               CSR 11 H = H
;14254  ;               CSR 10 H = H
;14255  ;               PORT INSTR H = H
;14256  ;               CPU P2 H = H
;14257  ;
;14258  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
;14259  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
;14260  ;
;14261  ;       FIFO B will also be selected by the IDC microcode to allow FIFO B
;14262  ;       OVFLW L to be asserted.
;14263  ;       The IDC microcode will issue UCMD/SET.FIFOA. This will
;14264  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;14265  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;14266  ;               UCMD 2 H = H
;14267  ;               UCMD 1 H = L
;14268  ;               UCMD 0 H = H
;14269  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;14270  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;14271  ;       The IDC microcode will execute a UCMD/CHG.FIFO. This will assert
;14272  ;       UCMD 2 H and UCMD 1 H of the IDC microword. These bits are decoded by
;14273  ;       the CONTROL STATUS REG PAL. The inputs will be:
;14274  ;               UCMD 2 H = H
;14275  ;               UCMD 1 H = H
;14276  ;               UCMD 0 H = L
;14277  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOA H = L will be
;14278  ;       inverted to USEL FIFOB H = H.
;14279  ;
;14280  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;14281  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
```

```
;14282  ;       The inputs to this PAL should be:
;14283  ;               CSR 17 H = H
;14284  ;               CSR 14 H = L
;14285  ;               CSR 13 H = H
;14286  ;               CSR 12 H = L
;14287  ;               CSR 11 H = H
;14288  ;               CSR 10 H = L
;14289  ;               PORT INSTR H = H
;14290  ;               CPU P2 H = H
;14291  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;14292  ;       STROBE DATA H.
;14293  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;14294  ;       clocked by CPU CLOCK H. This combination of inputs will assert
;14295  ;       PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO B H = H and
;14296  ;       PORT CLOCK L as the clock input to the FIFO B ADRS CNTR HI
;14297  ;       and LO PALs. When these PALs are clocked, FIFOB ADRS<7:0> will
;14298  ;       increment.
;14299  ;
;14300  ;       FIFO OVFLW L will not asssert because the inputs to FIFOA ADRS CNTR HI
;14301  ;       PAL will be USEL FIFOA H = L and FIFOB OVFLW L = H.
;14302  ;       Since R80 H will be = L, FIFOB OVFLW L at the FIFOB ADRS CNTR HI PAL,
;14303  ;       will not assert until FIFOB ADRS<7:4> = H and FIFOB LO FULL H = H
;14304  ;       and USEL FIFO B H = H and the PAL is clocked one more time.
;14305  ;
;14306  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;14307  ;               BEN1 S0 H = L
;14308  ;               BEN1 S1 H = L
;14309  ;               BEN1 S2 H = H
;14310  ;
;14311  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;14312  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;14313  ;       not assert XFER REQ H.
;14314  ;       The CPU will then check to insure that XFER REQ H did not
;14315  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;14316  ;
;14317  ;  ERROR 3:
;14318  ;
;14319  ;       FIFOB ADRS <7:0> will be = 11111111. The FIFOB ADRS CNTR PALs will
;14320  ;       be clocked one more time by writing a byte of data to FIFO B.
;14321  ;       The inputs to the FIFOB ADRS CNTR HI PAL will be:
;14322  ;               R80 H = L
;14323  ;               USEL FIFOB H = H
;14324  ;               FIFOB LO FULL H = H
;14325  ;               FIFOB ADRS <7:4> H = 1111
;14326  ;       This combination of inputs will assert FIFOB OVFLW L.
;14327  ;
;14328  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
;14329  ;               FIFOB OVFLW L = L
;14330  ;               USEL FIFO A H = L
;14331  ;       so approximately 20ns after FIFOB OVFLW L asserts, FIFO OVFLW L
;14332  ;       will assert.
;14333  ;
;14334  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;14335  ;               BEN1 S0 H = L
;14336  ;               BEN1 S1 H = L
```

```
                    ;14337  ;                   BEN1 S2 H = H
                    ;14338  ;
                    ;14339  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
                    ;14340  ;       branch to an instruction that will assert XFER REQ H.
                    ;14341  ;       The CPU will then check to insure that XFER REQ H asserted by
                    ;14342  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;14343  ;
                    ;14344  ;  ERROR 4:
                    ;14345  ;
                    ;14346  ;       The FIFO A ADRS CNTR PAL will be cleared which will insure that
                    ;14347  ;       FIFO OVFLW L is not asserted. The IDC microcode will then branch to
                    ;14348  ;       an instruction of FUNC/SET.FIFO.OVF. The output of the microsequencer
                    ;14349  ;       will be:
                    ;14350  ;               UFUNC 3 H = H
                    ;14351  ;               UFUNC 2 H = H
                    ;14352  ;               UFUNC 1 H = H
                    ;14353  ;               UFUNC 0 H = L
                    ;14354  ;       These bits will be decoded and USET FIFO OVF L will assert. This
                    ;14355  ;       signal is an input to the FIFOB ADRS CNTR HI PAL. USEL FIFOB H will
                    ;14356  ;       also be asserted. When the PAL is clocked by INCR.FIFO.CNTR/ON,
                    ;14357  ;       FIFOB OVFLW L will assert.  FIFOB OVFLW L =  L is an input to the
                    ;14358  ;       FIFOA ADRS CNTR H PAL. USEL FIFOA H will not be asserted, so
                    ;14359  ;       approximately 20ns later, FIFO OVFLW Lwill assert.
                    ;14360  ;
                    ;14361  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
                    ;14362  ;               BEN1 S0 H = L
                    ;14363  ;               BEN1 S1 H = L
                    ;14364  ;               BEN1 S2 H = H
                    ;14365  ;
                    ;14366  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
                    ;14367  ;       branch to an instruction that will assert XFER REQ H.
                    ;14368  ;       The CPU will then check to insure that XFER REQ H asserted by
                    ;14369  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;14370  ;--
                    ;14371  ;*******************************************************************************
                    ;14372  T.15:
U 0D8D, B65E,15     ;14373          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;14374                                                  ; CONTROL AND STATUS WORD
U 0D8E, 3E80,15     ;14375          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;14376                                                  ; STATUS WORD - BIT 15
                    ;14377                                                  ; INDICATES START OF TEST TO
                    ;14378                                                  ; CONSOLE
U 0D8F, 10E0,15     ;14379          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;14380  WAIT.T15.0:
U 0D90, 08D9,04     ;14381          JMP [WAIT.T15.0]                        ;LOOP HERE WAITING FOR
                    ;14382                                                  ; CONSOLE TO RESPOND
                    ;14383
U 0D91, 65A0,15     ;14384          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;14385                                                  ; IN LS
                    ;14386
U 0D92, B64A,15     ;14387          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0D93, 3E8C,15     ;14388          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;14389
                    ;14390
                    ;14391
```

```
U 0D94, E58A,15 ;14392          CLR LS[ERROR.MASK]
                ;14393
U 0D95, B670,15 ;14394          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0D96, 3E80,15 ;14395          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                ;14396
U 0D97, B66E,15 ;14397          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 0D98, 6D80,15 ;14398          BIS WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;14399
                ;14400
U 0D99, B78E,15 ;14401          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;14402          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 0D9A, D94E,35 ;14403           DT(LONG)&SET.ALU.CC
U 0D9B, 88D9,D1 ;14404          JMP.IF[BIT.SET] TO [SIZE.OK.T15.1]      ;IF YES THEN GO RUN TEST
                ;14405
U 0D9C, 8870,0C ;14406          JSR [DRIVE.SIZE]                        ;GO RUN DRIVE SIZING ROUTINE
                ;14407
                ;14408
                ;14409  SIZE.OK.T15.1:
                ;14410
U 0D9D, 8872,EC ;14411          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;14412
                ;14413          ;SELECT AN RL02 DRIVE
                ;14414
U 0D9E, B78E,15 ;14415          MOV LS[DRIVE.STATUS] TO WR[0]
                ;14416          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0D9F, 5940,35 ;14417           DT(LONG)&SET.ALU.CC
U 0DA0, 88DA,39 ;14418          JMP.IF[BITS.CLR] TO [SET.DS0.T15.1]     ;JMP IF DRV 0 IS NOT AN R80
U 0DA1, B717,15 ;14419          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 0DA2, 88DA,44 ;14420          JMP [TEST.T15.1]
                ;14421  SET.DS0.T15.1:
U 0DA3, 3715,15 ;14422          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;14423
                ;14424  TEST.T15.1:
                ;14425
U 0DA4, 2F87,95 ;14426          CLR WR[3]                               ;USE AS ADDR TRACKER
                ;14427
U 0DA5, 97DC,15 ;14428          PORT.CONTROL [SEL.FIFO.B]               ;SEL FIFO B FROM THE PORT
                ;14429
U 0DA6, 3720,15 ;14430          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0DA7, 370A,95 ;14431          MOV LS[SETCSR.F5] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 0DA8, AEC2,15 ;14432          BIS WR[1] TO WR[0]                      ; TO USEL FIFO A
U 0DA9, 17A0,15 ;14433          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;14434                                                  ;MAINT=1, CRDY=0, F<2:0>=101
                ;14435  ;USEL FIFO A
                ;14436  ;-------------------------------------------------------------------------------
                ;14437  ;-------------------------------------------------------------------------------
                ;14438  ;                                       *******
                ;14439  ;                                       * IDC *
                ;14440  ;                                       *******
                ;14441  ;-------------------------------------------------------------------------------
                ;14442  ;018:
                ;14443  ;=000
                ;14444  ;DIAG.IDLE:
                ;14445  ;
                ;14446  ;       BEN0/F0,
```

```
                ;14447  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;14448  ;       BEN2/F2,
                ;14449  ;       NAD/DIAG.IDLE
                ;14450  ;-------------------------------------------------------------------------
                ;14451  ;01D:
                ;14452  ;=101
                ;14453  ;
                ;14454  ;       BEN0/CRDY.L,
                ;14455  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;14456  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;14457  ;-------------------------------------------------------------------------
                ;14458  ;075:
                ;14459  ;=1*1
                ;14460  ;TEST.F5:
                ;14461  ;
                ;14462  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;14463  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;14464  ;
                ;14465  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;14466  ;                                       ; MUST USEL FIFO A
                ;14467  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;14468  ;                                       ; AND DIAG.IDLE
                ;14469  ;-------------------------------------------------------------------------
                ;14470  ;1D8:
                ;14471  ;XFER.REQ:
                ;14472  ;
                ;14473  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;14474  ;       NAD/DIAG.WAIT
                ;14475  ;-------------------------------------------------------------------------
                ;14476  ;1D7:
                ;14477  ;DIAG.WAIT:
                ;14478  ;
                ;14479  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;14480  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;14481  ;
                ;14482  ;-------------------------------------------------------------------------
                ;14483  ;159:
                ;14484  ;=*0*
                ;14485  ;DIAG.WAIT1:
                ;14486  ;
                ;14487  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;14488  ;                               ; COMMAND FROM THE CPU
                ;14489  ;
                ;14490  ;-------------------------------------------------------------------------
                ;14491  ;158:
                ;14492  ;=*1*
                ;14493  ;DIAG.WAIT2:
                ;14494  ;
                ;14495  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;14496  ;                               ; WAIT SOME MORE
                ;14497  ;-------------------------------------------------------------------------
                ;14498  WAIT.IDC.T15.1:
U 0DAA, DB00,1A ;14499          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0DAB, 88DA,D4 ;14500          JMP [IDC.DONE.T15.1]                    ;XFER REQ ASSERTED
U 0DAC, 08DA,A4 ;14501          JMP [WAIT.IDC.T15.1]                    ;WAIT SOME MORE
```

```
                ;14502
                ;14503  IDC.DONE.T15.1:
U 0DAD, B700,15 ;14504          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0DAE, 17A0,15 ;14505          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0DAF, 90FA,15 ;14506          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;14507
U 0DB0, 3720,15 ;14508          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0DB1, B708,95 ;14509          MOV LS[SETCSR.F4] TO WR[1]              ; THE IDC ROUTINE THAT WILL
U 0DB2, AEC2,15 ;14510          BIS WR[1] TO WR[0]                      ; UCHANGE FIFO TO SEL FIFO B
U 0DB3, 17A0,15 ;14511          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;14512                                                  ;MAINT=1,CRDY=0, F<2:0>=100
                ;14513  ;UCHNG FIFO TO SEL FIFO B
                ;14514  ;-------------------------------------------------------------------------
                ;14515  ;-------------------------------------------------------------------------
                ;14516  ;                               *******
                ;14517  ;                               * IDC *
                ;14518  ;                               *******
                ;14519  ;-----------------------------------------------------------------------
                ;14520  ;018:
                ;14521  ;=000
                ;14522  ;DIAG.IDLE:
                ;14523  ;
                ;14524  ;       BEN0/F0,
                ;14525  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;14526  ;       BEN2/F2,
                ;14527  ;       NAD/DIAG.IDLE
                ;14528  ;-----------------------------------------------------------------------
                ;14529  ;01C:
                ;14530  ;=100
                ;14531  ;
                ;14532  ;       BEN0/CRDY.L,
                ;14533  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;14534  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;14535  ;-----------------------------------------------------------------------
                ;14536  ;06F:
                ;14537  ;=1*1
                ;14538  ;
                ;14539  ;TEST.F4:
                ;14540  ;       UCMD/CHG.FIFO,                  ;CHANGE FIFO TO USEL FIFO B
                ;14541  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;14542  ;       NAD/XFER.REQ                    ;SEND XFER REQ
                ;14543  ;-----------------------------------------------------------------------
                ;14544  ;1D8:
                ;14545  ;XFER.REQ:
                ;14546  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;14547  ;       NAD/DIAG.WAIT
                ;14548  ;-----------------------------------------------------------------------
                ;14549  ;1D7:
                ;14550  ;DIAG.WAIT:
                ;14551  ;
                ;14552  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;14553  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;14554  ;-----------------------------------------------------------------------
                ;14555  ;159:
                ;14556  ;=*0*
```

```
                ;14557  ;DIAG.WAIT1:
                ;14558  ;
                ;14559  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;14560  ;                               ; COMMAND FROM THE CPU
                ;14561  ;-------------------------------------------------------------------------
                ;14562  ;15B:
                ;14563  ;=*1*
                ;14564  ;DIAG.WAIT2:
                ;14565  ;
                ;14566  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;14567  ;                               ; WAIT SOME MORE
                ;14568  ;-------------------------------------------------------------------------
                ;14569  WAIT.IDC.T15.2:
U 0DB4, DB00,1A ;14570          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0DB5, 08DB,74 ;14571          JMP [IDC.DONE.T15.2]                    ;XFER REQ ASSERTED
U 0DB6, 08DB,44 ;14572          JMP [WAIT.IDC.T15.2]                    ;WAIT SOME MORE
                ;14573  IDC.DONE.T15.2:
U 0DB7, B700,15 ;14574          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0DB8, 17A0,15 ;14575          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0DB9, 90FA,15 ;14576          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;14577
                ;14578
                ;14579  LOOP.T15.1:
U 0DBA, B640,15 ;14580          MOV LS[#1] TO WR[0]
U 0DBB, BE82,15 ;14581          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                ;14582
U 0DBC, 17C0,15 ;14583          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO B ADRS CNTR
                ;14584
U 0DBD, 3712,95 ;14585          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0DBE, B706,15 ;14586          MOV LS[SETCSR.F3] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 0DBF, AEC2,15 ;14587          BIS WR[1] TO WR[0]                      ; LOOP UNTIL OVFLW L ASSERTS
                ;14588                                                  ; AND THEN ASSERTS XFER REQ
U 0DC0, AEC4,15 ;14589          BIS WR[2]  TO WR[0]                     ;SELECT AN RL02
U 0DC1, 17A0,15 ;14590          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;14591                                                  ;MAINT=0, CRDY=1, F<2:0>=011
                ;14592  ;-------------------------------------------------------------------------
                ;14593  ;-------------------------------------------------------------------------
                ;14594  ;                               *******
                ;14595  ;                               * IDC *
                ;14596  ;                               *******
                ;14597  ;-------------------------------------------------------------------------
                ;14598  ;018:
                ;14599  ;=000
                ;14600  ;DIAG.IDLE:
                ;14601  ;
                ;14602  ;       BEN0/F0,
                ;14603  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;14604  ;       BEN2/F2,
                ;14605  ;       NAD/DIAG.IDLE
                ;14606  ;-------------------------------------------------------------------------
                ;14607  ;01B:
                ;14608  ;=011
                ;14609  ;       BEN0/CRDY.L,
                ;14610  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;14611  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
```

```
                ;14612  ;-------------------------------------------------------------------------
                ;14613  ;068:
                ;14614  ;=0*0
                ;14615  ;TEST.FUNC3:
                ;14616  ;
                ;14617  ;TEST.FIFO.OVLW.0:
                ;14618  ;       BEN1/FIFO.OVFLW.L,      ;IS FIFO OVFLW ASSERTED?
                ;14619  ;       NAD/TEST.FIFO.OVFLW.1
                ;14620  ;-------------------------------------------------------------------------
                ;14621  ;190:
                ;14622  ;=0*
                ;14623  ;TEST.FIFO.OVFLW.1:
                ;14624  ;
                ;14625  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;14626  ;-------------------------------------------------------------------------
                ;14627  ;192:
                ;14628  ;=1*
                ;14629  ;
                ;14630  ;       NAD/TEST.FIFO.OVFLW.0                   ;OVFLW NOT ASSERTED...LOOP
                ;14631  ;-------------------------------------------------------------------------
                ;14632
U 0DC2, 3792,15 ;14633          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;14634  NOP.T15.1:
                ;14635          DEC WR[0],
U 0DC3, A100,35 ;14636           DT(LONG)&SET.ALU.CC
U 0DC4, 08DC,31 ;14637          JMP.IF[NEQ] TO [NOP.T15.1]
                ;14638
                ;14639
                ;14640
                ;14641
U 0DC5, DB00,1A ;14642          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF OVFLW L ASSERTED
U 0DC6, 08E0,04 ;14643          JMP [ERROR.T15.1]                       ;OVFLW L ASSERTED WHEN FIFO
                ;14644                                                  ; ADRS WAS CLEAR
                ;14645
U 0DC7, 2F80,15 ;14646          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0DC8, 2F82,95 ;14647          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0DC9, BE89,95 ;14648          MOV WR[3] TO LS[ADDRESS.DATA]
U 0DCA, 0869,3C ;14649          JSR [CHECK.RESULT]
U 0DCB, 88DB,A4 ;14650          JMP [LOOP.T15.1]
                ;14651
                ;14652
                ;14653
U 0DCC, 3642,15 ;14654          MOV LS[#2] TO WR[0]                     ;SET UP FOR ERROR 2
U 0DCD, BE82,15 ;14655          MOV WR[0] TO LS[ERROR.NUMBER]
                ;14656
U 0DCE, B626,15 ;14657          MOV LS[#FF] TO WR[0]                    ;ONE BEFORE OVFLW FOR AN RL02
U 0DCF, 3E10,15 ;14658          MOV WR[0] TO LS[T8]
                ;14659
U 0DD0, 2F87,95 ;14660          CLR WR[3]                               ;USE TO TRACK FIFO ADRS
                ;14661  INCR.CNTR.T15.1:
U 0DD1, 97A8,15 ;14662          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;14663                                                  ; TO FIFO B TO INCR ADRS CNTR
U 0DD2, 2047,95 ;14664          INC WR[3]                               ;INCR ADRS TRACKER
                ;14665
U 0DD3, B788,15 ;14666          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
```

```
                ;14667  NOP.T15.2:
                ;14668          DEC WR[0],
U 0DD4, A100,35 ;14669           DT(LONG)&SET.ALU.CC
U 0DD5, 08DD,41 ;14670          JMP.IF[NEQ] TO [NOP.T15.2]
                ;14671
                ;14672
U 0DD6, DB00,1A ;14673          SKIP.IF[NO.FAST.INTERRUPT]              ;CHECK IF OVFLW L ASSERTED
U 0DD7, 08E0,04 ;14674          JMP [ERROR.T15.1]                       ;OVFLW L ASSERTED TOO SOON
                ;14675
                ;14676
U 0DD8, 2F80,15 ;14677          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0DD9, 2F82,95 ;14678          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0DDA, BE89,95 ;14679          MOV WR[3] TO LS[ADDRESS.DATA]
U 0DDB, 0869,3C ;14680          JSR [CHECK.RESULT]
U 0DDC, 88DB,A4 ;14681          JMP [LOOP.T15.1]
                ;14682
                ;14683          CMP LS[T8] WITH WR[3],                  ;LAST COUNT?
U 0DDD, 4E11,B5 ;14684           DT(LONG)&SET.ALU.CC
U 0DDE, 08DD,11 ;14685          JMP.IF[NEQ] TO [INCR.CNTR.T15.1]        ;JUMP IF NOT LAST COUNT
                ;14686
                ;14687
U 0DDF, B788,15 ;14688          MOV LS[#3] TO WR[0]
U 0DE0, BE82,15 ;14689          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 3
                ;14690
U 0DE1, 97A8,15 ;14691          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF DATA TO
                ;14692                                                      ;FIFO B
                ;14693                                                  ; TO INCR ADRS CNTR TO OVFLW
U 0DE2, 2047,95 ;14694          INC WR[3]                               ;INCR THE ADRS TRACKER
U 0DE3, B788,15 ;14695          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;14696  NOP.T15.3:
                ;14697          DEC WR[0],
U 0DE4, A100,35 ;14698           DT(LONG)&SET.ALU.CC
U 0DE5, 08DE,41 ;14699          JMP.IF[NEQ] TO [NOP.T15.3]
                ;14700
                ;14701
                ;14702
U 0DE6, DB00,1A ;14703          SKIP.IF[NO.FAST.INTERRUPT]              ;OVFLW L ASSERTED?
U 0DE7, 88DE,94 ;14704          JMP [OVFLW.OK.T15.1]                    ;OK
U 0DE8, 08E0,04 ;14705          JMP [ERROR.T15.1]                       ;OVFLW DID NOT ASSERT
                ;14706
                ;14707  OVFLW.OK.T15.1:
                ;14708
U 0DE9, 2F80,15 ;14709          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0DEA, 2F82,95 ;14710          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0DEB, BE89,95 ;14711          MOV WR[3] TO LS[ADDRESS.DATA]
U 0DEC, 0869,3C ;14712          JSR [CHECK.RESULT]
U 0DED, 88DB,A4 ;14713          JMP [LOOP.T15.1]
                ;14714
U 0DEE, 3644,15 ;14715          MOV LS[#4] TO WR[0]
U 0DEF, BE82,15 ;14716          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 4
                ;14717  LOOP.T15.2:
U 0DF0, 8872,EC ;14718          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
U 0DF1, 17C0,15 ;14719          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO B ADRS CNTR
                ;14720                                                  ; TO DEASSERT OVFLW L
                ;14721
```

```
                ;14722                                          ;SET UP THE CSR TO BRANCH TO
U ODF2, B706,15 ;14723          MOV LS[SETCSR.F3] TO WR[0]      ; THE CORRECT IDC ROUTINE THAT
                ;14724                                          ; WILL USET OVFLW AND THEN
                ;14725                                          ; BRANCH TO SEE IF OVFLW DID
                ;14726                                          ; ASSERT
U ODF3, AEC4,15 ;14727          BIS WR[2] TO WR[0]              ;SELECT AN RL02
U ODF4, 17A0,15 ;14728          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;14729                                          ;MAINT=0, CRDY=0, F<2:0>=011
                ;14730  ;-------------------------------------------------------------------------
                ;14731  ;-------------------------------------------------------------------------
                ;14732  ;                               *******
                ;14733  ;                               * IDC *
                ;14734  ;                               *******
                ;14735  ;-------------------------------------------------------------------
                ;14736  ;018:
                ;14737  ;=000
                ;14738  ;DIAG.IDLE:
                ;14739  ;
                ;14740  ;       BEN0/F0,
                ;14741  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;14742  ;       BEN2/F2,
                ;14743  ;       NAD/DIAG.IDLE
                ;14744  ;-------------------------------------------------------------------
                ;14745  ;01B:
                ;14746  ;=011
                ;14747  ;       BEN0/CRDY.L,
                ;14748  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;14749  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;14750  ;-------------------------------------------------------------------
                ;14751  ;069:
                ;14752  ;=0*1
                ;14753  ;TEST.USET.OVFLW:
                ;14754  ;
                ;14755  ;       FUNC/SET.FIFO.OVF,                      ;USET OVFLW
                ;14756  ;       INCR.FIFO.CNTR/ON,                      ;CLK OVFLW
                ;14757  ;       NAD/TEST.FIFO.OVFLW.0
                ;14758  ;-------------------------------------------------------------------
                ;14759  ;068:
                ;14760  ;=0*0
                ;14761  ;TEST.FIFO.OVFLW.0:
                ;14762  ;
                ;14763  ;       BEN1/FIFO.OVFLW.L,              ;IS FIFO OVERFLOW ASSERTED?
                ;14764  ;       NAD/TEST.FIFO.OVFLW.1
                ;14765  ;-------------------------------------------------------------------
                ;14766  ;190:
                ;14767  ;=0*
                ;14768  ;TEST.FIFO.OVFLW.1:
                ;14769  ;
                ;14770  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;14771  ;-------------------------------------------------------------------
                ;14772  ;192:
                ;14773  ;=1*
                ;14774  ;
                ;14775  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;14776  ;-------------------------------------------------------------------
```

```
                    ;14777
U 0DF5, 3792,15     ;14778          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                    ;14779  NOP.T15.4:
                    ;14780          DEC WR[0],
U 0DF6, A100,35     ;14781           DT(LONG)&SET.ALU.CC
U 0DF7, 08DF,61     ;14782          JMP.IF[NEQ] TO [NOP.T15.4]
                    ;14783
U 0DF8, DB00,1A     ;14784          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF OVFLW L ASSERTED
U 0DF9, 08E0,54     ;14785          JMP [CALL.CH.RESULT.T15.1]              ;OVFLW ASSERTED OK
                    ;14786
                    ;14787  ERROR.T15.2:
U 0DFA, 3640,95     ;14788          MOV LS[#1] TO WR[1]                     ;OVFLW DID NOT ASSERT
U 0DFB, 2F80,15     ;14789          CLR WR[0]                               ; FORCE AN ERROR
U 0DFC, 6588,15     ;14790          CLR LS[ADDRESS.DATA]                    ;CLR FOR PRINTOUT
U 0DFD, 0869,3C     ;14791          JSR [CHECK.RESULT]
U 0DFE, 08DF,04     ;14792          JMP [LOOP.T15.2]                        ;LOOP HERE IF ERR & LOE IS SET
U 0DFF, 08E0,A4     ;14793          JMP [CLEANUP.T15.1]                     ; ELSE END TEST
                    ;14794
                    ;14795
                    ;14796  ERROR.T15.1:
U 0E00, 3640,95     ;14797          MOV LS[#1] TO WR[1]                     ;FORCE AN ERROR
U 0E01, 2F80,15     ;14798          CLR WR[0]
U 0E02, BE89,95     ;14799          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U 0E03, 0869,3C     ;14800          JSR [CHECK.RESULT]
U 0E04, 88DB,A4     ;14801          JMP [LOOP.T15.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;14802                                                  ;ELSE SKIP OTHER ERRORS AND END
                    ;14803                                                  ; TEST
                    ;14804  CALL.CH.RESULT.T15.1:
                    ;14805
U 0E05, 2F80,15     ;14806          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0E06, 2F82,95     ;14807          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0E07, 6588,15     ;14808          CLR LS[ADDRESS.DATA]
U 0E08, 0869,3C     ;14809          JSR [CHECK.RESULT]
U 0E09, 08DF,04     ;14810          JMP [LOOP.T15.2]
                    ;14811
                    ;14812
                    ;14813  CLEANUP.T15.1:
U 0E0A, 8875,3C     ;14814          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                    ;14815                                                  ; THIS TEST
                    ;14816  END.T15:                                        ;END TEST
                    ;14817
                    ;14818
                    ;14819
                    ;14820
                    ;14821
                    ;14822
```

```
;14823  .PAGE  "Test 16  FIFO B ADRS CNTR OVFLW  L BRANCH TEST 2 (M8388 IDC MODULE)"
;14824  ;++
;14825  ;
;14826  ; Test Description:
;14827  ;
;14828  ;       This test will only be run if an R80 is available on the system.
;14829  ;       This test is designed to verify that OVFLW L asserts on the correct
;14830  ;       address count (200 HEX) of FIFO B when an R80 is selected.
;14831  ;       USET FIFO OVFLW will also be verified.
;14832  ;
;14833  ; Assumptions:
;14834  ;
;14835  ;       It is assumed that XFER.REQ works correctly.
;14836  ;
;14837  ; Test Steps:
;14838  ;
;14839  ;       1. Set up error mask, error number and module number in LS
;14840  ;          (for error printouts) and clear the previous error number in LS.
;14841  ;       2. If the DRIVE SIZING TEST has not been run previously then
;14842  ;          go run the DISK DRIVE SIZING ROUTINE.
;14843  ;       3. If an R80 is not available on the system, then go to end of test.
;14844  ;       4. Force the IDC microcode to DIAG.IDLE.
;14845  ;       5. PSEL FIFO B.
;14846  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;14847  ;
;14848  ;                                       *******
;14849  ;                                       * IDC *
;14850  ;                                       *******
;14851  ;
;14852  ;               IDC1. Select FIFO A, UCM = 5.
;14853  ;               IDC2. Change FIFO, UCM = 6. (to USEL FIFO B)
;14854  ;
;14855  ;       7. Set up the CSR to branch to the correct IDC microcode loop.
;14856  ;
;14857  ;                                       *******
;14858  ;                                       * IDC *
;14859  ;                                       *******
;14860  ;               The IDC microcode  will continue looping on the following
;14861  ;               steps until OVFLW L asserts or a CLEAR IDC is issued.
;14862  ;
;14863  ;               IDC3. Select BEN1/OVFLW L.
;14864  ;               IDC4. If OVFLW L is asserted then assert XFER REQ and go to
;14865  ;                     DIAG.WAIT.
;14866  ;               IDC5. Go to IDC3.
;14867  ;
;14868  ;       8. Clear the FIFO ADRS CNTR.
;14869  ;       9. If XFER REQ is asserted (OVFLW asserted) then issue error.
;14870  ;      10. Increment the error number.
;14871  ;      11. Select an R80 drive.
;14872  ;      12. Set WR[3] = 0 to use as a counter.
;14873  ;      13. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;14874  ;      14. Increment WR[3].
;14875  ;      15. If XFER REQ is asserted (OVFLW asserted) then issue error.
;14876  ;      16. Repeat Steps 13 - 16 until WR[3] = 511 (1FF HEX).
;14877  ;      17. Increment the error number.
```

```
;14878  ;       18. Write a byte of data to FIFO B to increment the FIFO ADRS CNTR by 1.
;14879  ;       19. Increment WR[3].
;14880  ;       20. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;14881  ;       21. Force the IDC microcode to DIAG.IDLE.
;14882  ;       22. Clear the FIFO ADRS CNTR.
;14883  ;       23. Set up the CSR to branch to the correct IDC routine.
;14884  ;
;14885  ;                                       *******
;14886  ;                                       * IDC *
;14887  ;                                       *******
;14888  ;
;14889  ;               IDC5. Set FUNC<35:32> = 0E, USET.FIFO OVFLW.
;14890  ;               IDC6. Perform Steps IDC2 - IDC4.
;14891  ;
;14892  ;       24. NOP to allow IDC time to branch.
;14893  ;       25. If XFER REQ is not asserted (OVFLW did not assert) then issue error.
;14894  ;       26. CLEAR IDC.
;14895  ;       27. End test.
;14896  ;
;14897  ;
;14898  ; Errors:
;14899  ;
;14900  ;                 Printout:
;14901  ;                         EXPECTED          RECEIVED        OTHER DATA
;14902  ;                           N/A               N/A             WR[3]
;14903  ;
;14904  ;       ERROR 1 - PCLR FIFO CNTR failed or BEN1/FIFO OVFLW L failed unasserted.
;14905  ;
;14906  ;       ERROR 2 - PINCR FIFO CNTR failed or OVFLW L asserted too soon for an
;14907  ;                 R80 drive.
;14908  ;
;14909  ;       ERROR 3 - OVFLW L did not assert at 512 for an R80 drive.
;14910  ;
;14911  ;       ERROR 4 - OVFLW did not set when a USET FIFO OVFLW was executed.
;14912  ;
;14913  ; Debug:
;14914  ;       An R80 disk drive will be selected which will deassert L  RL02 H at
;14915  ;       the CSR SELECTED STATUS LATCH PAL.
;14916  ;       L RL02 H = L  is inverted to become R80 H = H.
;14917  ;
;14918  ;  ERROR 1:
;14919  ;
;14920  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;14921  ;       be decoded by the PORT INTERFACE REG PAL.
;14922  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;14923  ;
;14924  ;                               CSR 17 H = H
;14925  ;                               CSR 14 H = H
;14926  ;                               CSR 12 H = L
;14927  ;                               CSR 11 H = L
;14928  ;                               CSR 10 H = L
;14929  ;                               PORT INSTR H = H
;14930  ;                               CPU P2 H = H
;14931  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;14932  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear
```

```
;14933  ;       FIFO OVFLW L.
;14934  ;
;14935  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;14936  ;               BEN1 S0 H = L
;14937  ;               BEN1 S1 H = L
;14938  ;               BEN1 S2 H = H
;14939  ;
;14940  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;14941  ;       remain in the loop waiting for FIFO OVFLW L to assert and will
;14942  ;       not assert XFER REQ H.
;14943  ;       The CPU will then check to insure that XFER REQ H did not
;14944  ;       assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;14945  ;
;14946  ;  ERROR 2:
;14947  ;
;14948  ;       FIFO B is selected by the port by a PORT.CONTROL [SEL.FIFO.B]
;14949  ;       instruction so that the FIFO CNTR can be incremented from the
;14950  ;       PORT. This instruction is decoded by the PORT INTERFACE REG PAL.
;14951  ;       The inputs will be:
;14952  ;               CSR 17 H = H
;14953  ;               CSR 14 H = H
;14954  ;               CSR 12 H = H
;14955  ;               CSR 11 H = H
;14956  ;               CSR 10 H = H
;14957  ;               PORT INSTR H = H
;14958  ;               CPU P2 H = H
;14959  ;
;14960  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
;14961  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
;14962  ;
;14963  ;       FIFO B will also be selected by the IDC microcode to allow FIFO B
;14964  ;       OVFLW  L to be asserted.
;14965  ;       The IDC microcode will issue UCMD/SET.FIFOA. This will
;14966  ;       assert UCMD 2 H and UCMD 0 H of the IDC microword. These bits are
;14967  ;       decoded by the CONTROL STATUS REG PAL. The inputs will be:
;14968  ;               UCMD 2 H = H
;14969  ;               UCMD 1 H = L
;14970  ;               UCMD 0 H = H
;14971  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOB H will deassert and
;14972  ;       USEL FIFOA H being the inverse of USEL FIFOB H, will assert.
;14973  ;       The IDC microcode will execute a UCMD/CHG.FIFO. This will assert
;14974  ;       UCMD 2 H and UCMD 1 H of the IDC microword. These bits are decoded by
;14975  ;       the CONTROL STATUS REG PAL. The inputs will be:
;14976  ;               UCMD 2 H = H
;14977  ;               UCMD 1 H = H
;14978  ;               UCMD 0 H = L
;14979  ;       When the PAL is clocked by P2 CLOCK L, USEL FIFOA H = L will be
;14980  ;       inverted to USEL FIFOB H = H.
;14981  ;
;14982  ;       A PORT.WRITE PORT.ADRS[DATA.BYTE] is issued from the CPU. This
;14983  ;       instruction will be decoded by the PORT RD/WR DECODE PAL.
;14984  ;       The inputs to this PAL should be:
;14985  ;               CSR 17 H = H
;14986  ;               CSR 14 H = L
;14987  ;               CSR 13 H = H
```

```
;14988  ;                CSR 12 H = L
;14989  ;                CSR 11 H = H
;14990  ;                CSR 10 H = L
;14991  ;                PORT INSTR H = H
;14992  ;                CPU P2 H = H
;14993  ;        This combination of inputs will assert BYTE L and WRITE DATA L, and
;14994  ;        STROBE DATA H.
;14995  ;        BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS and are
;14996  ;        clocked by CPU CLOCK H. This combination of inputs will assert
;14997  ;        PINCR FIFO CNTR H. This signal is ANDED with PSEL FIFO B H = H and
;14998  ;        PORT CLOCK L as the clock input to the FIFO B ADRS CNTR HI
;14999  ;        and LO PALs. When these PALs are clocked, FIFOB ADRS<8:0> will
;15000  ;        increment.
;15001  ;
;15002  ;        FIFO OVFLW L will not asssert because the inputs to FIFOA ADRS CNTR HI
;15003  ;        PAL will be USEL FIFOA H = L and FIFOB OVFLW L = H.
;15004  ;        Since R80 H will be = H, FIFOB OVFLW L at the FIFOB ADRS CNTR HI PAL,
;15005  ;        will not assert until FIFOB ADRS<8:4> = H and FIFOB LO FULL H = H
;15006  ;        and USEL FIFO B H = H and the PAL is clocked once more.
;15007  ;
;15008  ;        When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;15009  ;                BEN1 S0 H = L
;15010  ;                BEN1 S1 H = L
;15011  ;                BEN1 S2 H = H
;15012  ;
;15013  ;        This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;15014  ;        remain in the loop waiting for FIFO OVFLW L to assert and will
;15015  ;        not assert XFER REQ H.
;15016  ;        The CPU will then check to insure that XFER REQ H did not
;15017  ;        assert by executing a SKIP.IF[NO.FAST.INTERRUPT].
;15018  ;
;15019  ;  ERROR 3:
;15020  ;       FIFOB ADRS <8:0> will be = 111111111. The FIFOB ADRS CNTR PALs will
;15021  ;       be clocked one more time by writing a byte of data to FIFO B.
;15022  ;       The inputs to the FIFOB ADRS CNTR HI PAL will be:
;15023  ;               R80 H = L
;15024  ;               USEL FIFOB H = H
;15025  ;               FIFOB LO FULL H = H
;15026  ;               FIFOB ADRS <7:4> H = 1111
;15027  ;       This combination of inputs will assert FIFOB OVFLW L.
;15028  ;
;15029  ;       The inputs to the FIFOA ADRS CNTR HI PAL will be:
;15030  ;               FIFOB OVFLW L = L
;15031  ;               USEL FIFO A H = L
;15032  ;       so approximately 20ns after FIFOB OVFLW L assets, FIFO OVFLW L
;15033  ;       will assert.
;15034  ;
;15035  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
;15036  ;               BEN1 S0 H = L
;15037  ;               BEN1 S1 H = L
;15038  ;               BEN1 S2 H = H
;15039  ;
;15040  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
;15041  ;       branch to an instruction that will assert XFER REQ H.
;15042  ;       The CPU will then check to insure that XFER REQ H asserted by
```

```
                    ;15043  ;       executing a SKIP.IF[NO.FAST.INTERRUPT].
                    ;15044  ;
                    ;15045  ;  ERROR 4:
                    ;15046  ;
                    ;15047  ;
                    ;15048  ;       The FIFO A ADRS CNTR PAL will be cleared which will insure that
                    ;15049  ;       FIFO OVFLW L is not asserted. The IDC microcode will then branch to
                    ;15050  ;       an instruction of FUNC/SET.FIFO.OVF. The output of the microsequencer
                    ;15051  ;       will be:
                    ;15052  ;               UFUNC 3 H = H
                    ;15053  ;               UFUNC 2 H = H
                    ;15054  ;               UFUNC 1 H = H
                    ;15055  ;               UFUNC 0 H = L
                    ;15056  ;       These bits will be decoded and USET FIFO OVF L will assert. This
                    ;15057  ;       signal is an input to the FIFOB ADRS CNTR HI PAL. USEL FIFOB H will
                    ;15058  ;       also be asserted. When the PAL is clocked by INCR.FIFO.CNTR/ON,
                    ;15059  ;       FIFOB OVFLW L will assert.  FIFOB OVFLW L =  L is an input to the
                    ;15060  ;       FIFOA ADRS CNTR H PAL. USEL FIFOA H will not be asserted, so
                    ;15061  ;       approximately 20ns later, FIFO OVFLW Lwill assert.
                    ;15062  ;
                    ;15063  ;       When the BEN1/FIFO.OVFLW.L IDC microinstruction is executed:
                    ;15064  ;               BEN1 S0 H = L
                    ;15065  ;               BEN1 S1 H = L
                    ;15066  ;               BEN1 S2 H = H
                    ;15067  ;
                    ;15068  ;       This will select FIFO OVFLW L as NUA 1 H. The IDC microcode will
                    ;15069  ;       branch to an instruction that will assert XFER REQ H.
                    ;15070  ;       The CPU will then check to insure that XFER REQ H asserted by
                    ;15071  ;--
                    ;15072  ;*******************************************************************************
                    ;15073  T.16:
U 0E0B, B65E,15     ;15074          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;15075                                                  ; CONTROL AND STATUS WORD
U 0E0C, 3E80,15     ;15076          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;15077                                                  ; STATUS WORD - BIT 15
                    ;15078                                                  ; INDICATES START OF TEST TO
                    ;15079                                                  ; CONSOLE
U 0E0D, 10E0,15     ;15080          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;15081  WAIT.T16.0:
U 0E0E, 88E0,E4     ;15082          JMP [WAIT.T16.0]                        ;LOOP HERE WAITING FOR
                    ;15083                                                  ; CONSOLE TO RESPOND
                    ;15084
U 0E0F, 65A0,15     ;15085          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;15086                                                  ; IN LS
                    ;15087
U 0E10, B64A,15     ;15088          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0E11, 3E8C,15     ;15089          MOV WR[0] TO LS[MODULE.NUM]              ; INDICATE IDC MODULE
                    ;15090
                    ;15091
                    ;15092
U 0E12, E58A,15     ;15093          CLR LS[ERROR.MASK]
                    ;15094
U 0E13, B670,15     ;15095          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 0E14, 3E80,15     ;15096          MOV WR[0] TO LS[CONTROL.STATUS]          ; IF ERROR
                    ;15097
```

```
U 0E15, B66E,15 ;15098          MOV LS[NA.EXP.REC] TO WR[0]              ;SET UP TO PRINT N/A FOR
U 0E16, 6D80,15 ;15099          BIS WR[0] TO LS[CONTROL.STATUS]          ; EXPECTED & RECEIVED DATA
                ;15100
                ;15101
U 0E17, B78E,15 ;15102          MOV LS[DRIVE.STATUS] TO WR[0]            ;HAS THE DRIVE SIZING ROUTINE
                ;15103          BIT LS[BIT7] WITH WR[0],                 ; BEEN RUN?
U 0E18, D94E,35 ;15104           DT(LONG)&SET.ALU.CC
U 0E19, 08E1,B1 ;15105          JMP.IF[BIT.SET] TO [SIZE.OK.T16.1]       ;IF YES THEN GO RUN TEST
                ;15106
U 0E1A, 8870,0C ;15107          JSR [DRIVE.SIZE]                         ;GO RUN DRIVE SIZING ROUTINE
                ;15108
                ;15109  SIZE.OK.T16.1:
                ;15110
U 0E1B, 8872,EC ;15111          JSR [DIAG.CODE]                          ;FORCE THE IDC TO DIAG.IDLE
                ;15112
                ;15113          ;SELECT AN R80 DRIVE IF ONE IS AVAILABLE...ELSE SKIP TEST
                ;15114
U 0E1C, B78E,15 ;15115          MOV LS[DRIVE.STATUS] TO WR[0]
U 0E1D, 3790,95 ;15116          MOV LS[#FFFFFFF0] TO WR[1]
U 0E1E, AF42,15 ;15117          BIC WR[1] TO WR[0]                       ;CHECK BITS <3:0>
                ;15118          CMP LS[ZERO] WITH WR[0],                 ;ANY R80S?
U 0E1F, CE9C,35 ;15119           DT(LONG)&SET.ALU.CC
U 0E20, 08E9,79 ;15120          JMP.IF[EQL] TO [CLEANUP.T16.1]           ;NO R80, CLEANUP AND END TEST
                ;15121
U 0E21, B78E,15 ;15122          MOV LS[DRIVE.STATUS] TO WR[0]
                ;15123          BIT LS[BIT0] WITH WR[0],                 ;IS DRIVE 0 AN R80?
U 0E22, 5940,35 ;15124           DT(LONG)&SET.ALU.CC
U 0E23, 88E2,91 ;15125          JMP.IF[BIT.SET] TO [SEL.DR0.T16.1]       ;JMP IF DRV 0 = R80
                ;15126
                ;15127          BIT LS[BIT1] WITH WR[0],                 ;IS DRIVE 1 AN R80?
U 0E24, D942,35 ;15128           DT(LONG)&SET.ALU.CC
U 0E25, 08E2,B1 ;15129          JMP.IF[BIT.SET] TO [SEL.DR1.T16.1]       ;JMP IF DRV 1 = R80
                ;15130
                ;15131          BIT LS[BIT2] WITH WR[0],                 ;IS DRIVE 2 AN R80?
U 0E26, D944,35 ;15132           DT(LONG)&SET.ALU.CC
U 0E27, 08E2,D1 ;15133          JMP.IF[BIT.SET] TO [SEL.DR2.T16.1]       ;JMP IF DRV 2 = R80
                ;15134
U 0E28, 88E2,F4 ;15135          JMP [SEL.DR3.T16.1]                      ;JMP AND SEL DR 3
                ;15136
                ;15137  SEL.DR0.T16.1:
U 0E29, 3715,15 ;15138          MOV LS[SETCSR.DS0] TO WR[2]              ;SAV DRV SEL = 0
U 0E2A, 08E3,04 ;15139          JMP [TEST.T16.1]                         ;GO DO TEST
                ;15140
                ;15141  SEL.DR1.T16.1:
U 0E2B, B717,15 ;15142          MOV LS[SETCSR.DS1] TO WR[2]              ;SAV DRV SEL = 1
U 0E2C, 08E3,04 ;15143          JMP [TEST.T16.1]                         ;GO DO TEST
                ;15144
                ;15145  SEL.DR2.T16.1:
U 0E2D, 3719,15 ;15146          MOV LS[SETCSR.DS2] TO WR[2]              ;SAV DRV SEL = 2
U 0E2E, 08E3,04 ;15147          JMP [TEST.T16.1]                         ;GO DO TEST
                ;15148
                ;15149  SEL.DR3.T16.1:
U 0E2F, B71B,15 ;15150          MOV LS[SETCSR.DS3] TO WR[2]              ;SAV DRV SEL = 3
                ;15151
                ;15152  TEST.T16.1:
```

```
U 0E30, 2F87,95 ;15153          CLR WR[3]                                ;USE AS ADDR TRACKER
                ;15154
U 0E31, 97DC,15 ;15155          PORT.CONTROL [SEL.FIFO.B]                ;SEL FIFO B FROM THE PORT
U 0E32, 3720,15 ;15156          MOV LS[SETCSR.MAINT] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 0E33, 370A,95 ;15157          MOV LS[SETCSR.F5] TO WR[1]               ; THE CORRECT IDC ROUTINE
U 0E34, AEC2,15 ;15158          BIS WR[1] TO WR[0]                       ; TO SELECT FIFO A
U 0E35, 17A0,15 ;15159          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;15160                                                   ;MAINT=1, CRDY=0, F<2:0>=101
                ;15161  ;USEL FIFO A
                ;15162  ;-------------------------------------------------------------------------------
                ;15163  ;-------------------------------------------------------------------------------
                ;15164  ;                                *******
                ;15165  ;                                * IDC *
                ;15166  ;                                *******
                ;15167  ;-------------------------------------------------------------------------------
                ;15168  ;018:
                ;15169  ;=000
                ;15170  ;DIAG.IDLE:
                ;15171  ;
                ;15172  ;       BEN0/F0,
                ;15173  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;15174  ;       BEN2/F2,
                ;15175  ;       NAD/DIAG.IDLE
                ;15176  ;-------------------------------------------------------------------
                ;15177  ;01D:
                ;15178  ;=101
                ;15179  ;
                ;15180  ;       BEN0/CRDY.L,
                ;15181  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15182  ;       NAD/TEST.FUNC5           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15183  ;-------------------------------------------------------------------
                ;15184  ;075:
                ;15185  ;=1*1
                ;15186  ;TEST.F5:
                ;15187  ;
                ;15188  ;       FUNC/CLR.ONLINE,         ;CLR ONLINE FOR THE DRIVE SELECTED
                ;15189  ;                                ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;15190  ;
                ;15191  ;       UCMD/SET.FIFOA,          ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;15192  ;                                ; MUST USEL FIFO A
                ;15193  ;       NAD/XFER.REQ             ;DO NOT INCR DAR BETWEEN HERE
                ;15194  ;                                ; AND DIAG.IDLE
                ;15195  ;-------------------------------------------------------------------
                ;15196  ;1D8:
                ;15197  ;XFER.REQ:
                ;15198  ;
                ;15199  ;       UCMD/SET.XFER.RQST,      ;SEND XFER REQ TO THE CPU
                ;15200  ;       NAD/DIAG.WAIT
                ;15201  ;-------------------------------------------------------------------------------
                ;15202  ;1D7:
                ;15203  ;DIAG.WAIT:
                ;15204  ;
                ;15205  ;       BEN1/XFER.REQ,           ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;15206  ;       NAD/DIAG.WAIT1           ; BEFORE RETURNING TO DIAG.IDLE
                ;15207  ;
```

```
                ;15208  ;-------------------------------------------------------------------------
                ;15209  ;159:
                ;15210  ;=*0*
                ;15211  ;DIAG.WAIT1:
                ;15212  ;
                ;15213  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;15214  ;                               ; COMMAND FROM THE CPU
                ;15215  ;
                ;15216  ;-------------------------------------------------------------------------
                ;15217  ;15B:
                ;15218  ;=*1*
                ;15219  ;DIAG.WAIT2:
                ;15220  ;
                ;15221  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;15222  ;                               ; WAIT SOME MORE
                ;15223  ;
                ;15224  ;-------------------------------------------------------------------------
                ;15225  WAIT.IDC.T16.1:
U 0E36, DB00,1A ;15226          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0E37, 08E3,94 ;15227          JMP [IDC.DONE.T16.1]                    ;XFER REQ ASSERTED
U 0E38, 08E3,64 ;15228          JMP [WAIT.IDC.T16.1]                    ;WAIT SOME MORE
                ;15229
                ;15230  IDC.DONE.T16.1:
U 0E39, B700,15 ;15231          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0E3A, 17A0,15 ;15232          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0E3B, 90FA,15 ;15233          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;15234
U 0E3C, 3720,15 ;15235          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 0E3D, B708,95 ;15236          MOV LS[SETCSR.F4] TO WR[1]              ; THE IDC ROUTINE THAT WILL
U 0E3E, AEC2,15 ;15237          BIS WR[1] TO WR[0]                      ; UCHANGE FIFO TO SEL FIFO B
U 0E3F, 17A0,15 ;15238          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;15239                                                  ;MAINT=1,CRDY=0, F<2:0>=100
                ;15240  ;UCHNG FIFO TO SEL FIFO B
                ;15241  ;-------------------------------------------------------------------------
                ;15242  ;-------------------------------------------------------------------------
                ;15243  ;                               *******
                ;15244  ;                               * IDC *
                ;15245  ;                               *******
                ;15246  ;-------------------------------------------------------------------------
                ;15247  ;018:
                ;15248  ;=000
                ;15249  ;DIAG.IDLE:
                ;15250  ;
                ;15251  ;       BEN0/F0,
                ;15252  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;15253  ;       BEN2/F2,
                ;15254  ;       NAD/DIAG.IDLE
                ;15255  ;-------------------------------------------------------------------------
                ;15256  ;01C:
                ;15257  ;=100
                ;15258  ;
                ;15259  ;       BEN0/CRDY.L,
                ;15260  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15261  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15262  ;-------------------------------------------------------------------------
```

```
                ;15263  ;06F:
                ;15264  ;=1*1
                ;15265  ;
                ;15266  ;TEST.F4:
                ;15267  ;       UCMD/CHG.FIFO,                  ;CHANGE FIFO TO USEL FIFO B
                ;15268  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
                ;15269  ;       NAD/XFER.REQ                    ;SEND XFER REQ
                ;15270  ;-------------------------------------------------------------------------
                ;15271  ;1D8:
                ;15272  ;XFER.REQ:
                ;15273  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;15274  ;       NAD/DIAG.WAIT
                ;15275  ;-------------------------------------------------------------------------
                ;15276  ;1D7:
                ;15277  ;DIAG.WAIT:
                ;15278  ;
                ;15279  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;15280  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;15281  ;-------------------------------------------------------------------------
                ;15282  ;159:
                ;15283  ;=*0*
                ;15284  ;DIAG.WAIT1:
                ;15285  ;
                ;15286  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;15287  ;                               ; COMMAND FROM THE CPU
                ;15288  ;-------------------------------------------------------------------------
                ;15289  ;158:
                ;15290  ;=*1*
                ;15291  ;DIAG.WAIT2:
                ;15292  ;
                ;15293  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;15294  ;                               ; WAIT SOME MORE
                ;15295  ;-------------------------------------------------------------------------
                ;15296  WAIT.IDC.T16.2:
U 0E40, DB00,1A ;15297          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 0E41, 88E4,34 ;15298          JMP [IDC.DONE.T16.2]                    ;XFER REQ ASSERTED
U 0E42, 88E4,04 ;15299          JMP [WAIT.IDC.T16.2]                    ;WAIT SOME MORE
                ;15300  IDC.DONE.T16.2:
U 0E43, B700,15 ;15301          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 0E44, 17A0,15 ;15302          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0E45, 90FA,15 ;15303          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;15304
                ;15305
                ;15306  LOOP.T16.1:
U 0E46, B640,15 ;15307          MOV LS[#1] TO WR[0]
U 0E47, BE82,15 ;15308          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 1
                ;15309
U 0E48, 17C0,15 ;15310          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO B ADRS CNTR
                ;15311
U 0E49, 3712,95 ;15312          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 0E4A, B706,15 ;15313          MOV LS[SETCSR.F3] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 0E4B, AEC2,15 ;15314          BIS WR[1] TO WR[0]                      ; LOOP UNTIL OVFLW ASSERTS
                ;15315                                                  ; AND THEN SETS XFER REQ
U 0E4C, AEC4,15 ;15316          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0E4D, 17A0,15 ;15317          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
```

```
                ;15318                                                  ;MAINT=0, CRDY=1, F<2:0>=011
                ;15319  ;-------------------------------------------------------------------------------
                ;15320  ;-------------------------------------------------------------------------------
                ;15321  ;                               *******
                ;15322  ;                               * IDC *
                ;15323  ;                               *******
                ;15324  ;-------------------------------------------------------------------------------
                ;15325  ;018:
                ;15326  ;=000
                ;15327  ;DIAG.IDLE:
                ;15328  ;
                ;15329  ;       BEN0/F0,
                ;15330  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;15331  ;       BEN2/F2,
                ;15332  ;       NAD/DIAG.IDLE
                ;15333  ;-------------------------------------------------------------------------
                ;15334  ;01B:
                ;15335  ;=011
                ;15336  ;       BEN0/CRDY.L,
                ;15337  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15338  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15339  ;-------------------------------------------------------------------------
                ;15340  ;068:
                ;15341  ;=0*0
                ;15342  ;TEST.FUNC3:
                ;15343  ;
                ;15344  ;TEST.FIFO.OVLW.0:
                ;15345  ;       BEN1/FIFO.OVFLW.L,      ;IS FIFO OVFLW ASSERTED?
                ;15346  ;       NAD/TEST.FIFO.OVFLW.1
                ;15347  ;-------------------------------------------------------------------------
                ;15348  ;190:
                ;15349  ;=0*
                ;15350  ;TEST.FIFO.OVFLW.1:
                ;15351  ;
                ;15352  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;15353  ;-------------------------------------------------------------------------
                ;15354  ;192:
                ;15355  ;=1*
                ;15356  ;
                ;15357  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;15358  ;-------------------------------------------------------------------------
                ;15359
U 0E4E, 3792,15 ;15360          MOV LS[#6] TO WR[0]             ;NOP TO WAIT FOR IDC
                ;15361  NOP.T16.1:
                ;15362          DEC WR[0],
U 0E4F, A100,35 ;15363           DT(LONG)&SET.ALU.CC
U 0E50, 88E4,F1 ;15364          JMP.IF[NEQ] TO [NOP.T16.1]
                ;15365
U 0E51, DB00,1A ;15366          SKIP.IF[NO.FAST.INTERRUPT]      ;SEE IF OVFLW L ASSERTED
U 0E52, 08E8,D4 ;15367          JMP [ERROR.T16.1]               ;OVFLW L ASSERTED WHEN FIFO
                ;15368                                          ; ADRS WAS CLEAR
                ;15369
U 0E53, 2F80,15 ;15370          CLR WR[0]                       ;CALL CHECK.RESULT TO LOCK
U 0E54, 2F82,95 ;15371          CLR WR[1]                       ; IN INTERMITTENT ERRORS
U 0E55, BE89,95 ;15372          MOV WR[3] TO LS[ADDRESS.DATA]
```

```
U 0E56, 0869,3C ;15373          JSR [CHECK.RESULT]
U 0E57, 88E4,64 ;15374          JMP [LOOP.T16.1]
                ;15375
                ;15376
U 0E58, 3642,15 ;15377          MOV LS[#2] TO WR[0]                     ;SET UP FOR ERROR 2
U 0E59, BE82,15 ;15378          MOV WR[0] TO LS[ERROR.NUMBER]
                ;15379
                ;15380
                ;15381
U 0E5A, 378C,15 ;15382          MOV LS[#1FE] TO WR[0]
U 0E5B, 2040,15 ;15383          INC WR[0]                               ;ONE BEFORE OVFLW FOR AN R80
U 0E5C, 3E10,15 ;15384          MOV WR[0] TO LS[T8]
                ;15385
U 0E5D, 2F87,95 ;15386          CLR WR[3]                               ;USE TO TRACK FIFO ADRS
                ;15387  INCR.CNTR.T16.1:
U 0E5E, 97A8,15 ;15388          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE A BYTE OF UNKNOWN DATA
                ;15389                                                  ; TO FIFO B TO INCR ADRS CNTR
U 0E5F, 2047,95 ;15390          INC WR[3]                               ;INCR ADRS TRACKER
U 0E60, B788,15 ;15391          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;15392  NOP.T16.2:
                ;15393          DEC WR[0],
U 0E61, A100,35 ;15394           DT(LONG)&SET.ALU.CC
U 0E62, 88E6,11 ;15395          JMP.IF[NEQ] TO [NOP.T16.2]
                ;15396
                ;15397
U 0E63, DB00,1A ;15398          SKIP.IF[NO.FAST.INTERRUPT]              ;CHECK IF OVFLW L ASSERTED
U 0E64, 08E8,D4 ;15399          JMP [ERROR.T16.1]                       ;OVFLW L ASSERTED TOO SOON
                ;15400
                ;15401
U 0E65, 2F80,15 ;15402          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0E66, 2F82,95 ;15403          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0E67, BE89,95 ;15404          MOV WR[3] TO LS[ADDRESS.DATA]
U 0E68, 0869,3C ;15405          JSR [CHECK.RESULT]
U 0E69, 88E4,64 ;15406          JMP [LOOP.T16.1]
                ;15407
                ;15408
                ;15409          CMP LS[T8] WITH WR[3],                  ;LAST COUNT?
U 0E6A, 4E11,B5 ;15410           DT(LONG)&SET.ALU.CC
U 0E6B, 88E5,E1 ;15411          JMP.IF[NEQ] TO [INCR.CNTR.T16.1]        ;JUMP IF NOT LAST COUNT
                ;15412
U 0E6C, B788,15 ;15413          MOV LS[#3] TO WR[0]
U 0E6D, BE82,15 ;15414          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 3
                ;15415
U 0E6E, 97A8,15 ;15416          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A BYTE OF DATA TO
                ;15417                                                          ;FIFO B
                ;15418                                                  ; TO INCR ADRS CNTR OVFLW
U 0E6F, 2047,95 ;15419          INC WR[3]                               ;INCR THE ADRS TRACKER
U 0E70, B788,15 ;15420          MOV LS[#3] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;15421  NOP.T16.3:
                ;15422          DEC WR[0],
U 0E71, A100,35 ;15423           DT(LONG)&SET.ALU.CC
U 0E72, 08E7,11 ;15424          JMP.IF[NEQ] TO [NOP.T16.3]
                ;15425
U 0E73, DB00,1A ;15426          SKIP.IF[NO.FAST.INTERRUPT]              ;OVFLW L ASSERTED?
U 0E74, 88E7,64 ;15427          JMP [OVFLW.OK.T16.1]                    ;OK
```

```
U 0E75, 08E8,D4 ;15428          JMP [ERROR.T16.1]                       ;OVFLW DID NOT ASSERT
                ;15429
                ;15430  OVFLW.OK.T16.1:
                ;15431
U 0E76, 2F80,15 ;15432          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0E77, 2F82,95 ;15433          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0E78, BE89,95 ;15434          MOV WR[3] TO LS[ADDRESS.DATA]
U 0E79, 0869,3C ;15435          JSR [CHECK.RESULT]
U 0E7A, 88E4,64 ;15436          JMP [LOOP.T16.1]
                ;15437
U 0E7B, 3644,15 ;15438          MOV LS[#4] TO WR[0]
U 0E7C, BE82,15 ;15439          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 4
                ;15440  LOOP.T16.2:
U 0E7D, 8872,EC ;15441          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
U 0E7E, 17C0,15 ;15442          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR FIFO B ADRS CNTR
                ;15443                                                  ; TO DEASSERT OVFLW L
                ;15444
                ;15445                                                  ;SET UP THE CSR TO BRANCH TO
U 0E7F, B706,15 ;15446          MOV LS[SETCSR.F3] TO WR[0]              ; THE CORRECT IDC ROUTINE THAT
                ;15447                                                  ; WILL USET OVFLW AND THEN
                ;15448                                                  ; BRANCH TO SEE IF OVFLW DID
                ;15449                                                  ; ASSERT
U 0E80, AEC4,15 ;15450          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0E81, 17A0,15 ;15451          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;15452                                                  ;MAINT=0, CRDY=0, F<2:0>=011
                ;15453  ;-------------------------------------------------------------------------------
                ;15454  ;-------------------------------------------------------------------------------
                ;15455  ;                              *******
                ;15456  ;                              * IDC *
                ;15457  ;                              *******
                ;15458  ;-------------------------------------------------------------------------------
                ;15459  ;018:
                ;15460  ;=000
                ;15461  ;DIAG.IDLE:
                ;15462  ;
                ;15463  ;       BEN0/F0,
                ;15464  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;15465  ;       BEN2/F2,
                ;15466  ;       NAD/DIAG.IDLE
                ;15467  ;-------------------------------------------------------------------------------
                ;15468  ;01B:
                ;15469  ;=011
                ;15470  ;       BEN0/CRDY.L,
                ;15471  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15472  ;       NAD/TEST.FUNC3          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15473  ;-------------------------------------------------------------------------------
                ;15474  ;069:
                ;15475  ;=0*1
                ;15476  ;TEST.USET.OVFLW:
                ;15477  ;
                ;15478  ;       FUNC/SET.FIFO.OVF,                      ;USET OVFLW
                ;15479  ;       INCR.FIFO.CNTR/ON,                      ;CLK OVFLW
                ;15480  ;       NAD/TEST.FIFO.OVFLW.0
                ;15481  ;-------------------------------------------------------------------------------
                ;15482  ;068:
```

```
                ;15483  ;=0*0
                ;15484  ;TEST.FIFO.OVFLW.0:
                ;15485  ;
                ;15486  ;       BEN1/FIFO.OVFLW.L,              ;IS FIFO OVERFLOW ASSERTED?
                ;15487  ;       NAD/TEST.FIFO.OVFLW.1
                ;15488  ;-------------------------------------------------------------------------
                ;15489  ;190:
                ;15490  ;=0*
                ;15491  ;TEST.FIFO.OVFLW.1:
                ;15492  ;
                ;15493  ;       NAD/XFER.REQ                    ;OVFLW ASSERTED
                ;15494  ;-------------------------------------------------------------------------
                ;15495  ;192:
                ;15496  ;=1*
                ;15497  ;
                ;15498  ;       NAD/TEST.FIFO.OVFLW.0           ;OVFLW NOT ASSERTED...LOOP
                ;15499  ;-------------------------------------------------------------------------
                ;15500
U 0E82, 3792,15 ;15501          MOV LS[#6] TO WR[0]                     ;NOP TO WAIT FOR IDC
                ;15502  NOP.T16.4:
                ;15503          DEC WR[0],
U 0E83, A100,35 ;15504           DT(LONG)&SET.ALU.CC
U 0E84, 88E8,31 ;15505          JMP.IF[NEQ] TO [NOP.T16.4]
                ;15506
U 0E85, DB00,1A ;15507          SKIP.IF[NO.FAST.INTERRUPT]              ;SEE IF OVFLW L ASSERTED
U 0E86, 88E9,24 ;15508          JMP [CALL.CH.RESULT.T16.1]              ;OVFLW ASSERTED OK
                ;15509
                ;15510  ERROR.T16.2:
U 0E87, 3640,95 ;15511          MOV LS[#1] TO WR[1]                     ;OVFLW DID NOT ASSERT
U 0E88, 2F80,15 ;15512          CLR WR[0]                               ; FORCE AN ERROR
U 0E89, 6588,15 ;15513          CLR LS[ADDRESS.DATA]                    ;CLR FOR PRINTOUT
U 0E8A, 0869,3C ;15514          JSR [CHECK.RESULT]
U 0E8B, 08E7,D4 ;15515          JMP [LOOP.T16.2]                        ;LOOP HERE IF ERR & LOE IS SET
U 0E8C, 88E9,74 ;15516          JMP [CLEANUP.T16.1]                     ; ELSE END TEST
                ;15517
                ;15518
                ;15519  ERROR.T16.1:                                    ;OVFLW L DID NOT ASSERT
U 0E8D, 3640,95 ;15520          MOV LS[#1] TO WR[1]                     ;FORCE AN ERROR
U 0E8E, 2F80,15 ;15521          CLR WR[0]
U 0E8F, BE89,95 ;15522          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U 0E90, 0869,3C ;15523          JSR [CHECK.RESULT]
U 0E91, 88E4,64 ;15524          JMP [LOOP.T16.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;15525                                                  ;ELSE SKIP OTHER ERRORS AND END
                ;15526  CALL.CH.RESULT.T16.1:
                ;15527
U 0E92, 2F80,15 ;15528          CLR WR[0]                               ;CALL CHECK.RESULT TO LOCK
U 0E93, 2F82,95 ;15529          CLR WR[1]                               ; IN INTERMITTENT ERRORS
U 0E94, 6588,15 ;15530          CLR LS[ADDRESS.DATA]
U 0E95, 0869,3C ;15531          JSR [CHECK.RESULT]
U 0E96, 08E7,D4 ;15532          JMP [LOOP.T16.2]
                ;15533                                                  ; TEST
                ;15534  CLEANUP.T16.1:
U 0E97, 8875,3C ;15535          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;15536                                                  ; THIS TEST
                ;15537  END.T16:                                       ;END TEST
```

```
                ;15538
                ;15539
                ;15540
```

```
;15541  .PAGE  "Test 17  LOOP COUNTER TEST (M8388 IDC MODULE)"
;15542  ;++
;15543  ;
;15544  ; Test Description:
;15545  ;
;15546  ;       This test is designed to test the loop counter and the associated
;15547  ;       BEN0/CNTR OVFLW branch condition. The loop counter will be loaded with
;15548  ;       FF, which will assert CNTR OVFLW H. BEN0/CNTR OVFLW H will be
;15549  ;       selected and if the microcode branches correctly, the DAR will be
;15550  ;       incremented.
;15551  ;       The loop counter will then be loaded with a zero. The IDC microcode
;15552  ;       will then execute an instruction which will select BEN0/CNTR OVFLW H
;15553  ;       and will increment the loop counter. When CNTR OVFLW asserts, the
;15554  ;       microcode will branch to an instruction that will increment the DAR.
;15555  ;       The CPU will read the DAR after every increment of the Loop Counter to
;15556  ;       insure that the CNTR OVFLW asserts only at FF.
;15557  ;
;15558  ; Assumptions:
;15559  ;
;15560  ;       It is assumed that the UINCR.DAR function works correctly.
;15561  ;
;15562  ; Test Steps:
;15563  ;
;15564  ;       1. Set up error mask, error number and module number in LS
;15565  ;          (for error printouts) and clear the previous error number in LS.
;15566  ;       2. Force the IDC microcode to DIAG.IDLE.
;15567  ;       3. Clear the DAR and set WR[2] = FF to indicate Loop count.
;15568  ;       4. Set up the CSR to branch to correct microcode routine.
;15569  ;
;15570  ;
;15571  ;                                       *******
;15572  ;                                       * IDC *
;15573  ;                                       *******
;15574  ;
;15575  ;               IDC1. Load the loop counter with a constant of FF.
;15576  ;
;15577  ;       5. Wait for a XFER.REQ from IDC.
;15578  ;       6. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;15579  ;       7. Set up the CSR to branch to correct microcode routine.
;15580  ;
;15581  ;
;15582  ;                                       *******
;15583  ;                                       * IDC *
;15584  ;                                       *******
;15585  ;
;15586  ;               IDC2. Increment the loop counter.
;15587  ;               IDC3. Select BEN0/CNTR OVFLW H.
;15588  ;               IDC4. If CNTR OVFLW H is asserted, then increment the DAR.
;15589  ;               IDC5. Issue XFER REQ to flag the CPU.
;15590  ;
;15591  ;       8. Wait for a XFER.REQ from IDC.
;15592  ;       9. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;15593  ;      10. Check the DAR = 1.
;15594  ;      11. Increment the error number.
;15595  ;      12. Clear WR[2] to use as a counter.
```

```
;15596  ;       13. Clear the DAR.
;15597  ;       14. Set up the CSR to branch to the correct microcode routine.
;15598  ;
;15599  ;                                       *******
;15600  ;                                       * IDC *
;15601  ;                                       *******
;15602  ;
;15603  ;               IDC6. Load the loop counter with a constant of zero.
;15604  ;               IDC7. Send XFER REQ and go to DIAG.WAIT.
;15605  ;
;15606  ;       15. Wait for a XFER REQ from IDC.
;15607  ;       16. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;15608  ;       17. Set up the CSR to branch to the correct microcode routine.
;15609  ;
;15610  ;                                       *******
;15611  ;                                       * IDC *
;15612  ;                                       *******
;15613  ;
;15614  ;
;15615  ;               IDC8. Increment the LOOP COUNTER.
;15616  ;               IDC9. Select BEN0/CNTR OVFLW H.
;15617  ;               IDC10. If CNTR OVFLW H is asserted then increment the DAR.
;15618  ;               IDC11. Issue XFER REQ and go to DIAG.WAIT.
;15619  ;
;15620  ;
;15621  ;       18. Wait for a XFER.REQ from the IDC.
;15622  ;       19. Clear CSR F<2:0> and issue XFER GRANT to clear the XFER.REQ.
;15623  ;       20. Check DAR = 0.
;15624  ;       21. Clear the DAR.
;15625  ;       22. Add 1 to WR[2].
;15626  ;       23. While WR[2] < FF, perform Steps 17 - 23.
;15627  ;       24. Increment the error number.
;15628  ;       25. Perform Steps 14 - 16.
;15629  ;       26. Check the DAR = 1. (LOOP COUNTER should overflow at FF + 1)
;15630  ;       27. Clear IDC.
;15631  ;       28. End test.
;15632  ;
;15633  ; Errors:
;15634  ;
;15635  ;                       Printout:
;15636  ;                               EXPECTED        RECEIVED        OTHER DATA
;15637  ;                                 DAR             DAR             WR[2]
;15638  ;                                                                 LOOP COUNT
;15639  ;
;15640  ;       ERROR 1 - The Loop Counter did not overflow when loaded with FF and
;15641  ;                 incremented once.
;15642  ;
;15643  ;       ERROR 2 - The Loop Counter overflowed too soon.
;15644  ;
;15645  ;       ERROR 3 - The Loop Counter did not overflow when incremented to FF + 1.
;15646  ;
;15647  ; Debug:
;15648  ;
;15649  ;  ERROR 1:
;15650  ;
```

```
                ;15651  ;       The microcode will execute an a LOAD.LOOP.CNTR.[OFF] instruction
                ;15652  ;       which will assert ULOAD LPCNTR L. The loop counter is loaded with
                ;15653  ;       the constant of FF which comes from the microword bits
                ;15654  ;       <63:56>. This will assert CNTR OVFLW H.
                ;15655  ;       When the BEN0/CNTR OVFLW H IDC microinstruction is executed:
                ;15656  ;               BEN0 S0 H = L
                ;15657  ;               BEN0 S1 H = H
                ;15658  ;               BEN0 S2 H = L
                ;15659  ;
                ;15660  ;       This will select CNTR OVFLW H as NUA 0 H. CNTR OVFLW H will be asserted
                ;15661  ;       so the IDC microcode will branch to an instruction that will
                ;15662  ;       increment the DAR.
                ;15663  ;
                ;15664  ;  ERROR 2:
                ;15665  ;
                ;15666  ;       The microcode will execute an a LOAD.LOOP.CNTR.[00] instruction
                ;15667  ;       which will assert ULOAD LPCNTR L. The loop counter is loaded with
                ;15668  ;       the constant of 00 which comes from the microword bits
                ;15669  ;       <63:56>.
                ;15670  ;       When BEN0/CNTR OVFLW H IDC microinstruction is executed:
                ;15671  ;               BEN0 S0 H = L
                ;15672  ;               BEN0 S1 H = H
                ;15673  ;               BEN0 S2 H = L
                ;15674  ;
                ;15675  ;       This will select CNTR OVFLW H as NUA 0 H. CNTR OVFLW H will not
                ;15676  ;       be asserted so the IDC microcode will branch to an instruction
                ;15677  ;       that will send XFER REQ without incrementing the DAR.
                ;15678  ;
                ;15679  ;  ERROR 3:
                ;15680  ;
                ;15681  ;       When the Loop Counter is incremented to FF + 1, CNTR OVFLW H will
                ;15682  ;       assert. BEN0/CNTR OVFLW will be selected. The microcode will branch
                ;15683  ;       to an instruction which will increment the DAR and then issue
                ;15684  ;       XFER.REQ.
                ;15685  ;--
                ;15686  ;*************************************************************************
                ;15687  T.17:
U 0E98, B65E,15 ;15688          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;15689                                                  ; CONTROL AND STATUS WORD
U 0E99, 3E80,15 ;15690          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;15691                                                  ; STATUS WORD - BIT 15
                ;15692                                                  ; INDICATES START OF TEST TO
                ;15693                                                  ; CONSOLE
U 0E9A, 10E0,15 ;15694          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;15695  WAIT.T17.0:
U 0E9B, 88E9,B4 ;15696          JMP [WAIT.T17.0]                        ;LOOP HERE WAITING FOR
                ;15697                                                  ; CONSOLE TO RESPOND
                ;15698
U 0E9C, 65A0,15 ;15699          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;15700                                                  ; IN LS
                ;15701
U 0E9D, B64A,15 ;15702          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0E9E, 3E8C,15 ;15703          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;15704
U 0E9F, B670,15 ;15705          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP THE PRINT OTHER DATA
```

```
U 0EA0, 3E80,15 ;15706          MOV WR[0] TO LS[CONTROL.STATUS]          ; IF ERROR
                ;15707
U 0EA1, B640,15 ;15708          MOV LS[#1] TO WR[0]                      ;SET WR0 = 1
U 0EA2, BE82,15 ;15709          MOV WR[0] TO LS[ERROR.NUMBER]            ;SET UP ERROR NUMBER = 1 IN LS
                ;15710
U 0EA3, 3776,15 ;15711          MOV LS[DAR.MASK] TO WR[0]                ;SET UP THE MASK FOR THE DAR
U 0EA4, 3E8A,15 ;15712          MOV WR[0] TO LS[ERROR.MASK]
                ;15713
U 0EA5, 8872,EC ;15714          JSR [DIAG.CODE]                          ;FORCE THE IDC TO DIAG.IDLE
                ;15715
U 0EA6, 3627,15 ;15716          MOV LS[#FF] TO WR[2]                     ;LOOP COUNT
                ;15717
                ;15718  LOOP.T17.1:
U 0EA7, 2F80,15 ;15719          CLR WR[0]                                ;WR[0] = 0
U 0EA8, 97A4,15 ;15720          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]     ;CLEAR THE DAR
                ;15721
U 0EA9, B720,95 ;15722          MOV LS[SETCSR.MAINT] TO WR[1]            ; THE CORRECT IDC ROUTINE
U 0EAA, 370E,15 ;15723          MOV LS[SETCSR.F7] TO WR[0]
U 0EAB, AEC2,15 ;15724          BIS WR[1] TO WR[0]
U 0EAC, 17A0,15 ;15725          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;15726                                                   ;MAINT=1,CRDY=0,F<2:0>=111
                ;15727  ;LOAD LPCNTR = FF
                ;15728  ;-------------------------------------------------------------------------
                ;15729  ;-------------------------------------------------------------------------
                ;15730  ;                              *******
                ;15731  ;                              * IDC *
                ;15732  ;                              *******
                ;15733  ;-------------------------------------------------------------------------
                ;15734  ;018:
                ;15735  ;=000
                ;15736  ;DIAG.IDLE:
                ;15737  ;
                ;15738  ;       BEN0/F0,
                ;15739  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;15740  ;       BEN2/F2,
                ;15741  ;       NAD/DIAG.IDLE
                ;15742  ;-------------------------------------------------------------------------
                ;15743  ;01F:
                ;15744  ;=111
                ;15745  ;
                ;15746  ;       BEN0/CRDY.L,
                ;15747  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15748  ;       NAD/TEST.FUNC7           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15749  ;-------------------------------------------------------------------------
                ;15750  ;07D:
                ;15751  ;=1*1
                ;15752  ;TEST.F7:
                ;15753  ;
                ;15754  ;       FUNC/SET.ONLINE,                 ;SET ONLINE THE DRIVE SELECTED BY
                ;15755  ;                                        ; DRIVE SEL <1:0> (FOR ONLINE TESTS)
                ;15756  ;
                ;15757  ;       LOAD.LOOP.CNTR.[OFF],            ;LOAD LOOP CNTR = FF (FOR LP CNTR TST)
                ;15758  ;
                ;15759  ;       NAD/XFER.REQ                     ;DO NOT INCR DAR BETWEEN HERE
                ;15760  ;                                        ; AND DIAG.IDLE
```

```
                ;15761  ;-----------------------------------------------------------------------
                ;15762  ;1D8:
                ;15763  ;XFER.REQ:
                ;15764  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;15765  ;       NAD/DIAG.WAIT
                ;15766  ;-----------------------------------------------------------------------
                ;15767  ;1D7:
                ;15768  ;DIAG.WAIT:
                ;15769  ;
                ;15770  ;       BEN"/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;15771  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;15772  ;-----------------------------------------------------------------------
                ;15773  ;159:
                ;15774  ;=*0*
                ;15775  ;DIAG.WAIT1:
                ;15776  ;
                ;15777  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;15778  ;                               ; COMMAND FROM THE CPU
                ;15779  ;-----------------------------------------------------------------------
                ;15780  ;15B:
                ;15781  ;=*1*
                ;15782  ;DIAG.WAIT2:
                ;15783  ;
                ;15784  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;15785  ;                               ; WAIT SOME MORE
                ;15786  ;-----------------------------------------------------------------------
                ;15787  WAIT.IDC.T17.1:
U 0EAD, DB00,1A ;15788          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0EAE, 88EB,04 ;15789          JMP [IDC.DONE.T17.1]                    ;IDC DONE
U 0EAF, 88EA,D4 ;15790          JMP [WAIT.IDC.T17.1]                    ;WAIT SOME MORE
                ;15791
                ;15792  IDC.DONE.T17.1:
U 0EB0, B700,15 ;15793          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 0EB1, 17A0,15 ;15794          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0EB2, 90FA,15 ;15795          MISC2 [TRANSFER.GRANT]                  ;SEND XFER GRANT TO CLR REQ
                ;15796
U 0EB3, 2045,15 ;15797          INC WR[2]                               ;INCREMENT THE TEST LP CNTR
                ;15798
U 0EB4, 3712,95 ;15799          MOV LS[SETCSR.CRDY] TO WR[1]
U 0EB5, 3708,15 ;15800          MOV LS[SETCSR.F4] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 0EB6, AEC2,15 ;15801          BIS WR[1] TO WR[0]                      ; THE CORRECT ROUTINE
U 0EB7, 17A0,15 ;15802          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
                ;15803                                                  ;MAINT=0,CRDY=1,F<2:0>=100
                ;15804  ;INCR THE LOOP CNTR
                ;15805  ;-----------------------------------------------------------------------
                ;15806  ;-----------------------------------------------------------------------
                ;15807  ;                               *******
                ;15808  ;                               * IDC *
                ;15809  ;                               *******
                ;15810  ;-----------------------------------------------------------------------
                ;15811  ;018:
                ;15812  ;=000
                ;15813  ;DIAG.IDLE:
                ;15814  ;
                ;15815  ;       BEN0/F0,
```

```
;15816  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;15817  ;       BEN2/F2,
;15818  ;       NAD/DIAG.IDLE
;15819  ;-------------------------------------------------------------------------
;15820  ;01C:
;15821  ;=100
;15822  ;
;15823  ;       BEN0/CRDY.L,
;15824  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;15825  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;15826  ;-------------------------------------------------------------------------
;15827  ;06A:
;15828  ;=0*0
;15829  ;TEST.FUNC4:
;15830  ;
;15831  ;TEST.INCR.LPCNTR:
;15832  ;
;15833  ;       INCR.LPCNTR/ON,                 ;INCREMENT THE LOOP CNTR
;15834  ;       BEN0/CNTR.OVFLW,                ;DID LOOP CNTR OVFLW?
;15835  ;       NAD/BEN0.1
;15836  ;-------------------------------------------------------------------------
;15837  ;18A:
;15838  ;=0
;15839  ;BEN0.1:
;15840  ;
;15841  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 IS NOT ASSERTED
;15842  ;                                       ; FLAG THE CPU
;15843  ;-------------------------------------------------------------------------
;15844  ;18B:
;15845  ;=1
;15846  ;BEN0.2:
;15847  ;
;15848  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
;15849  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 WAS ASSERTED
;15850  ;                                       ; FLAG THE CPU
;15851  ;-------------------------------------------------------------------------
;15852  ;1D8:
;15853  ;XFER.REQ:
;15854  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;15855  ;       NAD/DIAG.WAIT
;15856  ;-------------------------------------------------------------------------
;15857  ;1D7:
;15858  ;DIAG.WAIT:
;15859  ;
;15860  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;15861  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;15862  ;-------------------------------------------------------------------------
;15863  ;159:
;15864  ;=*0*
;15865  ;DIAG.WAIT1:
;15866  ;
;15867  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;15868  ;                               ; COMMAND FROM THE CPU
;15869  ;-------------------------------------------------------------------------
;15870  ;15B:
```

```
                ;15871  ;=*1*
                ;15872  ;DIAG.WAIT2:
                ;15873  ;
                ;15874  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;15875  ;                               ; WAIT SOME MORE
                ;15876  ;-------------------------------------------------------------------------
                ;15877  WAIT.IDC.T17.2:
U 0EB8, DB00,1A ;15878          SKIP.IF[NO.FAST.INTERRUPT]                      ;WAIT FOR THE IDC
U 0EB9, 08EB,B4 ;15879          JMP [IDC.DONE.T17.2]                            ;IDC DONE
U 0EBA, 08EB,84 ;15880          JMP [WAIT.IDC.T17.2]                            ;WAIT SOME MORE
                ;15881
                ;15882  IDC.DONE.T17.2:
U 0EBB, B700,15 ;15883          MOV LS[SETCSR.F0] TO WR[0]                      ;CLEAR THE FUNCTION BITS
U 0EBC, 17A0,15 ;15884          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]            ;WRITE THE CSR
U 0EBD, 90FA,15 ;15885          MISC2 [TRANSFER.GRANT]                          ;SEND XFER GRANT TO CLR REQ
                ;15886
                ;15887
                ;15888  READ.DAR.T17.1:
U 0EBE, 9090,15 ;15889          MISC [SET.PORT.I.O]                             ;SELECT THE IDC
U 0EBF, 1784,15 ;15890          PORT.READ PORT.ADRS[DAR]                        ;SET UP TO READ THE DAR
U 0EC0, 3B32,15 ;15891          MOV PORT TO LS[PORT0]                           ;READ THE DATA FROM DAR AND
                ;15892                                                          ; SAVE IT IN LS
U 0EC1, 3732,15 ;15893          MOV LS[PORT0] TO WR[0]                          ;SET UP RECEIVED DATA
U 0EC2, 3640,95 ;15894          MOV LS[#1] TO WR[1]                             ;SET UP EXPECTED DATA
U 0EC3, 3E89,15 ;15895          MOV WR[2] TO LS[ADDRESS.DATA]                   ;SET UP TO PRINT OTHER DATA
U 0EC4, 0869,3C ;15896          JSR [CHECK.RESULT]                              ;CHECK THE DATA
U 0EC5, 88EA,74 ;15897          JMP [LOOP.T17.1]                                ;LOOP HERE IF ERR & LOE IS SET
U 0EC6, FF82,15 ;15898          INC LS[ERROR.NUMBER]                            ;SET UP FOR NEXT ERROR
                ;15899
U 0EC7, 2F85,15 ;15900          CLR WR[2]                                       ;USE AS A COUNTER
                ;15901
U 0EC8, 2F80,15 ;15902          CLR WR[0]                                       ;WR[0] = 0
U 0EC9, 97A4,15 ;15903          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]            ;CLR THE DAR
U 0ECA, B720,95 ;15904          MOV LS[SETCSR.MAINT] TO WR[1]                   ;SET UP THE CSR TO BRANCH TO
U 0ECB, B70C,15 ;15905          MOV LS[SETCSR.F6] TO WR[0]                      ; THE CORRECT IDC ROUTINE
U 0ECC, AEC2,15 ;15906          BIS WR[1] TO WR[0]                              ; THAT WILL LOAD LP CNTR = 0
U 0ECD, 17A0,15 ;15907          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]            ;WRITE THE CSR
                ;15908                                                          ;MAINT=1,CRDY=0,F<2:0>=110
                ;15909  ;LOAD THE LOOP CNTR = 00
                ;15910  ;-------------------------------------------------------------------------
                ;15911  ;-------------------------------------------------------------------------
                ;15912  ;                               *******
                ;15913  ;                               * IDC *
                ;15914  ;                               *******
                ;15915  ;-------------------------------------------------------------------------
                ;15916  ;018:
                ;15917  ;=000
                ;15918  ;DIAG.IDLE:
                ;15919  ;
                ;15920  ;       BEN0/F0,
                ;15921  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;15922  ;       BEN2/F2,
                ;15923  ;       NAD/DIAG.IDLE
                ;15924  ;-------------------------------------------------------------------------
                ;15925  ;01E:
```

```
                ;15926  ;=110
                ;15927  ;
                ;15928  ;       BEN0/CRDY.L,
                ;15929  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;15930  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;15931  ;-------------------------------------------------------------------------
                ;15932  ;077:
                ;15933  ;=1*1
                ;15934  ;TEST.F6:
                ;15935  ;                               ;DO NOT INCR DAR BETWEEN HERE AND
                ;15936  ;                               ; DIAG.IDLE OR DIAG.WAIT
                ;15937  ;
                ;15938  ;       LOAD.LOOP.CNTR.[00],    ;LOAD LOOP CNTR WITH 00
                ;15939  ;
                ;15940  ;       UCMD/SET.DLT,           ;SET DLT FOR DLT TEST
                ;15941  ;
                ;15942  ;       FUNC/SET.INT,           ;SET INT FOR INTERRUPT TEST
                ;15943  ;
                ;15944  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
                ;15945  ;-------------------------------------------------------------------------
                ;15946  ;1D8:
                ;15947  ;XFER.REQ:
                ;15948  ;       UCMD/SET.XFER.RQST,     ;SEND XFER REQ TO THE CPU
                ;15949  ;       NAD/DIAG.WAIT
                ;15950  ;-------------------------------------------------------------------------
                ;15951  ;1D7:
                ;15952  ;DIAG.WAIT:
                ;15953  ;
                ;15954  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;15955  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;15956  ;-------------------------------------------------------------------------
                ;15957  ;159:
                ;15958  ;=*0*
                ;15959  ;DIAG.WAIT1:
                ;15960  ;
                ;15961  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;15962  ;                               ; COMMAND FROM THE CPU
                ;15963  ;-------------------------------------------------------------------------
                ;15964  ;15B:
                ;15965  ;=*1*
                ;15966  ;DIAG.WAIT2:
                ;15967  ;
                ;15968  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;15969  ;                               ; WAIT SOME MORE
                ;15970  ;-------------------------------------------------------------------------
                ;15971  WAIT.IDC.T17.3:
U 0ECE, DB00,1A ;15972          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0ECF, 08ED,14 ;15973          JMP [IDC.DONE.T17.3]                    ;IDC DONE
U 0ED0, 88EC,E4 ;15974          JMP [WAIT.IDC.T17.3]                    ;WAIT SOME MORE
                ;15975
                ;15976  IDC.DONE.T17.3:
U 0ED1, 2F87,95 ;15977          CLR WR[3]                               ;SET THE EXPECTED DATA
                ;15978  INCR.CNTR.T17:
U 0ED2, B700,15 ;15979          MOV LS[SETCSR.F0] TO WR[0]              ;CLR THE FUNCTION BITS
U 0ED3, 17A0,15 ;15980          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
```

```
U 0ED4, 90FA,15 ;15981          MISC2 [TRANSFER.GRANT]                    ;SEND GRANT TO CLR XFER REQ
                ;15982
U 0ED5, 3712,95 ;15983          MOV LS[SETCSR.CRDY] TO WR[1]
U 0ED6, 3708,15 ;15984          MOV LS[SETCSR.F4] TO WR[0]                ;SET UP THE CSR TO BRANCH TO
U 0ED7, AEC2,15 ;15985          BIS WR[1] TO WR[0]                        ; THE CORRECT IDC ROUTINE
U 0ED8, 17A0,15 ;15986          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRTIE THE CSR
                ;15987                                                    ;MAINT=0,CRDY=1,F<2:0>=100
                ;15988  ;INCR THE LOOP CNTR
                ;15989  ;-------------------------------------------------------------------------
                ;15990  ;-------------------------------------------------------------------------
                ;15991  ;                               *******
                ;15992  ;                               * IDC *
                ;15993  ;                               *******
                ;15994  ;-------------------------------------------------------------------------
                ;15995  ;018:
                ;15996  ;=000
                ;15997  ;DIAG.IDLE:
                ;15998  ;
                ;15999  ;       BEN0/F0,
                ;16000  ;       BEN1/F1,                  ;BRANCH ON THE CSR F<2:0> BITS
                ;16001  ;       BEN2/F2,
                ;16002  ;       NAD/DIAG.IDLE
                ;16003  ;-------------------------------------------------------------------------
                ;16004  ;01C:
                ;16005  ;=100
                ;16006  ;
                ;16007  ;       BEN0/CRDY.L,
                ;16008  ;       BEN2/MAINT,               ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;16009  ;       NAD/TEST.FUNC4            ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;16010  ;-------------------------------------------------------------------------
                ;16011  ;06A:
                ;16012  ;=0*0
                ;16013  ;TEST.FUNC4:
                ;16014  ;
                ;16015  ;TEST.INCR.LPCNTR:
                ;16016  ;
                ;16017  ;       INCR.LPCNTR/ON,           ;INCREMENT THE LOOP CNTR
                ;16018  ;       BEN0/CNTR.OVFLW,          ;DID LOOP CNTR OVFLW?
                ;16019  ;       NAD/BEN0.1
                ;16020  ;-------------------------------------------------------------------------
                ;16021  ;18A:
                ;16022  ;=0
                ;16023  ;BEN0.1:
                ;16024  ;
                ;16025  ;       NAD/XFER.REQ              ;SELECTED BRANCH 0 IS NOT ASSERTED
                ;16026  ;                                 ; FLAG THE CPU
                ;16027  ;-------------------------------------------------------------------------
                ;16028  ;18B:
                ;16029  ;=1
                ;16030  ;BEN0.2:
                ;16031  ;
                ;16032  ;       INCR.DAR/ON,              ;INCREMENT THE DAR
                ;16033  ;       NAD/XFER.REQ              ;SELECTED BRANCH 0 WAS ASSERTED
                ;16034  ;                                 ; FLAG THE CPU
                ;16035  ;-------------------------------------------------------------------------
```

```
                ;16036  ;1D8:
                ;16037  ;XFER.REQ:
                ;16038  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;16039  ;       NAD/DIAG.WAIT
                ;16040  ;-------------------------------------------------------------------------
                ;16041  ;1D7:
                ;16042  ;DIAG.WAIT:
                ;16043  ;
                ;16044  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;16045  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;16046  ;-------------------------------------------------------------------------
                ;16047  ;159:
                ;16048  ;=*0*
                ;16049  ;DIAG.WAIT1:
                ;16050  ;
                ;16051  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;16052  ;                               ; COMMAND FROM THE CPU
                ;16053  ;-------------------------------------------------------------------------
                ;16054  ;15B:
                ;16055  ;=*1*
                ;16056  ;DIAG.WAIT2:
                ;16057  ;
                ;16058  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;16059  ;                               ; WAIT SOME MORE
                ;16060  ;-------------------------------------------------------------------------
                ;16061  WAIT.IDC.T17.4:
U 0ED9, DB00,1A ;16062          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0EDA, 88ED,C4 ;16063          JMP [IDC.DONE.T17.4]                    ;IDC DONE
U 0EDB, 88ED,94 ;16064          JMP [WAIT.IDC.T17.4]                    ;WAIT SOME MORE
                ;16065
                ;16066  IDC.DONE.T17.4:
U 0EDC, B700,15 ;16067          MOV LS[SETCSR.F0] TO WR[0]              ;CLR THE FUNCTION BITS
U 0EDD, 17A0,15 ;16068          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0EDE, 90FA,15 ;16069          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;16070
                ;16071  READ.DAR.T17.2:
U 0EDF, 9090,15 ;16072          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0EE0, 1784,15 ;16073          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0EE1, 3B32,15 ;16074          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;16075                                                  ; SAVE IT IN LS
U 0EE2, 3732,15 ;16076          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0EE3, 2006,95 ;16077          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
U 0EE4, 3E89,15 ;16078          MOV WR[2] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U 0EE5, 0869,3C ;16079          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0EE6, 88EF,24 ;16080          JMP [LOOP.T17.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;16081
U 0EE7, 2F80,15 ;16082          CLR WR[0]                               ;WR[0] = 0
U 0EE8, 97A4,15 ;16083          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
U 0EE9, 2045,15 ;16084          INC WR[2]                               ;INCR THE CPU LOOP CNTR
                ;16085          CMP WR[3] WITH LS[#1],
U 0EEA, CF41,B5 ;16086           DT(LONG)&SET.ALU.CC                    ;TEST DONE?
U 0EEB, 88F1,C9 ;16087          JMP.IF[EQL] TO [CLEANUP.T17.1]          ;JMP IF DONE
                ;16088
                ;16089          CMP WR[2] WITH LS[#FF],
U 0EEC, 4F27,35 ;16090           DT(LONG)&SET.ALU.CC                    ;LAST COUNT BEFORE OVFLW ?
```

```
U 0EED, 08ED,21 ;16091          JMP.IF[NEQ] TO [INCR.CNTR.T17]          ;NOT LAST COUNT
                ;16092
U 0EEE, FF82,15 ;16093          INC LS[ERROR.NUMBER]                    ;SET UP FOR NEXT ERROR
U 0EEF, 2045,15 ;16094          INC WR[2]                               ;INCR THE TEST COUNTER
U 0EF0, B641,95 ;16095          MOV LS[#1] TO WR[3]                     ;SET UP THE EXPECTED DATA
U 0EF1, 08ED,24 ;16096          JMP [INCR.CNTR.T17]                     ;CHECK CNTR OVFLW
                ;16097
                ;16098  LOOP.T17.2:
                ;16099
U 0EF2, 2F85,15 ;16100          CLR WR[2]                               ;CLR THE TEST COUNTER
U 0EF3, 2F80,15 ;16101          CLR WR[0]                               ;WR[0] = 0
U 0EF4, 97A4,15 ;16102          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;16103
U 0EF5, B720,95 ;16104          MOV LS[SETCSR.MAINT] TO WR[1]           ;SET UP THE CSR TO BRANCH TO
U 0EF6, B70C,15 ;16105          MOV LS[SETCSR.F6] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 0EF7, AEC2,15 ;16106          BIS WR[1] TO WR[0]                      ; THAT WILL LOAD LP CNTR = 0
U 0EF8, 17A0,15 ;16107          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;16108                                                  ;MAINT=1,CRDY=0,F<2:0>=110
                ;16109
                ;16110  ;LOAD THE LOOP CNTR = 00
                ;16111  ;-------------------------------------------------------------------------------
                ;16112  ;-------------------------------------------------------------------------------
                ;16113  ;                                *******
                ;16114  ;                                * IDC *
                ;16115  ;                                *******
                ;16116  ;-------------------------------------------------------------------------
                ;16117  ;018:
                ;16118  ;=000
                ;16119  ;DIAG.IDLE:
                ;16120  ;
                ;16121  ;       BEN0/F0,
                ;16122  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;16123  ;       BEN2/F2,
                ;16124  ;       NAD/DIAG.IDLE
                ;16125  ;-------------------------------------------------------------------
                ;16126  ;01E:
                ;16127  ;=110
                ;16128  ;
                ;16129  ;       BEN0/CRDY.L,
                ;16130  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;16131  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;16132  ;-------------------------------------------------------------------
                ;16133  ;077:
                ;16134  ;=1*1
                ;16135  ;TEST.F6:
                ;16136  ;                                       ;DO NOT INCR DAR BETWEEN HERE AND
                ;16137  ;                                       ; DIAG.IDLE OR DIAG.WAIT
                ;16138  ;
                ;16139  ;       LOAD.LOOP.CNTR.[00],            ;LOAD LOOP CNTR WITH 00
                ;16140  ;
                ;16141  ;       UCMD/SET.DLT,                   ;SET DLT FOR DLT TEST
                ;16142  ;
                ;16143  ;       FUNC/SET.INT,                   ;SET INT FOR INTERRUPT TEST
                ;16144  ;
                ;16145  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
```

```
                ;16146  ;-------------------------------------------------------------------------
                ;16147  ;1D8:
                ;16148  ;XFER.REQ:
                ;16149  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;16150  ;       NAD/DIAG.WAIT
                ;16151  ;-------------------------------------------------------------------------
                ;16152  ;1D7:
                ;16153  ;DIAG.WAIT:
                ;16154  ;
                ;16155  ;       BEN'/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;16156  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;16157  ;-------------------------------------------------------------------------
                ;16158  ;159:
                ;16159  ;=*0*
                ;16160  ;DIAG.WAIT1:
                ;16161  ;
                ;16162  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;16163  ;                               ; COMMAND FROM THE CPU
                ;16164  ;-------------------------------------------------------------------------
                ;16165  ;15B:
                ;16166  ;=*1*
                ;16167  ;DIAG.WAIT2:
                ;16168  ;
                ;16169  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;16170  ;                               ; WAIT SOME MORE
                ;16171  ;-------------------------------------------------------------------------
                ;16172  WAIT.IDC.T17.5:
U 0EF9, DB00,1A ;16173          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0EFA, 08EF,C4 ;16174          JMP [IDC.DONE.T17.5]                    ;IDC DONE
U 0EFB, 08EF,94 ;16175          JMP [WAIT.IDC.T17.5]                    ;WAIT SOME MORE
                ;16176
                ;16177  IDC.DONE.T17.5:
U 0EFC, B700,15 ;16178          MOV LS[SETCSR.F0] TO WR[0]              ;CLR THE FUNCTION BITS
U 0EFD, 17A0,15 ;16179          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0EFE, 90FA,15 ;16180          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;16181
                ;16182  ERR.INCR.LPCNTR.T17:
U 0EFF, 3712,95 ;16183          MOV LS[SETCSR.CRDY] TO WR[1]
U 0F00, 3708,15 ;16184          MOV LS[SETCSR.F4] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 0F01, AEC2,15 ;16185          BIS WR[1] TO WR[0]                      ; THE CORRECT IDC ROUTINE
U 0F02, 17A0,15 ;16186          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRTIE THE CSR
                ;16187                                                  ;MAINT=0,CRDY=1,F<2:0>=100
                ;16188  ;INCR THE LOOP CNTR
                ;16189  ;-------------------------------------------------------------------------
                ;16190  ;-------------------------------------------------------------------------
                ;16191  ;                               *******
                ;16192  ;                               * IDC *
                ;16193  ;                               *******
                ;16194  ;-------------------------------------------------------------------------
                ;16195  ;018:
                ;16196  ;=000
                ;16197  ;DIAG.IDLE:
                ;16198  ;
                ;16199  ;       BEN0/F0,
                ;16200  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
```

```
;16201  ;       BEN2/F2,
;16202  ;       NAD/DIAG.IDLE
;16203  ;-------------------------------------------------------------------------
;16204  ;01C:
;16205  ;=100
;16206  ;
;16207  ;       BEN0/CRDY.L,
;16208  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;16209  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;16210  ;-------------------------------------------------------------------------
;16211  ;06A:
;16212  ;=0*0
;16213  ;TEST.FUNC4:
;16214  ;
;16215  ;TEST.INCR.LPCNTR:
;16216  ;
;16217  ;       INCR.LPCNTR/ON,                 ;INCREMENT THE LOOP CNTR
;16218  ;       BEN0/CNTR.OVFLW,                ;DID LOOP CNTR OVFLW?
;16219  ;       NAD/BEN0.1
;16220  ;-------------------------------------------------------------------------
;16221  ;18A:
;16222  ;=0
;16223  ;BEN0.1:
;16224  ;
;16225  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 IS NOT ASSERTED
;16226  ;                                       ; FLAG THE CPU
;16227  ;-------------------------------------------------------------------------
;16228  ;18B:
;16229  ;=1
;16230  ;BEN0.2:
;16231  ;
;16232  ;       INCR.DAR/ON,                    ;INCREMENT THE DAR
;16233  ;       NAD/XFER.REQ                    ;SELECTED BRANCH 0 WAS ASSERTED
;16234  ;                                       ; FLAG THE CPU
;16235  ;-------------------------------------------------------------------------
;16236  ;1D8:
;16237  ;XFER.REQ:
;16238  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;16239  ;       NAD/DIAG.WAIT
;16240  ;-------------------------------------------------------------------------
;16241  ;1D7:
;16242  ;DIAG.WAIT:
;16243  ;
;16244  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;16245  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;16246  ;-------------------------------------------------------------------------
;16247  ;159:
;16248  ;=*0*
;16249  ;DIAG.WAIT1:
;16250  ;
;16251  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;16252  ;                               ; COMMAND FROM THE CPU
;16253  ;-------------------------------------------------------------------------
;16254  ;15B:
;16255  ;=*1*
```

```
                    ;16256  ;DIAG.WAIT2:
                    ;16257  ;
                    ;16258  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;16259  ;                               ; WAIT SOME MORE
                    ;16260  ;-------------------------------------------------------------------
                    ;16261  WAIT.IDC.T17.6:
U 0F03, DB00,1A     ;16262          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0F04, 88F0,64     ;16263          JMP [IDC.DONE.T17.6]                    ;IDC DONE
U 0F05, 88F0,34     ;16264          JMP [WAIT.IDC.T17.6]                    ;WAIT SOME MORE
                    ;16265
                    ;16266  IDC.DONE.T17.6:
U 0F06, B700,15     ;16267          MOV LS[SETCSR.F0] TO WR[0]              ;CLR THE FUNCTION BITS
U 0F07, 17A0,15     ;16268          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0F08, 90FA,15     ;16269          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                    ;16270
U 0F09, 9090,15     ;16271          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0F0A, 1784,15     ;16272          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0F0B, 3B32,15     ;16273          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;16274                                                  ; SAVE IT IN LS
U 0F0C, 3732,15     ;16275          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0F0D, 2006,95     ;16276          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
U 0F0E, 3E89,15     ;16277          MOV WR[2] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA..LOOP CNT
U 0F0F, 0869,3C     ;16278          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0F10, 88F1,24     ;16279          JMP [ERROR.T17.2]                       ;LOOP HERE IF ERR & LOE IS SET
U 0F11, 08F1,C4     ;16280          JMP [CLEANUP.T17.1]                     ;IF CL LOOP...END TEST
                    ;16281
                    ;16282  ERROR.T17.2:
U 0F12, 2045,15     ;16283          INC WR[2]                               ;INC THE TEST COUNTER
                    ;16284
                    ;16285          CMP WR[3] WITH LS[#1],                  ;ERROR 2 OR ERROR 3 LOOP?
U 0F13, CF41,B5     ;16286           DT(LONG)&SET.ALU.CC
U 0F14, 08F1,89     ;16287          JMP.IF[EQL] TO [ERROR3.T17]             ;JMP IF ERROR 3
                    ;16288
                    ;16289          CMP WR[2] WITH LS[#100],                ;LAST COUNT?
U 0F15, CF51,35     ;16290           DT(LONG)&SET.ALU.CC
U 0F16, 08EF,F1     ;16291          JMP.IF[NEQ] TO [ERR.INCR.LPCNTR.T17]    ;GO INCR THE LP CNTR
U 0F17, 88EF,24     ;16292          JMP [LOOP.T17.2]                        ;RELOAD LP CNTR = 0
                    ;16293
                    ;16294  ERROR3.T17:
U 0F18, B7BA,95     ;16295          MOV LS[#101] TO WR[1]
                    ;16296          CMP WR[0] WITH WR[1],
U 0F19, 2640,B5     ;16297           DT(LONG)&SET.ALU.CC                    ;OVERFLOW??
U 0F1A, 08EF,F1     ;16298          JMP.IF[NEQ] TO [ERR.INCR.LPCNTR.T17]    ;GO INC COUNTER
U 0F1B, 88EF,24     ;16299          JMP [LOOP.T17.2]                        ;RELOAD LP CNTR = 00
                    ;16300
                    ;16301  CLEANUP.T17.1:
U 0F1C, 8875,3C     ;16302          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY THIS
                    ;16303                                                  ; TEST
                    ;16304
                    ;16305  END.T17:                                        ;END TEST
                    ;16306
                    ;16307
                    ;16308
                    ;16309
                    ;16310
```

;16311

```
;16312  .PAGE  "Test 18  R80 BRANCH TEST (M8388 IDC MODULE)"
;16313  ;++
;16314  ;
;16315  ; Test Description:
;16316  ;
;16317  ;       This test will verify that the R80 branch condition operates correctly
;16318  ;       when unasserted, and if an R80 is available on the system, the R80
;16319  ;       branch condition will also be verified when asserted.
;16320  ;
;16321  ; Assumptions:
;16322  ;
;16323  ;       It is assumed that all previous tests have run successfully.
;16324  ;
;16325  ; Test Steps:
;16326  ;
;16327  ;       1. Set up error mask, error number and module number in LS
;16328  ;          (for error printouts) and clear the previous error number in LS.
;16329  ;       2. If the DRIVE SIZING TEST has not previously been run then,
;16330  ;          JSR to DRIVE.SIZE.
;16331  ;       3. Force the IDC microcode to DIAG.IDLE.
;16332  ;       4. Select an RL02 disk drive or a line with no disk attached.
;16333  ;       5. Clear the DAR.
;16334  ;       6. Set up the CSR to branch to the correct IDC routine.
;16335  ;
;16336  ;                                       *******
;16337  ;                                       * IDC *
;16338  ;                                       *******
;16339  ;
;16340  ;               IDC1. Select BEN0/R80.
;16341  ;               IDC2. If R80 H is asserted, then increment the DAR.
;16342  ;               IDC3. Send XFER REQ to flag the CPU.
;16343  ;               IDC4. Go to DIAG.IDLE.
;16344  ;
;16345  ;       7. Wait for an XFER REQ from IDC.
;16346  ;       8. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;16347  ;       9. If the DAR = 1 then issue error. (DAR will increment only if R80 was
;16348  ;                                               asserted)
;16349  ;      10. If an R80 is not available on the system the go to end of test.
;16350  ;      11. Increment the error number.
;16351  ;      12. Select an R80.
;16352  ;      13. Clear the DAR.
;16353  ;      14. Set up the CSR to branch to the correct IDC routine.
;16354  ;
;16355  ;                                       *******
;16356  ;                                       * IDC *
;16357  ;                                       *******
;16358  ;
;16359  ;               IDC5. Perform steps IDC1-IDC4.
;16360  ;
;16361  ;      15. Wait for an XFER REQ from IDC.
;16362  ;      16. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;16363  ;      17. If DAR = 0 then issue error.(DAR will increment if R80 is asserted).
;16364  ;      18. CLEAR IDC.
```

```
                ;16367  ;       19. End test.
                ;16368  ;
                ;16369  ; Errors:
                ;16370  ;
                ;16371  ;                   Printout:
                ;16372  ;                           EXPECTED          RECEIVED
                ;16373  ;                             DAR               DAR
                ;16374  ;
                ;16375  ;       ERROR 1 - R80 H branch failed unasserted.
                ;16376  ;
                ;16377  ;       ERROR 2 - R80 H branch failed asserted.
                ;16378  ;
                ;16379  ; Debug:
                ;16380  ;
                ;16381  ; ERROR 1:
                ;16382  ;       The DAR will be cleared.
                ;16383  ;       A drive that asserts L RL02 H at the CSR SELECTED STATUS LATCH PAL
                ;16384  ;       is selected. This signal is inverted to R80 H = L. The IDC
                ;16385  ;       microcode will branch to an instruction that will select BEN0/R80.
                ;16386  ;       This outputs at the microsequencer will be:
                ;16387  ;               BEN0 S2 H = H
                ;16388  ;               BEN0 S1 H = L
                ;16389  ;               BEN0 S0 H = L
                ;16390  ;       This will select R80 H = L as NUA 0 H. The microcode will branch
                ;16391  ;       to an instruction will send XFER REQ to flag the CPU but will NOT
                ;16392  ;       increment the DAR.
                ;16393  ;       The CPU will then read and check the DAR.
                ;16394  ;
                ;16395  ; ERROR 2:
                ;16396  ;       If no R80 is available, go to end of test.
                ;16397  ;
                ;16398  ;       The DAR is cleared.
                ;16399  ;       A drive that does NOT assert LRL20 H at the CSR SELECTED STATUS
                ;16400  ;       LATCH PAL will be selected. This signal is inverted to become
                ;16401  ;       R80 H = H.
                ;16402  ;       microcode will branch to an instruction that will select BEN0/R80.
                ;16403  ;       This outputs at the microsequencer will be:
                ;16404  ;               BEN0 S2 H = H
                ;16405  ;               BEN0 S1 H = L
                ;16406  ;               BEN0 S0 H = L
                ;16407  ;       This will select R80 H = H as NUA 0 H. The microcode will branch
                ;16408  ;       to an instruction that will increment the DAR and then send
                ;16409  ;       XFER REQ to flag the CPU.
                ;16410  ;       The CPU will then read and check the DAR.
                ;16411  ;--
                ;16412  ;*******************************************************************************
                ;16413  T.18:
U 0F1D, B65E,15 ;16414          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;16415                                                  ; CONTROL AND STATUS WORD
U 0F1E, 3E80,15 ;16416          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;16417                                                  ; STATUS WORD - BIT 15
                ;16418                                                  ; INDICATES START OF TEST TO
                ;16419                                                  ; CONSOLE
U 0F1F, 10E0,15 ;16420          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;16421  WAIT.T18.0:
```

```
U 0F20, 08F2,04 ;16422          JMP [WAIT.T18.0]                        ;LOOP HERE WAITING FOR
                ;16423                                                  ; CONSOLE TO RESPOND
                ;16424
U 0F21, 65A0,15 ;16425          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;16426                                                  ; IN LS
                ;16427
U 0F22, B64A,15 ;16428          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0F23, 3E8C,15 ;16429          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;16430
                ;16431
U 0F24, B640,15 ;16432          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0F25, BE82,15 ;16433          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;16434
U 0F26, 3776,15 ;16435          MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK THE DAR
U 0F27, 3E8A,15 ;16436          MOV WR[0] TO LS[ERROR.MASK]
                ;16437
U 0F28, B78E,15 ;16438          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING TEST BEEN
                ;16439          BIT LS[BIT7] WITH WR[0],                ; RUN?
U 0F29, D94E,35 ;16440           DT(LONG)&SET.ALU.CC
U 0F2A, 08F2,C1 ;16441          JMP.IF[BIT.SET] TO [SIZE.OK.T18.1]      ;IF YES THEN GO RUN TEST
                ;16442
U 0F2B, 8870,0C ;16443          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;16444
                ;16445  SIZE.OK.T18.1:
                ;16446
U 0F2C, 8872,EC ;16447          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;16448
                ;16449          ;SELECT AN RL02
                ;16450
U 0F2D, B78E,15 ;16451          MOV LS[DRIVE.STATUS] TO WR[0]
                ;16452          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0F2E, 5940,35 ;16453           DT(LONG)&SET.ALU.CC
U 0F2F, 88F3,29 ;16454          JMP.IF[BITS.CLR] TO [SET.DS0.T18.1]     ;JMP IF DRV 0 IS NOT AN R80
U 0F30, B717,15 ;16455          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 0F31, 88F3,34 ;16456          JMP [TEST.T18.1]
                ;16457  SET.DS0.T18.1:
U 0F32, 3715,15 ;16458          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;16459
                ;16460  TEST.T18.1:
                ;16461  LOOP.T18.1:
U 0F33, 2F80,15 ;16462          CLR WR[0]                               ;WR[0] = 0
U 0F34, 97A4,15 ;16463          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
U 0F35, B712,15 ;16464          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 0F36, B720,95 ;16465          MOV LS[SETCSR.MAINT] TO WR[1]           ; BRANCH TO THE CORRECT IDC
U 0F37, AEC2,15 ;16466          BIS WR[1] TO WR[0]                      ; ROUTINE
U 0F38, B708,95 ;16467          MOV LS[SETCSR.F4] TO WR[1]
U 0F39, AEC2,15 ;16468          BIS WR[1] TO WR[0]
U 0F3A, AEC4,15 ;16469          BIS WR[2] TO WR[0]                      ;SELECT AN RL02
U 0F3B, 17A0,15 ;16470          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;16471                                                  ;MAINT=1,CRDY=1,F<2:0>=100
                ;16472  ;-------------------------------------------------------------------------------
                ;16473  ;-------------------------------------------------------------------------------
                ;16474  ;                                *******
                ;16475  ;                                * IDC *
                ;16476  ;                                *******
```

```
;16477  ;-------------------------------------------------------------------------
;16478  ;018:
;16479  ;=000
;16480  ;DIAG.IDLE:
;16481  ;
;16482  ;       BEN0/F0,
;16483  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;16484  ;       BEN2/F2,
;16485  ;       NAD/DIAG.IDLE
;16486  ;-------------------------------------------------------------------------
;16487  ;01C:
;16488  ;=100
;16489  ;
;16490  ;       BEN0/CRDY.L,
;16491  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;16492  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;16493  ;-------------------------------------------------------------------------
;16494  ;06E:
;16495  ;=1*0
;16496  ;TEST.R80.1:
;16497  ;
;16498  ;       BEN0/R80,                       ;IS R80 ASSERTED CSR <26>?
;16499  ;       BEN2/R80.FORMAT.H,              ;IS CSR BIT <29> ASSERTED?
;16500  ;       NAD/R80.BR.TST
;16501  ;-------------------------------------------------------------------------
;16502  ;07A:
;16503  ;=0*0
;16504  ;R80.BR.TST:
;16505  ;
;16506  ;       NAD/XFER.REQ                    ;R80 NOT ASSERTED AND R80 FORMAT
;16507  ;                                       ; NOT ASSERTED DO NOT INC THE DAR
;16508  ;-------------------------------------------------------------------------
;16509  ;07B:
;16510  ;=0*1
;16511  ;R80.BR.TST.1:
;16512  ;
;16513  ;       INCR.DAR/ON,                    ;INC THE DAR..R80 ASSERTED
;16514  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;16515  ;-------------------------------------------------------------------------
;16516  ;07E:
;16517  ;=1*0
;16518  ;R80.BR.TST.2:
;16519  ;
;16520  ;       INCR.DAR/ON,                    ;INC THE DAR..R80.FORMAT ASSERTED
;16521  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;16522  ;-------------------------------------------------------------------------
;16523  ;=
;16524  ;END THE BRANCH BLOCK
;16525  ;-------------------------------------------------------------------------
;16526  ;1D8:
;16527  ;XFER.REQ:
;16528  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;16529  ;       NAD/DIAG.WAIT
;16530  ;-------------------------------------------------------------------------
;16531  ;1D7:
```

```
                    ;16532  ;DIAG.WAIT:
                    ;16533  ;
                    ;16534  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                    ;16535  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                    ;16536  ;-------------------------------------------------------------------
                    ;16537  ;159:
                    ;16538  ;=*0*
                    ;16539  ;DIAG.WAIT1:
                    ;16540  ;
                    ;16541  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;16542  ;                               ; COMMAND FROM THE CPU
                    ;16543  ;-------------------------------------------------------------------
                    ;16544  ;15B:
                    ;16545  ;=*1*
                    ;16546  ;DIAG.WAIT2:
                    ;16547  ;
                    ;16548  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;16549  ;                               ; WAIT SOME MORE
                    ;16550  ;-------------------------------------------------------------------
                    ;16551  WAIT.IDC.T18.1:
U 0F3C, DB00,1A     ;16552          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0F3D, 88F3,F4     ;16553          JMP [IDC.DONE.T18.1]                    ;IDC DONE
U 0F3E, 88F3,C4     ;16554          JMP [WAIT.IDC.T18.1]                    ;WAIT SOME MORE
                    ;16555
                    ;16556  IDC.DONE.T18.1:
U 0F3F, B700,15     ;16557          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 0F40, 17A0,15     ;16558          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0F41, 90FA,15     ;16559          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                    ;16560                                                  ; AND FORCE TO DIAG.IDLE
                    ;16561  READ.DAR.T18.1:
U 0F42, 9090,15     ;16562          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0F43, 1784,15     ;16563          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0F44, 3B32,15     ;16564          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;16565                                                  ; SAVE IT IN LS
U 0F45, 3732,15     ;16566          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0F46, 2F82,95     ;16567          CLR WR[1]                               ;SET UP THE EXPECTED DATA
U 0F47, 0869,3C     ;16568          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0F48, 88F3,34     ;16569          JMP [LOOP.T18.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;16570
                    ;16571
                    ;16572          ;SELECT AN R80 DRIVE IF ONE IS AVAILABLE...ELSE SKIP REST OF TEST
                    ;16573
U 0F49, B78E,15     ;16574          MOV LS[DRIVE.STATUS] TO WR[0]
U 0F4A, 3790,95     ;16575          MOV LS[#FFFFFFF0] TO WR[1]
U 0F4B, AF42,15     ;16576          BIC WR[1] TO WR[0]                      ;CHECK BITS <3:0>
                    ;16577          CMP LS[ZERO] WITH WR[0],                ;ANY R80S?
U 0F4C, CE9C,35     ;16578           DT(LONG)&SET.ALU.CC
U 0F4D, 08F4,F1     ;16579          JMP.IF[NEQ] TO [FIND.R80.T18]           ;YES..GO DO TEST
                    ;16580
U 0F4E, 08F7,54     ;16581          JMP [CLEANUP.T18.1]                     ;NO R80, CLEANUP AND END TEST
                    ;16582
                    ;16583  FIND.R80.T18:
U 0F4F, B78E,15     ;16584          MOV LS[DRIVE.STATUS] TO WR[0]
                    ;16585          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 0F50, 5940,35     ;16586           DT(LONG)&SET.ALU.CC
```

```
U 0F51, 08F5,71 ;16587          JMP.IF[BIT.SET] TO [SEL.DR0.T18.1]      ;JMP IF DRV 0 = R80
                ;16588
                ;16589          BIT LS[BIT1] WITH WR[0],                ;IS DRIVE 1 AN R80?
U 0F52, D942,35 ;16590           DT(LONG)&SET.ALU.CC
U 0F53, 88F5,91 ;16591          JMP.IF[BIT.SET] TO [SEL.DR1.T18.1]      ;JMP IF DRV 1 = R80
                ;16592
                ;16593          BIT LS[BIT2] WITH WR[0],                ;IS DRIVE 2 AN R80?
U 0F54, D944,35 ;16594           DT(LONG)&SET.ALU.CC
U 0F55, 08F5,B1 ;16595          JMP.IF[BIT.SET] TO [SEL.DR2.T18.1]      ;JMP IF DRV 2 = R80
                ;16596
U 0F56, 08F5,D4 ;16597          JMP [SEL.DR3.T18.1]                     ;JMP AND SEL DR 3
                ;16598
                ;16599  SEL.DR0.T18.1:
U 0F57, 3715,15 ;16600          MOV LS[SETCSR.DS0] TO WR[2]             ;SAV DRV SEL = 0
U 0F58, 08F5,E4 ;16601          JMP [TEST.T18.2]                        ;GO DO TEST
                ;16602
                ;16603  SEL.DR1.T18.1:
U 0F59, B717,15 ;16604          MOV LS[SETCSR.DS1] TO WR[2]             ;SAV DRV SEL = 1
U 0F5A, 08F5,E4 ;16605          JMP [TEST.T18.2]                        ;GO DO TEST
                ;16606
                ;16607  SEL.DR2.T18.1:
U 0F5B, 3719,15 ;16608          MOV LS[SETCSR.DS2] TO WR[2]             ;SAV DRV SEL = 2
U 0F5C, 08F5,E4 ;16609          JMP [TEST.T18.2]                        ;GO DO TEST
                ;16610
                ;16611  SEL.DR3.T18.1:
U 0F5D, B71B,15 ;16612          MOV LS[SETCSR.DS3] TO WR[2]             ;SAV DRV SEL = 3
                ;16613
                ;16614  TEST.T18.2:
U 0F5E, FF82,15 ;16615          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;16616  LOOP.T18.2:
U 0F5F, 2F80,15 ;16617          CLR WR[0]                               ;WR[0] = 0
U 0F60, 97A4,15 ;16618          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
U 0F61, B712,15 ;16619          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 0F62, B720,95 ;16620          MOV LS[SETCSR.MAINT] TO WR[1]           ; BRANCH TO THE CORRECT IDC
U 0F63, AEC2,15 ;16621          BIS WR[1] TO WR[0]                      ; ROUTINE
U 0F64, B708,95 ;16622          MOV LS[SETCSR.F4] TO WR[1]
U 0F65, AEC2,15 ;16623          BIS WR[1] TO WR[0]
U 0F66, AEC4,15 ;16624          BIS WR[2] TO WR[0]                      ;SELECT AN R80
U 0F67, 17A0,15 ;16625          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;16626                                                  ;MAINT=1,CRDY=1,F<2:0>=100
                ;16627  ;-------------------------------------------------------------------------------
                ;16628  ;-------------------------------------------------------------------------------
                ;16629  ;                                *******
                ;16630  ;                                * IDC *
                ;16631  ;                                *******
                ;16632  ;-------------------------------------------------------------------------
                ;16633  ;018:
                ;16634  ;=000
                ;16635  ;DIAG.IDLE:
                ;16636  ;
                ;16637  ;       BEN0/F0,
                ;16638  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;16639  ;       BEN2/F2,
                ;16640  ;       NAD/DIAG.IDLE
                ;16641  ;-------------------------------------------------------------------------
```

```
;16642  ;01C:
;16643  ;=100
;16644  ;
;16645  ;       BEN0/CRDY.L,
;16646  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;16647  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;16648  ;-----------------------------------------------------------------------
;16649  ;06E:
;16650  ;=1*0
;16651  ;TEST.R80.1:
;16652  ;
;16653  ;       BEN0/R80,                       ;IS R80 ASSERTED CSR <26>?
;16654  ;       BEN2/R80.FORMAT.H,              ;IS CSR BIT <29> ASSERTED?
;16655  ;       NAD/R80.BR.TST
;16656  ;-----------------------------------------------------------------------
;16657  ;07A:
;16658  ;=0*0
;16659  ;R80.BR.TST:
;16660  ;
;16661  ;       NAD/XFER.REQ                    ;R80 NOT ASSERTED AND R80 FORMAT
;16662  ;                                       ; NOT ASSERTED DO NOT INC THE DAR
;16663  ;-----------------------------------------------------------------------
;16664  ;07B:
;16665  ;=0*1
;16666  ;R80.BR.TST.1:
;16667  ;
;16668  ;       INCR.DAR/ON,                    ;INC THE DAR..R80 ASSERTED
;16669  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;16670  ;-----------------------------------------------------------------------
;16671  ;07E:
;16672  ;=1*0
;16673  ;R80.BR.TST.2:
;16674  ;
;16675  ;       INCR.DAR/ON,                    ;INC THE DAR..R80.FORMAT ASSERTED
;16676  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;16677  ;-----------------------------------------------------------------------
;16678  ;=
;16679  ;END THE BRANCH BLOCK
;16680  ;-----------------------------------------------------------------------
;16681  ;1D8:
;16682  ;XFER.REQ:
;16683  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;16684  ;       NAD/DIAG.WAIT
;16685  ;-----------------------------------------------------------------------
;16686  ;1D7:
;16687  ;DIAG.WAIT:
;16688  ;
;16689  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;16690  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;16691  ;-----------------------------------------------------------------------
;16692  ;159:
;16693  ;=*J*
;16694  ;DIAG.WAIT1:
;16695  ;
;16696  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
```

```
                ;16697  ;                               ; COMMAND FROM THE CPU
                ;16698  ;-------------------------------------------------------------------
                ;16699  ;15B:
                ;16700  ;=*1*
                ;16701  ;DIAG.WAIT2:
                ;16702  ;
                ;16703  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;16704  ;                               ; WAIT SOME MORE
                ;16705  ;-------------------------------------------------------------------
                ;16706  WAIT.IDC.T18.2:
U 0F68, DB00,1A ;16707          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR THE IDC
U 0F69, 08F6,B4 ;16708          JMP [IDC.DONE.T18.2]                    ;IDC DONE
U 0F6A, 08F6,84 ;16709          JMP [WAIT.IDC.T18.2]                    ;WAIT SOME MORE
                ;16710
                ;16711  IDC.DONE.T18.2:
U 0F6B, B700,15 ;16712          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 0F6C, 17A0,15 ;16713          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0F6D, 90FA,15 ;16714          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;16715                                                  ; AND FORCE TO DIAG.IDLE
                ;16716  READ.DAR.T18.2:
U 0F6E, 9090,15 ;16717          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0F6F, 1784,15 ;16718          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0F70, 3B32,15 ;16719          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;16720                                                  ; SAVE IT IN LS
U 0F71, 3732,15 ;16721          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0F72, 3640,95 ;16722          MOV LS[#1] TO WR[1]                     ;SET UP EXPECTED DATA
U 0F73, 0869,3C ;16723          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0F74, 88F5,F4 ;16724          JMP [LOOP.T18.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;16725
                ;16726  CLEANUP.T18.1:
U 0F75, 8875,3C ;16727          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;16728                                                  ; THIS TEST
                ;16729
                ;16730  END.T18:                                        ;END TEST
                ;16731
                ;16732
                ;16733
                ;16734
```

```
;16735  .PAGE  "Test 19  R80 FORMAT BRANCH  TEST (M8388 IDC MODULE)"
;16736  ;++
;16737  ; Test Description:
;16738  ;
;16739  ;       This test is designed to insure that the BEN2/R80 FORMAT branch
;16740  ;       condition operates correctly. CSR bit <29> (R80 FORMAT) will be set
;16741  ;       by writing to the CSR. The IDC will then select BEN2/R80 FORMAT.
;16742  ;       If R80 FORMAT is asserted, then DAR will be incremented.
;16743  ;       If R80 FORMAT is NOT asserted the DAR will not be incremented.
;16744  ;       The CPU will then read and check the DAR = 1. CSR bit <29> will then
;16745  ;       be cleared. The IDC will again select BEN2/R80 FORMAT.
;16746  ;       If R80 FORMAT is NOT asserted the DAR will not be incremented.
;16747  ;       If R80 FORMAT is asserted, then DAR will be incremented.
;16748  ;       The CPU will then read and check the DAR = 0.
;16749  ;
;16750  ; Assumptions:
;16751  ;
;16752  ;       It is assumed that the CONTROL STATUS REGISTER TEST has been
;16753  ;       previously run successfully.
;16754  ;
;16755  ; Test Steps:
;16756  ;
;16757  ;       1. Set up error mask, error number and module number in LS
;16758  ;          (for error printouts) and clear the previous error number in LS.
;16759  ;       2. If the DRIVE SIZING TEST has not previously been run then,
;16760  ;          JSR to DRIVE.SIZE.
;16761  ;       3. Force the IDC microcode to DIAG.IDLE.
;16762  ;       4. Select a drive which asserts L RL02 H.
;16763  ;       5. Clear the DAR.
;16764  ;       6. Set CSR <29> R80 FORMAT.
;16765  ;       8. Set up the CSR to branch to the correct IDC routine.
;16766  ;
;16767  ;                                       *******
;16768  ;                                       * IDC *
;16769  ;                                       *******
;16770  ;
;16771  ;               IDC1. Select BEN2/R80 FORMAT.
;16772  ;               IDC2. Increment the DAR if R80 FORMAT is asserted.
;16773  ;               IDC3. Send XFER REQ to flag the CPU.
;16774  ;
;16775  ;       8. Wait for a XFER REQ from IDC.
;16776  ;       9. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;16777  ;      10. Check the DAR = 1.
;16778  ;      11. Increment the error number.
;16779  ;      12. Clear the DAR.
;16780  ;      13. Clear CSR <29> R80 FORMAT.
;16781  ;      14. Set up the CSR to branch to the correct IDC routine.
;16782  ;
;16783  ;                                       *******
;16784  ;                                       * IDC *
;16785  ;                                       *******
;16786  ;
;16787  ;               IDC4. Select BEN2/R80 FORMAT.
;16788  ;               IDC5. Increment the DAR if R80 FORMAT is asserted.
;16789  ;               IDC6. Send XFER REQ to flag the CPU.
```

```
                ;16790  ;
                ;16791  ;       15. Wait for a XFER REQ from IDC.
                ;16792  ;       16. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
                ;16793  ;       17. Check the DAR = 0.
                ;16794  ;       18. Clear IDC.
                ;16795  ;       19. End test.
                ;16796  ;
                ;16797  ; Errors:
                ;16798  ;
                ;16799  ;
                ;16800  ;                       Printout:
                ;16801  ;                               EXPECTED          RECEIVED
                ;16802  ;                                 DAR               DAR
                ;16803  ;
                ;16804  ;       ERROR 1 - BEN2/R80 FORMAT branch failed when R80 FORMAT was asserted.
                ;16805  ;
                ;16806  ;       ERROR 2 - BEN2/R80 FORMAT branch failed when R80 FORMAT was
                ;16807  ;                 NOT asserted.
                ;16808  ;
                ;16809  ; Debug:
                ;16810  ;
                ;16811  ;       Since CSR <29> (R80 FORMAT) has previously been tested, it is most
                ;16812  ;       likely that the branch condition has failed.
                ;16813  ;
                ;16814  ; ERROR 1:
                ;16815  ;       Select a drive which asserts L RL02 H so that the inverse of that,
                ;16816  ;       R80 H = L.
                ;16817  ;       Set CSR <29>, R80 FORMAT H.
                ;16818  ;       The IDC microcode will branch to an BEN2/R80.FORMAT.H instruction.
                ;16819  ;       The outputs of the microsequencr will be:
                ;16820  ;               BEN2 S2 H = H
                ;16821  ;               BEN2 S1 H = H
                ;16822  ;               BEN2 S0 H = L
                ;16823  ;       This will select R80 FORMAT H = H as NUA 2 H. The IDC microcode
                ;16824  ;       will branch to an instruction that will increment the DAR and then
                ;16825  ;       send XFER REQ to flag the CPU.
                ;16826  ;       The CPU will then read and check the DAR.
                ;16827  ;
                ;16828  ; ERROR 2:
                ;16829  ;       Select a drive which asserts L RL02 H so that the inverse of that,
                ;16830  ;       R80 H = L.
                ;16831  ;       Clear CSR <29>, R80 FORMAT H.
                ;16832  ;       The IDC microcode will branch to an BEN2/R80.FORMAT.H instruction.
                ;16833  ;       The outputs of the microsequencr will be:
                ;16834  ;               BEN2 S2 H = H
                ;16835  ;               BEN2 S1 H = H
                ;16836  ;               BEN2 S0 H = L
                ;16837  ;       This will select R80 FORMAT L = H as NUA 2 H. The IDC microcode
                ;16838  ;       will branch to an instruction that will send XFER REQ to flag
                ;16839  ;       the CPU and will NOT increment the DAR.
                ;16840  ;       The CPU will then read and check the DAR.
                ;16841  ;--
                ;16842  ;*******************************************************************************
                ;16843  T.19:
U 0F76, B65E,15 ;16844          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
```

```
                ;16845                                          ; CONTROL AND STATUS WORD
U 0F77, 3E80,15 ;16846          MOV WR[0] TO LS[CONTROL.STATUS]  ;SET BIT 15 IN CONTROL AND
                ;16847                                          ; STATUS WORD - BIT 15
                ;16848                                          ; INDICATES START OF TEST TO
                ;16849                                          ; CONSOLE
U 0F78, 10E0,15 ;16850          MISC [SET.CP.ATTN]              ;ISSUE CPU ATTN TO CONSOLE
                ;16851  WAIT.T19.0:
U 0F79, 08F7,94 ;16852          JMP [WAIT.T19.0]                ;LOOP HERE WAITING FOR
                ;16853                                          ; CONSOLE TO RESPOND
                ;16854
U 0F7A, 65A0,15 ;16855          CLR LS[PREVIOUS.ERROR]          ;CLEAR PREVIOUS ERROR NUMBER
                ;16856                                          ; IN LS
                ;16857
U 0F7B, B64A,15 ;16858          MOV LS[IDC] TO WR[0]            ;STORE MODULE CODE IN LS TO
U 0F7C, 3E8C,15 ;16859          MOV WR[0] TO LS[MODULE.NUM]     ; INDICATE IDC MODULE
                ;16860
                ;16861
U 0F7D, B640,15 ;16862          MOV LS[#1] TO WR[0]             ;SET WR0 = 1
U 0F7E, BE82,15 ;16863          MOV WR[0] TO LS[ERROR.NUMBER]   ;SET UP ERROR NUMBER = 1 IN LS
                ;16864
U 0F7F, 3776,15 ;16865          MOV LS[DAR.MASK] TO WR[0]
U 0F80, 3E8A,15 ;16866          MOV WR[0] TO LS[ERROR.MASK]     ;SET MASK TO CHECK <18:0>
                ;16867
U 0F81, B78E,15 ;16868          MOV LS[DRIVE.STATUS] TO WR[0]   ;HAS THE DRIVE SIZING TEST BEEN
                ;16869          BIT LS[BIT7] WITH WR[0],        ; RUN?
U 0F82, D94E,35 ;16870           DT(LONG)&SET.ALU.CC
U 0F83, 08F8,51 ;16871          JMP.IF[BIT.SET] TO [SIZE.OK.T19.1]  ;IF YES THEN GO RUN TEST
                ;16872
U 0F84, 8870,0C ;16873          JSR [DRIVE.SIZE]                ;GO RUN THE SIZING ROUTINE
                ;16874
                ;16875  SIZE.OK.T19.1:
                ;16876
U 0F85, 8872,EC ;16877          JSR [DIAG.CODE]                 ;FORCE THE IDC TO DIAG.IDLE
                ;16878
                ;16879          ;SELECT AN RL02
                ;16880
U 0F86, B78E,15 ;16881          MOV LS[DRIVE.STATUS] TO WR[0]
                ;16882          BIT LS[BIT0] WITH WR[0],        ;IS DRIVE 0 AN R80?
U 0F87, 5940,35 ;16883           DT(LONG)&SET.ALU.CC
U 0F88, 08F8,B9 ;16884          JMP.IF[BITS.CLR] TO [SET.DS0.T19.1]  ;JMP IF DRV 0 IS NOT AN R80
U 0F89, B717,15 ;16885          MOV LS[SETCSR.DS1] TO WR[2]     ;SAVE THE DATA TO SEL DRIVE 1
U 0F8A, 08F8,C4 ;16886          JMP [TEST.T19.1]
                ;16887  SET.DS0.T19.1:
U 0F8B, 3715,15 ;16888          MOV LS[SETCSR.DS0] TO WR[2]     ;SAVE THE DATA TO SEL DRIVE 0
                ;16889
                ;16890  TEST.T19.1:
                ;16891  LOOP.T19.1:
U 0F8C, 2F80,15 ;16892          CLR WR[0]
U 0F8D, 97A4,15 ;16893          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]  ;CLEAR THE DAR
                ;16894
U 0F8E, B712,15 ;16895          MOV LS[SETCSR.CRDY] TO WR[0]    ;SET UP THE CSR TO BRANCH TO
U 0F8F, B720,95 ;16896          MOV LS[SETCSR.MAINT] TO WR[1]   ; THE ROUTINE THAT WILL SELECT
U 0F90, AEC2,15 ;16897          BIS WR[1] TO WR[0]              ; BEN2/R80.FORMAT
U 0F91, B708,95 ;16898          MOV LS[SETCSR.F4] TO WR[1]
U 0F92, AEC2,15 ;16899          BIS WR[1] TO WR[0]
```

```
U 0F93, AEC4,15 ;16900          BIS WR[2] TO WR[0]                      ;INCLUDE THE DRIVE SELECT
U 0F94, C77A,15 ;16901          BIS LS[BIT29] TO WR[0]                  ;SET CSR BIT <29> R80 FORMAT
U 0F95, 17A0,15 ;16902          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;16903                                                  ;MAINT=1,CRDY=1,F<2:0>=100
                ;16904  ;-------------------------------------------------------------------------
                ;16905  ;-------------------------------------------------------------------------
                ;16906  ;                               *******
                ;16907  ;                               * IDC *
                ;16908  ;                               *******
                ;16909  ;-------------------------------------------------------------------------
                ;16910  ;018:
                ;16911  ;=000
                ;16912  ;DIAG.IDLE:
                ;16913  ;
                ;16914  ;       BEN0/F0,
                ;16915  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;16916  ;       BEN2/F2,
                ;16917  ;       NAD/DIAG.IDLE
                ;16918  ;-------------------------------------------------------------------------
                ;16919  ;01C:
                ;16920  ;=100
                ;16921  ;
                ;16922  ;       BEN0/CRDY.L,
                ;16923  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;16924  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;16925  ;-------------------------------------------------------------------------
                ;16926  ;06E:
                ;16927  ;=1*0
                ;16928  ;TEST.R80.1:
                ;16929  ;
                ;16930  ;       BEN0/R80,               ;IS R80 ASSERTED CSR <26>?
                ;16931  ;       BEN2/R80.FORMAT.H,      ;IS CSR BIT <29> ASSERTED?
                ;16932  ;       NAD/R80.BR.TST
                ;16933  ;-------------------------------------------------------------------------
                ;16934  ;07A:
                ;16935  ;=0*0
                ;16936  ;R80.BR.TST:
                ;16937  ;
                ;16938  ;       NAD/XFER.REQ            ;R80 NOT ASSERTED AND R80 FORMAT
                ;16939  ;                               ; NOT ASSERTED DO NOT INC THE DAR
                ;16940  ;-------------------------------------------------------------------------
                ;16941  ;07B:
                ;16942  ;=0*1
                ;16943  ;R80.BR.TST.1:
                ;16944  ;
                ;16945  ;       INCR.DAR/ON,            ;INC THE DAR..R80 ASSERTED
                ;16946  ;       NAD/XFER.REQ            ;FLAG THE CPU
                ;16947  ;-------------------------------------------------------------------------
                ;16948  ;07E:
                ;16949  ;=1*0
                ;16950  ;R80.BR.TST.2:
                ;16951  ;
                ;16952  ;       INCR.DAR/ON,            ;INC THE DAR..R80.FORMAT ASSERTED
                ;16953  ;       NAD/XFER.REQ            ;FLAG THE CPU
                ;16954  ;-------------------------------------------------------------------------
```

```
                ;16955  ;=
                ;16956  ;END THE BRANCH BLOCK
                ;16957  ;-------------------------------------------------------------------------------
                ;16958  ;1D8:
                ;16959  ;XFER.REQ:
                ;16960  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;16961  ;       NAD/DIAG.WAIT
                ;16962  ;-------------------------------------------------------------------------------
                ;16963  ;1D7:
                ;16964  ;DIAG.WAIT:
                ;16965  ;
                ;16966  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;16967  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;16968  ;-------------------------------------------------------------------------------
                ;16969  ;159:
                ;16970  ;=*0*
                ;16971  ;DIAG.WAIT1:
                ;16972  ;
                ;16973  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;16974  ;                               ; COMMAND FROM THE CPU
                ;16975  ;-------------------------------------------------------------------------------
                ;16976  ;15B:
                ;16977  ;=*1*
                ;16978  ;DIAG.WAIT2:
                ;16979  ;
                ;16980  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;16981  ;                               ; WAIT SOME MORE
                ;16982  ;-------------------------------------------------------------------------------
                ;16983  WAIT.IDC.T19.1:
U 0F96, DB00,1A ;16984          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 0F97, 88F9,94 ;16985          JMP [IDC.DONE.T19.1]                    ;XFER REQ SET
U 0F98, 88F9,64 ;16986          JMP [WAIT.IDC.T19.1]                    ;WAIT SOME MORE
                ;16987
                ;16988  IDC.DONE.T19.1:
U 0F99, B700,15 ;16989          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 0F9A, 17A0,15 ;16990          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0F9B, 90FA,15 ;16991          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;16992
                ;16993  READ.DAR.T19.1:
U 0F9C, 9090,15 ;16994          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0F9D, 1784,15 ;16995          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0F9E, 3B32,15 ;16996          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;16997                                                  ; SAVE IT IN  LS
U 0F9F, 3732,15 ;16998          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0FA0, 3640,95 ;16999          MOV LS[#1] TO WR[1]                     ;SET UP THE EXPECTED DATA
U 0FA1, 0869,3C ;17000          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0FA2, 08F8,C4 ;17001          JMP [LOOP.T19.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;17002
U 0FA3, FF82,15 ;17003          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;17004
                ;17005  LOOP.T19.2:
U 0FA4, 2F80,15 ;17006          CLR WR[0]
U 0FA5, 97A4,15 ;17007          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                ;17008
U 0FA6, B712,15 ;17009          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
```

```
U 0FA7, B720,95 ;17010          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE ROUTINE THAT WILL SELECT
U 0FA8, AEC2,15 ;17011          BIS WR[1] TO WR[0]                      ; BEN2/R80.FORMAT
U 0FA9, B708,95 ;17012          MOV LS[SETCSR.F4] TO WR[1]
U 0FAA, AEC2,15 ;17013          BIS WR[1] TO WR[0]                      ;BIT 29 - R80 FORMAT = 0
U 0FAB, AEC4,15 ;17014          BIS WR[2] TO WR[0]                      ;INCLUDE THE DRIVE SELECT
U 0FAC, 17A0,15 ;17015          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;17016                                                  ;MAINT=1,CRDY=1,F<2:0>=100
                ;17017  ;-------------------------------------------------------------------------------
                ;17018  ;-------------------------------------------------------------------------------
                ;17019  ;                               *******
                ;17020  ;                               * IDC *
                ;17021  ;                               *******
                ;17022  ;-------------------------------------------------------------------------
                ;17023  ;018:
                ;17024  ;=000
                ;17025  ;DIAG.IDLE:
                ;17026  ;
                ;17027  ;       BEN0/F0,
                ;17028  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;17029  ;       BEN2/F2,
                ;17030  ;       NAD/DIAG.IDLE
                ;17031  ;-------------------------------------------------------------------------
                ;17032  ;01C:
                ;17033  ;=100
                ;17034  ;
                ;17035  ;       BEN0/CRDY.L,
                ;17036  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;17037  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;17038  ;-------------------------------------------------------------------------
                ;17039  ;06E:
                ;17040  ;=1*0
                ;17041  ;TEST.R80.1:
                ;17042  ;
                ;17043  ;       BEN0/R80,               ;IS R80 ASSERTED CSR <26>?
                ;17044  ;       BEN2/R80.FORMAT.H,      ;IS CSR BIT <29> ASSERTED?
                ;17045  ;       NAD/R80.BR.TST
                ;17046  ;-------------------------------------------------------------------------
                ;17047  ;07A:
                ;17048  ;=0*0
                ;17049  ;R80.BR.TST:
                ;17050  ;
                ;17051  ;       NAD/XFER.REQ            ;R80 NOT ASSERTED AND R80 FORMAT
                ;17052  ;                               ; NOT ASSERTED DO NOT INC THE DAR
                ;17053  ;-------------------------------------------------------------------------
                ;17054  ;07B:
                ;17055  ;=0*1
                ;17056  ;R80.BR.TST.1:
                ;17057  ;
                ;17058  ;       INCR.DAR/ON,            ;INC THE DAR..R80 ASSERTED
                ;17059  ;       NAD/XFER.REQ            ;FLAG THE CPU
                ;17060  ;-------------------------------------------------------------------------
                ;17061  ;07E:
                ;17062  ;=1*0
                ;17063  ;R80.BR.TST.2:
                ;17064  ;
```

```
                ;17065  ;       INCR.DAR/ON,                    ;INC THE DAR..R80.FORMAT ASSERTED
                ;17066  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;17067  ;-------------------------------------------------------------------------
                ;17068  ;=
                ;17069  ;END THE BRANCH BLOCK
                ;17070  ;-------------------------------------------------------------------------
                ;17071  ;1D8:
                ;17072  ;XFER.REQ:
                ;17073  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;17074  ;       NAD/DIAG.WAIT
                ;17075  ;-------------------------------------------------------------------------
                ;17076  ;1D7:
                ;17077  ;DIAG.WAIT:
                ;17078  ;
                ;17079  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;17080  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;17081  ;-------------------------------------------------------------------------
                ;17082  ;159:
                ;17083  ;=*0*
                ;17084  ;DIAG.WAIT1:
                ;17085  ;
                ;17086  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;17087  ;                               ; COMMAND FROM THE CPU
                ;17088  ;-------------------------------------------------------------------------
                ;17089  ;15B:
                ;17090  ;=*1*
                ;17091  ;DIAG.WAIT2:
                ;17092  ;
                ;17093  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;17094  ;                               ; WAIT SOME MORE
                ;17095  ;-------------------------------------------------------------------------
                ;17096  WAIT.IDC.T19.2:
U OFAD, DB00,1A ;17097          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U OFAE, 08FB,04 ;17098          JMP [IDC.DONE.T19.2]                    ;XFER REQ SET
U OFAF, 08FA,D4 ;17099          JMP [WAIT.IDC.T19.2]                    ;WAIT SOME MORE
                ;17100
                ;17101  IDC.DONE.T19.2:
U OFB0, B700,15 ;17102          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U OFB1, 17A0,15 ;17103          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U OFB2, 90FA,15 ;17104          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;17105
                ;17106  READ.DAR.T19.2:
U OFB3, 9090,15 ;17107          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U OFB4, 1784,15 ;17108          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U OFB5, 3B32,15 ;17109          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;17110                                                  ; SAVE IT IN  LS
U OFB6, 3732,15 ;17111          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U OFB7, 2F82,95 ;17112          CLR WR[1]                               ;SET UP THE EXPECTED DATA
U OFB8, 0869,3C ;17113          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U OFB9, 08FA,44 ;17114          JMP [LOOP.T19.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;17115
U OFBA, 8875,3C ;17116          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;17117                                                  ; THIS TEST
                ;17118
                ;17119  END.T19:                                        ;END TEST
```

```
                ;17120
                ;17121
```

```
;17122  .PAGE  "Test  1A AUTOMATIC SKIP SECTOR INHIBIT BRANCH TEST (M8388 IDC MODULE)"
;17123  ;++
;17124  ; Test Description:
;17125  ;
;17126  ;       This test will check the BEN2/ASSI H branch condition is working
;17127  ;       correctly. CSR <27> (ASSI) will be set. The IDC microcode will
;17128  ;       select BEN2/ASSI H. If ASSI H is asserted the DAR will be incremented
;17129  ;       twice. If ASSI H is not asserted the DAR will be incremented once.
;17130  ;       CSR <27> (ASSI) will then be cleared. The IDC microcode will again
;17131  ;       select BEN2/ASSI H. If ASSI H is NOT asserted, the DAR will be
;17132  ;       incrmented once. If ASSI H is asserted the DAR will be
;17133  ;       incremented twice.
;17134  ;
;17135  ; Assumptions:
;17136  ;
;17137  ;       It is assumed that the CSR test has previously been run successfully.
;17138  ;
;17139  ; Test Steps:
;17140  ;
;17141  ;       1. Set up error mask, error number and module number in LS
;17142  ;          (for error printouts) and clear the previous error number in LS.
;17143  ;       2. Force the IDC to DIAG.IDLE.
;17144  ;       3. Clear the DAR.
;17145  ;       4. Set CSR <27> ASSI.
;17146  ;       5. Set up the CSR to branch to the correct IDC routine.
;17147  ;
;17148  ;                                       *******
;17149  ;                                       * IDC *
;17150  ;                                       *******
;17151  ;
;17152  ;               IDC1. Select BEN2/ASSI H.
;17153  ;               IDC2. If ASSI H is asserted, increment the DAR twice.
;17154  ;                     If ASSI H is NOT asserted, increment the DAR once.
;17155  ;               IDC3. Send XFER REQ to flag the CPU.
;17156  ;
;17157  ;       6. Wait for XFER REQ from IDC.
;17158  ;       7. Clear CSR F<2:0> and send XFER GRANT to clear XFER REQ.
;17159  ;       8. Check the DAR = 2.
;17160  ;       9. Increment the error number.
;17161  ;      10. Clear the DAR.
;17162  ;      11. Clear CSR <27> ASSI.
;17163  ;      12. Set up the CSR to branch to the correct IDC routine.
;17164  ;
;17165  ;                                       *******
;17166  ;                                       * IDC *
;17167  ;                                       *******
;17168  ;
;17169  ;               IDC4. Perform Steps IDC1 - IDC3.
;17170  ;
;17171  ;      13. Wait for XFER REQ from IDC.
;17172  ;      14. Clear CSR F<2:0> and send XFER GRANT to clear XFER REQ.
;17173  ;      15. Check DAR = 1.
;17174  ;      16. Clear IDC.
;17175  ;      17. End test.
;17176  ;
```

```
                ;17177  ; Errors:
                ;17178  ;
                ;17179  ;
                ;17180  ;               Printout:
                ;17181  ;                       EXPECTED        RECEIVED
                ;17182  ;                         DAR             DAR
                ;17183  ;
                ;17184  ;       ERROR 1 - BEN2/ASSI H failed with ASSI H asserted.
                ;17185  ;
                ;17186  ;       ERROR 2 - BEN2/ASSI H failed with ASSI H NOT asserted.
                ;17187  ;
                ;17188  ; Debug:
                ;17189  ;
                ;17190  ;       Since CSR <27> (ASSI) has previously been tested, it is most
                ;17191  ;       likely that the branch condition has failed.
                ;17192  ;
                ;17193  ; ERROR 1:
                ;17194  ;       Set CSR <27>, ASSI H.
                ;17195  ;       The IDC microcode will branch to an BEN2/IASS instruction.
                ;17196  ;       The outputs of the microsequencr will be:
                ;17197  ;               BEN2 S2 H = H
                ;17198  ;               BEN2 S1 H = L
                ;17199  ;               BEN2 S0 H = H
                ;17200  ;       This will select ASSI H = H as NUA 2 H. The IDC microcode
                ;17201  ;       will branch to set of instructions that will increment the DAR
                ;17202  ;       twice and send XFER REQ to flag the CPU.
                ;17203  ;       The CPU will then read and check the DAR = 2.
                ;17204  ;
                ;17205  ; ERROR 2:
                ;17206  ;       Clear CSR <27>, ASSI H.
                ;17207  ;       The IDC microcode will branch to an BEN2/IASS instruction.
                ;17208  ;       The outputs of the microsequencr will be:
                ;17209  ;               BEN2 S2 H = H
                ;17210  ;               BEN2 S1 H = L
                ;17211  ;               BEN2 S0 H = H
                ;17212  ;       This will select ASSI = L as NUA 2 H. The IDC microcode
                ;17213  ;       will branch to an instruction that will increment the DAR
                ;17214  ;       and tehn send XFER REQ to flag the CPU.
                ;17215  ;       The CPU will then read and check the DAR = 1.
                ;17216  ;--
                ;17217  ;*******************************************************************************
                ;17218  T.1A:
U 0FBB, B65E,15 ;17219          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;17220                                                  ; CONTROL AND STATUS WORD
U 0FBC, 3E80,15 ;17221          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;17222                                                  ; STATUS WORD - BIT 15
                ;17223                                                  ; INDICATES START OF TEST TO
                ;17224                                                  ; CONSOLE
U 0FBD, 10E0,15 ;17225          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;17226  WAIT.T1A.0:
U 0FBE, 88FB,E4 ;17227          JMP [WAIT.T1A.0]                        ;LOOP HERE WAITING FOR
                ;17228                                                  ; CONSOLE TO RESPOND
                ;17229
U 0FBF, 65A0,15 ;17230          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;17231                                                  ; IN LS
```

```
                ;17232
U 0FC0, B64A,15 ;17233          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 0FC1, 3E8C,15 ;17234          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;17235
                ;17236
U 0FC2, B640,15 ;17237          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 0FC3, BE82,15 ;17238          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;17239
U 0FC4, 3776,15 ;17240          MOV LS[DAR.MASK] TO WR[0]
U 0FC5, 3E8A,15 ;17241          MOV WR[0] TO LS[ERROR.MASK]             ;SET UP MASK TO CHECK <18:0>
                ;17242
U 0FC6, 8872,EC ;17243          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT TO
                ;17244                                                  ; DIAG.IDLE
                ;17245
                ;17246  LOOP.T1A.1:
U 0FC7, 2F80,15 ;17247          CLR WR[0]
U 0FC8, 97A4,15 ;17248          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                ;17249
U 0FC9, 370E,15 ;17250          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 0FCA, 17A0,15 ;17251          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                ;17252
                ;17253  ;CONTINUE TO BRANCH
U 0FCB, 379E,15 ;17254          MOV LS[SETCSR.R80] TO WR[0]
U 0FCC, 370C,95 ;17255          MOV LS[SETCSR.F6] TO WR[1]
U 0FCD, AEC2,15 ;17256          BIS WR[1] TO WR[0]
U 0FCE, C776,15 ;17257          BIS LS[BIT27] TO WR[0]                  ;SET CSR <ASSI>
U 0FCF, 17A0,15 ;17258          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;17259                                                  ;F<2:0>=110
                ;17260  ;SELECT BEN2/ASSI
                ;17261  ;-------------------------------------------------------------------------------
                ;17262  ;-------------------------------------------------------------------------------
                ;17263  ;                               *******
                ;17264  ;                               * IDC *
                ;17265  ;                               *******
                ;17266  ;-------------------------------------------------------------------------------
                ;17267  ;018:
                ;17268  ;=000
                ;17269  ;DIAG.IDLE:
                ;17270  ;
                ;17271  ;       BEN0/F0,
                ;17272  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;17273  ;       BEN2/F2,
                ;17274  ;       NAD/DIAG.IDLE
                ;17275  ;-------------------------------------------------------------------------------
                ;17276  ;01F:
                ;17277  ;=111
                ;17278  ;
                ;17279  ;       BEN0/CRDY.L,
                ;17280  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;17281  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;17282  ;-------------------------------------------------------------------------------
                ;17283  ;079:
                ;17284  ;=0*1
                ;17285  ;
                ;17286  ;       NAD/GROUP1
```

```
;17287  ;-------------------------------------------------------------------------
;17288  ;182:
;17289  ;=0**
;17290  ;GROUP1:
;17291  ;
;17292  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;17293  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;17294  ;                                       ; FUNCTION BITS
;17295  ;-------------------------------------------------------------------------
;17296  ;186:
;17297  ;=1**
;17298  ;
;17299  ;       BEN0/F0,
;17300  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;17301  ;       BEN2/F2,
;17302  ;       NAD/GROUP1.F0
;17303  ;-------------------------------------------------------------------------
;17304  ;02E:
;17305  ;=110
;17306  ;
;17307  ;       BEN2/IASS,              ;IS ASSI ASSERTED?
;17308  ;       NAD/BEN2.1
;17309  ;-------------------------------------------------------------------------
;17310  ;1A0:
;17311  ;=0**
;17312  ;BEN2.1:
;17313  ;
;17314  ;       INCR.DAR/ON,                    ;INCR DAR
;17315  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;17316  ;-------------------------------------------------------------------------
;17317  ;1A4:
;17318  ;=1**
;17319  ;BEN2.2:
;17320  ;
;17321  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;17322  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;17323  ;-------------------------------------------------------------------------
;17324  ;1D8:
;17325  ;XFER.REQ:
;17326  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;17327  ;       NAD/DIAG.WAIT
;17328  ;-------------------------------------------------------------------------
;17329  ;1D7:
;17330  ;DIAG.WAIT:
;17331  ;
;17332  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;17333  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;17334  ;-------------------------------------------------------------------------
;17335  ;159:
;17336  ;=*0*
;17337  ;DIAG.WAIT1:
;17338  ;
;17339  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;17340  ;                               ; COMMAND FROM THE CPU
;17341  ;-------------------------------------------------------------------------
```

```
                    ;17342  ;15B:
                    ;17343  ;=*1*
                    ;17344  ;DIAG.WAIT2:
                    ;17345  ;
                    ;17346  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;17347  ;                               ; WAIT SOME MORE
                    ;17348  ;-------------------------------------------------------------------------
                    ;17349  WAIT.IDC.T1A.1:
U 0FD0, DB00,1A     ;17350          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 0FD1, 08FD,34     ;17351          JMP [IDC.DONE.T1A.1]                    ;XFER REQ SET
U 0FD2, 08FD,04     ;17352          JMP [WAIT.IDC.T1A.1]                    ;WAIT SOME MORE
                    ;17353
                    ;17354  IDC.DONE.T1A.1:
U 0FD3, B700,15     ;17355          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 0FD4, 17A0,15     ;17356          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 0FD5, 90FA,15     ;17357          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                    ;17358
                    ;17359  READ.DAR.T1A.1:
U 0FD6, 9090,15     ;17360          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 0FD7, 1784,15     ;17361          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 0FD8, 3B32,15     ;17362          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;17363                                                  ; SAVE IT IN  LS
U 0FD9, 3732,15     ;17364          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 0FDA, B642,95     ;17365          MOV LS[#2] TO WR[1]                     ;SET UP EXPECTED DATA
U 0FDB, 0869,3C     ;17366          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 0FDC, 08FC,74     ;17367          JMP [LOOP.T1A.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;17368
U 0FDD, FF82,15     ;17369          INC LS[ERROR.NUMBER]                    ;ERROR 2
                    ;17370
                    ;17371  LOOP.T1A.2:
U 0FDE, 2F80,15     ;17372          CLR WR[0]
U 0FDF, 97A4,15     ;17373          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                    ;17374
U 0FE0, 370E,15     ;17375          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 0FE1, 17A0,15     ;17376          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                    ;17377
                    ;17378  ;CONTINUE TO BRANCH
U 0FE2, 379E,15     ;17379          MOV LS[SETCSR.R80] TO WR[0]
U 0FE3, 370C,95     ;17380          MOV LS[SETCSR.F6] TO WR[1]
U 0FE4, AEC2,15     ;17381          BIS WR[1] TO WR[0]
U 0FE5, 17A0,15     ;17382          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;17383                                                  ;F<2:0>=110
                    ;17384                                                  ;BIT <27> ASSI = 0
                    ;17385  ;SELECT BEN2/ASSI
                    ;17386  ;-------------------------------------------------------------------------
                    ;17387  ;-------------------------------------------------------------------------
                    ;17388  ;                               *******
                    ;17389  ;                               * IDC *
                    ;17390  ;                               *******
                    ;17391  ;-------------------------------------------------------------------------
                    ;17392  ;018:
                    ;17393  ;=000
                    ;17394  ;DIAG.IDLE:
                    ;17395  ;
                    ;17396  ;       BEN0/F0,
```

```
;17397  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;17398  ;       BEN2/F2,
;17399  ;       NAD/DIAG.IDLE
;17400  ;-------------------------------------------------------------------------
;17401  ;01F:
;17402  ;=111
;17403  ;
;17404  ;       BEN0/CRDY.L,
;17405  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;17406  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;17407  ;-------------------------------------------------------------------------
;17408  ;079:
;17409  ;=0*1
;17410  ;
;17411  ;       NAD/GROUP1
;17412  ;-------------------------------------------------------------------------
;17413  ;182:
;17414  ;=0**
;17415  ;GROUP1:
;17416  ;
;17417  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;17418  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;17419  ;                                       ; FUNCTION BITS
;17420  ;-------------------------------------------------------------------------
;17421  ;186:
;17422  ;=1**
;17423  ;
;17424  ;       BEN0/F0,
;17425  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;17426  ;       BEN2/F2,
;17427  ;       NAD/GROUP1.F0
;17428  ;-------------------------------------------------------------------------
;17429  ;02E:
;17430  ;=110
;17431  ;
;17432  ;       BEN2/IASS,              ;IS ASSI ASSERTED?
;17433  ;       NAD/BEN2.1
;17434  ;-------------------------------------------------------------------------
;17435  ;1A0:
;17436  ;=0**
;17437  ;BEN2.1:
;17438  ;
;17439  ;       INCR.DAR/ON,                    ;INCR DAR
;17440  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;17441  ;-------------------------------------------------------------------------
;17442  ;1A4:
;17443  ;=1**
;17444  ;BEN2.2:
;17445  ;
;17446  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;17447  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;17448  ;-------------------------------------------------------------------------
;17449  ;1D8:
;17450  ;XFER.REQ:
;17451  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
```

```
                ;17452  ;       NAD/DIAG.WAIT
                ;17453  ;-------------------------------------------------------------------------
                ;17454  ;1D7:
                ;17455  ;DIAG.WAIT:
                ;17456  ;
                ;17457  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;17458  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;17459  ;-------------------------------------------------------------------------
                ;17460  ;159:
                ;17461  ;=*0*
                ;17462  ;DIAG.WAIT1:
                ;17463  ;
                ;17464  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;17465  ;                               ; COMMAND FROM THE CPU
                ;17466  ;-------------------------------------------------------------------------
                ;17467  ;15B:
                ;17468  ;=*1*
                ;17469  ;DIAG.WAIT2:
                ;17470  ;
                ;17471  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;17472  ;                               ; WAIT SOME MORE
                ;17473  ;-------------------------------------------------------------------------
                ;17474  WAIT.IDC.T1A.2:
U OFE6, DB00,1A ;17475          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U OFE7, 08FE,94 ;17476          JMP [IDC.DONE.T1A.2]                    ;XFER REQ SET
U OFE8, 08FE,64 ;17477          JMP [WAIT.IDC.T1A.2]                    ;WAIT SOME MORE
                ;17478
                ;17479  IDC.DONE.T1A.2:
U OFE9, B700,15 ;17480          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U OFEA, 17A0,15 ;17481          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U OFEB, 90FA,15 ;17482          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;17483
                ;17484  READ.DAR.T1A.2:
U OFEC, 9090,15 ;17485          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U OFED, 1784,15 ;17486          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U OFEE, 3B32,15 ;17487          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;17488                                                  ; SAVE IT IN  LS
U OFEF, 3732,15 ;17489          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U OFF0, 3640,95 ;17490          MOV LS[#1] TO WR[1]                     ;SET UP EXPECTED DATA
U OFF1, 0869,3C ;17491          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U OFF2, 88FD,E4 ;17492          JMP [LOOP.T1A.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;17493
U OFF3, 8875,3C ;17494          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY THIS
                ;17495                                                  ; TEST
                ;17496
                ;17497  END.T1A:                                        ;END TEST
                ;17498
                ;17499
                ;17500
```

```
;17501  .PAGE  "Test 1B  ONLINE PAL & BRANCH TEST, DR SEL CSR<9:8> (M8388 IDC MODULE)"
;17502  ;++
;17503  ;
;17504  ; Test Description:
;17505  ;
;17506  ;       This test is designed to verify the ONLINE REGISTER PAL and the
;17507  ;       associated BEN1/ONLINE H branch condition. A portion of the DRIVE
;17508  ;       SELECT LOGIC PAL will also be verified in this test.
;17509  ;       When the BEN1/ONLINE H branch condition is selected, if ONLINE H
;17510  ;       is asserted the DAR will be incremented and then XFER.REQ will be
;17511  ;       issued. Otherwise XFER.REQ is issued.
;17512  ;       CSR Bits <9:8> will be used to select the current drive.
;17513  ;
;17514  ;       All drives will be cleared online. Each one will then be checked
;17515  ;       to insure that it is clear.
;17516  ;
;17517  ;       Drive 0 will then be selected as the current drive and set online.
;17518  ;       BEN1/ONLINE H will be selected and the CPU will be called to check the
;17519  ;       DAR=1. Each of the other drives will be selected and checked that they
;17520  ;       remained clear.
;17521  ;
;17522  ;       Drive 0 will again be selected as the current drive and online will be
;17523  ;       cleared. BEN1/ONLINE H will be selected and the CPU will be called to
;17524  ;       check the DAR=0.
;17525  ;
;17526  ;       The next drive will then be selected, and the same sequence of testing
;17527  ;       will be performed  as was using Drive 0 until all drives <3:0> have
;17528  ;       been tested.
;17529  ;
;17530  ; Assumptions:
;17531  ;
;17532  ;       It is assumed that the UINCR.DAR function works correctly.
;17533  ;
;17534  ; Test Steps:
;17535  ;
;17536  ;       1. Set up error mask, error number and module number in LS
;17537  ;          (for error printouts) and clear the previous error number in LS.
;17538  ;       2. Force the IDC microcode to DIAG.IDLE.
;17539  ;       3. Clear the DAR.
;17540  ;       4. Move the number 0 to WR[2] to indicate the current drive selected.
;17541  ;       5. Move WR[2] to CSR <DS1> <DS0>.
;17542  ;       6. Set up the CSR to branch to the correct microcode routine.
;17543  ;
;17544  ;
;17545  ;                                       *******
;17546  ;                                       * IDC *
;17547  ;                                       *******
;17548  ;
;17549  ;               IDC1. Set FUNC BITS <35:32> = 2, CLEAR ONLINE.
;17550  ;               IDC2. Issue XFER REQ to flag the CPU and go to DIAG.WAIT.
;17551  ;
;17552  ;       7. Wait for a XFER.REQ from IDC.
;17553  ;       8. Clear CSR F<2:0> and issue XFER GRANT to clear XFER.REQ.
;17554  ;       9. Set WR[2] = to next drive number and repeat Steps 5 - 9 until all
;17555  ;          drives have been cleared.
```

```
;17556  ;       10. Set WR[2] = 0.
;17557  ;       11. Move WR[2] to CSR <DS1> <DS0>.
;17558  ;       12. Set up the CSR to branch to the correct microcode routine.
;17559  ;
;17560  ;                                       *******
;17561  ;                                       * IDC *
;17562  ;                                       *******
;17563  ;
;17564  ;               IDC3. Select BEN1/ONLINE H.
;17565  ;               IDC4. If ONLINE H is asserted, then increment the DAR.
;17566  ;               IDC5. Issue XFER REQ to flag the CPU.
;17567  ;
;17568  ;       13. Wait for a XFER REQ from IDC.
;17569  ;       14. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;17570  ;       15. Check the DAR = 0.
;17571  ;       16. Move the next drive number to WR[2] and perform Steps 11 - 16
;17572  ;           until all the drives have been checked.
;17573  ;       17. Increment the error number.
;17574  ;       18. Clear the DAR.
;17575  ;       19. Set WR[2] = 0.
;17576  ;       20. Move WR[2] to CSR <DS1><DS0>.
;17577  ;       21. Set up the CSR to branch to the correct microcode routine.
;17578  ;
;17579  ;                                       *******
;17580  ;                                       * IDC *
;17581  ;                                       *******
;17582  ;
;17583  ;               IDC6. Set FUNC BITS <35:32> = A, SET.ONLINE.
;17584  ;
;17585  ;       22. Wait for XFER.REQ from the IDC.
;17586  ;       23. Clear CSR F<2:0> and issue XFER GRANT to clear the XFER.REQ.
;17587  ;       24. Set up the CSR to branch to the correct IDC routine.
;17588  ;
;17589  ;                                       *******
;17590  ;                                       * IDC *
;17591  ;                                       *******
;17592  ;
;17593  ;               IDC7. Select BEN1/ONLINE H.
;17594  ;               IDC8. If ONLINE H is asserted then increment the DAR.
;17595  ;               IDC9. Issue XFER REQ to flag the CPU and go to DIAG.WAIT.
;17596  ;
;17597  ;       25. Wait for XFER.REQ from the IDC.
;17598  ;       26. Clear CSR F<2:0> and issue XFER GRANT to clear the XFER.REQ.
;17599  ;       27. Check the DAR = 1.
;17600  ;       28. Increment the error number.
;17601  ;       29. Check that all the other drives remained cleared.
;17602  ;       30. Increment the error number.
;17603  ;       31. Move WR[2] to CSR <DS1> <DS0>.
;17604  ;       32. Clear the DAR.
;17605  ;       33. Set up the CSR to branch to the correct microcode routine.
;17606  ;
;17607  ;                                       *******
;17608  ;                                       * IDC *
;17609  ;                                       *******
;17610  ;
```

```
;17611  ;
;17612  ;                IDC10. Set FUNC BITS <35:32> = 9, CLR.ONLINE.
;17613  ;
;17614  ;
;17615  ;       34. Wait for a XFER REQ from IDC.
;17616  ;       35. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;17617  ;       36. Set up the CSR to branch to the correct microcode routine.
;17618  ;
;17619  ;                                       *******
;17620  ;                                       * IDC *
;17621  ;                                       *******
;17622  ;
;17623  ;
;17624  ;                IDC11. Select BEN1/ONLINE H.
;17625  ;                IDC12. If ONLINE H is asserted, then increment the DAR.
;17626  ;                IDC13. Issue XFER REQ to flag the CPU.
;17627  ;
;17628  ;       37. Wait for a XFER REQ from IDC.
;17629  ;       38. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;17630  ;       39. Check the DAR = 0.
;17631  ;       40. Move the next drive number to WR[2] and perform Steps 20 - 40
;17632  ;           until all drives have been checked.
;17633  ;       41. Clear IDC.
;17634  ;       42. End test.
;17635  ;
;17636  ;
;17637  ; Errors:
;17638  ;
;17639  ;                 Printout:
;17640  ;                         EXPECTED          RECEIVED          OTHER DATA
;17641  ;                           DAR               DAR             Drive Number
;17642  ;
;17643  ;       ERROR 1 - The drive indicated by WR[2] was not cleared online.
;17644  ;
;17645  ;       ERROR 2 - The drive number in OTHER DATA was not set online when
;17646  ;                 selected by CSR<9:8> and USET.ONLINE was asserted.
;17647  ;
;17648  ;       ERROR 3 - The drive number in OTHER DATA was set online when another
;17649  ;                  drive number was selected.
;17650  ;
;17651  ;       ERROR 4 - The drive number in OTHER DATA was not cleared online when
;17652  ;                 selected by CSR <9:8> and CLR.ONLINE was asserted.
;17653  ;
;17654  ; Debug:
;17655  ;
;17656  ; ERROR 1:
;17657  ;
;17658  ;       The Drive Number which is being selected is put is CSR<9:8>. These
;17659  ;       bits are DS1 H AND DS0 H. These bits are inputs to the DR SEL LOG
;17660  ;       PAL and because USEL DRV H = L, these bits are output asDRIVE SEL 1
;17661  ;       and DRIVE SEL 0. DRIVE SEL <1:0> are inputs to the ONLINE REG PAL.
;17662  ;       CSR bits <9:8> are first written = [00] to select drive 0. Then the IDC
;17663  ;       microcode branches to a FUNC/CLR.ONLINE instruction. the outputs of the
;17664  ;       microsequencer will be:
;17665  ;                UFUNC 3 H = H
```

```
;17666  ;                UFUNC 2 H = L
;17667  ;                UFUNC 1 H = L
;17668  ;                UFUNC 0 H = H
;17669  ;        These bits are decoded and will assert UCLR ONLINE which is an input
;17670  ;        to the ONLINE REG PAL. At the next P2 CLOCK L, ONLINE 0 L will be
;17671  ;        negated.
;17672  ;        The same sequence is repeated to clear online for each drive.
;17673  ;        The DAR is cleared.
;17674  ;        Then Drive 0 is again selected. When Drive 0 is selected at the ONLINE
;17675  ;        REG PAL, output ONLINE H will reflect ONLINE 0 L. The IDC microcode
;17676  ;        will then branch to an instruction that selects BEN1/DRIVE.ONLINE.
;17677  ;        The outputs of the microsequencer will be:
;17678  ;                BEN1 S2 H = H
;17679  ;                BEN1 S1 H = H
;17680  ;                BEN1 S0 H = L
;17681  ;        These bits will output ONLINE H = L as NUA 1 H. The IDC microcode
;17682  ;        will branch to an instruction that will send XFER REQ to flag the
;17683  ;        CPU and will NOT increment the DAR. The CPU will then read and check
;17684  ;        the DAR = 0.
;17685  ;        Each drive is then checked to insure that each is cleared online.
;17686  ;
;17687  ; ERROR 2:
;17688  ;        Drive 0 is selected by CSR <9:8> (see ERROR 1).
;17689  ;        The IDC microcode will branch to a FUNC/SET.ONLINE instruction.
;17690  ;        The outputs of the microsequencer will be:
;17691  ;                FUNC 3 H = H
;17692  ;                FUNC 2 H = L
;17693  ;                FUNC 1 H = H
;17694  ;                FUNC 0 H = L
;17695  ;        These bits are decoded are will assert USET ONLINE L which is an
;17696  ;        input to the ONLINE REG PAL. At the next P2 CLOCK L, ONLINE 0 L will
;17697  ;        assert and approximately 20ns later ONLINE H will assert. The IDC
;17698  ;        microcode will then branch to an instruction that selects
;17699  ;        BEN1/DRIVE.ONLINE. The outputs of the microsequencer will be:
;17700  ;                BEN1 S2 H = H
;17701  ;                BEN1 S1 H = H
;17702  ;                BEN1 S0 H = L
;17703  ;        These bits will output ONLINE H = H as NUA 1 H. The IDC microcode
;17704  ;        will branch to an instruction that will increment the DAR and then
;17705  ;        send XFER REQ to flag the CPU. The CPU will then read and check
;17706  ;        the DAR = 1.
;17707  ; ERROR 3:
;17708  ;        Each of the other drives is then checked to insure that each remained
;17709  ;        cleared online after ERROR 2.
;17710  ;
;17711  ; ERROR 4:
;17712  ;        The DAR is cleared.
;17713  ;        Drive 0 is selected (See ERROR 1).  The IDC
;17714  ;        microcode branches to a FUNC/CLR.ONLINE instruction. the outputs of the
;17715  ;        microsequencer will be:
;17716  ;                UFUNC 3 H = H
;17717  ;                UFUNC 2 H = L
;17718  ;                UFUNC 1 H = L
;17719  ;                UFUNC 0 H = H
;17720  ;        These bits are decoded and will assert UCLR ONLINE which is an input
```

```
                ;17721  ;       to the ONLINE REG PAL. At the next P2 CLOCK L, ONLINE 0 L will be
                ;17722  ;       negated. Approximately 20ns later ONLINE H will be negated.
                ;17723  ;       The IDC microcode will then branch to an instruction that selects
                ;17724  ;       BEN1/DRIVE.ONLINE. The outputs of the microsequencer will be:
                ;17725  ;               BEN1 S2 H = H
                ;17726  ;               BEN1 S1 H = H
                ;17727  ;               BEN1 S0 H = L
                ;17728  ;       These bits will output ONLINE H = L as NUA 1 H. The IDC microcode
                ;17729  ;       will branch to an instruction that will send XFER REQ to flag the CPU
                ;17730  ;       amd will NOT increment the DAR. The CPU will then read and check
                ;17731  ;       the DAR = 0.
                ;17732  ;
                ;17733  ;       The above sequence of ERRORS 2, 3, and 4 will be repeated with the
                ;17734  ;       drive number that is selected in OTHER.DATA.
                ;17735  ;
                ;17736  ;--
                ;17737  ;*******************************************************************************
                ;17738  T.1B:
U OFF4, B65E,15 ;17739          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;17740                                                  ; CONTROL AND STATUS WORD
U OFF5, 3E80,15 ;17741          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;17742                                                  ; STATUS WORD - BIT 15
                ;17743                                                  ; INDICATES START OF TEST TO
                ;17744                                                  ; CONSOLE
U OFF6, 10E0,15 ;17745          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;17746  WAIT.T1B.0:
U OFF7, 08FF,74 ;17747          JMP [WAIT.T1B.0]                        ;LOOP HERE WAITING FOR
                ;17748                                                  ; CONSOLE TO RESPOND
                ;17749
U OFF8, 65A0,15 ;17750          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;17751                                                  ; IN LS
                ;17752
U OFF9, B64A,15 ;17753          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U OFFA, 3E8C,15 ;17754          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;17755
                ;17756
U OFFB, B640,15 ;17757          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U OFFC, BE82,15 ;17758          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;17759
U OFFD, 3776,15 ;17760          MOV LS[DAR.MASK] TO WR[0]               ;SET UP THE MASK FOR BITS
U OFFE, 3E8A,15 ;17761          MOV WR[0] TO LS[ERROR.MASK]             ; <18:0>
                ;17762
U OFFF, B670,15 ;17763          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP SO OTHER DATA WILL
U 1000, 3E80,15 ;17764          MOV WR[C] TO LS[CONTROL.STATUS]         ; PRINT
                ;17765
U 1001, 8872,EC ;17766          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;17767
                ;17768
U 1002, 2F85,15 ;17769          CLR WR[2]                               ;USED AS THE DRIVE NUM COUNTER
                ;17770  CLR.DRIVES.T1B:
U 1003, 2004,15 ;17771          MOV WR[2] TO WR[0]                      ;SHIFT THE DRIVE NUMBER INTO
U 1004, 3646,95 ;17772          MOV LS[#8] TO WR[1]                     ; BITS <9:8> TO WRITE TO THE
                ;17773  SHIFT.T1B.1:                                    ; CSR
U 1005, 23D0,15 ;17774          ASHL WR[0]
                ;17775          DEC WR[1],
```

```
U 1006, A102,B5 ;17776          DT(LONG)&SET.ALU.CC
U 1007, 0900,51 ;17777          JMP.IF[NEQ] TO [SHIFT.T1B.1]          ;WR[0] CONTAINS DR NUM IN<9:8>
                ;17778
U 1008, B720,95 ;17779          MOV LS[SETCSR.MAINT] TO WR[1]         ;SET UP THE CSR TO BRANCH TO
U 1009, AEC2,15 ;17780          BIS WR[1] TO WR[0]                    ; THE IDC ROUTINE THAT WILL
U 100A, 370A,95 ;17781          MOV LS[SETCSR.F5] TO WR[1]            ; CLR ONLINE AND THEN SEND
U 100B, AEC2,15 ;17782          BIS WR[1] TO WR[0]                    ; XFER REQ
U 100C, 17A0,15 ;17783          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;WRITE THE CSR
                ;17784                                                ;MAINT=1,CRDY=0,F<2:0>=101
                ;17785  ;UCLR ONLINE
                ;17786  ;-------------------------------------------------------------------------
                ;17787  ;-------------------------------------------------------------------------
                ;17788  ;                               *******
                ;17789  ;                               * IDC *
                ;17790  ;                               *******
                ;17791  ;-------------------------------------------------------------------------
                ;17792  ;018:
                ;17793  ;=000
                ;17794  ;DIAG.IDLE:
                ;17795  ;
                ;17796  ;       BEN0/F0,
                ;17797  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;17798  ;       BEN2/F2,
                ;17799  ;       NAD/DIAG.IDLE
                ;17800  ;-------------------------------------------------------------------------
                ;17801  ;01D:
                ;17802  ;=101
                ;17803  ;
                ;17804  ;       BEN0/CRDY.L,
                ;17805  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;17806  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;17807  ;-------------------------------------------------------------------------
                ;17808  ;075:
                ;17809  ;=1*1
                ;17810  ;TEST.F5:
                ;17811  ;
                ;17812  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;17813  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;17814  ;
                ;17815  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;17816  ;                                       ; MUST USEL FIFO A)
                ;17817  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;17818  ;                                       ; AND DIAG.IDLE
                ;17819  ;-------------------------------------------------------------------------
                ;17820  ;1D8:
                ;17821  ;XFER.REQ:
                ;17822  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;17823  ;       NAD/DIAG.WAIT
                ;17824  ;-------------------------------------------------------------------------
                ;17825  ;1D7:
                ;17826  ;DIAG.WAIT:
                ;17827  ;
                ;17828  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;17829  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;17830  ;-------------------------------------------------------------------------
```

```
                ;17831  ;159:
                ;17832  ;=*0*
                ;17833  ;DIAG.WAIT1:
                ;17834  ;
                ;17835  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;17836  ;                               ; COMMAND FROM THE CPU
                ;17837  ;-------------------------------------------------------------------------
                ;17838  ;15B:
                ;17839  ;=*1*
                ;17840  ;DIAG.WAIT2:
                ;17841  ;
                ;17842  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;17843  ;                               ; WAIT SOME MORE
                ;17844  ;-------------------------------------------------------------------------
                ;17845  WAIT.IDC.T1B.1:
U 100D, DB00,1A ;17846          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 100E, 8901,04 ;17847          JMP [IDC.DONE.T1B.1]                    ;IDC DONE
U 100F, 8900,D4 ;17848          JMP [WAIT.IDC.T1B.1]                    ;WAIT SOME MORE
                ;17849
                ;17850  IDC.DONE.T1B.1:
U 1010, B700,15 ;17851          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 1011, 17A0,15 ;17852          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1012, 90FA,15 ;17853          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;17854
U 1013, 2045,15 ;17855          INC WR[2]                               ;INC THE DRIVE NUMBER
                ;17856          CMP WR[2] WITH LS[#4],                  ;LAST DRIVE BEEN CLEARED?
U 1014, CF45,35 ;17857           DT(LONG)&SET.ALU.CC
U 1015, 0900,31 ;17858          JMP.IF[NEQ] TO [CLR.DRIVES.T1B]         ;JMP IF NOT DONE
                ;17859
                ;17860  ;ALL DRIVES <3:0> SHOULD NOW HAVE ONLINE CLEARED
                ;17861
U 1016, 2F85,15 ;17862          CLR WR[2]                               ;DRIVE NUM = 0
                ;17863
                ;17864  TEST.DR.CLR.T1B:
U 1017, 2004,15 ;17865          MOV WR[2] TO WR[0]                      ;SHIFT THE DRIVE NUMBER INTO
U 1018, 3646,95 ;17866          MOV LS[#8] TO WR[1]                     ; BITS <9:8> TO WRITE TO THE
                ;17867  SHIFT.T1B.2:                                    ; CSR
U 1019, 23D0,15 ;17868          ASHL WR[0]
                ;17869          DEC WR[1],
U 101A, A102,B5 ;17870           DT(LONG)&SET.ALU.CC
U 101B, 8901,91 ;17871          JMP.IF[NEQ] TO [SHIFT.T1B.2]            ;WR[0] CONTAINS DR NUM IN<9:8>
U 101C, A001,95 ;17872          MOV WR[0] TO WR[3]                      ;SAVE THE INFO
                ;17873  LOOP.T1B.1:
U 101D, 2F80,15 ;17874          CLR WR[0]
U 101E, 97A4,15 ;17875          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                ;17876
U 101F, 3712,95 ;17877          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1020, B70A,15 ;17878          MOV LS[SETCSR.F5] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 1021, AEC2,15 ;17879          BIS WR[1] TO WR[0]                      ; SELECT BEN1/ONLINE
U 1022, 2EC6,15 ;17880          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE NUMBER
U 1023, 17A0,15 ;17881          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;17882                                                  ;MAINT=0,CRDY=1,F<2:0>=101
                ;17883  ;SELECT BEN1/DRIVE.ONLINE
                ;17884  ;-------------------------------------------------------------------------
                ;17885  ;-------------------------------------------------------------------------
```

```
;17886  ;                                       *******
;17887  ;                                       * IDC *
;17888  ;                                       *******
;17889  ;-------------------------------------------------------------------------
;17890  ;018:
;17891  ;=000
;17892  ;DIAG.IDLE:
;17893  ;
;17894  ;       BEN0/F0,
;17895  ;       BEN1/F1,                        ;BRANCH ON THE CSR F<2:0> BITS
;17896  ;       BEN2/F2,
;17897  ;       NAD/DIAG.IDLE
;17898  ;-------------------------------------------------------------------------
;17899  ;01D:
;17900  ;=101
;17901  ;
;17902  ;       BEN0/CRDY.L,
;17903  ;       BEN2/MAINT,                     ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;17904  ;       NAD/TEST.FUNC5                  ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;17905  ;-------------------------------------------------------------------------
;17906  ;070:
;17907  ;=0*0
;17908  ;TEST.FUNC5:
;17909  ;
;17910  ;ONLINETST1.1:
;17911  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
;17912  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
;17913  ;-------------------------------------------------------------------------
;17914  ;191:
;17915  ;=0*
;17916  ;ONLINETST1.2:
;17917  ;
;17918  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
;17919  ;-------------------------------------------------------------------------
;17920  ;193:
;17921  ;=1*
;17922  ;ONLINETST1.3:
;17923  ;
;17924  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
;17925  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
;17926  ;-------------------------------------------------------------------------
;17927  ;1D8:
;17928  ;XFER.REQ:
;17929  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;17930  ;       NAD/DIAG.WAIT
;17931  ;-------------------------------------------------------------------------
;17932  ;1D7:
;17933  ;DIAG.WAIT:
;17934  ;
;17935  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;17936  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;17937  ;-------------------------------------------------------------------------
;17938  ;159:
;17939  ;=*0*
;17940  ;DIAG.WAIT1:
```

```
                    ;17941  ;
                    ;17942  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;17943  ;                               ; COMMAND FROM THE CPU
                    ;17944  ;-------------------------------------------------------------------------
                    ;17945  ;15B:
                    ;17946  ;=*1*
                    ;17947  ;DIAG.WAIT2:
                    ;17948  ;
                    ;17949  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;17950  ;                               ; WAIT SOME MORE
                    ;17951  ;-------------------------------------------------------------------------
                    ;17952  WAIT.IDC.T1B.2:
U 1024, DB00,1A     ;17953          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1025, 0902,74     ;17954          JMP [IDC.DONE.T1B.2]                    ;IDC DONE
U 1026, 0902,44     ;17955          JMP [WAIT.IDC.T1B.2]                    ;WAIT SOME MORE
                    ;17956
                    ;17957  IDC.DONE.T1B.2:
U 1027, B700,15     ;17958          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 1028, 17A0,15     ;17959          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1029, 90FA,15     ;17960          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                    ;17961
                    ;17962  READ.DAR.T1B.1:
U 102A, 9090,15     ;17963          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 102B, 1784,15     ;17964          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 102C, 3B32,15     ;17965          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;17966                                                  ; SAVE IT IN LS
U 102D, 3E89,15     ;17967          MOV WR[2] TO LS[ADDRESS.DATA]           ;SET UP DR NUM FOR PRINTOUT
                    ;17968
U 102E, 3732,15     ;17969          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 102F, 2F82,95     ;17970          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1030, 0869,3C     ;17971          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1031, 0901,D4     ;17972          JMP [LOOP.T1B.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;17973
U 1032, 2045,15     ;17974          INC WR[2]                               ;NEXT DRIVE NUM
                    ;17975          CMP WR[2] WITH LS[#4],                  ;LAST DRIVE BEEN TESTED?
U 1033, CF45,35     ;17976           DT(LONG)&SET.ALU.CC
U 1034, 0901,71     ;17977          JMP.IF[NEQ] TO [TEST.DR.CLR.T1B]        ;JMP IF NOT LAST
                    ;17978
                    ;17979
                    ;17980
U 1035, 2F85,15     ;17981          CLR WR[2]                               ;CLR THE DRIVE NUMBER
                    ;17982  CHECK.DR.SET.T1B:
U 1036, 2004,15     ;17983          MOV WR[2] TO WR[0]                      ;SHIFT THE DRIVE NUMBER INTO
U 1037, 3646,95     ;17984          MOV LS[#8] TO WR[1]                     ; BITS <9:8> TO WRITE TO THE
                    ;17985  SHIFT.T1B.3:                                    ; CSR
U 1038, 23D0,15     ;17986          ASHL WR[0]
                    ;17987          DEC WR[1],
U 1039, A102,B5     ;17988           DT(LONG)&SET.ALU.CC
U 103A, 8903,81     ;17989          JMP.IF[NEQ] TO [SHIFT.T1B.3]            ;WR[0] CONTAINS DR NUM IN<9:8>
U 103B, A001,95     ;17990          MOV WR[0] TO WR[3]                      ;SAVE DR NUM IN BITS<9:8>
                    ;17991
                    ;17992  LOOP.T1B.2:
U 103C, 2F80,15     ;17993          CLR WR[0]
U 103D, 97A4,15     ;17994          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                    ;17995
```

```
U 103E, B720,95 ;17996          MOV LS[SETCSR.MAINT] TO WR[1]          ;SET UP THE CSR TO BRANCH TO
U 103F, 370E,15 ;17997          MOV LS[SETCSR.F7] TO WR[0]             ; BRANCH TO THE IDC ROUTINE
U 1040, AEC2,15 ;17998          BIS WR[1] TO WR[0]                     ; THAT WILL SET ONLINE
U 1041, 2EC6,15 ;17999          BIS WR[3] TO WR[0]
U 1042, 17A0,15 ;18000          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]   ;WRITE THE CSR
                ;18001                                                 ;MAINT=1,CRDY=0,F<2:0>=111
                ;18002  ;USET ONLINE
                ;18003  ;-------------------------------------------------------------------------
                ;18004  ;-------------------------------------------------------------------------
                ;18005  ;                              *******
                ;18006  ;                              * IDC *
                ;18007  ;                              *******
                ;18008  ;-------------------------------------------------------------------
                ;18009  ;018:
                ;18010  ;=000
                ;18011  ;DIAG.IDLE:
                ;18012  ;
                ;18013  ;       BEN0/F0,
                ;18014  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;18015  ;       BEN2/F2,
                ;18016  ;       NAD/DIAG.IDLE
                ;18017  ;-------------------------------------------------------------------
                ;18018  ;01F:
                ;18019  ;=111
                ;18020  ;
                ;18021  ;       BEN0/CRDY.L,
                ;18022  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;18023  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;18024  ;-------------------------------------------------------------------
                ;18025  ;07D:
                ;18026  ;=1*1
                ;18027  ;TEST.F7:
                ;18028  ;
                ;18029  ;       FUNC/SET.ONLINE,                ;SET ONLINE THE DRIVE SELECTED BY
                ;18030  ;                                       ; DRIVE SEL <1:0> (FOR ONLINE TESTS)
                ;18031  ;
                ;18032  ;       LOAD.LOOP.CNTR.[OFF],           ;LOAD LOOP CNTR = FF (FOR LP CNTR TST)
                ;18033  ;
                ;18034  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;18035  ;                                       ; AND DIAG.IDLE
                ;18036  ;-------------------------------------------------------------------
                ;18037  ;1D8:
                ;18038  ;XFER.REQ:
                ;18039  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18040  ;       NAD/DIAG.WAIT
                ;18041  ;-------------------------------------------------------------------
                ;18042  ;1D7:
                ;18043  ;DIAG.WAIT:
                ;18044  ;
                ;18045  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18046  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18047  ;-------------------------------------------------------------------
                ;18048  ;159:
                ;18049  ;=*0*
                ;18050  ;DIAG.WAIT1:
```

```
                ;18051  ;
                ;18052  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;18053  ;                               ; COMMAND FROM THE CPU
                ;18054  ;-------------------------------------------------------------------------
                ;18055  ;15B:
                ;18056  ;=*1*
                ;18057  ;DIAG.WAIT2:
                ;18058  ;
                ;18059  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18060  ;                               ; WAIT SOME MORE
                ;18061  ;-------------------------------------------------------------------------
                ;18062  WAIT.IDC.T1B.3:
U 1043, DB00,1A ;18063          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1044, 8904,64 ;18064          JMP [IDC.DONE.T1B.3]                    ;IDC DONE
U 1045, 8904,34 ;18065          JMP [WAIT.IDC.T1B.3]                    ;WAIT SOME MORE
                ;18066
                ;18067  IDC.DONE.T1B.3:
U 1046, B700,15 ;18068          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 1047, 17A0,15 ;18069          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1048, 90FA,15 ;18070          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18071
U 1049, B712,15 ;18072          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 104A, 370A,95 ;18073          MOV LS[SETCSR.F5] TO WR[1]              ; THE IDC ROUTINE THAT WILL
U 104B, AEC2,15 ;18074          BIS WR[1] TO WR[0]                      ; SEL BEN1/ONLINE AND INCR DAR
                ;18075                                                  ; IF IT IS ASSERTED
U 104C, 2EC6,15 ;18076          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE NUMBER WR[3]
U 104D, 17A0,15 ;18077          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;18078                                                  ;MAINT=0,CRDY=1,F<2:0>=101
                ;18079  ;SELECT BEN1/DRIVE.ONLINE
                ;18080  ;-------------------------------------------------------------------------
                ;18081  ;-------------------------------------------------------------------------
                ;18082  ;                               *******
                ;18083  ;                               * IDC *
                ;18084  ;                               *******
                ;18085  ;-------------------------------------------------------------------------
                ;18086  ;018:
                ;18087  ;=000
                ;18088  ;DIAG.IDLE:
                ;18089  ;
                ;18090  ;       BEN0/F0,
                ;18091  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;18092  ;       BEN2/F2,
                ;18093  ;       NAD/DIAG.IDLE
                ;18094  ;-------------------------------------------------------------------------
                ;18095  ;01D:
                ;18096  ;=101
                ;18097  ;
                ;18098  ;       BEN0/CRDY.L,
                ;18099  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;18100  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;18101  ;-------------------------------------------------------------------------
                ;18102  ;070:
                ;18103  ;=0*0
                ;18104  ;TEST.FUNC5:
                ;18105  ;
```

```
                ;18106  ;ONLINETST1.1:
                ;18107  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
                ;18108  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
                ;18109  ;-------------------------------------------------------------------------
                ;18110  ;191:
                ;18111  ;=0*
                ;18112  ;ONLINETST1.2:
                ;18113  ;
                ;18114  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
                ;18115  ;-------------------------------------------------------------------------
                ;18116  ;193:
                ;18117  ;=1*
                ;18118  ;ONLINETST1.3:
                ;18119  ;
                ;18120  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
                ;18121  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
                ;18122  ;-------------------------------------------------------------------------
                ;18123  ;1D8:
                ;18124  ;XFER.REQ:
                ;18125  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18126  ;       NAD/DIAG.WAIT
                ;18127  ;-------------------------------------------------------------------------
                ;18128  ;1D7:
                ;18129  ;DIAG.WAIT:
                ;18130  ;
                ;18131  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18132  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18133  ;-------------------------------------------------------------------------
                ;18134  ;159:
                ;18135  ;=*0*
                ;18136  ;DIAG.WAIT1:
                ;18137  ;
                ;18138  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;18139  ;                               ; COMMAND FROM THE CPU
                ;18140  ;-------------------------------------------------------------------------
                ;18141  ;15B:
                ;18142  ;=*1*
                ;18143  ;DIAG.WAIT2:
                ;18144  ;
                ;18145  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18146  ;                               ; WAIT SOME MORE
                ;18147  ;-------------------------------------------------------------------------
                ;18148  WAIT.IDC.T1B.4:
U 104E, DB00,1A ;18149          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 104F, 8905,14 ;18150          JMP [IDC.DONE.T1B.4]                    ;IDC DONE
U 1050, 0904,E4 ;18151          JMP [WAIT.IDC.T1B.4]                    ;WAIT SOME MORE
                ;18152
                ;18153  IDC.DONE.T1B.4:
U 1051, B700,15 ;18154          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 1052, 17A0,15 ;18155          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1053, 90FA,15 ;18156          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18157
                ;18158  READ.DAR.T1B.4:
U 1054, 9090,15 ;18159          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1055, 1784,15 ;18160          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
```

```
U 1056, 3B32,15 ;18161          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;18162                                                      ; SAVE IT IN LS
U 1057, 3E89,15 ;18163          MOV WR[2] TO LS[ADDRESS.DATA]               ;SET UP DRIVE NUM FOR PRINTOUT
U 1058, 3642,15 ;18164          MOV LS[#2] TO WR[0]
U 1059, BE82,15 ;18165          MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP FOR ERROR 2
                ;18166
U 105A, 3732,15 ;18167          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 105B, 3640,95 ;18168          MOV LS[#1] TO WR[1]                         ;SET UP EXPECTED DATA
U 105C, 0869,3C ;18169          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 105D, 0903,C4 ;18170          JMP [LOOP.T1B.2]                            ;LOOP HERE IF ERR & LOE IS SET
                ;18171
U 105E, 2F80,15 ;18172          CLR WR[0]
U 105F, 97A4,15 ;18173          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;CLR THE DAR
                ;18174
U 1060, B788,15 ;18175          MOV LS[#3] TO WR[0]
U 1061, BE82,15 ;18176          MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP ERROR 3
                ;18177
                ;18178
U 1062, BE11,15 ;18179          MOV WR[2] TO LS[T8]                         ;GET THE DRIVE NUMBER
                ;18180  CHECK.NEXT.DR.T1B:
U 1063, 7F10,15 ;18181          INC LS[T8]                                  ;NEXT DRIVE NUMBER
U 1064, 3610,95 ;18182          MOV LS[T8] TO WR[1]                         ;MOV TO MASK BITS
U 1065, B79A,15 ;18183          MOV LS[#FFFFFFFC] TO WR[0]                  ;GET THE MASK
U 1066, AF40,95 ;18184          BIC WR[0] TO WR[1]                          ;MASK ALL EXCEPT BITS <1:0>
                ;18185                                                      ; BECAUSE CHECKING DRIVES <3:0>
U 1067, BE10,95 ;18186          MOV WR[1] TO LS[T8]                         ;SAVE IN LS[T8]
                ;18187          CMP LS[T8] WITH WR[2],                      ;ALL DRIVES BEEN CHECKED?
U 1068, CE11,35 ;18188           DT(LONG)&SET.ALU.CC
U 1069, 8908,79 ;18189          JMP.IF[EQL] TO [DONE.CHK.CLR.T1B]           ;YES..JMP
U 106A, A006,15 ;18190          MOV WR[3] TO WR[0]                          ;WR[3] HAS DR NUM BITS <9:8>
U 106B, C050,15 ;18191          ADD LS[#100] TO WR[0]                       ;INC THE DRIVE NUM
                ;18192
U 106C, B798,95 ;18193          MOV LS[#FFFFFCFF] TO WR[1]
U 106D, AF42,15 ;18194          BIC WR[1] TO WR[0]                          ;CHECKING DRIVES <3:0>
                ;18195                                                      ;WR[0] NOW HAS NEW DRIVE NUM
                ;18196                                                      ; IN BITS <9:8>
U 106E, BE12,15 ;18197          MOV WR[0] TO LS[T9]                         ;SAVE IT
U 106F, 3712,95 ;18198          MOV LS[SETCSR.CRDY] TO WR[1]                ;SET UP THE CSR TO BRANCH TO
U 1070, AEC2,15 ;18199          BIS WR[1] TO WR[0]                          ; THE IDC ROUTINE THAT WILL
U 1071, 370A,95 ;18200          MOV LS[SETCSR.F5] TO WR[1]                  ; SEL BEN1/ONLINE AND INCR DAR
U 1072, AEC2,15 ;18201          BIS WR[1] TO WR[0]                          ; IF ASSERTED
U 1073, BE14,15 ;18202          MOV WR[0] TO LS[T10]                        ;SAVE INFO IN LS[T10]
                ;18203
U 1074, 4778,15 ;18204          BIS LS[BIT28] TO WR[0]                      ;SET THE TIMEOUT INHIBIT BIT
U 1075, 17A0,15 ;18205          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;18206                                                      ;MAINT=0,CRDY=1,F<2:0>=101
                ;18207  ;SELECT BEN1/DRIVE.ONLINE
                ;18208  ;-------------------------------------------------------------------------------
                ;18209  ;-------------------------------------------------------------------------------
                ;18210  ;                                  *******
                ;18211  ;                                  * IDC *
                ;18212  ;                                  *******
                ;18213  ;-------------------------------------------------------------------------------
                ;18214  ;018:
                ;18215  ;=000
```

```
;18216  ;DIAG.IDLE:
;18217  ;
;18218  ;       BEN0/F0,
;18219  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;18220  ;       BEN2/F2,
;18221  ;       NAD/DIAG.IDLE
;18222  ;-----------------------------------------------------------------------
;18223  ;01D:
;18224  ;=101
;18225  ;
;18226  ;       BEN0/CRDY.L,
;18227  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;18228  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;18229  ;-----------------------------------------------------------------------
;18230  ;070:
;18231  ;=0*0
;18232  ;TEST.FUNC5:
;18233  ;
;18234  ;ONLINETST1.1:
;18235  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
;18236  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
;18237  ;-----------------------------------------------------------------------
;18238  ;191:
;18239  ;=0*
;18240  ;ONLINETST1.2:
;18241  ;
;18242  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
;18243  ;-----------------------------------------------------------------------
;18244  ;193:
;18245  ;=1*
;18246  ;ONLINETST1.3:
;18247  ;
;18248  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
;18249  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
;18250  ;-----------------------------------------------------------------------
;18251  ;1D8:
;18252  ;XFER.REQ:
;18253  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;18254  ;       NAD/DIAG.WAIT
;18255  ;-----------------------------------------------------------------------
;18256  ;1D7:
;18257  ;DIAG.WAIT:
;18258  ;
;18259  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;18260  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;18261  ;-----------------------------------------------------------------------
;18262  ;159:
;18263  ;=*0*
;18264  ;DIAG.WAIT1:
;18265  ;
;18266  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;18267  ;                               ; COMMAND FROM THE CPU
;18268  ;-----------------------------------------------------------------------
;18269  ;15B:
;18270  ;=*1*
```

```
                    ;18271  ;DIAG.WAIT2:
                    ;18272  ;
                    ;18273  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;18274  ;                               ; WAIT SOME MORE
                    ;18275  ;-------------------------------------------------------------------------
                    ;18276  WAIT.IDC.T1B.5:
U 1076, DB00,1A     ;18277          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1077, 8907,94     ;18278          JMP [IDC.DONE.T1B.5]                    ;IDC DONE
U 1078, 8907,64     ;18279          JMP [WAIT.IDC.T1B.5]                    ;WAIT SOME MORE
                    ;18280
                    ;18281  IDC.DONE.T1B.5:
U 1079, B700,15     ;18282          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 107A, 17A0,15     ;18283          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 107B, 90FA,15     ;18284          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                    ;18285
                    ;18286  READ.DAR.T1B.5:
U 107C, 9090,15     ;18287          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 107D, 1784,15     ;18288          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 107E, 3B32,15     ;18289          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                    ;18290                                                  ; SAVE IT IN LS
                    ;18291
U 107F, B610,15     ;18292          MOV LS[T8] TO WR[0]                     ;GET THE DRIVE NUMBER UNDER
U 1080, BE88,15     ;18293          MOV WR[0] TO LS[ADDRESS.DATA]           ; TEST FOR PRINTOUT
U 1081, 3732,15     ;18294          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1082, 2F82,95     ;18295          CLR WR[1]                               ;SET UP THE EXPECTED DATA
U 1083, 0869,3C     ;18296          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1084, 890B,34     ;18297          JMP [LOOP.T1B.3]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;18298
                    ;18299  CONTINUE.T1B:
U 1085, 3613,95     ;18300          MOV LS[T9] TO WR[3]                     ;RESTORE DRIVE NUMBER IN BITS
                    ;18301                                                  ; <9:8> TO WR[3]
U 1086, 0906,34     ;18302          JMP [CHECK.NEXT.DR.T1B]                 ;CHECK NEXT DRIVE
                    ;18303
                    ;18304  DONE.CHK.CLR.T1B:
                    ;18305
U 1087, 3644,15     ;18306          MOV LS[#4] TO WR[0]
U 1088, BE82,15     ;18307          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP FOR ERROR 4
                    ;18308
                    ;18309
U 1089, 2004,15     ;18310          MOV WR[2] TO WR[0]                      ;SHIFT THE DR NUM TO BITS<9:8>
U 108A, 3646,95     ;18311          MOV LS[#8] TO WR[1]
                    ;18312  SHIFT.T1B.4:
U 108B, 23D0,15     ;18313          ASHL WR[0]
                    ;18314          DEC WR[1],
U 108C, A102,B5     ;18315           DT(LONG)&SET.ALU.CC
U 108D, 0908,B1     ;18316          JMP.IF[NEQ] TO [SHIFT.T1B.4]            ;WR[0] HAS DR NUM IN BITS <9:8>
                    ;18317
U 108E, A001,95     ;18318          MOV WR[0] TO WR[3]                      ;SAV THE INFO
                    ;18319
                    ;18320  LOOP.T1B.4:
U 108F, 2F80,15     ;18321          CLR WR[0]
U 1090, 97A4,15     ;18322          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                    ;18323
U 1091, 3720,15     ;18324          MOV LS[SETCSR.MAINT] TO WR[0]           ;SET UP THE CSR TO BRANCH TO
U 1092, 370A,95     ;18325          MOV LS[SETCSR.F5] TO WR[1]              ; THE IDC ROUTINE THAT WILL
```

```
U 1093, AEC2,15 ;18326          BIS WR[1] TO WR[0]                      ; CLEAR ONLINE
U 1094, 2EC6,15 ;18327          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE NUMBER
U 1095, 17A0,15 ;18328          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;18329                                                  ;MAINT=1,CRDY=0,F<2:0>=101
                ;18330  ;UCLR ONLINE
                ;18331  ;-------------------------------------------------------------------------------
                ;18332  ;-------------------------------------------------------------------------------
                ;18333  ;                                  *******
                ;18334  ;                                  * IDC *
                ;18335  ;                                  *******
                ;18336  ;-------------------------------------------------------------------------
                ;18337  ;018:
                ;18338  ;=000
                ;18339  ;DIAG.IDLE:
                ;18340  ;
                ;18341  ;       BEN0/F0,
                ;18342  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;18343  ;       BEN2/F2,
                ;18344  ;       NAD/DIAG.IDLE
                ;18345  ;-------------------------------------------------------------------------
                ;18346  ;01D:
                ;18347  ;=101
                ;18348  ;
                ;18349  ;       BEN0/CRDY.L,
                ;18350  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;18351  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;18352  ;-------------------------------------------------------------------------
                ;18353  ;075:
                ;18354  ;=1*1
                ;18355  ;TEST.F5:
                ;18356  ;
                ;18357  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;18358  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;18359  ;
                ;18360  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;18361  ;                                       ; MUST USEL FIFO A)
                ;18362  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;18363  ;                                       ; AND DIAG.IDLE
                ;18364  ;-------------------------------------------------------------------------
                ;18365  ;1D8:
                ;18366  ;XFER.REQ:
                ;18367  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18368  ;       NAD/DIAG.WAIT
                ;18369  ;-------------------------------------------------------------------------
                ;18370  ;1D7:
                ;18371  ;DIAG.WAIT:
                ;18372  ;
                ;18373  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18374  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18375  ;-------------------------------------------------------------------------
                ;18376  ;159:
                ;18377  ;=*0*
                ;18378  ;DIAG.WAIT1:
                ;18379  ;
                ;18380  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
```

```
                ;18381  ;                               ; COMMAND FROM THE CPU
                ;18382  ;-------------------------------------------------------------------------
                ;18383  ;15B:
                ;18384  ;=*1*
                ;18385  ;DIAG.WAIT2:
                ;18386  ;
                ;18387  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18388  ;                               ; WAIT SOME MORE
                ;18389  ;-------------------------------------------------------------------------
                ;18390  WAIT.IDC.T1B.6:
U 1096, DB00,1A ;18391          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1097, 0909,94 ;18392          JMP [IDC.DONE.T1B.6]                    ;IDC DONE
U 1098, 0909,64 ;18393          JMP [WAIT.IDC.T1B.6]                    ;WAIT SOME MORE
                ;18394
                ;18395  IDC.DONE.T1B.6:
U 1099, B700,15 ;18396          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 109A, 17A0,15 ;18397          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 109B, 90FA,15 ;18398          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18399
                ;18400
U 109C, 3712,95 ;18401          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 109D, B70A,15 ;18402          MOV LS[SETCSR.F5] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 109E, AEC2,15 ;18403          BIS WR[1] TO WR[0]                      ; SEL BEN1/ONLINE AND INCR DAR
                ;18404                                                  ; IF ASSERTED
U 109F, 2EC6,15 ;18405          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE NUMBER
U 10A0, 17A0,15 ;18406          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;18407                                                  ;MAINT=0,CRDY=1,F<2:0>=101
                ;18408  ;SELECT BEN1/DRIVE.ONLINE
                ;18409  ;-------------------------------------------------------------------------
                ;18410  ;-------------------------------------------------------------------------
                ;18411  ;                               *******
                ;18412  ;                               * IDC *
                ;18413  ;                               *******
                ;18414  ;-------------------------------------------------------------------------
                ;18415  ;018:
                ;18416  ;=000
                ;18417  ;DIAG.IDLE:
                ;18418  ;
                ;18419  ;       BEN0/F0,
                ;18420  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;18421  ;       BEN2/F2,
                ;18422  ;       NAD/DIAG.IDLE
                ;18423  ;-------------------------------------------------------------------------
                ;18424  ;01D:
                ;18425  ;=101
                ;18426  ;
                ;18427  ;       BEN0/CRDY.L,
                ;18428  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;18429  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;18430  ;-------------------------------------------------------------------------
                ;18431  ;070:
                ;18432  ;=0*0
                ;18433  ;TEST.FUNC5:
                ;18434  ;
                ;18435  ;ONLINETST1.1:
```

```
                ;18436  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
                ;18437  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
                ;18438  ;-------------------------------------------------------------------------
                ;18439  ;191:
                ;18440  ;=0*
                ;18441  ;ONLINETST1.2:
                ;18442  ;
                ;18443  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
                ;18444  ;-------------------------------------------------------------------------
                ;18445  ;193:
                ;18446  ;=1*
                ;18447  ;ONLINETST1.3:
                ;18448  ;
                ;18449  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
                ;18450  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
                ;18451  ;-------------------------------------------------------------------------
                ;18452  ;1D8:
                ;18453  ;XFER.REQ:
                ;18454  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18455  ;       NAD/DIAG.WAIT
                ;18456  ;-------------------------------------------------------------------------
                ;18457  ;1D7:
                ;18458  ;DIAG.WAIT:
                ;18459  ;
                ;18460  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18461  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18462  ;-------------------------------------------------------------------------
                ;18463  ;159:
                ;18464  ;=*0*
                ;18465  ;DIAG.WAIT1:
                ;18466  ;
                ;18467  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;18468  ;                               ; COMMAND FROM THE CPU
                ;18469  ;-------------------------------------------------------------------------
                ;18470  ;15B:
                ;18471  ;=*1*
                ;18472  ;DIAG.WAIT2:
                ;18473  ;
                ;18474  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18475  ;                               ; WAIT SOME MORE
                ;18476  ;-------------------------------------------------------------------------
                ;18477  WAIT.IDC.T1B.7:
U 10A1, DB00,1A ;18478          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 10A2, 890A,44 ;18479          JMP [IDC.DONE.T1B.7]                    ;IDC DONE
U 10A3, 890A,14 ;18480          JMP [WAIT.IDC.T1B.7]                    ;WAIT SOME MORE
                ;18481
                ;18482  IDC.DONE.T1B.7:
U 10A4, B700,15 ;18483          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 10A5, 17A0,15 ;18484          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 10A6, 90FA,15 ;18485          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18486
                ;18487  READ.DAR.T1B.7:
U 10A7, 9090,15 ;18488          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 10A8, 1784,15 ;18489          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 10A9, 3B32,15 ;18490          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
```

```
                    ;18491                                                  ; SAVE IT IN LS
                    ;18492
U 10AA, 3E89,15     ;18493          MOV WR[2] TO LS[ADDRESS.DATA]           ;DR NUM FOR PRINTOUT
U 10AB, 3732,15     ;18494          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 10AC, 2F82,95     ;18495          CLR WR[1]                               ;SET UP EXPECTED DATA
U 10AD, 0869,3C     ;18496          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 10AE, 8908,F4     ;18497          JMP [LOOP.T1B.4]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;18498
U 10AF, 2045,15     ;18499          INC WR[2]                               ;NEXT DRIVE NUMBER
                    ;18500          CMP WR[2] WITH LS[#4],                  ;LAST DRIVE BEEN TESTED?
U 10B0, CF45,35     ;18501           DT(LONG)&SET.ALU.CC
U 10B1, 0903,61     ;18502          JMP.IF[NEQ] TO [CHECK.DR.SET.T1B]
U 10B2, 890D,34     ;18503          JMP [CLEANUP.T1B]                       ;DONE..GO CLEANUP
                    ;18504
                    ;18505  LOOP.T1B.3:
U 10B3, B720,95     ;18506          MOV LS[SETCSR.MAINT] TO WR[1]           ;SET UP THE CSR TO BRANCH TO
U 10B4, 370E,15     ;18507          MOV LS[SETCSR.F7] TO WR[0]              ; BRANCH TO THE IDC ROUTINE
U 10B5, AEC2,15     ;18508          BIS WR[1] TO WR[0]                      ; THAT WILL SET ONLINE
U 10B6, 2EC6,15     ;18509          BIS WR[3] TO WR[0]
U 10B7, 17A0,15     ;18510          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;18511                                                  ;MAINT=1,CRDY=0,F<2:0>=111
                    ;18512  ;USET ONLINE
                    ;18513  ;-------------------------------------------------------------------------------
                    ;18514  ;-------------------------------------------------------------------------------
                    ;18515  ;                                *******
                    ;18516  ;                                * IDC *
                    ;18517  ;                                *******
                    ;18518  ;-------------------------------------------------------------------------------
                    ;18519  ;018:
                    ;18520  ;=000
                    ;18521  ;DIAG.IDLE:
                    ;18522  ;
                    ;18523  ;       BEN0/F0,
                    ;18524  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                    ;18525  ;       BEN2/F2,
                    ;18526  ;       NAD/DIAG.IDLE
                    ;18527  ;-------------------------------------------------------------------------------
                    ;18528  ;01F:
                    ;18529  ;=111
                    ;18530  ;
                    ;18531  ;       BEN0/CRDY.L,
                    ;18532  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                    ;18533  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                    ;18534  ;-------------------------------------------------------------------------------
                    ;18535  ;07D:
                    ;18536  ;=1*1
                    ;18537  ;TEST.F7:
                    ;18538  ;
                    ;18539  ;       FUNC/SET.ONLINE,                ;SET ONLINE THE DRIVE SELECTED BY
                    ;18540  ;                                       ; DRIVE SEL <1:0> (FOR ONLINE TESTS)
                    ;18541  ;
                    ;18542  ;       LOAD.LOOP.CNTR.[OFF],           ;LOAD LOOP CNTR = FF (FOR LP CNTR TST)
                    ;18543  ;
                    ;18544  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                    ;18545  ;                                       ; AND DIAG.IDLE
```

```
                ;18546  ;-------------------------------------------------------------------------
                ;18547  ;1D8:
                ;18548  ;XFER.REQ:
                ;18549  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18550  ;       NAD/DIAG.WAIT
                ;18551  ;-------------------------------------------------------------------------
                ;18552  ;1D7:
                ;18553  ;DIAG.WAIT:
                ;18554  ;
                ;18555  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18556  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18557  ;-------------------------------------------------------------------------
                ;18558  ;159:
                ;18559  ;=*0*
                ;18560  ;DIAG.WAIT1:
                ;18561  ;
                ;18562  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;18563  ;                               ; COMMAND FROM THE CPU
                ;18564  ;-------------------------------------------------------------------------
                ;18565  ;15B:
                ;18566  ;=*1*
                ;18567  ;DIAG.WAIT2:
                ;18568  ;
                ;18569  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18570  ;                               ; WAIT SOME MORE
                ;18571  ;-------------------------------------------------------------------------
                ;18572  WAIT.IDC.T1B.8:
U 10B8, DB00,1A ;18573          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 10B9, 090B,B4 ;18574          JMP [IDC.DONE.T1B.8]                    ;IDC DONE
U 10BA, 090B,84 ;18575          JMP [WAIT.IDC.T1B.8]                    ;WAIT SOME MORE
                ;18576
                ;18577  IDC.DONE.T1B.8:
U 10BB, B700,15 ;18578          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 10BC, 17A0,15 ;18579          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 10BD, 90FA,15 ;18580          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18581
U 10BE, 2F80,15 ;18582          CLR WR[0]
U 10BF, 97A4,15 ;18583          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;18584
U 10C0, 3614,15 ;18585          MOV LS[T10] TO WR[0]                    ;GET THE DATA TO WRITE THE CSR
                ;18586                                                  ; WITH THE FAILING DRIVE NUMBER
                ;18587                                                  ; AND INFO TO BRANCH TO THE
                ;18588                                                  ;CORRECT IDC ROUTINE
U 10C1, 4778,15 ;18589          BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
U 10C2, 17A0,15 ;18590          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;18591                                                  ;MAINT=0,CRDY=1,F<2:0>=101
                ;18592  ;SELECT BEN1/ONLINE
                ;18593  ;-------------------------------------------------------------------------
                ;18594  ;-------------------------------------------------------------------------
                ;18595  ;                               *******
                ;18596  ;                               * IDC *
                ;18597  ;                               *******
                ;18598  ;-------------------------------------------------------------------------
                ;18599  ;018:
                ;18600  ;=000
```

```
;18601  ;DIAG.IDLE:
;18602  ;
;18603  ;       BEN0/F0,
;18604  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;18605  ;       BEN2/F2,
;18606  ;       NAD/DIAG.IDLE
;18607  ;-------------------------------------------------------------------------
;18608  ;01D:
;18609  ;=101
;18610  ;
;18611  ;       BEN0/CRDY.L,
;18612  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;18613  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;18614  ;-------------------------------------------------------------------------
;18615  ;070:
;18616  ;=0*0
;18617  ;TEST.FUNC5:
;18618  ;
;18619  ;ONLINETST1.1:
;18620  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
;18621  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
;18622  ;-------------------------------------------------------------------------
;18623  ;191:
;18624  ;=0*
;18625  ;ONLINETST1.2:
;18626  ;
;18627  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
;18628  ;-------------------------------------------------------------------------
;18629  ;193:
;18630  ;=1*
;18631  ;ONLINETST1.3:
;18632  ;
;18633  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
;18634  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
;18635  ;-------------------------------------------------------------------------
;18636  ;1D8:
;18637  ;XFER.REQ:
;18638  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;18639  ;       NAD/DIAG.WAIT
;18640  ;-------------------------------------------------------------------------
;18641  ;1D7:
;18642  ;DIAG.WAIT:
;18643  ;
;18644  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;18645  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;18646  ;-------------------------------------------------------------------------
;18647  ;159:
;18648  ;=*0*
;18649  ;DIAG.WAIT1:
;18650  ;
;18651  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;18652  ;                               ; COMMAND FROM THE CPU
;18653  ;-------------------------------------------------------------------------
;18654  ;15B:
;18655  ;=*1*
```

```
                ;18656  ;DIAG.WAIT2:
                ;18657  ;
                ;18658  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18659  ;                               ; WAIT SOME MORE
                ;18660  ;-------------------------------------------------------------------
                ;18661  WAIT.IDC.T1B.9:
U 10C3, DB00,1A ;18662          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 10C4, 090C,64 ;18663          JMP [IDC.DONE.T1B.9]                    ;IDC DONE
U 10C5, 090C,34 ;18664          JMP [WAIT.IDC.T1B.9]                    ;WAIT SOME MORE
                ;18665
                ;18666  IDC.DONE.T1B.9:
U 10C6, B700,15 ;18667          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 10C7, 17A0,15 ;18668          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 10C8, 90FA,15 ;18669          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18670
                ;18671  READ.DAR.T1B.9:
U 10C9, 9090,15 ;18672          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 10CA, 1784,15 ;18673          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 10CB, 3B32,15 ;18674          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;18675                                                  ; SAVE IT IN LS
                ;18676
U 10CC, B610,15 ;18677          MOV LS[T8] TO WR[0]                     ;GET THE DRIVE NUMBER UNDER
U 10CD, BE88,15 ;18678          MOV WR[0] TO LS[ADDRESS.DATA]           ; TEST FOR PRINTOUT
U 10CE, 3732,15 ;18679          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 10CF, 2F82,95 ;18680          CLR WR[1]                               ;SET UP THE EXPECTED DATA
U 10D0, 0869,3C ;18681          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 10D1, 890B,34 ;18682          JMP [LOOP.T1B.3]                        ;LOOP HERE IF ERR & LOE IS SET
U 10D2, 8908,54 ;18683          JMP [CONTINUE.T1B]                      ;CONTINUE TEST
                ;18684
                ;18685  CLEANUP.T1B:
U 10D3, 8875,3C ;18686          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY THIS
                ;18687                                                  ; TEST
                ;18688
                ;18689  END.T1B:                                        ;END TEST
                ;18690
                ;18691
                ;18692
```

```
;18693  .PAGE  "Test 1C  ONLINE PAL & BRANCH TEST WITH USEL.DRV (M8388 IDC MODULE)"
;18694  ;++
;18695  ;
;18696  ; Test Description:
;18697  ;
;18698  ;       This test is designed to verify the ONLINE REGISTER PAL and a
;18699  ;       portion of the drive select logic.
;18700  ;
;18701  ;       First all of the drives will be cleared online using CSR <9:8>,
;18702  ;       (DS1, DS0) as the drive select.
;18703  ;
;18704  ;       Then Drive 0 will be selected by USEL DRV <1:0> and it will
;18705  ;       be set online. Drive 0 will then be selected by CSR <9:8>
;18706  ;       and checked that it is online.
;18707  ;       This sequence will be repeated for each drive <3:0>.
;18708  ;
;18709  ; Assumptions:
;18710  ;
;18711  ;       It is assumed that the ONLINE TEST with CSR <DS1> <DS0> has run
;18712  ;       successfully.
;18713  ;
;18714  ; Test Steps:
;18715  ;
;18716  ;       1. Set up error mask, error number and module number in LS
;18717  ;          (for error printouts) and clear the previous error number in LS.
;18718  ;       2. Force the IDC microcode to DIAG.IDLE.
;18719  ;       3. Set CSR <DS1> <DS0> = 0.
;18720  ;       4. Set up the CSR to branch to the correct microcode routine.
;18721  ;
;18722  ;                                       *******
;18723  ;                                       * IDC *
;18724  ;                                       *******
;18725  ;
;18726  ;               IDC1. Set FUNC BITS <2:0> = 9, CLR.ONLINE.
;18727  ;               IDC2. Issue XFER REQ to flag the CPU and go to DIAG.IDLE.
;18728  ;
;18729  ;       5. Wait for a XFER REQ from IDC.
;18730  ;       6. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;18731  ;       7. Move the next drive number to CSR <DS1> <DS0> and perform
;18732  ;          Steps 4 - 7 until all drives have been cleared online.
;18733  ;       8. Set WR[2] = 0 to indicate the drive number under test.
;18734  ;       9. Set up the CSR to branch to the correct microcode routine.
;18735  ;
;18736  ;                                       *******
;18737  ;                                       * IDC *
;18738  ;                                       *******
;18739  ;
;18740  ;               IDC3. Load the Loop Counter with 0.
;18741  ;
;18742  ;      10. Wait for a XFER REQ from IDC.
;18743  ;      11. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;18744  ;      12. Set up the CSR to branch to the correct microcode routine.
;18745  ;
;18746  ;
;18747  ;                                       *******
```

```
;18748  ;                                        * IDC *
;18749  ;                                        *******
;18750  ;               IDC4. Assert USEL.DRV.
;18751  ;               IDC5. Set FUNC BITS <35:32> = A, SET.ONLINE.
;18752  ;               IDC6. Issue XFER REQ and go to DIAG.IDLE.
;18753  ;
;18754  ;       13. Wait for a XFER REQ from IDC.
;18755  ;       14. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;18756  ;       15. Use CSR <DS1> <DS0> to select the drive number.
;18757  ;       16. Clear the DAR.
;18758  ;       17. Set up the CSR to branch to the correct microcode routine.
;18759  ;
;18760  ;                                        *******
;18761  ;                                        * IDC *
;18762  ;                                        *******
;18763  ;
;18764  ;               IDC7. Select BEN1/ONLINE H.
;18765  ;               IDC8. If ONLINE H is asserted then increment the DAR.
;18766  ;               IDC9. Issue XFER REQ to flag the CPU and go to DIAG.IDLE.
;18767  ;
;18768  ;       18. Wait for a XFER REQ from IDC.
;18769  ;       19. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;18770  ;       20. Check the DAR = 1.
;18771  ;       21. Set up the CSR to branch to the correct microcode routine.
;18772  ;
;18773  ;                                        *******
;18774  ;                                        * IDC *
;18775  ;                                        *******
;18776  ;
;18777  ;               IDC10. Increment the Loop Counter to select the next drive.
;18778  ;
;18779  ;       22. Wait for a XFER REQ from IDC.
;18780  ;       23. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;18781  ;       24. Increment the counter WR[2].
;18782  ;       25. Repeat Steps 12 - 25 until all drives have been tested.
;18783  ;
;18784  ; Errors:
;18785  ;
;18786  ;                       Printout:
;18787  ;                               EXPECTED        RECEIVED        OTHER DATA
;18788  ;                                 DAR             DAR             WR[2]
;18789  ;                                                                 Drive Number
;18790  ;
;18791  ;       ERROR 1 - The drive number in WR[2] was not online after USET.ONLINE
;18792  ;                  was asserted with this drive selected by USEL <1:0>.
;18793  ;
;18794  ; Debug:
;18795  ;
;18796  ; ERROR 1:
;18797  ;       All of the drives will be cleared online using CSR<9:8> as the drive
;18798  ;       select.
;18799  ;       The IDC microcode will then branch to a LOAD.LOOP.CNTR.[00]
;18800  ;       instruction. The outputs of the microsequencer will be:
;18801  ;               ULOAD LPCNTR L = L
;18802  ;
```

```
                ;18803  ;               CNST <7:0> H = L (00)
                ;18804  ;       These signals are inputs to the LOOP COUNTER. When the LOOP COUNTER
                ;18805  ;       is clocked by SEQ CLOCK H, the outputs will be:
                ;18806  ;               UDRV SEL 1 H = L
                ;18807  ;               UDRV SEL 0 H = L
                ;18808  ;       These are inputs to the DR SEL LOG PAL. The IDC microcode will
                ;18809  ;       branch to an instruction that will use these signal as the drive sel.
                ;18810  ;-------------------------------------------------------------------------------
                ;18811  ;ONLINETST2.1:
                ;18812  ;
                ;18813  ;       SEL.DRV/UPROG,                  ;USE THE LOOP COUNTER TO SELECT THE
                ;18814  ;       FUNC/SET.ONLINE,                ; DRIVE NUMBER AND SET IT ONLINE
                ;18815  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;18816  ;-------------------------------------------------------------------------------
                ;18817  ;       This will assert USEL DRV H which is an input to the DR SEL LOG PAL.
                ;18818  ;       USEL DRV H = H will select UDRV SEL 1 = L and UDRV SEL 0 = L as the
                ;18819  ;       outputs, DRIVE SEL 1 H = L and DRIVE SEL 0 H = L. These signals are
                ;18820  ;       inputs to the ONLINE REG PAL.
                ;18821  ;       The outputs of the microsequencer will be for FUNC/SET.ONLINE:
                ;18822  ;               FUNC 3 H = H
                ;18823  ;               FUNC 2 H = L
                ;18824  ;               FUNC 1 H = H
                ;18825  ;               FUNC 0 H = L
                ;18826  ;       These bits are decoded are will assert USET ONLINE L which is an
                ;18827  ;       input to the ONLINE REG PAL. At the next P2 CLOCK L, ONLINE 0 L will
                ;18828  ;       assert and approximately 20ns later ONLINE H will assert.
                ;18829  ;       The Drive number 0 will then be selected by CSR <9:8>. The IDC
                ;18830  ;       microcode will then branch to an instruction that selects
                ;18831  ;       BEN1/DRIVE.ONLINE. The outputs of the microsequencer will be:
                ;18832  ;               BEN1 S2 H = H
                ;18833  ;               BEN1 S1 H = H
                ;18834  ;               BEN1 S0 H = L
                ;18835  ;       These bits will output ONLINE H = H as NUA 1 H. The IDC microcode
                ;18836  ;       will branch to an instruction that will increment the DAR and then
                ;18837  ;       send XFER REQ to flag the CPU. The CPU will then read and check
                ;18838  ;       the DAR = 1.
                ;18839  ;
                ;18840  ;       To select the next drive to set it online, the IDC will execute,
                ;18841  ;       INCR.LPCNTR/ON. This will assert UINCR LPCNTR H which is an input
                ;18842  ;       to the LOOP COUNTER. When the LOOP COUNTER is clocked with SEQ
                ;18843  ;       CLOCK H, UDRV SEL <1:0> H will increment to the next count. These bits
                ;18844  ;       are then used to set the next drive ONLINE. The Drive Nunmber
                ;18845  ;       which is selected by UDRV SEL <1:0> will be reflected in WR[2] and
                ;18846  ;       OTHER.DATA.
                ;18847  ;
                ;18848  ;--
                ;18849  ;*******************************************************************************
                ;18850  T.1C:
U 10D4, B65E,15 ;18851          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;18852                                                  ; CONTROL AND STATUS WORD
U 10D5, 3E80,15 ;18853          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;18854                                                  ; STATUS WORD - BIT 15
                ;18855                                                  ; INDICATES START OF TEST TO
                ;18856                                                  ; CONSOLE
U 10D6, 10E0,15 ;18857          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
```

```
                ;18858  WAIT.T1C.0:
U 10D7, 090D,74 ;18859          JMP [WAIT.T1C.0]                        ;LOOP HERE WAITING FOR
                ;18860                                                  ; CONSOLE TO RESPOND
                ;18861
U 10D8, 65A0,15 ;18862          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;18863                                                  ; IN LS
                ;18864
U 10D9, B64A,15 ;18865          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 10DA, 3E8C,15 ;18866          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;18867
                ;18868
U 10DB, B640,15 ;18869          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 10DC, BE82,15 ;18870          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;18871
U 10DD, 3776,15 ;18872          MOV LS[DAR.MASK] TO WR[0]
U 10DE, 3E8A,15 ;18873          MOV WR[0] TO LS[ERROR.MASK]             ;SET UP ERROR MASK FOR THE DAR
                ;18874
U 10DF, B670,15 ;18875          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP THE CONTROL.STATUS
U 10E0, 3E80,15 ;18876          MOV WR[0] TO LS[CONTROL.STATUS]         ; TO PRINT OTHER DATA ON ERROR
                ;18877
U 10E1, 8872,EC ;18878          JSR [DIAG.CODE]
                ;18879
                ;18880  ;CLEAR ONLINE FOR ALL DRIVES <3:0>
                ;18881
U 10E2, 2F85,15 ;18882          CLR WR[2]                               ;USED AS THE DRIVE NUM COUNTER
                ;18883  CLR.DRIVES.T1C:
U 10E3, 2004,15 ;18884          MOV WR[2] TO WR[0]                      ;SHIFT THE DRIVE NUMBER INTO
U 10E4, 3646,95 ;18885          MOV LS[#8] TO WR[1]                     ; BITS <9:8> TO WRITE TO THE
                ;18886  SHIFT.T1C.1:                                    ; CSR
U 10E5, 23D0,15 ;18887          ASHL WR[0]
                ;18888          DEC WR[1],
U 10E6, A102,B5 ;18889           DT(LONG)&SET.ALU.CC
U 10E7, 890E,51 ;18890          JMP.IF[NEQ] TO [SHIFT.T1C.1]            ;WR[0] CONTAINS DR NUM IN<9:8>
                ;18891
U 10E8, B720,95 ;18892          MOV LS[SETCSR.MAINT] TO WR[1]           ;SET UP THE CSR TO BRANCH TO
U 10E9, AEC2,15 ;18893          BIS WR[1] TO WR[0]                      ; THE IDC ROUTINE THAT WILL
U 10EA, 370A,95 ;18894          MOV LS[SETCSR.F5] TO WR[1]              ; CLR ONLINE AND THEN SEND
U 10EB, AEC2,15 ;18895          BIS WR[1] TO WR[0]                      ; XFER REQ
U 10EC, 17A0,15 ;18896          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;18897                                                  ;MAINT=1,CRDY=0,F<2:0>=101
                ;18898  ;UCLR ONLINE
                ;18899  ;-------------------------------------------------------------------------------
                ;18900  ;-------------------------------------------------------------------------------
                ;18901  ;                               *******
                ;18902  ;                               * IDC *
                ;18903  ;                               *******
                ;18904  ;-------------------------------------------------------------------------------
                ;18905  ;018:
                ;18906  ;=000
                ;18907  ;DIAG.IDLE:
                ;18908  ;
                ;18909  ;       BEN0/F0,
                ;18910  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;18911  ;       BEN2/F2,
                ;18912  ;       NAD/DIAG.IDLE
```

```
                ;18913  ;-----------------------------------------------------------------------
                ;18914  ;01D:
                ;18915  ;=101
                ;18916  ;
                ;18917  ;       BEN0/CRDY.L,
                ;18918  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;18919  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;18920  ;-----------------------------------------------------------------------
                ;18921  ;075:
                ;18922  ;=1*1
                ;18923  ;TEST.F5:
                ;18924  ;
                ;18925  ;       FUNC/CLR.ONLINE,                ;CLR ONLINE FOR THE DRIVE SELECTED
                ;18926  ;                                       ; BY DRIVE SEL<1:0> (ONLINE PAL TESTS)
                ;18927  ;
                ;18928  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A (USED FOR ANY TEST WHICH
                ;18929  ;                                       ; MUST USEL FIFO A)
                ;18930  ;       NAD/XFER.REQ                    ;DO NOT INCR DAR BETWEEN HERE
                ;18931  ;                                       ; AND DIAG.IDLE
                ;18932  ;-----------------------------------------------------------------------
                ;18933  ;1D8:
                ;18934  ;XFER.REQ:
                ;18935  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;18936  ;       NAD/DIAG.WAIT
                ;18937  ;-----------------------------------------------------------------------
                ;18938  ;1D7:
                ;18939  ;DIAG.WAIT:
                ;18940  ;
                ;18941  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;18942  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;18943  ;-----------------------------------------------------------------------
                ;18944  ;159:
                ;18945  ;=*0*
                ;18946  ;DIAG.WAIT1:
                ;18947  ;
                ;18948  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;18949  ;                               ; COMMAND FROM THE CPU
                ;18950  ;---------- -----------------------------------------------------------
                ;18951  ;15B:
                ;18952  ;=*1*
                ;18953  ;DIAG.WAIT2:
                ;18954  ;
                ;18955  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;18956  ;                               ; WAIT SOME MORE
                ;18957  ;-----------------------------------------------------------------------
                ;18958  WAIT.IDC.T1C.1:
U 10ED, DB00,1A ;18959          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 10EE, 090F,04 ;18960          JMP [IDC.DONE.T1C.1]                    ;IDC DONE
U 10EF, 090E,D4 ;18961          JMP [WAIT.IDC.T1C.1]                    ;WAIT SOME MORE
                ;18962
                ;18963  IDC.DONE.T1C.1:
U 10F0, B700,15 ;18964          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 10F1, 17A0,15 ;18965          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 10F2, 90FA,15 ;18966          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;18967
```

```
U 10F3, 2045,15 ;18968          INC WR[2]                                ;INC THE DRIVE NUMBER
                ;18969          CMP WR[2] WITH LS[#4],                   ;LAST DRIVE BEEN CLEARED?
U 10F4, CF45,35 ;18970           DT(LONG)&SET.ALU.CC
U 10F5, 890E,31 ;18971          JMP.IF[NEQ] TO [CLR.DRIVES.T1C]          ;JMP IF NOT DONE
                ;18972
                ;18973  ;ALL DRIVES <3:0> SHOULD NOW HAVE ONLINE CLEARED
                ;18974
U 10F6, 2F85,15 ;18975          CLR WR[2]                                ;CLEAR THE DRIVE NUMBER
U 10F7, B720,95 ;18976          MOV LS[SETCSR.MAINT] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 10F8, B70C,15 ;18977          MOV LS[SETCSR.F6] TO WR[0]               ; THE IDC ROUTINE THAT WILL
U 10F9, AEC2,15 ;18978          BIS WR[1] TO WR[0]                       ; LOAD LPCNTR = 0(DR NUM =0)
U 10FA, 17A0,15 ;18979          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;18980                                                   ;MAINT=1,CRDY=0,F<2:0>=110
                ;18981  ;LOAD THE LOOP CNTR = 00
                ;18982  ;-------------------------------------------------------------------------
                ;18983  ;-------------------------------------------------------------------------
                ;18984  ;                               *******
                ;18985  ;                               * IDC *
                ;18986  ;                               *******
                ;18987  ;-------------------------------------------------------------------------
                ;18988  ;018:
                ;18989  ;=000
                ;18990  ;DIAG.IDLE:
                ;18991  ;
                ;18992  ;       BEN0/F0,
                ;18993  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;18994  ;       BEN2/F2,
                ;18995  ;       NAD/DIAG.IDLE
                ;18996  ;-------------------------------------------------------------------------
                ;18997  ;01E:
                ;18998  ;=110
                ;18999  ;
                ;19000  ;       BEN0/CRDY.L,
                ;19001  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;19002  ;       NAD/TEST.FUNC6           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;19003  ;-------------------------------------------------------------------------
                ;19004  ;077:
                ;19005  ;=1*1
                ;19006  ;TEST.F6:
                ;19007  ;                                ;DO NOT INCR DAR BETWEEN HERE AND
                ;19008  ;                                ; DIAG.IDLE OR DIAG.WAIT
                ;19009  ;
                ;19010  ;       LOAD.LOOP.CNTR.[00],     ;LOAD LOOP CNTR WITH 00
                ;19011  ;
                ;19012  ;       UCMD/SET.DLT,            ;SET DLT FOR DLT TEST
                ;19013  ;
                ;19014  ;       FUNC/SET.INT,            ;SET INT FOR INTERRUPT TEST
                ;19015  ;
                ;19016  ;       NAD/XFER.REQ             ;SEND XFER REQ TO FLAG THE CPU
                ;19017  ;-------------------------------------------------------------------------
                ;19018  ;1D8:
                ;19019  ;XFER.REQ:
                ;19020  ;       UCMD/SET.XFER.RQST,      ;SEND XFER REQ TO THE CPU
                ;19021  ;       NAD/DIAG.WAIT
                ;19022  ;-------------------------------------------------------------------------
```

```
                ;19023  ;1D7:
                ;19024  ;DIAG.WAIT:
                ;19025  ;
                ;19026  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;19027  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;19028  ;-------------------------------------------------------------------------
                ;19029  ;159:
                ;19030  ;=*0*
                ;19031  ;DIAG.WAIT1:
                ;19032  ;
                ;19033  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;19034  ;                               ; COMMAND FROM THE CPU
                ;19035  ;-------------------------------------------------------------------------
                ;19036  ;15B:
                ;19037  ;=*1*
                ;19038  ;DIAG.WAIT2:
                ;19039  ;
                ;19040  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;19041  ;                               ; WAIT SOME MORE
                ;19042  ;-------------------------------------------------------------------------
                ;19043  WAIT.IDC.T1C.2:
U 10FB, DB00,1A ;19044          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 10FC, 890F,E4 ;19045          JMP [IDC.DONE.T1C.2]                    ;IDC DONE
U 10FD, 890F,B4 ;19046          JMP [WAIT.IDC.T1C.2]                    ;WAIT SOME MORE
                ;19047
                ;19048  IDC.DONE.T1C.2:
U 10FE, B700,15 ;19049          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 10FF, 17A0,15 ;19050          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1100, 90FA,15 ;19051          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;19052
                ;19053  TEST.NEXT.DR.T1C:
                ;19054  LOOP.T1C.1:
U 1101, B70A,15 ;19055          MOV LS[SETCSR.F5] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 1102, 17A0,15 ;19056          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE IDC ROUTINE THAT WILL
                ;19057                                                  ; ASSERT USEL DR AND SET.ONLINE
                ;19058                                                  ;MAINT=0,CRDY=0,F<2:0>=101
                ;19059  ;-------------------------------------------------------------------------
                ;19060  ;-------------------------------------------------------------------------
                ;19061  ;                               *******
                ;19062  ;                               * IDC *
                ;19063  ;                               *******
                ;19064  ;-------------------------------------------------------------------------
                ;19065  ;018:
                ;19066  ;=000
                ;19067  ;DIAG.IDLE:
                ;19068  ;
                ;19069  ;       BEN0/F0,
                ;19070  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;19071  ;       BEN2/F2,
                ;19072  ;       NAD/DIAG.IDLE
                ;19073  ;-------------------------------------------------------------------------
                ;19074  ;01D:
                ;19075  ;=101
                ;19076  ;
                ;19077  ;       BEN0/CRDY.L,
```

```
                ;19078  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;19079  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;19080  ;-------------------------------------------------------------------------
                ;19081  ;071:
                ;19082  ;=0*1
                ;19083  ;ONLINETST2.1:
                ;19084  ;
                ;19085  ;       SEL.DRV/UPROG,                  ;USE THE LOOP COUNTER TO SELECT THE
                ;19086  ;       FUNC/SET.ONLINE,                ; DRIVE NUMBER AND SET IT ONLINE
                ;19087  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;19088  ;-------------------------------------------------------------------------
                ;19089  ;1D8:
                ;19090  ;XFER.REQ:
                ;19091  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;19092  ;       NAD/DIAG.WAIT
                ;19093  ;-------------------------------------------------------------------------
                ;19094  ;1D7:
                ;19095  ;DIAG.WAIT:
                ;19096  ;
                ;19097  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;19098  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;19099  ;-------------------------------------------------------------------------
                ;19100  ;159:
                ;19101  ;=*0*
                ;19102  ;DIAG.WAIT1:
                ;19103  ;
                ;19104  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;19105  ;                               ; COMMAND FROM THE CPU
                ;19106  ;-------------------------------------------------------------------------
                ;19107  ;15B:
                ;19108  ;=*1*
                ;19109  ;DIAG.WAIT2:
                ;19110  ;
                ;19111  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;19112  ;                               ; WAIT SOME MORE
                ;19113  ;-------------------------------------------------------------------------
                ;19114  WAIT.IDC.T1C.3:
U 1103, DB00,1A ;19115          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1104, 8910,64 ;19116          JMP [IDC.DONE.T1C.3]                    ;IDC DONE
U 1105, 8910,34 ;19117          JMP [WAIT.IDC.T1C.3]                    ;WAIT SOME MORE
                ;19118
                ;19119  IDC.DONE.T1C.3:
U 1106, B700,15 ;19120          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 1107, 17A0,15 ;19121          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1108, 90FA,15 ;19122          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;19123
                ;19124  ;PUT THE DRIVE NUMBER IN CSR <9:8>
                ;19125
U 1109, 2004,15 ;19126          MOV WR[2] TO WR[0]                      ;GET THE DRIVE NUMBER
U 110A, 3646,95 ;19127          MOV LS[#8] TO WR[1]
                ;19128  SHIFT.T1C.2:
U 110B, 23D0,15 ;19129          ASHL WR[0]                              ;SHIFT IT INTO BITS <9:8>
                ;19130          DEC WR[1],
U 110C, A102,B5 ;19131           DT(LONG)&SET.ALU.CC
U 110D, 0910,B1 ;19132          JMP.IF[NEQ] TO [SHIFT.T1C.2]
```

```
                ;19133                                          ;WR[0] NOW HAS DR NUM IN <9:8>
U 110E, A001,95 ;19134          MOV WR[0] TO WR[3]               ;SAVE IT IN WR[3]
                ;19135
                ;19136  ;NOW CHECK IF DRIVE IS ONLINE USING THE CSR TO SELECT THE DRIVE
                ;19137
U 110F, 2F80,15 ;19138          CLR WR[0]
U 1110, 97A4,15 ;19139          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;19140
U 1111, 3712,95 ;19141          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1112, B70A,15 ;19142          MOV LS[SETCSR.F5] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 1113, AEC2,15 ;19143          BIS WR[1] TO WR[0]                      ; SEL BEN1/ONLINE H
U 1114, 2EC6,15 ;19144          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE NUMBER
U 1115, 17A0,15 ;19145          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;19146                                                  ;MAINT=0,CRDY=1,F<2:0>=101
                ;19147  ;SELECT BEN1/DRIVE.ONLINE
                ;19148  ;-------------------------------------------------------------------------
                ;19149  ;-------------------------------------------------------------------------
                ;19150  ;                               *******
                ;19151  ;                               * IDC *
                ;19152  ;                               *******
                ;19153  ;-------------------------------------------------------------------------
                ;19154  ;018:
                ;19155  ;=000
                ;19156  ;DIAG.IDLE:
                ;19157  ;
                ;19158  ;       BEN0/F0,
                ;19159  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;19160  ;       BEN2/F2,
                ;19161  ;       NAD/DIAG.IDLE
                ;19162  ;-------------------------------------------------------------------------
                ;19163  ;01D:
                ;19164  ;=101
                ;19165  ;
                ;19166  ;       BEN0/CRDY.L,
                ;19167  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;19168  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;19169  ;-------------------------------------------------------------------------
                ;19170  ;070:
                ;19171  ;=0*0
                ;19172  ;TEST.FUNC5:
                ;19173  ;
                ;19174  ;ONLINETST1.1:
                ;19175  ;       BEN1/DRIVE.ONLINE,              ;IS THE DRIVE SELECTED BY DRIVE
                ;19176  ;       NAD/ONLINETST1.2                ; SELECT <1:0> ONLINE?
                ;19177  ;-------------------------------------------------------------------------
                ;19178  ;191:
                ;19179  ;=0*
                ;19180  ;ONLINETST1.2:
                ;19181  ;
                ;19182  ;       NAD/XFER.REQ                    ;ONLINE NOT ASSERTED
                ;19183  ;-------------------------------------------------------------------------
                ;19184  ;193:
                ;19185  ;=1*
                ;19186  ;ONLINETST1.3:
                ;19187  ;
```

```
                ;19188  ;       INCR.DAR/ON,                    ;ONLINE ASSERTED..INCR THE DAR
                ;19189  ;       NAD/XFER.REQ                    ; AND SEND XFER REQ TO FLAG THE CPU
                ;19190  ;-------------------------------------------------------------------------
                ;19191  ;1D8:
                ;19192  ;XFER.REQ:
                ;19193  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;19194  ;       NAD/DIAG.WAIT
                ;19195  ;-------------------------------------------------------------------------
                ;19196  ;1D7:
                ;19197  ;DIAG.WAIT:
                ;19198  ;
                ;19199  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;19200  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;19201  ;-------------------------------------------------------------------------
                ;19202  ;159:
                ;19203  ;=*0*
                ;19204  ;DIAG.WAIT1:
                ;19205  ;
                ;19206  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;19207  ;                               ; COMMAND FROM THE CPU
                ;19208  ;-------------------------------------------------------------------------
                ;19209  ;15B:
                ;19210  ;=*1*
                ;19211  ;DIAG.WAIT2:
                ;19212  ;
                ;19213  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;19214  ;                               ; WAIT SOME MORE
                ;19215  ;-------------------------------------------------------------------------
                ;19216  WAIT.IDC.T1C.4:
U 1116, DB00,1A ;19217          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 1117, 0911,94 ;19218          JMP [IDC.DONE.T1C.4]                    ;IDC DONE
U 1118, 0911,64 ;19219          JMP [WAIT.IDC.T1C.4]                    ;WAIT SOME MORE
                ;19220
                ;19221  IDC.DONE.T1C.4:
U 1119, B700,15 ;19222          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 111A, 17A0,15 ;19223          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 111B, 90FA,15 ;19224          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;19225
                ;19226  READ.DAR.T1C.1:
U 111C, 9090,15 ;19227          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 111D, 1784,15 ;19228          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 111E, 3B32,15 ;19229          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;19230                                                  ; SAVE IT IN LS
U 111F, 3E89,15 ;19231          MOV WR[2] TO LS[ADDRESS.DATA]           ;SET UP THE DR NUM FOR PRINTOUT
U 1120, 3732,15 ;19232          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1121, 3640,95 ;19233          MOV LS[#1] TO WR[1]                     ;SET UP THE EXPECTED DATA
U 1122, 0869,3C ;19234          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1123, 0910,14 ;19235          JMP [LOOP.T1C.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;19236
U 1124, 2045,15 ;19237          INC WR[2]                               ;NEXT DRIVE NUMBER
                ;19238          CMP LS[#4] WITH WR[2],                  ;ALL DRIVES BEEN TESTED?
U 1125, 4E45,35 ;19239           DT(LONG)&SET.ALU.CC
U 1126, 8913,29 ;19240          JMP.IF[EQL] TO [CLEANUP.T1C]            ;JMP IF DONE
                ;19241
                ;19242  ;INCR THE LOOP COUNTER TO INCR THE USEL DR LINES
```

```
                ;19243
U 1127, 3712,95 ;19244          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1128, 3708,15 ;19245          MOV LS[SETCSR.F4] TO WR[0]              ; THE IDC ROUTINE THAT WILL
U 1129, AEC2,15 ;19246          BIS WR[1] TO WR[0]                      ; INCR THE LOOP CNTR
U 112A, 17A0,15 ;19247          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;19248                                                  ;MAINT=0,CRDY=1,F<2:0>=100
                ;19249  ;INCR THE LOOP CNTR TO SELECT NEXT DRIVE
                ;19250  ;-------------------------------------------------------------------------
                ;19251  ;-------------------------------------------------------------------------
                ;19252  ;                               *******
                ;19253  ;                               * IDC *
                ;19254  ;                               *******
                ;19255  ;-------------------------------------------------------------------------
                ;19256  ;018:
                ;19257  ;=000
                ;19258  ;DIAG.IDLE:
                ;19259  ;
                ;19260  ;       BEN0/F0,
                ;19261  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;19262  ;       BEN2/F2,
                ;19263  ;       NAD/DIAG.IDLE
                ;19264  ;-------------------------------------------------------------------------
                ;19265  ;01C:
                ;19266  ;=100
                ;19267  ;
                ;19268  ;       BEN0/CRDY.L,
                ;19269  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;19270  ;       NAD/TEST.FUNC4          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;19271  ;-------------------------------------------------------------------------
                ;19272  ;06A:
                ;19273  ;=0*0
                ;19274  ;TEST.FUNC4:
                ;19275  ;
                ;19276  ;TEST.INCR.LPCNTR:
                ;19277  ;
                ;19278  ;       INCR.LPCNTR/ON,         ;INCREMENT THE LOOP CNTR
                ;19279  ;       BEN0/CNTR.OVFLW,        ;DID LOOP CNTR OVFLW?
                ;19280  ;       NAD/BEN0.1
                ;19281  ;-------------------------------------------------------------------------
                ;19282  ;18A:
                ;19283  ;=0
                ;19284  ;BEN0.1:
                ;19285  ;
                ;19286  ;       NAD/XFER.REQ            ;SELECTED BRANCH 0 IS NOT ASSERTED
                ;19287  ;                               ; FLAG THE CPU
                ;19288  ;-------------------------------------------------------------------------
                ;19289  ;18B:
                ;19290  ;=1
                ;19291  ;BEN0.2:
                ;19292  ;
                ;19293  ;       INCR.DAR/ON,            ;INCREMENT THE DAR
                ;19294  ;       NAD/XFER.REQ            ;SELECTED BRANCH 0 WAS ASSERTED
                ;19295  ;                               ; FLAG THE CPU
                ;19296  ;-------------------------------------------------------------------------
                ;19297  ;1D8:
```

```
                ;19298  ;XFER.REQ:
                ;19299  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;19300  ;       NAD/DIAG.WAIT
                ;19301  ;-------------------------------------------------------------------------
                ;19302  ;1D7:
                ;19303  ;DIAG.WAIT:
                ;19304  ;
                ;19305  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;19306  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;19307  ;-------------------------------------------------------------------------
                ;19308  ;159:
                ;19309  ;=*0*
                ;19310  ;DIAG.WAIT1:
                ;19311  ;
                ;19312  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;19313  ;                               ; COMMAND FROM THE CPU
                ;19314  ;-------------------------------------------------------------------------
                ;19315  ;15B:
                ;19316  ;=*1*
                ;19317  ;DIAG.WAIT2:
                ;19318  ;
                ;19319  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;19320  ;                               ; WAIT SOME MORE
                ;19321  ;-------------------------------------------------------------------------
                ;19322  WAIT.IDC.T1C.5:
U 112B, DB00,1A ;19323          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR IDC TO COMPLETE
U 112C, 8912,E4 ;19324          JMP [IDC.DONE.T1C.5]                    ;IDC DONE
U 112D, 8912,B4 ;19325          JMP [WAIT.IDC.T1C.5]                    ;WAIT SOME MORE
                ;19326
                ;19327  IDC.DONE.T1C.5:
U 112E, B700,15 ;19328          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR THE FUNCTION BITS
U 112F, 17A0,15 ;19329          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
U 1130, 90FA,15 ;19330          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;19331
U 1131, 0910,14 ;19332          JMP [TEST.NEXT.DR.T1C]                  ;GO CHECK THE NEXT DRIVE
                ;19333
                ;19334  CLEANUP.T1C:
U 1132, 8875,3C ;19335          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                ;19336                                                  ; BY THIS TEST
                ;19337  END.T1C:                                        ;END TEST
                ;19338
                ;19339
```

```
;19340  .PAGE  "Test 1D  DATA BUS IN AND DATA BUS OUT TEST (M8388 IDC MODULE)"
;19341  ;++
;19342  ;
;19343  ; Test Description:
;19344  ;
;19345  ;       This test will verify the integrity of data bus in and data bus out.
;19346  ;       A portion of the I/O BUS IN LATCHES, I/O BUS OUT LATCHES and location 0
;19347  ;       of FIFO A and FIFO B will also be verified in this test.
;19348  ;       Only one location in FIFO A and FIFO B  will be used to enable better
;19349  ;       isolation.
;19350  ;       The CPU will do a WRITE.DATA.BYTE of the data pattern to FIFO A
;19351  ;       address 0.
;19352  ;       The CPU will then read FIFO A address 0 and then compare the write and
;19353  ;       read data to insure that the write and the read functioned correctly.
;19354  ;       The data patterns that will be used are:
;19355  ;
;19356  ;               Pattern 1 - AA
;19357  ;               Pattern 2 - 55
;19358  ;               Pattern 3 - 33
;19359  ;               Pattern 4 - 0F
;19360  ;       FIFO B will be selected after FIFO A has been verified using all of
;19361  ;       the data patterns.
;19362  ;
;19363  ; Assumptions:
;19364  ;
;19365  ;       It is assumed that the CPU and the Y Bus are fully operational.
;19366  ;
;19367  ; Test Steps:
;19368  ;
;19369  ;       1. Set up error mask, error number and module number in LS
;19370  ;          (for error printouts) and clear the previous error number in LS.
;19371  ;       2. Select FIFO A.
;19372  ;       3. Get the data pattern from LS.
;19373  ;       4. Move the data pattern to WR 0.
;19374  ;       5. Clear the FIFO Address Counter.
;19375  ;       6. Execute a WRITE.DATA.BYTE to the FIFO.
;19376  ;       7. Clear the FIFO Address Counter.
;19377  ;       8. Execute a READ.BYTE from the  FIFO.
;19378  ;       9. Check the result.
;19379  ;      10. Get the next data pattern from LS and go to Step 3 until all data
;19380  ;          patterns have been tested using FIFO A.
;19381  ;      11. Get the next data pattern and Select FIFO B.
;19382  ;      12. Repeat Steps 3 - 9 until all data patterns have been tested
;19383  ;          udsing FIFO B.
;19384  ;
;19385  ; Errors:
;19386  ;
;19387  ;       ERROR 1 - The byte data path failed using FIFO A.
;19388  ;
;19389  ;                 Printout:
;19390  ;                         EXPECTED          RECEIVED
;19391  ;                          FIFO A            FIFO A
;19392  ;
;19393  ;       ERROR 2 - The byte data path failed using FIFO B.
;19394  ;
```

```
;19395  ;                    Printout:
;19396  ;                                  EXPECTED          RECEIVED
;19397  ;                                   FIFO B            FIFO B
;19398  ;
;19399  ;
;19400  ;
;19401  ;
;19402  ;
;19403  ; Debug:
;19404  ;
;19405  ;  ERROR 1:
;19406  ;
;19407  ;   SEL.FIFO.A:
;19408  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;19409  ;       instruction. This instruction is decoded by the PORT INTERFACE REG PAL.
;19410  ;       The inputs will be:
;19411  ;               CSR 17 H = H
;19412  ;               CSR 14 H = H
;19413  ;               CSR 12 H = H
;19414  ;               CSR 11 H = H
;19415  ;               CSR 10 H = L
;19416  ;               PORT INSTR H = H
;19417  ;               CPU P2 H = H
;19418  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;19419  ;
;19420  ;   WRITE.DATA.BYTE:
;19421  ;
;19422  ;       This instruction will be decoded in the PORT RD/WR DECODE PAL.
;19423  ;       The inputs to this PAL will be:
;19424  ;               CSR 17 H = H
;19425  ;               CSR 14 H = L
;19426  ;               CSR 13 H = H
;19427  ;               CSR 12 H = L
;19428  ;               CSR 11 H = H
;19429  ;               CSR 10 H = L
;19430  ;               PORT INSTR H = H
;19431  ;               CPU P2 H = H
;19432  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;19433  ;       STROBE DATA H.
;19434  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS. This
;19435  ;       combination of inputs will assert PWRITE FIFO H and PENB INREG B0 L.
;19436  ;       PENB INREG B0 L and STROBE DATA H will enable the data from the I/O Bus
;19437  ;       onto BUS IN. PWRITE FIFO H will be ANDED with PSEL FIFOA H and PORT
;19438  ;       CLK L. This combination of signals will assert WRITE FIFOA L which will
;19439  ;       write the data which is on BUS IN into FIFOA.
;19440  ;
;19441  ;       The CPU will then select FIFO A and issue a CLEAR.FIFO.ADRS which will
;19442  ;       clear the address lines of FIFOA.
;19443  ;
;19444  ;   READ.DATA.BYTE:
;19445  ;
;19446  ;       To read a byte of data from the FIFO, the CPU must first issue a
;19447  ;       MISC [SET.PORT.I.O] which will assert SEL IDC H.
;19448  ;       The CPU then  will do a PORT.READ PORT ADRS[DATA.BYTE]. This
;19449  ;       instruction will be decoded by PORT INTERFACE REGISTER PAL and the
```

```
;19450  ;       PORT RD/WR DECODE PAL. The inputs to the PORT RD/WR DECODE PAL will
;19451  ;       be:
;19452  ;               CSR 17 H = H
;19453  ;               CSR 14 H = L
;19454  ;               CSR 13 H = L
;19455  ;               CSR 12 H = L
;19456  ;               CSR 11 H = H
;19457  ;               CSR 10 H = L
;19458  ;               PORT INSTR H = H
;19459  ;               CPU P2 H = H
;19460  ;       These inputs will assert READ DATA L and BYTE L.
;19461  ;       These two signals are inputs to the PORT USEQ A and B PALS. These PALS
;19462  ;       do not single-step with the CPU since they are clocked by CPU CLOCK H
;19463  ;       which is a free running clock.
;19464  ;       BRANCH TEST L will be asserted. When PORT USEQ PALS are clocked after
;19465  ;       READ DATA L and BYTE L assert, the outputs of PORT USEQ A will be:
;19466  ;               PORT NAD 0 H = H
;19467  ;               PORT NAD 1 H = H
;19468  ;               PORT NAD 2 H = H
;19469  ;               BRANCH TEST L = H
;19470  ;               PENB FIFO H = H
;19471  ;               PINCR FIFO CNTR H = H
;19472  ;               PWRITE FIFO H = L
;19473  ;
;19474  ;       The only output of PORT USEQ B that will assert is PLOAD OUTREG B0 L.
;19475  ;
;19476  ;       PENB FIFO H is ANDED with PSEL FIFOA H = H and asserts
;19477  ;       ENB FIFOA L which enables address 0 of FIFOA onto BUS OUT. PLOAD OUTREG
;19478  ;       B0 L clocks this data into the I/O BUS OUT LATCHES.
;19479  ;
;19480  ;       At the same time, the PORT INTERFACE REG PAL is decoding the same
;19481  ;       instruction. The inputs to this PAL will be:
;19482  ;
;19483  ;               CSR 17 H = H
;19484  ;               CSR 14 H = L
;19485  ;               READ PORT L = H
;19486  ;               CSR 12 H = L
;19487  ;               CSR 11 H = H
;19488  ;               CSR 10 H = L
;19489  ;               PORT INSTR H = H
;19490  ;               CPU P2 H = H
;19491  ;       On the next CPU CLOCK H, the outputs will be:
;19492  ;
;19493  ;               SEL IDC H = H
;19494  ;               R2 L = H
;19495  ;               R1 L = L
;19496  ;               R0 L = H
;19497  ;               PSEL FIFOA H = H
;19498  ;
;19499  ;       The CPU will then issue a MOV PORT TO LS[] instruction. This will
;19500  ;       assert READ PORT L which is an input to the PORT INTERFACE REG PAL.
;19501  ;       At the next CPU CLOCK , output READ PORT H will assert.
;19502  ;       This signal is one of the enables to the decoder of R<2:0>.
;19503  ;       READ PORT H is also ANDED with SEL IDC H, which will be asserted,
;19504  ;       and SEL ACC L = H. This combination of inputs will assert READ IDC L
```

```
                ;19505  ;       which is the enable to the decoder of R<2:0>.
                ;19506  ;       The combination of R<2:0> inputs that were previously latched by the
                ;19507  ;       PORT INTERFACE REG PAL, will assert SEL BYTE L. This signal is ORED
                ;19508  ;       with SEL WORD L and will assert ENB OUTREG L. ENB OUTREG L is the
                ;19509  ;       output enable for the I/O BUS OUT LATCHES and outputs the data onto
                ;19510  ;       the I/O BUS.
                ;19511  ;       READ IDC L which was previously asserted, directs the Tranceivers to
                ;19512  ;       take the data from the I/O BUS and put it on the Y BUS. The CPU then
                ;19513  ;       moves the data to an LS location.
                ;19514  ;
                ;19515  ;
                ;19516  ;  ERROR 2:
                ;19517  ;
                ;19518  ;       The same as error 1 except FIFO B will be selected.
                ;19519  ;
                ;19520  ;       FIFO B is selected by the port by a PORT.CONTROL [SEL.FIFO.B]
                ;19521  ;       instruction. This instruction is decoded by the PORT INTERFACE REG PAL.
                ;19522  ;       The inputs will be:
                ;19523  ;               CSR 17 H = H
                ;19524  ;               CSR 14 H = H
                ;19525  ;               CSR 12 H = H
                ;19526  ;               CSR 11 H = H
                ;19527  ;               CSR 10 H = H
                ;19528  ;               PORT INSTR H = H
                ;19529  ;               CPU P2 H = H
                ;19530  ;
                ;19531  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
                ;19532  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
                ;19533  ;--
                ;19534  ;*******************************************************************************
                ;19535  T.1D:
U 1133, B65E,15 ;19536          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;19537                                                  ; CONTROL AND STATUS WORD
U 1134, 3E80,15 ;19538          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;19539                                                  ; STATUS WORD - BIT 15
                ;19540                                                  ; INDICATES START OF TEST TO
                ;19541                                                  ; CONSOLE
U 1135, 10E0,15 ;19542          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;19543  WAIT.T1D.0:
U 1136, 8913,64 ;19544          JMP [WAIT.T1D.0]                        ;LOOP HERE WAITING FOR
                ;19545                                                  ; CONSOLE TO RESPOND
                ;19546
U 1137, 65A0,15 ;19547          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;19548                                                  ; IN LS
                ;19549
U 1138, B64A,15 ;19550          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1139, 3E8C,15 ;19551          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;19552
                ;19553
U 113A, B640,15 ;19554          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 113B, BE82,15 ;19555          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;19556
U 113C, B62C,15 ;19557          MOV LS[#FFFFFF00] TO WR[0]              ;SET UP THE ERROR MASK TO
U 113D, 3E8A,15 ;19558          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK THE LOW BYTE
                ;19559
```

```
U 113E, 2F85,15 ;19560          CLR WR[2]                                   ;USE AS A LOOP COUNTER
                ;19561
U 113F, B699,95 ;19562          MOV LS[#AAAAAAAA] TO WR[3]                  ;GET THE DATA PATTERN
                ;19563  CHK.NXT.PAT.T1D:
U 1140, 452D,95 ;19564          BIC LS[#FFFFFF00] TO WR[3]                  ;SAVE THE LOW BYTE (AA)
                ;19565  LOOP.T1D.1:
U 1141, A006,15 ;19566          MOV WR[3] TO WR[0]                          ;MOV IT TO WR[0] FOR THE WRITE
                ;19567
U 1142, 17D8,15 ;19568          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A
U 1143, 17C0,15 ;19569          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLEAR THE FIFO A ADDR CNTR
U 1144, 97A8,15 ;19570          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR FIFOA ADDRESS 0 = AA
U 1145, 17C0,15 ;19571          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET ADDRS CNTR = 0
                ;19572
                ;19573  READ.FIFOA.T1D.1:
U 1146, 9090,15 ;19574          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 1147, 1788,15 ;19575          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ FIFO A
U 1148, 3B32,15 ;19576          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM FIFO A
                ;19577                                                      ; SAVE IT IN LS
U 1149, 3732,15 ;19578          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 114A, 2006,95 ;19579          MOV WR[3] TO WR[1]                          ;SET UP EXPECTED DATA
U 114B, 0869,3C ;19580          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 114C, 8914,14 ;19581          JMP [LOOP.T1D.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;19582
                ;19583          CMP WR[2] WITH LS[ZERO],                    ;FIRST LOOP COUNT?
U 114D, CF9D,35 ;19584           DT(LONG)&SET.ALU.CC
U 114E, 0915,21 ;19585          JMP.IF[NEQ] TO [CHK.LPCNT.T1D.1]            ;JMP IF NOT FIRST
U 114F, 369B,95 ;19586          MOV LS[#55555555] TO WR[3]                  ;GET DATA PATTERN 2
U 1150, 2045,15 ;19587          INC WR[2]                                   ;INCR THE LOOP COUNT
U 1151, 0914,04 ;19588          JMP [CHK.NXT.PAT.T1D]                       ;CHECK THE NEXT PATTERN
                ;19589
                ;19590  CHK.LPCNT.T1D.1:
                ;19591          CMP WR[2] WITH LS[#1],                      ;SECOND LOOP COUNT?
U 1152, 4F41,35 ;19592           DT(LONG)&SET.ALU.CC
U 1153, 0915,71 ;19593          JMP.IF[NEQ] TO [CHK.LPCNT.T1D.2]
U 1154, B6C5,95 ;19594          MOV LS[#33333333] TO WR[3]                  ;GET DATA PATTERN 3
U 1155, 2045,15 ;19595          INC WR[2]                                   ;INCR THE LOOP COUNT
U 1156, 0914,04 ;19596          JMP [CHK.NXT.PAT.T1D]                       ;CHECK THE NEXT PATTERN
                ;19597
                ;19598  CHK.LPCNT.T1D.2:
                ;19599          CMP WR[2] WITH LS[#2],                      ;THIRD  LOOP COUNT?
U 1157, CF43,35 ;19600           DT(LONG)&SET.ALU.CC
U 1158, 8915,C1 ;19601          JMP.IF[NEQ] TO [CHECK.FIFOB.T1D]            ;JMP IF DONE ALL PATS
U 1159, 36C7,95 ;19602          MOV LS[#0F0F0F0F] TO WR[3]                  ;GET DATA PATTERN 4
U 115A, 2045,15 ;19603          INC WR[2]                                   ;INCR THE LOOP COUNT
U 115B, 0914,04 ;19604          JMP [CHK.NXT.PAT.T1D]                       ;CHECK THE NEXT PATTERN
                ;19605
                ;19606  ;TEST ONE LOCATION OF FIFO B
                ;19607
                ;19608  CHECK.FIFOB.T1D:
U 115C, FF82,15 ;19609          INC LS[ERROR.NUMBER]                        ;ERROR 2
                ;19610
U 115D, 2F85,15 ;19611          CLR WR[2]                                   ;USE AS A LOOP COUNTER
                ;19612
U 115E, B699,95 ;19613          MOV LS[#AAAAAAAA] TO WR[3]                  ;GET THE DATA PATTERN
                ;19614
```

```
                ;19615  CHK.NXT.PATB.T1D:
U 115F, 452D,95 ;19616          BIC LS[#FFFFFF00] TO WR[3]              ;SAVE THE LOW BYTE (AA)
                ;19617  LOOP.T1D.2:
U 1160, A006,15 ;19618          MOV WR[3] TO WR[0]                      ;MOV PAT TO WR[0] FOR THE WRITE
                ;19619
U 1161, 97DC,15 ;19620          PORT.CONTROL [SEL.FIFO.B]               ;SELECT FIFO B
U 1162, 17C0,15 ;19621          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLEAR THE FIFO B ADDR CNTR
U 1163, 97A8,15 ;19622          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR FIFO B ADDRESS 0 = AA
U 1164, 17C0,15 ;19623          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRS CNTR = 0
                ;19624
                ;19625  READ.FIFOB.T1D.1:
U 1165, 9090,15 ;19626          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1166, 1788,15 ;19627          PORT.READ PORT.ADRS[DATA.BYTE]          ;SET UP TO READ FIFO B
U 1167, 3B32,15 ;19628          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM FIFO B
                ;19629                                                  ; SAVE IT IN LS
U 1168, 3732,15 ;19630          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1169, 2006,95 ;19631          MOV WR[3] TO WR[1]                      ;SET UP EXPECTED DATA
U 116A, 0869,3C ;19632          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 116B, 8916,04 ;19633          JMP [LOOP.T1D.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;19634
                ;19635          CMP WR[2] WITH LS[ZERO],                ;FIRST LOOP COUNT?
U 116C, CF9D,35 ;19636           DT(LONG)&SET.ALU.CC
U 116D, 8917,11 ;19637          JMP.IF[NEQ] TO [CHK.LPCNT.T1D.3]        ;JMP IF NOT FIRST
U 116E, 369B,95 ;19638          MOV LS[#55555555] TO WR[3]              ;GET DATA PATTERN 2
U 116F, 2045,15 ;19639          INC WR[2]                               ;INCR THE LOOP COUNT
U 1170, 8915,F4 ;19640          JMP [CHK.NXT.PATB.T1D]                  ;CHECK THE NEXT PATTERN
                ;19641
                ;19642  CHK.LPCNT.T1D.3:
                ;19643          CMP WR[2] WITH LS[#1],                  ;SECOND LOOP COUNT?
U 1171, 4F41,35 ;19644           DT(LONG)&SET.ALU.CC
U 1172, 0917,61 ;19645          JMP.IF[NEQ] TO [CHK.LPCNT.T1D.4]
U 1173, B6C5,95 ;19646          MOV LS[#33333333] TO WR[3]              ;GET DATA PATTERN 3
U 1174, 2045,15 ;19647          INC WR[2]                               ;INCR THE LOOP COUNT
U 1175, 8915,F4 ;19648          JMP [CHK.NXT.PATB.T1D]                  ;CHECK THE NEXT PATTERN
                ;19649
                ;19650  CHK.LPCNT.T1D.4:
                ;19651          CMP WR[2] WITH LS[#2],                  ;THIRD  LOOP COUNT?
U 1176, CF43,35 ;19652           DT(LONG)&SET.ALU.CC
U 1177, 8917,B1 ;19653          JMP.IF[NEQ] TO [CLEANUP.T1D]            ;JMP IF DONE ALL PATS
U 1178, 36C7,95 ;19654          MOV LS[#0F0F0F0F] TO WR[3]              ;GET DATA PATTERN 4
U 1179, 2045,15 ;19655          INC WR[2]                               ;INCR THE LOOP COUNT
U 117A, 8915,F4 ;19656          JMP [CHK.NXT.PATB.T1D]                  ;CHECK THE NEXT PATTERN
                ;19657
                ;19658
                ;19659
                ;19660  CLEANUP.T1D:
U 117B, 8875,3C ;19661          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY THIS
                ;19662                                                  ;TEST
                ;19663
                ;19664  END.T1D:                                        ;END TEST
                ;19665
```

```
;19666  .PAGE  "Test 1E  FIFO A DATA INTEGRITY TEST (M8388 IDC MODULE)"
;19667  ;++
;19668  ;
;19669  ; Test Description:
;19670  ;
;19671  ;       This test is designed to verify that every location in FIFO A can be
;19672  ;       written and read correctly. This will accomplished by doing byte writes
;19673  ;       to every location of FIFO A.
;19674  ;       The data patterns that will be used are:
;19675  ;
;19676  ;               Data pattern 1 = All ones
;19677  ;               Data Pattern 2 = All zeros
;19678  ;               Data Pattern 3 = Float a one through a field of zeros.
;19679  ;               Data Pattern 4 = Float a zero through a field of ones.
;19680  ;
;19681  ; Assumptions:
;19682  ;
;19683  ;       It is assumed that  BUS IN and BUS OUT have been tested and found
;19684  ;       fully operational.
;19685  ;
;19686  ; Test Steps:
;19687  ;
;19688  ;       1. Set up error mask, error number and module number in LS
;19689  ;          (for error printouts) and clear the previous error number in LS.
;19690  ;       2. Use WR[2] to track the address.
;19691  ;       3. Clear WR[2].
;19692  ;       4. Clear FIFO A Address Counter.
;19693  ;       5. Move the Data Pattern from LS to WR[0].
;19694  ;       6. Do a byte write to FIFO A.
;19695  ;       7. Increment WR[2].
;19696  ;       8. If WR[2] is less than 512, then go to Step 6.
;19697  ;       9. Clear FIFO A Address Counter.
;19698  ;      10. Read a byte from FIFO A.
;19699  ;      11. Check it.
;19700  ;      12. Increment WR[2].
;19701  ;      13. If WR[2] is less than 512 go to Step 10.
;19702  ;      14. Get the next data pattern and go to Step 3 until all data patterns
;19703  ;          have been tested.
;19704  ;
;19705  ; Errors:
;19706  ;
;19707  ;       ERROR 1 - FIFO A failed.
;19708  ;
;19709  ;               Printout:
;19710  ;                       EXPECTED        RECEIVED        OTHER DATA
;19711  ;                        FIFO A          FIFO A           WR[2]
;19712  ;                                                      FIFOA ADDRESS
;19713  ; Debug:
;19714  ;
;19715  ;  ERROR 1:
;19716  ;
;19717  ;       Because of hardware restrictions, this test will only loop on the
;19718  ;       read of address 0 of FIFO A. This will allow verifying the enables.
;19719  ;
;19720  ;       The control logic and the data path has been verified in a previous
```

```
                ;19721  ;       test. Therefore, if the enables are OK, one must determine only which
                ;19722  ;       RAM contains the failure.
                ;19723  ;       FIFO A consists of 4 chips. Address 0 - 255 (0 - FF) are in two chips,
                ;19724  ;       and Address 256-511 (100 - 1FF) are in two chips.
                ;19725  ;       The failure can be isolated to which one of the two chips by examining
                ;19726  ;       the bit number that failed. Bits <3:0> are in one chip and
                ;19727  ;       bits <7:4> are in the other.
                ;19728  ;
                ;19729  ;--
                ;19730  ;*************************************************************************************
                ;19731  T.1E:
U 117C, B65E,15 ;19732          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;19733                                                          ; CONTROL AND STATUS WORD
U 117D, 3E80,15 ;19734          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;19735                                                          ; STATUS WORD - BIT 15
                ;19736                                                          ; INDICATES START OF TEST TO
                ;19737                                                          ; CONSOLE
U 117E, 10E0,15 ;19738          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;19739  WAIT.T1E.0:
U 117F, 0917,F4 ;19740          JMP [WAIT.T1E.0]                                ;LOOP HERE WAITING FOR
                ;19741                                                          ; CONSOLE TO RESPOND
                ;19742
U 1180, 65A0,15 ;19743          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
                ;19744                                                          ; IN LS
                ;19745
U 1181, B64A,15 ;19746          MOV LS[IDC] TO WR[0]                            ;STORE MODULE CODE IN LS TO
U 1182, 3E8C,15 ;19747          MOV WR[0] TO LS[MODULE.NUM]                     ; INDICATE IDC MODULE
                ;19748
                ;19749
U 1183, B640,15 ;19750          MOV LS[#1] TO WR[0]                             ;SET WR0 = 1
U 1184, BE82,15 ;19751          MOV WR[0] TO LS[ERROR.NUMBER]                   ;SET UP ERROR NUMBER = 1 IN LS
                ;19752
                ;19753
U 1185, B62C,15 ;19754          MOV LS[#FFFFFF00] TO WR[0]                      ;SET UP THE ERROR MASK TO
U 1186, 3E8A,15 ;19755          MOV WR[0] TO LS[ERROR.MASK]                     ; CHECK THE LOW BYTE
                ;19756
                ;19757
U 1187, B670,15 ;19758          MOV LS[OTHER.DATA] TO WR[0]                     ;SET UP CONTROL.STATUS TO PRINT
U 1188, 3E80,15 ;19759          MOV WR[0] TO LS[CONTROL.STATUS]                 ; OTHER DATA IF ERROR
U 1189, DB00,15 ;19760          NOP
                ;19761  ;CHECK FIFO WITH ALL ONES
                ;19762
U 118A, 2F85,15 ;19763          CLR WR[2]                                       ;USE AS ADDRESS TRACKER
U 118B, 17D8,15 ;19764          PORT.CONTROL [SEL.FIFO.A]                       ;SELECT FIFO A FROM THE PORT
U 118C, 17C0,15 ;19765          PORT.CONTROL [CLEAR.FIFO.CNTR]                  ;SET FIFO A ADDRESS = 0
U 118D, B626,15 ;19766          MOV LS[#FF] TO WR[0]                            ;GET THE FIRST DATA PATTERN
                ;19767
                ;19768  WRITE.FIFO.ONES.T1E:
U 118E, 97A8,15 ;19769          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR BYTE OF DATA TO FIFO A
U 118F, 2045,15 ;19770          INC WR[2]                                       ;INCR THE ADDRS TRACKER
                ;19771          CMP WR[2] WITH LS[#200],
U 1190, 4F53,35 ;19772           DT(LONG)&SET.ALU.CC                            ;FIFO ALL WRITTEN WITH PAT?
U 1191, 8918,E1 ;19773          JMP.IF[NEQ] TO [WRITE.FIFO.ONES.T1E]            ;JMP IF NOT DONE
                ;19774
                ;19775  LOOP.T1E.PAT1:
```

```
U 1192, 2F85,15 ;19776          CLR WR[2]                                   ;USE AS THE ADDRESS TRACKER
U 1193, 17C0,15 ;19777          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLR THE ADDRESS COUNTER
                ;19778
                ;19779  READ.FIFO.ONES.T1E:
U 1194, 9090,15 ;19780          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 1195, 1788,15 ;19781          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ THE FIFO
U 1196, 3B32,15 ;19782          MOV PORT TO LS[PORT0]                       ;READ A BYTE OF DATA FROM THE
                ;19783                                                      ; FIFO AND SAVE IT IN LS
U 1197, 3E89,15 ;19784          MOV WR[2] TO LS[ADDRESS.DATA]               ;ADDRESS COUNTER
U 1198, 3732,15 ;19785          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 1199, 3626,95 ;19786          MOV LS[#FF] TO WR[1]                        ;SET UP EXPECTED DATA
U 119A, 0869,3C ;19787          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 119B, 0919,24 ;19788          JMP [LOOP.T1E.PAT1]                         ;LOOP HERE IF ERR & LOE IS SET
U 119C, 2045,15 ;19789          INC WR[2]                                   ;INCREMENT THE ADRS CNTR
                ;19790          CMP WR[2] WITH LS[#200],
U 119D, 4F53,35 ;19791           DT(LONG)&SET.ALU.CC                        ;CHECKED ALL LOCATIONS?
U 119E, 0919,41 ;19792          JMP.IF[NEQ] TO [READ.FIFO.ONES.T1E]         ;JMP IF NOT DONE
                ;19793
                ;19794  ;CHECK FIFO WITH ALL ZEROS
                ;19795
U 119F, 2F85,15 ;19796          CLR WR[2]                                   ;USE AS ADDRESS TRACKER
U 11A0, 17D8,15 ;19797          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A FROM THE PORT
U 11A1, 17C0,15 ;19798          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO A ADDRESS = 0
U 11A2, 2F80,15 ;19799          CLR WR[0]                                   ;GET THE DATA PATTERN
                ;19800
                ;19801  WRITE.FIFO.ZERO.T1E:
U 11A3, 97A8,15 ;19802          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR A BYTE OF DATA TO FIFO A
U 11A4, 2045,15 ;19803          INC WR[2]                                   ;INCR THE ADDRS TRACKER
                ;19804          CMP WR[2] WITH LS[#200],
U 11A5, 4F53,35 ;19805           DT(LONG)&SET.ALU.CC                        ;FIFO ALL WRITTEN WITH PAT?
U 11A6, 891A,31 ;19806          JMP.IF[NEQ] TO [WRITE.FIFO.ZERO.T1E]        ;JMP IF NOT DONE
                ;19807
                ;19808  LOOP.T1E.PAT2:
U 11A7, 2F85,15 ;19809          CLR WR[2]                                   ;USE AS THE ADDRESS TRACKER
U 11A8, 17C0,15 ;19810          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLR THE ADDRESS COUNTER
                ;19811
                ;19812  READ.FIFO.ZERO.T1E:
U 11A9, 9090,15 ;19813          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 11AA, 1788,15 ;19814          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ THE FIFO
U 11AB, 3B32,15 ;19815          MOV PORT TO LS[PORT0]                       ;READ A BYTE OF DATA FROM THE
                ;19816                                                      ; FIFO AND SAVE IT IN LS
U 11AC, 3E89,15 ;19817          MOV WR[2] TO LS[ADDRESS.DATA]               ;ADDRESS COUNTER
U 11AD, 3732,15 ;19818          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 11AE, 2F82,95 ;19819          CLR WR[1]                                   ;SET UP EXPECTED DATA
U 11AF, 0869,3C ;19820          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 11B0, 091A,74 ;19821          JMP [LOOP.T1E.PAT2]                         ;LOOP HERE IF ERR & LOE IS SET
U 11B1, 2045,15 ;19822          INC WR[2]                                   ;INCREMENT THE ADRS CNTR
                ;19823          CMP WR[2] WITH LS[#200],
U 11B2, 4F53,35 ;19824           DT(LONG)&SET.ALU.CC                        ;CHECKED ALL LOCATIONS?
U 11B3, 891A,91 ;19825          JMP.IF[NEQ] TO [READ.FIFO.ZERO.T1E]         ;JMP IF NOT DONE
                ;19826
                ;19827  ;FLOATINGS ONES PATTERN
                ;19828
U 11B4, 17D8,15 ;19829          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A FROM THE PORT
U 11B5, E5F8,15 ;19830          CLR LS[OS]                                  ;CLR THE INDEX TO THE DATA PAT
```

```
U 11B6, B647,95 ;19831          MOV LS[#8] TO WR[3]                          ;LAST INDEX TO WRITE A BYTE
                ;19832                                                       ; WITH FLOATING PAT
                ;19833
                ;19834  WRITE.NEXT.1PAT.T1E:
U 11B7, 17C0,15 ;19835          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;SET FIFO A ADDRESS = 0
U 11B8, 2F85,15 ;19836          CLR WR[2]                                    ;USE AS ADDRESS TRACKER
                ;19837
                ;19838  WRITE.FIFO.FLOAT1.T1E:
U 11B9, 36F6,15 ;19839          MOV LS[SHIFT.OS(4-0)] TO WR[0]               ;PUT THE DATA PAT IN WR[0]
U 11BA, 97A8,15 ;19840          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR BYTE OF DATA TO FIFO A
U 11BB, 2045,15 ;19841          INC WR[2]                                    ;INCR THE ADDRS TRACKER
                ;19842          CMP WR[2] WITH LS[#200],
U 11BC, 4F53,35 ;19843           DT(LONG)&SET.ALU.CC                         ;FIFO ALL WRITTEN WITH PAT?
U 11BD, 091B,91 ;19844          JMP.IF[NEQ] TO [WRITE.FIFO.FLOAT1.T1E]       ;JMP IF NOT DONE
                ;19845
                ;19846  LOOP.T1E.PAT3:
U 11BE, 2F85,15 ;19847          CLR WR[2]                                    ;USE AS THE ADDRESS TRACKER
U 11BF, 17C0,15 ;19848          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;CLR THE ADDRESS COUNTER
                ;19849
                ;19850  READ.FIFO.FLOAT1.T1E:
U 11C0, 9090,15 ;19851          MISC [SET.PORT.I.O]                          ;SELECT THE IDC
U 11C1, 1788,15 ;19852          PORT.READ PORT.ADRS[DATA.BYTE]               ;SET UP TO READ THE FIFO
U 11C2, 3B32,15 ;19853          MOV PORT TO LS[PORT0]                        ;READ A BYTE OF DATA FROM THE
                ;19854                                                       ; FIFO AND SAVE IT IN LS
U 11C3, 3E89,15 ;19855          MOV WR[2] TO LS[ADDRESS.DATA]                ;ADDRESS COUNTER
U 11C4, 3732,15 ;19856          MOV LS[PORT0] TO WR[0]                       ;SET UP RECEIVED DATA
U 11C5, B6F6,95 ;19857          MOV LS[SHIFT.OS(4-0)] TO WR[1]               ;SET UP EXPECTED DATA
U 11C6, 0869,3C ;19858          JSR [CHECK.RESULT]                           ;CHECK THE DATA
U 11C7, 891B,E4 ;19859          JMP [LOOP.T1E.PAT3]                          ;LOOP HERE IF ERR & LOE IS SET
U 11C8, 2045,15 ;19860          INC WR[2]                                    ;INCREMENT THE ADRS CNTR
                ;19861          CMP WR[2] WITH LS[#200],                     ;CHECKED ALL LOCATIONS WITH
U 11C9, 4F53,35 ;19862           DT(LONG)&SET.ALU.CC                         ; THIS DATA PATTERN?
U 11CA, 891C,01 ;19863          JMP.IF[NEQ] TO [READ.FIFO.FLOAT1.T1E]        ;JMP IF NOT DONE
                ;19864
U 11CB, 7FF8,15 ;19865          INC LS[OS]                                   ;INCR THE INDEX TO THE NEXT
                ;19866                                                       ; DATA PATTERN
                ;19867          CMP LS[OS] WITH WR[3],                       ;DONE WITH THE FLOATING ONES
U 11CC, 4EF9,B5 ;19868           DT(LONG)&SET.ALU.CC                         ; DATA PATTERNS?
U 11CD, 891B,71 ;19869          JMP.IF[NEQ] TO [WRITE.NEXT.1PAT.T1E]         ;JMP IF NOT DONE
                ;19870
                ;19871  ;FLOATING ZERO PATTERN
                ;19872
U 11CE, 17D8,15 ;19873          PORT.CONTROL [SEL.FIFO.A]                    ;SELECT FIFO A FROM THE PORT
U 11CF, E5F8,15 ;19874          CLR LS[OS]                                   ;CLR THE INDEX TO THE DATA PAT
U 11D0, B647,95 ;19875          MOV LS[#8] TO WR[3]                          ;LAST INDEX TO WRITE A BYTE
                ;19876                                                       ; WITH FLOATING PAT
                ;19877  WRITE.NEXT.0PAT.T1E:
U 11D1, 17C0,15 ;19878          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;SET FIFO A ADDRESS = 0
U 11D2, 2F85,15 ;19879          CLR WR[2]                                    ;USE AS ADDRESS TRACKER
                ;19880
                ;19881  WRITE.FIFO.FLOAT0.T1E:
U 11D3, 36F6,15 ;19882          MOV LS[SHIFT.OS(4-0)] TO WR[0]               ;PUT THE DATA PAT IN WR[0]
U 11D4, 97A8,15 ;19883          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR BYTE OF DATA TO FIFO A
U 11D5, 2045,15 ;19884          INC WR[2]                                    ;INCR THE ADDRS TRACKER
                ;19885          CMP WR[2] WITH LS[#200],
```

```
U 11D6, 4F53,35 ;19886          DT(LONG)&SET.ALU.CC                          ;FIFO ALL WRITTEN WITH PAT?
U 11D7, 091D,31 ;19887          JMP.IF[NEQ] TO [WRITE.FIFO.FLOAT0.T1E]       ;JMP IF NOT DONE
                ;19888
                ;19889  LOOP.T1E.PAT4:
U 11D8, 2F85,15 ;19890          CLR WR[2]                                    ;USE AS THE ADDRESS TRACKER
U 11D9, 17C0,15 ;19891          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;CLR THE ADDRESS COUNTER
                ;19892
                ;19893  READ.FIFO.FLOAT0.T1E:
U 11DA, 9090,15 ;19894          MISC [SET.PORT.I.O]                          ;SELECT THE IDC
U 11DB, 1788,15 ;19895          PORT.READ PORT.ADRS[DATA.BYTE]               ;SET UP TO READ THE FIFO
U 11DC, 3B32,15 ;19896          MOV PORT TO LS[PORT0]                        ;READ A BYTE OF DATA FROM THE
                ;19897                                                       ; FIFO AND SAVE IT IN LS
U 11DD, 3E89,15 ;19898          MOV WR[2] TO LS[ADDRESS.DATA]                ;ADDRESS COUNTER
U 11DE, 3732,15 ;19899          MOV LS[PORT0] TO WR[0]                       ;SET UP RECEIVED DATA
U 11DF, B6F6,95 ;19900          MOV LS[SHIFT.OS(4-0)] TO WR[1]               ;SET UP EXPECTED DATA
U 11E0, 0869,3C ;19901          JSR [CHECK.RESULT]                           ;CHECK THE DATA
U 11E1, 891D,84 ;19902          JMP [LOOP.T1E.PAT4]                          ;LOOP HERE IF ERR & LOE IS SET
U 11E2, 2045,15 ;19903          INC WR[2]                                    ;INCREMENT THE ADRS CNTR
                ;19904          CMP WR[2] WITH LS[#200],                     ;CHECKED ALL LOCATIONS WITH
U 11E3, 4F53,35 ;19905           DT(LONG)&SET.ALU.CC                         ; THIS DATA PATTERN?
U 11E4, 091D,A1 ;19906          JMP.IF[NEQ] TO [READ.FIFO.FLOAT0.T1E]        ;JMP IF NOT DONE
                ;19907
U 11E5, 7FF8,15 ;19908          INC LS[OS]                                   ;INCR THE INDEX TO THE NEXT
                ;19909                                                       ; DATA PATTERN
                ;19910          CMP LS[OS] WITH WR[3],                       ;DONE WITH THE FLOATING ONES
U 11E6, 4EF9,B5 ;19911           DT(LONG)&SET.ALU.CC                         ; DATA PATTERNS?
U 11E7, 891D,11 ;19912          JMP.IF[NEQ] TO [WRITE.NEXT.OPAT.T1E]         ;JMP IF NOT DONE
                ;19913
U 11E8, 8875,3C ;19914          JSR [CLEANUP]                                ;CLEANUP CONDITIONS SET BY THIS
                ;19915                                                       ; TEST
                ;19916
                ;19917  END.T1E:                                             ;END TEST
                ;19918
                ;19919
```

```
;19920  .PAGE  "Test 1F  FIFO B DATA INTEGRITY TEST (M8388 IDC MODULE)"
;19921  ;++
;19922  ;
;19923  ; Test Description:
;19924  ;
;19925  ;       This test is designed to verify that every location in FIFO B can be
;19926  ;       written and read correctly. This will accomplished by doing byte writes
;19927  ;       to every location of FIFO B.
;19928  ;       The data patterns that will be used are:
;19929  ;
;19930  ;               Data Pattern 1 = All ones
;19931  ;               Data Pattern 2 = All zeros
;19932  ;               Data Pattern 3 = Float a one through a field of zeros.
;19933  ;               Data Pattern 4 = Float a zero through a field of ones.
;19934  ;
;19935  ; Assumptions:
;19936  ;
;19937  ;       It is assumed that BUS IN and BUS OUT have been tested and found fully
;19938  ;       operational.
;19939  ;
;19940  ;
;19941  ; Test Steps:
;19942  ;
;19943  ;       1. Set up error mask, error number and module number in LS
;19944  ;          (for error printouts) and clear the previous error number in LS.
;19945  ;       2. Use WR[2] to track the address.
;19946  ;       3. Clear WR[2].
;19947  ;       4. Clear FIFO B Address Counter.
;19948  ;       5. Move the Data Pattern from LS to WR[0].
;19949  ;       6. Do a byte write to FIFO B.
;19950  ;       7. Increment WR[2].
;19951  ;       8. If WR[2] is less than 512, then go to Step 6.
;19952  ;       9. Clear FIFO B Address Counter.
;19953  ;      10. Read a byte from FIFO B.
;19954  ;      11. Check it.
;19955  ;      12. Increment WR[2].
;19956  ;      13. If WR[2] is less than 512 go to Step 10.
;19957  ;      14. Get the next data pattern and go to Step 3 until all data patterns
;19958  ;          have been tested.
;19959  ;
;19960  ; Errors:
;19961  ;
;19962  ;       ERROR 1 - FIFO B failed.
;19963  ;
;19964  ;               Printout:
;19965  ;                       EXPECTED        RECEIVED        OTHER DATA
;19966  ;                       FIFO B          FIFO B          WR[2]
;19967  ;                                                       FIFOB ADDRESS
;19968  ;
;19969  ; Debug:
;19970  ;
;19971  ;       Because of hardware restrictions, this test will only loop on the
;19972  ;       read of address 0 of FIFO B. This will allow verifying the enables.
;19973  ;
;19974  ;       The control logic and the data path has been verified in a previous
```

```
                ;19975  ;       test. Therefore, if the enables are OK, one must determine only which
                ;19976  ;       RAM contains the failure.
                ;19977  ;       FIFO B consists of 4 chips. Address 0 - 255 (0 - FF) are in two chips,
                ;19978  ;       and Address 256-511 (i00 - 1FF) are in two chips.
                ;19979  ;       The failure can be isolated to which one of the two chips by examining
                ;19980  ;       the bit number that failed. Bits <3:0> are in one chip and
                ;19981  ;       bits <7:4> are in the other.
                ;19982  ;
                ;19983  ;--
                ;19984  ;*******************************************************************************
                ;19985  T.1F:
U 11E9, B65E,15 ;19986          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;19987                                                          ; CONTROL AND STATUS WORD
U 11EA, 3E80,15 ;19988          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;19989                                                          ; STATUS WORD - BIT 15
                ;19990                                                          ; INDICATES START OF TEST TO
                ;19991                                                          ; CONSOLE
U 11EB, 10E0,15 ;19992          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;19993  WAIT.T1F.0:
U 11EC, 091E,C4 ;19994          JMP [WAIT.T1F.0]                                ;LOOP HERE WAITING FOR
                ;19995                                                          ; CONSOLE TO RESPOND
                ;19996
U 11ED, 65A0,15 ;19997          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
                ;19998                                                          ; IN LS
                ;19999
U 11EE, B64A,15 ;20000          MOV LS[IDC] TO WR[0]                            ;STORE MODULE CODE IN LS TO
U 11EF, 3E8C,15 ;20001          MOV WR[0] TO LS[MODULE.NUM]                     ; INDICATE IDC MODULE
                ;20002
                ;20003
U 11F0, B640,15 ;20004          MOV LS[#1] TO WR[0]                             ;SET WR0 = 1
U 11F1, BE82,15 ;20005          MOV WR[0] TO LS[ERROR.NUMBER]                   ;SET UP ERROR NUMBER = 1 IN LS
                ;20006
                ;20007
U 11F2, B62C,15 ;20008          MOV LS[#FFFFFF00] TO WR[0]                      ;SET UP THE ERROR MASK TO
U 11F3, 3E8A,15 ;20009          MOV WR[0] TO LS[ERROR.MASK]                     ; CHECK THE LOW BYTE
                ;20010
                ;20011
U 11F4, B670,15 ;20012          MOV LS[OTHER.DATA] TO WR[0]                     ;SET UP CONTROL.STATUS TO PRINT
U 11F5, 3E80,15 ;20013          MOV WR[0] TO LS[CONTROL.STATUS]                 ; OTHER DATA IF ERROR
                ;20014
                ;20015  ;CHECK FIFO WITH ALL ONES
                ;20016
U 11F6, 2F85,15 ;20017          CLR WR[2]                                       ;USE AS ADDRESS TRACKER
U 11F7, 97DC,15 ;20018          PORT.CONTROL [SEL.FIFO.B]                       ;SELECT FIFO B FROM THE PORT
U 11F8, 17C0,15 ;20019          PORT.CONTROL [CLEAR.FIFO.CNTR]                  ;SET FIFO B ADDRESS = 0
U 11F9, B626,15 ;20020          MOV LS[#FF] TO WR[0]                            ;GET THE FIRST DATA PATTERN
                ;20021
                ;20022  WRITE.FIFO.ONES.T1F:
U 11FA, 97A8,15 ;20023          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR BYTE OF DATA TO FIFO B
U 11FB, 2045,15 ;20024          INC WR[2]                                       ;INCR THE ADDRS TRACKER
                ;20025          CMP WR[2] WITH LS[#200],
U 11FC, 4F53,35 ;20026           DT(LONG)&SET.ALU.CC                            ;FIFO ALL WRITTEN WITH PAT?
U 11FD, 891F,A1 ;20027          JMP.IF[NEQ] TO [WRITE.FIFO.ONES.T1F]            ;JMP IF NOT DONE
                ;20028
                ;20029  LOOP.T1F.PAT1:
```

```
U 11FE, 2F85,15 ;20030          CLR WR[2]                                ;USE AS THE ADDRESS TRACKER
U 11FF, 17C0,15 ;20031          PORT.CONTROL [CLEAR.FIFO.CNTR]           ;CLR THE ADDRESS COUNTER
                ;20032
                ;20033  READ.FIFO.ONES.T1F:
U 1200, 9090,15 ;20034          MISC [SET.PORT.I.O]                      ;SELECT THE IDC
U 1201, 1788,15 ;20035          PORT.READ PORT.ADRS[DATA.BYTE]           ;SET UP TO READ THE FIFO
U 1202, 3B32,15 ;20036          MOV PORT TO LS[PORT0]                    ;READ A BYTE OF DATA FROM THE
                ;20037                                                   ; FIFO AND SAVE IT IN LS
U 1203, 3E89,15 ;20038          MOV WR[2] TO LS[ADDRESS.DATA]            ;ADDRESS COUNTER
U 1204, 3732,15 ;20039          MOV LS[PORT0] TO WR[0]                   ;SET UP RECEIVED DATA
U 1205, 3626,95 ;20040          MOV LS[#FF] TO WR[1]                     ;SET UP EXPECTED DATA
U 1206, 0869,3C ;20041          JSR [CHECK.RESULT]                       ;CHECK THE DATA
U 1207, 091F,E4 ;20042          JMP [LOOP.T1F.PAT1]                      ;LOOP HERE IF ERR & LOE IS SET
U 1208, 2045,15 ;20043          INC WR[2]                                ;INCREMENT THE ADRS CNTR
                ;20044          CMP WR[2] WITH LS[#200],
U 1209, 4F53,35 ;20045           DT(LONG)&SET.ALU.CC                     ;CHECKED ALL LOCATIONS?
U 120A, 8920,01 ;20046          JMP.IF[NEQ] TO [READ.FIFO.ONES.T1F]      ;JMP IF NOT DONE
                ;20047
                ;20048  ;CHECK FIFO WITH ALL ZEROS
                ;20049
U 120B, 2F85,15 ;20050          CLR WR[2]                                ;USE AS ADDRESS TRACKER
U 120C, 97DC,15 ;20051          PORT.CONTROL [SEL.FIFO.B]                ;SELECT FIFO B FROM THE PORT
U 120D, 17C0,15 ;20052          PORT.CONTROL [CLEAR.FIFO.CNTR]           ;SET FIFO B ADDRESS = 0
U 120E, 2F80,15 ;20053          CLR WR[0]                                ;GET THE DATA PATTERN
                ;20054
                ;20055  WRITE.FIFO.ZERO.T1F:
U 120F, 97A8,15 ;20056          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR BYTE OF DATA TO FIFO B
U 1210, 2045,15 ;20057          INC WR[2]                                ;INCR THE ADDRS TRACKER
                ;20058          CMP WR[2] WITH LS[#200],
U 1211, 4F53,35 ;20059           DT(LONG)&SET.ALU.CC                     ;FIFO ALL WRITTEN WITH PAT?
U 1212, 8920,F1 ;20060          JMP.IF[NEQ] TO [WRITE.FIFO.ZERO.T1F]     ;JMP IF NOT DONE
                ;20061
                ;20062  LOOP.T1F.PAT2:
U 1213, 2F85,15 ;20063          CLR WR[2]                                ;USE AS THE ADDRESS TRACKER
U 1214, 17C0,15 ;20064          PORT.CONTROL [CLEAR.FIFO.CNTR]           ;CLR THE ADDRESS COUNTER
                ;20065
                ;20066  READ.FIFO.ZERO.T1F:
U 1215, 9090,15 ;20067          MISC [SET.PORT.I.O]                      ;SELECT THE IDC
U 1216, 1788,15 ;20068          PORT.READ PORT.ADRS[DATA.BYTE]           ;SET UP TO READ THE FIFO
U 1217, 3B32,15 ;20069          MOV PORT TO LS[PORT0]                    ;READ A BYTE OF DATA FROM THE
                ;20070                                                   ; FIFO AND SAVE IT IN LS
U 1218, 3E89,15 ;20071          MOV WR[2] TO LS[ADDRESS.DATA]            ;ADDRESS COUNTER
U 1219, 3732,15 ;20072          MOV LS[PORT0] TO WR[0]                   ;SET UP RECEIVED DATA
U 121A, 2F82,95 ;20073          CLR WR[1]                                ;SET UP EXPECTED DATA
U 121B, 0869,3C ;20074          JSR [CHECK.RESULT]                       ;CHECK THE DATA
U 121C, 0921,34 ;20075          JMP [LOOP.T1F.PAT2]                      ;LOOP HERE IF ERR & LOE IS SET
U 121D, 2045,15 ;20076          INC WR[2]                                ;INCREMENT THE ADRS CNTR
                ;20077          CMP WR[2] WITH LS[#200],
U 121E, 4F53,35 ;20078           DT(LONG)&SET.ALU.CC                     ;CHECKED ALL LOCATIONS?
U 121F, 0921,51 ;20079          JMP.IF[NEQ] TO [READ.FIFO.ZERO.T1F]      ;JMP IF NOT DONE
                ;20080
                ;20081  ;FLOATINGS ONES PATTERN
                ;20082
U 1220, 97DC,15 ;20083          PORT.CONTROL [SEL.FIFO.B]                ;SELECT FIFO B FROM THE PORT
U 1221, E5F8,15 ;20084          CLR LS[OS]                               ;CLR THE INDEX TO THE DATA PAT
```

```
U 1222, B647,95 ;20085          MOV LS[#8] TO WR[3]                          ;LAST INDEX TO WRITE A BYTE
                ;20086                                                       ; WITH FLOATING PAT
                ;20087
                ;20088  WRITE.NEXT.1PAT.T1F:
U 1223, 17C0,15 ;20089          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;SET FIFO B ADDRESS = 0
U 1224, 2F85,15 ;20090          CLR WR[2]                                    ;USE AS ADDRESS TRACKER
                ;20091
                ;20092  WRITE.FIFO.FLOAT1.T1F:
U 1225, 36F6,15 ;20093          MOV LS[SHIFT.OS(4-0)] TO WR[0]               ;PUT THE DATA PAT IN WR[0]
U 1226, 97A8,15 ;20094          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]   ;WR BYTE OF DATA TO FIFO B
U 1227, 2045,15 ;20095          INC WR[2]                                    ;INCR THE ADDRS TRACKER
                ;20096          CMP WR[2] WITH LS[#200],
U 1228, 4F53,35 ;20097           DT(LONG)&SET.ALU.CC                         ;FIFO ALL WRITTEN WITH PAT?
U 1229, 0922,51 ;20098          JMP.IF[NEQ] TO [WRITE.FIFO.FLOAT1.T1F]       ;JMP IF NOT DONE
                ;20099
                ;20100  LOOP.T1F.PAT3:
U 122A, 2F85,15 ;20101          CLR WR[2]                                    ;USE AS THE ADDRESS TRACKER
U 122B, 17C0,15 ;20102          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;CLR THE ADDRESS COUNTER
                ;20103
                ;20104  READ.FIFO.FLOAT1.T1F:
U 122C, 9090,15 ;20105          MISC [SET.PORT.I.O]                          ;SELECT THE IDC
U 122D, 1788,15 ;20106          PORT.READ PORT.ADRS[DATA.BYTE]               ;SET UP TO READ THE FIFO
U 122E, 3B32,15 ;20107          MOV PORT TO LS[PORT0]                        ;READ A BYTE OF DATA FROM THE
                ;20108                                                       ; FIFO AND SAVE IT IN LS
U 122F, 3E89,15 ;20109          MOV WR[2] TO LS[ADDRESS.DATA]                ;ADDRESS COUNTER
U 1230, 3732,15 ;20110          MOV LS[PORT0] TO WR[0]                       ;SET UP RECEIVED DATA
U 1231, B6F6,95 ;20111          MOV LS[SHIFT.OS(4-0)] TO WR[1]               ;SET UP EXPECTED DATA
U 1232, 0869,3C ;20112          JSR [CHECK.RESULT]                           ;CHECK THE DATA
U 1233, 0922,A4 ;20113          JMP [LOOP.T1F.PAT3]                          ;LOOP HERE IF ERR & LOE IS SET
U 1234, 2045,15 ;20114          INC WR[2]                                    ;INCREMENT THE ADRS CNTR
                ;20115          CMP WR[2] WITH LS[#200],                     ;CHECKED ALL LOCATIONS WITH
U 1235, 4F53,35 ;20116           DT(LONG)&SET.ALU.CC                         ; THIS DATA PATTERN?
U 1236, 0922,C1 ;20117          JMP.IF[NEQ] TO [READ.FIFO.FLOAT1.T1F]        ;JMP IF NOT DONE
                ;20118
U 1237, 7FF8,15 ;20119          INC LS[OS]                                   ;INCR THE INDEX TO THE NEXT
                ;20120                                                       ; DATA PATTERN
                ;20121          CMP LS[OS] WITH WR[3],                       ;DONE WITH THE FLOATING ONES
U 1238, 4EF9,B5 ;20122           DT(LONG)&SET.ALU.CC                         ; DATA PATTERNS?
U 1239, 0922,31 ;20123          JMP.IF[NEQ] TO [WRITE.NEXT.1PAT.T1F]         ;JMP IF NOT DONE
                ;20124
                ;20125  ;FLOATING ZERO PATTERN
                ;20126
U 123A, 97DC,15 ;20127          PORT.CONTROL [SEL.FIFO.B]                    ;SELECT FIFO B FROM THE PORT
U 123B, E5F8,15 ;20128          CLR LS[OS]                                   ;CLR THE INDEX TO THE DATA PAT
U 123C, B647,95 ;20129          MOV LS[#8] TO WR[3]                          ;LAST INDEX TO WRITE A BYTE
                ;20130                                                       ; WITH FLOATING PAT
                ;20131  WRITE.NEXT.0PAT.T1F:
U 123D, 17C0,15 ;20132          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;SET FIFO B ADDRESS = 0
U 123E, 2F85,15 ;20133          CLR WR[2]                                    ;USE AS ADDRESS TRACKER
                ;20134
                ;20135  WRITE.FIFO.FLOAT0.T1F:
U 123F, 36F6,15 ;20136          MOV LS[SHIFT.OS(4-0)] TO WR[0]               ;PUT THE DATA PAT IN WR[0]
U 1240, 97A8,15 ;20137          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]   ;WR BYTE OF DATA TO FIFO B
U 1241, 2045,15 ;20138          INC WR[2]                                    ;INCR THE ADDRS TRACKER
                ;20139          CMP WR[2] WITH LS[#200],
```

```
U 1242, 4F53,35 ;20140          DT(LONG)&SET.ALU.CC                          ;FIFO ALL WRITTEN WITH PAT?
U 1243, 8923,F1 ;20141          JMP.IF[NEQ] TO [WRITE.FIFO.FLOAT0.T1F]       ;JMP IF NOT DONE
                ;20142
                ;20143  LOOP.T1F.PAT4:
U 1244, 2F85,15 ;20144          CLR WR[2]                                    ;USE AS THE ADDRESS TRACKER
U 1245, 17C0,15 ;20145          PORT.CONTROL [CLEAR.FIFO.CNTR]               ;CLR THE ADDRESS COUNTER
                ;20146
                ;20147  READ.FIFO.FLOAT0.T1F:
U 1246, 9090,15 ;20148          MISC [SET.PORT.I.0]                          ;SELECT THE IDC
U 1247, 1788,15 ;20149          PORT.READ PORT.ADRS[DATA.BYTE]               ;SET UP TO READ THE FIFO
U 1248, 3B32,15 ;20150          MOV PORT TO LS[PORT0]                        ;READ A BYTE OF DATA FROM THE
                ;20151                                                       ; FIFO AND SAVE IT IN LS
U 1249, 3E89,15 ;20152          MOV WR[2] TO LS[ADDRESS.DATA]                ;ADDRESS COUNTER
U 124A, 3732,15 ;20153          MOV LS[PORT0] TO WR[0]                       ;SET UP RECEIVED DATA
U 124B, B6F6,95 ;20154          MOV LS[SHIFT.OS(4-0)] TO WR[1]               ;SET UP EXPECTED DATA
U 124C, 0869,3C ;20155          JSR [CHECK.RESULT]                           ;CHECK THE DATA
U 124D, 8924,44 ;20156          JMP [LOOP.T1F.PAT4]                          ;LOOP HERE IF ERR & LOE IS SET
U 124E, 2045,15 ;20157          INC WR[2]                                    ;INCREMENT THE ADRS CNTR
                ;20158          CMP WR[2] WITH LS[#200],                     ;CHECKED ALL LOCATIONS WITH
U 124F, 4F53,35 ;20159           DT(LONG)&SET.ALU.CC                         ; THIS DATA PATTERN?
U 1250, 0924 61 ;20160          JMP.IF[NEQ] TO [READ.FIFO.FLOAT0.T1F]        ;JMP IF NOT DONE
                ;20161
U 1251, 7FF8,15 ;20162          INC LS[OS]                                   ;INCR THE INDEX TO THE NEXT
                ;20163                                                       ; DATA PATTERN
                ;20164          CMP LS[OS] WITH WR[3],                       ;DONE WITH THE FLOATING ONES
U 1252, 4EF9,B5 ;20165           DT(LONG)&SET.ALU.CC                         ; DATA PATTERNS?
U 1253, 0923,D1 ;20166          JMP.IF[NEQ] TO [WRITE.NEXT.OPAT.T1F]         ;JMP IF NOT DONE
                ;20167
U 1254, 8875,3C ;20168          JSR [CLEANUP]                                ;CLEANUP CONDITIONS SET BY THIS
                ;20169                                                       ; TEST
                ;20170
                ;20171  END.T1F:                                             ;END TEST
                ;20172
                ;20173
                ;20174
```

```
;20175  .PAGE  "Test 20  I/O BUS IN AND OUT LATCHES TEST (M8388 IDC MODULE)"
;20176  ;++
;20177  ;
;20178  ; Test Description:
;20179  ;
;20180  ;       This test is designed to verify the I/O BUS IN and I/O BUS OUT LATCHES
;20181  ;       which buffer data to and from the FIFOs. This will be accomplished by
;20182  ;       doing longword writes to FIFO A and then doing longword reads of
;20183  ;       the data. The data patterns that will be used are:
;20184  ;
;20185  ;               Data pattern 1 = AAAAAAAA
;20186  ;               Data pattern 2 = 55555555
;20187  ;               Data pattern 3 = 33333333
;20188  ;               Data pattern 4 = 0F0F0F0F
;20189  ;               Data pattern 5 = 00FF00FF
;20190  ;               Data pattern 6 = 0000FFFF
;20191  ;
;20192  ; Assumptions:
;20193  ;
;20194  ;       It is assumed that all previous tests have run successfully.
;20195  ;
;20196  ; Test Steps:
;20197  ;
;20198  ;       1. Set up error mask, error number and module number in LS
;20199  ;          (for error printouts) and clear the previous error number in LS.
;20200  ;       2. Mov the data pattern from LS to WR[0].
;20201  ;       3. Clear the FIFO Address Counter.
;20202  ;       4. Do a WRITE.DATA.WORD to FIFO A. ( Word = 32 bits.)
;20203  ;       5. Clear the FIFO Address Counter.
;20204  ;       6. Read FIFO A.
;20205  ;       7. Check the data.
;20206  ;       8. Get the next data pattern and go to Step 2 until all patterns have
;20207  ;          been tested.
;20208  ;
;20209  ; Errors:
;20210  ;
;20211  ;       ERROR 1 - The data read from FIFO A was incorrect.
;20212  ;
;20213  ;               Printout:
;20214  ;                       EXPECTED          RECEIVED
;20215  ;                     FIFO A DATA       FIFO A DATA
;20216  ; Debug:
;20217  ;
;20218  ;  ERROR 1:
;20219  ;
;20220  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;20221  ;       instruction. This instruction is decoded by the PORT INTERFACE REG PAL.
;20222  ;       The inputs will be:
;20223  ;               CSR 17 H = H
;20224  ;               CSR 14 H = H
;20225  ;               CSR 12 H = H
;20226  ;               CSR 11 H = H
;20227  ;               CSR 10 H = L
;20228  ;               PORT INSTR H = H
;20229  ;               CPU P2 H = H
```

```
;20230  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;20231  ;
;20232  ;    WRITE.DATA.WORD:
;20233  ;
;20234  ;       This instruction will be decoded by the PORT RD/WR DECODE PAL.
;20235  ;       When the instruction is issued, the inputs to this PAL will be:
;20236  ;               CSR 17 H = H
;20237  ;               CSR 14 H = L
;20238  ;               CSR 13 H = H
;20239  ;               CSR 12 H = L
;20240  ;               CSR 11 H = H
;20241  ;               CSR 10 H = H
;20242  ;               PORT INSTR H = H
;20243  ;               CPU P2 H = H
;20244  ;
;20245  ;       This combination of inputs will assert WRITE DATA L and STROBE
;20246  ;       DATA H. STROBE DATA H will clock the data from the I/O BUS into the
;20247  ;       I/O BUS IN LATCHES.
;20248  ;       WRITE DATA L is an input to the PORT USEQ A and B PALS.
;20249  ;       These PALS cannot be single stepped. If the CPU is in single step
;20250  ;       mode when this instruction is issued, the PORT USEQ A and B PALS
;20251  ;       will complete the following sequence before the next micro-state.
;20252  ;
;20253  ;       On the first CPU CLOCK H pulse after WRITE DATA L asserts, the PORT
;20254  ;       USEQ PALS will enable Byte 0 to be written into
;20255  ;       FIFO A and then the address is incremented. On the next clock pulse
;20256  ;       the next byte is written and the address incremented. This continues
;20257  ;       until the entire longword has been written into the FIFO. At the end
;20258  ;       of this sequence, BRANCH TEST L will assert to wait for the next
;20259  ;       instruction.
;20260  ;
;20261  ;    READ.DATA.WORD:
;20262  ;
;20263  ;       The CPU will clear the FIFO Address Counter and then read the FIFO.
;20264  ;       The CPU must then issue a MISC [SET.PORT.I.O] which will assert
;20265  ;       SEL IDC H. The CPU will then issue the PORT.READ PORT ADRS[DATA.WORD]
;20266  ;       instruction. This instruction will be decoded by the PORT INTERFACE REG
;20267  ;       PAL and the PORT RD/WR DECODE PAL. The inputs to the PORT RD/WR DECODE
;20268  ;       PAL will be:
;20269  ;               CSR 17 H = H
;20270  ;               CSR 14 H = L
;20271  ;               CSR 13 H = L
;20272  ;               CSR 12 H = L
;20273  ;               CSR 11 H = H
;20274  ;               CSR 10 H = H
;20275  ;               PORT INSTR H = H
;20276  ;               CPU P2 H = H
;20277  ;       These inputs will assert READ DATA L. This signal as an input to the
;20278  ;       PORT USEQ A PAL when BRANCH TEST L is asserted and the PAL is clocked,
;20279  ;       will assert PENB FIFO H and PINCR FIFO CNTR H. PENB FIFO H is ANDED
;20280  ;       with PSEL FIFOA H and will assert ENB FIFOA L which enables the data
;20281  ;       from the FIFO onto BUS OUT. At the same time,READ DATA L as an input
;20282  ;       to PORT USEQ B PAL will assert PLOAD OUTREG BO L when BRANCH TEST L
;20283  ;       is asserted and the PAL is clocked. PLOAD OUTREG BO L will clock the
;20284  ;       data on BUS OUT into Byte 0 of the I/O BUS OUT LATCHES. The FIFO
```

```
                ;20285  ;       Address Counter will the be clocked by PINCR FIFO CNTR H. The PORT USEQ
                ;20286  ;       PALS will then sequence through and output the data from the FIFO to
                ;20287  ;       the I/O BUS OUT LATCHES a byte at a time. When the last byte has been
                ;20288  ;       loaded, BRANCH TEST L will assert to wait for the next instruction.
                ;20289  ;       The CPU will issue a MOV PORT TO LS[] instruction. This will assert
                ;20290  ;       READ PORT L which is an input to the PORT INTERFACE REG PAL. At the
                ;20291  ;       next CPU Clock pulse, output READ PORT H will assert. This signal
                ;20292  ;       will be ANDED with SEL IDC H and SEL ACC L and will assert READ
                ;20293  ;       IDC L. READ PORT H and READ IDC L are the enables for the Decoder of
                ;20294  ;       R<2:0> which were outputs from the PORT INTERFACE REG PAL. When R<2:0>
                ;20295  ;       are decoded, SEL WORD L will assert. This signal will assert ENB
                ;20296  ;       OUTREG L which will enable the I/O BUS OUT LATCHES onto the I/O BUS.
                ;20297  ;       READ IDC L as the direction input to the Y BUS Transceivers,
                ;20298  ;       will direct the I/O BUS onto the Y BUS.
                ;20299  ;--
                ;20300  ;*******************************************************************************
                ;20301  T.20:
U 1255, B65E,15 ;20302          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;20303                                                  ; CONTROL AND STATUS WORD
U 1256, 3E80,15 ;20304          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;20305                                                  ; STATUS WORD - BIT 15
                ;20306                                                  ; INDICATES START OF TEST TO
                ;20307                                                  ; CONSOLE
U 1257, 10E0,15 ;20308          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;20309  WAIT.T20.0:
U 1258, 0925,84 ;20310          JMP [WAIT.T20.0]                        ;LOOP HERE WAITING FOR
                ;20311                                                  ; CONSOLE TO RESPOND
                ;20312
U 1259, 65A0,15 ;20313          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;20314                                                  ; IN LS
                ;20315
U 125A, B64A,15 ;20316          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 125B, 3E8C,15 ;20317          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;20318
                ;20319
U 125C, B640,15 ;20320          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 125D, BE82,15 ;20321          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;20322
U 125E, E58A,15 ;20323          CLR LS[ERROR.MASK]                      ;SET UP ERROR MASK TO CHECK
                ;20324                                                  ; ALL BITS
                ;20325
U 125F, 2F85,15 ;20326          CLR WR[2]                               ;USE AS A LOOP COUNTER
U 1260, B699,95 ;20327          MOV LS[#AAAAAAAA] TO WR[3]              ;GET THE DATA PAT
                ;20328  CHK.NXT.PAT.T20:
                ;20329  LOOP.T20.1:
U 1261, 17D8,15 ;20330          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A FROM THE PORT
U 1262, 17C0,15 ;20331          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
                ;20332
U 1263, A006,15 ;20333          MOV WR[3] TO WR[0]                      ;MOV THE PAT TO WR[0] FOR WRITE
U 1264, 17AC,15 ;20334          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WR LONG WORD OF DATA
                ;20335
U 1265, 17C0,15 ;20336          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO ADDRESS = 0
                ;20337
                ;20338  READ.FIFO.T20.1:
U 1266, 9090,15 ;20339          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
```

```
U 1267, 978C,15 ;20340          PORT.READ PORT.ADRS[DATA.WORD]          ;SET UP TO READ THE FIFO
U 1268, DB00,15 ;20341          NOP                                     ;ALLOW TIME FOR LONGWORD
U 1269, 3B32,15 ;20342          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM FIFO AND
                ;20343                                                  ; SAVE IT IN LS
U 126A, 3732,15 ;20344          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 126B, 2006,95 ;20345          MOV WR[3] TO WR[1]                      ;SET UP EXPECTED DATA
U 126C, 0869,3C ;20346          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 126D, 0926,14 ;20347          JMP [LOOP.T20.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;20348
                ;20349
                ;20350          CMP WR[2] WITH LS[ZERO],                ;FIRST LOOP COUNT?
U 126E, CF9D,35 ;20351           DT(LONG)&SET.ALU.CC
U 126F, 0927,31 ;20352          JMP.IF[NEQ] TO [CHK.LPCNT.T20.1]        ;JMP IF NOT FIRST
U 1270, 369B,95 ;20353          MOV LS[#55555555] TO WR[3]              ;GET DATA PATTERN 2
U 1271, 2045,15 ;20354          INC WR[2]                               ;INCR THE LOOP COUNT
U 1272, 0926,14 ;20355          JMP [CHK.NXT.PAT.T20]                   ;CHECK THE NEXT PATTERN
                ;20356
                ;20357  CHK.LPCNT.T20.1:
                ;20358          CMP WR[2] WITH LS[#1],                  ;SECOND LOOP COUNT?
U 1273, 4F41,35 ;20359           DT(LONG)&SET.ALU.CC
U 1274, 8927,81 ;20360          JMP.IF[NEQ] TO [CHK.LPCNT.T20.2]
U 1275, B6C5,95 ;20361          MOV LS[#33333333] TO WR[3]              ;GET DATA PATTERN 3
U 1276, 2045,15 ;20362          INC WR[2]                               ;INCR THE LOOP COUNT
U 1277, 0926,14 ;20363          JMP [CHK.NXT.PAT.T20]                   ;CHECK THE NEXT PATTERN
                ;20364
                ;20365  CHK.LPCNT.T20.2:
                ;20366          CMP WR[2] WITH LS[#2],                  ;THIRD  LOOP COUNT?
U 1278, CF43,35 ;20367           DT(LONG)&SET.ALU.CC
U 1279, 8927,D1 ;20368          JMP.IF[NEQ] TO [CHK.LPCNT.T20.3]        ;JMP IF NOT
U 127A, 36C7,95 ;20369          MOV LS[#0F0F0F0F] TO WR[3]              ;GET DATA PATTERN 4
U 127B, 2045,15 ;20370          INC WR[2]                               ;INCR THE LOOP COUNT
U 127C, 0926,14 ;20371          JMP [CHK.NXT.PAT.T20]                   ;CHECK THE NEXT PATTERN
                ;20372
                ;20373  CHK.LPCNT.T20.3:
U 127D, 3788,95 ;20374          MOV LS[#3] TO WR[1]
                ;20375          CMP WR[2] WITH WR[1],                   ;FOURTH LOOP COUNT?
U 127E, A644,B5 ;20376           DT(LONG)&SET.ALU.CC
U 127F, 0928,31 ;20377          JMP.IF[NEQ] TO [CHK.LPCNT.T20.4]        ;JMP IF NOT
U 1280, B6C9,95 ;20378          MOV LS[#00FF00FF] TO WR[3]              ;GET DATA PATTERN 5
U 1281, 2045,15 ;20379          INC WR[2]                               ;INCR THE LOOP COUNT
U 1282, 0926,14 ;20380          JMP [CHK.NXT.PAT.T20]                   ;CHECK THE NEXT PATTERN
                ;20381
                ;20382  CHK.LPCNT.T20.4:
                ;20383          CMP WR[2] WITH LS[#4],                  ;LAST LOOP COUNT?
U 1283, CF45,35 ;20384           DT(LONG)&SET.ALU.CC
U 1284, 8928,81 ;20385          JMP.IF[NEQ] TO [CLEANUP.T20]            ;JMP IF DONE
U 1285, B773,95 ;20386          MOV LS[#0000FFFF] TO WR[3]              ;GET DATA PATTERN 6
U 1286, 2045,15 ;20387          INC WR[2]                               ;INCR THE LOOP COUNT
U 1287, 0926,14 ;20388          JMP [CHK.NXT.PAT.T20]                   ;CHECK THE NEXT PATTERN
                ;20389
                ;20390  CLEANUP.T20:
U 1288, 8875,3C ;20391          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;20392                                                  ; THIS TEST
                ;20393
                ;20394  END.T20:                                        ;END TEST
```

```
                ;20395
                ;20396
```

```
;20397  .PAGE  "Test 21  FIFO A AND FIFO B UNIQUENESS TEST (M8388 IDC MODULE)"
;20398  ;++
;20399  ;
;20400  ; Test Description:
;20401  ;
;20402  ;       This test is designed to insure that FIFO A and FIFO B Port control
;20403  ;       lines are operating independent of one another.
;20404  ;
;20405  ;       FIFO A, Address 0 will be written with all ones. Then FIFO B,
;20406  ;       Address 0 will be written with all zeros. FIFO A, Adress 0 will
;20407  ;       then be checked to insure that it still contains all ones.
;20408  ;
;20409  ; Assumptions:
;20410  ;
;20411  ;       It is assumed that all previous tests have run successfully.
;20412  ;
;20413  ; Test Steps:
;20414  ;
;20415  ;       1. Set up error mask, error number and module number in LS
;20416  ;          (for error printouts) and clear the previous error number in LS.
;20417  ;       2. Clear the FIFO A Adrs Counter.
;20418  ;       3. Move FF to WR[0].
;20419  ;       4. Write FIFO A with FF.
;20420  ;       5. Clear the FIFO B Adrs Counter.
;20421  ;       6. Move 0 to WR[0].
;20422  ;       7. Write FIFO B with 0.
;20423  ;       8. Clear the FIFO A Adrs Counter.
;20424  ;       9. Read Address 0 of FIFO A.
;20425  ;      10. Check for all ones.
;20426  ;      11. End test.
;20427  ;
;20428  ; Errors:
;20429  ;
;20430  ;       ERROR 1 - The data read from FIFO A was incorrect.
;20431  ;
;20432  ;                 Printout:
;20433  ;                         EXPECTED          RECEIVED
;20434  ;                       FIFO A DATA       FIFO A DATA
;20435  ; Debug:
;20436  ;
;20437  ; ERROR 1:
;20438  ;       FIFO A is selected by the port by a PORT.CONTROL [SEL.FIFO.A]
;20439  ;       instruction. This instruction is decoded by the PORT INTERFACE REG PAL.
;20440  ;       The inputs will be:
;20441  ;               CSR 17 H = H
;20442  ;               CSR 14 H = H
;20443  ;               CSR 12 H = H
;20444  ;               CSR 11 H = H
;20445  ;               CSR 10 H = L
;20446  ;               PORT INSTR H = H
;20447  ;               CPU P2 H = H
;20448  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will assert.
;20449  ;
;20450  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;20451  ;       be decoded by the PORT INTERFACE REG PAL.
```

```
;20452  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;20453  ;
;20454  ;                       CSR 17 H = H
;20455  ;                       CSR 14 H = H
;20456  ;                       CSR 12 H = L
;20457  ;                       CSR 11 H = L
;20458  ;                       CSR 10 H = L
;20459  ;                       PORT INSTR H = H
;20460  ;                       CPU P2 H = H
;20461  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;20462  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;20463  ;       the address lines.
;20464  ;
;20465  ;       The data to be written #FF is put in WR[0].
;20466  ;       The CPU will then issue a PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0].
;20467  ;       This instruction will be decoded in the PORT RD/WR DECODE PAL.
;20468  ;       The inputs to this PAL will be:
;20469  ;               CSR 17 H = H
;20470  ;               CSR 14 H = L
;20471  ;               CSR 13 H = H
;20472  ;               CSR 12 H = L
;20473  ;               CSR 11 H = H
;20474  ;               CSR 10 H = L
;20475  ;               PORT INSTR H = H
;20476  ;               CPU P2 H = H
;20477  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;20478  ;       STROBE DATA H.
;20479  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS. This
;20480  ;       combination of inputs will assert PWRITE FIFO H and PENB INREG B0 L.
;20481  ;       PENB INREG B0 L and STROBE DATA H will enable the data from the I/O Bus
;20482  ;       onto BUS IN. PWRITE FIFO H will be ANDED with PSEL FIFOA H= H and PORT
;20483  ;       CLK L. This combination of signals will assert WRITE FIFOA L which will
;20484  ;       write the data which is on BUS IN into FIFOA.
;20485  ;
;20486  ;       FIFO B is then selected by the port by a PORT.CONTROL [SEL.FIFO.B]
;20487  ;       instruction. This instruction is decoded by the PORT INTERFACE REG PAL.
;20488  ;       The inputs will be:
;20489  ;               CSR 17 H = H
;20490  ;               CSR 14 H = H
;20491  ;               CSR 12 H = H
;20492  ;               CSR 11 H = H
;20493  ;               CSR 10 H = H
;20494  ;               PORT INSTR H = H
;20495  ;               CPU P2 H = H
;20496  ;
;20497  ;       When the PAL is clocked by CPU CLOCK H, PSEL FIFO A H will deassert.
;20498  ;       PSEL FIFO B H = H, is the inverse of PSEL FIFO A H = L.
;20499  ;
;20500  ;       The CPU will issue  PORT.CONTROL [CLEAR.FIFO.CNTR] which will
;20501  ;       be decoded by the PORT INTERFACE REG PAL.
;20502  ;       The inputs to the PORT INTERFACE REG PAL will be as follows:
;20503  ;
;20504  ;                       CSR 17 H = H
;20505  ;                       CSR 14 H = H
;20506  ;                       CSR 12 H = L
```

```
;20507  ;                       CSR 11 H = L
;20508  ;                       CSR 10 H = L
;20509  ;                       PORT INSTR H = H
;20510  ;                       CPU P2 H = H
;20511  ;       When CPU CLOCK H clocks the PAL, PCLR FIFO CNTR H will assert. This
;20512  ;       signal is an input to the FIFO ADRS CNTR PALS and will clear all of
;20513  ;       the address lines.
;20514  ;
;20515  ;       The data to be written (0) is put on WR[0].
;20516  ;       The CPU will then issue a PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0].
;20517  ;       This instruction will be decoded in the PORT RD/WR DECODE PAL.
;20518  ;       The inputs to this PAL will be:
;20519  ;               CSR 17 H = H
;20520  ;               CSR 14 H = L
;20521  ;               CSR 13 H = H
;20522  ;               CSR 12 H = L
;20523  ;               CSR 11 H = H
;20524  ;               CSR 10 H = L
;20525  ;               PORT INSTR H = H
;20526  ;               CPU P2 H = H
;20527  ;       This combination of inputs will assert BYTE L and WRITE DATA L, and
;20528  ;       STROBE DATA H.
;20529  ;       BYTE L and WRITE DATA L are inputs to the PORT USEQ A & B PALS. This
;20530  ;       combination of inputs will assert PWRITE FIFO H and PENB INREG B0 L.
;20531  ;       PENB INREG B0 L and STROBE DATA H will enable the data from the I/O Bus
;20532  ;       onto BUS IN. PWRITE FIFO H is  ANDED with PSEL FIFOB H= H and PORT
;20533  ;       CLK L. This combination of signals will assert WRITE FIFOB L which will
;20534  ;       write the data which is on BUS IN into FIFOB.
;20535  ;
;20536  ;       FIFO A will again be selected and the address lines cleared.
;20537  ;       To read a byte of data from the FIFO, the CPU must first issue a
;20538  ;       MISC [SET.PORT.I.O] which will assert SEL IDC H.
;20539  ;       The CPU then  will do a PORT.READ PORT ADRS[DATA.BYTE]. This
;20540  ;       instruction will be decoded by PORT INTERFACE REGISTER PAL and the
;20541  ;       PORT RD/WR DECODE PAL. The inputs to the PORT RD/WR DECODE PAL will
;20542  ;       be:
;20543  ;               CSR 17 H = H
;20544  ;               CSR 14 H = L
;20545  ;               CSR 13 H = L
;20546  ;               CSR 12 H = L
;20547  ;               CSR 11 H = H
;20548  ;               CSR 10 H = L
;20549  ;               PORT INSTR H = H
;20550  ;               CPU P2 H = H
;20551  ;       These inputs will assert READ DATA L and BYTE L.
;20552  ;       These two signals are inputs to the PORT USEQ A and B PALS. These PALS
;20553  ;       do not single-step with the CPU since they are clocked by CPU CLOCK H
;20554  ;       which is a free running clock.
;20555  ;       BRANCH TEST L will be asserted. When PORT USEQ PALS are clocked after
;20556  ;       READ DATA L and BYTE L assert, the outputs of PORT USEQ A will be:
;20557  ;               PORT NAD 0 H = H
;20558  ;               PORT NAD 1 H = H
;20559  ;               PORT NAD 2 H = H
;20560  ;               BRANCH TEST L = H
;20561  ;               PENB FIFO H = H
```

```
                ;20562  ;               PINCR FIFO CNTR H = H
                ;20563  ;               PWRITE FIFO H = L
                ;20564  ;
                ;20565  ;       The only output of PORT USEQ B that will assert is PLOAD OUTREG BO L.
                ;20566  ;
                ;20567  ;       PENB FIFO H is ANDED with PSEL FIFOA H = H and asserts
                ;20568  ;       ENB FIFOA L which enables address 0 of FIFOA onto BUS OUT. PLOAD OUTREG
                ;20569  ;       BO L clocks this data into the I/O BUS OUT LATCHES.
                ;20570  ;
                ;20571  ;       At the same time, the PORT INTERFACE REG PAL is decoding the same
                ;20572  ;       instruction. The inputs to this PAL will be:
                ;20573  ;
                ;20574  ;               CSR 17 H = H
                ;20575  ;               CSR 14 H = L
                ;20576  ;               READ PORT L = H
                ;20577  ;               CSR 12 H = L
                ;20578  ;               CSR 11 H = H
                ;20579  ;               CSR 10 H = L
                ;20580  ;               PORT INSTR H = H
                ;20581  ;               CPU P2 H = H
                ;20582  ;       On the next CPU CLOCK H, the outputs will be:
                ;20583  ;
                ;20584  ;               SEL IDC H = H
                ;20585  ;               R2 L = H
                ;20586  ;               R1 L = L
                ;20587  ;               RO L = H
                ;20588  ;               PSEL FIFOA H = H
                ;20589  ;
                ;20590  ;       The CPU will then issue a MOV PORT TO LS[] instruction. This will
                ;20591  ;       assert READ PORT L which is an input to the PORT INTERFACE REG PAL.
                ;20592  ;       At the next CPU CLOCK , output READ PORT H will assert.
                ;20593  ;       This signal is one of the enables to the decoder of R<2:0>.
                ;20594  ;       READ PORT H is also ANDED with SEL IDC H, which will be asserted,
                ;20595  ;       and SEL ACC L = H. This combination of inputs will assert READ IDC L
                ;20596  ;       which is the enable to the decoder of R<2:0>.
                ;20597  ;       The combination of R<2:0> inputs that were previously latched by the
                ;20598  ;       PORT INTERFACE REG PAL, will assert SEL BYTE L. This signal is ORED
                ;20599  ;       with SEL WORD L and will assert ENB OUTREG L. ENB OUTREG L is the
                ;20600  ;       output enable for the I/O BUS OUT LATCHES and outputs the data onto
                ;20601  ;       the I/O BUS.
                ;20602  ;       READ IDC L which was previously asserted, directs the Tranceivers to
                ;20603  ;       take the data from the I/O BUS and put it on the Y BUS. The CPU then
                ;20604  ;       moves the data to an LS location.
                ;20605  ;
                ;20606  ;       The CPU will then read and check the LS location.
                ;20607  ;
                ;20608  ;--
                ;20609  ;*****************************************************************************
                ;20610  T.21:
U 1289, B65E,15 ;20611          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;20612                                                  ; CONTROL AND STATUS WORD
U 128A, 3E80,15 ;20613          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;20614                                                  ; STATUS WORD - BIT 15
                ;20615                                                  ; INDICATES START OF TEST TO
                ;20616                                                  ; CONSOLE
```

```
U 128B, 10E0,15 ;20617          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;20618  WAIT.T21.0:
U 128C, 0928,C4 ;20619          JMP [WAIT.T21.0]                                ;LOOP HERE WAITING FOR
                ;20620                                                  ; CONSOLE TO RESPOND
                ;20621
U 128D, 65A0,15 ;20622          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;20623                                                  ; IN LS
                ;20624
U 128E, B64A,15 ;20625          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 128F, 3E8C,15 ;20626          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;20627
                ;20628
U 1290, B640,15 ;20629          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1291, BE82,15 ;20630          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;20631
U 1292, B62C,15 ;20632          MOV LS[#FFFFFF00] TO WR[0]              ;SET UP THE ERROR MASK TO
U 1293, 3E8A,15 ;20633          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK THE LO BYTE
                ;20634
                ;20635  LOOP.T21.1:
U 1294, 17D8,15 ;20636          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1295, 17C0,15 ;20637          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
U 1296, B626,15 ;20638          MOV LS[#FF] TO WR[0]                    ;GET THE DATA TO WRITE
U 1297, 97A8,15 ;20639          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR BYTE OF ONES TO FIFO A
U 1298, 97DC,15 ;20640          PORT.CONTROL [SEL.FIFO.B]               ;SELECT FIFO B
U 1299, 17C0,15 ;20641          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
U 129A, 2F80,15 ;20642          CLR WR[0]                               ;GET THE DATA TO WRITE
U 129B, 97A8,15 ;20643          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR 0 TO FIFO B ADRS=0
U 129C, 17D8,15 ;20644          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 129D, 17C0,15 ;20645          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
                ;20646
                ;20647  READ.FIFO.T21:
U 129E, 9090,15 ;20648          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 129F, 1788,15 ;20649          PORT.READ PORT.ADRS[DATA.BYTE]          ;SET UP TO READ FIFO A ADRS =0
U 12A0, 3B32,15 ;20650          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM THE FIFO
                ;20651                                                  ; AND SAVE IT IN  LS
U 12A1, 1080,15 ;20652          MISC [SET.ACC.I.O]                      ;RETURN SELECT TO ACCELERATOR
U 12A2, 3732,15 ;20653          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 12A3, 3626,95 ;20654          MOV LS[#FF] TO WR[1]                    ;SET UP EXPECTED DATA
U 12A4, 0869,3C ;20655          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 12A5, 0929,44 ;20656          JMP [LOOP.T21.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;20657
U 12A6, 8875,3C ;20658          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;20659                                                  ; THIS TEST
                ;20660
                ;20661  END.T21:                                        ;END TEST
                ;20662
                ;20663
                ;20664
```

```
;20665  .PAGE  "Test 22  FIFO A ADDRESSING TEST (M8388 IDC MODULE)"
;20666  ;++
;20667  ;
;20668  ; Test Description:
;20669  ;
;20670  ;       This test is designed to insure that there are no addressing problems
;20671  ;       in FIFO A. This will be accomplished by first writing a background of
;20672  ;       all zeros to FIFO A. Address 0 of FIFO A will then be written with all
;20673  ;       ones and all other addresses in FIFO A will be checked to insure that
;20674  ;       they were not corrupted.
;20675  ;       The address counter will then be cleared and all locations that were
;20676  ;       previously written with ones will be read to insure that the data is
;20677  ;       correct. Then the next location will be written with all ones, and all
;20678  ;       higher addresses in FIFO A will be read to insure that they still
;20679  ;       contain all zeros. This will be repeated until all of FIFO A has been
;20680  ;       written as ones.
;20681  ;
;20682  ;       The procedure described above will then be repeated with first writing
;20683  ;       a background of ones and then writing zeros to each location.
;20684  ;
;20685  ; Assumptions:
;20686  ;
;20687  ;       It is assumed that all previous tests have run successfully.
;20688  ;
;20689  ; Test Steps:
;20690  ;
;20691  ;       1. Set up error mask, error number and module number in LS
;20692  ;          (for error printouts) and clear the previous error number in LS.
;20693  ;       2. Write all zeros to FIFO A.
;20694  ;       3. Clear the FIFO A Address Counter.
;20695  ;       4. Use WR[2] to track the last address written and use
;20696  ;          WR[3] to track the last address read.
;20697  ;       5. Write all ones to the first location in FIFO A.
;20698  ;       6. Check the remaining locations of FIFO A for all zeros.
;20699  ;       7. Read previously written all ones locations and check.
;20700  ;       8. Write the next location to all ones.
;20701  ;       9. Check the remaining locations in FIFO A for all zeros.
;20702  ;      10. Repeat Steps 7 - 10 until FIFO A has been written to all ones.
;20703  ;      11. Repeat the above sequence with writing a background of ones and
;20704  ;          then writing zeros and reading.
;20705  ; Errors:
;20706  ;
;20707  ;       Printout:
;20708  ;               EXPECTED        RECEIVED        OTHER DATA
;20709  ;               FIFO DATA       FIFO DATA       LS[ADDRESS.DATA]
;20710  ;                                               LO WORD=LAST ADRS
;20711  ;                                                       WRITTEN
;20712  ;                                               HI WORD=LAST ADRS
;20713  ;
;20714  ;
;20715  ;       ERROR 1 - There is an addressing problem in FIFO A with a background of
;20716  ;                 zeros and writing ones.
;20717  ;
;20718  ;       ERROR 2 - There is an addressing problem in FIFO A with a background of
;20719  ;                  ones and writing zeros.
```

```
                ;20720  ;
                ;20721  ; Debug:
                ;20722  ;
                ;20723  ;       Because of hardware restrictions, this test conatins a special error
                ;20724  ;       loop. If loop is set, this test will go into a loop that is set up to
                ;20725  ;       increment the address lines of the FIFO. This is done to allow one to
                ;20726  ;       examine each of the address lines while looping to insure that each is
                ;20727  ;       incrementing correctly. The address lines should increment once for
                ;20728  ;       each byte write from the PORT.
                ;20729  ;       If the error loop is exited, and then a continue is issued, this test
                ;20730  ;       will cleanup and then end.
                ;20731  ;
                ;20732  ; ERROR 1:
                ;20733  ;       The CPU will issue a PORT.CONTROL[SEL.FIFO.A] instruction to select
                ;20734  ;       FIFO A from the PORT. The PORT.CONTROL[CLEAR.FIFO.CNTR] instruction
                ;20735  ;       will clear the address of FIFO A. Then each location of FIFO A will be
                ;20736  ;       written with [00] to provide a background of all zeros by issuing byte
                ;20737  ;       writes from the CPU. FIFO A address will then be cleared. Address 0
                ;20738  ;       will be written with [FF]. The entire FIFO A will then be read to
                ;20739  ;       insure that the data in all locations is correct.
                ;20740  ;       Then the next address will be written with [FF] and the entire
                ;20741  ;       FIFO checked again. This will be repeated until all location of the
                ;20742  ;       FIFO A have been written = [FF]. The address lines will increment by
                ;20743  ;       1 for each byte write.
                ;20744  ;
                ;20745  ; ERROR 2:
                ;20746  ;       The same as ERROR 1 except a background of ones is used and then
                ;20747  ;       each location is written with [00].
                ;20748  ;--
                ;20749  ;*************************************************************************
                ;20750  ;       LS[T8]  = BACKGROUND DATA
                ;20751  ;       LS[T9]  = USED AS A COUNTER TO TRACK THE FIFO ADDRESS
                ;20752  ;       LS[T10] = WRITE DATA
                ;20753  ;       LS[T11] = EXPECTED DATA
                ;20754  ;       WR[2]   = LAST ADDRESS WRITTEN
                ;20755  ;       WR[3]   = LAST ADDRESS READ IN UPPER WORD
                ;20756  ;*************************************************************************
                ;20757  T.22:
U 12A7, B65E,15 ;20758          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;20759                                                  ; CONTROL AND STATUS WORD
U 12A8, 3E80,15 ;20760          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;20761                                                  ; STATUS WORD - BIT 15
                ;20762                                                  ; INDICATES START OF TEST TO
                ;20763                                                  ; CONSOLE
U 12A9, 10E0,15 ;20764          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;20765  WAIT.T22.0:
U 12AA, 892A,A4 ;20766          JMP [WAIT.T22.0]                        ;LOOP HERE WAITING FOR
                ;20767                                                  ; CONSOLE TO RESPOND
                ;20768
U 12AB, 65A0,15 ;20769          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;20770                                                  ; IN LS
                ;20771
U 12AC, B64A,15 ;20772          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 12AD, 3E8C,15 ;20773          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;20774
```

```
                    ;20775
U 12AE, B640,15     ;20776          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 12AF, BE82,15     ;20777          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;20778
U 12B0, B62C,15     ;20779          MOV LS[#FFFFFF00] TO WR[0]              ;SET UP THE ERROR MASK TO
U 12B1, 3E8A,15     ;20780          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK THE LOW BYTE
                    ;20781
U 12B2, B670,15     ;20782          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP THE CONTROL.STATUS
U 12B3, 3E80,15     ;20783          MOV WR[0] TO LS[CONTROL.STATUS]         ; TO PRINT OTHER DATA ON ERROR
                    ;20784
                    ;20785
                    ;20786  ;WRITE FIFO A WITH A BACKGROUND OF ALL ZEROS
                    ;20787
U 12B4, E510,15     ;20788          CLR LS[T8]                              ;GET THE DATA TO WRITE
U 12B5, 892B,FC     ;20789          JSR [WRITE.BACKGROUND.T22]              ;GO WRITE ALL OF THE FIFO
                    ;20790
                    ;20791  ;TEST THE FIFO BY WRITING ONES AND READING
                    ;20792
U 12B6, B626,15     ;20793          MOV LS[#FF] TO WR[0]
U 12B7, BE14,15     ;20794          MOV WR[0] TO LS[T10]                    ;DATA TO WRITE
                    ;20795
U 12B8, 892C,8C     ;20796          JSR [TEST.FIFO.T22]                     ;GO TEST THE FIFO WITH A
                    ;20797                                                  ; BACKGROUND OF ZEROS AND
                    ;20798                                                  ; THEN WRITING ONES
                    ;20799
U 12B9, FF82,15     ;20800          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                    ;20801
                    ;20802  ;FIFO NOW HAS A BACKGROUND OF ALL ONES
U 12BA, B626,15     ;20803          MOV LS[#FF] TO WR[0]                    ;PUT THE BACKGROUND DATA IN
U 12BB, 3E10,15     ;20804          MOV WR[0] TO LS[T8]                     ; LS[T8]
                    ;20805  ;TEST THE FIFO BY WRITING ZEROS AND READING
U 12BC, 6514,15     ;20806          CLR LS[T10]                             ;GET THE DATA TO WRITE
U 12BD, 892C,8C     ;20807          JSR [TEST.FIFO.T22]                     ;GO TEST THE FIFO WITH A
                    ;20808                                                  ; BACKGROUND OF ONES AND
                    ;20809                                                  ; THEN WRITING ZEROS
U 12BE, 092F,B4     ;20810          JMP [CLEANUP.T22]                       ;DONE..GO CLEANUP AND END TEST
                    ;20811
                    ;20812
                    ;20813  ;-------------------------------------------------------------------------
                    ;20814
                    ;20815  ;THIS IS A SUBROUTINE TO WRITE THE ENTIRE FIFO WITH THE DATA IN LS[T8]
                    ;20816
                    ;20817  WRITE.BACKGROUND.T22:
U 12BF, 2F85,15     ;20818          CLR WR[2]                               ;USE AS A COUNTER
U 12C0, 17D8,15     ;20819          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 12C1, 17C0,15     ;20820          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
                    ;20821
                    ;20822  WRITE.FIFO.ALL.T22:
U 12C2, B610,15     ;20823          MOV LS[T8] TO WR[0]                     ;GET THE DATA TO WRITE
U 12C3, 97A8,15     ;20824          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR TO FIFO A
                    ;20825
U 12C4, 2045,15     ;20826          INC WR[2]                               ;INCR THE ADDRESS COUNTER
                    ;20827          CMP WR[2] WITH LS[#200],                ;FIFO A WRITTEN WITH ALL ZEROS?
U 12C5, 4F53,35     ;20828           DT(LONG)&SET.ALU.CC
U 12C6, 092C,21     ;20829          JMP.IF[NEQ] TO [WRITE.FIFO.ALL.T22]
```

```
U 12C7, 5B00,14 ;20830          RETURN
                ;20831
                ;20832
                ;20833  ;-------------------------------------------------------------------------
                ;20834  ;-------------------------------------------------------------------------
                ;20835
                ;20836  ;THIS IS A SUBROUTINE THAT WILL WRITE ONE LOCATION AT A TIME WITH THE DATA
                ;20837  ;THAT IS IN LS[T10]. THE REST OF THE FIFO WILL THEN BE READ AND CHECKED.
                ;20838  ;THE BACKGROUND DATA MUST BE IN LS[T8] WHEN THIS ROUTINE IS CALLED.
                ;20839
                ;20840  TEST.FIFO.T22:
U 12C8, 2F85,15 ;20841          CLR WR[2]                                   ;ADRS CNTR= LAST ADRS WRITTEN
U 12C9, 2F87,95 ;20842          CLR WR[3]                                   ;ADRS CNTR= LAST ADRS READ
                ;20843                                                      ; WILL BE IN THE HI WORD
                ;20844                                                      ; FOR PRINTOUT
U 12CA, 6512,15 ;20845          CLR LS[T9]                                  ;ADRS CNTR = LAST ADRS READ
                ;20846                                                      ; WILL BE IN LOW BYTE
                ;20847
U 12CB, 17C0,15 ;20848          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO A ADRS = 0
                ;20849
                ;20850  WRITE.FIFO.A.T22:
                ;20851          CMP WR[2] WITH LS[#200],                    ;DONE?
U 12CC, 4F53,35 ;20852           DT(LONG)&SET.ALU.CC
U 12CD, 092F,59 ;20853          JMP.IF[EQL] TO [RETURN.T22]                 ;JMP IF DONE
                ;20854
U 12CE, 3614,15 ;20855          MOV LS[T10] TO WR[0]                        ;GET THE DATA
U 12CF, 97A8,15 ;20856          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR FIFO A
                ;20857
U 12D0, 3610,95 ;20858          MOV LS[T8] TO WR[1]                         ;SET UP THE EXPECTED DATA
U 12D1, BE16,95 ;20859          MOV WR[1] TO LS[T11]
                ;20860
U 12D2, C061,95 ;20861          ADD LS[#10000] TO WR[3]                     ;INCR THE LAST ADRS READ
U 12D3, FF12,15 ;20862          INC LS[T9]                                  ;INCR THE LAST ADRS READ
                ;20863
U 12D4, B652,15 ;20864          MOV LS[#200] TO WR[0]                       ;NEXT READ AT ZERO?
                ;20865          CMP LS[T9] WITH WR[0],
U 12D5, CE12,35 ;20866           DT(LONG)&SET.ALU.CC
U 12D6, 092D,C1 ;20867          JMP.IF[NEQ] TO [READ.FIFO.A.T22]            ;JMP IF NOT 0
                ;20868
U 12D7, 3614,15 ;20869          MOV LS[T10] TO WR[0]                        ;CHANGE THE EXPECTED DATA
U 12D8, 3E16,15 ;20870          MOV WR[0] TO LS[T11]                        ; TO THE DATA BEING WRITTEN
U 12D9, 6512,15 ;20871          CLR LS[T9]                                  ;CLR THE ADDRESS TRACKER
U 12DA, 2F87,95 ;20872          CLR WR[3]                                   ;CLR THE PRINTOUT COUNTER
U 12DB, 17C0,15 ;20873          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLR THE FIFO ADRS CNTR
                ;20874  READ.FIFO.A.T22:
U 12DC, 9090,15 ;20875          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 12DD, 1788,15 ;20876          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ THE FIFO
U 12DE, 3B32,15 ;20877          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM FIFO AND
                ;20878                                                      ; SAVE IT IN  LS
U 12DF, 3E89,15 ;20879          MOV WR[2] TO LS[ADDRESS.DATA]               ;SET UP THE ADDRESS INFORMATION
U 12E0, ED89,95 ;20880          BIS WR[3] TO LS[ADDRESS.DATA]               ; FOR PRINTOUT
U 12E1, 3732,15 ;20881          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 12E2, 3616,95 ;20882          MOV LS[T11] TO WR[1]                        ;SET UP EXPECTED DATA
U 12E3, 0869,3C ;20883          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 12E4, 892F,64 ;20884          JMP [LOOP.T22.1]                            ;LOOP HERE IF ERR & LOE IS SET
```

```
                ;20885
U 12E5, C061,95 ;20886          ADD LS[#10000] TO WR[3]                     ;INCR THE LAST ADRS READ
U 12E6, FF12,15 ;20887          INC LS[T9]                                  ;INCR THE LAST ADRS READ
                ;20888
                ;20889
U 12E7, 4841,15 ;20890          ADD WR[2] PLUS LS[#1] TO Q                  ;ADD 1 TO THE LAST ADRS WRITTEN
                ;20891                                                      ; AND SAVE IT IN Q
                ;20892          CMP LS[T9] WITH Q,                          ;IS THIS THE NEXT ADRS TO BE
U 12E8, DA12,35 ;20893           DT(LONG)&SET.ALU.CC                        ; WRITTEN?
U 12E9, 092E,C1 ;20894          JMP.IF[NEQ] TO [CHK.READ.T22]               ;JMP IF NOT
                ;20895
U 12EA, 2045,15 ;20896          INC WR[2]                                   ;INC THE LAST ADRS WRITTEN
U 12EB, 892C,C4 ;20897          JMP [WRITE.FIFO.A.T22]                      ;GO WRITE THE NEXT ADDRESS
                ;20898
                ;20899  CHK.READ.T22:
U 12EC, B652,15 ;20900          MOV LS[#200] TO WR[0]                       ;LAST LOCATION IN FIFO READ?
                ;20901          CMP LS[T9] WITH WR[0],                      ;NEXT LOCATION = 0?
U 12ED, CE12,35 ;20902           DT(LONG)&SET.ALU.CC
U 12EE, 092D,C1 ;20903          JMP.IF[NEQ] TO [READ.FIFO.A.T22]            ;JMP IF NOT 0
                ;20904
U 12EF, 3614,15 ;20905          MOV LS[T10] TO WR[0]                        ;CHANGE THE EXPECTED DATA
U 12F0, 3E16,15 ;20906          MOV WR[0] TO LS[T11]                        ; TO THE DATA BEING WRITTEN
U 12F1, 2F87,95 ;20907          CLR WR[3]                                   ;LAST READ ADDRESS = 0
U 12F2, 6512,15 ;20908          CLR LS[T9]                                  ;LAST READ ADDRESS = 0
U 12F3, 17C0,15 ;20909          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLR THE FIFO ADRS CNTR
U 12F4, 092D,C4 ;20910          JMP [READ.FIFO.A.T22]                       ;GO READ FOR ONES
                ;20911  RETURN.T22:
U 12F5, 5B00,14 ;20912          RETURN
                ;20913
                ;20914
                ;20915  ;-------------------------------------------------------------------------------
                ;20916  ;-------------------------------------------------------------------------------
                ;20917  ;ERROR LOOP
                ;20918
                ;20919  LOOP.T22.1:
U 12F6, 2F80,15 ;20920          CLR WR[0]                                   ;DATA TO WRITE
U 12F7, 97A8,15 ;20921          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE TO INCR THE ADRS
                ;20922
                ;20923                                                      ;EXPECTED AND RECEIVED DATA
                ;20924                                                      ; IS MEANINGLESS WHEN IN THE
                ;20925                                                      ; ERROR LOOP
U 12F8, 0869,3C ;20926          JSR [CHECK.RESULT]
U 12F9, 892F,64 ;20927          JMP [LOOP.T22.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;20928                                                      ;IF STOP LOOP AND CONTINUE,
U 12FA, 092F,B4 ;20929          JMP [CLEANUP.T22]                           ; CLEANUP AND END TEST
                ;20930
                ;20931  ;-------------------------------------------------------------------------------
                ;20932
                ;20933  CLEANUP.T22:
U 12FB, 8875,3C ;20934          JSR [CLEANUP]                               ;CLEANUP THE CONDITIONS SET BY
                ;20935                                                      ; THIS TEST
                ;20936  END.T22:                                            ;END TEST
                ;20937
                ;20938
                ;20939
```

```
;20940  .PAGE  "Test 23  FIFO B ADDRESSING TEST (M8388 IDC MODULE)"
;20941  ;++
;20942  ;
;20943  ; Test Description:
;20944  ;
;20945  ;       This test is designed to insure that there are no addressing problems
;20946  ;       in FIFO B. This will be accomplished by first writing a background of
;20947  ;       all zeros to FIFO B. Address 0 of FIFO B will then be written with all
;20948  ;       ones and all other addresses in FIFO B will be checked to insure that
;20949  ;       they were not corrupted.
;20950  ;       The address counter will then be cleared and all locations that were
;20951  ;       previously written with ones will be read to insure that the data is
;20952  ;       correct. Then the next location will be written with all ones, and all
;20953  ;       higher addresses in FIFO B will be read to insure that they still
;20954  ;       contain all zeros. This will be repeated until all of FIFO B has been
;20955  ;       written as ones.
;20956  ;
;20957  ;       The procedure described above will then be repeated with first writing
;20958  ;       a background of ones and then writing zeros to each location.
;20959  ;
;20960  ;
;20961  ; Assumptions:
;20962  ;
;20963  ;       It is assumed that all previous tests have run successfully.
;20964  ;
;20965  ; Test Steps:
;20966  ;
;20967  ;       1. Set up error mask, error number and module number in LS
;20968  ;          (for error printouts) and clear the previous error number in LS.
;20969  ;       2. Write all zeros to FIFO B.
;20970  ;       3. Clear the FIFO B Address Counter.
;20971  ;       4. Use WR[2] to track the last address written and use
;20972  ;          WR[3] to track the last address read.
;20973  ;       5. Write all ones to the first location in FIFO B.
;20974  ;       6. Check the remaining locations of FIFO B for all zeros.
;20975  ;       7. Read previously written all ones locations and check.
;20976  ;       8. Write the next location to all ones.
;20977  ;       9. Check the remaining locations in FIFO B for all zeros.
;20978  ;      10. Repeat Steps 7 - 10 until FIFO B has been written to all ones.
;20979  ;      11. Repeat the above sequence with first writing a background of ones
;20980  ;          and then writing zeros and reading.
;20981  ; Errors:
;20982  ;
;20983  ;
;20984  ;       Printout:
;20985  ;               EXPECTED        RECEIVED        OTHER DATA
;20986  ;               FIFO DATA       FIFO DATA       LS[ADDRESS.DATA]
;20987  ;                                               LO WORD=LAST ADRS
;20988  ;                                                       WRITTEN
;20989  ;                                               HI WORD=LAST ADRS
;20990  ;                                                       READ
;20991  ;
;20992  ;
;20993  ;
;20994  ;       ERROR 1 - There is an addressing problem in FIFO B with a background of
```

```
                ;20995  ;                   zeros and writing ones.
                ;20996  ;
                ;20997  ;       ERROR 2 - There is an addressing problem in FIFO B with a background of
                ;20998  ;                 ones and writing zeros.
                ;20999  ;
                ;21000  ; Debug:
                ;21001  ;
                ;21002  ;       Because of hardware restrictions, this test conatins a special error
                ;21003  ;       loop. If loop is set, this test will go into a loop that is set up to
                ;21004  ;       increment the address lines of the FIFO. This is done to allow one to
                ;21005  ;       examine each of the address lines while looping to insure that each is
                ;21006  ;       incrementing correctly. The address lines should increment once for
                ;21007  ;       each byte write from the PORT.
                ;21008  ;       If the error loop is exited, and then a continue is issued, this test
                ;21009  ;       will cleanup and then end.
                ;21010  ;
                ;21011  ; ERROR 1:
                ;21012  ;       The CPU will issue a PORT.CONTROL[SEL.FIFO.B] instruction to select
                ;21013  ;       FIFO B from the PORT. The PORT.CONTROL[CLEAR.FIFO.CNTR] instruction
                ;21014  ;       will clear the address of FIFO B. Then each location of FIFO B will be
                ;21015  ;       written with [00] to provide a background of all zeros by issuing byte
                ;21016  ;       writes from the CPU. FIFO B address will then be cleared. Address 0
                ;21017  ;       will be written with [FF]. The entire FIFO B will then be read to
                ;21018  ;       insure that the data in all locations is correct.
                ;21019  ;       Then the next address will be written with [FF] and the entire
                ;21020  ;       FIFO checked again. This will be repeated until all location of the
                ;21021  ;       FIFO B have been written = [FF]. The address lines will increment by
                ;21022  ;       1 for each byte write.
                ;21023  ;
                ;21024  ; ERROR 2:
                ;21025  ;       The same as ERROR 1 except a background of ones is used and then
                ;21026  ;       each location is written with [00].
                ;21027  ;--
                ;21028  ;*************************************************************************************
                ;21029  ;       LS[T8]  = BACKGROUND DATA
                ;21030  ;       LS[T9]  = USED AS A COUNTER TO TRACK THE FIFO ADDRESS
                ;21031  ;       LS[T10] = WRITE DATA
                ;21032  ;       LS[T11] = EXPECTED DATA
                ;21033  ;       WR[2]   = LAST ADDRESS WRITTEN
                ;21034  ;       WR[3]   = LAST ADDRESS READ IN UPPER WORD
                ;21035  ;*************************************************************************************
                ;21036  T.23:
U 12FC, B65E,15 ;21037          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;21038                                                  ; CONTROL AND STATUS WORD
U 12FD, 3E80,15 ;21039          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;21040                                                  ; STATUS WORD - BIT 15
                ;21041                                                  ; INDICATES START OF TEST TO
                ;21042                                                  ; CONSOLE
U 12FE, 10E0,15 ;21043          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;21044  WAIT.T23.0:
U 12FF, 892F,F4 ;21045          JMP [WAIT.T23.0]                        ;LOOP HERE WAITING FOR
                ;21046                                                  ; CONSOLE TO RESPOND
                ;21047
U 1300, 65A0,15 ;21048          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;21049                                                  ; IN LS
```

```
                    ;21050
U 1301, B64A,15     ;21051          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1302, 3E8C,15     ;21052          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;21053
                    ;21054
U 1303, B640,15     ;21055          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1304, BE82,15     ;21056          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;21057
U 1305, B62C,15     ;21058          MOV LS[#FFFFFF00] TO WR[0]              ;SET UP THE ERROR MASK TO
U 1306, 3E8A,15     ;21059          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK THE LOW BYTE
                    ;21060
U 1307, B670,15     ;21061          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP THE CONTROL.STATUS TO
U 1308, 3E80,15     ;21062          MOV WR[0] TO LS[CONTROL.STATUS]         ; PRINT OTHER DATA ON ERROR
                    ;21063
                    ;21064
                    ;21065  ;WRITE FIFO B WITH A BACKGROUND OF ALL ZEROS
                    ;21066
U 1309, E510,15     ;21067          CLR LS[T8]                              ;GET THE DATA TO WRITE
U 130A, 8931,4C     ;21068          JSR [WRITE.BACKGROUND.T23]              ;GO WRITE ALL OF THE FIFO
                    ;21069
                    ;21070  ;TEST THE FIFO BY WRITING ONES AND READING
                    ;21071
U 130B, B626,15     ;21072          MOV LS[#FF] TO WR[0]
U 130C, BE14,15     ;21073          MOV WR[0] TO LS[T10]                    ;DATA TO WRITE
                    ;21074
U 130D, 8931,DC     ;21075          JSR [TEST.FIFO.T23]                     ;GO TEST THE FIFO WITH A
                    ;21076                                                  ; BACKGROUND OF ZEROS AND
                    ;21077                                                  ; THEN WRITING ONES
U 130E, FF82,15     ;21078          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                    ;21079
                    ;21080  ;THE FIFO NOW HAS A BACKGROUND OF ALL ONES
U 130F, B626,15     ;21081          MOV LS[#FF] TO WR[0]                    ;PUT THE BACKGROUND DATA IN
U 1310, 3E10,15     ;21082          MOV WR[0] TO LS[T8]                     ; LS[T8]
                    ;21083  ;TEST THE FIFO BY WRITING ZEROS AND READING
                    ;21084
U 1311, 6514,15     ;21085          CLR LS[T10]                             ;DATA TO WRITE
U 1312, 8931,DC     ;21086          JSR [TEST.FIFO.T23]                     ;GO TEST THE FIFO WITH A
                    ;21087                                                  ; BACKGROUND OF ONES AND
                    ;21088                                                  ; THEN WRITING ZEROS
                    ;21089
U 1313, 0935,04     ;21090          JMP [CLEANUP.T23]                       ;DONE..CLEANUP AND END TEST
                    ;21091
                    ;21092
                    ;21093  ;-------------------------------------------------------------------------
                    ;21094
                    ;21095  ;THIS IS A SUBROUTINE TO WRITE THE ENTIRE FIFO WITH THE DATA IN LS[T8]
                    ;21096
                    ;21097  WRITE.BACKGROUND.T23:
U 1314, 2F85,15     ;21098          CLR WR[2]                               ;USE AS A COUNTER
U 1315, 97DC,15     ;21099          PORT.CONTROL [SEL.FIFO.B]               ;SELECT FIFO B
U 1316, 17C0,15     ;21100          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
                    ;21101
                    ;21102  WRITE.FIFO.ALL.T23:
U 1317, 2F80,15     ;21103          CLR WR[0]                               ;DATA = 0
U 1318, 97A8,15     ;21104          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WR 0 TO FIFO B
```

```
                    ;21105
U 1319, 2045,15     ;21106          INC WR[2]                                   ;INCR THE ADDRESS COUNTER
                    ;21107          CMP WR[2] WITH LS[#200],                    ;FIFO B WRITTEN WITH ALL ZEROS?
U 131A, 4F53,35     ;21108           DT(LONG)&SET.ALU.CC
U 131B, 0931,71     ;21109          JMP.IF[NEQ] TO [WRITE.FIFO.ALL.T23]
U 131C, 5B00,14     ;21110          RETURN
                    ;21111
                    ;21112  ;-----------------------------------------------------------------------
                    ;21113
                    ;21114  ;THIS IS A SUBROUTINE THAT WILL WRITE ONE LOCATION AT A TIME WITH THE DATA
                    ;21115  ;THAT IS IN LS[T10]. THE REST OF THE FIFO WILL THEN BE READ AND CHECKED.
                    ;21116  ;THE BACKGROUND DATA MUST BE IN LS[T8] WHEN THIS ROUTINE IS CALLED.
                    ;21117
                    ;21118  TEST.FIFO.T23:
U 131D, 2F85,15     ;21119          CLR WR[2]                                   ;ADRS CNTR= LAST ADRS WRITTEN
U 131E, 2F87,95     ;21120          CLR WR[3]                                   ;ADRS CNTR= LAST ADRS READ
                    ;21121                                                      ; WILL BE IN THE HI WORD
                    ;21122                                                      ; FOR PRINTOUT
U 131F, 6512,15     ;21123          CLR LS[T9]                                  ;ADRS CNTR = LAST ADRS READ
                    ;21124                                                      ; WILL BE IN LOW BYTE
                    ;21125
U 1320, 17C0,15     ;21126          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO B ADRS = 0
                    ;21127
                    ;21128  WRITE.FIFO.B.T23:
                    ;21129          CMP WR[2] WITH LS[#200],                    ;DONE?
U 1321, 4F53,35     ;21130           DT(LONG)&SET.ALU.CC
U 1322, 0934,A9     ;21131          JMP.IF[EQL] TO [RETURN.T23]                 ;JMP IF DONE
                    ;21132
U 1323, 3614,15     ;21133          MOV LS[T10] TO WR[0]                        ;GET THE DATA
U 1324, 97A8,15     ;21134          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WR FIFO B
                    ;21135
U 1325, 3610,95     ;21136          MOV LS[T8] TO WR[1]                         ;SET UP THE EXPECTED DATA
U 1326, BE16,95     ;21137          MOV WR[1] TO LS[T11]                        ; SAVE IT IS LS[T11]
                    ;21138
U 1327, C061,95     ;21139          ADD LS[#10000] TO WR[3]                     ;INCR THE LAST ADRS READ
U 1328, FF12,15     ;21140          INC LS[T9]                                  ;INCR THE LAST ADRS READ
                    ;21141
U 1329, B652,15     ;21142          MOV LS[#200] TO WR[0]                       ;NEXT READ AT ZERO?
                    ;21143          CMP LS[T9] WITH WR[0],
U 132A, CE12,35     ;21144           DT(LONG)&SET.ALU.CC
U 132B, 8933,11     ;21145          JMP.IF[NEQ] TO [READ.FIFO.B.T23]            ;JMP IF NOT 0
                    ;21146
U 132C, 3614,15     ;21147          MOV LS[T10] TO WR[0]                        ;CHANGE THE EXPECTED DATA
U 132D, 3E16,15     ;21148          MOV WR[0] TO LS[T11]                        ; TO DATA WRITTEN
                    ;21149
U 132E, 6512,15     ;21150          CLR LS[T9]                                  ;CLR THE ADDRESS TRACKER
U 132F, 2F87,95     ;21151          CLR WR[3]                                   ;CLR THE PRINTOUT COUNTER
U 1330, 17C0,15     ;21152          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;CLR THE FIFO ADRS CNTR
                    ;21153
                    ;21154  READ.FIFO.B.T23:
U 1331, 9090,15     ;21155          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 1332, 1788,15     ;21156          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ THE FIFO
U 1333, 3B32,15     ;21157          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM FIFO AND
                    ;21158                                                      ; SAVE IT IN  LS
U 1334, 3E89,15     ;21159          MOV WR[2] TO LS[ADDRESS.DATA]               ;SET UP THE ADDRESS INFORMATION
```

```
U 1335, ED89,95 ;21160          BIS WR[3] TO LS[ADDRESS.DATA]          ; FOR PRINTOUT
U 1336, 3732,15 ;21161          MOV LS[PORT0] TO WR[0]                 ;SET UP RECEIVED DATA
U 1337, 3616,95 ;21162          MOV LS[T11] TO WR[1]                   ;SET UP EXPECTED DATA
U 1338, 0869,3C ;21163          JSR [CHECK.RESULT]                     ;CHECK THE DATA
U 1339, 0934,B4 ;21164          JMP [LOOP.T23.1]                       ;LOOP HERE IF ERR & LOE IS SET
                ;21165
U 133A, C061,95 ;21166          ADD LS[#10000] TO WR[3]                ;INCR THE LAST ADRS READ
U 133B, FF12,15 ;21167          INC LS[T9]                             ;INCR THE LAST ADRS READ
                ;21168
U 133C, 4841,15 ;21169          ADD WR[2] PLUS LS[#1] TO Q             ;ADD 1 TO THE LAST ADRS WRITTEN
                ;21170                                                 ; AND SAVE IT IN Q
                ;21171          CMP LS[T9] WITH Q,                     ;IS THIS THE NEXT ADRS TO BE
U 133D, DA12,35 ;21172           DT(LONG)&SET.ALU.CC                   ; WRITTEN?
U 133E, 0934,11 ;21173          JMP.IF[NEQ] TO [CHK.READ.T23]          ;JMP IF NOT
                ;21174
U 133F, 2045,15 ;21175          INC WR[2]                              ;INC THE LAST ADRS WRITTEN
U 1340, 0932,14 ;21176          JMP [WRITE.FIFO.B.T23]                 ;GO WRITE THE NEXT ADDRESS
                ;21177
                ;21178  CHK.READ.T23:
U 1341, B652,15 ;21179          MOV LS[#200] TO WR[0]                  ;LAST LOCATION IN FIFO READ?
                ;21180          CMP LS[T9] WITH WR[0],                 ;NEXT LOCATION = 0?
U 1342, CE12,35 ;21181           DT(LONG)&SET.ALU.CC
U 1343, 8933,11 ;21182          JMP.IF[NEQ] TO [READ.FIFO.B.T23]       ;JMP IF NOT 0
                ;21183
U 1344, 3614,15 ;21184          MOV LS[T10] TO WR[0]                   ;CHANGE THE EXPECTED DATA
U 1345, 3E16,15 ;21185          MOV WR[0] TO LS[T11]                   ; TO DATA WRITTEN
U 1346, 2F87,95 ;21186          CLR WR[3]                              ;LAST READ ADDRESS = 0
U 1347, 6512,15 ;21187          CLR LS[T9]                             ;LAST READ ADDRESS = 0
U 1348, 17C0,15 ;21188          PORT.CONTROL [CLEAR.FIFO.CNTR]         ;CLR THE FIFO ADRS CNTR
U 1349, 8933,14 ;21189          JMP [READ.FIFO.B.T23]                  ;GO READ FOR ONES
                ;21190  RETURN.T23:
U 134A, 5B00,14 ;21191          RETURN
                ;21192
                ;21193  ;-------------------------------------------------------------------------
                ;21194  ;ERROR LOOP
                ;21195
                ;21196  LOOP.T23.1:
U 134B, 2F80,15 ;21197          CLR WR[0]                              ;DATA TO WRITE
U 134C, 97A8,15 ;21198          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE TO INCR THE ADRS
                ;21199
                ;21200                                                 ;EXPECTED AND RECEIVED DATA
                ;21201                                                 ; IS MEANINGLESS WHILE IN THE
                ;21202                                                 ; THE ERROR LOOP
U 134D, 0869,3C ;21203          JSR [CHECK.RESULT]
U 134E, 0934,B4 ;21204          JMP [LOOP.T23.1]                       ;LOOP HERE IF ERR & LOE IS SET
                ;21205                                                 ;IF STOP LOOP AND CONTINUE,
U 134F, 0935,04 ;21206          JMP [CLEANUP.T23]                      ; CLEANUP AND END TEST
                ;21207
                ;21208  ;-------------------------------------------------------------------------
                ;21209  CLEANUP.T23:
U 1350, 8875,3C ;21210          JSR [CLEANUP]                          ;CLEANUP THE CONDITIONS SET BY
                ;21211                                                 ; THIS TEST
                ;21212  END.T23:                                       ;END TEST
                ;21213
                ;21214
```

```
ZZ-ENKCF-1.4    ;     ENKCF.MIC                Test 23  FIFO B ADD15-MAR-83          Fiche 3  Frame B3          Sequence 439
;     ENKCF.MCR                MICRO2  1M(01)    15-MAR-83  11:46:22    ENKCF Micro-diagnostic for IDC module  Rev 01.40     Page  433
;     ENKCF.MIC                Test 23  FIFO B ADDRESSING TEST (M8388 IDC MODULE)

                ;21215
```

```
;21216  .PAGE  "Test 24  PARALLEL IN/OUT DATA SHIFT REGISTER TEST (M8388 IDC MODULE)"
;21217  ;++
;21218  ;
;21219  ; Test Description:
;21220  ;
;21221  ;       This test is designed to insure that the Data Shift Register can be
;21222  ;       parallel loaded and read correctly. The data pattern will be loaded
;21223  ;       into the Data Shift Register from FIFO A address 0 and then enabled
;21224  ;       into FIFO A address 1 for the CPU to read and check.
;21225  ;       The data patterns that will be used are:
;21226  ;               Data Pattern 1 = AA
;21227  ;               Data Pattern 2 = 55
;21228  ;               Data Pattern 3 = 33
;21229  ;               Data Pattern 4 = 0F
;21230  ;
;21231  ;       After these data patterns have been checked, the UCLR DSR function will
;21232  ;       be tested to insure that it indeed does clear the DSR.
;21233  ;
;21234  ; Assumptions:
;21235  ;
;21236  ;       It is assumed that all previous test have run successfully.
;21237  ;
;21238  ; Test Steps:
;21239  ;
;21240  ;       1. Set up error mask, error number and module number in LS
;21241  ;          (for error printouts) and clear the previous error number in LS.
;21242  ;       2. Force the IDC microcode to DIAG.IDLE.
;21243  ;       3. Clear the FIFO A Address Counter.
;21244  ;       4. Clear FIFO A addresses 0 and 1.
;21245  ;       5. Write the data pattern to FIFO A address 0.
;21246  ;       6. Clear the FIFO A Address Counter.
;21247  ;       7. Set up the CSR to branch to the correct IDC routine.
;21248  ;
;21249  ;
;21250  ;                                       *******
;21251  ;                                       * IDC *
;21252  ;                                       *******
;21253  ;
;21254  ;               IDC1. Enable FIFO A onto BUS OUT.
;21255  ;               IDC2. Issue ULOAD DSR.
;21256  ;               IDC3. UENB DSR onto BUS IN.
;21257  ;               IDC4. Write the data to FIFO A address 1.
;21258  ;               IDC5. Issue a XFER.REQ to flag the CPU.
;21259  ;
;21260  ;       8. Wait for a XFER.REQ from IDC.
;21261  ;       9. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;21262  ;      10. Check the data in FIFO A address 1.
;21263  ;      11. Get the next data pattern and execute Steps 3 - 10 until all data
;21264  ;          patterns have been checked.
;21265  ;      12. Increment the error number.
;21266  ;      13. Clear the FIFO A Address Counter.
;21267  ;      14. Write FFFFFFF to FIFO A.
;21268  ;      15. Clear the FIFO A Address Counter.
;21269  ;      16. Set up the CSR to branch to the correct IDC routine.
;21270  ;
```

```
;21271  ;
;21272  ;                                        *******
;21273  ;                                        * IDC *
;21274  ;                                        *******
;21275  ;
;21276  ;               IDC6. Load the DSR with the data in FIFO A.
;21277  ;               IDC7. Issue a UCLR DSR.
;21278  ;               IDC8. Enable the DSR into FIFO A address=1.
;21279  ;               IDC9. Issue a XFER.REQ to flag the CPU.
;21280  ;
;21281  ;       17. Wait for a XFER.REQ from IDC.
;21282  ;       18. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;21283  ;       19. Check the data in FIFO A.
;21284  ;       20. Clear IDC.
;21285  ;       21. End test.
;21286  ;
;21287  ; Errors:
;21288  ;
;21289  ;                 Printout:
;21290  ;                         EXPECTED          RECEIVED
;21291  ;                         DSR DATA          DSR DATA
;21292  ;                                            FROM FIFO A
;21293  ;
;21294  ;       ERROR 1 - The Data Shift Register or the DSR Buffer failed.
;21295  ;
;21296  ;       ERROR 2 - The UCLR DSR function failed.
;21297  ;
;21298  ; Debug:
;21299  ;
;21300  ; ERROR 1:
;21301  ;       FIFO A address 0 will contain the data pattern to be loaded into the
;21302  ;       DSR and FIFO A address 1 will be cleared to be used to store the
;21303  ;       data read from the DSR. The IDC microcode will branch to an instruction
;21304  ;       that will select FIFO A from the IDC microcode. The next IDC
;21305  ;       instruction is:
;21306  ;-------------------------------------------------------------------------
;21307  ;1DE:
;21308  ;TEST.DSR.1:
;21309  ;
;21310  ;       ENB.FIFO/ON,                    ;ENABLE FIFO A ONTO BUS OUT
;21311  ;       LOAD.DSR/ON,                    ; AND LOAD THE DATA INTO THE DSR
;21312  ;       INCR.FIFO.CNTR/ON,              ; INCREMENT THE FIFO A CNTR TO 1
;21313  ;       NAD/TEST.DSR.2
;21314  ;-------------------------------------------------------------------------
;21315  ;       UENB FIFO H will be asserted by this instruction. The signal is
;21316  ;       ANDED with USEL FIFO A H = H, the output of which is ENB FIFOA L = L.
;21317  ;       ENB FIFOA L will enable the data from FIFO A address 0 onto
;21318  ;       BUS OUT <7:0>. This is the input BUS for the DSR. ULOAD DSR L is also
;21319  ;       asserted by this instruction. This signal is inverted to LOAD DSR H = H
;21320  ;       which will load the data from BUS OUT <7:0> into the DSR.
;21321  ;       Also asserted by this instruction is UINCR FIFO CNTR H which is part
;21322  ;       of the clock signal to FIFO A. Since USEL FIFO A H is also asserted,
;21323  ;       at the next CURRENT CLK L, the FIFO A address will be incremented
;21324  ;       to 1.
;21325  ;
```

```
                    ;21326  ;       The next instruction is:
                    ;21327  ;-------------------------------------------------------------------------
                    ;21328  ;1DF:
                    ;21329  ;TEST.DSR.2:
                    ;21330  ;
                    ;21331  ;       ENB.DSR/ON,                     ;LOAD THE DSR ONTO BUS IN
                    ;21332  ;       WRT.FIFO/ON,                    ;WRITE THE DATA INTO FIFO A ADRS=1
                    ;21333  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                    ;21334  ;-------------------------------------------------------------------------
                    ;21335  ;       This instruction will assert UENB DSR L which will load the data
                    ;21336  ;       from the DSR onto BUS IN <7:0> which is the input BUS for FIFO A.
                    ;21337  ;       This instruction will also assert UWRITE FIFO H which is ANDED with
                    ;21338  ;       USEL FIFOA H = H and CURRENT CLK L, so on the next clock,
                    ;21339  ;       WRITE FIFOA L will assert. This signal will load the data from BUS IN
                    ;21340  ;       <7:0> into address 1 of FIFO A. XFER REQ is then sent to falg the CPU.
                    ;21341  ;       The CPU will then read and check the data in address 1 of FIFO A.
                    ;21342  ;
                    ;21343  ; ERROR 2:
                    ;21344  ;       The DSR will be loaded with [FF]. The IDC microcode will then issue
                    ;21345  ;       a instrcution of FUNC/CLR.DSR. The outputs of the microsequencer
                    ;21346  ;       will be:
                    ;21347  ;               UFUNC 3 H = L
                    ;21348  ;               UFUNC 2 H = L
                    ;21349  ;               UFUNC 1 H = H
                    ;21350  ;               UFUNC 0 H = L
                    ;21351  ;       These bits will be decoded and will assert UCLR DSR L. This signal is
                    ;21352  ;       the clear input to the DSR and will clear DSR <7:0> H. The data from
                    ;21353  ;       the DSR is then written into FIFO A address 1. XFER REQ is sent to
                    ;21354  ;       flag the CPU. The CPU will then read and check the data of FIFO A
                    ;21355  ;       address 1 = [00].
                    ;21356  ;
                    ;21357  ;--
                    ;21358  ;*************************************************************************************
                    ;21359  T.24:
U 1351, B65E,15     ;21360          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;21361                                                  ; CONTROL AND STATUS WORD
U 1352, 3E80,15     ;21362          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;21363                                                  ; STATUS WORD - BIT 15
                    ;21364                                                  ; INDICATES START OF TEST TO
                    ;21365                                                  ; CONSOLE
U 1353, 10E0,15     ;21366          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;21367  WAIT.T24.0:
U 1354, 8935,44     ;21368          JMP [WAIT.T24.0]                        ;LOOP HERE WAITING FOR
                    ;21369                                                  ; CONSOLE TO RESPOND
                    ;21370
U 1355, 65A0,15     ;21371          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;21372                                                  ; IN LS
                    ;21373
U 1356, B64A,15     ;21374          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1357, 3E8C,15     ;21375          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                    ;21376
                    ;21377
U 1358, B640,15     ;21378          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1359, BE82,15     ;21379          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;21380
```

```
U 135A, B62C,15 ;21381          MOV LS[#FFFFFF00] TO WR[0]                ;SET UP THE ERROR MASK TO CHECK
U 135B, 3E8A,15 ;21382          MOV WR[0] TO LS[ERROR.MASK]               ; THE LOW BYTE
                ;21383
U 135C, 8872,EC ;21384          JSR [DIAG.CODE]                           ;FORCE THE IDC TO DIAG.IDLE
                ;21385
U 135D, 2F85,15 ;21386          CLR WR[2]                                 ;USE AS A LOOP CNTR
U 135E, B699,95 ;21387          MOV LS[#AAAAAAAA] TO WR[3]                ;GET THE DATA PATTERN
                ;21388
                ;21389  CHK.NXT.PAT.T24:
                ;21390  LOOP.T24.1:
                ;21391
                ;21392
U 135F, 17D8,15 ;21393          PORT.CONTROL [SEL.FIFO.A]
U 1360, 17C0,15 ;21394          PORT.CONTROL [CLEAR.FIFO.CNTR]            ;CLR THE FIFO A ADRS CNTR
                ;21395
U 1361, 2F80,15 ;21396          CLR WR[0]
U 1362, 17AC,15 ;21397          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;CLR ADRS 0 AND 1 OF FIFO A
                ;21398
                ;21399
U 1363, 17D8,15 ;21400          PORT.CONTROL [SEL.FIFO.A]
U 1364, 17C0,15 ;21401          PORT.CONTROL [CLEAR.FIFO.CNTR]            ;CLR THE FIFO A ADRS CNTR
                ;21402
U 1365, A006,15 ;21403          MOV WR[3] TO WR[0]                        ;MOV PAT TO WR[0] FOR WRITE
U 1366, 97A8,15 ;21404          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE FIFO A ADRS 0 = PAT
                ;21405
U 1367, 17C0,15 ;21406          PORT.CONTROL [CLEAR.FIFO.CNTR]            ;CLR THE FIFO A ADRS CNTR
U 1368, 3720,15 ;21407          MOV LS[SETCSR.MAINT] TO WR[0]             ;SET UP THE CSR TO BRANCH TO
U 1369, 3712,95 ;21408          MOV LS[SETCSR.CRDY] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 136A, AEC2,15 ;21409          BIS WR[1] TO WR[0]
U 136B, 370A,95 ;21410          MOV LS[SETCSR.F5] TO WR[1]
U 136C, AEC2,15 ;21411          BIS WR[1] TO WR[0]
U 136D, 17A0,15 ;21412          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
                ;21413                                                    ;MAINT=1,CRDY=1,F<2:0>=101
                ;21414  ;-----------------------------------------------------------------------------
                ;21415  ;-----------------------------------------------------------------------------
                ;21416  ;                               *******
                ;21417  ;                               * IDC *
                ;21418  ;                               *******
                ;21419  ;-------------------------------------------------------------------------
                ;21420  ;018:
                ;21421  ;=000
                ;21422  ;DIAG.IDLE:
                ;21423  ;
                ;21424  ;       BEN0/F0,
                ;21425  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;21426  ;       BEN2/F2,
                ;21427  ;       NAD/DIAG.IDLE
                ;21428  ;-------------------------------------------------------------------------
                ;21429  ;01D:
                ;21430  ;=101
                ;21431  ;
                ;21432  ;       BEN0/CRDY.L,
                ;21433  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;21434  ;       NAD/TEST.FUNC5          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;21435  ;-------------------------------------------------------------------------
```

```
                ;21436  ;074:
                ;21437  ;=1*0
                ;21438  ;TEST.DSR.0:
                ;21439  ;
                ;21440  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A
                ;21441  ;       NAD/TEST.DSR.1
                ;21442  ;-------------------------------------------------------------------------
                ;21443  ;1DE:
                ;21444  ;TEST.DSR.1:
                ;21445  ;
                ;21446  ;       ENB.FIFO/ON,                    ;ENABLE FIFO A ONTO BUS OUT
                ;21447  ;       LOAD.DSR/ON,                    ; AND LOAD THE DATA INTO THE DSR
                ;21448  ;       INCR.FIFO.CNTR/ON,              ; INCREMENT THE FIFO A CNTR TO 1
                ;21449  ;       NAD/TEST.DSR.2
                ;21450  ;-------------------------------------------------------------------------
                ;21451  ;1DF:
                ;21452  ;TEST.DSR.2:
                ;21453  ;
                ;21454  ;       ENB.DSR/ON,                     ;LOAD THE DSR ONTO BUS IN
                ;21455  ;       WRT.FIFO/ON,                    ;WRITE THE DATA INTO FIFO A ADRS=1
                ;21456  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;21457  ;-------------------------------------------------------------------------
                ;21458  ;1D8:
                ;21459  ;XFER.REQ:
                ;21460  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;21461  ;       NAD/DIAG.WAIT
                ;21462  ;-------------------------------------------------------------------------
                ;21463  ;1D7:
                ;21464  ;DIAG.WAIT:
                ;21465  ;
                ;21466  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;21467  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;21468  ;-------------------------------------------------------------------------
                ;21469  ;159:
                ;21470  ;=*0*
                ;21471  ;DIAG.WAIT1:
                ;21472  ;
                ;21473  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;21474  ;                               ; COMMAND FROM THE CPU
                ;21475  ;-------------------------------------------------------------------------
                ;21476  ;15B:
                ;21477  ;=*1*
                ;21478  ;DIAG.WAIT2:
                ;21479  ;
                ;21480  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;21481  ;                               ; WAIT SOME MORE
                ;21482  ;-------------------------------------------------------------------------
                ;21483  WAIT.IDC.T24.1:
U 136E, DB00,1A ;21484          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 136F, 0937,14 ;21485          JMP [IDC.DONE.T24.1]                    ;XFER REQ ASSERTED
U 1370, 8936,E4 ;21486          JMP [WAIT.IDC.T24.1]                    ;WAIT SOME MORE
                ;21487
                ;21488  IDC.DONE.T24.1:
U 1371, B700,15 ;21489          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 1372, 17A0,15 ;21490          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WRITE THE CSR
```

```
U 1373, 90FA,15 ;21491          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                ;21492
                ;21493  READ.FIFO.T24.1:
U 1374, 9090,15 ;21494          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1375, 1788,15 ;21495          PORT.READ PORT.ADRS[DATA.BYTE]          ;SET UP TO READ FIFO A ADRS=1
U 1376, 3B32,15 ;21496          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM FIFO AND
                ;21497                                                  ; SAVE IT IN  LS
U 1377, 3732,15 ;21498          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1378, 2006,95 ;21499          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
                ;21500
U 1379, 0869,3C ;21501          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 137A, 0935,F4 ;21502          JMP [LOOP.T24.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;21503
                ;21504
                ;21505          CMP WR[2] WITH LS[ZERO],                ;FIRST LOOP COUNT?
U 137B, CF9D,35 ;21506           DT(LONG)&SET.ALU.CC
U 137C, 8938,01 ;21507          JMP.IF[NEQ] TO [CHK.LPCNT.T24.1]        ;JMP IF NOT FIRST
U 137D, 369B,95 ;21508          MOV LS[#55555555] TO WR[3]              ;GET DATA PATTERN 2
U 137E, 2045,15 ;21509          INC WR[2]                               ;INCR THE LOOP COUNT
U 137F, 0935,F4 ;21510          JMP [CHK.NXT.PAT.T24]                   ;CHECK THE NEXT PATTERN
                ;21511
                ;21512  CHK.LPCNT.T24.1:
                ;21513          CMP WR[2] WITH LS[#1],                  ;SECOND LOOP COUNT?
U 1380, 4F41,35 ;21514           DT(LONG)&SET.ALU.CC
U 1381, 8938,51 ;21515          JMP.IF[NEQ] TO [CHK.LPCNT.T24.2]        ;JMP IF NOT
U 1382, B6C5,95 ;21516          MOV LS[#33333333] TO WR[3]              ;GET DATA PATTERN 3
U 1383, 2045,15 ;21517          INC WR[2]                               ;INCR THE LOOP COUNT
U 1384, 0935,F4 ;21518          JMP [CHK.NXT.PAT.T24]                   ;CHECK THE NEXT PATTERN
                ;21519
                ;21520  CHK.LPCNT.T24.2:
                ;21521          CMP WR[2] WITH LS[#2],                  ;THIRD  LOOP COUNT?
U 1385, CF43,35 ;21522           DT(LONG)&SET.ALU.CC
U 1386, 8938,A1 ;21523          JMP.IF[NEQ] TO [TEST.CLR.T24]           ;JMP IF DONE
U 1387, 36C7,95 ;21524          MOV LS[#0F0F0F0F] TO WR[3]              ;GET DATA PATTERN 4
U 1388, 2045,15 ;21525          INC WR[2]                               ;INCR THE LOOP COUNT
U 1389, 0935,F4 ;21526          JMP [CHK.NXT.PAT.T24]                   ;CHECK THE NEXT PATTERN
                ;21527
                ;21528  TEST.CLR.T24:
U 138A, FF82,15 ;21529          INC LS[ERROR.NUMBER]                    ;ERROR 2
                ;21530
                ;21531  LOOP.T24.2:
                ;21532
                ;21533
U 138B, 17D8,15 ;21534          PORT.CONTROL [SEL.FIFO.A]
U 138C, 17C0,15 ;21535          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLR THE FIFO A ADRS CNTR
                ;21536
U 138D, B69E,15 ;21537          MOV LS[#FFFFFFFF] TO WR[0]              ;WRITE ONES TO FIFO A
U 138E, 17AC,15 ;21538          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;  ADDRESS ZERO AND 1
U 138F, 17C0,15 ;21539          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;CLR FIFO A ADRS CNTR
                ;21540
U 1390, 3712,95 ;21541          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1391, B70C,15 ;21542          MOV LS[SETCSR.F6] TO WR[0]              ;THE CORRECT IDC ROUTINE
U 1392, AEC2,15 ;21543          BIS WR[1] TO WR[0]
U 1393, 17A0,15 ;21544          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;21545                                                  ;MAINT=0,CRDY=1,F<2:0>=110
```

```
;21546  ;-------------------------------------------------------------------------------
;21547  ;-------------------------------------------------------------------------------
;21548  ;                                  *******
;21549  ;                                  * IDC *
;21550  ;                                  *******
;21551  ;-------------------------------------------------------------------------------
;21552  ;018:
;21553  ;=000
;21554  ;DIAG.IDLE:
;21555  ;
;21556  ;       BEN0/F0,
;21557  ;       BEN1/F1,                   ;BRANCH ON THE CSR F<2:0> BITS
;21558  ;       BEN2/F2,
;21559  ;       NAD/DIAG.IDLE
;21560  ;-------------------------------------------------------------------------------
;21561  ;01E:
;21562  ;=110
;21563  ;
;21564  ;       BEN0/CRDY.L,
;21565  ;       BEN2/MAINT,                ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;21566  ;       NAD/TEST.FUNC6             ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;21567  ;-------------------------------------------------------------------------------
;21568  ;072:
;21569  ;=0*0
;21570  ;TEST.FUNC6:
;21571  ;
;21572  ;UCLR.DSR.0:
;21573  ;
;21574  ;       UCMD/SET.FIFOA,                    ;SELECT FIFO A
;21575  ;       NAD/UCLR.DSR.1
;21576  ;-------------------------------------------------------------------------------
;21577  ;1E0:
;21578  ;UCLR.DSR.1:
;21579  ;
;21580  ;       ENB.FIFO/ON,                       ;ENABLE FIFO A ONTO BUS OUT
;21581  ;       LOAD.DSR/ON,                       ; AND LOAD THE DATA INTO THE DSR
;21582  ;       INCR.FIFO.CNTR/ON,                 ; INCREMENT THE FIFO A CNTR
;21583  ;       NAD/UCLR.DSR.2
;21584  ;-------------------------------------------------------------------------------
;21585  ;1E1:
;21586  ;UCLR.DSR.2:
;21587  ;
;21588  ;       FUNC/CLR.DSR,                      ;CLEAR THE DSR
;21589  ;       NAD/UCLR.DSR.3
;21590  ;-------------------------------------------------------------------------------
;21591  ;1E2:
;21592  ;UCLR.DSR.3:
;21593  ;
;21594  ;       ENB.DSR/ON,                        ;LOAD THE DSR ONTO BUS IN
;21595  ;       WRT.FIFO/ON,                       ;WRITE THE DATA INTO FIFO
;21596  ;       NAD/XFER.REQ                       ;SEND XFER REQ TO FLAG THE CPU
;21597  ;-------------------------------------------------------------------------------
;21598  ;1D8:
;21599  ;XFER.REQ:
;21600  ;       UCMD/SET.XFER.RQST,                ;SEND XFER REQ TO THE CPU
```

```
                    ;21601  ;       NAD/DIAG.WAIT
                    ;21602  ;-------------------------------------------------------------------------
                    ;21603  ;1D7:
                    ;21604  ;DIAG.WAIT:
                    ;21605  ;
                    ;21606  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                    ;21607  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                    ;21608  ;-------------------------------------------------------------------------
                    ;21609  ;159:
                    ;21610  ;=*0*
                    ;21611  ;DIAG.WAIT1:
                    ;21612  ;
                    ;21613  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;21614  ;                               ; COMMAND FROM THE CPU
                    ;21615  ;-------------------------------------------------------------------------
                    ;21616  ;15B:
                    ;21617  ;=*1*
                    ;21618  ;DIAG.WAIT2:
                    ;21619  ;
                    ;21620  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;21621  ;                               ; WAIT SOME MORE
                    ;21622  ;-------------------------------------------------------------------------
                    ;21623  WAIT.IDC.T24.2:
U 1394, DB00,1A     ;21624          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ TO SET
U 1395, 8939,74     ;21625          JMP [IDC.DONE.T24.2]                    ;XFER REQ ASSERTED
U 1396, 8939,44     ;21626          JMP [WAIT.IDC.T24.2]                    ;WAIT SOME MORE
                    ;21627
                    ;21628  IDC.DONE.T24.2:
U 1397, B700,15     ;21629          MOV LS[SETCSR.F0] TO WR[0]              ;SET UP TO CLR CSR F<2:0>
U 1398, 17A0,15     ;21630          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WRITE THE CSR
U 1399, 90FA,15     ;21631          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR XFER REQ
                    ;21632
                    ;21633
                    ;21634  READ.FIFO.T24.2:
U 139A, 9090,15     ;21635          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 139B, 1788,15     ;21636          PORT.READ PORT.ADRS[DATA.BYTE]          ;SET UP TO READ THE FIFO
U 139C, 3B32,15     ;21637          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM FIFO AND
                    ;21638                                                  ; SAVE IT IN  LS
U 139D, 3732,15     ;21639          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 139E, 2F82,95     ;21640          CLR WR[1]                               ;SET UP THE EXPECTED DATA
                    ;21641
U 139F, 0869,3C     ;21642          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 13A0, 0938,B4     ;21643          JMP [LOOP.T24.2]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;21644
U 13A1, 8875,3C     ;21645          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                    ;21646                                                  ;BY THIS TEST
                    ;21647  END.T24:                                        ;END TEST
                    ;21648
```

```
;21649  .PAGE  "Test 25  SERIAL SHIFT OUT FUNCTION OF DSR TEST (M8388 IDC MODULE)"
;21650  ;++
;21651  ;
;21652  ; Test Description:
;21653  ;
;21654  ;       This test is designed to insure that the Data Shift Register can
;21655  ;       serially shift out data correctly. The data pattern will be loaded into
;21656  ;       FIFO A. The DSR will be loaded from FIFO A.
;21657  ;       The data will be shifted one position to the right and then written
;21658  ;       into FIFO B. The CPU will then read the data from FIFO B and check.
;21659  ;       The data patterns that will be used are:
;21660  ;               Data Pattern 1 = 80
;21661  ;               Data Pattern 2 = 40
;21662  ;               Data Pattern 3 = 20
;21663  ;               Data Pattern 4 = 10
;21664  ;               Data Pattern 5 = 08
;21665  ;               Data Pattern 6 = 04
;21666  ;               Data Pattern 7 = 02
;21667  ;               Data Pattern 8 = 01
;21668  ;
;21669  ;       The expected data will be the data pattern shifted right once.
;21670  ;
;21671  ; Assumptions:
;21672  ;
;21673  ;       It is assumed that all previous test have run successfully.
;21674  ;
;21675  ; Test Steps:
;21676  ;
;21677  ;       1. Set up error mask, error number and module number in LS
;21678  ;          (for error printouts) and clear the previous error number in LS.
;21679  ;       2. Force the IDC microcode to DIAG.IDLE.
;21680  ;       3. Clear the FIFO B Address Counter.
;21681  ;       4. Clear the FIFO A Address Counter.
;21682  ;       5. Write the data pattern into FIFO A.
;21683  ;       6. Clear the FIFO A Address Counter.
;21684  ;       7. Set up the CSR to branch to the correct IDC routine.
;21685  ;
;21686  ;                                       *******
;21687  ;                                       * IDC *
;21688  ;                                       *******
;21689  ;
;21690  ;               IDC1. Load the data from FIFO A into the DSR.
;21691  ;               IDC2. Set UCMD = 6, Change FIFO to select FIFO B and DSR will
;21692  ;                     shift one.
;21693  ;               IDC3. Enable the data from the DSR through the DSR BUFFER and
;21694  ;                     into FIFO B.
;21695  ;               IDC4. Issue XFER REQ to flag the CPU.
;21696  ;
;21697  ;       8. Wait for a XFER.REQ from IDC.
;21698  ;       9. Clear CSR F<2:0> and issue XFER GRANT to clear the XFER.REQ.
;21699  ;      10. Check FIFO B address 0.
;21700  ;      11. Shift the data pattern and the expected data once to the right and
;21701  ;          go to Step 3 until all data patterns have been tested.
;21702  ;      12. Clear IDC.
;21703  ;      13. End test.
```

```
                ;21704  ;
                ;21705  ; Errors:
                ;21706  ;
                ;21707  ;       ERROR 1 - The serial shift out function of the Data Shift Register
                ;21708  ;                 failed.
                ;21709  ;
                ;21710  ;                 Printout:
                ;21711  ;                         EXPECTED          RECEIVED
                ;21712  ;                         DSR DATA          DSR DATA
                ;21713  ;
                ;21714  ; Debug:
                ;21715  ;
                ;21716  ; ERROR 1:
                ;21717  ;       The data pattern is written into FIFO A address 0. FIFO B address 0
                ;21718  ;       is cleared and will be used to write the data from the DSR.
                ;21719  ;       The IDC microcode will branch to an instrcution that will load the
                ;21720  ;       data from FIFO A address 0, into the DSR. The IDC will then execute an
                ;21721  ;       instruction that will UCMD/CHG.FIFO which will select FIFO B. At the
                ;21722  ;       same time, the DSR will be clocked once by CURRENT CLK H and the data
                ;21723  ;       in the DSR will shift once to the right. The data which has been
                ;21724  ;       shifted once right in the DSR will be loaded into FIFO B address 0.
                ;21725  ;       XFER REQ will be sent to flag the CPU. The CPU will then read FIFO B
                ;21726  ;       address 0 and check the data = the original data pattern shifted
                ;21727  ;       right once. Only bits <6:0> will be checked.
                ;21728  ;--
                ;21729  ;*******************************************************************************
                ;21730  T.25:
U 13A2, B65E,15 ;21731          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;21732                                                  ; CONTROL AND STATUS WORD
U 13A3, 3E80,15 ;21733          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;21734                                                  ; STATUS WORD - BIT 15
                ;21735                                                  ; INDICATES START OF TEST TO
                ;21736                                                  ; CONSOLE
U 13A4, 10E0,15 ;21737          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;21738  WAIT.T25.0:
U 13A5, 093A,54 ;21739          JMP [WAIT.T25.0]                        ;LOOP HERE WAITING FOR
                ;21740                                                  ; CONSOLE TO RESPOND
                ;21741
U 13A6, 65A0,15 ;21742          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;21743                                                  ; IN LS
                ;21744
U 13A7, B64A,15 ;21745          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 13A8, 3E8C,15 ;21746          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;21747
                ;21748
U 13A9, B640,15 ;21749          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 13AA, BE82,15 ;21750          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;21751
U 13AB, B79C,15 ;21752          MOV LS[#FFFFFF80] TO WR[0]
U 13AC, 3E8A,15 ;21753          MOV WR[0] TO LS[ERROR.MASK]             ;SET UP MASK TO CHECK 7 BITS
                ;21754
U 13AD, 8872,EC ;21755          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;21756
U 13AE, 364F,95 ;21757          MOV LS[#80] TO WR[3]                    ;GET THE FIRST DATA PAT
                ;21758
```

```
                ;21759  CHECK.DSR.T25:
U 13AF, 2007,15 ;21760          MOV WR[3] TO WR[2]                      ;SET UP THE EXPECTED DATA
U 13B0, 2351,15 ;21761          ASHR WR[2]                              ;WR[2] = EXPECTED DATA
                ;21762
                ;21763  LOOP.T25.1:
                ;21764
U 13B1, 97DC,15 ;21765          PORT.CONTROL [SEL.FIFO.B]               ;SELECT FIFO B
U 13B2, 17C0,15 ;21766          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO B ADRS = 0
                ;21767
U 13B3, 17D8,15 ;21768          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 13B4, 17C0,15 ;21769          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS = 0
                ;21770
U 13B5, A006,15 ;21771          MOV WR[3] TO WR[0]                      ;GET DATA PAT FOR THE WRITE
                ;21772
U 13B6, 97A8,15 ;21773          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE TO FIFO A
U 13B7, 17C0,15 ;21774          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO B ADRS = 0
                ;21775
U 13B8, B70C,15 ;21776          MOV LS[SETCSR.F6] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 13B9, 17A0,15 ;21777          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                ;21778                                                  ;MAINT=0,CRDY=0,F<2:0>=110
                ;21779  ;-------------------------------------------------------------------------------
                ;21780  ;-------------------------------------------------------------------------------
                ;21781  ;                               *******
                ;21782  ;                               * IDC *
                ;21783  ;                               *******
                ;21784  ;-------------------------------------------------------------------------------
                ;21785  ;018:
                ;21786  ;=000
                ;21787  ;DIAG.IDLE:
                ;21788  ;
                ;21789  ;       BEN0/F0,
                ;21790  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;21791  ;       BEN2/F2,
                ;21792  ;       NAD/DIAG.IDLE
                ;21793  ;-------------------------------------------------------------------------------
                ;21794  ;01E:
                ;21795  ;=110
                ;21796  ;
                ;21797  ;       BEN0/CRDY.L,
                ;21798  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;21799  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;21800  ;-------------------------------------------------------------------------------
                ;21801  ;073:
                ;21802  ;=0*1
                ;21803  ;SHIFT.DSR.0:
                ;21804  ;
                ;21805  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A
                ;21806  ;       NAD/SHIFT.DSR.1
                ;21807  ;-------------------------------------------------------------------------------
                ;21808  ;1E3:
                ;21809  ;SHIFT.DSR.1:
                ;21810  ;
                ;21811  ;       ENB.FIFO/ON,                    ;ENABLE FIFO A ONTO BUS OUT
                ;21812  ;       LOAD.DSR/ON,                    ; AND LOAD THE DATA INTO THE DSR
                ;21813  ;       NAD/SHIFT.DSR.2
```

```
                ;21814  ;-----------------------------------------------------------------------
                ;21815  ;1E4:
                ;21816  ;SHIFT.DSR.2:
                ;21817  ;
                ;21818  ;       UCMD/CHG.FIFO,                  ;SELECT FIFO B
                ;21819  ;       NAD/SHIFT.DSR.3                 ;DSR WILL SHIFT ONCE
                ;21820  ;-----------------------------------------------------------------------
                ;21821  ;1E5:
                ;21822  ;SHIFT.DSR.3:
                ;21823  ;
                ;21824  ;       ENB.DSR/ON,                     ;LOAD THE DSR ONTO BUS IN
                ;21825  ;       WRT.FIFO/ON,                    ;WRITE THE DATA INTO FIFO B
                ;21826  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;21827  ;-----------------------------------------------------------------------
                ;21828  ;1D8:
                ;21829  ;XFER.REQ:
                ;21830  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;21831  ;       NAD/DIAG.WAIT
                ;21832  ;-----------------------------------------------------------------------
                ;21833  ;1D7:
                ;21834  ;DIAG.WAIT:
                ;21835  ;
                ;21836  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;21837  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;21838  ;-----------------------------------------------------------------------
                ;21839  ;159:
                ;21840  ;=*0*
                ;21841  ;DIAG.WAIT1:
                ;21842  ;
                ;21843  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;21844  ;                               ; COMMAND FROM THE CPU
                ;21845  ;-----------------------------------------------------------------------
                ;21846  ;15B:
                ;21847  ;=*1*
                ;21848  ;DIAG.WAIT2:
                ;21849  ;
                ;21850  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;21851  ;                               ; WAIT SOME MORE
                ;21852  ;-----------------------------------------------------------------------
                ;21853  WAIT.IDC.T25.1:
U 13BA, DB00,1A ;21854          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 13BB, 093B,D4 ;21855          JMP [IDC.DONE.T25.1]                    ;XFER REQ SET
U 13BC, 893B,A4 ;21856          JMP [WAIT.IDC.T25.1]                    ;WAIT SOME MORE
                ;21857
                ;21858  IDC.DONE.T25.1:
U 13BD, B700,15 ;21859          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 13BE, 17A0,15 ;21860          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 13BF, 90FA,15 ;21861          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;21862
                ;21863
U 13C0, 97DC,15 ;21864          PORT.CONTROL [SEL.FIFO.B]               ;SELECT FIFO B
U 13C1, 17C0,15 ;21865          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS = 0
                ;21866
                ;21867  READ.FIFO.T25.1:
U 13C2, 9090,15 ;21868          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
```

```
U 13C3, 1788,15 ;21869          PORT.READ PORT.ADRS[DATA.BYTE]          ;SET UP TO READ THE FIFO
U 13C4, 3B32,15 ;21870          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM FIFO AND
                ;21871                                                  ; SAVE IT IN  LS
U 13C5, 3732,15 ;21872          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 13C6, A004,95 ;21873          MOV WR[2] TO WR[1]                      ;SET UP EXPECTED DATA
U 13C7, 0869,3C ;21874          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 13C8, 093B,14 ;21875          JMP [LOOP.T25.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;21876
U 13C9, A351,95 ;21877          ASHR WR[3]                              ;SHIFT TO FORM NEW DATA
                ;21878          TST WR[3],                              ;DONE?
U 13CA, 2007,B5 ;21879           DT(LONG)&SET.ALU.CC
U 13CB, 093A,F1 ;21880          JMP.IF[NEQ] TO [CHECK.DSR.T25]          ;JMP TO CHECK NEXT DATA PAT
                ;21881                                                  ; IF NOT DONE
U 13CC, 8875,3C ;21882          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;21883                                                  ; THIS TEST
                ;21884  END.T25:                                        ;END TEST
                ;21885
                ;21886
```

```
;21887  .PAGE  "Test 26  RL02 DATA PATH TEST 1 (M8388 IDC MODULE)"
;21888  ;++
;21889  ; Test Description:
;21890  ;
;21891  ;       This test will verify that the IDC produces a disk clock when in
;21892  ;       the diskless loop mode. It will also verify the RL02 data path on
;21893  ;       IDC excluding the drivers and receivers to the RL02 Disk Drive using a
;21894  ;       data pattern of a byte of zeros.
;21895  ;       The data will be loaded into data buffer A. It will then be shifted
;21896  ;       through the DSR and then through the MFM encoder. The data will then
;21897  ;       go through the data separator, through the serial input of the DSR and
;21898  ;       into data buffer A address = 1.
;21899  ;       The CPU will then read and check the data.
;21900  ;
;21901  ; Assumptions:
;21902  ;
;21903  ;       It is assumed that the Data Input, Data Output Buffer, Data
;21904  ;       Buffer A, Data Buffer B, Bus In, Bus Out, and the parallel
;21905  ;       inputs and outputs of the DSR are functional.
;21906  ;
;21907  ; Test Steps:
;21908  ;
;21909  ;       1. Set up error mask, error number and module number in LS
;21910  ;          (for error printouts) and clear the previous error number in LS.
;21911  ;       2. Load the data pattern into Data Buffer A.
;21912  ;       3. Set up the CSR to branch to the correct IDC routine.
;21913  ;
;21914  ;                                       *******
;21915  ;                                       * IDC *
;21916  ;                                       *******
;21917  ;
;21918  ;               IDC1. Shift out 32 zeros to sync up data separator.
;21919  ;               IDC2. Load the data pattern byte into the DSR.
;21920  ;               IDC3. Shift the byte thru the MFM encoder and back thru the
;21921  ;                     data separator into the DSR.
;21922  ;               IDC4. Write the byte into Data Buffer A.
;21923  ;               IDC5. Issue a XFER.REQ to the CPU to indicate IDC has completed
;21924  ;                     the operation.
;21925  ;
;21926  ;       4. Wait for XFER REQ from the IDC.
;21927  ;       5. If XFER REQ does not assert then issue error to indicate no response
;21928  ;          from the IDC.
;21929  ;       6. Increment the error number.
;21930  ;       7. Read Data Buffer A address = 1 and check the data.
;21931  ;       8. End test.
;21932  ;
;21933  ; Errors:
;21934  ;
;21935  ;       ERROR 1 - One or more of the clocks stopped when the Disk Clock was
;21936  ;                 selected in conjunction with the RL02 diskless loop.
;21937  ;
;21938  ;                 Printout:
;21939  ;                         EXPECTED          RECEIVED
;21940  ;                           N/A               N/A
;21941  ;
```

```
;21942  ;       ERROR 2 - The RL02 Data Path failed with data pattern = 00.
;21943  ;
;21944  ;                 Printout:
;21945  ;                                 EXPECTED          RECEIVED
;21946  ;                                  FIFO A            FIFO A
;21947  ;                                  ADDR=1            ADDR=1
;21948  ; Debug:
;21949  ;
;21950  ; ERROR 1 -
;21951  ;
;21952  ;       The most likely cause of the diskless loop stopping the sequencer
;21953  ;       clock is that the VCO (TP2) in the data separator must be adjusted.
;21954  ;       The VCO should be adjusted to 8.2MHZ (122 nanoseconds cycle time).
;21955  ;       Other conditions for the data separator to not stop the sequencer are:
;21956  ;       RL02 H = H
;21957  ;       UENB LOOP LOCK H = H
;21958  ;       UMAINT H = H
;21959  ;       SEL DSK CLK H = H
;21960  ;       CRDY L = H
;21961  ;
;21962  ;       The CLOCK SYNC LOGIC must also be operating so that the DISK CLOCK
;21963  ;       is selected as the SEQ CLOCK.
;21964  ;
;21965  ; ERROR 2 -
;21966  ;
;21967  ;       The RL02 Data Path up to the parallel load of the DSR has been proven
;21968  ;       fully operational in previous tests. After the data is parallel loaded
;21969  ;       into the DSR, the control line LOAD DSR H should deassert and the data
;21970  ;       should then be serially shifted out through DSR 0. If this is not
;21971  ;       happening correctly, then either the control line LOAD DSR H did not
;21972  ;       deassert, or DSR 0 is shorted or the DSR itself is bad.
;21973  ;
;21974  ;       The data is then shifted into the MFM ENCODER PAL to become
;21975  ;       WRT DATA <3:0>.
;21976  ;       Input UMAINT H should be H and 4.1 MHZ CLK L should be clocking
;21977  ;       DSR 0 through to WRT DATA <3:0>. The 4.1 MHZ CLK is generated by a
;21978  ;       8.2 MHZ crystal oscillator located on the IDC module. The 8.2 MHZ
;21979  ;       is then divided through the PEAK SHIFT COMP PAL to become 4.1 MHZ.
;21980  ;
;21981  ;       WRT DATA <3:0> then becomes the inputs to the PEAK SHIFT COMP PAL.
;21982  ;       This PAL modifies the frequency of the write data which would in
;21983  ;       normal operation be the data written on the disk. However in this
;21984  ;       diskless loop, the data is output as  WRITE DATA L, and then
;21985  ;       immediately looped  back through the data separator.
;21986  ;
;21987  ;       The data is output from the Data Separator as DS DATA H. DS DATA H is
;21988  ;       then ANDed with SEL STATUS CLK L which should be deasserted, and the
;21989  ;       data becomes read data RL DATA L.
;21990  ;
;21991  ;       RL DATA L is then selected through a MIX by RL02 H = H, and becomes
;21992  ;       READ DATA H. READ DATA H is then latched up through a flip flop and
;21993  ;       becomes SER DATA IN H which is the serial input to the DSR. After the
;21994  ;       byte of data has been serially shifted into the DSR, the byte of data
;21995  ;       will be loaded into a quad buffer which is enabled by UENB DSR L = L.
;21996  ;
```

```
                ;21997  ;       The data will then be loaded into Data Buffer A address = 1 to be
                ;21998  ;       read and checked by the CPU.
                ;21999  ;--
                ;22000  ;*******************************************************************************
                ;22001  T.26:
U 13CD, B65E,15 ;22002          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;22003                                                  ; CONTROL AND STATUS WORD
U 13CE, 3E80,15 ;22004          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;22005                                                  ; STATUS WORD - BIT 15
                ;22006                                                  ; INDICATES START OF TEST TO
                ;22007                                                  ; CONSOLE
U 13CF, 10E0,15 ;22008          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;22009  WAIT.T26.0:
U 13D0, 893D,04 ;22010          JMP [WAIT.T26.0]                        ;LOOP HERE WAITING FOR
                ;22011                                                  ; CONSOLE TO RESPOND
U 13D1, 65A0,15 ;22012          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;22013                                                  ; IN LS
                ;22014
                ;22015
U 13D2, E58A,15 ;22016          CLR LS[ERROR.MASK]                      ;CHECK ALL BITS
                ;22017
U 13D3, B66E,15 ;22018          MOV LS[NA.EXP.REC] TO WR[0]             ;SET UP TO PRINT N/A FOR
U 13D4, 3E80,15 ;22019          MOV WR[0] TO LS[CONTROL.STATUS]         ; EXPECTED & RECEIVED DATA
                ;22020
U 13D5, B64A,15 ;22021          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 13D6, 3E8C,15 ;22022          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;22023
U 13D7, B640,15 ;22024          MOV LS[#1] TO WR[0]
U 13D8, BE82,15 ;22025          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;22026
                ;22027
U 13D9, B78E,15 ;22028          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;22029          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 13DA, D94E,35 ;22030           DT(LONG)&SET.ALU.CC
U 13DB, 093D,D1 ;22031          JMP.IF[BIT.SET] TO [SIZE.OK.T26.1]      ;IF YES THEN GO RUN TEST
                ;22032
U 13DC, 8870,0C ;22033          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;22034
                ;22035  SIZE.OK.T26.1:
U 13DD, 8872,EC ;22036          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;22037
                ;22038          ;SELECT AN RL02 DRIVE
                ;22039
U 13DE, B78E,15 ;22040          MOV LS[DRIVE.STATUS] TO WR[0]
                ;22041          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 13DF, 5940,35 ;22042           DT(LONG)&SET.ALU.CC
U 13E0, 093E,39 ;22043          JMP.IF[BITS.CLR] TO [SET.DS0.T26.1]     ;JMP IF DRV 0 IS NOT AN R80
U 13E1, B717,15 ;22044          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 13E2, 093E,44 ;22045          JMP [TEST.T26.1]
                ;22046  SET.DS0.T26.1:
U 13E3, 3715,15 ;22047          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;22048
                ;22049  TEST.T26.1:
                ;22050  LOOP.T26.1:
                ;22051  LOOP.T26.2:
```

```
U 13E4, 2F80,15 ;22052          CLR WR[0]                                   ;SET DATA = 0
U 13E5, 17D8,15 ;22053          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A FOR WRITE
U 13E6, 17C0,15 ;22054          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO TO ADDRESS 0
U 13E7, 97A8,15 ;22055          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE THE DATA TO FIFO A
                ;22056
U 13E8, B626,15 ;22057          MOV LS[#FF] TO WR[0]                        ;WRITE FIFO A ADDRESS 1 = FF
U 13E9, 97A8,15 ;22058          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0] ;WRITE THE DATA TO FIFO A
                ;22059
                ;22060
U 13EA, 17C0,15 ;22061          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO TO ADDRESS 0
U 13EB, 3708,15 ;22062          MOV LS[SETCSR.F4] TO WR[0]                  ;SET CSR F<2:0>=100 TO BRANCH
                ;22063                                                      ; AND CLR CRDY
U 13EC, AEC4,15 ;22064          BIS WR[2] TO WR[0]                          ;INCLUDE THE RL02 DRV SELECT
U 13ED, 17A0,15 ;22065          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ; WRITE THE DATA TO IDC CSR
                ;22066                                                      ;MAINT=0,CRDY=0,F<2:0>=100
                ;22067  ;-----------------------------------------------------------------------------
                ;22068  ;-----------------------------------------------------------------------------
                ;22069  ;                                *******
                ;22070  ;                                * IDC *
                ;22071  ;                                *******
                ;22072  ;-----------------------------------------------------------------------------
                ;22073  ;018:
                ;22074  ;=000
                ;22075  ;DIAG.IDLE:
                ;22076  ;
                ;22077  ;       BEN0/F0,
                ;22078  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
                ;22079  ;       BEN2/F2,
                ;22080  ;       NAD/DIAG.IDLE
                ;22081  ;-----------------------------------------------------------------------------
                ;22082  ;01C:
                ;22083  ;=100
                ;22084  ;
                ;22085  ;       BEN0/CRDY.L,
                ;22086  ;       BEN2/MAINT,                 ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;22087  ;       NAD/TEST.FUNC4              ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;22088  ;-----------------------------------------------------------------------------
                ;22089  ;06B:
                ;22090  ;=0*1
                ;22091  ;DISKLESS.DIAG.0:
                ;22092  ;
                ;22093  ;       UMAINT/ON,
                ;22094  ;       LOOP.LOCK/ON,               ;MAINT PREVENTS LOOP LOCK FROM SELECTING
                ;22095  ;       DISK.WRITE/ON,              ;READ DATA...DISK WRITE STILL SELECTS DSR0
                ;22096  ;       LOAD.LOOP.CNTR.[0E0],
                ;22097  ;       NAD/DISKLESS.DIAG.1
                ;22098  ;-----------------------------------------------------------------------------
                ;22099  ;184:
                ;22100  ;=0
                ;22101  ;DISKLESS.DIAG.1:
                ;22102  ;
                ;22103  ;       UMAINT/ON,
                ;22104  ;       LOOP.LOCK/ON,               ;SHIFT OUT 32 ZEROS TO SYNC UP
                ;22105  ;       DISK.WRITE/ON,              ; DATA SEPARATOR
                ;22106  ;       UCMD/SET.FIFOA,
```

```
;22107  ;       INCR.LPCNTR/ON,
;22108  ;       BEN0/CNTR.OVFLW,
;22109  ;       NAD/DISKLESS.DIAG.1
;22110  ;-------------------------------------------------------------------------
;22111  ;185:
;22112  ;=1
;22113  ;DISKLESS.DIAG.2:
;22114  ;
;22115  ;       UMAINT/ON,
;22116  ;       LOOP.LOCK/ON,
;22117  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;22118  ;       ENB.DSK.CLK,
;22119  ;       NAD/DISKLESS.DIAG.3A
;22120  ;-------------------------------------------------------------------------
;22121  ;1D9:
;22122  ;DISKLESS.DIAG.3A:
;22123  ;
;22124  ;       UMAINT/ON,
;22125  ;       LOOP.LOCK/ON,
;22126  ;       DISK.WRITE/ON,
;22127  ;       NAD/DISKLESS.DIAG.3B
;22128  ;-------------------------------------------------------------------------
;22129  ;1DA:
;22130  ;DISKLESS.DIAG.3B:
;22131  ;
;22132  ;       UMAINT/ON,
;22133  ;       LOOP.LOCK/ON,
;22134  ;       DISK.WRITE/ON,
;22135  ;       NAD/DISKLESS.DIAG.3
;22136  ;-------------------------------------------------------------------------
;22137  ;1DB:
;22138  ;DISKLESS.DIAG.3:
;22139  ;
;22140  ;       UMAINT/ON,
;22141  ;       LOOP.LOCK/ON,
;22142  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;22143  ;       ENB.FIFO/ON,
;22144  ;       LOAD.DSR/ON,
;22145  ;       NAD/DISKLESS.DIAG.4A
;22146  ;-------------------------------------------------------------------------
;22147  ;1DC:
;22148  ;DISKLESS.DIAG.4A:
;22149  ;
;22150  ;       UMAINT/ON,
;22151  ;       LOOP.LOCK/ON,           ;INCREMENT THE FIFO ADDRESS COUNTER
;22152  ;       DISK.WRITE/ON,
;22153  ;       INCR.FIFO.CNTR/ON,
;22154  ;       LOAD.LOOP.CNTR.[0F5],
;22155  ;       NAD/DISKLESS.DIAG.4
;22156  ;-------------------------------------------------------------------------
;22157  ;188:
;22158  ;=0
;22159  ;DISKLESS.DIAG.4:
;22160  ;
;22161  ;       UMAINT/ON,
```

```
                ;22162  ;       LOOP.LOCK/ON,
                ;22163  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
                ;22164  ;       INCR.LPCNTR/ON,                 ; LOOP
                ;22165  ;       BEN0/CNTR.OVFLW,
                ;22166  ;       NAD/DISKLESS.DIAG.4
                ;22167  ;-------------------------------------------------------------------------------
                ;22168  ;189:
                ;22169  ;=1
                ;22170  ;DISKLESS.DIAG.5:
                ;22171  ;
                ;22172  ;       UMAINT/ON,
                ;22173  ;       LOOP.LOCK/ON,
                ;22174  ;       ENB.DSR/ON,                     ;LOAD THE DATA INTO FIFO A
                ;22175  ;       WRT.FIFO/ON,
                ;22176  ;       DISK.WRITE/ON,
                ;22177  ;       NAD/DISKLESS.DIAG.6
                ;22178  ;-------------------------------------------------------------------------------
                ;22179  ;1DD:
                ;22180  ;DISKLESS.DIAG.6:
                ;22181  ;
                ;22182  ;       UMAINT/ON,
                ;22183  ;       LOOP.LOCK/ON,
                ;22184  ;       DISK.WRITE/ON,
                ;22185  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
                ;22186  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;22187  ;-------------------------------------------------------------------------------
                ;22188  ;1D8:
                ;22189  ;XFER.REQ:
                ;22190  ;
                ;22191  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;22192  ;       NAD/DIAG.WAIT
                ;22193  ;-------------------------------------------------------------------------------
                ;22194  ;1D7:
                ;22195  ;DIAG.WAIT:
                ;22196  ;
                ;22197  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;22198  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;22199  ;-------------------------------------------------------------------------------
                ;22200  ;159:
                ;22201  ;=*0*
                ;22202  ;DIAG.WAIT1:
                ;22203  ;
                ;22204  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;22205  ;                               ; COMMAND FROM THE CPU
                ;22206  ;-------------------------------------------------------------------------------
                ;22207  ;15B:
                ;22208  ;=*1*
                ;22209  ;DIAG.WAIT2:
                ;22210  ;
                ;22211  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;22212  ;                               ; WAIT SOME MORE
                ;22213  ;-------------------------------------------------------------------------------
                ;22214
U 13EE, B64C,15 ;22215          MOV LS[#40] TO WR[0]                    ;SET THE LOOP COUNT
                ;22216  WAIT.IDC.T26:
```

```
U 13EF, DB00,1A ;22217          SKIP.IF[NO.FAST.INTERRUPT]                  ;SKIP UNTIL IDC DONE
U 13F0, 893F,74 ;22218          JMP [IDC.DONE.T26]                          ;EXIT LOOP WHEN IDC IS DONE
                ;22219          DEC WR[0],                                  ;SET UP A LOOP TO CATCH
U 13F1, A100,35 ;22220           DT(LONG)&SET.ALU.CC                        ; IF THE SEQ STOPS WITH THE
U 13F2, 893E,F1 ;22221          JMP.IF[NEQ] TO [WAIT.IDC.T26]               ; DISK CLOCK SELECTED
                ;22222
U 13F3, 2F80,15 ;22223          CLR WR[0]                                   ;FORCE AN ERROR TO REPORT THAT
U 13F4, 3640,95 ;22224          MOV LS[#1] TO WR[1]                         ; THE IDC IS NOT RESPONDING IN
U 13F5, 0869,3C ;22225          JSR [CHECK.RESULT]                          ; THE DISKLESS LOOP
U 13F6, 093E,44 ;22226          JMP [LOOP.T26.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;22227
                ;22228  IDC.DONE.T26:
                ;22229
U 13F7, 2F80,15 ;22230          CLR WR[0]
U 13F8, 2F82,95 ;22231          CLR WR[1]
U 13F9, 0869,3C ;22232          JSR [CHECK.RESULT]                          ;CALL CHECK.RESULT TO LOCK
                ;22233                                                      ; IN INTERMITTANT ERRORS
U 13FA, 093E,44 ;22234          JMP [LOOP.T26.1]
                ;22235
U 13FB, B700,15 ;22236          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR THE FUNC BITS
U 13FC, 17A0,15 ;22237          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ; WRITE THE DATA TO IDC CSR
U 13FD, 90FA,15 ;22238          MISC2 [TRANSFER.GRANT]                      ;SEND TRANSFER GRANT
                ;22239
U 13FE, 3642,15 ;22240          MOV LS[#2] TO WR[0]
U 13FF, BE82,15 ;22241          MOV WR[0] TO LS[ERROR.NUMBER]               ;ERROR 2
U 1400, E580,15 ;22242          CLR LS[CONTROL.STATUS]                      ;ALLOW EXP AND REC DATA TO
                ;22243                                                      ; BE PRINTED ON ERROR
U 1401, B62C,15 ;22244          MOV LS[#FFFFFF00] TO WR[0]
U 1402, 3E8A,15 ;22245          MOV WR[0] TO LS[ERROR.MASK]                 ;SET MASK TO CHECK LO BYTE
                ;22246
                ;22247  ;READ THE BYTE OF DATA
U 1403, 9090,15 ;22248          MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 1404, 1788,15 ;22249          PORT.READ PORT.ADRS[DATA.BYTE]              ;SET UP TO READ  BYTE OF DATA
U 1405, 3B32,15 ;22250          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM FIFO AND
                ;22251                                                      ; SAVE IT IN  LS
U 1406, 3732,15 ;22252          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 1407, 2F82,95 ;22253          CLR WR[1]                                   ;SET UP THE EXPECTED DATA
U 1408, 0869,3C ;22254          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1409, 093E,44 ;22255          JMP [LOOP.T26.2]                            ;LOOP HERE IF ERR & LOE IS SET
                ;22256
                ;22257
U 140A, 8875,3C ;22258          JSR [CLEANUP]                               ;CLEANUP CONDITIONS SET BY
                ;22259                                                      ; THIS TEST
                ;22260
                ;22261  END.T26:                                            ;END TEST
                ;22262
                ;22263
                ;22264
```

```
;22265  .PAGE  "Test 27  RL02 DATA PATH TEST 2 (M8388 IDC MODULE)"
;22266  ;++
;22267  ;
;22268  ; Test Description:
;22269  ;
;22270  ;       This test will verify the RL02 data path on IDC excluding the
;22271  ;       the drivers and receivers to the RL02 Disk Drive. The data will be
;22272  ;       loaded into data buffer A. It will then be shifted through the DSR and
;22273  ;       then through the MFM encoder. The data will then go through the data
;22274  ;       separator, through the serial input of the DSR and into data buffer A
;22275  ;       ADDRESS =1.
;22276  ;       The CPU will then read data buffer A and check the data.
;22277  ;       The data patterns that will be used are:
;22278  ;               1. AA
;22279  ;               2. 55
;22280  ;               3. 33
;22281  ;               4. 0F
;22282  ;               5. FF
;22283  ;
;22284  ; Assumptions:
;22285  ;
;22286  ;       It is assumed that the Data Input, Data Output Buffer, Data
;22287  ;       Buffer A, Bus In, Bus Out, and the parallel inputs and outputs
;22288  ;       of the DSR are functional.
;22289  ;
;22290  ; Test Steps:
;22291  ;
;22292  ;       1. Set up error mask, error number and module number in LS
;22293  ;          (for error printouts) and clear the previous error number in LS.
;22294  ;       2. Load the data pattern into Data Buffer A from WR[0].
;22295  ;       3. Set up the  CSR to branch to the correct IDC routine.
;22296  ;
;22297  ;
;22298  ;                               *******
;22299  ;                               * IDC *
;22300  ;                               *******
;22301  ;
;22302  ;               IDC1. Shift out 32 zeros to sync up data separator.
;22303  ;               IDC2. Load the data pattern byte into the DSR.
;22304  ;               IDC3. Shift the byte thru the MFM encoder and back thru the
;22305  ;                     data separator into the DSR.
;22306  ;               IDC4. Write the byte into Data Buffer A address = 1.
;22307  ;               IDC5. Issue a XFER.REQ to the CPU to indicate IDC has completed
;22308  ;                     the operation.
;22309  ;
;22310  ;       4. Check the contents of FIFO A, ADDRESS 1. If incorrect,
;22311  ;          issue ERROR.
;22312  ;          Else load next data pattern into WR[0] and GO TO Step 2 until all
;22313  ;          data patterns have been tested.
;22314  ;
;22315  ; Errors:
;22316  ;
;22317  ;                       Printout:
;22318  ;                               EXPECTED        RECEIVED
;22319  ;                                FIFO A          FIFO A
```

```
                    ;22320  ;                               ADDR=1          ADDR=1
                    ;22321  ;
                    ;22322  ;       ERROR 1 - RL02 Data Path failed using data pattern of AA
                    ;22323  ;       ERROR 2 - RL02 Data Path failed using data pattern of 55
                    ;22324  ;       ERROR 3 - RL02 Data Path failed using data pattern of 33
                    ;22325  ;       ERROR 4 - RL02 Data Path failed using data pattern of 0F
                    ;22326  ;       ERROR 5 - RL02 Data Path failed using data pattern of FF
                    ;22327  ;
                    ;22328  ; Debug:
                    ;22329  ;
                    ;22330  ;       The RL02 Data Path up to the parallel load of the DSR has been proven
                    ;22331  ;       fully operational in previous tests. After the data is parallel loaded
                    ;22332  ;       into the DSR, the control line LOAD DSR H should deassert and the data
                    ;22333  ;       should then be serially shifted out through DSR 0. If this is not
                    ;22334  ;       happening correctly, then either the control line LOAD DSR H did not
                    ;22335  ;       deassert, or DSR 0 is shorted or the DSR itself is bad.
                    ;22336  ;
                    ;22337  ;       The data is then shifted into the MFM ENCODER PAL to become
                    ;22338  ;       WRT DATA <3:0>.
                    ;22339  ;       Input UMAINT H should be H and 4.1 MHZ CLK L should be clocking
                    ;22340  ;       DSR 0 through to WRT DATA <3:0>. The 4.1 MHZ CLK is generated by a
                    ;22341  ;       8.2 MHZ crystal oscillator located on the IDC module. The 8.2 MHZ
                    ;22342  ;       is then divided through the PEAK SHIFT COMP PAL to become 4.1 MHZ.
                    ;22343  ;
                    ;22344  ;       WRT DATA <3:0> then becomes the inputs to the PEAK SHIFT COMP PAL.
                    ;22345  ;       This PAL modifies the frequency of the write data which would in
                    ;22346  ;       normal operation be the data written on the disk. However in this
                    ;22347  ;       diskless loop, the data is output as WRITE DATA L, and then
                    ;22348  ;       immediately looped  back through the data separator.
                    ;22349  ;
                    ;22350  ;       The data is output from the Data Separator as DS DATA H. DS DATA H is
                    ;22351  ;       then ANDed with SEL STATUS CLK L which should be deasserted, and the
                    ;22352  ;       data becomes read data RL DATA L.
                    ;22353  ;
                    ;22354  ;       RL DATA L is then selected through a MIX by RL02 H = H, and becomes
                    ;22355  ;       READ DATA H. READ DATA H is then latched up through a flip flop and
                    ;22356  ;       becomes SER DATA IN H which is the serial input to the DSR. After the
                    ;22357  ;       byte of data has been serially shifted into the DSR, the byte of data
                    ;22358  ;       will be loaded into a quad buffer which is enabled by UENB DSR L = L.
                    ;22359  ;
                    ;22360  ;       The data will then be loaded into Data Buffer A address = 1,  to
                    ;22361  ;       be read and checked by the CPU.
                    ;22362  ;--
                    ;22363  ;*******************************************************************************
                    ;22364  T.27:
U 140B, B65E,15     ;22365          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;22366                                                  ; CONTROL AND STATUS WORD
U 140C, 3E80,15     ;22367          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;22368                                                  ; STATUS WORD - BIT 15
                    ;22369                                                  ; INDICATES START OF TEST TO
                    ;22370                                                  ; CONSOLE
U 140D, 10E0,15     ;22371          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;22372  WAIT.T27.0:
U 140E, 0940,E4     ;22373          JMP [WAIT.T27.0]                        ;LOOP HERE WAITING FOR
                    ;22374                                                  ; CONSOLE TO RESPOND
```

```
U 140F, 65A0,15 ;22375          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;22376                                                  ; IN LS
                ;22377
U 1410, B62C,15 ;22378          MOV LS[#FFFFFF00] TO WR[0]              ;SET MASK TO CHECK LOW BYTE
U 1411, 3E8A,15 ;22379          MOV WR[0] TO LS[ERROR.MASK]
                ;22380
U 1412, B64A,15 ;22381          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1413, 3E8C,15 ;22382          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;22383
U 1414, B640,15 ;22384          MOV LS[#1] TO WR[0]
U 1415, BE82,15 ;22385          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;22386
                ;22387
U 1416, B78E,15 ;22388          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;22389          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 1417, D94E,35 ;22390           DT(LONG)&SET.ALU.CC
U 1418, 0941,A1 ;22391          JMP.IF[BIT.SET] TO [SIZE.OK.T27.1]      ;IF YES THEN GO RUN TEST
                ;22392
U 1419, 8870,0C ;22393          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;22394
                ;22395  SIZE.OK.T27.1:
U 141A, 8872,EC ;22396          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;22397
                ;22398          ;SELECT AN RL02 DRIVE
                ;22399
U 141B, B78E,15 ;22400          MOV LS[DRIVE.STATUS] TO WR[0]
                ;22401          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 141C, 5940,35 ;22402           DT(LONG)&SET.ALU.CC
U 141D, 8942,09 ;22403          JMP.IF[BITS.CLR] TO [SET.DS0.T27.1]     ;JMP IF DRV 0 IS NOT AN R80
U 141E, B717,15 ;22404          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 141F, 8942,14 ;22405          JMP [TEST.T27.1]
                ;22406  SET.DS0.T27.1:
U 1420, 3715,15 ;22407          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;22408
                ;22409  TEST.T27.1:
                ;22410  LOOP.T27.1:
U 1421, B698,15 ;22411          MOV LS[#AAAAAAAA] TO WR[0]              ;GET FIRST DATA PATTERN
U 1422, 3F24,15 ;22412          MOV WR[0] TO LS[SAV.DATA.PAT]           ;SAVE IT
U 1423, 0873,DC ;22413          JSR [WRITE.READ.BYTE]                   ;CYCLE A BYTE OF [AA] THRU THE
                ;22414                                                  ; RL02 DATA PATH
U 1424, 0869,3C ;22415          JSR [CHECK.RESULT]                      ;WHEN RETURN,CHECK THE DATA
U 1425, 8942,14 ;22416          JMP [LOOP.T27.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;22417
U 1426, FF82,15 ;22418          INC LS[ERROR.NUMBER]                    ;NEXT ERROR NUMBER
                ;22419
                ;22420  LOOP.T27.2:
U 1427, 369A,15 ;22421          MOV LS[#55555555] TO WR[0]              ;GET THE NEXT DATA PATTERN
U 1428, 3F24,15 ;22422          MOV WR[0] TO LS[SAV.DATA.PAT]           ;SAVE IT
U 1429, 0873,DC ;22423          JSR [WRITE.READ.BYTE]                   ;CYCLE BYTE OF [55] THRU RL02
                ;22424                                                  ; DATA PATH
U 142A, 0869,3C ;22425          JSR [CHECK.RESULT]                      ;GO CHECK RESULT
U 142B, 8942,74 ;22426          JMP [LOOP.T27.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;22427
U 142C, FF82,15 ;22428          INC LS[ERROR.NUMBER]                    ;NEXT ERROR NUMBER
                ;22429
```

```
                    ;22430  LOOP.T27.3:
U 142D, B6C4,15     ;22431          MOV LS[#33333333] TO WR[0]          ;GET THE NEXT DATA PATTERN
U 142E, 3F24,15     ;22432          MOV WR[0] TO LS[SAV.DATA.PAT]       ;SAVE IT
U 142F, 0873,DC     ;22433          JSR [WRITE.READ.BYTE]               ;CYCLE BYTE OF [33] THRU RL02
                    ;22434                                              ; DATA PATH
U 1430, 0869,3C     ;22435          JSR [CHECK.RESULT]                  ;GO CHECK RESULT
U 1431, 8942,D4     ;22436          JMP [LOOP.T27.3]                    ;LOOP HERE IF ERR & LOE IS SET
                    ;22437
                    ;22438
U 1432, FF82,15     ;22439          INC LS[ERROR.NUMBER]                ;ERROR 4
                    ;22440
                    ;22441  LOOP.T27.4:
U 1433, 36C6,15     ;22442          MOV LS[#0F0F0F0F] TO WR[0]          ;GET THE NEXT DATA PATTERN
U 1434, 3F24,15     ;22443          MOV WR[0] TO LS[SAV.DATA.PAT]       ;SAVE IT
U 1435, 0873,DC     ;22444          JSR [WRITE.READ.BYTE]               ;CYCLE BYTE OF [0F] THRU RL02
                    ;22445                                              ; DATA PATH
U 1436, 0869,3C     ;22446          JSR [CHECK.RESULT]                  ;GO CHECK RESULT
U 1437, 8943,34     ;22447          JMP [LOOP.T27.4]                    ;LOOP HERE IF ERR & LOE IS SET
                    ;22448
U 1438, FF82,15     ;22449          INC LS[ERROR.NUMBER]                ;ERROR 5
                    ;22450
                    ;22451  LOOP.T27.5:
U 1439, B69E,15     ;22452          MOV LS[#FFFFFFFF] TO WR[0]          ;GET THE NEXT DATA PATTERN
U 143A, 3F24,15     ;22453          MOV WR[0] TO LS[SAV.DATA.PAT]       ;SAVE IT
U 143B, 0873,DC     ;22454          JSR [WRITE.READ.BYTE]               ;CYCLE BYTE OF [FF] THRU RL02
                    ;22455                                              ; DATA PATH
U 143C, 0869,3C     ;22456          JSR [CHECK.RESULT]                  ;GO CHECK RESULT
U 143D, 8943,94     ;22457          JMP [LOOP.T27.5]                    ;LOOP HERE IF ERR & LOE IS SET
                    ;22458
                    ;22459
U 143E, 8875,3C     ;22460          JSR [CLEANUP]                       ;CLEANUP THE CONDITIONS SET BY
                    ;22461                                              ; THIS TEST
                    ;22462
                    ;22463  END.T27:                                    ;END TEST
                    ;22464
                    ;22465
                    ;22466
```

```
;22467  .PAGE  "Test 28  ECC STAT<1:0> LINES TEST (M8388 IDC MODULE)"
;22468  ;++
;22469  ;
;22470  ; Test Description:
;22471  ;
;22472  ;       This test is designed to check the ECC STAT<1:0> lines. First a
;22473  ;       UCLR ECC is issued and ECC STAT <1:0> are checked = 00.
;22474  ;       Then an ECC error will be generated and ECC STAT <1:0> checked = 01.
;22475  ;
;22476  ; Assumptions:
;22477  ;
;22478  ;       It is assumed that all previous tests have run successfully.
;22479  ;
;22480  ; Test Steps:
;22481  ;
;22482  ;       1. Set up error mask, error number and module number in LS
;22483  ;          (for error printouts) and clear the previous error number in LS.
;22484  ;       2. Force the IDC microcode to DIAG.IDLE.
;22485  ;       3. Set up the CSR to branch to the correct IDC microcode routine.
;22486  ;
;22487  ;                                       *******
;22488  ;                                       * IDC *
;22489  ;                                       *******
;22490  ;
;22491  ;               IDC1. Execute an instruction with FUNC <35:32> = 0001,
;22492  ;                     UCLR ECC.
;22493  ;
;22494  ;       4. Wait for a XFER REQ from the IDC.
;22495  ;       5. Clear CSR F<2:0> and send XFER GRANT.
;22496  ;       6. Check CSR <21:20> = 00, ECC STAT<1:0>.
;22497  ;       7. Write a one to FIFO A address 0.
;22498  ;       8. Set up the CSR to branch to the correct IDC routine.
;22499  ;
;22500  ;
;22501  ;                                       *******
;22502  ;                                       * IDC *
;22503  ;                                       *******
;22504  ;
;22505  ;               IDC2. Load the one form FIFO A address 0 into the DC007
;22506  ;                     internal shift register to make it non-zero.
;22507  ;               IDC3. Assert CHECK.FIELD and UMAINT to select DSR0 as NRZ data.
;22508  ;               IDC4. Deassert CHECK.FIELD to assert ERR.
;22509  ;               IDC5. Send XFER REQ to flag the CPU.
;22510  ;
;22511  ;       9. Wait for XFER REQ from the IDC.
;22512  ;      10. Clear CSR F<2:0> and send XFER GRANT to clear XFER REQ.
;22513  ;      11. Check CSR <21:20> = 01.
;22514  ;      12. Clear IDC.
;22515  ;      13. End test.
;22516  ;
;22517  ; Errors:
;22518  ;
;22519  ;
;22520  ;                       Printout:
;22521  ;
```

```
                ;22522  ;                       EXPECTED          RECEIVED
                ;22523  ;                       ECC STAT<1:0>     ECC STAT<1:0>
                ;22524  ;                       CSR <21:20>       CSR <21:20>
                ;22525  ;
                ;22526  ;       ERROR 1 - The ECC STAT <1:0> bits did not both initialize to 00.
                ;22527  ;
                ;22528  ;       ERROR 2 - DC007 ERR did not set or the ECC STAT<1:0> bits failed.
                ;22529  ;
                ;22530  ;
                ;22531  ; Debug:
                ;22532  ;
                ;22533  ; ERROR 1 -
                ;22534  ;       The IDC microcode will execute an instrcution with FUNC <3:0>=0001.
                ;22535  ;       These bits will be decoded and will assert UCLR ECC L. This signal
                ;22536  ;       is the Clear line to the CRC/ECC chip and will deassert ECC STAT 1 H
                ;22537  ;       and ECC STAT 0 H. These signals are driven onto IO BUS <21:20> when the
                ;22538  ;       CSR is read.
                ;22539  ;
                ;22540  ; ERROR 2 -
                ;22541  ;       A one is loaded into FIFO A address 0. This data is then loaded into
                ;22542  ;       the DSR. The IDC microword will then assert UMAINT H, UCHECK FIELD H
                ;22543  ;       and UENB CRC H. UMAINT H allows DSR 0 H to become NRZ WRT DATA H at the
                ;22544  ;       MFM ENCODER PAL. UCHECK FIELD H = H and UENB CRC H = H allow NRZ WRT
                ;22545  ;       DATA H to be shifted in to the internal Pattern register of the CRC/ECC
                ;22546  ;       chip. In the next IDC micro-instruction, UCHECK FIELD H will be
                ;22547  ;       deasserted to make the CRC/ECC chip believe that it has read the check
                ;22548  ;       field. UDATA FIELD H will be asserted to keep the internal clock
                ;22549  ;       running and ENB CRC  H will be asserted to prevent certain CRC/ECC chip
                ;22550  ;       internal signals. UMAINT H is still asserted to allow DSR 0 H as
                ;22551  ;       NRZ WRT DATA H. When UCHECK FIELD H was deasserted, the internal
                ;22552  ;       CRC/ECC chip Pattern register was non-zero so an internal error
                ;22553  ;       condition will result, forcing ECC STAT 1 H = L and ECC STAT 0 H = H.
                ;22554  ;       These signals are driven onto IO BUS <21:20> when the CSR is read.
                ;22555  ;--
                ;22556  ;*****************************************************************************
                ;22557  T.28:
U 143F, B65E,15 ;22558          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;22559                                                  ; CONTROL AND STATUS WORD
U 1440, 3E80,15 ;22560          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;22561                                                  ; STATUS WORD - BIT 15
                ;22562                                                  ; INDICATES START OF TEST TO
                ;22563                                                  ; CONSOLE
U 1441, 10E0,15 ;22564          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;22565  WAIT.T28.0:
U 1442, 8944,24 ;22566          JMP [WAIT.T28.0]                        ;LOOP HERE WAITING FOR
                ;22567                                                  ; CONSOLE TO RESPOND
                ;22568
U 1443, 65A0,15 ;22569          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;22570                                                  ; IN LS
                ;22571
U 1444, B64A,15 ;22572          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1445, 3E8C,15 ;22573          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;22574
                ;22575
U 1446, 37A4,15 ;22576          MOV LS[#FFCFFFFF] TO WR[0]              ;MASK TO CHECK BITS <21:20>
```

```
U 1447, 3E8A,15 ;22577          MOV WR[0] TO LS[ERROR.MASK]
                ;22578
U 1448, 8872,EC ;22579          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;22580
                ;22581  LOOP.T28.1:
                ;22582  LOOP.T28.2:
U 1449, B640,15 ;22583          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 144A, BE82,15 ;22584          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;22585
U 144B, B712,15 ;22586          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 144C, B720,95 ;22587          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE CORRECT IDC ROUTINE
U 144D, AEC2,15 ;22588          BIS WR[1] TO WR[0]
U 144E, 370C,95 ;22589          MOV LS[SETCSR.F6] TO WR[1]
U 144F, AEC2,15 ;22590          BIS WR[1] TO WR[0]
U 1450, 17A0,15 ;22591          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;22592                                                  ;MAINT=1,CRDY=1,F<2:0>=110
                ;22593  ;-------------------------------------------------------------------------------
                ;22594  ;-------------------------------------------------------------------------------
                ;22595  ;                               *******
                ;22596  ;                               * IDC *
                ;22597  ;                               *******
                ;22598  ;-------------------------------------------------------------------------------
                ;22599  ;018:
                ;22600  ;=000
                ;22601  ;DIAG.IDLE:
                ;22602  ;
                ;22603  ;       BEN0/F0,
                ;22604  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;22605  ;       BEN2/F2,
                ;22606  ;       NAD/DIAG.IDLE
                ;22607  ;-------------------------------------------------------------------------------
                ;22608  ;01E:
                ;22609  ;=110
                ;22610  ;
                ;22611  ;       BEN0/CRDY.L,
                ;22612  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;22613  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;22614  ;-------------------------------------------------------------------------------
                ;22615  ;076:
                ;22616  ;=1*0
                ;22617  ;TEST.ECC.1:
                ;22618  ;
                ;22619  ;       FUNC/CLR.ECC,           ;ISSUE CLR ECC TO INIT THE DC007
                ;22620  ;       NAD/XFER.REQ            ;FLAG THE CPU
                ;22621  ;-------------------------------------------------------------------------------
                ;22622  ;1D8:
                ;22623  ;XFER.REQ:
                ;22624  ;       UCMD/SET.XFER.RQST,     ;SEND XFER REQ TO THE CPU
                ;22625  ;       NAD/DIAG.WAIT
                ;22626  ;-------------------------------------------------------------------------------
                ;22627  ;1D7:
                ;22628  ;DIAG.WAIT:
                ;22629  ;
                ;22630  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;22631  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
```

```
                ;22632  ;-----------------------------------------------------------------------
                ;22633  ;159:
                ;22634  ;=*0*
                ;22635  ;DIAG.WAIT1:
                ;22636  ;
                ;22637  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;22638  ;                               ; COMMAND FROM THE CPU
                ;22639  ;-----------------------------------------------------------------------
                ;22640  ;15B:
                ;22641  ;=*1*
                ;22642  ;DIAG.WAIT2:
                ;22643  ;
                ;22644  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;22645  ;                               ; WAIT SOME MORE
                ;22646  ;-----------------------------------------------------------------------
                ;22647  WAIT.IDC.T28.1:
U 1451, DB00,1A ;22648          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1452, 0945,44 ;22649          JMP [IDC.DONE.T28.1]                    ;XFER REQ SET
U 1453, 0945,14 ;22650          JMP [WAIT.IDC.T28.1]                    ;WAIT SOME MORE
                ;22651
                ;22652  IDC.DONE.T28.1:
U 1454, B700,15 ;22653          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1455, 17A0,15 ;22654          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1456, 90FA,15 ;22655          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;22656
                ;22657
                ;22658  READ.CSR.T28.1:
U 1457, 9090,15 ;22659          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1458, 9780,15 ;22660          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1459, 3B32,15 ;22661          MOV PORT TO LS[PORT0]                   ;READ THE CSR AND
                ;22662                                                  ; SAVE IT IN  LS
U 145A, 3732,15 ;22663          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 145B, 2F82,95 ;22664          CLR WR[1]                               ;EXPECTED DATA
U 145C, 0869,3C ;22665          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 145D, 0944,94 ;22666          JMP [LOOP.T28.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;22667
                ;22668  ;FORCE AN ERROR ON THE DC007 CHIP AND CHECK ECC STAT<1:0>=01
                ;22669
                ;22670  ;WRITE A ONE TO THE FIFO TO LATER BE LOADED INTO THE DC007 PATTERN REG TO
                ;22671  ; FORCE ERROR
                ;22672
U 145E, 3642,15 ;22673          MOV LS[#2] TO WR[0]
U 145F, BE82,15 ;22674          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 2
                ;22675
U 1460, 17D8,15 ;22676          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1461, 17C0,15 ;22677          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
U 1462, B640,15 ;22678          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE
U 1463, 97A8,15 ;22679          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A ONE TO FIFO A
U 1464, 17C0,15 ;22680          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
                ;22681
U 1465, 3712,95 ;22682          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1466, 370E,15 ;22683          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 1467, AEC2,15 ;22684          BIS WR[1] TO WR[0]
U 1468, 17A0,15 ;22685          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;22686                                                  ;MAINT=0,CRDY=1,F<2:0>=111
```

```
                ;22687
                ;22688  ;CONTINUE BRANCHING
                ;22689
U 1469, B79F,15 ;22690          MOV LS[SETCSR.R80] TO WR[2]             ;CONTINUE TO BRANCH TO THE
U 146A, 3702,15 ;22691          MOV LS[SETCSR.F1] TO WR[0]              ; IDC ROUTINE
U 146B, 3712,95 ;22692          MOV LS[SETCSR.CRDY] TO WR[1]
U 146C, AEC2,15 ;22693          BIS WR[1] TO WR[0]                      ;SET CRDY TO HOLD SDIO LO
U 146D, AEC4,15 ;22694          BIS WR[2] TO WR[0]
U 146E, 17A0,15 ;22695          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;22696                                                  ;R80=1,F<2:0>=001
                ;22697  ;-------------------------------------------------------------------------
                ;22698  ;-------------------------------------------------------------------------
                ;22699  ;                               *******
                ;22700  ;                               * IDC *
                ;22701  ;                               *******
                ;22702  ;-----------------------------------------------------------------------
                ;22703  ;018:
                ;22704  ;=000
                ;22705  ;DIAG.IDLE:
                ;22706  ;
                ;22707  ;       BEN0/F0,
                ;22708  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;22709  ;       BEN2/F2,
                ;22710  ;       NAD/DIAG.IDLE
                ;22711  ;-----------------------------------------------------------------------
                ;22712  ;01F:
                ;22713  ;=111
                ;22714  ;
                ;22715  ;       BEN0/CRDY.L,
                ;22716  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;22717  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;22718  ;-----------------------------------------------------------------------
                ;22719  ;078:
                ;22720  ;=0*0
                ;22721  ;TEST.FUNC7:
                ;22722  ;
                ;22723  ;       NAD/GROUP0
                ;22724  ;-----------------------------------------------------------------------
                ;22725  ;163:
                ;22726  ;=0**
                ;22727  ;GROUP0:
                ;22728  ;
                ;22729  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;22730  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;22731  ;                                       ; FUNCTION BITS
                ;22732  ;-----------------------------------------------------------------------
                ;22733  ;167:
                ;22734  ;=1**
                ;22735  ;
                ;22736  ;       BEN0/F0,
                ;22737  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;22738  ;       BEN2/F2,
                ;22739  ;       NAD/GROUP0.F0
                ;22740  ;-----------------------------------------------------------------------
                ;22741  ;021:
```

```
;22742  ;=001
;22743  ;POS.REG.1:
;22744  ;
;22745  ;       UCMD/SET.FIFOA,                 ;SEL FIFO A
;22746  ;       NAD/POS.REG.2
;22747  ;-------------------------------------------------------------------------
;22748  ;1E9:
;22749  ;POS.REG.2:
;22750  ;
;22751  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;22752  ;       LOAD.DSR/ON,
;22753  ;       NAD/POS.REG.3
;22754  ;-------------------------------------------------------------------------
;22755  ;1EA:
;22756  ;POS.REG.3:
;22757  ;
;22758  ;       UMAINT/ON,                      ;ENABLE DSR0 AS NRZ DATA
;22759  ;       CHECK.FIELD/ON,                 ;MAKE DC007 BELIEVE IT HAS READ THE
;22760  ;       MODE/CRC,                       ; CHECK FIELD
;22761  ;       NAD/POS.REG.4
;22762  ;-------------------------------------------------------------------------
;22763  ;1EB:
;22764  ;POS.REG.4:
;22765  ;
;22766  ;       MODE/CRC,                       ;DROP CHECK FIELD WHILE THE INTERNAL
;22767  ;                                       ; DC007 SHIFT REG IS NON-ZERO TO
;22768  ;                                       ; ASSERT ERROR INTERNAL TO THE DC007
;22769  ;                                       ;ERROR ALLOWS THE POS REG TO INCR
;22770  ;       DATA.FIELD/ON,                  ;ASSERT DATA FIELD TO ALLOW CLK
;22771  ;       UMAINT/ON,                      ;TO SELECT DSR0 AS NRZ DATA
;22772  ;       NAD/POS.REG.5
;22773  ;-------------------------------------------------------------------------
;22774  ;1EC:
;22775  ;POS.REG.5:
;22776  ;
;22777  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
;22778  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
;22779  ;       UMAINT/ON,                      ;TO SEL DSR0 AS NRZ DATA
;22780  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;22781  ;-------------------------------------------------------------------------
;22782  ;1D8:
;22783  ;XFER.REQ:
;22784  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;22785  ;       NAD/DIAG.WAIT
;22786  ;-------------------------------------------------------------------------
;22787  ;1D7:
;22788  ;DIAG.WAIT:
;22789  ;
;22790  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;22791  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;22792  ;-------------------------------------------------------------------------
;22793  ;159:
;22794  ;=*0*
;22795  ;DIAG.WAIT1:
;22796  ;
```

```
                ;22797  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;22798  ;                               ; COMMAND FROM THE CPU
                ;22799  ;-------------------------------------------------------------------------
                ;22800  ;15B:
                ;22801  ;=*1*
                ;22802  ;DIAG.WAIT2:
                ;22803  ;
                ;22804  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;22805  ;                               ; WAIT SOME MORE
                ;22806  ;-------------------------------------------------------------------------
                ;22807  WAIT.IDC.T28.2:
U 146F, DB00,1A ;22808          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1470, 8947,24 ;22809          JMP [IDC.DONE.T28.2]                    ;XFER REQ SET
U 1471, 8946,F4 ;22810          JMP [WAIT.IDC.T28.2]                    ;WAIT SOME MORE
                ;22811
                ;22812  IDC.DONE.T28.2:
U 1472, B700,15 ;22813          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1473, 17A0,15 ;22814          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1474, 90FA,15 ;22815          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;22816
                ;22817  READ.CSR.T28.2:
U 1475, 9090,15 ;22818          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1476, 9780,15 ;22819          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1477, 3B32,15 ;22820          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;22821                                                  ; SAVE IT IN  LS
U 1478, 3732,15 ;22822          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1479, 3668,95 ;22823          MOV LS[BIT20] TO WR[1]                  ;SET UP EXPECTED DATA
U 147A, 0869,3C ;22824          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 147B, 0944,94 ;22825          JMP [LOOP.T28.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;22826
                ;22827
                ;22828
U 147C, 8875,3C ;22829          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;22830                                                  ; THIS TEST
                ;22831
                ;22832
                ;22833
                ;22834
                ;22835  END.T28:                                        ;END TEST
                ;22836
                ;22837
```

```
;22838  .PAGE  "Test 29  DC007 INTERNAL SHIFT REGISTER INIT TEST (M8388 IDC MODULE)"
;22839  ;++
;22840  ;
;22841  ; Test Description:
;22842  ;
;22843  ;       This test is designed to insure that none of the bits of the internal
;22844  ;       shift register of the CRC/ECC chip are stuck at one. This will be done
;22845  ;       by asserting UCLR ECC which should clear the shift register. The CPU
;22846  ;       will then do a READ PATTERN, which reads bits <31:21> of the shift
;22847  ;       register and check for all zeros. The register will then be shifted
;22848  ;       left B Hex times while shifting in zeros. The CPU will then do a
;22849  ;       READ PATTERN and check for all zeros. The register will again be
;22850  ;       shifted left B Hex times and the CPU will READ PATTERN and check for
;22851  ;       all zeros.
;22852  ;
;22853  ; Assumptions:
;22854  ;
;22855  ;       It is assumed that all previous test have run successfully.
;22856  ;
;22857  ; Test Steps:
;22858  ;
;22859  ;       1. Set up error mask, error number and module number in LS
;22860  ;          (for error printouts) and clear the previous error number in LS.
;22861  ;       2. Force the IDC microcode to DIAG.IDLE.
;22862  ;       3. Set up the CSR to branch to the correct IDC microcode routine.
;22863  ;
;22864  ;                                       *******
;22865  ;                                       * IDC *
;22866  ;                                       *******
;22867  ;
;22868  ;               IDC1. Execute an instruction with FUNC <35:32> = 0001,
;22869  ;                     UCLR ECC.
;22870  ;               IDC2. Send XFER REQ.
;22871  ;
;22872  ;       4. Wait for an XFER REQ from IDC.
;22873  ;       5. Clear CSR F<2:0> and send XFER GRANT.
;22874  ;       6. Execute a READ PATTERN and check the data = 0.
;22875  ;       7. Increment the error number.
;22876  ;       8. Set up the CSR to branch to the correct IDC routine.
;22877  ;
;22878  ;
;22879  ;                                       *******
;22880  ;                                       * IDC *
;22881  ;                                       *******
;22882  ;
;22883  ;               IDC3. Shift the pattern register B HEX times.
;22884  ;               IDC4. Send XFER REQ.
;22885  ;
;22886  ;       9. Wait for XFER REQ from the IDC.
;22887  ;      10. Clear CSR F<2:0> and send XFER GRANT.
;22888  ;      11. Read PATTERN and check data = 0.
;22889  ;      12. Increment the error number.
;22890  ;      13. Repeat Steps 8 - 11 to read the reamining bits of the register.
;22891  ;      14. Clear IDC.
;22892  ;      15. End test.
```

```
;22893   ;
;22894   ; Errors:
;22895   ;
;22896   ;                   Printout:
;22897   ;                           EXPECTED                    RECEIVED
;22898   ;                      INTERNAL SHIFT REG          INTERNAL SHIFT REG
;22899   ;                        (ECC PATTERN)               (ECC PATTERN)
;22900   ;
;22901   ;         ERROR 1 - The CRC/ECC internal shift register failed or the READ
;22902   ;                   PATTERN instruction failed.
;22903   ;
;22904   ;         ERROR 2 - The CRC/ECC internal shift register failed.
;22905   ;
;22906   ;         ERROR 3 - The CRC/ECC internal shift register failed.
;22907   ;
;22908   ;
;22909   ; Debug:
;22910   ;
;22911   ; ERROR 1 -
;22912   ;         The IDC microcode will execute an instrcution with FUNC <3:0>=0001.
;22913   ;         These bits will be decoded and will assert UCLR ECC L. This signal
;22914   ;         is the Clear line to the CRC/ECC chip and will clear the CRC/ECC
;22915   ;         chip internal Pattern register.
;22916   ;         The CPU will issue a MISC [SET.PORT.I.0] instruction that will
;22917   ;         deassert SEL ACC IN H. This is inverted to SEL ACC L = H.
;22918   ;         The CPU will then issue a PORT.READ PORT.ADRS[PATTERN] instruction.
;22919   ;         The inputs to the PORT INTERFACE REG PAL will be:
;22920   ;                 CSR 17 H = H
;22921   ;                 CSR 14 H = L
;22922   ;                 CSR 12 H = H
;22923   ;                 CSR 11 H = L
;22924   ;                 CSR 10 H = L
;22925   ;                 PORT INSTR H = H
;22926   ;                 CPU P2 H = H
;22927   ;         At CPU CLOCK H, the outputs will be:
;22928   ;                 SEL IDC H = H
;22929   ;                 R2 L = L
;22930   ;                 R1 L = H
;22931   ;                 R0 L = H
;22932   ;         The next instruction issued by the CPU will be a MOV PORT TO LS[].
;22933   ;         This will assert READ PORT L. This signal is inverted by the PORT
;22934   ;         INTERFACE REG PAL and becomes READ PORT H = H. READ PORT H = H
;22935   ;         is gated with SEL IDC H = H and SEL ACC L = H and will assert READ
;22936   ;         IDC L.  READ IDC L = L and READ PORT H = H are the enables for the
;22937   ;         decoder of R2 L = L, R1 L = H, R0 L = H. This combination of inputs
;22938   ;         will assert SEL PATTERN L. SEL PATTERN L is an input to the CRC/ECC
;22939   ;         chip and will drive the internal Pattern register bits<21:31> onto
;22940   ;         BUS IO <10:0>. This data is then stored in the specified LS location.
;22941   ;
;22942   ; ERROR 2 -
;22943   ;         The CRC/ECC internal Pattern register is shifted 11 times so that
;22944   ;         the next 11 bits can be read.
;22945   ;         This is done by executing 11 IDC microinstructions with UENB CRC H = L,
;22946   ;         UDATA FIELD H = H, UMAINT H = H. UMAINT H = H allows DSR 0 to become
;22947   ;         NRZ WRT DATA H at the MFM ENCODER PAL so that zeros continue to
```

```
                ;22948  ;       be shifted into the CRC/ECC internal Pattern register. UDATA FIELD H
                ;22949  ;       allows the Pattern register to be clocked and UENB CRC H = L allows
                ;22950  ;       all 32 bits of the internal Pattern register to shift. The CPU will
                ;22951  ;       then read bits<21:31> of the Pattern register.
                ;22952  ;
                ;22953  ; ERROR 3 -
                ;22954  ;       The CRC/ECC internal Pattern register is shifted 11 times so that
                ;22955  ;       the last 11 bits can be read.
                ;22956  ;       See ERROR 2.
                ;22957  ;--
                ;22958  ;*****************************************************************************
                ;22959  T.29:
U 147D, B65E,15 ;22960          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;22961                                                          ; CONTROL AND STATUS WORD
U 147E, 3E80,15 ;22962          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;22963                                                          ; STATUS WORD - BIT 15
                ;22964                                                          ; INDICATES START OF TEST TO
                ;22965                                                          ; CONSOLE
U 147F, 10E0,15 ;22966          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;22967  WAIT.T29.0:
U 1480, 0948,04 ;22968          JMP [WAIT.T29.0]                                ;LOOP HERE WAITING FOR
                ;22969                                                          ; CONSOLE TO RESPOND
                ;22970
U 1481, 65A0,15 ;22971          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
                ;22972                                                          ; IN LS
                ;22973
U 1482, B64A,15 ;22974          MOV LS[IDC] TO WR[0]                            ;STORE MODULE CODE IN LS TO
U 1483, 3E8C,15 ;22975          MOV WR[0] TO LS[MODULE.NUM]                     ; INDICATE IDC MODULE
                ;22976
                ;22977
                ;22978
U 1484, B7A6,15 ;22979          MOV LS[#FFFFE000] TO WR[0]                      ;SET UP THE MASK TO CHECK
U 1485, 3E8A,15 ;22980          MOV WR[0] TO LS[ERROR.MASK]                     ; BITS <12:0>
                ;22981
U 1486, 8872,EC ;22982          JSR [DIAG.CODE]                                 ;FORCE THE IDC TO DIAG.IDLE
                ;22983
                ;22984  LOOP.T29.1:
U 1487, B640,15 ;22985          MOV LS[#1] TO WR[0]                             ;SET WR0 = 1
U 1488, BE82,15 ;22986          MOV WR[0] TO LS[ERROR.NUMBER]                   ;SET UP ERROR NUMBER = 1 IN LS
                ;22987
U 1489, B712,15 ;22988          MOV LS[SETCSR.CRDY] TO WR[0]                    ;SET UP THE CSR TO BRANCH TO
U 148A, B720,95 ;22989          MOV LS[SETCSR.MAINT] TO WR[1]                   ; THE CORRECT IDC ROUTINE
U 148B, AEC2,15 ;22990          BIS WR[1] TO WR[0]
U 148C, 370C,95 ;22991          MOV LS[SETCSR.F6] TO WR[1]
U 148D, AEC2,15 ;22992          BIS WR[1] TO WR[0]
U 148E, 17A0,15 ;22993          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]            ;WRITE THE CSR
                ;22994                                                          ;MAINT=1,CRDY=1,F<2:0>=110
                ;22995  ;UCLR ECC
                ;22996  ;-------------------------------------------------------------------------
                ;22997  ;-------------------------------------------------------------------------
                ;22998  ;                               *******
                ;22999  ;                               * IDC *
                ;23000  ;                               *******
                ;23001  ;-----------------------------------------------------------------------
                ;23002  ;018:
```

```
                ;23003  ;=000
                ;23004  ;DIAG.IDLE:
                ;23005  ;
                ;23006  ;       BEN0/F0,
                ;23007  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23008  ;       BEN2/F2,
                ;23009  ;       NAD/DIAG.IDLE
                ;23010  ;-------------------------------------------------------------------------
                ;23011  ;01E:
                ;23012  ;=110
                ;23013  ;
                ;23014  ;       BEN0/CRDY.L,
                ;23015  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;23016  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;23017  ;-------------------------------------------------------------------------
                ;23018  ;076:
                ;23019  ;=1*0
                ;23020  ;TEST.ECC.1:
                ;23021  ;
                ;23022  ;       FUNC/CLR.ECC,                   ;ISSUE CLR ECC TO INIT THE DC007
                ;23023  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;23024  ;-------------------------------------------------------------------------
                ;23025  ;1D8:
                ;23026  ;XFER.REQ:
                ;23027  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;23028  ;       NAD/DIAG.WAIT
                ;23029  ;-------------------------------------------------------------------------
                ;23030  ;1D7:
                ;23031  ;DIAG.WAIT:
                ;23032  ;
                ;23033  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;23034  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;23035  ;-------------------------------------------------------------------------
                ;23036  ;159:
                ;23037  ;=*0*
                ;23038  ;DIAG.WAIT1:
                ;23039  ;
                ;23040  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;23041  ;                               ; COMMAND FROM THE CPU
                ;23042  ;-------------------------------------------------------------------------
                ;23043  ;15B:
                ;23044  ;=*1*
                ;23045  ;DIAG.WAIT2:
                ;23046  ;
                ;23047  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;23048  ;                               ; WAIT SOME MORE
                ;23049  ;-------------------------------------------------------------------------
                ;23050  WAIT.IDC.T29.1:
U 148F, DB00,1A ;23051          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1490, 0949,24 ;23052          JMP [IDC.DONE.T29.1]                    ;XFER REQ SET
U 1491, 0948,F4 ;23053          JMP [WAIT.IDC.T29.1]                    ;WAIT SOME MORE
                ;23054
                ;23055  IDC.DONE.T29.1:
U 1492, B700,15 ;23056          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1493, 17A0,15 ;23057          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
```

```
U 1494, 90FA,15 ;23058          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;23059
                ;23060  READ.PATTERN.T29.1:
U 1495, 9090,15 ;23061          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1496, 1790,15 ;23062          PORT.READ PORT.ADRS[PATTERN]            ;READ THE PATTERN INFO
U 1497, 3B32,15 ;23063          MOV PORT TO LS[PORT0]                   ;AND SAVE IT IS LS
U 1498, 3732,15 ;23064          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1499, 2F82,95 ;23065          CLR WR[1]                               ;EXPECTED DATA
U 149A, 0869,3C ;23066          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 149B, 8948,74 ;23067          JMP [LOOP.T29.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;23068
                ;23069
                ;23070  ;CLK THE DC007 CHIP 11 TIMES TO SHIFT THE REGISTER AND READ AGAIN FOR ALL ZEROS
                ;23071
U 149C, 3643,95 ;23072          MOV LS[#2] TO WR[3]                     ;USE AS A COUNTER
U 149D, FF82,15 ;23073          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;23074
                ;23075  SHFT.REG.T29:
U 149E, B712,15 ;23076          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 149F, B70E,95 ;23077          MOV LS[SETCSR.F7] TO WR[1]              ; THE CORRECT IDC ROUTINE
U 14A0, AEC2,15 ;23078          BIS WR[1] TO WR[0]
U 14A1, 17A0,15 ;23079          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23080                                                  ;MAINT=0,CRDY=1,F<2:0>=111
                ;23081
                ;23082  ;SET UP THE CSR AGAIN TO CONTINUE BRANCH TO THE CORRECT IDC ROUTINE
                ;23083
U 14A2, B79E,95 ;23084          MOV LS[SETCSR.R80] TO WR[1]
U 14A3, B712,15 ;23085          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET CRDY TO HOLD SDIO=0
U 14A4, AEC2,15 ;23086          BIS WR[1] TO WR[0]                      ;PUT DATA IN WR[0]
U 14A5, 3706,95 ;23087          MOV LS[SETCSR.F3] TO WR[1]              ;
U 14A6, AEC2,15 ;23088          BIS WR[1] TO WR[0]                      ;PUT ALL THE DATA TO WRT IN WR0
U 14A7, 17A0,15 ;23089          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23090                                                  ;R80=1, F<2:0>=011
                ;23091  ;-------------------------------------------------------------------------------
                ;23092  ;-------------------------------------------------------------------------------
                ;23093  ;                               *******
                ;23094  ;                               * IDC *
                ;23095  ;                               *******
                ;23096  ;-------------------------------------------------------------------------------
                ;23097  ;018:
                ;23098  ;=000
                ;23099  ;DIAG.IDLE:
                ;23100  ;
                ;23101  ;       BEN0/F0,
                ;23102  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23103  ;       BEN2/F2,
                ;23104  ;       NAD/DIAG.IDLE
                ;23105  ;-------------------------------------------------------------------------------
                ;23106  ;01F:
                ;23107  ;=111
                ;23108  ;
                ;23109  ;       BEN0/CRDY.L,
                ;23110  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;23111  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;23112  ;-------------------------------------------------------------------------------
```

```
;23113  ;078:
;23114  ;=0*0
;23115  ;TEST.FUNC7:
;23116  ;
;23117  ;       NAD/GROUP0
;23118  ;-------------------------------------------------------------------------
;23119  ;163:
;23120  ;=0**
;23121  ;GROUP0:
;23122  ;
;23123  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;23124  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
;23125  ;                                       ; FUNCTION BITS
;23126  ;-------------------------------------------------------------------------
;23127  ;167:
;23128  ;=1**
;23129  ;
;23130  ;       BEN0/F0,
;23131  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;23132  ;       BEN2/F2,
;23133  ;       NAD/GROUP0.F0
;23134  ;-------------------------------------------------------------------------
;23135  ;023:
;23136  ;=011
;23137  ;DC007.SHIFT.REG.1:
;23138  ;
;23139  ;       LOAD.LOOP.CNTR.[0F5],           ;SHIFT THE DC007 INT REG 11 TIMES
;23140  ;       NAD/DC007.SHIFT.REG.2
;23141  ;-------------------------------------------------------------------------
;23142  ;194:
;23143  ;=0
;23144  ;DC007.SHIFT.REG.2:
;23145  ;
;23146  ;       MODE/ECC,                       ;ASSERT ECC TO SHFT BIT 31
;23147  ;       DATA.FIELD/ON,                  ;TO ALLOW READ CLK
;23148  ;       UMAINT/ON,                      ;TO SELECT DSR0 AS NRZ DATA
;23149  ;       INCR.LPCNTR/ON,
;23150  ;       BEN0/CNTR.OVFLW,                ;LOOP UNTIL SHIFT 11 TIMES
;23151  ;       NAD/DC007.SHIFT.REG.2
;23152  ;-------------------------------------------------------------------------
;23153  ;195:
;23154  ;=1
;23155  ;DC007.SHIFT.REG.3:
;23156  ;
;23157  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;23158  ;-------------------------------------------------------------------------
;23159  ;1D8:
;23160  ;XFER.REQ:
;23161  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;23162  ;       NAD/DIAG.WAIT
;23163  ;-------------------------------------------------------------------------
;23164  ;1D7:
;23165  ;DIAG.WAIT:
;23166  ;
;23167  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
```

```
                ;23168  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;23169  ;-------------------------------------------------------------------
                ;23170  ;159:
                ;23171  ;=*0*
                ;23172  ;DIAG.WAIT1:
                ;23173  ;
                ;23174  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;23175  ;                               ; COMMAND FROM THE CPU
                ;23176  ;-------------------------------------------------------------------
                ;23177  ;15B:
                ;23178  ;=*1*
                ;23179  ;DIAG.WAIT2:
                ;23180  ;
                ;23181  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;23182  ;                               ; WAIT SOME MORE
                ;23183  ;-------------------------------------------------------------------
                ;23184  WAIT.IDC.T29.2:
U 14A8, DB00,1A ;23185          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 14A9, 094A,B4 ;23186          JMP [IDC.DONE.T29.2]                    ;XFER REQ SET
U 14AA, 094A,84 ;23187          JMP [WAIT.IDC.T29.2]                    ;WAIT SOME MORE
                ;23188
                ;23189  IDC.DONE.T29.2:
U 14AB, B700,15 ;23190          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 14AC, 17A0,15 ;23191          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 14AD, 90FA,15 ;23192          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;23193
                ;23194  READ.PATTERN.T29.2:
U 14AE, 9090,15 ;23195          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 14AF, 1790,15 ;23196          PORT.READ PORT.ADRS[PATTERN]            ;READ THE PATTERN INFO
U 14B0, 3B32,15 ;23197          MOV PORT TO LS[PORT0]                   ;AND SAVE IT IS LS
U 14B1, 3732,15 ;23198          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 14B2, 2F82,95 ;23199          CLR WR[1]                               ;SET UP EXPECTED DATA
U 14B3, 0869,3C ;23200          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 14B4, 8948,74 ;23201          JMP [LOOP.T29.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;23202
U 14B5, FF82,15 ;23203          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 3
                ;23204          DEC WR[3],                              ;DEC THE COUNTER
U 14B6, A107,B5 ;23205           DT(LONG)&SET.ALU.CC
U 14B7, 0949,E1 ;23206          JMP.IF[NEQ] TO [SHFT.REG.T29]           ;JMP IF LOOP COUNT NOT = 0
                ;23207
U 14B8, 8875,3C ;23208          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                ;23209                                                  ; BY THIS TEST
                ;23210
                ;23211  END.T29:                                        ;END TEST
                ;23212
                ;23213
```

```
;23214  .PAGE  "Test 2A  DC007 PATTERN REGISTER TEST (M8388 IDC MODULE)"
;23215  ;++
;23216  ;
;23217  ; Test Description:
;23218  ;
;23219  ;       This test is designed to insure that the internal shift register
;23220  ;       (pattern register) of the DC007 chip is working correctly.
;23221  ;       This will be accomplished by first clearing the register. A one is then
;23222  ;       shifted from the DSR and into bit 0 of the pattern register. The
;23223  ;       pattern register is then read and checked. The pattern register is then
;23224  ;       shifted one time and read and checked again until it has been shifted
;23225  ;       105 times. The pattern register does not perform a normal shift
;23226  ;       function. When in ECC mode, Bits<23,21,11,2> become the XOR of Feedback
;23227  ;       and the preceding bit. In this test Feedback = Bit 31.
;23228  ;
;23229  ; Assumptions:
;23230  ;
;23231  ;       It is assumed that all previous tests have run successfully.
;23232  ;
;23233  ; Test Steps:
;23234  ;
;23235  ;       1. Set up error mask, error number and module number in LS
;23236  ;          (for error printouts) and clear the previous error number in LS.
;23237  ;       2. Force the IDC microcode to DIAG.IDLE.
;23238  ;       3. Write a one to FIFO A.
;23239  ;       4. Set up the CSR to branch to the correct IDC microcode routine.
;23240  ;
;23241  ;                                       *******
;23242  ;                                       * IDC *
;23243  ;                                       *******
;23244  ;
;23245  ;               IDC1. Execute an instruction with FUNC <35:32> = 0001,
;23246  ;                     UCLR ECC.
;23247  ;               IDC2. Load the data pattern from the FIFO and into the Data
;23248  ;                     Shift Register.
;23249  ;               IDC3. Assert UMAINT to allow DSR0 to become SDIO.(NRZ DATA).
;23250  ;               IDC4. Shift the one into the DC007 internal shift register.
;23251  ;               IDC5. Send XFER REQ to flag the CPU.
;23252  ;
;23253  ;       5. Wait for XFER REQ from the IDC.
;23254  ;       6. Clear CSR F<2:0> and send XFER GRANT.
;23255  ;       7. Check the pattern register.
;23256  ;       8. Increment the error number.
;23257  ;       9. Set up the CSR to branch to the correct IDC routine.
;23258  ;
;23259  ;                                       *******
;23260  ;                                       * IDC *
;23261  ;                                       *******
;23262  ;
;23263  ;               IDC5. Allow the pattern register to clock once.
;23264  ;               IDC6. Send XFER REQ to flag the CPU.
;23265  ;
;23266  ;      10. Wait for XFER REQ from the IDC.
;23267  ;      11. Clear CSR F<2:0> and send XFER GRANT.
;23268  ;      12. Check the pattern register.
```

```
                    ;23269  ;       13. Repeat Steps 8 - 13 105 times.
                    ;23270  ;       14. Clear IDC.
                    ;23271  ;       15. End test.
                    ;23272  ;
                    ;23273  ; Errors:
                    ;23274  ;
                    ;23275  ;                   Printout:
                    ;23276  ;                           EXPECTED                RECEIVED
                    ;23277  ;                       INTERNAL SHIFT REG      INTERNAL SHIFT REG
                    ;23278  ;                         (ECC PATTERN)           (ECC PATTERN)
                    ;23279  ;
                    ;23280  ;       ERROR 1 - CRC/ECC chip internal shift register failed when a one was
                    ;23281  ;                 shifted into the Pattern register.
                    ;23282  ;
                    ;23283  ;       ERROR 2 - CRC/ECC chip internal shift register failed when the data
                    ;23284  ;                 was being shifted through the Pattern register.
                    ;23285  ;
                    ;23286  ; Debug:
                    ;23287  ;
                    ;23288  ; ERROR 1 -
                    ;23289  ;       A data pattern of one is written to FIFO A address 0.
                    ;23290  ;       The IDC microcode will execute adn instruction with F<2:0>=0001 which
                    ;23291  ;       will be decoded and assert UCLR ECC L. This signal will clear the
                    ;23292  ;       CRC/ECC internal Pattern register.
                    ;23293  ;       The data pattern is loaded into the DSR and UMAINT H is asserted which
                    ;23294  ;       allows DSR 0 H to becomes NRZ WRT DATA H. In the next IDC
                    ;23295  ;       micro-instruction, UDATA FIELD H is asserted and UENB CRC H is
                    ;23296  ;       deasserted. UDATA FIELD H = H allows NRZ WRT DATA H to be shifted into
                    ;23297  ;       the CRC/ECC Pattern register and UENB CRC H = L enables some internal
                    ;23298  ;       signals of the CRC/ECC chip. The CPU will then read bits <21:31> of the
                    ;23299  ;       Pattern register on BUS IO <10:0>. The CRC/ECC chip internal Pattern
                    ;23300  ;       register does NOT perform a normal shift function. There is some
                    ;23301  ;       XORing of certain signals. The CPU microcode will calculate the
                    ;23302  ;       expected data.
                    ;23303  ;
                    ;23304  ; ERROR 2 -
                    ;23305  ;       The data in the CRC/ECC chip internal Pattern register will be shifted
                    ;23306  ;       once, and then the CPU microcode will read bits <21:31> of the Pattern
                    ;23307  ;       register on BUS IO <10:0>. This will be done 105 (decimal) times to
                    ;23308  ;       fully test the CRC/ECC internal Pattern register.
                    ;23309  ;       To shift the CRC/ECC chip internal Pattern register, the IDC will
                    ;23310  ;       execute an instruction with UDATA FIELD H = H, UMAINT H = H and
                    ;23311  ;       UENB CRC H = L. UDATA FIELD H = H enables the internal clocks.
                    ;23312  ;       UENB CRC H = L allows certain internal signals. UMAINT H = H
                    ;23313  ;       allows zeros to be shifted in as NRZ WRT DATA H.
                    ;23314  ;
                    ;23315  ;--
                    ;23316  ;*******************************************************************************
                    ;23317  T.2A:
U 14B9, B65E,15     ;23318          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;23319                                                  ; CONTROL AND STATUS WORD
U 14BA, 3E80,15     ;23320          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;23321                                                  ; STATUS WORD - BIT 15
                    ;23322                                                  ; INDICATES START OF TEST TO
                    ;23323                                                  ; CONSOLE
```

```
U 14BB, 10E0,15 ;23324          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;23325  WAIT.T2A.0:
U 14BC, 094B,C4 ;23326          JMP [WAIT.T2A.0]                                ;LOOP HERE WAITING FOR
                ;23327                                                  ; CONSOLE TO RESPOND
                ;23328
U 14BD, 65A0,15 ;23329          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;23330                                                  ; IN LS
                ;23331
U 14BE, B64A,15 ;23332          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 14BF, 3E8C,15 ;23333          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;23334
                ;23335
                ;23336
U 14C0, 37AE,15 ;23337          MOV LS[#FFFFF800] TO WR[0]              ;SET UP THE MASK TO CHECK
U 14C1, 3E8A,15 ;23338          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <10:0>
                ;23339
                ;23340
U 14C2, 8872,EC ;23341          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;23342
                ;23343  LOOP.T2A.2:
U 14C3, 37A3,95 ;23344          MOV LS[#A0100500] TO WR[3]              ;EXPECTED DATA
U 14C4, 17D8,15 ;23345          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 14C5, 17C0,15 ;23346          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A  ADRS = 0
U 14C6, B640,15 ;23347          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE
U 14C7, 97A8,15 ;23348          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A ONE TO FIFO A
                ;23349  LOOP.T2A.1:
U 14C8, B640,15 ;23350          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 14C9, BE82,15 ;23351          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;23352
U 14CA, 17C0,15 ;23353          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO ADRS =0
U 14CB, 3712,95 ;23354          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 14CC, 370E,15 ;23355          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 14CD, AEC2,15 ;23356          BIS WR[1] TO WR[0]
U 14CE, 17A0,15 ;23357          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23358                                                  ;MAINT=0,CRDY=1,F<2:0>=111
                ;23359  ;CONTINUE BRANCHING
                ;23360
U 14CF, 379E,15 ;23361          MOV LS[SETCSR.R80] TO WR[0]             ;CONTINUE TO BRANCH TO ROUTINE
U 14D0, 3700,95 ;23362          MOV LS[SETCSR.F0] TO WR[1]
U 14D1, 3713,15 ;23363          MOV LS[SETCSR.CRDY] TO WR[2]            ;SET CRDY TO HOLD SDIO LOW
U 14D2, AEC4,15 ;23364          BIS WR[2] TO WR[0]
U 14D3, AEC2,15 ;23365          BIS WR[1] TO WR[0]
U 14D4, 17A0,15 ;23366          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23367                                                  ;R80=1, F<2:0>=000
                ;23368  ;-------------------------------------------------------------------------------
                ;23369  ;-------------------------------------------------------------------------------
                ;23370  ;                               *******
                ;23371  ;                               * IDC *
                ;23372  ;                               *******
                ;23373  ;-------------------------------------------------------------------------------
                ;23374  ;018:
                ;23375  ;=000
                ;23376  ;DIAG.IDLE:
                ;23377  ;
                ;23378  ;       BEN0/F0,
```

```
;23379  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;23380  ;       BEN2/F2,
;23381  ;       NAD/DIAG.IDLE
;23382  ;-------------------------------------------------------------------------
;23383  ;01F:
;23384  ;=111
;23385  ;
;23386  ;       BEN0/CRDY.L,
;23387  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;23388  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;23389  ;-------------------------------------------------------------------------
;23390  ;078:
;23391  ;=0*0
;23392  ;TEST.FUNC7:
;23393  ;
;23394  ;       NAD/GROUP0
;23395  ;-------------------------------------------------------------------------
;23396  ;163:
;23397  ;=0**
;23398  ;GROUP0:
;23399  ;
;23400  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;23401  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
;23402  ;                                       ; FUNCTION BITS
;23403  ;-------------------------------------------------------------------------
;23404  ;167:
;23405  ;=1**
;23406  ;
;23407  ;       BEN0/F0,
;23408  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;23409  ;       BEN2/F2,
;23410  ;       NAD/GROUP0.F0
;23411  ;-------------------------------------------------------------------------
;23412  ;020:
;23413  ;=000
;23414  ;GROUP0.F0:
;23415  ;
;23416  ;PAT.REG.1:
;23417  ;
;23418  ;       FUNC/CLR.ECC,           ;CLR ECC TO ZERO THE PATTERN REGISTER
;23419  ;       NAD/PAT.REG.2
;23420  ;-------------------------------------------------------------------------
;23421  ;1E6:
;23422  ;PAT.REG.2:
;23423  ;
;23424  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A
;23425  ;       NAD/PAT.REG.3
;23426  ;-------------------------------------------------------------------------
;23427  ;1E7:
;23428  ;PAT.REG.3:
;23429  ;
;23430  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;23431  ;       LOAD.DSR/ON,
;23432  ;       UMAINT/ON,                      ;ASSERT MAINT SO DSR0 BECOMES NRZ DATA
;23433  ;       NAD/PAT.REG.4
```

```
                ;23434  ;-------------------------------------------------------------------------
                ;23435  ;1E8:
                ;23436  ;PAT.REG.4:
                ;23437  ;
                ;23438  ;       DATA.FIELD/ON,                  ;ALLOW READ CLK
                ;23439  ;       MODE/ECC,                       ;ECC MODE TO SHIFT BIT 31
                ;23440  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;23441  ;-------------------------------------------------------------------------
                ;23442  ;1D8:
                ;23443  ;XFER.REQ:
                ;23444  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;23445  ;       NAD/DIAG.WAIT
                ;23446  ;-------------------------------------------------------------------------
                ;23447  ;1D7:
                ;23448  ;DIAG.WAIT:
                ;23449  ;
                ;23450  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;23451  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;23452  ;-------------------------------------------------------------------------
                ;23453  ;159:
                ;23454  ;=*0*
                ;23455  ;DIAG.WAIT1:
                ;23456  ;
                ;23457  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;23458  ;                               ; COMMAND FROM THE CPU
                ;23459  ;-------------------------------------------------------------------------
                ;23460  ;15B:
                ;23461  ;=*1*
                ;23462  ;DIAG.WAIT2:
                ;23463  ;
                ;23464  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;23465  ;                               ; WAIT SOME MORE
                ;23466  ;-------------------------------------------------------------------------
                ;23467  WAIT.IDC.T2A.1:
U 14D5, DB00,1A ;23468          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 14D6, 894D,84 ;23469          JMP [IDC.DONE.T2A.1]                    ;XFER REQ SET
U 14D7, 094D,54 ;23470          JMP [WAIT.IDC.T2A.1]                    ;WAIT SOME MORE
                ;23471
                ;23472  IDC.DONE.T2A.1:
U 14D8, B700,15 ;23473          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 14D9, 17A0,15 ;23474          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 14DA, 90FA,15 ;23475          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;23476
                ;23477  READ.PAT.T2A.1:
U 14DB, 9090,15 ;23478          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 14DC, 1790,15 ;23479          PORT.READ PORT.ADRS[PATTERN]            ;SET UP TO READ PATTERN REG
U 14DD, 3B32,15 ;23480          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM PAT AND
                ;23481                                                  ; SAVE IT IN  LS
U 14DE, 3732,15 ;23482          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 14DF, 2006,95 ;23483          MOV WR[3] TO WR[1]                      ;SET UP EXPECTED DATA
U 14E0, 0869,3C ;23484          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 14E1, 094C,84 ;23485          JMP [LOOP.T2A.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;23486
U 14E2, FF82,15 ;23487          INC LS[ERROR.NUMBER]                    ;ERROR 2
U 14E3, B7A9,15 ;23488          MOV LS[#69] TO WR[2]                    ;USE AS A LOOP COUNTER=105
```

```
                ;23489
                ;23490  CHK.PAT.REG.T2A:
                ;23491
                ;23492  ;SET UP THE NEW EXPECTED DATA
U 14E4, 2341,95 ;23493          ROR WR[3]                       ;ROTATE THE 32 BITS OF DATA
                ;23494          BIT LS[BIT31] WITH WR[3],       ;IS BIT 31 SET?
U 14E5, D97F,B5 ;23495           DT(LONG)&SET.ALU.CC
U 14E6, 894E,99 ;23496          JMP.IF[BITS.CLR] TO [NO.XOR.T2A.1]  ;JMP IF BIT31 = 0 WR[3] HAS
                ;23497                                          ; EXPECTED DATA
U 14E7, B7A0,15 ;23498          MOV LS[#20100500] TO WR[0]      ;GET THE MASK
U 14E8, 2F81,95 ;23499          XOR WR[0] TO WR[3]              ;GET THE NEW EXPECTED DATA
                ;23500
                ;23501  NO.XOR.T2A.1:
U 14E9, 3712,95 ;23502          MOV LS[SETCSR.CRDY] TO WR[1]    ;SET UP THE CSR TO BRANCH TO
U 14EA, 370E,15 ;23503          MOV LS[SETCSR.F7] TO WR[0]      ; THE CORRECT IDC ROUTINE
U 14EB, AEC2,15 ;23504          BIS WR[1] TO WR[0]
U 14EC, 17A0,15 ;23505          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;WRITE THE CSR
                ;23506                                          ;MAINT=0,CRDY=1,F<2:0>=111
                ;23507  ;CONTINUE BRANCHING
U 14ED, 379E,15 ;23508          MOV LS[SETCSR.R80] TO WR[0]     ;CONTINUE TO BRANCH
U 14EE, B708,95 ;23509          MOV LS[SETCSR.F4] TO WR[1]
U 14EF, AEC2,15 ;23510          BIS WR[1] TO WR[0]
U 14F0, 3712,95 ;23511          MOV LS[SETCSR.CRDY] TO WR[1]    ;SET CRDY TO HOLD SDIO =LO
U 14F1, AEC2,15 ;23512          BIS WR[1] TO WR[0]
U 14F2, 17A0,15 ;23513          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]  ;WRITE THE CSR
                ;23514                                          ;R80=1,F<2:0>=100
                ;23515  ;-------------------------------------------------------------------------
                ;23516  ;-------------------------------------------------------------------------
                ;23517  ;                               *******
                ;23518  ;                               * IDC *
                ;23519  ;                               *******
                ;23520  ;-------------------------------------------------------------------------
                ;23521  ;018:
                ;23522  ;=000
                ;23523  ;DIAG.IDLE:
                ;23524  ;
                ;23525  ;       BEN0/F0,
                ;23526  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23527  ;       BEN2/F2,
                ;23528  ;       NAD/DIAG.IDLE
                ;23529  ;-------------------------------------------------------------------------
                ;23530  ;01F:
                ;23531  ;=111
                ;23532  ;
                ;23533  ;       BEN0/CRDY.L,
                ;23534  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;23535  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;23536  ;-------------------------------------------------------------------------
                ;23537  ;078:
                ;23538  ;=0*0
                ;23539  ;TEST.FUNC7:
                ;23540  ;
                ;23541  ;       NAD/GROUP0
                ;23542  ;-------------------------------------------------------------------------
                ;23543  ;163:
```

```
                ;23544  ;=0**
                ;23545  ;GROUP0:
                ;23546  ;
                ;23547  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;23548  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;23549  ;                                       ; FUNCTION BITS
                ;23550  ;-------------------------------------------------------------------------------
                ;23551  ;167:
                ;23552  ;=1**
                ;23553  ;
                ;23554  ;       BEN0/F0,
                ;23555  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23556  ;       BEN2/F2,
                ;23557  ;       NAD/GROUP0.F0
                ;23558  ;-------------------------------------------------------------------------------
                ;23559  ;024:
                ;23560  ;=100
                ;23561  ;SHFT.PAT.REG.1:
                ;23562  ;
                ;23563  ;       MODE/ECC,                       ;SET MODE ECC TO ALLOW BIT 31 TO SHIFT
                ;23564  ;       DATA.FIELD/ON,                  ;ALLOW READ CLK
                ;23565  ;       UMAINT/ON,                      ;TO SELECT DSR0 AS NRZ DATA
                ;23566  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;23567  ;-------------------------------------------------------------------------------
                ;23568  ;1D8:
                ;23569  ;XFER.REQ:
                ;23570  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;23571  ;       NAD/DIAG.WAIT
                ;23572  ;-------------------------------------------------------------------------------
                ;23573  ;1D7:
                ;23574  ;DIAG.WAIT:
                ;23575  ;
                ;23576  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;23577  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;23578  ;-------------------------------------------------------------------------------
                ;23579  ;159:
                ;23580  ;=*0*
                ;23581  ;DIAG.WAIT1:
                ;23582  ;
                ;23583  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;23584  ;                               ; COMMAND FROM THE CPU
                ;23585  ;-------------------------------------------------------------------------------
                ;23586  ;15B:
                ;23587  ;=*1*
                ;23588  ;DIAG.WAIT2:
                ;23589  ;
                ;23590  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;23591  ;                               ; WAIT SOME MORE
                ;23592  ;-------------------------------------------------------------------------------
                ;23593  WAIT.IDC.T2A.2:
U 14F3, DB00,1A ;23594          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 14F4, 894F,64 ;23595          JMP [IDC.DONE.T2A.2]                    ;XFER REQ SET
U 14F5, 894F,34 ;23596          JMP [WAIT.IDC.T2A.2]                    ;WAIT SOME MORE
                ;23597
                ;23598  IDC.DONE.T2A.2:
```

```
U 14F6, B700,15 ;23599          MOV LS[SETCSR.F0] TO WR[0]                ;CLEAR CSR F<2:0>
U 14F7, 17A0,15 ;23600          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
U 14F8, 90FA,15 ;23601          MISC2 [TRANSFER.GRANT]                    ;SEND GRANT TO CLR THE XFER REQ
                ;23602
                ;23603
                ;23604  READ.PAT.T2A.2:
U 14F9, 9090,15 ;23605          MISC [SET.PORT.I.O]                       ;SELECT THE IDC
U 14FA, 1790,15 ;23606          PORT.READ PORT.ADRS[PATTERN]              ;SET UP TO READ PATTERN REG
U 14FB, 3B32,15 ;23607          MOV PORT TO LS[PORT0]                     ;READ THE DATA FROM PAT AND
                ;23608                                                    ; SAVE IT IN  LS
U 14FC, 3732,15 ;23609          MOV LS[PORT0] TO WR[0]                    ;SET UP RECEIVED DATA
U 14FD, 2006,95 ;23610          MOV WR[3] TO WR[1]                        ;SET UP THE EXPECTED DATA
U 14FE, 0869,3C ;23611          JSR [CHECK.RESULT]                        ;CHECK THE DATA
U 14FF, 894C,34 ;23612          JMP [LOOP.T2A.2]                          ;LOOP HERE IF ERR & LOE IS SET
                ;23613          DEC WR[2],                                ;DONE?
U 1500, A105,35 ;23614           DT(LONG)&SET.ALU.CC
U 1501, 894E,41 ;23615          JMP.IF[NEQ] TO [CHK.PAT.REG.T2A]          ;JMP IF NOT DONE
U 1502, 0950,34 ;23616          JMP [CLEANUP.T2A]
                ;23617
                ;23618
                ;23619  CLEANUP.T2A:
U 1503, 8875,3C ;23620          JSR [CLEANUP]                             ;CLEANUP THE CONDITIONS SET BY
                ;23621                                                    ; THIS TEST
                ;23622  END.T2A:                                          ;END TEST
                ;23623
                ;23624
```

```
;23625  .PAGE  "Test 2B  DC007 POSITION REGISTER TEST(M8388 IDC MODULE)"
;23626  ;++
;23627  ;
;23628  ; Test Description:
;23629  ;
;23630  ;       This test is designed to verify that the position register of the
;23631  ;       DC007 chip is working correctly. A UCLR ECC will be executed and the
;23632  ;       position register will be checked for the initial value of 06837 Hex
;23633  ;       (064067 octal). The reigster will then be clocked on tick at a time
;23634  ;       and read to insure that the register incremented. When the limit value
;23635  ;       1021 HEX is reached the register will be clocked one more time and the
;23636  ;       data should remain the same.
;23637  ;
;23638  ; Assumptions:
;23639  ;
;23640  ;       It is assumed that all previous tests have run successfully.
;23641  ;
;23642  ; Test Steps:
;23643  ;
;23644  ;       1. Set up error mask, error number and module number in LS
;23645  ;          (for error printouts) and clear the previous error number in LS.
;23646  ;       2. Force the IDC microcode to DIAG.IDLE.
;23647  ;       3. Set up the CSR to branch to the correct IDC microcode routine.
;23648  ;
;23649  ;                                       *******
;23650  ;                                       * IDC *
;23651  ;                                       *******
;23652  ;
;23653  ;               IDC1. Execute an instruction with FUNC <35:32> = 0001,
;23654  ;                     UCLR ECC.
;23655  ;
;23656  ;       4. Wait for a XFER REQ from the IDC.
;23657  ;       5. Clear CSR F<2:0> and send XFER GRANT.
;23658  ;       6. READ POSITION and check for lower 13 bits of 06837 Hex
;23659  ;            (064067 octal).
;23660  ;       7. Set up the CSR to branch to the correct IDC routine.
;23661  ;
;23662  ;                                       *******
;23663  ;                                       * IDC *
;23664  ;                                       *******
;23665  ;
;23666  ;               IDC2. Assert Error to allow the position register to clock.
;23667  ;               IDC3. Clock the position register.
;23668  ;               IDC4. Send XFER REQ to flag the CPU.
;23669  ;
;23670  ;       8. Wait for an XFER REQ from the IDC.
;23671  ;       9. Clear CSR F<:2:0> and send XFER GRANT.
;23672  ;      10. Check the Position Register data.
;23673  ;      11. Set up the CSR to branch to the correct IDC routine.
;23674  ;
;23675  ;                                       *******
;23676  ;                                       * IDC *
;23677  ;                                       *******
;23678  ;
;23679  ;
```

```
;23680  ;
;23681  ;               IDC5. Clock the position register.
;23682  ;               IDC6. Send XFER REQ to flag the CPU.
;23683  ;
;23684  ;       12. Wait for an XFER REQ from the IDC.
;23685  ;       13. Clear CSR F<2:0> and send XFER GRANT.
;23686  ;       14. Check the Position Register.
;23687  ;       15. Repeat Steps 11 - 15 until Limit (1021 HEX).
;23688  ;       16. Repeat Steps 11 - 15 and check that the Position Register
;23689  ;           data did not change.
;23690  ;       17. Clear IDC.
;23691  ;       18. End test.
;23692  ;
;23693  ; Errors:
;23694  ;
;23695  ;                   Printout:
;23696  ;                           EXPECTED        RECEIVED
;23697  ;                           ECC POSITION    ECC POSITION
;23698  ;
;23699  ;       ERROR 1 - The CRC/ECC chip internal position register failed or
;23700  ;                 the READ POSITION instruction failed.
;23701  ;
;23702  ;       ERROR 2 - The CRC/ECC chip internal Position register failed.
;23703  ;
;23704  ;       ERROR 3 - The CRC/ECC chip internal Position register failed when
;23705  ;                 LIMIT was reached.
;23706  ;
;23707  ;       ERROR 4 - CSR ECC STAT<1:0> failed or CRC/ECC failed.
;23708  ;
;23709  ;
;23710  ; Debug:
;23711  ;
;23712  ; ERROR 1 -
;23713  ;       The IDC microcode will execute an instrcution with FUNC <3:0>=0001.
;23714  ;       These bits will be decoded and will assert UCLR ECC L. This signal
;23715  ;       is the Clear line to the CRC/ECC chip and will initialize the CRC/ECC
;23716  ;       chip internal Position register to 6837 HEX. Only bits <12:0> can be
;23717  ;       read by the CPU.
;23718  ;       The CPU will issue a MISC [SET.PORT.I.O] instruction that will
;23719  ;       deassert SEL ACC IN H. This is inverted to SEL ACC L = H.
;23720  ;       The CPU will then issue a PORT.READ PORT.ADRS[POSITION] instruction.
;23721  ;       The inputs to the PORT INTERFACE REG PAL will be:
;23722  ;               CSR 17 H = H
;23723  ;               CSR 14 H = L
;23724  ;               CSR 12 H = H
;23725  ;               CSR 11 H = L
;23726  ;               CSR 10 H = H
;23727  ;               PORT INSTR H = H
;23728  ;               CPU P2 H = H
;23729  ;       At CPU CLOCK H, the outputs will be:
;23730  ;               SEL IDC H = H
;23731  ;               R2 L = L
;23732  ;               R1 L = H
;23733  ;               R0 L = L
;23734  ;       The next instruction issued by the CPU will be a MOV PORT TO LS[].
```

```
                ;23735  ;       This will assert READ PORT L. This signal is inverted by the PORT
                ;23736  ;       INTERFACE REG PAL and becomes READ PORT H = H. READ PORT H = H
                ;23737  ;       is gated with SEL IDC H = H and SEL ACC L = H and will assert READ
                ;23738  ;       IDC L.  READ IDC L = L and READ PORT H = H are the enables for the
                ;23739  ;       decoder of R2 L = L, R1 L = H, R0 L = L. This combination of inputs
                ;23740  ;       will assert SEL POSITION L. SEL POSITION L is an input to the CRC/ECC
                ;23741  ;       chip and will drive the internal Position register bits<12:0> onto
                ;23742  ;       BUS IO <12:0>. This data is then stored in the specified LS location.
                ;23743  ; ERROR 2 -
                ;23744  ;       The IDC microcode will first assert ERR (internal to the CRC/ECC chip)
                ;23745  ;       to enable the CRC/ECC Position register to increment
                ;23746  ;       (see ECC STAT <1:0> LINES TEST  ERROR 2).
                ;23747  ;       The IDC microcode will then execute an instruction with UDATA FIELD
                ;23748  ;       H = H, UMAINT H = H and UENB CRC H = L. UDATA FIELD H = H will allow
                ;23749  ;       the internal Position register to increment once after ERR is asserted.
                ;23750  ;       UMAINT H = H allows DSR 0 to become NRZ WRT DATA H. CRC H = L allows
                ;23751  ;       certain necessry CRC/ECC chip internal signals. The CPU will then read
                ;23752  ;       the Position register bits<12:0> on BUS IO <12:0>.
                ;23753  ;
                ;23754  ; ERROR 3 -
                ;23755  ;       When the LIMIT value is reached (1021 HEX) the Position register
                ;23756  ;       data should remain unchanged.
                ;23757  ;       The IDC microcode will execute an instruction with UDATA FIELD
                ;23758  ;       H = H, UMAINT H = H and UENB CRC H = L. UDATA FIELD H = H will allow
                ;23759  ;       the internal Position register to increment once after ERR is asserted
                ;23760  ;       only if LIMIT (internal signal to the CRC/ECC chip) has not been
                ;23761  ;       reached. So this time the Position register data should remain
                ;23762  ;       unchanged.
                ;23763  ;
                ;23764  ; ERROR 4 -
                ;23765  ;       When the CRC/ECC chip reaches LIMIT, the ECC STAT <1:0> = 10.
                ;23766  ;       These are CSR <21:20>. The CPU will read and check the CSR.
                ;23767  ;--
                ;23768  ;*******************************************************************************
                ;23769  T.2B:
U 1504, B65E,15 ;23770          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;23771                                                  ; CONTROL AND STATUS WORD
U 1505, 3E80,15 ;23772          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;23773                                                  ; STATUS WORD - BIT 15
                ;23774                                                  ; INDICATES START OF TEST TO
                ;23775                                                  ; CONSOLE
U 1506, 10E0,15 ;23776          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;23777  WAIT.T2B.0:
U 1507, 8950,74 ;23778          JMP [WAIT.T2B.0]                        ;LOOP HERE WAITING FOR
                ;23779                                                  ; CONSOLE TO RESPOND
                ;23780
U 1508, 65A0,15 ;23781          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;23782                                                  ; IN LS
                ;23783
U 1509, B64A,15 ;23784          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 150A, 3E8C,15 ;23785          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;23786
                ;23787
                ;23788
U 150B, B7A6,15 ;23789          MOV LS[#FFFFE000] TO WR[0]              ;SET UP THE ERROR MASK TO
```

```
U 150C, 3E8A,15 ;23790          MOV WR[0] TO LS[ERROR.MASK]              ; CHECK BITS <12:0>
                ;23791
                ;23792
U 150D, 8872,EC ;23793          JSR [DIAG.CODE]                          ;FORCE THE IDC TO DIAG.IDLE
                ;23794
                ;23795  LOOP.T2B.1:
                ;23796  LOOP.T2B.2:
                ;23797  LOOP.T2B.3:
U 150E, B640,15 ;23798          MOV LS[#1] TO WR[0]                      ;SET WR0 = 1
U 150F, BE82,15 ;23799          MOV WR[0] TO LS[ERROR.NUMBER]            ;SET UP ERROR NUMBER = 1 IN LS
                ;23800
U 1510, B7AB,95 ;23801          MOV LS[#6837] TO WR[3]                   ;SAVE THE EXPECTED DATA  WR[3]
U 1511, B712,15 ;23802          MOV LS[SETCSR.CRDY] TO WR[0]             ;SET UP THE CSR TO BRANCH TO
U 1512, B720,95 ;23803          MOV LS[SETCSR.MAINT] TO WR[1]            ; THE CORRECT IDC ROUTINE
U 1513, AEC2,15 ;23804          BIS WR[1] TO WR[0]
U 1514, 370C,95 ;23805          MOV LS[SETCSR.F6] TO WR[1]
U 1515, AEC2,15 ;23806          BIS WR[1] TO WR[0]
U 1516, 17A0,15 ;23807          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;23808                                                   ;MAINT=1,CRDY=1,F<2:0>=110
                ;23809  ;UCLR ECC
                ;23810  ;-------------------------------------------------------------------------
                ;23811  ;-------------------------------------------------------------------------
                ;23812  ;                              *******
                ;23813  ;                              * IDC *
                ;23814  ;                              *******
                ;23815  ;-------------------------------------------------------------------------
                ;23816  ;018:
                ;23817  ;=000
                ;23818  ;DIAG.IDLE:
                ;23819  ;
                ;23820  ;       BEN0/F0,
                ;23821  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;23822  ;       BEN2/F2,
                ;23823  ;       NAD/DIAG.IDLE
                ;23824  ;-------------------------------------------------------------------------
                ;23825  ;01E:
                ;23826  ;=110
                ;23827  ;
                ;23828  ;       BEN0/CRDY.L,
                ;23829  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;23830  ;       NAD/TEST.FUNC6           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;23831  ;-------------------------------------------------------------------------
                ;23832  ;076:
                ;23833  ;=1*0
                ;23834  ;TEST.ECC.1:
                ;23835  ;
                ;23836  ;       FUNC/CLR.ECC,                    ;ISSUE CLR ECC TO INIT THE DC007
                ;23837  ;       NAD/XFER.REQ                     ;FLAG THE CPU
                ;23838  ;-------------------------------------------------------------------------
                ;23839  ;1D8:
                ;23840  ;XFER.REQ:
                ;23841  ;       UCMD/SET.XFER.RQST,              ;SEND XFER REQ TO THE CPU
                ;23842  ;       NAD/DIAG.WAIT
                ;23843  ;-------------------------------------------------------------------------
                ;23844  ;1D7:
```

```
                ;23845  ;DIAG.WAIT:
                ;23846  ;
                ;23847  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;23848  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;23849  ;-------------------------------------------------------------------------
                ;23850  ;159:
                ;23851  ;=*0*
                ;23852  ;DIAG.WAIT1:
                ;23853  ;
                ;23854  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;23855  ;                               ; COMMAND FROM THE CPU
                ;23856  ;-------------------------------------------------------------------------
                ;23857  ;15B:
                ;23858  ;=*1*
                ;23859  ;DIAG.WAIT2:
                ;23860  ;
                ;23861  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;23862  ;                               ; WAIT SOME MORE
                ;23863  ;-------------------------------------------------------------------------
                ;23864  WAIT.IDC.T2B.1:
U 1517, DB00,1A ;23865          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1518, 8951,A4 ;23866          JMP [IDC.DONE.T2B.1]                    ;XFER REQ SET
U 1519, 0951,74 ;23867          JMP [WAIT.IDC.T2B.1]                    ;WAIT SOME MORE
                ;23868
                ;23869  IDC.DONE.T2B.1:
U 151A, B700,15 ;23870          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 151B, 17A0,15 ;23871          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 151C, 90FA,15 ;23872          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;23873
                ;23874  READ.POS.T2B.1:
U 151D, 9090,15 ;23875          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 151E, 9794,15 ;23876          PORT.READ PORT.ADRS[POSITION]           ;SET UP TO READ THE POSITION
U 151F, 3B32,15 ;23877          MOV PORT TO LS[PORT0]                   ;READ THE POSITION AND
                ;23878                                                  ; SAVE IT IN  LS
U 1520, 3732,15 ;23879          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1521, 2006,95 ;23880          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
U 1522, 0869,3C ;23881          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1523, 8950,E4 ;23882          JMP [LOOP.T2B.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;23883
U 1524, 3642,15 ;23884          MOV LS[#2] TO WR[0]
U 1525, BE82,15 ;23885          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 2
                ;23886
U 1526, 2047,95 ;23887          INC WR[3]                               ;INCR THE EXPECTED DATA
                ;23888
U 1527, 17D8,15 ;23889          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1528, 17C0,15 ;23890          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
U 1529, B640,15 ;23891          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE
U 152A, 97A8,15 ;23892          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A ONE TO FIFO A
U 152B, 17C0,15 ;23893          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
                ;23894
U 152C, 3712,95 ;23895          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 152D, 370E,15 ;23896          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 152E, AEC2,15 ;23897          BIS WR[1] TO WR[0]
U 152F, 17A0,15 ;23898          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23899                                                  ;MAINT=0,CRDY=1,F<2:0>=111
```

```
                ;23900
                ;23901  ;CONTINUE BRANCHING
                ;23902
U 1530, B79F,15 ;23903          MOV LS[SETCSR.R80] TO WR[2]             ;CONTINUE TO BRANCH TO THE
U 1531, 3702,15 ;23904          MOV LS[SETCSR.F1] TO WR[0]              ; IDC ROUTINE
U 1532, AEC2,15 ;23905          BIS WR[1] TO WR[0]                      ;SET CRDY TO HOLD SDIO LO
U 1533, AEC4,15 ;23906          BIS WR[2] TO WR[0]
U 1534, 17A0,15 ;23907          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;23908                                                  ;R80=1,F<2:0>=001
                ;23909  ;-------------------------------------------------------------------------------
                ;23910  ;-------------------------------------------------------------------------------
                ;23911  ;                               *******
                ;23912  ;                               * IDC *
                ;23913  ;                               *******
                ;23914  ;-------------------------------------------------------------------------
                ;23915  ;018:
                ;23916  ;=000
                ;23917  ;DIAG.IDLE:
                ;23918  ;
                ;23919  ;       BEN0/F0,
                ;23920  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23921  ;       BEN2/F2,
                ;23922  ;       NAD/DIAG.IDLE
                ;23923  ;-------------------------------------------------------------------------
                ;23924  ;01F:
                ;23925  ;=111
                ;23926  ;
                ;23927  ;       BEN0/CRDY.L,
                ;23928  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;23929  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;23930  ;-------------------------------------------------------------------------
                ;23931  ;078:
                ;23932  ;=0*0
                ;23933  ;TEST.FUNC7:
                ;23934  ;
                ;23935  ;       NAD/GROUP0
                ;23936  ;-------------------------------------------------------------------------
                ;23937  ;163:
                ;23938  ;=0**
                ;23939  ;GROUP0:
                ;23940  ;
                ;23941  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;23942  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;23943  ;                                       ; FUNCTION BITS
                ;23944  ;-------------------------------------------------------------------------
                ;23945  ;167:
                ;23946  ;=1**
                ;23947  ;
                ;23948  ;       BEN0/F0,
                ;23949  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;23950  ;       BEN2/F2,
                ;23951  ;       NAD/GROUP0.F0
                ;23952  ;-------------------------------------------------------------------------
                ;23953  ;021:
                ;23954  ;=001
```

```
;23955  ;POS.REG.1:
;23956  ;
;23957  ;       UCMD/SET.FIFOA,                 ;SEL FIFO A
;23958  ;       NAD/POS.REG.2
;23959  ;-------------------------------------------------------------------------
;23960  ;1E9:
;23961  ;POS.REG.2:
;23962  ;
;23963  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;23964  ;       LOAD.DSR/ON,
;23965  ;       NAD/POS.REG.3
;23966  ;-------------------------------------------------------------------------
;23967  ;1EA:
;23968  ;POS.REG.3:
;23969  ;
;23970  ;       UMAINT/ON,                      ;ENABLE DSR0 AS NRZ DATA
;23971  ;       CHECK.FIELD/ON,                 ;MAKE DC007 BELIEVE IT HAS READ THE
;23972  ;       MODE/CRC,                       ; CHECK FIELD
;23973  ;       NAD/POS.REG.4
;23974  ;-------------------------------------------------------------------------
;23975  ;1EB:
;23976  ;POS.REG.4:
;23977  ;
;23978  ;       MODE/CRC,                       ;DROP CHECK FIELD WHILE THE INTERNAL
;23979  ;                                       ; DC007 SHIFT REG IS NON-ZERO TO
;23980  ;                                       ; ASSERT ERROR INTERNAL TO THE DC007
;23981  ;                                       ;ERROR ALLOWS THE POS REG TO INCR
;23982  ;       DATA.FIELD/ON,                  ;ASSERT DATA FIELD TO ALLOW CLK
;23983  ;       UMAINT/ON,                      ;TO SELECT DSR0 AS NRZ DATA
;23984  ;       NAD/POS.REG.5
;23985  ;-------------------------------------------------------------------------
;23986  ;1EC:
;23987  ;POS.REG.5:
;23988  ;
;23989  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
;23990  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
;23991  ;       UMAINT/ON,                      ;TO SEL DSR0 AS NRZ DATA
;23992  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;23993  ;-------------------------------------------------------------------------
;23994  ;1D8:
;23995  ;XFER.REQ:
;23996  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;23997  ;       NAD/DIAG.WAIT
;23998  ;-------------------------------------------------------------------------
;23999  ;1D7:
;24000  ;DIAG.WAIT:
;24001  ;
;24002  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;24003  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;24004  ;-------------------------------------------------------------------------
;24005  ;159:
;24006  ;=*0*
;24007  ;DIAG.WAIT1:
;24008  ;
;24009  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
```

```
                ;24010  ;                               ; COMMAND FROM THE CPU
                ;24011  ;-------------------------------------------------------------------------
                ;24012  ;15B:
                ;24013  ;=*1*
                ;24014  ;DIAG.WAIT2:
                ;24015  ;
                ;24016  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;24017  ;                               ; WAIT SOME MORE
                ;24018  ;-------------------------------------------------------------------------
                ;24019  WAIT.IDC.T2B.2:
U 1535, DB00,1A ;24020          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1536, 8953,84 ;24021          JMP [IDC.DONE.T2B.2]                    ;XFER REQ SET
U 1537, 0953,54 ;24022          JMP [WAIT.IDC.T2B.2]                    ;WAIT SOME MORE
                ;24023
                ;24024  IDC.DONE.T2B.2:
U 1538, B700,15 ;24025          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1539, 17A0,15 ;24026          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 153A, 90FA,15 ;24027          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;24028
                ;24029
                ;24030  READ.POS.T2B.2:
U 153B, 9090,15 ;24031          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 153C, 9794,15 ;24032          PORT.READ PORT.ADRS[POSITION]           ;SET UP TO READ THE POSITION
U 153D, 3B32,15 ;24033          MOV PORT TO LS[PORT0]                   ;READ THE POSITION AND
                ;24034                                                  ; SAVE IT IN  LS
U 153E, 3732,15 ;24035          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 153F, 2006,95 ;24036          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
U 1540, 0869,3C ;24037          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1541, 8950,E4 ;24038          JMP [LOOP.T2B.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;24039
                ;24040  TEST.POSREG.T2B:
                ;24041
                ;24042  ;A ONE IN WR[2] INDICATES THAT THE LIMIT HAS NOT BEEN REACHED
                ;24043
U 1542, 2F85,15 ;24044          CLR WR[2]                               ;CLR THE LIMIT INDICATOR
                ;24045
U 1543, 37B0,15 ;24046          MOV LS[#1021] TO WR[0]                  ;GET THE LIMIT VALUE
                ;24047          CMP WR[3] WITH WR[0],                   ;LIMIT BEEN REACHED?
U 1544, A646,35 ;24048           DT(LONG)&SET.ALU.CC
U 1545, 8954,89 ;24049          JMP.IF[EQL] TO [CHECK.NXT.T2B]          ;DO NOT INCR EXP DATA IF LIMIT
                ;24050
U 1546, 2047,95 ;24051          INC WR[3]                               ;INC THE EXPECTED DATA
U 1547, 3641,15 ;24052          MOV LS[#1] TO WR[2]                     ;LIMIT INDICATOR...1=NOT LIMIT
                ;24053  CHECK.NXT.T2B:
                ;24054          TST WR[2],                              ;LIMIT?
U 1548, 2005,35 ;24055           DT(LONG)&SET.ALU.CC
U 1549, 8954,C1 ;24056          JMP.IF[NEQ] TO [CONT.T2B]               ;NOT LIMIT..STILL ERROR 2
                ;24057
U 154A, B788,15 ;24058          MOV LS[#3] TO WR[0]
U 154B, BE82,15 ;24059          MOV WR[0] TO LS[ERROR.NUMBER]           ;LIMIT...ERROR 3
                ;24060
                ;24061  CONT.T2B:
U 154C, 3712,95 ;24062          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 154D, 370E,15 ;24063          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 154E, AEC2,15 ;24064          BIS WR[1] TO WR[0]
```

```
U 154F, 17A0,15 ;24065          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;24066                                                   ;MAINT=0,CRDY=1,F<2:0>=111
                ;24067
                ;24068  ;CONTINUE BRANCHING
                ;24069
U 1550, 379E,15 ;24070          MOV LS[SETCSR.R80] TO WR[0]              ;CONTINUE TO BRANCH
U 1551, AEC2,15 ;24071          BIS WR[1] TO WR[0]                       ;SET CRDY TO HOLD SDOI LO
U 1552, B704,95 ;24072          MOV LS[SETCSR.F2] TO WR[1]               ;
U 1553, AEC2,15 ;24073          BIS WR[1] TO WR[0]
U 1554, 17A0,15 ;24074          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;24075                                                   ;R80=1,F<2:0>=010
                ;24076  ;-------------------------------------------------------------------------
                ;24077  ;-------------------------------------------------------------------------
                ;24078  ;                              *******
                ;24079  ;                              * IDC *
                ;24080  ;                              *******
                ;24081  ;-------------------------------------------------------------------------
                ;24082  ;018:
                ;24083  ;=000
                ;24084  ;DIAG.IDLE:
                ;24085  ;
                ;24086  ;       BEN0/F0,
                ;24087  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;24088  ;       BEN2/F2,
                ;24089  ;       NAD/DIAG.IDLE
                ;24090  ;-------------------------------------------------------------------------
                ;24091  ;01F:
                ;24092  ;=111
                ;24093  ;
                ;24094  ;       BEN0/CRDY.L,
                ;24095  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;24096  ;       NAD/TEST.FUNC7           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;24097  ;-------------------------------------------------------------------------
                ;24098  ;078:
                ;24099  ;=0*0
                ;24100  ;TEST.FUNC7:
                ;24101  ;
                ;24102  ;       NAD/GROUP0
                ;24103  ;-------------------------------------------------------------------------
                ;24104  ;163:
                ;24105  ;=0**
                ;24106  ;GROUP0:
                ;24107  ;
                ;24108  ;       BEN2/R80.FORMAT.H,               ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;24109  ;       NAD/GROUP0                       ; TO NEXT WORD AND THEN BRANCH ON THE
                ;24110  ;                                        ; FUNCTION BITS
                ;24111  ;-------------------------------------------------------------------------
                ;24112  ;167:
                ;24113  ;=1**
                ;24114  ;
                ;24115  ;       BEN0/F0,
                ;24116  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;24117  ;       BEN2/F2,
                ;24118  ;       NAD/GROUP0.F0
                ;24119  ;-------------------------------------------------------------------------
```

```
                ;24120  ;022:
                ;24121  ;=010
                ;24122  ;CLK.POS.REG.1:
                ;24123  ;
                ;24124  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
                ;24125  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
                ;24126  ;       UMAINT/ON,                      ;TO SEL DSR0 AS NRZ DATA
                ;24127  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;24128  ;-------------------------------------------------------------------------
                ;24129  ;1D8:
                ;24130  ;XFER.REQ:
                ;24131  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;24132  ;       NAD/DIAG.WAIT
                ;24133  ;-------------------------------------------------------------------------
                ;24134  ;1D7:
                ;24135  ;DIAG.WAIT:
                ;24136  ;
                ;24137  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;24138  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;24139  ;-------------------------------------------------------------------------
                ;24140  ;159:
                ;24141  ;=*0*
                ;24142  ;DIAG.WAIT1:
                ;24143  ;
                ;24144  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;24145  ;                               ; COMMAND FROM THE CPU
                ;24146  ;-------------------------------------------------------------------------
                ;24147  ;15B:
                ;24148  ;=*1*
                ;24149  ;DIAG.WAIT2:
                ;24150  ;
                ;24151  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;24152  ;                               ; WAIT SOME MORE
                ;24153  ;-------------------------------------------------------------------------
                ;24154  WAIT.IDC.T2B.3:
U 1555, DB00,1A ;24155          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1556, 8955,84 ;24156          JMP [IDC.DONE.T2B.3]                    ;XFER REQ SET
U 1557, 0955,54 ;24157          JMP [WAIT.IDC.T2B.3]                    ;WAIT SOME MORE
                ;24158
                ;24159  IDC.DONE.T2B.3:
U 1558, B700,15 ;24160          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1559, 17A0,15 ;24161          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 155A, 90FA,15 ;24162          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;24163
                ;24164  READ.POS.T2B.3:
U 155B, 9090,15 ;24165          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 155C, 9794,15 ;24166          PORT.READ PORT.ADRS[POSITION]           ;SET UP TO READ THE POSITION
U 155D, 3B32,15 ;24167          MOV PORT TO LS[PORT0]                   ;READ THE POSITION AND
                ;24168                                                  ; SAVE IT IN  LS
U 155E, 3732,15 ;24169          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 155F, 2006,95 ;24170          MOV WR[3] TO WR[1]                      ;SET UP THE EXPECTED DATA
U 1560, 0869,3C ;24171          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1561, 8950,E4 ;24172          JMP [LOOP.T2B.3]                        ;LOOP HERE IF ERR & LOE IS SET
                ;24173
                ;24174          TST WR[2],                              ;LIMIT?
```

```
U 1562, 2005,35 ;24175          DT(LONG)&SET.ALU.CC
U 1563, 8957,19 ;24176          JMP.IF[EQL] TO [TEST.STAT.T2B]          ;JMP IF LIMIT
                ;24177
                ;24178          CMP LS[#FFFF] WITH  WR[3],              ;TIME TO RESET EXPECTED DATA?
U 1564, CE29,B5 ;24179          DT(LONG)&SET.ALU.CC
U 1565, 0954,21 ;24180          JMP.IF[NEQ] TO [TEST.POSREG.T2B]        ;JMP IF NOT TIME TO RESET
U 1566, 2F87,95 ;24181          CLR WR[3]                               ;RESET THE EXPECTED DATA
U 1567, 3712,95 ;24182          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 1568, 370E,15 ;24183          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 1569, AEC2,15 ;24184          BIS WR[1] TO WR[0]
U 156A, 17A0,15 ;24185          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24186                                                  ;MAINT=0,CRDY=1,F<2:0>=111
                ;24187
                ;24188  ;CONTINUE BRANCHING
                ;24189
U 156B, 379E,15 ;24190          MOV LS[SETCSR.R80] TO WR[0]             ;CONTINUE TO BRANCH
U 156C, AEC2,15 ;24191          BIS WR[1] TO WR[0]                      ;SET CRDY TO HOLD SDIO LO
U 156D, 370A,95 ;24192          MOV LS[SETCSR.F5] TO WR[1]
U 156E, AEC2,15 ;24193          BIS WR[1] TO WR[0]
U 156F, 17A0,15 ;24194          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24195                                                  ;R80=1,F<2:0>=101
                ;24196  ;-------------------------------------------------------------------------
                ;24197  ;-------------------------------------------------------------------------
                ;24198  ;                               *******
                ;24199  ;                               * IDC *
                ;24200  ;                               *******
                ;24201  ;-------------------------------------------------------------------------
                ;24202  ;018:
                ;24203  ;=000
                ;24204  ;DIAG.IDLE:
                ;24205  ;
                ;24206  ;       BEN0/F0,
                ;24207  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;24208  ;       BEN2/F2,
                ;24209  ;       NAD/DIAG.IDLE
                ;24210  ;-------------------------------------------------------------------------
                ;24211  ;01F:
                ;24212  ;=111
                ;24213  ;
                ;24214  ;       BEN0/CRDY.L,
                ;24215  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;24216  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;24217  ;-------------------------------------------------------------------------
                ;24218  ;078:
                ;24219  ;=0*0
                ;24220  ;TEST.FUNC7:
                ;24221  ;
                ;24222  ;       NAD/GROUP0
                ;24223  ;-------------------------------------------------------------------------
                ;24224  ;163:
                ;24225  ;=0**
                ;24226  ;GROUP0:
                ;24227  ;
                ;24228  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;24229  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
```

```
;24230  ;                                       ; FUNCTION BITS
;24231  ;-------------------------------------------------------------------------
;24232  ;167:
;24233  ;=1**
;24234  ;
;24235  ;       BEN0/F0,
;24236  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;24237  ;       BEN2/F2,
;24238  ;       NAD/GROUP0.F0
;24239  ;-------------------------------------------------------------------------
;24240  ;025:
;24241  ;=101
;24242  ;SHFT.CLK.POS.1:
;24243  ;
;24244  ;       UCMD/SET.FIFOA,                 ;SEL FIFO A
;24245  ;       NAD/SHFT.CLK.POS.2
;24246  ;-------------------------------------------------------------------------
;24247  ;1ED:
;24248  ;SHFT.CLK.POS.2:
;24249  ;
;24250  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;24251  ;       LOAD.DSR/ON,
;24252  ;       NAD/SHFT.CLK.POS.3
;24253  ;-------------------------------------------------------------------------
;24254  ;1EE:
;24255  ;SHFT.CLK.POS.3:
;24256  ;
;24257  ;       UMAINT/ON,                      ;ENABLE DSR0 AS NRZ DATA
;24258  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
;24259  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
;24260  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;24261  ;-------------------------------------------------------------------------
;24262  ;1D8:
;24263  ;XFER.REQ:
;24264  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;24265  ;       NAD/DIAG.WAIT
;24266  ;-------------------------------------------------------------------------
;24267  ;1D7:
;24268  ;DIAG.WAIT:
;24269  ;
;24270  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;24271  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;24272  ;-------------------------------------------------------------------------
;24273  ;159:
;24274  ;=*0*
;24275  ;DIAG.WAIT1:
;24276  ;
;24277  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;24278  ;                               ; COMMAND FROM THE CPU
;24279  ;-------------------------------------------------------------------------
;24280  ;15B:
;24281  ;=*1*
;24282  ;DIAG.WAIT2:
;24283  ;
;24284  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
```

```
                ;24285  ;                                   ; WAIT SOME MORE
                ;24286  ;-------------------------------------------------------------------------
                ;24287
U 1570, 0955,54 ;24288          JMP [WAIT.IDC.T2B.3]                    ;JMP TO CHECK POS REG
                ;24289
                ;24290
                ;24291  TEST.STAT.T2B:
                ;24292  ;CHECK THAT THE ECC STAT<1:0>=10
                ;24293
U 1571, 3644,15 ;24294          MOV LS[#4] TO WR[0]
U 1572  BE82,15 ;24295          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 4
U 1573, 37A4,15 ;24296          MOV LS[#FFCFFFFF] TO WR[0]              ;GET THE MASK TO CHECK
U 1574, 3E8A,15 ;24297          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <21:20>
                ;24298  LOOP.T2B.4:
                ;24299  READ.CSR.T2B:
U 1575, 9090,15 ;24300          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1576, 9780,15 ;24301          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1577, 3B32,15 ;24302          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;24303                                                  ; SAVE IT IN  LS
U 1578, 3732,15 ;24304          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1579, B66A,95 ;24305          MOV LS[BIT21] TO WR[1]                  ;SET UP EXPECTED DATA
U 157A, 0869,3C ;24306          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 157B, 8957,54 ;24307          JMP [LOOP.T2B.4]                        ;LOOP HERE IF ERR & LOE IS SET
                ;24308
U 157C, 8875,3C ;24309          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;24310                                                  ; THIS TEST
                ;24311  END.T2B:                                        ;END TEST
                ;24312
                ;24313
```

```
;24314  .PAGE  "Test 2C  DC007 WRITE CLK AND CRC MODE TEST (M8388 IDC MODULE)"
;24315  ;++
;24316  ;
;24317  ; Test Description:
;24318  ;
;24319  ;       This test is designed to test that the write clk of the DC007 operates
;24320  ;       correctly and also that the internal DC007 pattern register shifts
;24321  ;       correctly when in CRC mode. This will be accomplished by first
;24322  ;       writing a one into the pattern register. The write clk and CRC mode
;24323  ;       will then be selected and the register will be shifted once. The CPU
;24324  ;       will then check the contents of the pattern register. This will be done
;24325  ;       31 times to assure that the register is operational.
;24326  ;       Only bits <12:00> of the pattern register can be read by the CPU.
;24327  ;
;24328  ; Assumptions:
;24329  ;
;24330  ;       It is assumed that all previous tests have been run successfully.
;24331  ;
;24332  ; Test Steps:
;24333  ;
;24334  ;       1. Set up error mask, error number,and module number in LS
;24335  ;          (for error printouts) and clear previous error number in LS.
;24336  ;       2. Force the IDC microcode to DIAG.IDLE.
;24337  ;       3. Select an RL02 disk or a line with no drive attached to assert
;24338  ;          RL02 H which will select the 4.1 MHZ clk as SYS CLK.
;24339  ;       4. Write a one to FIFO A address 0.
;24340  ;       5. Set up the CSR to branch to the correct IDC routine.
;24341  ;
;24342  ;                                       *******
;24343  ;                                       * IDC *
;24344  ;                                       *******
;24345  ;
;24346  ;               IDC1. Issue a UCLR ECC to zero the pattern register.
;24347  ;               IDC2. Shift a one into the pattern register.
;24348  ;               IDC3. Send XFER REQ to flag the CPU.
;24349  ;
;24350  ;       6. Wait for a XFER REQ from IDC.
;24351  ;       7. Clear CSR F<2:0> and send XFER GRANT.
;24352  ;       8. Check the data in the pattern register.
;24353  ;       9. Set up the CSR to branch to the correct IDC routine.
;24354  ;
;24355  ;                                       *******
;24356  ;                                       * IDC *
;24357  ;                                       *******
;24358  ;
;24359  ;               IDC4. Select SYS CLK.
;24360  ;               IDC5. Assert DATA FIELD and UDISK WRITE to select the WRT
;24361  ;                     CLK and allow the pattern reg to shift once.
;24362  ;               IDC6. Select CPU CLK.
;24363  ;               IDC7. Send XFER REQ to flag the CPU.
;24364  ;
;24365  ;      10. Wait for a XFER REQ from IDC.
;24366  ;      11. Clear CSR F<2:0> and send XFER GRANT.
;24367  ;
;24368  ;
```

```
;24369  ;       12. Read PATTERN and check the data
;24370  ;       13. Repeat Steps 9 - 13   31 times.
;24371  ;       14. Clear IDC.
;24372  ;       15. End test.
;24373  ;
;24374  ; Errors:
;24375  ;                       Printout:
;24376  ;                                EXPECTED                    RECEIVED
;24377  ;                           INTERNAL SHIFT REG          INTERNAL SHIFT REG
;24378  ;                             (ECC PATTERN)               (ECC PATTERN)
;24379  ;
;24380  ;       ERROR 1 - The CRC/ECC chip internal Pattern register failed in CRC
;24381  ;                 mode.
;24382  ;
;24383  ;       ERROR 2 - Either the SYS CLK select logic failed, or the SYS CLK
;24384  ;                 failed, or the CRC/ECC internal Pattern reigster failed
;24385  ;                 when using the WRT CLK in CRC mode.
;24386  ;
;24387  ;
;24388  ; Debug:
;24389  ;
;24390  ; ERROR 1 -
;24391  ;       The IDC microcode will execute an instrcution with FUNC <3:0>=0001.
;24392  ;       These bits will be decoded and will assert UCLR ECC L. This signal
;24393  ;       is the Clear line to the CRC/ECC chip and will clear the CRC/ECC
;24394  ;       chip internal Pattern register.
;24395  ;       The data pattern = 1 is loaded into the DSR. The next IDC micro-
;24396  ;       instruction will assert UMAINT H, UDATA FIELD H and UENB CRC H.
;24397  ;       UMAINT H will allow DSR 0 to become NRZ WRT DATA H which is enabled
;24398  ;       to shift into the Pattern register by UDATA FIELD H = H. UENB CRC H = H
;24399  ;       allows only bits <15:0> of the Pattern register to be used and a
;24400  ;       different XORing scheme is used than when in ECC mode. The CPU will
;24401  ;       then read the Pattern register bits <21:31>. Although these bits are
;24402  ;       not used in CRC mode, this allows certain internal conditions to be
;24403  ;       tested.
;24404  ;
;24405  ; ERROR 2 -
;24406  ;       The IDC will execute an instruction to select the System clock.
;24407  ;               USEL SYS H = H
;24408  ;               UCHANGE CLKSRC H = H
;24409  ;       UCHANGE CLKSRC H = H is gated with END SYNC CLR L = H and clears the
;24410  ;       CLOCK SYNC FF.
;24411  ;       When CURRENT CLK L, UCHANGE CLKSRC H is latch through a FF and asserts
;24412  ;       END SYNC CLR H and END SYNC CLR L.
;24413  ;       END SYNC CLR H = H is gated with CURRENT CLK H and will clock the
;24414  ;       Clock sequencer FF, thus latching up  USEL SYS CLK H as
;24415  ;       SEL SYS CLK H = H. When SEL SYS CLK H = H, SYS CLK H becomes CURRENT
;24416  ;       CLK H and is inverted to become CURRENT CLK L.
;24417  ;       Simultaneuosly, CURRENT CLK H is clocking the CLOCK SYNC FF. On the
;24418  ;       third CURRENT CLK H, SYNC FF 2 H is asserted. This is inverted to
;24419  ;       SYNC FF 2 L. SYNC FF 2 L is latch by CURRENT CLK L as ENB SEQ CLK L=L
;24420  ;       and ENB SEQ CLK H = H. SEL SYS CLK H = H is gated with ENB SEQ CLK H=H
;24421  ;       and allows SYS CLK H to become SEQ CLK H.
;24422  ;       RL02 H = H is the SEL line to a MUX which will allow 4.1 MHZ CLK L
;24423  ;       to become SYS CLK H. 8.2 MHZ CLK H is divided by the PEAK SHFT COMP
```

```
                ;24424  ;       PAL and generates 4.1 MHZ CLK L.
                ;24425  ;
                ;24426  ;       The next IDC micro-instruction will assert UDISK WRITE L, UMAINT H,
                ;24427  ;       UDATA FIELD H and UENB CRC H. Internal to the CRC/ECC chip,
                ;24428  ;       UDISK WRITE L = L  will select SYS CLK L as the internal clock. UDATA
                ;24429  ;       FIELD H = H will enable the internal clock which will shift the
                ;24430  ;       Pattern register once. UMAINT H = H allows DSR 0 to become
                ;24431  ;       NRZ WRT DATA H.
                ;24432  ;       UENB CRC H = H enables certain internal signals.
                ;24433  ;       The CPU CLK is then enabled.
                ;24434  ;       The CPU will then read the Pattern register.
                ;24435  ;--
                ;24436  ;*****************************************************************************
                ;24437  T.2C:
U 157D, B65E,15 ;24438          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;24439                                                  ; CONTROL AND STATUS WORD
U 157E, 3E80,15 ;24440          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;24441                                                  ; STATUS WORD - BIT 15
                ;24442                                                  ; INDICATES START OF TEST TO
                ;24443                                                  ; CONSOLE
U 157F, 10E0,15 ;24444          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;24445  WAIT.T2C.0:
U 1580, 8958,04 ;24446          JMP [WAIT.T2C.0]                        ;LOOP HERE WAITING FOR
                ;24447                                                  ; CONSOLE TO RESPOND
                ;24448
U 1581, 65A0,15 ;24449          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;24450                                                  ; IN LS
                ;24451
U 1582, B64A,15 ;24452          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1583, 3E8C,15 ;24453          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;24454
                ;24455
                ;24456
U 1584, B7A6,15 ;24457          MOV LS[#FFFFE000] TO WR[0]              ;GET THE ERROR MASK TO CHECK
U 1585, 3E8A,15 ;24458          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <12:00>
                ;24459
                ;24460
U 1586, B78E,15 ;24461          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;24462          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 1587, D94E,35 ;24463           DT(LONG)&SET.ALU.CC
U 1588, 8958,A1 ;24464          JMP.IF[BIT.SET] TO [SIZE.OK.T2C.1]      ;IF YES THEN GO RUN TEST
                ;24465
U 1589, 8870,0C ;24466          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;24467
                ;24468  SIZE.OK.T2C.1:
U 158A, 8872,EC ;24469          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;24470
                ;24471          ;SELECT AN RL02 DRIVE
                ;24472
U 158B, B78E,15 ;24473          MOV LS[DRIVE.STATUS] TO WR[0]
                ;24474          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 158C, 5940,35 ;24475           DT(LONG)&SET.ALU.CC
U 158D, 8959,09 ;24476          JMP.IF[BITS.CLR] TO [SET.DS0.T2C.1]     ;JMP IF DRV 0 IS NOT AN R80
U 158E, B717,15 ;24477          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
                ;24478                                                  ; IN WR[2]
```

```
U 158F, 8959,14 ;24479          JMP [TEST.T2C.1]
                ;24480  SET.DS0.T2C.1:
U 1590, 3715,15 ;24481          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;24482                                                  ; IN WR[2]
                ;24483  TEST.T2C.1:
                ;24484  LOOP.T2C.2:
                ;24485
U 1591, B7B3,95 ;24486          MOV LS[#A0010500] TO WR[3]              ;EXPECTED DATA
U 1592, 17D8,15 ;24487          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1593, 17C0,15 ;24488          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A  ADRS = 0
U 1594, B640,15 ;24489          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE
U 1595, 97A8,15 ;24490          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A ONE TO FIFO A
U 1596, 17C0,15 ;24491          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A  ADRS = 0
                ;24492
                ;24493  LOOP.T2C.1:
U 1597, B640,15 ;24494          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1598, BE82,15 ;24495          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;24496
U 1599, B712,15 ;24497          MOV LS[SETCSR.CRDY] TO WR[0]            ;SET UP THE CSR TO BRANCH TO
U 159A, B720,95 ;24498          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE CORRECT IDC ROUTINE
U 159B, AEC2,15 ;24499          BIS WR[1] TO WR[0]
U 159C, 370C,95 ;24500          MOV LS[SETCSR.F6] TO WR[1]
U 159D, AEC2,15 ;24501          BIS WR[1] TO WR[0]
U 159E, 17A0,15 ;24502          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24503                                                  ;MAINT=1,CRDY=1,F<2:0>=110
                ;24504  ;UCLR ECC
                ;24505  ;-------------------------------------------------------------------------
                ;24506  ;-------------------------------------------------------------------------
                ;24507  ;                               *******
                ;24508  ;                               * IDC *
                ;24509  ;                               *******
                ;24510  ;-------------------------------------------------------------------------
                ;24511  ;018:
                ;24512  ;=000
                ;24513  ;DIAG.IDLE:
                ;24514  ;
                ;24515  ;       BEN0/F0,
                ;24516  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;24517  ;       BEN2/F2,
                ;24518  ;       NAD/DIAG.IDLE
                ;24519  ;-------------------------------------------------------------------------
                ;24520  ;01E:
                ;24521  ;=110
                ;24522  ;
                ;24523  ;       BEN0/CRDY.L,
                ;24524  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;24525  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;24526  ;-------------------------------------------------------------------------
                ;24527  ;076:
                ;24528  ;=1*0
                ;24529  ;TEST.ECC.1:
                ;24530  ;
                ;24531  ;       FUNC/CLR.ECC,                   ;ISSUE CLR ECC TO INIT THE DC007
                ;24532  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;24533  ;-------------------------------------------------------------------------
```

```
                ;24534  ;1D8:
                ;24535  ;XFER.REQ:
                ;24536  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;24537  ;       NAD/DIAG.WAIT
                ;24538  ;-------------------------------------------------------------------------
                ;24539  ;1D7:
                ;24540  ;DIAG.WAIT:
                ;24541  ;
                ;24542  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;24543  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;24544  ;-------------------------------------------------------------------------
                ;24545  ;159:
                ;24546  ;=*0*
                ;24547  ;DIAG.WAIT1:
                ;24548  ;
                ;24549  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;24550  ;                               ; COMMAND FROM THE CPU
                ;24551  ;-------------------------------------------------------------------------
                ;24552  ;15B:
                ;24553  ;=*1*
                ;24554  ;DIAG.WAIT2:
                ;24555  ;
                ;24556  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;24557  ;                               ; WAIT SOME MORE
                ;24558  ;-------------------------------------------------------------------------
                ;24559  WAIT.IDC.T2C.1:
U 159F, DB00,1A ;24560          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 15A0, 895A,24 ;24561          JMP [IDC.DONE.T2C.1]                    ;XFER REQ SET
U 15A1, 0959,F4 ;24562          JMP [WAIT.IDC.T2C.1]                    ;WAIT SOME MORE
                ;24563
                ;24564  IDC.DONE.T2C.1:
U 15A2, B700,15 ;24565          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 15A3, 17A0,15 ;24566          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 15A4, 90FA,15 ;24567          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;24568
U 15A5, 3712,95 ;24569          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 15A6, 370E,15 ;24570          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 15A7, AEC2,15 ;24571          BIS WR[1] TO WR[0]
U 15A8, 17A0,15 ;24572          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24573                                                  ;MAINT=0,CRDY=1,F<2:0>=111
                ;24574  ;CONTINUE BRANCHING
                ;24575
U 15A9, 379E,15 ;24576          MOV LS[SETCSR.R80] TO WR[0]             ;CONTINUE TO BRANCH TO ROUTINE
U 15AA, 370A,95 ;24577          MOV LS[SETCSR.F5] TO WR[1]
U 15AB, AEC2,15 ;24578          BIS WR[1] TO WR[0]
U 15AC, 3712,95 ;24579          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO HOLD SDIO LOW
U 15AD, AEC2,15 ;24580          BIS WR[1] TO WR[0]
U 15AE, AEC4,15 ;24581          BIS WR[2] TO WR[0]                      ;SELECT AN RL02
U 15AF, 17A0,15 ;24582          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24583                                                  ;R80=1, F<2:0>=101
                ;24584  ;-------------------------------------------------------------------------
                ;24585  ;-------------------------------------------------------------------------
                ;24586  ;                               *******
                ;24587  ;                               * IDC *
                ;24588  ;                               *******
```

```
;24589  ;-------------------------------------------------------------------------
;24590  ;018:
;24591  ;=000
;24592  ;DIAG.IDLE:
;24593  ;
;24594  ;       BEN0/F0,
;24595  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;24596  ;       BEN2/F2,
;24597  ;       NAD/DIAG.IDLE
;24598  ;-------------------------------------------------------------------------
;24599  ;01F:
;24600  ;=111
;24601  ;
;24602  ;       BEN0/CRDY.L,
;24603  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;24604  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;24605  ;-------------------------------------------------------------------------
;24606  ;078:
;24607  ;=0*0
;24608  ;TEST.FUNC7:
;24609  ;
;24610  ;       NAD/GROUP0
;24611  ;-------------------------------------------------------------------------
;24612  ;163:
;24613  ;=0**
;24614  ;GROUP0:
;24615  ;
;24616  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;24617  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
;24618  ;                                       ; FUNCTION BITS
;24619  ;-------------------------------------------------------------------------
;24620  ;167:
;24621  ;=1**
;24622  ;
;24623  ;       BEN0/F0,
;24624  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;24625  ;       BEN2/F2,
;24626  ;       NAD/GROUP0.F0
;24627  ;-------------------------------------------------------------------------
;24628  ;025:
;24629  ;=101
;24630  ;SHFT.CLK.POS.1:
;24631  ;
;24632  ;       UCMD/SET.FIFOA,                 ;SEL FIFO A
;24633  ;       NAD/SHFT.CLK.POS.2
;24634  ;-------------------------------------------------------------------------
;24635  ;1ED:
;24636  ;SHFT.CLK.POS.2:
;24637  ;
;24638  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;24639  ;       LOAD.DSR/ON,
;24640  ;       NAD/SHFT.CLK.POS.3
;24641  ;-------------------------------------------------------------------------
;24642  ;1EE:
;24643  ;SHFT.CLK.POS.3:
```

```
                ;24644  ;
                ;24645  ;       UMAINT/ON,                      ;ENABLE DSR0 AS NRZ DATA
                ;24646  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
                ;24647  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
                ;24648  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;24649  ;-------------------------------------------------------------------------
                ;24650  ;1D8:
                ;24651  ;XFER.REQ:
                ;24652  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;24653  ;       NAD/DIAG.WAIT
                ;24654  ;-------------------------------------------------------------------------
                ;24655  ;1D7:
                ;24656  ;DIAG.WAIT:
                ;24657  ;
                ;24658  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;24659  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;24660  ;-------------------------------------------------------------------------
                ;24661  ;159:
                ;24662  ;=*0*
                ;24663  ;DIAG.WAIT1:
                ;24664  ;
                ;24665  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;24666  ;                               ; COMMAND FROM THE CPU
                ;24667  ;-------------------------------------------------------------------------
                ;24668  ;15B:
                ;24669  ;=*1*
                ;24670  ;DIAG.WAIT2:
                ;24671  ;
                ;24672  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;24673  ;                               ; WAIT SOME MORE
                ;24674  ;-------------------------------------------------------------------------
                ;24675  WAIT.IDC.T2C.2:
U 15B0, DB00,1A ;24676          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 15B1, 895B,34 ;24677          JMP [IDC.DONE.T2C.2]                    ;XFER REQ SET
U 15B2, 895B,04 ;24678          JMP [WAIT.IDC.T2C.2]                    ;WAIT SOME MORE
                ;24679
                ;24680  IDC.DONE.T2C.2:
U 15B3, B700,15 ;24681          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 15B4, 17A0,15 ;24682          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 15B5, 90FA,15 ;24683          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;24684
                ;24685  READ.PAT.T2C.1:
U 15B6, 9090,15 ;24686          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 15B7, 1790,15 ;24687          PORT.READ PORT.ADRS[PATTERN]            ;SET UP TO READ PATTERN REG
U 15B8, 3B32,15 ;24688          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM PAT AND
                ;24689                                                  ; SAVE IT IN  LS
U 15B9, 3732,15 ;24690          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 15BA, 2006,95 ;24691          MOV WR[3] TO WR[1]                      ;SET UP EXPECTED DATA
U 15BB, 0869,3C ;24692          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 15BC, 8959,74 ;24693          JMP [LOOP.T2C.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;24694
U 15BD, FF82,15 ;24695          INC LS[ERROR.NUMBER]                    ;ERROR 2
U 15BE, 37B6,15 ;24696          MOV LS[#1F] TO WR[0]
U 15BF, 3E10,15 ;24697          MOV WR[0] TO LS[T8]                     ;USE AS A LOOP COUNTER=31
                ;24698
```

```
                ;24699  CHK.PAT.REG.T2C:
                ;24700
                ;24701  ;SET UP THE NEW EXPECTED DATA
U 15C0, A351,95 ;24702          ASHR WR[3]                              ;SHIFT DATA ONCE RIGHT
                ;24703          BIT LS[BIT15] WITH WR[3],               ;IS BIT 15 SET?
U 15C1, 595F,B5 ;24704           DT(LONG)&SET.ALU.CC
U 15C2, 095C,79 ;24705          JMP.IF[BITS.CLR] TO [NO.XOR.T2C.1]      ;JMP IF BIT15 = 0
                ;24706
U 15C3, 37B4,95 ;24707          MOV LS[#20010500] TO WR[1]              ;GET THE MASK
U 15C4, AF83,95 ;24708          XOR WR[1] TO WR[3]                      ;CREATE THE NEW EXPECTED DATA
U 15C5, 477F,95 ;24709          BIS LS[BIT31] TO WR[3]
U 15C6, 895C,84 ;24710          JMP [SET.EXP.DAT.T2C]
                ;24711  NO.XOR.T2C.1:
U 15C7, C57F,95 ;24712          BIC LS[BIT31] TO WR[3]                  ;CREATE THE NEW EXPECTED DATA
                ;24713  SET.EXP.DAT.T2C:
U 15C8, 455F,95 ;24714          BIC LS[BIT15] TO WR[3]                  ;WR[3] HAS NEW EXPECTED DATA
                ;24715
U 15C9, 3712,95 ;24716          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET UP THE CSR TO BRANCH TO
U 15CA, 370E,15 ;24717          MOV LS[SETCSR.F7] TO WR[0]              ; THE CORRECT IDC ROUTINE
U 15CB, AEC2,15 ;24718          BIS WR[1] TO WR[0]
U 15CC, 17A0,15 ;24719          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24720                                                  ;MAINT=0,CRDY=1,F<2:0>=111
                ;24721  ;CONTINUE BRANCHING
U 15CD, 379E,15 ;24722          MOV LS[SETCSR.R80] TO WR[0]             ;CONTINUE TO BRANCH
U 15CE, 370C,95 ;24723          MOV LS[SETCSR.F6] TO WR[1]
U 15CF, AEC2,15 ;24724          BIS WR[1] TO WR[0]
U 15D0, 3712,95 ;24725          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO HOLD SDIO =LO
U 15D1, AEC2,15 ;24726          BIS WR[1] TO WR[0]
U 15D2, AEC4,15 ;24727          BIS WR[2] TO WR[0]                      ;SELECT AN RL02
U 15D3, 17A0,15 ;24728          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;24729                                                  ;R80=1,F<2:0>=110
                ;24730  ;-------------------------------------------------------------------------------
                ;24731  ;-------------------------------------------------------------------------------
                ;24732  ;                               *******
                ;24733  ;                               * IDC *
                ;24734  ;                               *******
                ;24735  ;-------------------------------------------------------------------------------
                ;24736  ;018:
                ;24737  ;=000
                ;24738  ;DIAG.IDLE:
                ;24739  ;
                ;24740  ;       BEN0/F0,
                ;24741  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;24742  ;       BEN2/F2,
                ;24743  ;       NAD/DIAG.IDLE
                ;24744  ;-------------------------------------------------------------------------------
                ;24745  ;01F:
                ;24746  ;=111
                ;24747  ;
                ;24748  ;       BEN0/CRDY.L,
                ;24749  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;24750  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;24751  ;-------------------------------------------------------------------------------
                ;24752  ;078:
                ;24753  ;=0*0
```

```
;24754  ;TEST.FUNC7:
;24755  ;
;24756  ;       NAD/GROUP0
;24757  ;-------------------------------------------------------------------------------
;24758  ;163:
;24759  ;=0**
;24760  ;GROUP0:
;24761  ;
;24762  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;24763  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
;24764  ;                                       ; FUNCTION BITS
;24765  ;-------------------------------------------------------------------------------
;24766  ;167:
;24767  ;=1**
;24768  ;
;24769  ;       BEN0/F0,
;24770  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;24771  ;       BEN2/F2,
;24772  ;       NAD/GROUP0.F0
;24773  ;-------------------------------------------------------------------------------
;24774  ;026:
;24775  ;=110
;24776  ;CRC.PAT.1:
;24777  ;
;24778  ;       ENB.SYS.CLK,                    ;SELECT THE RL02 SYSTEM CLK
;24779  ;       NAD/CRC.PAT.2
;24780  ;-------------------------------------------------------------------------------
;24781  ;1EF:
;24782  ;CRC.PAT.2:
;24783  ;
;24784  ;       MODE/CRC,                       ;SELECT CRC TO SHIFT BIT 15
;24785  ;       DATA.FIELD/ON,                  ;DATA.FIELD AND DISK.WRITE ALLOW
;24786  ;       DISK.WRITE/ON,                  ; THE INTERNAL WRT CLK
;24787  ;       UMAINT/ON,                      ;SELECT DSR0 AS NRZ DATA
;24788  ;       NAD/CRC.PAT.3
;24789  ;-------------------------------------------------------------------------------
;24790  ;1F0:
;24791  ;CRC.PAT.3:
;24792  ;
;24793  ;       ENB.CPU.CLK,                    ;RETURN TO THE CPU CLK
;24794  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;24795  ;-------------------------------------------------------------------------------
;24796  ;1D8:
;24797  ;XFER.REQ:
;24798  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;24799  ;       NAD/DIAG.WAIT
;24800  ;-------------------------------------------------------------------------------
;24801  ;1D7:
;24802  ;DIAG.WAIT:
;24803  ;
;24804  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;24805  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;24806  ;-------------------------------------------------------------------------------
;24807  ;159:
;24808  ;=*0*
```

```
                ;24809  ;DIAG.WAIT1:
                ;24810  ;
                ;24811  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;24812  ;                               ; COMMAND FROM THE CPU
                ;24813  ;-------------------------------------------------------------------------
                ;24814  ;15B:
                ;24815  ;=*1*
                ;24816  ;DIAG.WAIT2:
                ;24817  ;
                ;24818  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;24819  ;                               ; WAIT SOME MORE
                ;24820  ;-------------------------------------------------------------------------
                ;24821  WAIT.IDC.T2C.3:
U 15D4, DB00,1A ;24822          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 15D5, 095D,74 ;24823          JMP [IDC.DONE.T2C.3]                    ;XFER REQ SET
U 15D6, 095D,44 ;24824          JMP [WAIT.IDC.T2C.3]                    ;WAIT SOME MORE
                ;24825
                ;24826  IDC.DONE.T2C.3:
U 15D7, B700,15 ;24827          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 15D8, 17A0,15 ;24828          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 15D9, 90FA,15 ;24829          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;24830
                ;24831
                ;24832  READ.PAT.T2C.2:
U 15DA, 9090,15 ;24833          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 15DB, 1790,15 ;24834          PORT.READ PORT.ADRS[PATTERN]            ;SET UP TO READ PATTERN REG
U 15DC, 3B32,15 ;24835          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM PAT AND
                ;24836                                                  ; SAVE IT IN  LS
U 15DD, 3732,15 ;24837          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 15DE, 2006,95 ;24838          MOV WR[3] TO WR[1]                      ;SET UP EXPECTED DATA
U 15DF, 0869,3C ;24839          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 15E0, 8959,14 ;24840          JMP [LOOP.T2C.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;24841          DEC LS[T8],                             ;DONE?
U 15E1, FC10,35 ;24842           DT(LONG)&SET.ALU.CC
U 15E2, 095C,01 ;24843          JMP.IF[NEQ] TO [CHK.PAT.REG.T2C]       ;JMP IF NOT DONE
                ;24844
U 15E3, 8875,3C ;24845          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;24846                                                  ; THIS TEST
                ;24847  END.T2C:                                        ;END TEST
                ;24848
                ;24849
```

```
;24850  .PAGE  "Test 2D  CORRECTABLE ECC ERROR TEST (M8388 IDC MODULE)"
;24851  ;++
;24852  ;
;24853  ; Test Description:
;24854  ;
;24855  ;       This test is designed to insure that the DC007 chip recognizes a
;24856  ;       correctable error and that the ECC STAT <1:0> = 11 when a correctable
;24857  ;       error is found.
;24858  ;       This will be done by first issuing a UCLR ECC which will initialize the
;24859  ;       DC007 chip. Then an error will be generated. A pattern is loaded into
;24860  ;       internal DC007 shift pattern register that will then generate a
;24861  ;       correctable error. The RL02 System clock will be used.
;24862  ;
;24863  ; Assumptions:
;24864  ;
;24865  ;       It is assumed that all previous tests have run successfully.
;24866  ;
;24867  ; Test Steps:
;24868  ;
;24869  ;       1. Set up error mask, error number and module number in LS
;24870  ;          (for error printouts) and clear the previous error number in LS.
;24871  ;       2. Force the IDC microcode to DIAG.IDLE.
;24872  ;       3. Select a drive number that is not an R80.
;24873  ;       4. Write a one to FIFO A address 0.
;24874  ;       5. Set up the CSR to branch to the correct IDC microcode routine.
;24875  ;
;24876  ;                                       *******
;24877  ;                                       * IDC *
;24878  ;                                       *******
;24879  ;
;24880  ;
;24881  ;             IDC1. Execute an instruction with FUNC <35:32> = 0001,
;24882  ;                   UCLR ECC.
;24883  ;
;24884  ;             IDC2. Shift the one from FIFO A into the interal DC007 pattern
;24885  ;                   register.
;24886  ;
;24887  ;       6. Wait for a XFER REQ from the IDC.
;24888  ;       7. Clear CSR F<2:0> and send XFER GRANT.
;24889  ;       8. Set up the CSR to branch to the correct IDC routine.
;24890  ;
;24891  ;
;24892  ;
;24893  ;                                       *******
;24894  ;                                       * IDC *
;24895  ;                                       *******
;24896  ;
;24897  ;             IDC3. Assert DC007 ERR by first asserting CHECK.FIELD and then
;24898  ;                   deasserting CHECK.FIELD.
;24899  ;
;24900  ;       9. Wait for a XFER REQ from the IDC.
;24901  ;      10. Clear CSR F<2:0> and send XFER GRANT to clr XFER REQ.
;24902  ;      11. Set up the CSR to branch to the correct IDC routine.
;24903  ;
;24904  ;
```

```
;24905  ;
;24906  ;                                        *******
;24907  ;                                        * IDC *
;24908  ;                                        *******
;24909  ;
;24910  ;               IDC4. Select the RL02 SYSTEM clock.
;24911  ;               IDC5. Load the Loop counter= 00.
;24912  ;               IDC6. Allow 1 clk tick.
;24913  ;               IDC7. Increment the loop counter and select BEN0/CNTR OVFLW.
;24914  ;               IDC8. DC007 will clk 100 (HEX) times.
;24915  ;               IDC9. Select the CPU clk and send XFER REQ to flag the CPU.
;24916  ;
;24917  ;       12. Wait for XFER REQ from the IDC.
;24918  ;       13. Clear CSR F<2:0> and send XFER GRANT to clr the XFER REQ.
;24919  ;       14. Repeat Steps 11 - 14  169 (HEX) times.
;24920  ;       15. Read the CSR and check <21:20> = 11.
;24921  ;       16. Clear IDC.
;24922  ;       17. End test.
;24923  ;
;24924  ; Errors:
;24925  ;
;24926  ;
;24927  ;       ERROR 1 - The CRC/ECC chip failed when determining a correctable
;24928  ;                 error or ECC STAT <1:0> bits failed = 11.
;24929  ;
;24930  ;                 Printout:
;24931  ;                         EXPECTED          RECEIVED
;24932  ;                         ECC STAT<1:0>     ECC STAT<1:0>
;24933  ;                         CSR <21:20>       CSR <21:20>
;24934  ;
;24935  ;
;24936  ; Debug:
;24937  ;
;24938  ; ERROR 1 -
;24939  ;
;24940  ;       The IDC microcode will execute an instrcution with FUNC <3:0>=0001.
;24941  ;       These bits will be decoded and will assert UCLR ECC L. This signal
;24942  ;       is the Clear line to the CRC/ECC chip and will clear the CRC/ECC
;24943  ;       chip internal Pattern register.
;24944  ;       A one is then loaded into the Pattern register while UENC CRC H = L
;24945  ;       and UDATA FIELD H = H.
;24946  ;       The IDC microcode will then execute a series of instructions that will
;24947  ;       assert ERR internal to the CRC/ECC chip.
;24948  ;       In the next series of IDC micro-instructions, SYS CLK is selected which
;24949  ;       is the W CLK input to the CRC/ECC chip. This clock will be used as the
;24950  ;       internal clock for the CRC/ECC chip. Then UMAINT H is asserted and
;24951  ;       UENB CRC H is deasserted. This will allow the internal Pattern register
;24952  ;       to clock once each time this instruction is executed. This series of
;24953  ;       micro-instructions is repeated until the internal conditions for a
;24954  ;       correctable ECC error are simulated. This will set ECC status lines =
;24955  ;       ECC STAT 1 H = H and ECC STAT 0 H = H which indicates a correctable
;24956  ;       error has been found. The CPU will then read these lines as
;24957  ;       CSR <21:20>.
;24958  ;--
;24959  ;*******************************************************************************
```

```
                    ;24960  T.2D:
U 15E4, B65E,15     ;24961          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;24962                                                  ; CONTROL AND STATUS WORD
U 15E5, 3E80,15     ;24963          MOV WR[0] TO LS[CONTROL.STATUS]          ;SET BIT 15 IN CONTROL AND
                    ;24964                                                  ; STATUS WORD - BIT 15
                    ;24965                                                  ; INDICATES START OF TEST TO
                    ;24966                                                  ; CONSOLE
U 15E6, 10E0,15     ;24967          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;24968  WAIT.T2D.0:
U 15E7, 095E,74     ;24969          JMP [WAIT.T2D.0]                        ;LOOP HERE WAITING FOR
                    ;24970                                                  ; CONSOLE TO RESPOND
                    ;24971
U 15E8, 65A0,15     ;24972          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;24973                                                  ; IN LS
                    ;24974
U 15E9, B64A,15     ;24975          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 15EA, 3E8C,15     ;24976          MOV WR[0] TO LS[MODULE.NUM]              ; INDICATE IDC MODULE
                    ;24977
                    ;24978
U 15EB, B640,15     ;24979          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 15EC, BE82,15     ;24980          MOV WR[0] TO LS[ERROR.NUMBER]            ;SET UP ERROR NUMBER = 1 IN LS
                    ;24981
                    ;24982
U 15ED, 37A4,15     ;24983          MOV LS[#FFCFFFFF] TO WR[0]               ;MASK TO CHECK BITS <21:20>
U 15EE, 3E8A,15     ;24984          MOV WR[0] TO LS[ERROR.MASK]
                    ;24985
                    ;24986
                    ;24987
                    ;24988  ;FORCE THE DC007 TO FIND A CORRECTABLE ERROR...ECC STAT<1:0>=11
                    ;24989  ;CLR THE PATTERN REGISTER
                    ;24990
U 15EF, B78E,15     ;24991          MOV LS[DRIVE.STATUS] TO WR[0]            ;HAS THE DRIVE SIZING ROUTINE
                    ;24992          BIT LS[BIT7] WITH WR[0],                 ; BEEN RUN?
U 15F0, D94E,35     ;24993           DT(LONG)&SET.ALU.CC
U 15F1, 095F,31     ;24994          JMP.IF[BIT.SET] TO [SIZE.OK.T2D.1]       ;IF YES THEN GO DIRCETLY TO
                    ;24995                                                  ; TEST
                    ;24996
U 15F2, 8870,0C     ;24997          JSR [DRIVE.SIZE]                         ;GO RUN THE SIZING ROUTINE
                    ;24998
                    ;24999  SIZE.OK.T2D.1:
                    ;25000
                    ;25001          ;SELECT AN RL02 DRIVE
                    ;25002
U 15F3, B78E,15     ;25003          MOV LS[DRIVE.STATUS] TO WR[0]
                    ;25004          BIT LS[BIT0] WITH WR[0],                 ;IS DRIVE 0 AN R80?
U 15F4, 5940,35     ;25005           DT(LONG)&SET.ALU.CC
U 15F5, 095F,89     ;25006          JMP.IF[BITS.CLR] TO [SET.DS0.T2D.1]      ;JMP IF DRV 0 IS NOT AN R80
U 15F6, B717,15     ;25007          MOV LS[SETCSR.DS1] TO WR[2]              ;SAVE THE DATA TO SEL DRIVE 1
                    ;25008                                                  ; IN WR[2]
U 15F7, 095F,94     ;25009          JMP [TEST.T2D.1]
                    ;25010  SET.DS0.T2D.1:
U 15F8, 3715,15     ;25011          MOV LS[SETCSR.DS0] TO WR[2]              ;SAVE THE DATA TO SEL DRIVE 0
                    ;25012                                                  ; IN WR[2]
                    ;25013  TEST.T2D.1:
U 15F9, 8872,EC     ;25014          JSR [DIAG.CODE]                          ;FORCE THE IDC TO DIAG.IDLE
```

```
                ;25015  LOOP.T2D.1:
U 15FA, 17D8,15 ;25016          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A
U 15FB, 17C0,15 ;25017          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET ADRS = 0
U 15FC, B640,15 ;25018          MOV LS[#1] TO WR[0]                         ;GET THE DATA TO WRITE
U 15FD, 97A8,15 ;25019          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE A ONE TO FIFO A
U 15FE, 17C0,15 ;25020          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET ADRS = 0
                ;25021
U 15FF, 3712,95 ;25022          MOV LS[SETCSR.CRDY] TO WR[1]                ;SET UP THE CSR TO BRANCH TO
U 1600, 370E,15 ;25023          MOV LS[SETCSR.F7] TO WR[0]                  ; THE CORRECT IDC ROUTINE
U 1601, AEC2,15 ;25024          BIS WR[1] TO WR[0]
U 1602, 17A0,15 ;25025          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25026                                                      ;MAINT=0,CRDY=1,F<2:0>=111
                ;25027  ;CONTINUE BRANCHING
                ;25028
U 1603, 379E,15 ;25029          MOV LS[SETCSR.R80] TO WR[0]                 ;CONTINUE TO BRANCH TO ROUTINE
U 1604, 3700,95 ;25030          MOV LS[SETCSR.F0] TO WR[1]
U 1605, AEC2,15 ;25031          BIS WR[1] TO WR[0]
U 1606, 3712,95 ;25032          MOV LS[SETCSR.CRDY] TO WR[1]                ;SET CRDY TO HOLD SDIO LOW
U 1607, AEC2,15 ;25033          BIS WR[1] TO WR[0]
U 1608, 17A0,15 ;25034          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25035                                                      ;R80=1, F<2:0>=000
                ;25036  ;-------------------------------------------------------------------------
                ;25037  ;-------------------------------------------------------------------------
                ;25038  ;                                *******
                ;25039  ;                                * IDC *
                ;25040  ;                                *******
                ;25041  ;-------------------------------------------------------------------------
                ;25042  ;018:
                ;25043  ;=000
                ;25044  ;DIAG.IDLE:
                ;25045  ;
                ;25046  ;       BEN0/F0,
                ;25047  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
                ;25048  ;       BEN2/F2,
                ;25049  ;       NAD/DIAG.IDLE
                ;25050  ;-------------------------------------------------------------------------
                ;25051  ;01F:
                ;25052  ;=111
                ;25053  ;
                ;25054  ;       BEN0/CRDY.L,
                ;25055  ;       BEN2/MAINT,                 ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;25056  ;       NAD/TEST.FUNC7              ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;25057  ;-------------------------------------------------------------------------
                ;25058  ;078:
                ;25059  ;=0*0
                ;25060  ;TEST.FUNC7:
                ;25061  ;
                ;25062  ;       NAD/GROUP0
                ;25063  ;-------------------------------------------------------------------------
                ;25064  ;163:
                ;25065  ;=0**
                ;25066  ;GROUP0:
                ;25067  ;
                ;25068  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;25069  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
```

```
;25070  ;                                       ; FUNCTION BITS
;25071  ;-------------------------------------------------------------------------
;25072  ;167:
;25073  ;=1**
;25074  ;
;25075  ;       BEN0/F0,
;25076  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;25077  ;       BEN2/F2,
;25078  ;       NAD/GROUP0.F0
;25079  ;-------------------------------------------------------------------------
;25080  ;020:
;25081  ;=000
;25082  ;GROUP0.F0:
;25083  ;
;25084  ;PAT.REG.1:
;25085  ;
;25086  ;       FUNC/CLR.ECC,           ;CLR ECC TO ZERO THE PATTERN REGISTER
;25087  ;       NAD/PAT.REG.2
;25088  ;-------------------------------------------------------------------------
;25089  ;1E6:
;25090  ;PAT.REG.2:
;25091  ;
;25092  ;       UCMD/SET.FIFOA,                 ;SELECT FIFO A
;25093  ;       NAD/PAT.REG.3
;25094  ;-------------------------------------------------------------------------
;25095  ;1E7:
;25096  ;PAT.REG.3:
;25097  ;
;25098  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;25099  ;       LOAD.DSR/ON,
;25100  ;       UMAINT/ON,                      ;ASSERT MAINT SO DSR0 BECOMES NRZ DATA
;25101  ;       NAD/PAT.REG.4
;25102  ;-------------------------------------------------------------------------
;25103  ;1E8:
;25104  ;PAT.REG.4:
;25105  ;
;25106  ;       DATA.FIELD/ON,                  ;ALLOW READ CLK
;25107  ;       MODE/ECC,                       ;ECC MODE TO SHIFT BIT 31
;25108  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;25109  ;-------------------------------------------------------------------------
;25110  ;1D8:
;25111  ;XFER.REQ:
;25112  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;25113  ;       NAD/DIAG.WAIT
;25114  ;-------------------------------------------------------------------------
;25115  ;1D7:
;25116  ;DIAG.WAIT:
;25117  ;
;25118  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;25119  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;25120  ;-------------------------------------------------------------------------
;25121  ;159:
;25122  ;=*0*
;25123  ;DIAG.WAIT1:
;25124  ;
```

```
                ;25125  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;25126  ;                               ; COMMAND FROM THE CPU
                ;25127  ;-------------------------------------------------------------------------
                ;25128  ;15B:
                ;25129  ;=*1*
                ;25130  ;DIAG.WAIT2:
                ;25131  ;
                ;25132  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;25133  ;                               ; WAIT SOME MORE
                ;25134  ;-------------------------------------------------------------------------
                ;25135  WAIT.IDC.T2D.1:
U 1609, DB00,1A ;25136          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 160A, 0960,C4 ;25137          JMP [IDC.DONE.T2D.1]                    ;XFER REQ SET
U 160B, 0960,94 ;25138          JMP [WAIT.IDC.T2D.1]                    ;WAIT SOME MORE
                ;25139
                ;25140  IDC.DONE.T2D.1:
U 160C, B700,15 ;25141          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 160D, 17A0,15 ;25142          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 160E, 90FA,15 ;25143          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;25144
                ;25145
U 160F, 370E,15 ;25146          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
                ;25147                                                  ; THE CORRECT IDC ROUTINE
U 1610, 17A0,15 ;25148          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;25149                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;25150
                ;25151  ;CONTINUE BRANCHING
                ;25152
U 1611, B79E,95 ;25153          MOV LS[SETCSR.R80] TO WR[1]             ;CONTINUE TO BRANCH TO THE
U 1612, 3702,15 ;25154          MOV LS[SETCSR.F1] TO WR[0]              ; IDC ROUTINE
U 1613, AEC2,15 ;25155          BIS WR[1] TO WR[0]
U 1614, 3712,95 ;25156          MOV LS[SETCSR.CRDY] TO WR[1]
U 1615, AEC2,15 ;25157          BIS WR[1] TO WR[0]                      ;SET CRDY TO HOLD SDIO LO
U 1616, 17A0,15 ;25158          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;25159                                                  ;R80=1,F<2:0>=001
                ;25160  ;-------------------------------------------------------------------------
                ;25161  ;-------------------------------------------------------------------------
                ;25162  ;                               *******
                ;25163  ;                               * IDC *
                ;25164  ;                               *******
                ;25165  ;-------------------------------------------------------------------------
                ;25166  ;018:
                ;25167  ;=000
                ;25168  ;DIAG.IDLE:
                ;25169  ;
                ;25170  ;       BEN0/F0,
                ;25171  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;25172  ;       BEN2/F2,
                ;25173  ;       NAD/DIAG.IDLE
                ;25174  ;-------------------------------------------------------------------------
                ;25175  ;01F:
                ;25176  ;=111
                ;25177  ;
                ;25178  ;       BEN0/CRDY.L,
                ;25179  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
```

```
;25180  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;25181  ;-------------------------------------------------------------------------
;25182  ;078:
;25183  ;=0*0
;25184  ;TEST.FUNC7:
;25185  ;
;25186  ;       NAD/GROUP0
;25187  ;-------------------------------------------------------------------------
;25188  ;163:
;25189  ;=0**
;25190  ;GROUP0:
;25191  ;
;25192  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;25193  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
;25194  ;                                       ; FUNCTION BITS
;25195  ;-------------------------------------------------------------------------
;25196  ;167:
;25197  ;=1**
;25198  ;
;25199  ;       BEN0/F0,
;25200  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;25201  ;       BEN2/F2,
;25202  ;       NAD/GROUP0.F0
;25203  ;-------------------------------------------------------------------------
;25204  ;021:
;25205  ;=001
;25206  ;POS.REG.1:
;25207  ;
;25208  ;       UCMD/SET.FIFOA,                 ;SEL FIFO A
;25209  ;       NAD/POS.REG.2
;25210  ;-------------------------------------------------------------------------
;25211  ;1E9:
;25212  ;POS.REG.2:
;25213  ;
;25214  ;       ENB.FIFO/ON,                    ;LOAD THE DSR WITH DATA FROM THE FIFO
;25215  ;       LOAD.DSR/ON,
;25216  ;       NAD/POS.REG.3
;25217  ;-------------------------------------------------------------------------
;25218  ;1EA:
;25219  ;POS.REG.3:
;25220  ;
;25221  ;       UMAINT/ON,                      ;ENABLE DSR0 AS NRZ DATA
;25222  ;       CHECK.FIELD/ON,                 ;MAKE DC007 BELIEVE IT HAS READ THE
;25223  ;       MODE/CRC,                       ; CHECK FIELD
;25224  ;       NAD/POS.REG.4
;25225  ;-------------------------------------------------------------------------
;25226  ;1EB:
;25227  ;POS.REG.4:
;25228  ;
;25229  ;       MODE/CRC,                       ;DROP CHECK FIELD WHILE THE INTERNAL
;25230  ;                                       ; DC007 SHIFT REG IS NON-ZERO TO
;25231  ;                                       ; ASSERT ERROR INTERNAL TO THE DC007
;25232  ;                                       ;ERROR ALLOWS THE POS REG TO INCR
;25233  ;       DATA.FIELD/ON,                  ;ASSERT DATA FIELD TO ALLOW CLK
;25234  ;       UMAINT/ON,                      ;TO SELECT DSR0 AS NRZ DATA
```

```
                ;25235  ;       NAD/POS.REG.5
                ;25236  ;-------------------------------------------------------------------------
                ;25237  ;1EC:
                ;25238  ;POS.REG.5:
                ;25239  ;
                ;25240  ;       DATA.FIELD/ON,                  ;TO ALLOW THE POS REG TO CLK ONCE
                ;25241  ;       MODE/CRC,                       ;TO PREVENT INTERNAL DC007 SIGNALS
                ;25242  ;       UMAINT/ON,                      ;TO SEL DSR0 AS NRZ DATA
                ;25243  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;25244  ;-------------------------------------------------------------------------
                ;25245  ;1D8:
                ;25246  ;XFER.REQ:
                ;25247  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;25248  ;       NAD/DIAG.WAIT
                ;25249  ;-------------------------------------------------------------------------
                ;25250  ;1D7:
                ;25251  ;DIAG.WAIT:
                ;25252  ;
                ;25253  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;25254  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;25255  ;-------------------------------------------------------------------------
                ;25256  ;159:
                ;25257  ;=*0*
                ;25258  ;DIAG.WAIT1:
                ;25259  ;
                ;25260  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;25261  ;                               ; COMMAND FROM THE CPU
                ;25262  ;-------------------------------------------------------------------------
                ;25263  ;15B:
                ;25264  ;=*1*
                ;25265  ;DIAG.WAIT2:
                ;25266  ;
                ;25267  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;25268  ;                               ; WAIT SOME MORE
                ;25269  ;-------------------------------------------------------------------------
                ;25270  WAIT.IDC.T2D.2:
U 1617, DB00,1A ;25271          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1618, 8961,A4 ;25272          JMP [IDC.DONE.T2D.2]                    ;XFER REQ SET
U 1619, 0961,74 ;25273          JMP [WAIT.IDC.T2D.2]                    ;WAIT SOME MORE
                ;25274
                ;25275  IDC.DONE.T2D.2:
U 161A, B700,15 ;25276          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 161B, 17A0,15 ;25277          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 161C, 90FA,15 ;25278          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;25279
                ;25280
U 161D, B7B9,95 ;25281          MOV LS[#169] TO WR[3]                   ;USE AS A COUNTER
                ;25282
                ;25283  LOOP.AGN.T2D:
                ;25284
U 161E, 370E,15 ;25285          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 161F, 3712,95 ;25286          MOV LS[SETCSR.CRDY] TO WR[1]            ; THE CORRECT IDC ROUTINE
U 1620, AEC2,15 ;25287          BIS WR[1] TO WR[0]
U 1621, 17A0,15 ;25288          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;25289                                                  ;MAINT=0,CRDY=0,F<2:0>=111
```

```
                ;25290  ;CONTINUE BRANCHING
                ;25291
U 1622, B79E,95 ;25292          MOV LS[SETCSR.R80] TO WR[1]             ;CONTINUE TO BRANCH TO THE
U 1623, 370E,15 ;25293          MOV LS[SETCSR.F7] TO WR[0]              ; IDC ROUTINE
U 1624, AEC2,15 ;25294          BIS WR[1] TO WR[0]
U 1625, 3712,95 ;25295          MOV LS[SETCSR.CRDY] TO WR[1]
U 1626, AEC2,15 ;25296          BIS WR[1] TO WR[0]                      ;SET CRDY TO HOLD SDIO LO
U 1627, AEC4,15 ;25297          BIS WR[2] TO WR[0]                      ;SELECT THE RL02 SYSTEM CLK
U 1628, 17A0,15 ;25298          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;25299                                                  ;R80=1,F<2:0>=111
                ;25300  ;-------------------------------------------------------------------------
                ;25301  ;-------------------------------------------------------------------------
                ;25302  ;                               *******
                ;25303  ;                               * IDC *
                ;25304  ;                               *******
                ;25305  ;-------------------------------------------------------------------------
                ;25306  ;018:
                ;25307  ;=000
                ;25308  ;DIAG.IDLE:
                ;25309  ;
                ;25310  ;       BEN0/F0,
                ;25311  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;25312  ;       BEN2/F2,
                ;25313  ;       NAD/DIAG.IDLE
                ;25314  ;-------------------------------------------------------------------------
                ;25315  ;01F:
                ;25316  ;=111
                ;25317  ;
                ;25318  ;       BEN0/CRDY.L,
                ;25319  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;25320  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;25321  ;-------------------------------------------------------------------------
                ;25322  ;078:
                ;25323  ;=0*0
                ;25324  ;TEST.FUNC7:
                ;25325  ;
                ;25326  ;       NAD/GROUP0
                ;25327  ;-------------------------------------------------------------------------
                ;25328  ;163:
                ;25329  ;=0**
                ;25330  ;GROUP0:
                ;25331  ;
                ;25332  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;25333  ;       NAD/GROUP0                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;25334  ;                                       ; FUNCTION BITS
                ;25335  ;-------------------------------------------------------------------------
                ;25336  ;167:
                ;25337  ;=1**
                ;25338  ;
                ;25339  ;       BEN0/F0,
                ;25340  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;25341  ;       BEN2/F2,
                ;25342  ;       NAD/GROUP0.F0
                ;25343  ;-------------------------------------------------------------------------
                ;25344  ;027:
```

```
;25345  ;=111
;25346  ;ECC.STAT.1:
;25347  ;
;25348  ;       ENB.SYS.CLK,                    ;SELECT THE RL02 SYSTEM CLOCK
;25349  ;       NAD/ECC.STAT.2
;25350  ;-------------------------------------------------------------------------
;25351  ;1F1:
;25352  ;ECC.STAT.2:
;25353  ;
;25354  ;       LOAD.LOOP.CNTR.[00],            ;LOAD THE LPCNTR = 00
;25355  ;       NAD/ECC.STAT.3
;25356  ;-------------------------------------------------------------------------
;25357  ;196:
;25358  ;=0
;25359  ;ECC.STAT.3:
;25360  ;
;25361  ;       INCR.LPCNTR/ON,                 ;INCR THE LOOP CNTR
;25362  ;       UMAINT/ON,                      ;SELECTS DSR0 AS NRZ DATA
;25363  ;       MODE/ECC,                       ;SELECT ECC MODE
;25364  ;       BEN0/CNTR.OVFLW,                ;LOOP HERE 255 TIMES
;25365  ;       NAD/ECC.STAT.3
;25366  ;-------------------------------------------------------------------------
;25367  ;197:
;25368  ;=1
;25369  ;ECC.STAT.4:
;25370  ;
;25371  ;       ENB.CPU.CLK,                    ;ENABLE THE CPU CLK
;25372  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;25373  ;-------------------------------------------------------------------------
;25374  ;1D8:
;25375  ;XFER.REQ:
;25376  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;25377  ;       NAD/DIAG.WAIT
;25378  ;-------------------------------------------------------------------------
;25379  ;1D7:
;25380  ;DIAG.WAIT:
;25381  ;
;25382  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;25383  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;25384  ;-------------------------------------------------------------------------
;25385  ;159:
;25386  ;=*0*
;25387  ;DIAG.WAIT1:
;25388  ;
;25389  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;25390  ;                               ; COMMAND FROM THE CPU
;25391  ;-------------------------------------------------------------------------
;25392  ;15B:
;25393  ;=*1*
;25394  ;DIAG.WAIT2:
;25395  ;
;25396  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
;25397  ;                               ; WAIT SOME MORE
;25398  ;-------------------------------------------------------------------------
;25399  WAIT.IDC.T2D.3:
```

```
U 1629, DB00,1A ;25400          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 162A, 8962,C4 ;25401          JMP [IDC.DONE.T2D.3]                        ;XFER REQ SET
U 162B, 8962,94 ;25402          JMP [WAIT.IDC.T2D.3]                        ;WAIT SOME MORE
                ;25403
                ;25404  IDC.DONE.T2D.3:
U 162C, B700,15 ;25405          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 162D, 17A0,15 ;25406          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 162E, 90FA,15 ;25407          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;25408
                ;25409          DEC WR[3],                                  ;DEC THE LOOP CNTR
U 162F, A107,B5 ;25410           DT(LONG)&SET.ALU.CC                        ;DONE?
U 1630, 0961,E1 ;25411          JMP.IF[NEQ] TO [LOOP.AGN.T2D]               ;JMP IF NOT DONE
                ;25412
                ;25413  READ.CSR.T2D.1:
U 1631, 9090,15 ;25414          MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 1632, 9780,15 ;25415          PORT.READ PORT.ADRS[CSR]                    ;SET UP TO READ THE CSR
U 1633, 3B32,15 ;25416          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM CSR AND
                ;25417                                                      ; SAVE IT IN  LS
U 1634, 3732,15 ;25418          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 1635, 3668,95 ;25419          MOV LS[BIT20] TO WR[1]                      ;SET UP EXPECTED DATA
U 1636, C76A,95 ;25420          BIS LS[BIT21] TO WR[1]
U 1637, 0869,3C ;25421          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1638, 095F,A4 ;25422          JMP [LOOP.T2D.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;25423
U 1639, 8875,3C ;25424          JSR [CLEANUP]                               ;CLEANUP THE CONDITIONS SET BY
                ;25425                                                      ;THIS TEST
                ;25426  END.T2D:                                            ;END TEST
                ;25427
                ;25428
```

```
;25429  .PAGE  "Test 2E  HEADER MATCH TEST (M8388 IDC MODULE)"
;25430  ;++
;25431  ;
;25432  ; Test Description:
;25433  ;
;25434  ;       This test is designed to insure that the mismatch logic recognizes a
;25435  ;       match between the read data and the serial DAR data. Because of the
;25436  ;       design of the diskless loop, DAR bit <9> will be compared with Bit<0>
;25437  ;       of the read data.
;25438  ;       Set the drive select to an RL02 drive or a line with no drive attached.
;25439  ;       The data pattern will be loaded into the FIFO and the DAR. The data
;25440  ;       will then be taken from the FIFO and shifted through the diskless loop
;25441  ;       as read data. The data also will be serialized through the DAR
;25442  ;       SERIALIZER PALS. The DAR data and the read data will then be compared
;25443  ;       in the DSR RD SEQ REG PAL. The IDC will then do a TEST MATCH with
;25444  ;       BEN2/MISMATCH L selected. If the MATCH was not detected,
;25445  ;       (MISMATCH L = L), then the DAR will be incremented ONCE. If a MATCH was
;25446  ;       detected then the DAR will be incremented twice. The CPU will then
;25447  ;       check the contents of the DAR.
;25448  ;
;25449  ;       Data Pattern:
;25450  ;
;25451  ;                               DAR             READ DATA
;25452  ;                               0200              01
;25453  ; Assumptions:
;25454  ;
;25455  ;       It is assumed that the diskless loop is fully operational.
;25456  ;
;25457  ; Test Steps:
;25458  ;
;25459  ;       1. Set up error mask, error number and module number in LS
;25460  ;          (for error printouts) and clear the previous error number in LS.
;25461  ;       2. Force the IDC microcode to DIAG.IDLE.
;25462  ;       3. If the drive sizing routine has not been run previously , JSR to
;25463  ;          DRIVE.SIZE.
;25464  ;       4. Select an RL02 drive.
;25465  ;       5. Clear Match.
;25466  ;       6. Load the data pattern into the DAR.
;25467  ;       7. Load the data pattern into the FIFO.
;25468  ;       8. Set up the CSR to branch to the correct IDC microcode routine.
;25469  ;
;25470  ;
;25471  ;                                       *******
;25472  ;                                       * IDC *
;25473  ;                                       *******
;25474  ;
;25475  ;               IDC1. Select the disk clock.
;25476  ;               IDC2. Shift out the sync character.
;25477  ;               IDC3. Follow with the data from the FIFO.
;25478  ;               IDC4. Assert UENB BC H so that the DAR will begin serializing
;25479  ;                     after sync is seen.
;25480  ;               IDC5. Execute an instruction with UCON <1:0> = 10, TEST MATCH.
;25481  ;               IDC6. Select the CPU clk.
;25482  ;               IDC7. Select BEN2/MISMATCH L.
;25483  ;               IDC8. If MISMATCH L is asserted increment the DAR once.
```

```
;25484  ;                    If MISMATCH is not asserted ( a MATCH was detected)
;25485  ;                      increment the DAR twice.
;25486  ;                IDC9. Issue XFER.REQ to flag the CPU and go to DIAG.WAIT.
;25487  ;
;25488  ;       9. Wait for a XFER.REQ from IDC.
;25489  ;      10. Clear CSR <2:0> and issue XFER GRANT to clear the XFER.REQ.
;25490  ;      11. Check the DAR = 202 (DAR was loaded with 200 and should be
;25491  ;          incremented twice).
;25492  ;      12. Clear Match.
;25493  ;      13. Clear IDC.
;25494  ;      14. End test.
;25495  ;
;25496  ; Errors:
;25497  ;
;25498  ;       ERROR 1 - The mismatch logic failed when attempting to cause a match
;25499  ;                 between the serialized DAR and read data.
;25500  ;
;25501  ;                 Printout:
;25502  ;                          EXPECTED          RECEIVED
;25503  ;                            DAR               DAR
;25504  ; Debug:
;25505  ;
;25506  ; ERROR 1 -
;25507  ;       The data pattern is loaded into the DAR (data = 200) and into FIFO A
;25508  ;       address 0 (data = 01). A line with no disk drive attached or with an
;25509  ;       RL02 drive attched is selected and will assert RL02 H which is inverted
;25510  ;       to becomes R80 H = L. The IDC will branch to a routine that will load
;25511  ;       the data from FIFO A address 0, into the DSR. This data is then
;25512  ;       shifted through the RL02 diskless loop to become READ DATA H
;25513  ;       (see RL02 DATA PATH TESTS if diskless loop is not functioning
;25514  ;       correctly).
;25515  ;       READ DATA H is an input to the SERIAL DAR LO PAL and it becomes
;25516  ;       M.READ DATA H. This signal is an input to the DSK RD SEQ REG PAL.
;25517  ;       As this data is being shifted through the diskless loop, the DAR data
;25518  ;       is being serialized. The BIT COUNTER PAL is cleared when ENB CLR BC H
;25519  ;       is asserted from the IDC microword when SYNC SEEN L.
;25520  ;       R80 H will not be asserted at this time so the DAR will be serialized
;25521  ;       in order starting with Bit <0> up to Bit <18>. For example:
;25522  ;       when the bit couter = 2, bit 2 of the DAR will be output as MUX DAR H.
;25523  ;       The serializing is done in the BIT COUNTER PAL and the SERIAL DAR LO
;25524  ;       and SERIAL DAR HI PALS.
;25525  ;       The DAR at this time = 200, so MUX DAR H should remain L until the
;25526  ;       BIT COUNTER PAL = 01001 and then DAR bit <9> should be output as
;25527  ;       MUX DAR H = H.
;25528  ;       At the DSK RD SEQ REG PAL, SYNC SEEN L will be asserted at the next
;25529  ;       CURRENT CLK H after SEL DSK CLK H = H and BYTE COMPARE H = H. After
;25530  ;       SYNC SEEN L is asserted, COMPARE L will assert when SERIAL DAR H =
;25531  ;       M.READ DATA H with UWRT CHK H = L. COMPARE L will assert on the first
;25532  ;       match of SERIAL DAR H and  M.READ DATA H and will remain asserted
;25533  ;       unless a mismatch is encountered. Bits <8:0> of the DAR which are all
;25534  ;       zeros will be compared to zeros coming in as M.READ DATA H. When bit
;25535  ;       <9> of the DAR is selected Bit <0> of the data which was loaded into
;25536  ;       FIFO A will be M.READ DATA H, so in this test COMPARE L should remain
;25537  ;       asserted.
;25538  ;       The IDC will then issue an instruction with UCON <1:0> = 10. These bits
```

```
                ;25539  ;       will be decoded by the DSK RD SEQ REG PAL to perform a TEST.MATCH.
                ;25540  ;       COMPARE L is asserted at this time, so MISMATCH L = H.
                ;25541  ;       The IDC microcode will then select BEN2/MISMATCH L (BEN2 S2 H = L,
                ;25542  ;       BEN2 S1 H = L, BEN2 S0 H = H). MISMATCH L will not be asserted so the
                ;25543  ;       microcode will branch to a series of instructions that will increment
                ;25544  ;       the DAR twice. Since the DAR was loaded with 200, the expected data
                ;25545  ;       is 202.
                ;25546  ;--
                ;25547  ;*************************************************************************
                ;25548  T.2E:
U 163A, B65E,15 ;25549          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;25550                                                  ; CONTROL AND STATUS WORD
U 163B, 3E80,15 ;25551          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;25552                                                  ; STATUS WORD - BIT 15
                ;25553                                                  ; INDICATES START OF TEST TO
                ;25554                                                  ; CONSOLE
U 163C, 10E0,15 ;25555          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;25556  WAIT.T2E.0:
U 163D, 8963,D4 ;25557          JMP [WAIT.T2E.0]                        ;LOOP HERE WAITING FOR
                ;25558                                                  ; CONSOLE TO RESPOND
                ;25559
U 163E, 65A0,15 ;25560          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;25561                                                  ; IN LS
                ;25562
U 163F, B64A,15 ;25563          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1640, 3E8C,15 ;25564          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;25565
                ;25566
U 1641, B640,15 ;25567          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1642, BE82,15 ;25568          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;25569
U 1643, 3776,15 ;25570          MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK THE
U 1644, 3E8A,15 ;25571          MOV WR[0] TO LS[ERROR.MASK]             ; DAR
                ;25572
U 1645, B78E,15 ;25573          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;25574          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 1646, D94E,35 ;25575           DT(LONG)&SET.ALU.CC
U 1647, 8964,91 ;25576          JMP.IF[BIT.SET] TO [SIZE.OK.T2E.1]      ;IF YES THEN GO RUN TEST
                ;25577
U 1648, 8870,0C ;25578          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;25579
                ;25580  SIZE.OK.T2E.1:
U 1649, 8872,EC ;25581          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;25582
                ;25583          ;SELECT AN RL02 DRIVE AND SAVE THE INFO IN WR[2]
                ;25584
U 164A, B78E,15 ;25585          MOV LS[DRIVE.STATUS] TO WR[0]
                ;25586          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 164B, 5940,35 ;25587           DT(LONG)&SET.ALU.CC
U 164C, 0964,F9 ;25588          JMP.IF[BITS.CLR] TO [SET.DS0.T2E.1]     ;JMP IF DRV 0 IS NOT AN R80
U 164D, B717,15 ;25589          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 164E, 0965,04 ;25590          JMP [TEST.T2E.1]
                ;25591  SET.DS0.T2E.1:
U 164F, 3715,15 ;25592          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;25593
```

```
                ;25594  TEST.T2E.1:
U 1650, 370E,15 ;25595          MOV LS[SETCSR.F7] TO WR[0]
U 1651, 17A0,15 ;25596          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;25597                                                   ;MAINT=0,CRDY=0,F<2:0>=111
                ;25598  ;CONTINUE TO BRANCH
U 1652, 379E,15 ;25599          MOV LS[SETCSR.R80] TO WR[0]              ;SET UP THE CSR TO CONTINUE TO
U 1653, 3700,95 ;25600          MOV LS[SETCSR.F0] TO WR[1]               ; BRANCH TO THE CORRECT ROUTINE
U 1654, AEC2,15 ;25601          BIS WR[1] TO WR[0]
U 1655, 17A0,15 ;25602          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;25603                                                   ;F<2:0> = 000
                ;25604  ;UCLR MATCH
                ;25605  ;-------------------------------------------------------------------------
                ;25606  ;-------------------------------------------------------------------------
                ;25607  ;                               *******
                ;25608  ;                               * IDC *
                ;25609  ;                               *******
                ;25610  ;-------------------------------------------------------------------------
                ;25611  ;018:
                ;25612  ;=000
                ;25613  ;DIAG.IDLE:
                ;25614  ;
                ;25615  ;       BEN0/F0,
                ;25616  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;25617  ;       BEN2/F2,
                ;25618  ;       NAD/DIAG.IDLE
                ;25619  ;-------------------------------------------------------------------------
                ;25620  ;01F:
                ;25621  ;=111
                ;25622  ;
                ;25623  ;       BEN0/CRDY.L,
                ;25624  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;25625  ;       NAD/TEST.FUNC7           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;25626  ;-------------------------------------------------------------------------
                ;25627  ;079:
                ;25628  ;=0*1
                ;25629  ;
                ;25630  ;       NAD/GROUP1
                ;25631  ;-------------------------------------------------------------------------
                ;25632  ;182:
                ;25633  ;=0**
                ;25634  ;GROUP1:
                ;25635  ;
                ;25636  ;       BEN2/R80.FORMAT.H,               ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;25637  ;       NAD/GROUP1                       ; TO NEXT WORD AND THEN BRANCH ON THE
                ;25638  ;                                        ; FUNCTION BITS
                ;25639  ;-------------------------------------------------------------------------
                ;25640  ;186:
                ;25641  ;=1**
                ;25642  ;
                ;25643  ;       BEN0/F0,
                ;25644  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;25645  ;       BEN2/F2,
                ;25646  ;       NAD/GROUP1.F0
                ;25647  ;-------------------------------------------------------------------------
                ;25648  ;028:
```

```
                ;25649  ;=000
                ;25650  ;GROUP1.F0:
                ;25651  ;
                ;25652  ;CLR.MATCH.1:
                ;25653  ;
                ;25654  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
                ;25655  ;       NAD/TEST.MATCH.1
                ;25656  ;-------------------------------------------------------------------------
                ;25657  ;1F6:
                ;25658  ;TEST.MATCH.1:
                ;25659  ;
                ;25660  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
                ;25661  ;       NAD/BEN2.1
                ;25662  ;-------------------------------------------------------------------------
                ;25663  ;1A0:
                ;25664  ;=0**
                ;25665  ;BEN2.1:
                ;25666  ;
                ;25667  ;       INCR.DAR/ON,                    ;INCR DAR
                ;25668  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;25669  ;-------------------------------------------------------------------------
                ;25670  ;1A4:
                ;25671  ;=1**
                ;25672  ;BEN2.2:
                ;25673  ;
                ;25674  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;25675  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;25676  ;-------------------------------------------------------------------------
                ;25677  ;1D8:
                ;25678  ;XFER.REQ:
                ;25679  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;25680  ;       NAD/DIAG.WAIT
                ;25681  ;-------------------------------------------------------------------------
                ;25682  ;1D7:
                ;25683  ;DIAG.WAIT:
                ;25684  ;
                ;25685  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;25686  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;25687  ;-------------------------------------------------------------------------
                ;25688  ;159:
                ;25689  ;=*0*
                ;25690  ;DIAG.WAIT1:
                ;25691  ;
                ;25692  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;25693  ;                               ; COMMAND FROM THE CPU
                ;25694  ;-------------------------------------------------------------------------
                ;25695  ;15B:
                ;25696  ;=*1*
                ;25697  ;DIAG.WAIT2:
                ;25698  ;
                ;25699  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;25700  ;                               ; WAIT SOME MORE
                ;25701  ;-------------------------------------------------------------------------
                ;25702  WAIT.IDC.T2E.1:
U 1656, DB00,1A ;25703          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
```

```
U 1657, 0965,94 ;25704          JMP [IDC.DONE.T2E.1]                        ;XFER REQ SET
U 1658, 0965,64 ;25705          JMP [WAIT.IDC.T2E.1]                        ;WAIT SOME MORE
                ;25706
                ;25707  IDC.DONE.T2E.1:
U 1659, B700,15 ;25708          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 165A, 17A0,15 ;25709          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 165B, 90FA,15 ;25710          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;25711
                ;25712  LOOP.T2E.1:
U 165C, B652,15 ;25713          MOV LS[BIT9] TO WR[0]                       ;GET THE DAR DATA PATTERN
                ;25714
U 165D, 97A4,15 ;25715          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]        ;WRITE THE DAR
                ;25716
U 165E, B640,15 ;25717          MOV LS[#1] TO WR[0]                         ;GET THE DATA TO WRITE TO FIFOA
U 165F, 17D8,15 ;25718          PORT.CONTROL [SEL.FIFO.A]                   ;SELECT FIFO A
U 1660, 17C0,15 ;25719          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO A ADRS=0
U 1661, 97A8,15 ;25720          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE THE DATA TO FIFO A
                ;25721
U 1662, 17C0,15 ;25722          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET FIFO A ADRS=0
                ;25723
                ;25724  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;25725
U 1663, 370E,15 ;25726          MOV LS[SETCSR.F7] TO WR[0]
U 1664, 17A0,15 ;25727          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25728                                                      ;MAINT=0,CRDY=0,F<2:0>=111
                ;25729  ;CONTINUE TO BRANCH
U 1665, 379E,15 ;25730          MOV LS[SETCSR.R80] TO WR[0]                 ;SET UP THE CSR TO CONTINUE TO
U 1666, B704,95 ;25731          MOV LS[SETCSR.F2] TO WR[1]                  ; BRANCH TO THE CORRECT ROUTINE
U 1667, AEC2,15 ;25732          BIS WR[1] TO WR[0]
U 1668, AEC4,15 ;25733          BIS WR[2] TO WR[0]                          ;INCLUDE THE RL02 DRV SELECT
U 1669, 17A0,15 ;25734          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25735
                ;25736  ;-------------------------------------------------------------------------------
                ;25737  ;-------------------------------------------------------------------------------
                ;25738  ;                                *******
                ;25739  ;                                * IDC *
                ;25740  ;                                *******
                ;25741  ;-------------------------------------------------------------------------------
                ;25742  ;018:
                ;25743  ;=000
                ;25744  ;DIAG.IDLE:
                ;25745  ;
                ;25746  ;       BEN0/F0,
                ;25747  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
                ;25748  ;       BEN2/F2,
                ;25749  ;       NAD/DIAG.IDLE
                ;25750  ;-------------------------------------------------------------------------------
                ;25751  ;01F:
                ;25752  ;=111
                ;25753  ;
                ;25754  ;       BEN0/CRDY.L,
                ;25755  ;       BEN2/MAINT,                 ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;25756  ;       NAD/TEST.FUNC7              ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;25757  ;-------------------------------------------------------------------------------
                ;25758  ;079:
```

```
;25759  ;=0*1
;25760  ;
;25761  ;       NAD/GROUP1
;25762  ;-------------------------------------------------------------------------
;25763  ;182:
;25764  ;=0**
;25765  ;GROUP1:
;25766  ;
;25767  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;25768  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;25769  ;                                       ; FUNCTION BITS
;25770  ;-------------------------------------------------------------------------
;25771  ;186:
;25772  ;=1**
;25773  ;
;25774  ;       BEN0/F0,
;25775  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;25776  ;       BEN2/F2,
;25777  ;       NAD/GROUP1.F0
;25778  ;-------------------------------------------------------------------------
;25779  ;02A:
;25780  ;=010
;25781  ;MATCH.OR.WRTCHK.1:
;25782  ;
;25783  ;       UMAINT/ON,
;25784  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
;25785  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
;25786  ;       LOAD.LOOP.CNTR.[0E0],
;25787  ;       NAD/MATCH.OR.WRTCHK.2
;25788  ;-------------------------------------------------------------------------
;25789  ;198:
;25790  ;=0
;25791  ;MATCH.OR.WRTCHK.2:
;25792  ;
;25793  ;       UMAINT/ON,
;25794  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;25795  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;25796  ;       UCMD/SET.FIFOA,
;25797  ;       INCR.LPCNTR/ON,
;25798  ;       BEN0/CNTR.OVFLW,
;25799  ;       NAD/MATCH.OR.WRTCHK.2
;25800  ;-------------------------------------------------------------------------
;25801  ;199:
;25802  ;=1
;25803  ;MATCH.OR.WRTCHK.3:
;25804  ;
;25805  ;       UMAINT/ON,
;25806  ;       LOOP.LOCK/ON,
;25807  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;25808  ;       ENB.DSK.CLK,
;25809  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;25810  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;25811  ;-------------------------------------------------------------------------
;25812  ;1F2:
;25813  ;MATCH.OR.WRTCHK.4:
```

```
;25814  ;
;25815  ;       UMAINT/ON,
;25816  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;25817  ;       DISK.WRITE/ON,
;25818  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;25819  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;25820  ;-------------------------------------------------------------------------
;25821  ;1F3:
;25822  ;MATCH.OR.WRTCHK.5:
;25823  ;
;25824  ;       UMAINT/ON,
;25825  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;25826  ;       DISK.WRITE/ON,
;25827  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;25828  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;25829  ;-------------------------------------------------------------------------
;25830  ;1F4:
;25831  ;MATCH.OR.WRTCHK.6:
;25832  ;
;25833  ;       UMAINT/ON,
;25834  ;       LOOP.LOCK/ON,
;25835  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;25836  ;       ENB.FIFO/ON,
;25837  ;       LOAD.DSR/ON,
;25838  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;25839  ;       NAD/MATCH.OR.WRTCHK.7
;25840  ;-------------------------------------------------------------------------
;25841  ;183:
;25842  ;=0**
;25843  ;MATCH.OR.WRTCHK.7:
;25844  ;
;25845  ;       UMAINT/ON,
;25846  ;       LOOP.LOCK/ON,           ;MATCH TEST
;25847  ;       DISK.WRITE/ON,
;25848  ;       LOAD.LOOP.CNTR.[OF6],
;25849  ;       NAD/MATCH.1
;25850  ;-------------------------------------------------------------------------
;25851  ;19A:
;25852  ;=0
;25853  ;MATCH.1:
;25854  ;
;25855  ;       UMAINT/ON,
;25856  ;       LOOP.LOCK/ON,
;25857  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;25858  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;25859  ;       BEN0/CNTR.OVFLW,
;25860  ;       NAD/MATCH.1
;25861  ;-------------------------------------------------------------------------
;25862  ;19B:
;25863  ;=1
;25864  ;MATCH.2:
;25865  ;
;25866  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;25867  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;25868  ;       DISK.WRITE/ON,
```

```
;25869  ;       UCON/TEST.MATCH,
;25870  ;       NAD/MATCH.3
;25871  ;-------------------------------------------------------------------------
;25872  ;1F5:
;25873  ;MATCH.3:
;25874  ;
;25875  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;25876  ;       LOOP.LOCK/ON,                   ; GOING
;25877  ;       DISK.WRITE/ON,
;25878  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;25879  ;       NAD/TEST.MATCH.1
;25880  ;-------------------------------------------------------------------------
;25881  ;1F6:
;25882  ;TEST.MATCH.1:
;25883  ;
;25884  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;25885  ;       NAD/BEN2.1
;25886  ;-------------------------------------------------------------------------
;25887  ;1A0:
;25888  ;=0**
;25889  ;BEN2.1:
;25890  ;
;25891  ;       INCR.DAR/ON,                    ;INCR DAR
;25892  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;25893  ;-------------------------------------------------------------------------
;25894  ;1A4:
;25895  ;=1**
;25896  ;BEN2.2:
;25897  ;
;25898  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;25899  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;25900  ;-------------------------------------------------------------------------
;25901  ;1D8:
;25902  ;XFER.REQ:
;25903  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;25904  ;       NAD/DIAG.WAIT
;25905  ;-------------------------------------------------------------------------
;25906  ;1D7:
;25907  ;DIAG.WAIT:
;25908  ;
;25909  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;25910  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;25911  ;-------------------------------------------------------------------------
;25912  ;159:
;25913  ;=*0*
;25914  ;DIAG.WAIT1:
;25915  ;
;25916  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;25917  ;                               ; COMMAND FROM THE CPU
;25918  ;-------------------------------------------------------------------------
;25919  ;15B:
;25920  ;=*1*
;25921  ;DIAG.WAIT2:
;25922  ;
;25923  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
```

```
                ;25924  ;                                ; WAIT SOME MORE
                ;25925  ;-------------------------------------------------------------------------
                ;25926  WAIT.IDC.T2E.2:
U 166A, DB00,1A ;25927          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 166B, 8966,D4 ;25928          JMP [IDC.DONE.T2E.2]                        ;XFER REQ SET
U 166C, 0966,A4 ;25929          JMP [WAIT.IDC.T2E.2]                        ;WAIT SOME MORE
                ;25930
                ;25931  IDC.DONE.T2E.2:
U 166D, B700,15 ;25932          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 166E, 17A0,15 ;25933          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 166F, 90FA,15 ;25934          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;25935
                ;25936  READ.DAR.T2E.1:
U 1670, 9090,15 ;25937          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 1671, 1784,15 ;25938          PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 1672, 3B32,15 ;25939          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;25940                                                      ; SAVE IT IN  LS
U 1673, 3732,15 ;25941          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 1674, 3652,95 ;25942          MOV LS[BIT9] TO WR[1]                       ;SET UP EXPECTED DATA
U 1675, C742,95 ;25943          BIS LS[BIT1] TO WR[1]
U 1676, 0869,3C ;25944          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1677, 0965,C4 ;25945          JMP [LOOP.T2E.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;25946
                ;25947  CLEANUP.T2E:
                ;25948  ;CLR MATCH AS PART OF CLEANUP
                ;25949
U 1678, 370E,15 ;25950          MOV LS[SETCSR.F7] TO WR[0]
U 1679, 17A0,15 ;25951          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25952                                                      ;MAINT=0,CRDY=0,F<2:0>=111
                ;25953  ;CONTINUE TO BRANCH
U 167A, 379E,15 ;25954          MOV LS[SETCSR.R80] TO WR[0]                 ;SET UP THE CSR TO CONTINUE TO
U 167B, 3700,95 ;25955          MOV LS[SETCSR.F0] TO WR[1]                  ; BRANCH TO THE CORRECT ROUTINE
U 167C, AEC2,15 ;25956          BIS WR[1] TO WR[0]
U 167D, 17A0,15 ;25957          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;25958                                                      ;F<2:0> = 000
                ;25959  ;UCLR MATCH
                ;25960  ;-------------------------------------------------------------------------
                ;25961  ;-------------------------------------------------------------------------
                ;25962  ;                                *******
                ;25963  ;                                * IDC *
                ;25964  ;                                *******
                ;25965  ;-------------------------------------------------------------------------
                ;25966  ;018:
                ;25967  ;=000
                ;25968  ;DIAG.IDLE:
                ;25969  ;
                ;25970  ;       BEN0/F0,
                ;25971  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
                ;25972  ;       BEN2/F2,
                ;25973  ;       NAD/DIAG.IDLE
                ;25974  ;-------------------------------------------------------------------------
                ;25975  ;01F:
                ;25976  ;=111
                ;25977  ;
                ;25978  ;       BEN0/CRDY.L,
```

```
;25979  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;25980  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;25981  ;-------------------------------------------------------------------------
;25982  ;079:
;25983  ;=0*1
;25984  ;
;25985  ;       NAD/GROUP1
;25986  ;-------------------------------------------------------------------------
;25987  ;182:
;25988  ;=0**
;25989  ;GROUP1:
;25990  ;
;25991  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;25992  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;25993  ;                                       ; FUNCTION BITS
;25994  ;-------------------------------------------------------------------------
;25995  ;186:
;25996  ;=1**
;25997  ;
;25998  ;       BEN0/F0,
;25999  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26000  ;       BEN2/F2,
;26001  ;       NAD/GROUP1.F0
;26002  ;-------------------------------------------------------------------------
;26003  ;028:
;26004  ;=000
;26005  ;GROUP1.F0:
;26006  ;
;26007  ;CLR.MATCH.1:
;26008  ;
;26009  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;26010  ;       NAD/TEST.MATCH.1
;26011  ;-------------------------------------------------------------------------
;26012  ;1F6:
;26013  ;TEST.MATCH.1:
;26014  ;
;26015  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;26016  ;       NAD/BEN2.1
;26017  ;-------------------------------------------------------------------------
;26018  ;1A0:
;26019  ;=0**
;26020  ;BEN2.1:
;26021  ;
;26022  ;       INCR.DAR/ON,                    ;INCR DAR
;26023  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;26024  ;-------------------------------------------------------------------------
;26025  ;1A4:
;26026  ;=1**
;26027  ;BEN2.2:
;26028  ;
;26029  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;26030  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;26031  ;-------------------------------------------------------------------------
;26032  ;1D8:
;26033  ;XFER.REQ:
```

```
                    ;26034  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                    ;26035  ;       NAD/DIAG.WAIT
                    ;26036  ;-------------------------------------------------------------------------
                    ;26037  ;1D7:
                    ;26038  ;DIAG.WAIT:
                    ;26039  ;
                    ;26040  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                    ;26041  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                    ;26042  ;-------------------------------------------------------------------------
                    ;26043  ;159:
                    ;26044  ;=*0*
                    ;26045  ;DIAG.WAIT1:
                    ;26046  ;
                    ;26047  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;26048  ;                               ; COMMAND FROM THE CPU
                    ;26049  ;-------------------------------------------------------------------------
                    ;26050  ;15B:
                    ;26051  ;=*1*
                    ;26052  ;DIAG.WAIT2:
                    ;26053  ;
                    ;26054  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;26055  ;                               ; WAIT SOME MORE
                    ;26056  ;-------------------------------------------------------------------------
                    ;26057  WAIT.IDC.T2E.3:
U 167E, DB00,1A     ;26058          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 167F, 0968,14     ;26059          JMP [IDC.DONE.T2E.3]                    ;XFER REQ SET
U 1680, 0967,E4     ;26060          JMP [WAIT.IDC.T2E.3]                    ;WAIT SOME MORE
                    ;26061
                    ;26062  IDC.DONE.T2E.3:
U 1681, B700,15     ;26063          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1682, 17A0,15     ;26064          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1683, 90FA,15     ;26065          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                    ;26066
U 1684, 8875,3C     ;26067          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                    ;26068                                                  ; BY THIS TEST
                    ;26069  END.T2E:                                        ;END TEST
                    ;26070
                    ;26071
                    ;26072
                    ;26073
```

```
;26074  .PAGE  "Test 2F  CLEAR MATCH TEST (M8388 IDC MODULE)"
;26075  ;++
;26076  ;
;26077  ; Test Description:
;26078  ;
;26079  ;       This test is designed to insure that the IDC microcode will clear the
;26080  ;       MATCH condition when UCON <1:0> = 01, clear match.
;26081  ;       The data pattern to cause a match will be loaded into the FIFO and the
;26082  ;       DAR. The data will then be taken from the FIFO and shifted through the
;26083  ;       diskless loop as read data. The data will be serialized through the
;26084  ;       DAR SERIALIZER PALS. The DAR data and the read data will then be
;26085  ;       compared in the DSK RD SEQ REG PAL. This will cause a match condition
;26086  ;       (MISMATCH L = H). The microcode will execute an instruction with
;26087  ;       UCON <1:0> = 01, CLEAR MATCH. If the MISMATCH L is asserted, the DAR
;26088  ;       will be incremented once. If MISMATCH is not asserted, (a MATCH was
;26089  ;       detected) the DAR will be incremented twice. The CPU will then check
;26090  ;       the contents of the DAR.
;26091  ;
;26092  ;       Data Pattern that will cause a match:
;26093  ;
;26094  ;                               DAR             READ DATA
;26095  ;                               0200                 01
;26096  ;
;26097  ; Assumptions:
;26098  ;
;26099  ;       It is assumed that the diskless loop is fully operational and the
;26100  ;       HEADER MATCH TEST has run successfully.
;26101  ;
;26102  ; Test Steps:
;26103  ;
;26104  ;       1. Set up error mask, error number and module number in LS
;26105  ;          (for error printouts) and clear the previous error number in LS.
;26106  ;       2. Force the IDC microcode to DIAG.IDLE.
;26107  ;       3. If the drive sizing routine has not been run previously, JSR to
;26108  ;          DRIVE.SIZE.
;26109  ;       4. Select an RL02 drive.
;26110  ;       5. Load the data pattern into the DAR.
;26111  ;       6. Load the data pattern into the FIFO.
;26112  ;       7. Set up the CSR to branch to the correct IDC microcode routine.
;26113  ;
;26114  ;
;26115  ;                                       *******
;26116  ;                                       * IDC *
;26117  ;                                       *******
;26118  ;
;26119  ;               IDC1. Select the disk clock.
;26120  ;               IDC2. Send the sync character.
;26121  ;               IDC3. Follow with the data from the FIFO.
;26122  ;               IDC4. Assert UENB BC H so that the DAR will begin serializing
;26123  ;                     after sync is seen.
;26124  ;               IDC5. The above pattern should cause a match condition,
;26125  ;                     MISMATCH L = H.
;26126  ;
;26127  ;       8. Wait for a XFER REQ from IDC.
;26128  ;       9. Clear the DAR.
```

```
                ;26129  ;       10. Clear CSR F<2:0> and send XFER GRANT to clear XFER REQ.
                ;26130  ;       11. Set up the CSR to branch to the correct IDC routine.
                ;26131  ;
                ;26132  ;
                ;26133  ;                                       *******
                ;26134  ;                                       * IDC *
                ;26135  ;                                       *******
                ;26136  ;
                ;26137  ;
                ;26138  ;               IDC6. Execute an instruction with UCON <1:0> = 01, CLEAR MATCH.
                ;26139  ;               IDC7. Select BEN2/MISMATCH L.
                ;26140  ;               IDC8. If MISMATCH L is asserted (L), increment the DAR once.
                ;26141  ;                     If MISMATCH L is not asserted (a MATCH was detected)
                ;26142  ;                     then increment the DAR twice.
                ;26143  ;               IDC9. Issue XFER.REQ to flag the CPU.
                ;26144  ;
                ;26145  ;       12. Wait for a XFER.REQ from IDC.
                ;26146  ;       13. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
                ;26147  ;       14. Check the DAR = 1.
                ;26148  ;       15. Clear IDC.
                ;26149  ;       16. End test.
                ;26150  ;
                ;26151  ; Errors:
                ;26152  ;
                ;26153  ;        ERROR 1 - The BEN2/MISMATCH L branch failed or the CLEAR MATCH
                ;26154  ;                  function did not work.
                ;26155  ;
                ;26156  ;
                ;26157  ;                  Printout:
                ;26158  ;                          EXPECTED                    RECEIVED
                ;26159  ;                            DAR                         DAR
                ;26160  ; Debug:
                ;26161  ;
                ;26162  ; ERROR 1 -
                ;26163  ;       A match condition is produced between SERIAL DAR H and M.READ DATA H
                ;26164  ;       (MISMATCH L = H). The DAR is then cleared.
                ;26165  ;       The IDC will then issue an instruction with UCON <1:0> = 01(CLR.MATCH).
                ;26166  ;       These bits will be decoded by the DSK RD SEQ REG PAL and will assert
                ;26167  ;       MISMATCH L. The IDC microcode will then select BEN2/MISMATCH L.
                ;26168  ;       Since MISMATCH L = L, NUA 2 H = L and the microcode will branch to
                ;26169  ;       an instruction that will increment the DAR once.
                ;26170  ;--
                ;26171  ;*******************************************************************************
                ;26172  T.2F:
U 1685, B65E,15 ;26173          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;26174                                                  ; CONTROL AND STATUS WORD
U 1686, 3E80,15 ;26175          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;26176                                                  ; STATUS WORD - BIT 15
                ;26177                                                  ; INDICATES START OF TEST TO
                ;26178                                                  ; CONSOLE
U 1687, 10E0,15 ;26179          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;26180  WAIT.T2F.0:
U 1688, 0968,84 ;26181          JMP [WAIT.T2F.0]                        ;LOOP HERE WAITING FOR
                ;26182                                                  ; CONSOLE TO RESPOND
                ;26183
```

```
U 1689, 65A0,15 ;26184          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;26185                                                  ; IN LS
                ;26186
U 168A, B64A,15 ;26187          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 168B, 3E8C,15 ;26188          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;26189
                ;26190
U 168C, B640,15 ;26191          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 168D, BE82,15 ;26192          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;26193
U 168E, 3776,15 ;26194          MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK THE
U 168F, 3E8A,15 ;26195          MOV WR[0] TO LS[ERROR.MASK]             ; DAR
                ;26196
U 1690, B78E,15 ;26197          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;26198          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 1691, D94E,35 ;26199           DT(LONG)&SET.ALU.CC
U 1692, 8969,41 ;26200          JMP.IF[BIT.SET] TO [SIZE.OK.T2F.1]      ;IF YES THEN GO RUN TEST
                ;26201
U 1693, 8870,0C ;26202          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;26203
                ;26204  SIZE.OK.T2F.1:
U 1694, 8872,EC ;26205          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;26206
                ;26207          ;SELECT AN RL02 DRIVE AND SAVE THE INFO IN WR[2]
                ;26208
U 1695, B78E,15 ;26209          MOV LS[DRIVE.STATUS] TO WR[0]
                ;26210          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 1696, 5940,35 ;26211           DT(LONG)&SET.ALU.CC
U 1697, 8969,A9 ;26212          JMP.IF[BITS.CLR] TO [SET.DS0.T2F.1]     ;JMP IF DRV 0 IS NOT AN R80
U 1698, B717,15 ;26213          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 1699, 8969,B4 ;26214          JMP [TEST.T2F.1]
                ;26215  SET.DS0.T2F.1:
U 169A, 3715,15 ;26216          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;26217
                ;26218  TEST.T2F.1:
U 169B, B652,15 ;26219          MOV LS[BIT9] TO WR[0]                   ;GET THE DAR DATA PATTERN
                ;26220
U 169C, 97A4,15 ;26221          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DAR
                ;26222
U 169D, B640,15 ;26223          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE TO FIFOA
U 169E, 17D8,15 ;26224          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 169F, 17C0,15 ;26225          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
U 16A0, 97A8,15 ;26226          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE THE DATA TO FIFO A
                ;26227
U 16A1, 17C0,15 ;26228          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
                ;26229
                ;26230  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;26231
U 16A2, 370E,15 ;26232          MOV LS[SETCSR.F7] TO WR[0]
U 16A3, 17A0,15 ;26233          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26234                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;26235  ;CONTINUE TO BRANCH
U 16A4, 379E,15 ;26236          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 16A5, B704,95 ;26237          MOV LS[SETCSR.F2] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 16A6, AEC2,15 ;26238          BIS WR[1] TO WR[0]
```

```
U 16A7, AEC4,15 ;26239          BIS WR[2] TO WR[0]                          ;INCLUDE THE RL02 DRV SELECT
U 16A8, 17A0,15 ;26240          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;26241  ;-----------------------------------------------------------------------------
                ;26242  ;-----------------------------------------------------------------------------
                ;26243  ;                                *******
                ;26244  ;                                * IDC *
                ;26245  ;                                *******
                ;26246  ;-----------------------------------------------------------------------
                ;26247  ;018:
                ;26248  ;=000
                ;26249  ;DIAG.IDLE:
                ;26250  ;
                ;26251  ;       BEN0/F0,
                ;26252  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;26253  ;       BEN2/F2,
                ;26254  ;       NAD/DIAG.IDLE
                ;26255  ;-----------------------------------------------------------------------
                ;26256  ;01F:
                ;26257  ;=111
                ;26258  ;
                ;26259  ;       BEN0/CRDY.L,
                ;26260  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;26261  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;26262  ;-----------------------------------------------------------------------
                ;26263  ;079:
                ;26264  ;=0*1
                ;26265  ;
                ;26266  ;       NAD/GROUP1
                ;26267  ;-----------------------------------------------------------------------
                ;26268  ;182:
                ;26269  ;=0**
                ;26270  ;GROUP1:
                ;26271  ;
                ;26272  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;26273  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;26274  ;                                       ; FUNCTION BITS
                ;26275  ;-----------------------------------------------------------------------
                ;26276  ;186:
                ;26277  ;=1**
                ;26278  ;
                ;26279  ;       BEN0/F0,
                ;26280  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;26281  ;       BEN2/F2,
                ;26282  ;       NAD/GROUP1.F0
                ;26283  ;-----------------------------------------------------------------------
                ;26284  ;02A:
                ;26285  ;=010
                ;26286  ;MATCH.OR.WRTCHK.1:
                ;26287  ;
                ;26288  ;       UMAINT/ON,
                ;26289  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
                ;26290  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
                ;26291  ;       LOAD.LOOP.CNTR.[0E0],
                ;26292  ;       NAD/MATCH.OR.WRTCHK.2
                ;26293  ;-----------------------------------------------------------------------
```

```
;26294  ;198:
;26295  ;=0
;26296  ;MATCH.OR.WRTCHK.2:
;26297  ;
;26298  ;       UMAINT/ON,
;26299  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;26300  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;26301  ;       UCMD/SET.FIFOA,
;26302  ;       INCR.LPCNTR/ON,
;26303  ;       BEN0/CNTR.OVFLW,
;26304  ;       NAD/MATCH.OR.WRTCHK.2
;26305  ;-------------------------------------------------------------------------
;26306  ;199:
;26307  ;=1
;26308  ;MATCH.OR.WRTCHK.3:
;26309  ;
;26310  ;       UMAINT/ON,
;26311  ;       LOOP.LOCK/ON,
;26312  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;26313  ;       ENB.DSK.CLK,
;26314  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26315  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;26316  ;-----------------------------------------------------------------------------
;26317  ;1F2:
;26318  ;MATCH.OR.WRTCHK.4:
;26319  ;
;26320  ;       UMAINT/ON,
;26321  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;26322  ;       DISK.WRITE/ON,
;26323  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26324  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;26325  ;-----------------------------------------------------------------------------
;26326  ;1F3:
;26327  ;MATCH.OR.WRTCHK.5:
;26328  ;
;26329  ;       UMAINT/ON,
;26330  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;26331  ;       DISK.WRITE/ON,
;26332  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26333  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;26334  ;-----------------------------------------------------------------------------
;26335  ;1F4:
;26336  ;MATCH.OR.WRTCHK.6:
;26337  ;
;26338  ;       UMAINT/ON,
;26339  ;       LOOP.LOCK/ON,
;26340  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;26341  ;       ENB.FIFO/ON,
;26342  ;       LOAD.DSR/ON,
;26343  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;26344  ;       NAD/MATCH.OR.WRTCHK.7
;26345  ;-----------------------------------------------------------------------------
;26346  ;183:
;26347  ;=0**
;26348  ;MATCH.OR.WRTCHK.7:
```

```
;26349  ;
;26350  ;       UMAINT/ON,
;26351  ;       LOOP.LOCK/ON,           ;MATCH TEST
;26352  ;       DISK.WRITE/ON,
;26353  ;       LOAD.LOOP.CNTR.[0F6],
;26354  ;       NAD/MATCH.1
;26355  ;-------------------------------------------------------------------------
;26356  ;19A:
;26357  ;=0
;26358  ;MATCH.1:
;26359  ;
;26360  ;       UMAINT/ON,
;26361  ;       LOOP.LOCK/ON,
;26362  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;26363  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;26364  ;       BEN0/CNTR.OVFLW,
;26365  ;       NAD/MATCH.1
;26366  ;-------------------------------------------------------------------------
;26367  ;19B:
;26368  ;=1
;26369  ;MATCH.2:
;26370  ;
;26371  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;26372  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;26373  ;       DISK.WRITE/ON,
;26374  ;       UCON/TEST.MATCH,
;26375  ;       NAD/MATCH.3
;26376  ;-------------------------------------------------------------------------
;26377  ;1F5:
;26378  ;MATCH.3:
;26379  ;
;26380  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;26381  ;       LOOP.LOCK/ON,                   ; GOING
;26382  ;       DISK.WRITE/ON,
;26383  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;26384  ;       NAD/TEST.MATCH.1
;26385  ;-------------------------------------------------------------------------
;26386  ;1F6:
;26387  ;TEST.MATCH.1:
;26388  ;
;26389  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;26390  ;       NAD/BEN2.1
;26391  ;-------------------------------------------------------------------------
;26392  ;1A0:
;26393  ;=0**
;26394  ;BEN2.1:
;26395  ;
;26396  ;       INCR.DAR/ON,                    ;INCR DAR
;26397  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;26398  ;-------------------------------------------------------------------------
;26399  ;1A4:
;26400  ;=1**
;26401  ;BEN2.2:
;26402  ;
;26403  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
```

```
                ;26404  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;26405  ;-------------------------------------------------------------------------
                ;26406  ;1D8:
                ;26407  ;XFER.REQ:
                ;26408  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;26409  ;       NAD/DIAG.WAIT
                ;26410  ;-------------------------------------------------------------------------
                ;26411  ;1D7:
                ;26412  ;DIAG.WAIT:
                ;26413  ;
                ;26414  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;26415  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;26416  ;-------------------------------------------------------------------------
                ;26417  ;159:
                ;26418  ;=*0*
                ;26419  ;DIAG.WAIT1:
                ;26420  ;
                ;26421  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;26422  ;                               ; COMMAND FROM THE CPU
                ;26423  ;-------------------------------------------------------------------------
                ;26424  ;15B:
                ;26425  ;=*1*
                ;26426  ;DIAG.WAIT2:
                ;26427  ;
                ;26428  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;26429  ;                               ; WAIT SOME MORE
                ;26430  ;-------------------------------------------------------------------------
                ;26431  WAIT.IDC.T2F.1:
U 16A9, DB00,1A ;26432          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 16AA, 096A,C4 ;26433          JMP [IDC.DONE.T2F.1]                    ;XFER REQ SET
U 16AB, 096A,94 ;26434          JMP [WAIT.IDC.T2F.1]                    ;WAIT SOME MORE
                ;26435
                ;26436  IDC.DONE.T2F.1:
U 16AC, B700,15 ;26437          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 16AD, 17A0,15 ;26438          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 16AE, 90FA,15 ;26439          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;26440
                ;26441  LOOP.T2F.1:
                ;26442
U 16AF, 2F80,15 ;26443          CLR WR[0]                               ;GET THE DATA TO CLR THE DAR
U 16B0, 97A4,15 ;26444          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;26445
                ;26446  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;26447
U 16B1, 370E,15 ;26448          MOV LS[SETCSR.F7] TO WR[0]
U 16B2, 17A0,15 ;26449          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26450                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;26451  ;CONTINUE TO BRANCH
U 16B3, 379E,15 ;26452          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 16B4, 3700,95 ;26453          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 16B5, AEC2,15 ;26454          BIS WR[1] TO WR[0]
U 16B6, 17A0,15 ;26455          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26456                                                  ;F<2:0> = 000
                ;26457  ;UCLR MATCH
                ;26458  ;-------------------------------------------------------------------------
```

```
;26459  ;-------------------------------------------------------------------------------
;26460  ;                                *******
;26461  ;                                * IDC *
;26462  ;                                *******
;26463  ;-------------------------------------------------------------------------------
;26464  ;018:
;26465  ;=000
;26466  ;DIAG.IDLE:
;26467  ;
;26468  ;       BEN0/F0,
;26469  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26470  ;       BEN2/F2,
;26471  ;       NAD/DIAG.IDLE
;26472  ;-------------------------------------------------------------------------------
;26473  ;01F:
;26474  ;=111
;26475  ;
;26476  ;       BEN0/CRDY.L,
;26477  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;26478  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;26479  ;-------------------------------------------------------------------------------
;26480  ;079:
;26481  ;=0*1
;26482  ;
;26483  ;       NAD/GROUP1
;26484  ;-------------------------------------------------------------------------------
;26485  ;182:
;26486  ;=0**
;26487  ;GROUP1:
;26488  ;
;26489  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;26490  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;26491  ;                                       ; FUNCTION BITS
;26492  ;-------------------------------------------------------------------------------
;26493  ;186:
;26494  ;=1**
;26495  ;
;26496  ;       BEN0/F0,
;26497  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26498  ;       BEN2/F2,
;26499  ;       NAD/GROUP1.F0
;26500  ;-------------------------------------------------------------------------------
;26501  ;028:
;26502  ;=000
;26503  ;GROUP1.F0:
;26504  ;
;26505  ;CLR.MATCH.1:
;26506  ;
;26507  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;26508  ;       NAD/TEST.MATCH.1
;26509  ;-------------------------------------------------------------------------------
;26510  ;1F6:
;26511  ;TEST.MATCH.1:
;26512  ;
;26513  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
```

```
                ;26514  ;       NAD/BEN2.1
                ;26515  ;-------------------------------------------------------------------------
                ;26516  ;1A0:
                ;26517  ;=0**
                ;26518  ;BEN2.1:
                ;26519  ;
                ;26520  ;       INCR.DAR/ON,                    ;INCR DAR
                ;26521  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;26522  ;-------------------------------------------------------------------------
                ;26523  ;1A4:
                ;26524  ;=1**
                ;26525  ;BEN2.2:
                ;26526  ;
                ;26527  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;26528  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;26529  ;-------------------------------------------------------------------------
                ;26530  ;1D8:
                ;26531  ;XFER.REQ:
                ;26532  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;26533  ;       NAD/DIAG.WAIT
                ;26534  ;-------------------------------------------------------------------------
                ;26535  ;1D7:
                ;26536  ;DIAG.WAIT:
                ;26537  ;
                ;26538  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;26539  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;26540  ;-------------------------------------------------------------------------
                ;26541  ;159:
                ;26542  ;=*0*
                ;26543  ;DIAG.WAIT1:
                ;26544  ;
                ;26545  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;26546  ;                               ; COMMAND FROM THE CPU
                ;26547  ;-------------------------------------------------------------------------
                ;26548  ;15B:
                ;26549  ;=*1*
                ;26550  ;DIAG.WAIT2:
                ;26551  ;
                ;26552  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;26553  ;                               ; WAIT SOME MORE
                ;26554  ;-------------------------------------------------------------------------
                ;26555  WAIT.IDC.T2F.2:
U 16B7, DB00,1A ;26556          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 16B8, 896B,A4 ;26557          JMP [IDC.DONE.T2F.2]                    ;XFER REQ SET
U 16B9, 096B,74 ;26558          JMP [WAIT.IDC.T2F.2]                    ;WAIT SOME MORE
                ;26559
                ;26560  IDC.DONE.T2F.2:
U 16BA, B700,15 ;26561          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 16BB, 17A0,15 ;26562          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 16BC, 90FA,15 ;26563          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;26564
                ;26565  READ.DAR.T2F.1:
U 16BD, 9090,15 ;26566          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 16BE, 1784,15 ;26567          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 16BF, 3B32,15 ;26568          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
```

```
                    ;26569                                          ; SAVE IT IN  LS
U 16C0, 3732,15     ;26570          MOV LS[PORT0] TO WR[0]           ;SET UP RECEIVED DATA
U 16C1, 3640,95     ;26571          MOV LS[#1] TO WR[1]              ;SET UP EXPECTED DATA
U 16C2, 0869,3C     ;26572          JSR [CHECK.RESULT]               ;CHECK THE DATA
U 16C3, 096A,F4     ;26573          JMP [LOOP.T2F.1]                 ;LOOP HERE IF ERR & LOE IS SET
                    ;26574
U 16C4, 8875,3C     ;26575          JSR [CLEANUP]                    ;CLEANUP THE CONDITIONS SET
                    ;26576                                          ; BY THIS TEST
                    ;26577  END.T2F:                                ;END TEST
                    ;26578
                    ;26579
```

```
;26580  .PAGE  "Test 30  MISMATCH LOGIC TEST (M8388 IDC MODULE)"
;26581  ;++
;26582  ;
;26583  ; Test Description:
;26584  ;
;26585  ;       This test is designed to insure that the mismatch logic of the DSK
;26586  ;       RD SEQ REG PAL is functioning correctly. A drive with an RL02 or no
;26587  ;       disk will be selected. Because of the design of the diskless loop,
;26588  ;       DAR bit <9> is compared to RD DATA bit <0>.
;26589  ;       The data pattern will be loaded into FIFO and the DAR. The data will
;26590  ;       then be taken from the FIFO and shifted through the diskless loop as
;26591  ;       read data. The data will be serialized through the DAR SERIALIZER PALS.
;26592  ;       The DAR data and the read data will then be compared in the DSK RD
;26593  ;       SEQ REG PAL. The IDC will then do a test match. BEN2/MISMATCH L will
;26594  ;       be selected. If MISMATCH L is asserted then the DAR will be incremented
;26595  ;       once. If MISMATCH L is not asserted (a MATCH was detected), then the
;26596  ;       DAR will be incremented twice. The CPU will then check the contents
;26597  ;       of the DAR.
;26598  ;
;26599  ;       Data Patterns (2 bits):
;26600  ;
;26601  ;                                DAR             READ DATA
;26602  ;               Pattern 1:       000               01
;26603  ;               Pattern 2:       200               00
;26604  ;
;26605  ; Assumptions:
;26606  ;
;26607  ;       It is assumed that the diskless loop is fully operational and that
;26608  ;       the HEADER MATCH TEST and the CLEAR MATCH TEST have been run
;26609  ;       successfully.
;26610  ;
;26611  ; Test Steps:
;26612  ;
;26613  ;       1. Set up error mask, error number and module number in LS
;26614  ;          (for error printouts) and clear the previous error number in LS.
;26615  ;       2. Force the microcode to DIAG.IDLE.
;26616  ;       3. If the drive sizing routine has not been run previously, JSR to
;26617  ;          DRIVE.SIZE.
;26618  ;       4. Set up the CSR to branch to the correct IDC microcode routine.
;26619  ;
;26620  ;
;26621  ;                                       *******
;26622  ;                                       * IDC *
;26623  ;                                       *******
;26624  ;
;26625  ;               IDC1. Clear match.
;26626  ;               IDC2. Send XFER REQ to flag the CPU.
;26627  ;
;26628  ;       5. Wait for a XFER.REQ from IDC.
;26629  ;       6. Clear CSR <2:0> and issue XFER GRANT to clear the XFER.REQ.
;26630  ;       7. Select an RL02 drive.
;26631  ;       8. Load the data pattern into the DAR.
;26632  ;       9. Load the data pattern into the FIFO.
;26633  ;      10. Set up the CSR to branch to the correct IDC microcode routine.
;26634  ;
```

```
;26635  ;                                       *******
;26636  ;                                       * IDC *
;26637  ;                                       *******
;26638  ;
;26639  ;
;26640  ;               IDC3. Select the disk clock.
;26641  ;               IDC4. Shift out the sync character.
;26642  ;               IDC5. Follow with the data from the FIFO.
;26643  ;               IDC6. Assert UENB BC H so that the DAR will begin serializing
;26644  ;                     after sync is seen.
;26645  ;               IDC7. Execute an instruction with UCON <1:0> = 10, TEST MATCH.
;26646  ;               IDC8. Select the CPU clock.
;26647  ;               IDC9. Select BEN2/MISMATCH L.
;26648  ;               IDC10. If MISMATCH L is asserted then increment the DAR once.
;26649  ;                      If MISMATCH L is not asserted (a MATCH was detected)
;26650  ;                      increment the DAR twice.
;26651  ;               IDC11. Issue XFER.REQ to flag the CPU.
;26652  ;
;26653  ;       11. Wait for a XFER.REQ from IDC.
;26654  ;       12. Clear CSR <2:0> and issue XFER GRANT to clear the XFER.REQ.
;26655  ;       13. Check the DAR = 1.
;26656  ;       14. Increment the error number.
;26657  ;       15. Repeat Steps 4 - 12 for Data Pattern 2.
;26658  ;       16. Check the DAR = 201. (The DAR was loaded with 200 and should be
;26659  ;                                 incremented once)
;26660  ;       17. Clear Match.
;26661  ;       18. Clear IDC.
;26662  ;       19. End test.
;26663  ;
;26664  ; Errors:
;26665  ;
;26666  ;
;26667  ;                   Printout:
;26668  ;                                 EXPECTED                RECEIVED
;26669  ;                                   DAR                     DAR
;26670  ;
;26671  ;       ERROR 1 - The mismatch logic failed with DAR = 000 and READ DATA = 001.
;26672  ;
;26673  ;       ERROR 2 - The mismatch logic failed with DAR = 200 and READ DATA = 000.
;26674  ;
;26675  ; Debug:
;26676  ;
;26677  ; ERROR 1 -
;26678  ;
;26679  ;       The data pattern is loaded into the DAR and into FIFO A address 0.
;26680  ;       A line with no disk drive attached or with an RL02 drive attched is
;26681  ;       selected and will assert RL02 H and deassert R80 H. The IDC will
;26682  ;       branch to a routine that will load the data from FIFO A address 0, into
;26683  ;       the DSR. This data is then shifted through the RL02 diskless loop to
;26684  ;       become READ DATA H (see RL02 DATA PATH TESTS if diskless loop is not
;26685  ;       functioning correctly). READ DATA H is an input to the SERIAL DAR LO
;26686  ;       PAL and it becomes M.READ DATA H. This signal is an input to the
;26687  ;       DSK RD SEQ REG PAL.
;26688  ;       As this data is being shifted through the diskless loop, the DAR data
;26689  ;       is being serialized. The BIT COUNTER PAL is cleared when ENB CLR BC H
```

```
                ;26690  ;       is asserted from the IDC microword when SYNC SEEN L.
                ;26691  ;       R80 H will not be asserted at this time so the DAR will be serialized
                ;26692  ;       in order, starting with Bit <0> up to Bit <18>. For example:
                ;26693  ;       when the bit couter = 2, bit 2 of the DAR will be output as MUX DAR H.
                ;26694  ;       The serializing is done in the BIT COUNTER PAL and the SERIAL DAR LO
                ;26695  ;       and SERIAL DAR HI PALS.
                ;26696  ;       At the DSK RD SEQ REG PAL, SYNC SEEN L will be asserted at the next
                ;26697  ;       CURRENT CLK H after SEL DSK CLK H = H and BYTE COMPARE H = H. After
                ;26698  ;       SYNC SEEN L is asserted, COMPARE L will assert when SERIAL DAR H =
                ;26699  ;       M.READ DATA H with UWRT CHK H = L. COMPARE L will assert on the first
                ;26700  ;       match of SERIAL DAR H and  M.READ DATA H and will remain asserted
                ;26701  ;       until a mismatch is encountered. Bits <8:0> of the DAR which are all
                ;26702  ;       zeros will be compared to zeros coming in as M.READ DATA H. When bit
                ;26703  ;       <9> of the DAR is selected,  Bit <0> of the data which was loaded into
                ;26704  ;       FIFO A will be M.READ DATA H, and this should cause a mismatch which
                ;26705  ;       will deassert COMPARE L.
                ;26706  ;       The IDC will then issue an instruction with UCON <1:0> = 10. These bits
                ;26707  ;       will be decoded by the DSK RD SEQ REG PAL to perform a TEST.MATCH.
                ;26708  ;       COMPARE L = H at this time, so MISMATCH L = L.
                ;26709  ;       The IDC microcode will then select BEN2/MISMATCH L (BEN2 S2 H = L,
                ;26710  ;       BEN2 S1 H = L, BEN2 S0 H = H). MISMATCH L will be asserted so the
                ;26711  ;       microcode will branch to an instruction that will increment
                ;26712  ;       the DAR.
                ;26713  ;--
                ;26714  ;*******************************************************************************
                ;26715  T.30:
U 16C5, B65E,15 ;26716          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;26717                                                  ; CONTROL AND STATUS WORD
U 16C6, 3E80,15 ;26718          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;26719                                                  ; STATUS WORD - BIT 15
                ;26720                                                  ; INDICATES START OF TEST TO
                ;26721                                                  ; CONSOLE
U 16C7, 10E0,15 ;26722          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;26723  WAIT.T30.0:
U 16C8, 896C,84 ;26724          JMP [WAIT.T30.0]                        ;LOOP HERE WAITING FOR
                ;26725                                                  ; CONSOLE TO RESPOND
                ;26726
U 16C9, 65A0,15 ;26727          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;26728                                                  ; IN LS
                ;26729
U 16CA, B64A,15 ;26730          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 16CB, 3E8C,15 ;26731          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;26732
                ;26733
U 16CC, B640,15 ;26734          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 16CD, BE82,15 ;26735          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;26736
U 16CE, 3776,15 ;26737          MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK THE
U 16CF, 3E8A,15 ;26738          MOV WR[0] TO LS[ERROR.MASK]             ; DAR
                ;26739
U 16D0, B78E,15 ;26740          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;26741          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 16D1, D94E,35 ;26742           DT(LONG)&SET.ALU.CC
U 16D2, 096D,41 ;26743          JMP.IF[BIT.SET] TO [SIZE.OK.T30.1]      ;IF YES THEN GO RUN TEST
                ;26744
```

```
U 16D3, 8870,0C ;26745          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;26746
                ;26747  SIZE.OK.T30.1:
U 16D4, 8872,EC ;26748          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;26749
                ;26750          ;SELECT AN RL02 DRIVE AND SAVE THE INFO IN WR[2]
                ;26751
U 16D5, B78E,15 ;26752          MOV LS[DRIVE.STATUS] TO WR[0]
                ;26753          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 16D6, 5940,35 ;26754           DT(LONG)&SET.ALU.CC
U 16D7, 096D,A9 ;26755          JMP.IF[BITS.CLR] TO [SET.DS0.T30.1]     ;JMP IF DRV 0 IS NOT AN R80
U 16D8, B717,15 ;26756          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 16D9, 096D,B4 ;26757          JMP [TEST.T30.1]
                ;26758  SET.DS0.T30.1:
U 16DA, 3715,15 ;26759          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;26760
                ;26761  TEST.T30.1:
                ;26762  LOOP.T30.1:
U 16DB, 370E,15 ;26763          MOV LS[SETCSR.F7] TO WR[0]
U 16DC, 17A0,15 ;26764          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26765                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 16DD, 379E,15 ;26766          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 16DE, 3700,95 ;26767          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 16DF, AEC2,15 ;26768          BIS WR[1] TO WR[0]
U 16E0, 17A0,15 ;26769          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26770                                                  ;F<2:0> = 000
                ;26771  ;UCLR MATCH
                ;26772  ;-------------------------------------------------------------------------------
                ;26773  ;-------------------------------------------------------------------------------
                ;26774  ;                               *******
                ;26775  ;                               * IDC *
                ;26776  ;                               *******
                ;26777  ;-------------------------------------------------------------------------------
                ;26778  ;018:
                ;26779  ;=000
                ;26780  ;DIAG.IDLE:
                ;26781  ;
                ;26782  ;       BEN0/F0,
                ;26783  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;26784  ;       BEN2/F2,
                ;26785  ;       NAD/DIAG.IDLE
                ;26786  ;-------------------------------------------------------------------------------
                ;26787  ;01F:
                ;26788  ;=111
                ;26789  ;
                ;26790  ;       BEN0/CRDY.L,
                ;26791  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;26792  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;26793  ;-------------------------------------------------------------------------------
                ;26794  ;079:
                ;26795  ;=0*1
                ;26796  ;
                ;26797  ;       NAD/GROUP1
                ;26798  ;-------------------------------------------------------------------------------
                ;26799  ;182:
```

```
;26800  ;=0**
;26801  ;GROUP1:
;26802  ;
;26803  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;26804  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;26805  ;                                       ; FUNCTION BITS
;26806  ;-----------------------------------------------------------------------
;26807  ;186:
;26808  ;=1**
;26809  ;
;26810  ;       BEN0/F0,
;26811  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26812  ;       BEN2/F2,
;26813  ;       NAD/GROUP1.F0
;26814  ;-----------------------------------------------------------------------
;26815  ;028:
;26816  ;=000
;26817  ;GROUP1.F0:
;26818  ;
;26819  ;CLR.MATCH.1:
;26820  ;
;26821  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;26822  ;       NAD/TEST.MATCH.1
;26823  ;-----------------------------------------------------------------------
;26824  ;1F6:
;26825  ;TEST.MATCH.1:
;26826  ;
;26827  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;26828  ;       NAD/BEN2.1
;26829  ;-----------------------------------------------------------------------
;26830  ;1A0:
;26831  ;=0**
;26832  ;BEN2.1:
;26833  ;
;26834  ;       INCR.DAR/ON,                    ;INCR DAR
;26835  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;26836  ;-----------------------------------------------------------------------
;26837  ;1A4:
;26838  ;=1**
;26839  ;BEN2.2:
;26840  ;
;26841  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;26842  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;26843  ;-----------------------------------------------------------------------
;26844  ;1D8:
;26845  ;XFER.REQ:
;26846  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;26847  ;       NAD/DIAG.WAIT
;26848  ;-----------------------------------------------------------------------
;26849  ;1D7:
;26850  ;DIAG.WAIT:
;26851  ;
;26852  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;26853  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;26854  ;-----------------------------------------------------------------------
```

```
                ;26855  ;159:
                ;26856  ;=*0*
                ;26857  ;DIAG.WAIT1:
                ;26858  ;
                ;26859  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;26860  ;                               ; COMMAND FROM THE CPU
                ;26861  ;-------------------------------------------------------------------------
                ;26862  ;15B:
                ;26863  ;=*1*
                ;26864  ;DIAG.WAIT2:
                ;26865  ;
                ;26866  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;26867  ;                               ; WAIT SOME MORE
                ;26868  ;-------------------------------------------------------------------------
                ;26869  WAIT.IDC.T30.1:
U 16E1, DB00,1A ;26870          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 16E2, 096E,44 ;26871          JMP [IDC.DONE.T30.1]                    ;XFER REQ SET
U 16E3, 096E,14 ;26872          JMP [WAIT.IDC.T30.1]                    ;WAIT SOME MORE
                ;26873
                ;26874  IDC.DONE.T30.1:
U 16E4, B700,15 ;26875          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 16E5, 17A0,15 ;26876          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 16E6, 90FA,15 ;26877          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;26878
U 16E7, 2F80,15 ;26879          CLR WR[0]                               ;GET THE DATA TO WRITE TO DAR
U 16E8, 97A4,15 ;26880          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLR THE DAR
                ;26881
U 16E9, B640,15 ;26882          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE TO FIFOA
U 16EA, 17D8,15 ;26883          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 16EB, 17C0,15 ;26884          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
U 16EC, 97A8,15 ;26885          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE THE DATA TO FIFO A
                ;26886
U 16ED, 17C0,15 ;26887          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
                ;26888
                ;26889  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;26890
U 16EE, 370E,15 ;26891          MOV LS[SETCSR.F7] TO WR[0]
U 16EF, 17A0,15 ;26892          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26893                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 16F0, 379E,15 ;26894          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 16F1, B704,95 ;26895          MOV LS[SETCSR.F2] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 16F2, AEC2,15 ;26896          BIS WR[1] TO WR[0]
U 16F3, AEC4,15 ;26897          BIS WR[2] TO WR[0]                      ;INCLUDE THE RL02 DRV SELECT
U 16F4, 17A0,15 ;26898          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;26899
                ;26900  ;-------------------------------------------------------------------------
                ;26901  ;-------------------------------------------------------------------------
                ;26902  ;                               *******
                ;26903  ;                               * IDC *
                ;26904  ;                               *******
                ;26905  ;-------------------------------------------------------------------------
                ;26906  ;018:
                ;26907  ;=000
                ;26908  ;DIAG.IDLE:
                ;26909  ;
```

```
;26910  ;       BEN0/F0,
;26911  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26912  ;       BEN2/F2,
;26913  ;       NAD/DIAG.IDLE
;26914  ;-------------------------------------------------------------------------
;26915  ;01F:
;26916  ;=111
;26917  ;
;26918  ;       BEN0/CRDY.L,
;26919  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;26920  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;26921  ;-------------------------------------------------------------------------
;26922  ;079:
;26923  ;=0*1
;26924  ;
;26925  ;       NAD/GROUP1
;26926  ;-------------------------------------------------------------------------
;26927  ;182:
;26928  ;=0**
;26929  ;GROUP1:
;26930  ;
;26931  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;26932  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;26933  ;                                       ; FUNCTION BITS
;26934  ;-------------------------------------------------------------------------
;26935  ;186:
;26936  ;=1**
;26937  ;
;26938  ;       BEN0/F0,
;26939  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;26940  ;       BEN2/F2,
;26941  ;       NAD/GROUP1.F0
;26942  ;-------------------------------------------------------------------------
;26943  ;02A:
;26944  ;=010
;26945  ;MATCH.OR.WRTCHK.1:
;26946  ;
;26947  ;       UMAINT/ON,
;26948  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
;26949  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSRO
;26950  ;       LOAD.LOOP.CNTR.[0E0],
;26951  ;       NAD/MATCH.OR.WRTCHK.2
;26952  ;-------------------------------------------------------------------------
;26953  ;198:
;26954  ;=0
;26955  ;MATCH.OR.WRTCHK.2:
;26956  ;
;26957  ;       UMAINT/ON,
;26958  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;26959  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;26960  ;       UCMD/SET.FIFOA,
;26961  ;       INCR.LPCNTR/ON,
;26962  ;       BEN0/CNTR.OVFLW,
;26963  ;       NAD/MATCH.OR.WRTCHK.2
;26964  ;-------------------------------------------------------------------------
```

```
;26965  ;199:
;26966  ;=1
;26967  ;MATCH.OR.WRTCHK.3:
;26968  ;
;26969  ;       UMAINT/ON,
;26970  ;       LOOP.LOCK/ON,
;26971  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;26972  ;       ENB.DSK.CLK,
;26973  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26974  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;26975  ;-------------------------------------------------------------------------------
;26976  ;1F2:
;26977  ;MATCH.OR.WRTCHK.4:
;26978  ;
;26979  ;       UMAINT/ON,
;26980  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;26981  ;       DISK.WRITE/ON,
;26982  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26983  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;26984  ;-------------------------------------------------------------------------------
;26985  ;1F3:
;26986  ;MATCH.OR.WRTCHK.5:
;26987  ;
;26988  ;       UMAINT/ON,
;26989  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;26990  ;       DISK.WRITE/ON,
;26991  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;26992  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;26993  ;-------------------------------------------------------------------------------
;26994  ;1F4:
;26995  ;MATCH.OR.WRTCHK.6:
;26996  ;
;26997  ;       UMAINT/ON,
;26998  ;       LOOP.LOCK/ON,
;26999  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;27000  ;       ENB.FIFO/ON,
;27001  ;       LOAD.DSR/ON,
;27002  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;27003  ;       NAD/MATCH.OR.WRTCHK.7
;27004  ;-------------------------------------------------------------------------------
;27005  ;183:
;27006  ;=0**
;27007  ;MATCH.OR.WRTCHK.7:
;27008  ;
;27009  ;       UMAINT/ON,
;27010  ;       LOOP.LOCK/ON,           ;MATCH TEST
;27011  ;       DISK.WRITE/ON,
;27012  ;       LOAD.LOOP.CNTR.[OF6],
;27013  ;       NAD/MATCH.1
;27014  ;-------------------------------------------------------------------------------
;27015  ;19A:
;27016  ;=0
;27017  ;MATCH.1:
;27018  ;
;27019  ;       UMAINT/ON,
```

```
;27020  ;       LOOP.LOCK/ON,
;27021  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;27022  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;27023  ;       BEN0/CNTR.OVFLW,
;27024  ;       NAD/MATCH.1
;27025  ;-------------------------------------------------------------------------
;27026  ;19B:
;27027  ;=1
;27028  ;MATCH.2:
;27029  ;
;27030  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;27031  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;27032  ;       DISK.WRITE/ON,
;27033  ;       UCON/TEST.MATCH,
;27034  ;       NAD/MATCH.3
;27035  ;-------------------------------------------------------------------------
;27036  ;1F5:
;27037  ;MATCH.3:
;27038  ;
;27039  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;27040  ;       LOOP.LOCK/ON,                   ; GOING
;27041  ;       DISK.WRITE/ON,
;27042  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;27043  ;       NAD/TEST.MATCH.1
;27044  ;-------------------------------------------------------------------------
;27045  ;1F6:
;27046  ;TEST.MATCH.1:
;27047  ;
;27048  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;27049  ;       NAD/BEN2.1
;27050  ;-------------------------------------------------------------------------
;27051  ;1A0:
;27052  ;=0**
;27053  ;BEN2.1:
;27054  ;
;27055  ;       INCR.DAR/ON,                    ;INCR DAR
;27056  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;27057  ;-------------------------------------------------------------------------
;27058  ;1A4:
;27059  ;=1**
;27060  ;BEN2.2:
;27061  ;
;27062  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;27063  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;27064  ;-------------------------------------------------------------------------
;27065  ;1D8:
;27066  ;XFER.REQ:
;27067  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;27068  ;       NAD/DIAG.WAIT
;27069  ;-------------------------------------------------------------------------
;27070  ;1D7:
;27071  ;DIAG.WAIT:
;27072  ;
;27073  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;27074  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
```

```
                ;27075  ;-------------------------------------------------------------------------
                ;27076  ;159:
                ;27077  ;=*0*
                ;27078  ;DIAG.WAIT1:
                ;27079  ;
                ;27080  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;27081  ;                               ; COMMAND FROM THE CPU
                ;27082  ;-------------------------------------------------------------------------
                ;27083  ;15B:
                ;27084  ;=*1*
                ;27085  ;DIAG.WAIT2:
                ;27086  ;
                ;27087  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;27088  ;                               ; WAIT SOME MORE
                ;27089  ;-------------------------------------------------------------------------
                ;27090  WAIT.IDC.T30.2:
U 16F5, DB00,1A ;27091          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 16F6, 896F,84 ;27092          JMP [IDC.DONE.T30.2]                    ;XFER REQ SET
U 16F7, 096F,54 ;27093          JMP [WAIT.IDC.T30.2]                    ;WAIT SOME MORE
                ;27094
                ;27095  IDC.DONE.T30.2:
U 16F8, B700,15 ;27096          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 16F9, 17A0,15 ;27097          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 16FA, 90FA,15 ;27098          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;27099
                ;27100  READ.DAR.T30.1:
U 16FB, 9090,15 ;27101          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 16FC, 1784,15 ;27102          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 16FD, 3B32,15 ;27103          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;27104                                                  ; SAVE IT IN  LS
U 16FE, 3732,15 ;27105          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 16FF, 3640,95 ;27106          MOV LS[#1] TO WR[1]                     ;SET UP EXPECTED DATA
U 1700, 0869,3C ;27107          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1701, 096D,B4 ;27108          JMP [LOOP.T30.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;27109
U 1702, FF82,15 ;27110          INC LS[ERROR.NUMBER]                    ;ERROR 2
                ;27111
                ;27112  ;SET UP THE CSR TO FORCE THE IDC TO CLR MATCH
                ;27113
                ;27114  LOOP.T30.2:
U 1703, 370E,15 ;27115          MOV LS[SETCSR.F7] TO WR[0]
U 1704, 17A0,15 ;27116          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27117                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 1705, 379E,15 ;27118          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 1706, 3700,95 ;27119          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 1707, AEC2,15 ;27120          BIS WR[1] TO WR[0]
U 1708, 17A0,15 ;27121          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27122                                                  ;F<2:0> = 000
                ;27123  ;UCLR MATCH
                ;27124  ;-------------------------------------------------------------------------
                ;27125  ;-------------------------------------------------------------------------
                ;27126  ;                               *******
                ;27127  ;                               * IDC *
                ;27128  ;                               *******
                ;27129  ;-------------------------------------------------------------------------
```

```
;27130  ;018:
;27131  ;=000
;27132  ;DIAG.IDLE:
;27133  ;
;27134  ;       BEN0/F0,
;27135  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;27136  ;       BEN2/F2,
;27137  ;       NAD/DIAG.IDLE
;27138  ;-----------------------------------------------------------------------
;27139  ;01F:
;27140  ;=111
;27141  ;
;27142  ;       BEN0/CRDY.L,
;27143  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;27144  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;27145  ;-----------------------------------------------------------------------
;27146  ;079:
;27147  ;=0*1
;27148  ;
;27149  ;       NAD/GROUP1
;27150  ;-----------------------------------------------------------------------
;27151  ;182:
;27152  ;=0**
;27153  ;GROUP1:
;27154  ;
;27155  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;27156  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;27157  ;                                       ; FUNCTION BITS
;27158  ;-----------------------------------------------------------------------
;27159  ;186:
;27160  ;=1**
;27161  ;
;27162  ;       BEN0/F0,
;27163  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;27164  ;       BEN2/F2,
;27165  ;       NAD/GROUP1.F0
;27166  ;-----------------------------------------------------------------------
;27167  ;028:
;27168  ;=000
;27169  ;GROUP1.F0:
;27170  ;
;27171  ;CLR.MATCH.1:
;27172  ;
;27173  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;27174  ;       NAD/TEST.MATCH.1
;27175  ;-----------------------------------------------------------------------
;27176  ;1F6:
;27177  ;TEST.MATCH.1:
;27178  ;
;27179  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;27180  ;       NAD/BEN2.1
;27181  ;-----------------------------------------------------------------------
;27182  ;1A0:
;27183  ;=0**
;27184  ;BEN2.1:
```

```
                ;27185  ;
                ;27186  ;       INCR.DAR/ON,                    ;INCR DAR
                ;27187  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;27188  ;-------------------------------------------------------------------
                ;27189  ;1A4:
                ;27190  ;=1**
                ;27191  ;BEN2.2:
                ;27192  ;
                ;27193  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;27194  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;27195  ;-------------------------------------------------------------------
                ;27196  ;1D8:
                ;27197  ;XFER.REQ:
                ;27198  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;27199  ;       NAD/DIAG.WAIT
                ;27200  ;-------------------------------------------------------------------
                ;27201  ;1D7:
                ;27202  ;DIAG.WAIT:
                ;27203  ;
                ;27204  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;27205  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;27206  ;-------------------------------------------------------------------
                ;27207  ;159:
                ;27208  ;=*0*
                ;27209  ;DIAG.WAIT1:
                ;27210  ;
                ;27211  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;27212  ;                               ; COMMAND FROM THE CPU
                ;27213  ;-------------------------------------------------------------------
                ;27214  ;15B:
                ;27215  ;=*1*
                ;27216  ;DIAG.WAIT2:
                ;27217  ;
                ;27218  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;27219  ;                               ; WAIT SOME MORE
                ;27220  ;-------------------------------------------------------------------
                ;27221  WAIT.IDC.T30.3:
U 1709, DB00,1A ;27222          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 170A, 8970,C4 ;27223          JMP [IDC.DONE.T30.3]                    ;XFER REQ SET
U 170B, 8970,94 ;27224          JMP [WAIT.IDC.T30.3]                    ;WAIT SOME MORE
                ;27225
                ;27226  IDC.DONE.T30.3:
U 170C, B700,15 ;27227          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 170D, 17A0,15 ;27228          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 170E, 90FA,15 ;27229          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;27230
                ;27231
U 170F, B652,15 ;27232          MOV LS[BIT9] TO WR[0]                   ;GET THE DATA TO WRITE TO DAR
U 1710, 97A4,15 ;27233          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DAR = 200
                ;27234
U 1711, 2F80,15 ;27235          CLR WR[0]                               ;GET THE DATA TO WRITE TO FIFOA
U 1712, 17D8,15 ;27236          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1713, 17C0,15 ;27237          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
U 1714, 97A8,15 ;27238          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE THE DATA TO FIFO A
                ;27239
```

```
U 1715, 17C0,15 ;27240          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
                ;27241
                ;27242  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;27243
U 1716, 370E,15 ;27244          MOV LS[SETCSR.F7] TO WR[0]
U 1717, 17A0,15 ;27245          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27246                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 1718, 379E,15 ;27247          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 1719, B704,95 ;27248          MOV LS[SETCSR.F2] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 171A, AEC2,15 ;27249          BIS WR[1] TO WR[0]
U 171B, AEC4,15 ;27250          BIS WR[2] TO WR[0]                      ;INCLUDE THE RL02 DRV SELECT
U 171C, 17A0,15 ;27251          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27252
                ;27253  ;-------------------------------------------------------------------------
                ;27254  ;-------------------------------------------------------------------------
                ;27255  ;                               *******
                ;27256  ;                               * IDC *
                ;27257  ;                               *******
                ;27258  ;-----------------------------------------------------------------------
                ;27259  ;018:
                ;27260  ;=000
                ;27261  ;DIAG.IDLE:
                ;27262  ;
                ;27263  ;       BEN0/F0,
                ;27264  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;27265  ;       BEN2/F2,
                ;27266  ;       NAD/DIAG.IDLE
                ;27267  ;-----------------------------------------------------------------------
                ;27268  ;01F:
                ;27269  ;=!11
                ;27270  ;
                ;27271  ;       BEN0/CRDY.L,
                ;27272  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;27273  ;       NAD/TEST.FUNC?          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;27274  ;-----------------------------------------------------------------------
                ;27275  ;079:
                ;27276  ;=0*1
                ;27277  ;
                ;27278  ;       NAD/GROUP1
                ;27279  ;-----------------------------------------------------------------------
                ;27280  ;182:
                ;27281  ;=0**
                ;27282  ;GROUP1:
                ;27283  ;
                ;27284  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;27285  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;27286  ;                                       ; FUNCTION BITS
                ;27287  ;-----------------------------------------------------------------------
                ;27288  ;186:
                ;27289  ;=1**
                ;27290  ;
                ;27291  ;       BEN0/F0,
                ;27292  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;27293  ;       BEN2/F2,
                ;27294  ;       NAD/GROUP1.F0
```

```
;27295  ;-------------------------------------------------------------------------
;27296  ;02A:
;27297  ;=010
;27298  ;MATCH.OR.WRTCHK.1:
;27299  ;
;27300  ;       UMAINT/ON,
;27301  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
;27302  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
;27303  ;       LOAD.LOOP.CNTR.[0E0],
;27304  ;       NAD/MATCH.OR.WRTCHK.2
;27305  ;-------------------------------------------------------------------------
;27306  ;198:
;27307  ;=0
;27308  ;MATCH.OR.WRTCHK.2:
;27309  ;
;27310  ;       UMAINT/ON,
;27311  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;27312  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;27313  ;       UCMD/SET.FIFOA,
;27314  ;       INCR.LPCNTR/ON,
;27315  ;       BEN0/CNTR.OVFLW,
;27316  ;       NAD/MATCH.OR.WRTCHK.2
;27317  ;-------------------------------------------------------------------------
;27318  ;199:
;27319  ;=1
;27320  ;MATCH.OR.WRTCHK.3:
;27321  ;
;27322  ;       UMAINT/ON,
;27323  ;       LOOP.LOCK/ON,
;27324  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;27325  ;       ENB.DSK.CLK,
;27326  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27327  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;27328  ;-------------------------------------------------------------------------
;27329  ;1F2:
;27330  ;MATCH.OR.WRTCHK.4:
;27331  ;
;27332  ;       UMAINT/ON,
;27333  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;27334  ;       DISK.WRITE/ON,
;27335  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27336  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;27337  ;-------------------------------------------------------------------------
;27338  ;1F3:
;27339  ;MATCH.OR.WRTCHK.5:
;27340  ;
;27341  ;       UMAINT/ON,
;27342  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;27343  ;       DISK.WRITE/ON,
;27344  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27345  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;27346  ;-------------------------------------------------------------------------
;27347  ;1F4:
;27348  ;MATCH.OR.WRTCHK.6:
;27349  ;
```

```
;27350  ;       UMAINT/ON,
;27351  ;       LOOP.LOCK/ON,
;27352  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;27353  ;       ENB.FIFO/ON,
;27354  ;       LOAD.DSR/ON,
;27355  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;27356  ;       NAD/MATCH.OR.WRTCHK.7
;27357  ;-----------------------------------------------------------------------------
;27358  ;183:
;27359  ;=0**
;27360  ;MATCH.OR.WRTCHK.7:
;27361  ;
;27362  ;       UMAINT/ON,
;27363  ;       LOOP.LOCK/ON,           ;MATCH TEST
;27364  ;       DISK.WRITE/ON,
;27365  ;       LOAD.LOOP.CNTR.[0F6],
;27366  ;       NAD/MATCH.1
;27367  ;-----------------------------------------------------------------------------
;27368  ;19A:
;27369  ;=0
;27370  ;MATCH.1:
;27371  ;
;27372  ;       UMAINT/ON,
;27373  ;       LOOP.LOCK/ON,
;27374  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;27375  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;27376  ;       BEN0/CNTR.OVFLW,
;27377  ;       NAD/MATCH.1
;27378  ;-----------------------------------------------------------------------------
;27379  ;19B:
;27380  ;=1
;27381  ;MATCH.2:
;27382  ;
;27383  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;27384  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;27385  ;       DISK.WRITE/ON,
;27386  ;       UCON/TEST.MATCH,
;27387  ;       NAD/MATCH.3
;27388  ;-----------------------------------------------------------------------------
;27389  ;1F5:
;27390  ;MATCH.3:
;27391  ;
;27392  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;27393  ;       LOOP.LOCK/ON,                   ; GOING
;27394  ;       DISK.WRITE/ON,
;27395  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;27396  ;       NAD/TEST.MATCH.1
;27397  ;-----------------------------------------------------------------------------
;27398  ;1F6:
;27399  ;TEST.MATCH.1:
;27400  ;
;27401  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;27402  ;       NAD/BEN2.1
;27403  ;-----------------------------------------------------------------------------
;27404  ;1A0:
```

```
                ;27405  ;=0**
                ;27406  ;BEN2.1:
                ;27407  ;
                ;27408  ;       INCR.DAR/ON,                    ;INCR DAR
                ;27409  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;27410  ;-------------------------------------------------------------------
                ;27411  ;1A4:
                ;27412  ;=1**
                ;27413  ;BEN2.2:
                ;27414  ;
                ;27415  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;27416  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;27417  ;-------------------------------------------------------------------
                ;27418  ;1D8:
                ;27419  ;XFER.REQ:
                ;27420  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;27421  ;       NAD/DIAG.WAIT
                ;27422  ;-------------------------------------------------------------------
                ;27423  ;1D7:
                ;27424  ;DIAG.WAIT:
                ;27425  ;
                ;27426  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;27427  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;27428  ;-------------------------------------------------------------------
                ;27429  ;159:
                ;27430  ;=*0*
                ;27431  ;DIAG.WAIT1:
                ;27432  ;
                ;27433  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;27434  ;                               ; COMMAND FROM THE CPU
                ;27435  ;-------------------------------------------------------------------
                ;27436  ;15B:
                ;27437  ;=*1*
                ;27438  ;DIAG.WAIT2:
                ;27439  ;
                ;27440  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;27441  ;                               ; WAIT SOME MORE
                ;27442  ;-------------------------------------------------------------------
                ;27443  WAIT.IDC.T30.4:
U 171D, DB00,1A ;27444          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 171E, 0972,04 ;27445          JMP [IDC.DONE.T30.4]                    ;XFER REQ SET
U 171F, 8971,D4 ;27446          JMP [WAIT.IDC.T30.4]                    ;WAIT SOME MORE
                ;27447
                ;27448  IDC.DONE.T30.4:
U 1720, B700,15 ;27449          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1721, 17A0,15 ;27450          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1722, 90FA,15 ;27451          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;27452
                ;27453  READ.DAR.T30.2:
U 1723, 9090,15 ;27454          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1724, 1784,15 ;27455          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 1725, 3B32,15 ;27456          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;27457                                                  ; SAVE IT IN  LS
U 1726, 3732,15 ;27458          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1727, 3652,95 ;27459          MOV LS[BIT9] TO WR[1]                   ;SET UP EXPECTED DATA
```

```
U 1728, 4740,95 ;27460          BIS LS[BIT0] TO WR[1]
U 1729, 0869,3C ;27461          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 172A, 8970,34 ;27462          JMP [LOOP.T30.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;27463
                ;27464  CLEANUP.T30:
                ;27465  ;CLR MATCH AS PART OF CLEANUP
U 172B, 370E,15 ;27466          MOV LS[SETCSR.F7] TO WR[0]
U 172C, 17A0,15 ;27467          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27468                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 172D, 379E,15 ;27469          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 172E, 3700,95 ;27470          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 172F, AEC2,15 ;27471          BIS WR[1] TO WR[0]
U 1730, 17A0,15 ;27472          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27473                                                  ;F<2:0> = 000
                ;27474  ;UCLR MATCH
                ;27475  ;-------------------------------------------------------------------------------
                ;27476  ;-------------------------------------------------------------------------------
                ;27477  ;                               *******
                ;27478  ;                               * IDC *
                ;27479  ;                               *******
                ;27480  ;-------------------------------------------------------------------------------
                ;27481  ;018:
                ;27482  ;=000
                ;27483  ;DIAG.IDLE:
                ;27484  ;
                ;27485  ;       BEN0/F0,
                ;27486  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;27487  ;       BEN2/F2,
                ;27488  ;       NAD/DIAG.IDLE
                ;27489  ;-------------------------------------------------------------------------------
                ;27490  ;01F:
                ;27491  ;=111
                ;27492  ;
                ;27493  ;       BEN0/CRDY.L,
                ;27494  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;27495  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;27496  ;-------------------------------------------------------------------------------
                ;27497  ;079:
                ;27498  ;=0*1
                ;27499  ;
                ;27500  ;       NAD/GROUP1
                ;27501  ;-------------------------------------------------------------------------------
                ;27502  ;182:
                ;27503  ;=0**
                ;27504  ;GROUP1:
                ;27505  ;
                ;27506  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;27507  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;27508  ;                                       ; FUNCTION BITS
                ;27509  ;-------------------------------------------------------------------------------
                ;27510  ;186:
                ;27511  ;=1**
                ;27512  ;
                ;27513  ;       BEN0/F0,
                ;27514  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
```

```
;27515  ;       BEN2/F2,
;27516  ;       NAD/GROUP1.F0
;27517  ;-------------------------------------------------------------------------
;27518  ;028:
;27519  ;=000
;27520  ;GROUP1.F0:
;27521  ;
;27522  ;CLR.MATCH.1:
;27523  ;
;27524  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;27525  ;       NAD/TEST.MATCH.1
;27526  ;-------------------------------------------------------------------------
;27527  ;1F6:
;27528  ;TEST.MATCH.1:
;27529  ;
;27530  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;27531  ;       NAD/BEN2.1
;27532  ;-------------------------------------------------------------------------
;27533  ;1A0:
;27534  ;=0**
;27535  ;BEN2.1:
;27536  ;
;27537  ;       INCR.DAR/ON,                    ;INCR DAR
;27538  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;27539  ;-------------------------------------------------------------------------
;27540  ;1A4:
;27541  ;=1**
;27542  ;BEN2.2:
;27543  ;
;27544  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;27545  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;27546  ;-------------------------------------------------------------------------
;27547  ;1D8:
;27548  ;XFER.REQ:
;27549  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;27550  ;       NAD/DIAG.WAIT
;27551  ;-------------------------------------------------------------------------
;27552  ;1D7:
;27553  ;DIAG.WAIT:
;27554  ;
;27555  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;27556  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;27557  ;-------------------------------------------------------------------------
;27558  ;159:
;27559  ;=*0*
;27560  ;DIAG.WAIT1:
;27561  ;
;27562  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;27563  ;                               ; COMMAND FROM THE CPU
;27564  ;-------------------------------------------------------------------------
;27565  ;158:
;27566  ;=*1*
;27567  ;DIAG.WAIT2:
;27568  ;
;27569  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
```

```
                    ;27570  ;                                   ; WAIT SOME MORE
                    ;27571  ;-----------------------------------------------------------------------
                    ;27572  WAIT.IDC.T30.5:
U 1731, DB00,1A     ;27573          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 1732, 0973,44     ;27574          JMP [IDC.DONE.T30.5]                        ;XFER REQ SET
U 1733, 0973,14     ;27575          JMP [WAIT.IDC.T30.5]                        ;WAIT SOME MORE
                    ;27576
                    ;27577  IDC.DONE.T30.5:
U 1734, B700,15     ;27578          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 1735, 17A0,15     ;27579          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 1736, 90FA,15     ;27580          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                    ;27581
                    ;27582
U 1737, 8875,3C     ;27583          JSR [CLEANUP]                               ;CLEANUP CONDITIONS SET BY THIS
                    ;27584                                                      ; TEST
                    ;27585  END.T30:                                            ;END TEST
                    ;27586
                    ;27587
                    ;27588
                    ;27589
                    ;27590
```

```
;27591  .PAGE  "Test 31  DAR SERIALIZER AND RL02 HEADER MATCH TEST (M8388 IDC MODULE)"
;27592  ;++
;27593  ;
;27594  ; Test Description:
;27595  ;
;27596  ;       This test is designed to insure that the DAR serializer functions
;27597  ;       correctly when an RL02 drive is selected for bits <15:9> of the DAR.
;27598  ;       This will be accomplished by loading the data pattern into the DAR
;27599  ;       and into the FIFO. The data will be shifted out of the FIFO and
;27600  ;       through the diskless loop to become READ DATA H. The DAR will be
;27601  ;       serialized the then compared bit by bit to the READ DATA H. Because of
;27602  ;       the design of the diskless loop, DAR bit <9> is compared with READ
;27603  ;       DATA <0>, DAR <10> is compared with READ DATA bit <1>, etc.
;27604  ;       When all bits have been compared, the IDC will  execute a test match.
;27605  ;       If a match was detected, the DAR will be incremented twice. If the
;27606  ;       data did not match, the DAR will be incremented once.
;27607  ;       The CPU will then read and check the DAR.
;27608  ;
;27609  ;       Data Patterns:
;27610  ;
;27611  ;               Float a zero through a field of ones for bits <15:9> of the
;27612  ;               DAR.
;27613  ;
;27614  ; Assumptions:
;27615  ;
;27616  ;       It is assumed that the diskless loop has been proven fully operational.
;27617  ;
;27618  ; Test Steps:
;27619  ;
;27620  ;       1. Set up error mask, error number and module number in LS
;27621  ;          (for error printouts) and clear the previous error number in LS.
;27622  ;       2. Force the IDC microcode to DIAG.IDLE.
;27623  ;       3. If the drive sizing routine has not been run previously, JSR to
;27624  ;          DRIVE.SIZE.
;27625  ;       4. Select an RL02 drive.
;27626  ;       5. Clear Match.
;27627  ;       6. Load the data pattern into the DAR.
;27628  ;       7. Load the data pattern into the FIFO.
;27629  ;       8. Set up the CSR to branch to the correct IDC microcode routine.
;27630  ;
;27631  ;
;27632  ;                                       *******
;27633  ;                                       * IDC *
;27634  ;                                       *******
;27635  ;
;27636  ;               IDC1. Send the sync character.
;27637  ;               IDC2. Load the data pattern from the FIFO into the DSR.
;27638  ;               IDC3. Shift the data from the DSR and through the diskless
;27639  ;                     loop.
;27640  ;               IDC4. Assert UENB CLR BC H so that the DAR will begin
;27641  ;                     serializing after sync seen.
;27642  ;               IDC5. Compare the serialized DAR and READ DATA H.
;27643  ;               IDC6. Execute an instruction with UCON<1:0> = 10, test match.
;27644  ;               IDC7. Select the CPU clock.
;27645  ;               IDC8. Select BEN2/MISMATCH L.
```

```
;27646  ;               IDC9. If MISMATCH L is asserted, increment the DAR once.
;27647  ;                     If MISMATCH L is not asserted (a MATCH was detected)
;27648  ;                      increment the DAR twice.
;27649  ;               IDC10. Issue XFER.REQ to flag the CPU and go to DIAG.WAIT.
;27650  ;
;27651  ;       9. Wait for an XFER.REQ from IDC.
;27652  ;      10. Clear CSR F<2:0> and issue XFER GRANT to clear XFER.REQ.
;27653  ;      11. Check the DAR = data pattern being tested (MISMATCH should not be
;27654  ;          so the DAR should be incremented twice).
;27655  ;      12. Get the next data pattern and go to Step 5 until all data patterns
;27656  ;          have been tested.
;27657  ;      13. Clear Match.
;27658  ;      14. Clear IDC.
;27659  ;      15. End test.
;27660  ;
;27661  ; Errors:
;27662  ;
;27663  ;       ERROR 1 - The DAR serializer failed for an RL02.
;27664  ;
;27665  ;                 Printout:
;27666  ;                           EXPECTED          RECEIVED
;27667  ;                             DAR               DAR
;27668  ; Debug:
;27669  ;
;27670  ;       The data pattern is loaded into the DAR and into FIFO A address 0.
;27671  ;       A line with no disk drive attached or with an RL02 drive attched is
;27672  ;       selected and will assert RL02 H which is inverted to become R80 H = L.
;27673  ;       The IDC will branch to a routine that will load the data from FIFO A
;27674  ;       address 0, into the DSR. This data is then shifted through the RL02
;27675  ;       diskless loop to become READ DATA H (see RL02 DATA PATH TESTS if
;27676  ;       diskless loop is not functioning correctly).
;27677  ;       READ DATA H is an input to the SERIAL DAR LO PAL and it becomes
;27678  ;       M.READ DATA H. This signal is an input to the DSK RD SEQ REG PAL.
;27679  ;       As this data is being shifted through the diskless loop, the DAR data
;27680  ;       is being serialized. The BIT COUNTER PAL is cleared when ENB CLR BC H
;27681  ;       is asserted from the IDC microword when SYNC SEEN L.
;27682  ;       R80 H will not be asserted at this time so the DAR will be serialized
;27683  ;       in order starting with Bit <0> up to Bit <18>. For example:
;27684  ;       when the bit couter = 2, bit 2 of the DAR will be output as MUX DAR H.
;27685  ;       The serializing is done in the BIT COUNTER PAL and the SERIAL DAR LO
;27686  ;       and SERIAL DAR HI PALS.
;27687  ;       At the DSK RD SEQ REG PAL, SYNC SEEN L will be asserted at the next
;27688  ;       CURRENT CLK H after SEL DSK CLK H = H and BYTE COMPARE H = H. After
;27689  ;       SYNC SEEN L is asserted, COMPARE L will assert when SERIAL DAR H =
;27690  ;       M.READ DATA H with UWRT CHK H = L. COMPARE L will assert on the first
;27691  ;       match of SERIAL DAR H and  M.READ DATA H and will remain asserted.
;27692  ;       Bits <8:0> of the DAR which are all zeros will be compared to zeros
;27693  ;       coming in as M.READ DATA H. When bit <9> of the DAR is selected
;27694  ;       Bit <0> of the data which was loaded into FIFO A will be M.READ DATA H,
;27695  ;       DAR Bit <10> is selected and BIT <1> of FIFO A data is M.READ DATA H,
;27696  ;       etc. so in this test COMPARE L should remain asserted.
;27697  ;       The IDC will then issue an instruction with UCON <1:0> = 10. These bits
;27698  ;       will be decoded by the DSK RD SEQ REG PAL to perform a TEST.MATCH.
;27699  ;       COMPARE L is asserted at this time, so MISMATCH L = H.
;27700  ;       The IDC microcode will then select BEN2/MISMATCH L (BEN2 S2 H = L,
```

```
                ;27701  ;       BEN2 S1 H = L, BEN2 S0 H = H). MISMATCH L will not be asserted so the
                ;27702  ;       microcode will branch to a series of instructions that will increment
                ;27703  ;       the DAR twice.
                ;27704  ;--
                ;27705  ;*****************************************************************************
                ;27706  T.31:
U 1738, B65E,15 ;27707          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;27708                                                  ; CONTROL AND STATUS WORD
U 1739, 3E80,15 ;27709          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;27710                                                  ; STATUS WORD - BIT 15
                ;27711                                                  ; INDICATES START OF TEST TO
                ;27712                                                  ; CONSOLE
U 173A, 10E0,15 ;27713          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;27714  WAIT.T31.0:
U 173B, 0973,B4 ;27715          JMP [WAIT.T31.0]                        ;LOOP HERE WAITING FOR
                ;27716                                                  ; CONSOLE TO RESPOND
                ;27717
U 173C, 65A0,15 ;27718          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;27719                                                  ; IN LS
                ;27720
U 173D, B64A,15 ;27721          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 173E, 3E8C,15 ;27722          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;27723
                ;27724
U 173F, B640,15 ;27725          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1740, BE82,15 ;27726          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;27727
U 1741, 3776,15 ;27728          MOV LS[DAR.MASK] TO WR[0]               ;GET THE MASK TO CHECK THE
U 1742, 3E8A,15 ;27729          MOV WR[0] TO LS[ERROR.MASK]             ; DAR
                ;27730
U 1743, B78E,15 ;27731          MOV LS[DRIVE.STATUS] TO WR[0]           ;HAS THE DRIVE SIZING ROUTINE
                ;27732          BIT LS[BIT7] WITH WR[0],                ; BEEN RUN?
U 1744, D94E,35 ;27733           DT(LONG)&SET.ALU.CC
U 1745, 8974,71 ;27734          JMP.IF[BIT.SET] TO [SIZE.OK.T31.1]      ;IF YES THEN GO RUN TEST
                ;27735
U 1746, 8870,0C ;27736          JSR [DRIVE.SIZE]                        ;GO RUN THE SIZING ROUTINE
                ;27737
                ;27738  SIZE.OK.T31.1:
U 1747, 8872,EC ;27739          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;27740
                ;27741          ;SELECT AN RL02 DRIVE AND SAVE THE INFO IN WR[2]
                ;27742
U 1748, B78E,15 ;27743          MOV LS[DRIVE.STATUS] TO WR[0]
                ;27744          BIT LS[BIT0] WITH WR[0],                ;IS DRIVE 0 AN R80?
U 1749, 5940,35 ;27745           DT(LONG)&SET.ALU.CC
U 174A, 0974,D9 ;27746          JMP.IF[BITS.CLR] TO [SET.DS0.T31.1]     ;JMP IF DRV 0 IS NOT AN R80
U 174B, B717,15 ;27747          MOV LS[SETCSR.DS1] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 1
U 174C, 8974,E4 ;27748          JMP [TEST.T31.1]
                ;27749  SET.DS0.T31.1:
U 174D, 3715,15 ;27750          MOV LS[SETCSR.DS0] TO WR[2]             ;SAVE THE DATA TO SEL DRIVE 0
                ;27751
                ;27752  TEST.T31.1:
U 174E, B653,95 ;27753          MOV LS[BIT9] TO WR[3]                   ;GET THE FIRST DAR DATA PATTERN
U 174F, B640,15 ;27754          MOV LS[#1] TO WR[0]                     ;GET THE DATA TO WRITE TO FIFOA
U 1750, 3E10,15 ;27755          MOV WR[0] TO LS[T8]                     ;SAVE IN LS[T8]
```

```
                ;27756
                ;27757  TST.NXT.PAT.T31:
                ;27758  LOOP.T31.1:
U 1751, 370E,15 ;27759          MOV LS[SETCSR.F7] TO WR[0]
U 1752, 17A0,15 ;27760          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;27761                                                   ;MAINT=0,CRDY=0,F<2:0>=111
                ;27762  ;CONTINUE TO BRANCH
U 1753, 379E,15 ;27763          MOV LS[SETCSR.R80] TO WR[0]              ;SET UP THE CSR TO CONTINUE TO
U 1754, 3700,95 ;27764          MOV LS[SETCSR.F0] TO WR[1]               ; BRANCH TO THE CORRECT ROUTINE
U 1755, AEC2,15 ;27765          BIS WR[1] TO WR[0]
U 1756, 17A0,15 ;27766          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;27767                                                   ;F<2:0> = 000
                ;27768  ;UCLR MATCH
                ;27769  ;-------------------------------------------------------------------------
                ;27770  ;-------------------------------------------------------------------------
                ;27771  ;                                *******
                ;27772  ;                                * IDC *
                ;27773  ;                                *******
                ;27774  ;-------------------------------------------------------------------
                ;27775  ;018:
                ;27776  ;=000
                ;27777  ;DIAG.IDLE:
                ;27778  ;
                ;27779  ;       BEN0/F0,
                ;27780  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;27781  ;       BEN2/F2,
                ;27782  ;       NAD/DIAG.IDLE
                ;27783  ;-------------------------------------------------------------------
                ;27784  ;01F:
                ;27785  ;=111
                ;27786  ;
                ;27787  ;       BEN0/CRDY.L,
                ;27788  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;27789  ;       NAD/TEST.FUNC7           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;27790  ;-------------------------------------------------------------------
                ;27791  ;079:
                ;27792  ;=0*1
                ;27793  ;
                ;27794  ;       NAD/GROUP1
                ;27795  ;-------------------------------------------------------------------
                ;27796  ;182:
                ;27797  ;=0**
                ;27798  ;GROUP1:
                ;27799  ;
                ;27800  ;       BEN2/R80.FORMAT.H,               ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;27801  ;       NAD/GROUP1                       ; TO NEXT WORD AND THEN BRANCH ON THE
                ;27802  ;                                        ; FUNCTION BITS
                ;27803  ;-------------------------------------------------------------------
                ;27804  ;186:
                ;27805  ;=1**
                ;27806  ;
                ;27807  ;       BEN0/F0,
                ;27808  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;27809  ;       BEN2/F2,
                ;27810  ;       NAD/GROUP1.F0
```

```
;27811  ;-------------------------------------------------------------------------------
;27812  ;028:
;27813  ;=000
;27814  ;GROUP1.F0:
;27815  ;
;27816  ;CLR.MATCH.1:
;27817  ;
;27818  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;27819  ;       NAD/TEST.MATCH.1
;27820  ;-------------------------------------------------------------------------------
;27821  ;1F6:
;27822  ;TEST.MATCH.1:
;27823  ;
;27824  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;27825  ;       NAD/BEN2.1
;27826  ;-------------------------------------------------------------------------------
;27827  ;1A0:
;27828  ;=0**
;27829  ;BEN2.1:
;27830  ;
;27831  ;       INCR.DAR/ON,                    ;INCR DAR
;27832  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;27833  ;-------------------------------------------------------------------------------
;27834  ;1A4:
;27835  ;=1**
;27836  ;BEN2.2:
;27837  ;
;27838  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;27839  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;27840  ;-------------------------------------------------------------------------------
;27841  ;1D8:
;27842  ;XFER.REQ:
;27843  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;27844  ;       NAD/DIAG.WAIT
;27845  ;-------------------------------------------------------------------------------
;27846  ;1D7:
;27847  ;DIAG.WAIT:
;27848  ;
;27849  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;27850  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;27851  ;-------------------------------------------------------------------------------
;27852  ;159:
;27853  ;=*0*
;27854  ;DIAG.WAIT1:
;27855  ;
;27856  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;27857  ;                               ; COMMAND FROM THE CPU
;27858  ;-------------------------------------------------------------------------------
;27859  ;15B:
;27860  ;=*1*
;27861  ;DIAG.WAIT2:
;27862  ;
;27863  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
;27864  ;                               ; WAIT SOME MORE
;27865  ;-------------------------------------------------------------------------------
```

```
                ;27866  WAIT.IDC.T31.1:
U 1757, DB00,1A ;27867          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1758, 8975,A4 ;27868          JMP [IDC.DONE.T31.1]                    ;XFER REQ SET
U 1759, 0975,74 ;27869          JMP [WAIT.IDC.T31.1]                    ;WAIT SOME MORE
                ;27870
                ;27871  IDC.DONE.T31.1:
U 175A, B700,15 ;27872          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 175B, 17A0,15 ;27873          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 175C, 90FA,15 ;27874          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;27875
U 175D, A006,15 ;27876          MOV WR[3] TO WR[0]                      ;GET THE DAR PATTERN TO WRITE
U 175E, 97A4,15 ;27877          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;WRITE THE DAR
                ;27878
U 175F, B610,15 ;27879          MOV LS[T8] TO WR[0]                     ;GET THE DATA TO WRITE
U 1760, 17D8,15 ;27880          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1761, 17C0,15 ;27881          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
U 1762, 97A8,15 ;27882          PORT.WRITE PORT.ADRS[DATA.BYTE] WITH WR[0]  ;WRITE THE DATA TO FIFO A
                ;27883
U 1763, 17C0,15 ;27884          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET FIFO A ADRS=0
                ;27885
                ;27886  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;27887
U 1764, 370E,15 ;27888          MOV LS[SETCSR.F7] TO WR[0]
U 1765, 17A0,15 ;27889          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27890                                                  ;MAINT=0,CRDY=0,F<2:0>=111
U 1766, 379E,15 ;27891          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 1767, B704,95 ;27892          MOV LS[SETCSR.F2] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 1768, AEC2,15 ;27893          BIS WR[1] TO WR[0]
U 1769, AEC4,15 ;27894          BIS WR[2] TO WR[0]                      ;INCLUDE THE RL02 DRV SELECT
U 176A, 17A0,15 ;27895          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;27896
                ;27897  ;-------------------------------------------------------------------------------
                ;27898  ;-------------------------------------------------------------------------------
                ;27899  ;                               *******
                ;27900  ;                               * IDC *
                ;27901  ;                               *******
                ;27902  ;-------------------------------------------------------------------------------
                ;27903  ;018:
                ;27904  ;=000
                ;27905  ;DIAG.IDLE:
                ;27906  ;
                ;27907  ;       BEN0/F0,
                ;27908  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;27909  ;       BEN2/F2,
                ;27910  ;       NAD/DIAG.IDLE
                ;27911  ;-------------------------------------------------------------------------------
                ;27912  ;01F:
                ;27913  ;=111
                ;27914  ;
                ;27915  ;       BEN0/CRDY.L,
                ;27916  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;27917  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;27918  ;-------------------------------------------------------------------------------
                ;27919  ;079:
                ;27920  ;=0*1
```

```
;27921  ;
;27922  ;       NAD/GROUP1
;27923  ;-------------------------------------------------------------------------------
;27924  ;182:
;27925  ;=0**
;27926  ;GROUP1:
;27927  ;
;27928  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;27929  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;27930  ;                                       ; FUNCTION BITS
;27931  ;-------------------------------------------------------------------------------
;27932  ;186:
;27933  ;=1**
;27934  ;
;27935  ;       BEN0/F0,
;27936  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;27937  ;       BEN2/F2,
;27938  ;       NAD/GROUP1.F0
;27939  ;-------------------------------------------------------------------------------
;27940  ;02A:
;27941  ;=010
;27942  ;MATCH.OR.WRTCHK.1:
;27943  ;
;27944  ;       UMAINT/ON,
;27945  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
;27946  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
;27947  ;       LOAD.LOOP.CNTR.[0E0],
;27948  ;       NAD/MATCH.OR.WRTCHK.2
;27949  ;-------------------------------------------------------------------------------
;27950  ;198:
;27951  ;=0
;27952  ;MATCH.OR.WRTCHK.2:
;27953  ;
;27954  ;       UMAINT/ON,
;27955  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;27956  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;27957  ;       UCMD/SET.FIFOA,
;27958  ;       INCR.LPCNTR/ON,
;27959  ;       BEN0/CNTR.OVFLW,
;27960  ;       NAD/MATCH.OR.WRTCHK.2
;27961  ;-------------------------------------------------------------------------------
;27962  ;199:
;27963  ;=1
;27964  ;MATCH.OR.WRTCHK.3:
;27965  ;
;27966  ;       UMAINT/ON,
;27967  ;       LOOP.LOCK/ON,
;27968  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;27969  ;       ENB.DSK.CLK,
;27970  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27971  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;27972  ;-------------------------------------------------------------------------------
;27973  ;1F2:
;27974  ;MATCH.OR.WRTCHK.4:
;27975  ;
```

```
;27976  ;       UMAINT/ON,
;27977  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;27978  ;       DISK.WRITE/ON,
;27979  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27980  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;27981  ;-------------------------------------------------------------------------------
;27982  ;1F3:
;27983  ;MATCH.OR.WRTCHK.5:
;27984  ;
;27985  ;       UMAINT/ON,
;27986  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;27987  ;       DISK.WRITE/ON,
;27988  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;27989  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;27990  ;-------------------------------------------------------------------------------
;27991  ;1F4:
;27992  ;MATCH.OR.WRTCHK.6:
;27993  ;
;27994  ;       UMAINT/ON,
;27995  ;       LOOP.LOCK/ON,
;27996  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;27997  ;       ENB.FIFO/ON,
;27998  ;       LOAD.DSR/ON,
;27999  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;28000  ;       NAD/MATCH.OR.WRTCHK.7
;28001  ;-------------------------------------------------------------------------------
;28002  ;183:
;28003  ;=0**
;28004  ;MATCH.OR.WRTCHK.7:
;28005  ;
;28006  ;       UMAINT/ON,
;28007  ;       LOOP.LOCK/ON,           ;MATCH TEST
;28008  ;       DISK.WRITE/ON,
;28009  ;       LOAD.LOOP.CNTR.[0F6],
;28010  ;       NAD/MATCH.1
;28011  ;-------------------------------------------------------------------------------
;28012  ;19A:
;28013  ;=0
;28014  ;MATCH.1:
;28015  ;
;28016  ;       UMAINT/ON,
;28017  ;       LOOP.LOCK/ON,
;28018  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
;28019  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;28020  ;       BEN0/CNTR.OVFLW,
;28021  ;       NAD/MATCH.1
;28022  ;-------------------------------------------------------------------------------
;28023  ;19B:
;28024  ;=1
;28025  ;MATCH.2:
;28026  ;
;28027  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;28028  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;28029  ;       DISK.WRITE/ON,
;28030  ;       UCON/TEST.MATCH,
```

```
;28031  ;       NAD/MATCH.3
;28032  ;-------------------------------------------------------------------------------
;28033  ;1F5:
;28034  ;MATCH.3:
;28035  ;
;28036  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;28037  ;       LOOP.LOCK/ON,                   ; GOING
;28038  ;       DISK.WRITE/ON,
;28039  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;28040  ;       NAD/TEST.MATCH.1
;28041  ;-------------------------------------------------------------------------------
;28042  ;1F6:
;28043  ;TEST.MATCH.1:
;28044  ;
;28045  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;28046  ;       NAD/BEN2.1
;28047  ;-------------------------------------------------------------------------------
;28048  ;1A0:
;28049  ;=0**
;28050  ;BEN2.1:
;28051  ;
;28052  ;       INCR.DAR/ON,                    ;INCR DAR
;28053  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;28054  ;-------------------------------------------------------------------------------
;28055  ;1A4:
;28056  ;=1**
;28057  ;BEN2.2:
;28058  ;
;28059  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;28060  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;28061  ;-------------------------------------------------------------------------------
;28062  ;1D8:
;28063  ;XFER.REQ:
;28064  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;28065  ;       NAD/DIAG.WAIT
;28066  ;-------------------------------------------------------------------------------
;28067  ;1D7:
;28068  ;DIAG.WAIT:
;28069  ;
;28070  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;28071  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;28072  ;-------------------------------------------------------------------------------
;28073  ;159:
;28074  ;=*C*
;28075  ;DIAG.WAIT1:
;28076  ;
;28077  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;28078  ;                               ; COMMAND FROM THE CPU
;28079  ;-------------------------------------------------------------------------------
;28080  ;15B:
;28081  ;=*1*
;28082  ;DIAG.WAIT2:
;28083  ;
;28084  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
;28085  ;                               ; WAIT SOME MORE
```

```
                ;28086  ;-------------------------------------------------------------------------
                ;28087  WAIT.IDC.T31.2:
U 176B, DB00,1A ;28088          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 176C, 0976,E4 ;28089          JMP [IDC.DONE.T31.2]                        ;XFER REQ SET
U 176D, 0976,B4 ;28090          JMP [WAIT.IDC.T31.2]                        ;WAIT SOME MORE
                ;28091
                ;28092  IDC.DONE.T31.2:
U 176E, B700,15 ;28093          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 176F, 17A0,15 ;28094          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 1770, 90FA,15 ;28095          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;28096
                ;28097  READ.DAR.T31.1:
U 1771, 9090,15 ;28098          MISC [SET.PORT.I.0]                         ;SELECT THE IDC
U 1772, 1784,15 ;28099          PORT.READ PORT.ADRS[DAR]                    ;SET UP TO READ THE DAR
U 1773, 3B32,15 ;28100          MOV PORT TO LS[PORT0]                       ;READ THE DATA FROM DAR AND
                ;28101                                                      ; SAVE IT IN  LS
U 1774, 3732,15 ;28102          MOV LS[PORT0] TO WR[0]                      ;SET UP RECEIVED DATA
U 1775, 2006,95 ;28103          MOV WR[3] TO WR[1]                          ;SET UP EXPECTED DATA
U 1776, C742,95 ;28104          BIS LS[BIT1] TO WR[1]
U 1777, 0869,3C ;28105          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1778, 0975,14 ;28106          JMP [LOOP.T31.1]                            ;LOOP HERE IF ERR & LOE IS SET
                ;28107
                ;28108
                ;28109          BIT LS[BIT15] WITH WR[3],                   ;DONE?
U 1779, 595F,B5 ;28110           DT(LONG)&SET.ALU.CC
U 177A, 0978,01 ;28111          JMP.IF[BIT.SET] TO [CLEANUP.T31]            ;JMP IF DONE
                ;28112
                ;28113  ;GET NEXT DATA PATTERN FOR THE DAR
                ;28114
U 177B, A3C1,95 ;28115          ROL WR[3]                                   ;GET THE LAST DAR PATTERN
                ;28116                                                      ;ROTATE ONCE LEFT
                ;28117  ;GET THE NEXT FIFO PATTERN
                ;28118
U 177C, B610,15 ;28119          MOV LS[T8] TO WR[0]                         ;GET THE LAST FIFO PATTERN
U 177D, A3C0,15 ;28120          ROL WR[0]                                   ;ROTATE ONCE LEFT
U 177E, 3E10,15 ;28121          MOV WR[0] TO LS[T8]                         ;SAVE IN LS[T8]
                ;28122
U 177F, 0975,14 ;28123          JMP [TST.NXT.PAT.T31]                       ;GO TEST NEXT PATTERN
                ;28124
                ;28125  CLEANUP.T31:
U 1780, 370E,15 ;28126          MOV LS[SETCSR.F7] TO WR[0]
U 1781, 17A0,15 ;28127          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;28128                                                      ;MAINT=0,CRDY=0,F<2:0>=111
U 1782, 379E,15 ;28129          MOV LS[SETCSR.R80] TO WR[0]                 ;SET UP THE CSR TO CONTINUE TO
U 1783, 3700,95 ;28130          MOV LS[SETCSR.F0] TO WR[1]                  ; BRANCH TO THE CORRECT ROUTINE
U 1784, AEC2,15 ;28131          BIS WR[1] TO WR[0]
U 1785, 17A0,15 ;28132          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;28133                                                      ;F<2:0> = 000
                ;28134  ;UCLR MATCH
                ;28135  ;-------------------------------------------------------------------------
                ;28136  ;-------------------------------------------------------------------------
                ;28137  ;                              *******
                ;28138  ;                              * IDC *
                ;28139  ;                              *******
                ;28140  ;-------------------------------------------------------------------------
```

```
;28141  ;018:
;28142  ;=000
;28143  ;DIAG.IDLE:
;28144  ;
;28145  ;       BEN0/F0,
;28146  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;28147  ;       BEN2/F2,
;28148  ;       NAD/DIAG.IDLE
;28149  ;-------------------------------------------------------------------------
;28150  ;01F:
;28151  ;=111
;28152  ;
;28153  ;       BEN0/CRDY.L,
;28154  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;28155  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;28156  ;-------------------------------------------------------------------------
;28157  ;079:
;28158  ;=0*1
;28159  ;
;28160  ;       NAD/GROUP1
;28161  ;-------------------------------------------------------------------------
;28162  ;182:
;28163  ;=0**
;28164  ;GROUP1:
;28165  ;
;28166  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;28167  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;28168  ;                                       ; FUNCTION BITS
;28169  ;-------------------------------------------------------------------------
;28170  ;186:
;28171  ;=1**
;28172  ;
;28173  ;       BEN0/F0,
;28174  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;28175  ;       BEN2/F2,
;28176  ;       NAD/GROUP1.F0
;28177  ;-------------------------------------------------------------------------
;28178  ;028:
;28179  ;=000
;28180  ;GROUP1.F0:
;28181  ;
;28182  ;CLR.MATCH.1:
;28183  ;
;28184  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;28185  ;       NAD/TEST.MATCH.1
;28186  ;-------------------------------------------------------------------------
;28187  ;1F6:
;28188  ;TEST.MATCH.1:
;28189  ;
;28190  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;28191  ;       NAD/BEN2.1
;28192  ;-------------------------------------------------------------------------
;28193  ;1A0:
;28194  ;=0**
;28195  ;BEN2.1:
```

```
                ;28196  ;
                ;28197  ;       INCR.DAR/ON,                    ;INCR DAR
                ;28198  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;28199  ;-------------------------------------------------------------------------
                ;28200  ;1A4:
                ;28201  ;=1**
                ;28202  ;BEN2.2:
                ;28203  ;
                ;28204  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;28205  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;28206  ;-------------------------------------------------------------------------
                ;28207  ;1D8:
                ;28208  ;XFER.REQ:
                ;28209  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;28210  ;       NAD/DIAG.WAIT
                ;28211  ;-------------------------------------------------------------------------
                ;28212  ;1D7:
                ;28213  ;DIAG.WAIT:
                ;28214  ;
                ;28215  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;28216  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;28217  ;-------------------------------------------------------------------------
                ;28218  ;159:
                ;28219  ;=*0*
                ;28220  ;DIAG.WAIT1:
                ;28221  ;
                ;28222  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;28223  ;                               ; COMMAND FROM THE CPU
                ;28224  ;-------------------------------------------------------------------------
                ;28225  ;15B:
                ;28226  ;=*1*
                ;28227  ;DIAG.WAIT2:
                ;28228  ;
                ;28229  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;28230  ;                               ; WAIT SOME MORE
                ;28231  ;-------------------------------------------------------------------------
                ;28232  WAIT.IDC.T31.3:
U 1786, DB00,1A ;28233          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1787, 0978,94 ;28234          JMP [IDC.DONE.T31.3]                    ;XFER REQ SET
U 1788, 0978,64 ;28235          JMP [WAIT.IDC.T31.3]                    ;WAIT SOME MORE
                ;28236
                ;28237  IDC.DONE.T31.3:
U 1789, B700,15 ;28238          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 178A, 17A0,15 ;28239          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 178B, 90FA,15 ;28240          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;28241
                ;28242
U 178C, 8875,3C ;28243          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;28244                                                  ; THIS TEST
                ;28245  END.T31:                                        ;END TEST
                ;28246
                ;28247
                ;28248
                ;28249
```

```
;28250  .PAGE  "Test 32  WRITE CHECK TEST (M8388 IDC MODULE)"
;28251  ;++
;28252  ;
;28253  ; Test Description:
;28254  ;
;28255  ;       This test is designed to insure that the data compares correctly on
;28256  ;       a write check operation. The data will be loaded into the FIFO
;28257  ;       and shifted through the diskless loop to become READ DATA. The data
;28258  ;       to be compared will be loaded into the Data Shifted Register
;28259  ;       and shifted out as DSR 0 and will be compared with the READ DATA in the
;28260  ;       DSK RD SEQ REG PAL. A TEST MATCH will then be executed with
;28261  ;       BEN2/MISMATCH L selected. If a no match is detected, the DAR will
;28262  ;       be incremented once. If a Match is detected then the DAR will be
;28263  ;       incremented twice. The CPU will then check the DAR.
;28264  ;
;28265  ;       Data Patterns (2 bits):
;28266  ;
;28267  ;                               READ DATA               DSR
;28268  ;               Pattern 1:        01                    01
;28269  ;               Pattern 2:        01                    00
;28270  ;               Pattern 3:        00                    01
;28271  ;
;28272  ; Assumptions:
;28273  ;
;28274  ;       It is assumed that all previous tests have run successfully.
;28275  ;
;28276  ; Test Steps:
;28277  ;
;28278  ;       1. Set up error mask, error number and module number in LS
;28279  ;          (for error printouts) and clear the previous error number in LS.
;28280  ;       2. Force the IDC microcode to DIAG.IDLE.
;28281  ;       3. If the drive sizing routine has not been run previously, JSR to
;28282  ;          DRIVE.SIZE.
;28283  ;       4. Select an RL02 drive.
;28284  ;       5. Load the data pattern into the FIFO.
;28285  ;       6. Clear the DAR.
;28286  ;       7. Set up the CSR to branch to the correct IDC microcode routine.
;28287  ;
;28288  ;
;28289  ;                                       *******
;28290  ;                                       * IDC *
;28291  ;                                       *******
;28292  ;
;28293  ;               IDC1. Select the disk clock.
;28294  ;               IDC2. Shift out the sync character.
;28295  ;               IDC3. Follow with the first data from the FIFO and
;28296  ;                     shift it through the diskless loop to become READ DATA.
;28297  ;               IDC4. Load the next part of the data pattern into the DSR.
;28298  ;               IDC5. Execute an instruction with UCON <1:0> = 10, TEST MATCH.
;28299  ;               IDC6. Select the CPU clock.
;28300  ;               IDC7. Select BEN2/MISMATCH L.
;28301  ;               IDC8. If MISMATCH L is asserted then increment the DAR once.
;28302  ;                     If MISMATCH L is not asserted (a match was detected) then
;28303  ;                      increment DAR twice.
;28304  ;               IDC9. Issue XFER.REQ to flag the CPU.
```

```
;28305  ;
;28306  ;       8. Wait for a XFER.REQ from IDC.
;28307  ;       9. Clear CSR <2:0> and issue XFER GRANT to clear the XFER.REQ.
;28308  ;      10. Check the contents of the DAR.
;28309  ;      11. Get the next data pattern and go to Step 5 until all patterns have
;28310  ;          been tested.
;28311  ;      12. Clear IDC.
;28312  ;      13. End test.
;28313  ;
;28314  ; Errors:
;28315  ;
;28316  ;       ERROR 1 - Data did not compare correctly on a write check operation.
;28317  ;
;28318  ;
;28319  ;                 Printout:
;28320  ;                         EXPECTED          RECEIVED          OTHER DATA
;28321  ;                           DAR               DAR             FIFO A ADRS 0
;28322  ;                                                             BYTE 0 = RD DATA
;28323  ;                                                             BYTE 1 = DSR DATA
;28324  ;
;28325  ; Debug:
;28326  ;
;28327  ; ERROR 1 -
;28328  ;       The data pattern is loaded into FIFO A address 0. Byte 0 is the data
;28329  ;       that will be shifted through the RL02 diskless loop to become
;28330  ;       M.READ DATA H and BYTE 1 is the data loaded into the DSR and then
;28331  ;       shifted out through DAR 0 which is an input to the DSK RD SEQ REG PAL.
;28332  ;       A line with no disk drive attached or with an RL02 drive attched is
;28333  ;       selected and will assert RL02 H which is inverted to become R80 H = L.
;28334  ;       The IDC will branch to a routine that will load the Byte 0 of FIFO A
;28335  ;       address 0, into the DSR. This data is then shifted through the RL02
;28336  ;       diskless loop to become READ DATA H (see RL02 DATA PATH TESTS if
;28337  ;       diskless loop is not functioning correctly).
;28338  ;       READ DATA H is an input to the SERIAL DAR LO PAL and it becomes
;28339  ;       M.READ DATA H. This signal is an input to the DSK RD SEQ REG PAL.
;28340  ;       As bit 0 of this data becomes M.READ DATA H, the DSR is loaded with
;28341  ;       Byte 1 of FIFO A data.
;28342  ;       At the DSK RD SEQ REG PAL, SYNC SEEN L will be asserted at the next
;28343  ;       CURRENT CLK H after SEL DSK CLK H = H and BYTE COMPARE H = H. After
;28344  ;       SYNC SEEN L is asserted, COMPARE L will assert when DSR 0 =
;28345  ;       M.READ DATA H with UWRT CHK H = H. COMPARE L will assert on the first
;28346  ;       match of DSR 0 H and  M.READ DATA H and will remain asserted
;28347  ;       unless a mismatch is encountered. After SYNC SEEN L, M.READ DATA H and
;28348  ;       DSR 0 H should be zeros until the byte of data has shifted through the
;28349  ;       diskless loop and becomes M.READ DATA H and the DSR is loaded again.
;28350  ;       The IDC will then issue an instruction with UCON <1:0> = 10. These bits
;28351  ;       will be decoded by the DSK RD SEQ REG PAL to perform a TEST.MATCH.
;28352  ;       If COMPARE L is asserted at this time, MISMATCH L = H (data pat 1).
;28353  ;       If COMPARE L is not asserted at this time, MISMATCH L = L
;28354  ;       (data pat 2 and 3).
;28355  ;       The IDC microcode will then select BEN2/MISMATCH L (BEN2 S2 H = L,
;28356  ;       BEN2 S1 H = L, BEN2 S0 H = H). If MISMATCH L is not asserted,
;28357  ;       (data pat 1), the microcode will branch to a series of instructions
;28358  ;       that will increment the DAR twice.
;28359  ;       If MISMATCH L is asserted (data pat 2 and 3), the microcode will branch
```

```
                ;28360  ;       to an instruction that will increment the DAR once.
                ;28361  ;--
                ;28362  ;*************************************************************************
                ;28363  T.32:
U 178D, B65E,15 ;28364          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;28365                                                          ; CONTROL AND STATUS WORD
U 178E, 3E80,15 ;28366          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;28367                                                          ; STATUS WORD - BIT 15
                ;28368                                                          ; INDICATES START OF TEST TO
                ;28369                                                          ; CONSOLE
U 178F, 10E0,15 ;28370          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;28371  WAIT.T32.0:
U 1790, 8979,04 ;28372          JMP [WAIT.T32.0]                                ;LOOP HERE WAITING FOR
                ;28373                                                          ; CONSOLE TO RESPOND
                ;28374
U 1791, 65A0,15 ;28375          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
                ;28376                                                          ; IN LS
                ;28377
U 1792, B64A,15 ;28378          MOV LS[IDC] TO WR[0]                            ;STORE MODULE CODE IN LS TO
U 1793, 3E8C,15 ;28379          MOV WR[0] TO LS[MODULE.NUM]                     ; INDICATE IDC MODULE
                ;28380
                ;28381
U 1794, B640,15 ;28382          MOV LS[#1] TO WR[0]                             ;SET WR0 = 1
U 1795, BE82,15 ;28383          MOV WR[0] TO LS[ERROR.NUMBER]                   ;SET UP ERROR NUMBER = 1 IN LS
                ;28384
U 1796, 3776,15 ;28385          MOV LS[DAR.MASK] TO WR[0]                       ;GET THE MASK TO CHECK THE
U 1797, 3E8A,15 ;28386          MOV WR[0] TO LS[ERROR.MASK]                     ; DAR
                ;28387
U 1798, B670,15 ;28388          MOV LS[OTHER.DATA] TO WR[0]                     ;SET UP TO PRINT OTHER DATA
U 1799, 3E80,15 ;28389          MOV WR[0] TO LS[CONTROL.STATUS]                 ; IF ERROR
                ;28390
U 179A, B78E,15 ;28391          MOV LS[DRIVE.STATUS] TO WR[0]                   ;HAS THE DRIVE SIZING ROUTINE
                ;28392          BIT LS[BIT7] WITH WR[0],                        ; BEEN RUN?
U 179B, D94E,35 ;28393           DT(LONG)&SET.ALU.CC
U 179C, 0979,E1 ;28394          JMP.IF[BIT.SET] TO [SIZE.OK.T32.1]              ;IF YES THEN GO RUN TEST
                ;28395
U 179D, 8870,0C ;28396          JSR [DRIVE.SIZE]                                ;GO RUN THE SIZING ROUTINE
                ;28397
                ;28398  SIZE.OK.T32.1:
U 179E, 8872,EC ;28399          JSR [DIAG.CODE]                                 ;FORCE THE IDC TO DIAG.IDLE
                ;28400
                ;28401          ;SELECT AN RL02 DRIVE AND SAVE THE INFO IN WR[2]
                ;28402
U 179F, B78E,15 ;28403          MOV LS[DRIVE.STATUS] TO WR[0]
                ;28404          BIT LS[BIT0] WITH WR[0],                        ;IS DRIVE 0 AN R80?
U 17A0, 5940,35 ;28405           DT(LONG)&SET.ALU.CC
U 17A1, 897A,49 ;28406          JMP.IF[BITS.CLR] TO [SET.DS0.T32.1]             ;JMP IF DRV 0 IS NOT AN R80
U 17A2, B717,15 ;28407          MOV LS[SETCSR.DS1] TO WR[2]                     ;SAVE THE DATA TO SEL DRIVE 1
U 17A3, 897A,54 ;28408          JMP [TEST.T32.1]
                ;28409  SET.DS0.T32.1:
U 17A4, 3715,15 ;28410          MOV LS[SETCSR.DS0] TO WR[2]                     ;SAVE THE DATA TO SEL DRIVE 0
                ;28411
                ;28412  TEST.T32.1:
                ;28413  ;SET UP THE DATA IN FIFO A (FIRST BYTE WILL CONTAIN THE READ DATA PATTERN
                ;28414  ;AND THE SECOND BYTE WILL CONTAIN THE DSR DATA PATTERN)
```

```
                ;28415
U 17A5, 37BB,95 ;28416          MOV LS[#101] TO WR[3]                   ;GET THE FIRST PATTERN
U 17A6, 3642,15 ;28417          MOV LS[#2] TO WR[0]                     ;SET UP THE EXPECTED DATA
U 17A7, 3E10,15 ;28418          MOV WR[0] TO LS[T8]                     ;SAV EXP DATA IN LS[T8]
U 17A8, 3642,15 ;28419          MOV LS[#2] TO WR[0]
U 17A9, BE12,15 ;28420          MOV WR[0] TO LS[T9]                     ;SET UP THE LOOP CNTR
                ;28421
                ;28422  TST.NXT.PAT.T32:
                ;28423  LOOP.T32.1:
U 17AA, 370E,15 ;28424          MOV LS[SETCSR.F7] TO WR[0]
U 17AB, 17A0,15 ;28425          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28426                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;28427  ;CONTINUE TO BRANCH
U 17AC, 379E,15 ;28428          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 17AD, 3700,95 ;28429          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 17AE, AEC2,15 ;28430          BIS WR[1] TO WR[0]
U 17AF, 17A0,15 ;28431          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28432                                                  ;F<2:0> = 000
                ;28433  ;UCLR MATCH
                ;28434  ;-------------------------------------------------------------------------
                ;28435  ;-------------------------------------------------------------------------
                ;28436  ;                               *******
                ;28437  ;                               * IDC *
                ;28438  ;                               *******
                ;28439  ;-------------------------------------------------------------------------
                ;28440  ;018:
                ;28441  ;=000
                ;28442  ;DIAG.IDLE:
                ;28443  ;
                ;28444  ;       BEN0/F0,
                ;28445  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;28446  ;       BEN2/F2,
                ;28447  ;       NAD/DIAG.IDLE
                ;28448  ;-------------------------------------------------------------------------
                ;28449  ;01F:
                ;28450  ;=111
                ;28451  ;
                ;28452  ;       BEN0/CRDY.L,
                ;28453  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;28454  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;28455  ;-------------------------------------------------------------------------
                ;28456  ;079:
                ;28457  ;=0*1
                ;28458  ;
                ;28459  ;       NAD/GROUP1
                ;28460  ;-------------------------------------------------------------------------
                ;28461  ;182:
                ;28462  ;=0**
                ;28463  ;GROUP1:
                ;28464  ;
                ;28465  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;28466  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;28467  ;                                       ; FUNCTION BITS
                ;28468  ;-------------------------------------------------------------------------
                ;28469  ;186:
```

```
;28470  ;=1**
;28471  ;
;28472  ;       BEN0/F0,
;28473  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;28474  ;       BEN2/F2,
;28475  ;       NAD/GROUP1.F0
;28476  ;-------------------------------------------------------------------------
;28477  ;028:
;28478  ;=000
;28479  ;GROUP1.F0:
;28480  ;
;28481  ;CLR.MATCH.1:
;28482  ;
;28483  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;28484  ;       NAD/TEST.MATCH.1
;28485  ;-------------------------------------------------------------------------
;28486  ;1F6:
;28487  ;TEST.MATCH.1:
;28488  ;
;28489  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;28490  ;       NAD/BEN2.1
;28491  ;-------------------------------------------------------------------------
;28492  ;1A0:
;28493  ;=0**
;28494  ;BEN2.1:
;28495  ;
;28496  ;       INCR.DAR/ON,                    ;INCR DAR
;28497  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;28498  ;-------------------------------------------------------------------------
;28499  ;1A4:
;28500  ;=1**
;28501  ;BEN2.2:
;28502  ;
;28503  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;28504  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;28505  ;-------------------------------------------------------------------------
;28506  ;1D8:
;28507  ;XFER.REQ:
;28508  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;28509  ;       NAD/DIAG.WAIT
;28510  ;-------------------------------------------------------------------------
;28511  ;1D7:
;28512  ;DIAG.WAIT:
;28513  ;
;28514  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;28515  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;28516  ;-------------------------------------------------------------------------
;28517  ;159:
;28518  ;=*0*
;28519  ;DIAG.WAIT1:
;28520  ;
;28521  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;28522  ;                               ; COMMAND FROM THE CPU
;28523  ;-------------------------------------------------------------------------
;28524  ;15B:
```

```
                ;28525  ;=*1*
                ;28526  ;DIAG.WAIT2:
                ;28527  ;
                ;28528  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;28529  ;                               ; WAIT SOME MORE
                ;28530  ;-------------------------------------------------------------------------
                ;28531  WAIT.IDC.T32.1:
U 17B0, DB00,1A ;28532          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 17B1, 097B,34 ;28533          JMP [IDC.DONE.T32.1]                    ;XFER REQ SET
U 17B2, 097B,04 ;28534          JMP [WAIT.IDC.T32.1]                    ;WAIT SOME MORE
                ;28535
                ;28536  IDC.DONE.T32.1:
U 17B3, B700,15 ;28537          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 17B4, 17A0,15 ;28538          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 17B5, 90FA,15 ;28539          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;28540
                ;28541
                ;28542
U 17B6, A006,15 ;28543          MOV WR[3] TO WR[0]                      ;GET THE DATA TO WRITE
U 17B7, 17D8,15 ;28544          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 17B8, 17C0,15 ;28545          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
U 17B9, 17AC,15 ;28546          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE THE DATA TO THE FIFO
U 17BA, 17C0,15 ;28547          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADRS = 0
                ;28548
U 17BB, 2F80,15 ;28549          CLR WR[0]                               ;GET THE DATA TO WRITE THE DAR
U 17BC, 97A4,15 ;28550          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
                ;28551
                ;28552  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;28553
U 17BD, 370E,15 ;28554          MOV LS[SETCSR.F7] TO WR[0]
U 17BE, 17A0,15 ;28555          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28556                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;28557  ;CONTINUE TO BRANCH
U 17BF, 379E,15 ;28558          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 17C0, B704,95 ;28559          MOV LS[SETCSR.F2] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 17C1, AEC2,15 ;28560          BIS WR[1] TO WR[0]
U 17C2, B720,95 ;28561          MOV LS[SETCSR.MAINT] TO WR[1]           ;SET MAINT TO SEL WRTCHK TEST
U 17C3, AEC2,15 ;28562          BIS WR[1] TO WR[0]
U 17C4, AEC4,15 ;28563          BIS WR[2] TO WR[0]                      ;INCLUDE THE RL02 DRV SELECT
U 17C5, 17A0,15 ;28564          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28565                                                  ;FUNC<2:0>=010
                ;28566
                ;28567  ;-------------------------------------------------------------------------
                ;28568  ;-------------------------------------------------------------------------
                ;28569  ;                               *******
                ;28570  ;                               * IDC *
                ;28571  ;                               *******
                ;28572  ;-------------------------------------------------------------------------
                ;28573  ;018:
                ;28574  ;=000
                ;28575  ;DIAG.IDLE:
                ;28576  ;
                ;28577  ;       BEN0/F0,
                ;28578  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;28579  ;       BEN2/F2,
```

```
;28580  ;       NAD/DIAG.IDLE
;28581  ;-------------------------------------------------------------------------
;28582  ;01F:
;28583  ;=111
;28584  ;
;28585  ;       BEN0/CRDY.L,
;28586  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;28587  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;28588  ;-------------------------------------------------------------------------
;28589  ;079:
;28590  ;=0*1
;28591  ;
;28592  ;       NAD/GROUP1
;28593  ;-------------------------------------------------------------------------
;28594  ;182:
;28595  ;=0**
;28596  ;GROUP1:
;28597  ;
;28598  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;28599  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;28600  ;                                       ; FUNCTION BITS
;28601  ;-------------------------------------------------------------------------
;28602  ;186:
;28603  ;=1**
;28604  ;
;28605  ;       BEN0/F0,
;28606  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;28607  ;       BEN2/F2,
;28608  ;       NAD/GROUP1.F0
;28609  ;-------------------------------------------------------------------------
;28610  ;02A:
;28611  ;=010
;28612  ;MATCH.OR.WRTCHK.1:
;28613  ;
;28614  ;       UMAINT/ON,
;28615  ;       LOOP.LOCK/ON,           ;MAINT PREVENTS LOOP LOCK FROM SELECTING
;28616  ;       DISK.WRITE/ON,          ;READ DATA...DISK WRITE STILL SELECTS DSR0
;28617  ;       LOAD.LOOP.CNTR.[0E0],
;28618  ;       NAD/MATCH.OR.WRTCHK.2
;28619  ;-------------------------------------------------------------------------
;28620  ;198:
;28621  ;=0
;28622  ;MATCH.OR.WRTCHK.2:
;28623  ;
;28624  ;       UMAINT/ON,
;28625  ;       LOOP.LOCK/ON,           ;SHIFT OUT 32 ZEROS TO SYNC UP
;28626  ;       DISK.WRITE/ON,          ; DATA SEPARATOR
;28627  ;       UCMD/SET.FIFOA,
;28628  ;       INCR.LPCNTR/ON,
;28629  ;       BEN0/CNTR.OVFLW,
;28630  ;       NAD/MATCH.OR.WRTCHK.2
;28631  ;-------------------------------------------------------------------------
;28632  ;199:
;28633  ;=1
;28634  ;MATCH.OR.WRTCHK.3:
```

```
;28635  ;
;28636  ;       UMAINT/ON,
;28637  ;       LOOP.LOCK/ON,
;28638  ;       DISK.WRITE/ON,                  ;MUST WAIT 3 CYCLES FOR SYNC SEEN
;28639  ;       ENB.DSK.CLK,
;28640  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;28641  ;       NAD/MATCH.OR.WRTCHK.4           ; FOR THE MATCH TEST
;28642  ;-------------------------------------------------------------------------------
;28643  ;1F2:
;28644  ;MATCH.OR.WRTCHK.4:
;28645  ;
;28646  ;       UMAINT/ON,
;28647  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;28648  ;       DISK.WRITE/ON,
;28649  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;28650  ;       NAD/MATCH.OR.WRTCHK.5           ; FOR THE MATCH TEST
;28651  ;-------------------------------------------------------------------------------
;28652  ;1F3:
;28653  ;MATCH.OR.WRTCHK.5:
;28654  ;
;28655  ;       UMAINT/ON,
;28656  ;       LOOP.LOCK/ON,                   ;WAIT SOME MORE
;28657  ;       DISK.WRITE/ON,
;28658  ;       ENB.CLR.BC/ON,                  ;CLR THE BIT COUNTER WHEN SYNC SEEN
;28659  ;       NAD/MATCH.OR.WRTCHK.6           ; FOR THE MATCH TEST
;28660  ;-------------------------------------------------------------------------------
;28661  ;1F4:
;28662  ;MATCH.OR.WRTCHK.6:
;28663  ;
;28664  ;       UMAINT/ON,
;28665  ;       LOOP.LOCK/ON,
;28666  ;       DISK.WRITE/ON,          ;LOAD THE DATA FROM FIFO A INTO THE DSR
;28667  ;       ENB.FIFO/ON,            ;PREVIOUS CODE IS USED FOR MATCH TESTS AND
;28668  ;       LOAD.DSR/ON,            ;WRT CHK TESTS, SO NOW USE DIFFERNT CODE FOR
;28669  ;                               ; THE REST OF EACH TEST
;28670  ;       BEN2/MAINT,             ;MATCH TEST OR WRTCHK TEST?
;28671  ;       NAD/MATCH.OR.WRTCHK.7
;28672  ;-------------------------------------------------------------------------------
;28673  ;187:
;28674  ;=1**
;28675  ;MATCH.OR.WRTCHK.8:
;28676  ;       UMAINT/ON,
;28677  ;       LOOP.LOCK/ON,
;28678  ;       DISK.WRITE/ON,          ;WRITE CHECK TEST
;28679  ;       LOAD.LOOP.CNTR.[0FE],
;28680  ;       INCR.FIFO.CNTR/ON,      ;SET ADRS TO NEXT BYTE OF DATA
;28681  ;       NAD/WRT.CHK.1
;28682  ;-------------------------------------------------------------------------------
;28683  ;19C:
;28684  ;=0
;28685  ;WRT.CHK.1:
;28686  ;
;28687  ;       UMAINT/ON,
;28688  ;       LOOP.LOCK/ON,
;28689  ;       DISK.WRITE/ON,                  ;WAIT FOR DATA TO SHIFT THRU DISKLESS
```

```
;28690  ;       INCR.LPCNTR/ON,                 ; LOOP TO BECOME RD DATA
;28691  ;       BEN0/CNTR.OVFLW,
;28692  ;       WRT.CHK/ON,
;28693  ;       NAD/WRT.CHK.1
;28694  ;-------------------------------------------------------------------------
;28695  ;19D:
;28696  ;=1
;28697  ;WRT.CHK.2:
;28698  ;       UMAINT/ON,
;28699  ;       LOOP.LOCK/ON,
;28700  ;       DISK.WRITE/ON,          ;LOAD THE SECOND BYTE OF THE DATA FROM FIFO A
;28701  ;       ENB.FIFO/ON,            ; INTO THE DSR
;28702  ;       LOAD.DSR/ON,
;28703  ;       WRT.CHK/ON,
;28704  ;       NAD/WRT.CHK.3
;28705  ;-------------------------------------------------------------------------
;28706  ;1F7:
;28707  ;WRT.CHK.3:
;28708  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;28709  ;       LOOP.LOCK/ON,                   ; GOING
;28710  ;       DISK.WRITE/ON,
;28711  ;       WRT.CHK/ON,
;28712  ;       NAD/WRT.CHK.4
;28713  ;-------------------------------------------------------------------------
;28714  ;1F8:
;28715  ;WRT.CHK.4:
;28716  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;28717  ;       LOOP.LOCK/ON,                   ; GOING AND TEST MATCH
;28718  ;       DISK.WRITE/ON,
;28719  ;       UCON/TEST.MATCH,
;28720  ;       WRT.CHK/ON,
;28721  ;       NAD/WRT.CHK.5
;28722  ;-------------------------------------------------------------------------
;28723  ;1F9:
;28724  ;WRT.CHK.5:
;28725  ;       UMAINT/ON,                      ;KEEP THE CLK FROM THE DATA SEPARATOR
;28726  ;       LOOP.LOCK/ON,
;28727  ;       DISK.WRITE/ON,
;28728  ;       ENB.CPU.CLK,                    ;SELECT THE CPU CLK
;28729  ;       NAD/TEST.MATCH.1
;28730  ;-------------------------------------------------------------------------
;28731  ;1F6:
;28732  ;TEST.MATCH.1:
;28733  ;
;28734  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;28735  ;       NAD/BEN2.1
;28736  ;-------------------------------------------------------------------------
;28737  ;1A0:
;28738  ;=0**
;28739  ;BEN2.1:
;28740  ;
;28741  ;       INCR.DAR/ON,                    ;INCR DAR
;28742  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;28743  ;-------------------------------------------------------------------------
;28744  ;1A4:
```

```
                ;28745  ;=1**
                ;28746  ;BEN2.2:
                ;28747  ;
                ;28748  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;28749  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;28750  ;-------------------------------------------------------------------------
                ;28751  ;1D8:
                ;28752  ;XFER.REQ:
                ;28753  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;28754  ;       NAD/DIAG.WAIT
                ;28755  ;-------------------------------------------------------------------------
                ;28756  ;1D7:
                ;28757  ;DIAG.WAIT:
                ;28758  ;
                ;28759  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;28760  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;28761  ;-------------------------------------------------------------------------
                ;28762  ;159:
                ;28763  ;=*0*
                ;28764  ;DIAG.WAIT1:
                ;28765  ;
                ;28766  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;28767  ;                               ; COMMAND FROM THE CPU
                ;28768  ;-------------------------------------------------------------------------
                ;28769  ;15B:
                ;28770  ;=*1*
                ;28771  ;DIAG.WAIT2:
                ;28772  ;
                ;28773  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;28774  ;                               ; WAIT SOME MORE
                ;28775  ;-------------------------------------------------------------------------
                ;28776  WAIT.IDC.T32.2:
U 17C6, DB00,1A ;28777          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 17C7, 897C,94 ;28778          JMP [IDC.DONE.T32.2]                    ;XFER REQ SET
U 17C8, 897C,64 ;28779          JMP [WAIT.IDC.T32.2]                    ;WAIT SOME MORE
                ;28780
                ;28781  IDC.DONE.T32.2:
U 17C9, B700,15 ;28782          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 17CA, 17A0,15 ;28783          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 17CB, 90FA,15 ;28784          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;28785
                ;28786  READ.DAR.T32.1:
U 17CC, 9090,15 ;28787          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 17CD, 1784,15 ;28788          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 17CE, 3B32,15 ;28789          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;28790                                                  ; SAVE IT IN  LS
U 17CF, 3732,15 ;28791          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 17D0, 3610,95 ;28792          MOV LS[T8] TO WR[1]                     ;SET UP EXPECTED DATA
                ;28793
U 17D1, BE89,95 ;28794          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT OTHER DATA
                ;28795
U 17D2, 0869,3C ;28796          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 17D3, 897A,A4 ;28797          JMP [LOOP.T32.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;28798
U 17D4, 3612,15 ;28799          MOV LS[T9] TO WR[0]                     ;GET THE LOOP CNTR
```

```
                ;28800          TST WR[0],
U 17D5, 2000,35 ;28801           DT(LONG)&SET.ALU.CC
U 17D6, 897E,39 ;28802          JMP.IF[EQL] TO [CLEANUP.T32]            ;JUMP IF DONE
                ;28803
                ;28804          CMP LS[#1] WITH WR[0],                  ;LAST PAT?
U 17D7, 4E40,35 ;28805           DT(LONG)&SET.ALU.CC
U 17D8, 897D,E1 ;28806          JMP.IF[NEQ] TO [CHK.NXT.T32]            ;JMP IF NOT LAST
                ;28807
                ;28808  ;SET UP THE LAST DATA PATTERN
U 17D9, 3651,95 ;28809          MOV LS[#100] TO WR[3]                   ;SET UP THE DATA PAT
U 17DA, B640,15 ;28810          MOV LS[#1] TO WR[0]                     ;SET UP THE EXPECTED DATA
U 17DB, 3E10,15 ;28811          MOV WR[0] TO LS[T8]                     ;SAV EXP DATA IN LS[T8]
U 17DC, FC12,15 ;28812          DEC LS[T9]                              ;DECREMENT THE LOOP CNTR
U 17DD, 897A,A4 ;28813          JMP [TST.NXT.PAT.T32]                   ;GO TEST THE PATTERN
                ;28814
                ;28815  CHK.NXT.T32:
                ;28816  ;SET UP THE SECOND DATA PATTERN
U 17DE, B641,95 ;28817          MOV LS[#1] TO WR[3]                     ;SET UP THE DATA PAT
U 17DF, B640,15 ;28818          MOV LS[#1] TO WR[0]                     ;SET UP THE EXPECTED DATA
U 17E0, 3E10,15 ;28819          MOV WR[0] TO LS[T8]                     ;SAV EXP IN LS[T8]
U 17E1, FC12,15 ;28820          DEC LS[T9]                              ;DECREMENT THE LOOP CNTR
U 17E2, 897A,A4 ;28821          JMP [TST.NXT.PAT.T32]                   ;GO TEST THE PATTERN
                ;28822
                ;28823  CLEANUP.T32:
U 17E3, 370E,15 ;28824          MOV LS[SETCSR.F7] TO WR[0]
U 17E4, 17A0,15 ;28825          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28826                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;28827  ;CONTINUE TO BRANCH
U 17E5, 379E,15 ;28828          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 17E6, 3700,95 ;28829          MOV LS[SETCSR.F0] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 17E7, AEC2,15 ;28830          BIS WR[1] TO WR[0]
U 17E8, 17A0,15 ;28831          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;28832                                                  ;F<2:0> = 000
                ;28833  ;UCLR MATCH
                ;28834  ;-------------------------------------------------------------------------------
                ;28835  ;-------------------------------------------------------------------------------
                ;28836  ;                                *******
                ;28837  ;                                * IDC *
                ;28838  ;                                *******
                ;28839  ;-------------------------------------------------------------------------
                ;28840  ;018:
                ;28841  ;=000
                ;28842  ;DIAG.IDLE:
                ;28843  ;
                ;28844  ;       BEN0/F0,
                ;28845  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;28846  ;       BEN2/F2,
                ;28847  ;       NAD/DIAG.IDLE
                ;28848  ;-------------------------------------------------------------------------
                ;28849  ;01F:
                ;28850  ;=111
                ;28851  ;
                ;28852  ;       BEN0/CRDY.L,
                ;28853  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;28854  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
```

```
;28855  ;-------------------------------------------------------------------------
;28856  ;079:
;28857  ;=0*1
;28858  ;
;28859  ;       NAD/GROUP1
;28860  ;-------------------------------------------------------------------------
;28861  ;182:
;28862  ;=0**
;28863  ;GROUP1:
;28864  ;
;28865  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;28866  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;28867  ;                                       ; FUNCTION BITS
;28868  ;-------------------------------------------------------------------------
;28869  ;186:
;28870  ;=1**
;28871  ;
;28872  ;       BEN0/F0,
;28873  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;28874  ;       BEN2/F2,
;28875  ;       NAD/GROUP1.F0
;28876  ;-------------------------------------------------------------------------
;28877  ;028:
;28878  ;=000
;28879  ;GROUP1.F0:
;28880  ;
;28881  ;CLR.MATCH.1:
;28882  ;
;28883  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;28884  ;       NAD/TEST.MATCH.1
;28885  ;-------------------------------------------------------------------------
;28886  ;1F6:
;28887  ;TEST.MATCH.1:
;28888  ;
;28889  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;28890  ;       NAD/BEN2.1
;28891  ;-------------------------------------------------------------------------
;28892  ;1A0:
;28893  ;=0**
;28894  ;BEN2.1:
;28895  ;
;28896  ;       INCR.DAR/ON,                    ;INCR DAR
;28897  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;28898  ;-------------------------------------------------------------------------
;28899  ;1A4:
;28900  ;=1**
;28901  ;BEN2.2:
;28902  ;
;28903  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;28904  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;28905  ;-------------------------------------------------------------------------
;28906  ;1D8:
;28907  ;XFER.REQ:
;28908  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;28909  ;       NAD/DIAG.WAIT
```

```
                ;28910  ;-----------------------------------------------------------------------
                ;28911  ;1D7:
                ;28912  ;DIAG.WAIT:
                ;28913  ;
                ;28914  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;28915  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;28916  ;-----------------------------------------------------------------------
                ;28917  ;159:
                ;28918  ;=*0*
                ;28919  ;DIAG.WAIT1:
                ;28920  ;
                ;28921  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;28922  ;                               ; COMMAND FROM THE CPU
                ;28923  ;-----------------------------------------------------------------------
                ;28924  ;15B:
                ;28925  ;=*1*
                ;28926  ;DIAG.WAIT2:
                ;28927  ;
                ;28928  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;28929  ;                               ; WAIT SOME MORE
                ;28930  ;-----------------------------------------------------------------------
                ;28931  WAIT.IDC.T32.3:
U 17E9, DB00,1A ;28932          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 17EA, 097E,C4 ;28933          JMP [IDC.DONE.T32.3]                    ;XFER REQ SET
U 17EB, 097E,94 ;28934          JMP [WAIT.IDC.T32.3]                    ;WAIT SOME MORE
                ;28935
                ;28936  IDC.DONE.T32.3:
U 17EC, B700,15 ;28937          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 17ED, 17A0,15 ;28938          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 17EE, 90FA,15 ;28939          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;28940
U 17EF, 8875,3C ;28941          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY THIS
                ;28942                                                  ; TEST
                ;28943  END.T32:                                        ;END TEST
                ;28944
```

```
;28945  .PAGE  "Test 33  ATTENTION REGISTER TEST 1 (M8388 IDC MODULE)"
;28946  ;++
;28947  ;
;28948  ; Test Description:
;28949  ;
;28950  ;       This test is designed to test the Attention Register PAL. The
;28951  ;       Attention bits <3:0> are CSR bits <19:16>. These bits can be set
;28952  ;       only by the IDC microcode and are cleared by INIT or writing ones to
;28953  ;       the CSR.
;28954  ;       The Attention bits <3:0> will first be cleared by issuing a CLEAR IDC
;28955  ;       to init the IDC. The CSR will then be read to insure that bits <19:16>
;28956  ;       cleared.
;28957  ;       Then, each attention bit beginning with <0>, will be set independently,
;28958  ;       and all attention bits checked to verify that they are in the correct
;28959  ;       state. After all attention bits are set, bits <19:16> will be written
;28960  ;       as zeros. The CSR will then be read to insure that the ATTENTION BITS
;28961  ;       remained set since the ATTN bits are write one to clear bits.
;28962  ;
;28963  ; Assumptions:
;28964  ;
;28965  ;       It is assumed that all previous tests have run successfully.
;28966  ;
;28967  ; Test Steps:
;28968  ;
;28969  ;       1. Set up error mask, error number and module number in LS
;28970  ;          (for error printouts) and clear the previous error number in LS.
;28971  ;       2. INIT the IDC and force the IDC microcode to DIAG.IDLE.
;28972  ;       3. Check CSR bits <19:16> for zeros.
;28973  ;       4. Increment the error number.
;28974  ;       5. Select Drive 0.
;28975  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;28976  ;
;28977  ;
;28978  ;                                       *******
;28979  ;                                       * IDC *
;28980  ;                                       *******
;28981  ;
;28982  ;               IDC1. Execute an instruction with FUNC <35:32> = 0B,
;28983  ;                     USET.ATTN.
;28984  ;               IDC2. Issue XFER.REQ to flag the CPU.
;28985  ;
;28986  ;       7. Wait for an XFER.REQ from IDC.
;28987  ;       8. Clear CSR F<2:0> and issue XFER GRANT to clear the XFER.REQ.
;28988  ;       9. Check CSR <19:16>.
;28989  ;      10. Select the next drive and go to Step 6 until all drives have been
;28990  ;          tested.
;28991  ;      11. Increment the error number.
;28992  ;      12. Write zeros to CSR <19:16>.
;28993  ;      13. Check CSR <19:16> remain set.
;28994  ;      14. Clear IDC.
;28995  ;      15. End test.
;28996  ;
;28997  ; Errors:
;28998  ;
;28999  ;                 Printout:
```

```
;29000  ;                              EXPECTED          RECEIVED          OTHER DATA
;29001  ;                                CSR               CSR            DRV NUM SELECTED
;29002  ;                                                                  BITS<9:8> LS[T8]
;29003  ;
;29004  ;       ERROR 1 - CSR bits <19:16> did not clear when INIT was issued.
;29005  ;
;29006  ;       ERROR 2 - ATTENTION BIT 0 did not set or did not set independently.
;29007  ;
;29008  ;       ERROR 3 - ATTENTION BIT 1 did not set or did not set independently.
;29009  ;
;29010  ;       ERROR 4 - ATTENTION BIT 2 did not set or did not set independently.
;29011  ;
;29012  ;       ERROR 5 - ATTENTION BIT 3 did not set or did not set independently.
;29013  ;
;29014  ;       ERROR 6 - One or more of the ATTENTION BITS cleared when writing zeros
;29015  ;                 to the CSR.
;29016  ;
;29017  ; Debug:
;29018  ;
;29019  ; ERROR 1 -
;29020  ;       The CPU issues a series of PORT.CONTROL [CLEAR.IDC] instructions which
;29021  ;       are decoded by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L.
;29022  ;       At the next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the
;29023  ;       next clock INIT H is asserted. INIT H is an input to the ATTN REG PAL
;29024  ;       and when it asserts BUS IO <19:16> (CSR 19:16) will clear.
;29025  ;
;29026  ; ERROR 2 -
;29027  ;       Drive 0 is selected by CSR <9:8>. The IDC will branch to an instruction
;29028  ;       with F<3:0> = 1011. These bits will be decoded and will assert
;29029  ;       USET ATTN L. The inputs to the ATTN REG PAL will then be:
;29030  ;               DRIVE SEL 1 H = L
;29031  ;               DRIVE SEL 0 H = L
;29032  ;               USET ATTN L = L
;29033  ;       At the next P2 CLOCK L, BUS IO 16 H will assert.
;29034  ;       The CPU will then issue a READ.PORT PORT.ADRS[CSR] which is decoded
;29035  ;       by the PORT INTERFACE REG PAL and DECODER and will assert SEL CSR L.
;29036  ;       SEL CSR L is the enable for the ATTN REG PAL and allows BUS IO <19:16>
;29037  ;       to be read as CSR <19:16>.
;29038  ;
;29039  ; ERROR 3 -
;29040  ;       Drive 1 is selected by CSR <9:8>. The IDC will branch to an instruction
;29041  ;       with F<3:0> = 1011. These bits will be decoded and will assert
;29042  ;       USET ATTN L. The inputs to the ATTN REG PAL will then be:
;29043  ;               DRIVE SEL 1 H = L
;29044  ;               DRIVE SEL 0 H = H
;29045  ;               USET ATTN L = L
;29046  ;       At the next P2 CLOCK L, BUS IO 17 H will assert. BUS IO 16 should still
;29047  ;       be asserted.
;29048  ;       The CPU will then issue a READ.PORT PORT.ADRS[CSR] which is decoded
;29049  ;       by the PORT INTERFACE REG PAL and DECODER and will assert SEL CSR L.
;29050  ;       SEL CSR L is the enable for the ATTN REG PAL and allows BUS IO <19:16>
;29051  ;       to be read as CSR <19:16>.
;29052  ;
;29053  ; ERROR 4 -
;29054  ;       Drive 2 is selected by CSR <9:8>. The IDC will branch to an instruction
```

```
                    ;29055  ;       with F<3:0> = 1011. These bits will be decoded and will assert
                    ;29056  ;       USET ATTN L. The inputs to the ATTN REG PAL will then be:
                    ;29057  ;               DRIVE SEL 1 H = H
                    ;29058  ;               DRIVE SEL 0 H = L
                    ;29059  ;               USET ATTN L = L
                    ;29060  ;       At the next P2 CLOCK L, BUS IO 18 H will assert. BUS IO 17 and
                    ;29061  ;       BUS IO 16 should still be asserted.
                    ;29062  ;       The CPU will then issue a READ.PORT PORT.ADRS[CSR] which is decoded
                    ;29063  ;       by the PORT INTERFACE REG PAL and DECODER and will assert SEL CSR L.
                    ;29064  ;       SEL CSR L is the enable for the ATTN REG PAL and allows BUS IO <19:16>
                    ;29065  ;       to be read as CSR <19:16>.
                    ;29066  ;
                    ;29067  ; ERROR 5 -
                    ;29068  ;       Drive 3 is selected by CSR <9:8>. The IDC will branch to an instruction
                    ;29069  ;       with F<3:0> = 1011. These bits will be decoded and will assert
                    ;29070  ;       USET ATTN L. The inputs to the ATTN REG PAL will then be:
                    ;29071  ;               DRIVE SEL 1 H = H
                    ;29072  ;               DRIVE SEL 0 H = H
                    ;29073  ;               USET ATTN L = L
                    ;29074  ;       At the next P2 CLOCK L, BUS IO 19 H will assert. BUS IO 18 and
                    ;29075  ;       BUS IO 17 and BSU IO 16 should still be asserted.
                    ;29076  ;       The CPU will then issue a READ.PORT PORT.ADRS[CSR] which is decoded
                    ;29077  ;       by the PORT INTERFACE REG PAL and DECODER and will assert SEL CSR L.
                    ;29078  ;       SEL CSR L is the enable for the ATTN REG PAL and allows BUS IO <19:16>
                    ;29079  ;       to be read as CSR <19:16>.
                    ;29080  ;
                    ;29081  ; ERROR 6-
                    ;29082  ;       ATTN BITS <3:0> are all asserted. The CPU will then issue a
                    ;29083  ;       PORT.WRITE PORT.ADRS[CSR] with bits <19:16> = 0000. This instruction
                    ;29084  ;       will be decoded by the PORT RD/WR DECODE PAL and will assert
                    ;29085  ;       WRITE CSR L. The inputs to the ATTN REG PAL will now be:
                    ;29086  ;               WRITE CSR L = L
                    ;29087  ;               BUS IO 19 H = L
                    ;29088  ;               BUS IO 18 H = L
                    ;29089  ;               BUS IO 17 H = L
                    ;29090  ;               BUS IO 16 H = L
                    ;29091  ;       This combination of inputs should not affect the latched up outputs of
                    ;29092  ;       the ATTN REG PAL and ATTN BIT <3:0> should all remain asserted.
                    ;29093  ;--
                    ;29094  ;*******************************************************************************
                    ;29095  T.33:
U 17F0, B65E,15     ;29096          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                    ;29097                                                  ; CONTROL AND STATUS WORD
U 17F1, 3E80,15     ;29098          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                    ;29099                                                  ; STATUS WORD - BIT 15
                    ;29100                                                  ; INDICATES START OF TEST TO
                    ;29101                                                  ; CONSOLE
U 17F2, 10E0,15     ;29102          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                    ;29103  WAIT.T33.0:
U 17F3, 897F,34     ;29104          JMP [WAIT.T33.0]                        ;LOOP HERE WAITING FOR
                    ;29105                                                  ; CONSOLE TO RESPOND
                    ;29106
U 17F4, 65A0,15     ;29107          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                    ;29108                                                  ; IN LS
                    ;29109
```

```
U 17F5, B64A,15 ;29110          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 17F6, 3E8C,15 ;29111          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;29112
U 17F7, B640,15 ;29113          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 17F8, BE82,15 ;29114          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;29115
                ;29116
U 17F9, 37BC,15 ;29117          MOV LS[#FFF0FFFF] TO WR[0]              ;SET UP THE MASK TO CHECK
U 17FA, 3E8A,15 ;29118          MOV WR[0] TO LS[ERROR.MASK]             ; BIT <19:16>
                ;29119
U 17FB, B670,15 ;29120          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 17FC, 3E80,15 ;29121          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
                ;29122
                ;29123  LOOP.T33.1:
U 17FD, 8872,EC ;29124          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;29125                                                  ; AND INIT THE IDC
                ;29126  ;INIT SHOULD CLEAR CSR<19:16>
                ;29127
                ;29128  READ.CSR.T33.1:
U 17FE, 9090,15 ;29129          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 17FF, 9780,15 ;29130          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1800, 3B32,15 ;29131          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;29132                                                  ; SAVE IT IN  LS
U 1801, 3732,15 ;29133          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1802, 2F82,95 ;29134          CLR WR[1]                               ;SET UP THE EXPECTED DATA
U 1803, 3E88,95 ;29135          MOV WR[1] TO LS[ADDRESS.DATA]           ;CLR OTHER DATA
U 1804, 0869,3C ;29136          JSR [CHECK.RESULT]                      ;GO CHECK THE DATA
U 1805, 097F,D4 ;29137          JMP [LOOP.T33.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;29138
                ;29139
                ;29140  LOOP1.T33.2:
U 1806, 3642,15 ;29141          MOV LS[#2] TO WR[0]
U 1807, BE82,15 ;29142          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 2
                ;29143
U 1808, B714,15 ;29144          MOV LS[SETCSR.DS0] TO WR[0]             ;GET THE FIRST DRIVE NUM
U 1809, 3E10,15 ;29145          MOV WR[0] TO LS[T8]                     ;SAVE IN LS[T8]
U 180A, 3660,15 ;29146          MOV LS[#10000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 180B, BE12,15 ;29147          MOV WR[0] TO LS[T9]                     ;SAV EXP DATA IN LS[T9]
                ;29148
                ;29149  TST.NXT.T33:
U 180C, 370E,15 ;29150          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 180D, 17A0,15 ;29151          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                ;29152
                ;29153  ;CONTINUE TO BRANCH
U 180E, 379E,15 ;29154          MOV LS[SETCSR.R80] TO WR[0]
                ;29155
U 180F, 3712,95 ;29156          MOV LS[SETCSR.CRDY] TO WR[1]
U 1810, AEC2,15 ;29157          BIS WR[1] TO WR[0]
U 1811, B708,95 ;29158          MOV LS[SETCSR.F4] TO WR[1]
U 1812, AEC2,15 ;29159          BIS WR[1] TO WR[0]
U 1813, 3610,95 ;29160          MOV LS[T8] TO WR[1]                     ;INCLUDE THE DRIVE SELECT
U 1814, AEC2,15 ;29161          BIS WR[1] TO WR[0]
U 1815, 17A0,15 ;29162          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;29163                                                  ;F<2:0>=100
                ;29164  ;USET.ATTN....drive number selected by CSR <9:8>
```

```
;29165  ;-------------------------------------------------------------------------
;29166  ;-------------------------------------------------------------------------
;29167  ;                               *******
;29168  ;                               * IDC *
;29169  ;                               *******
;29170  ;-------------------------------------------------------------------------
;29171  ;018:
;29172  ;=000
;29173  ;DIAG.IDLE:
;29174  ;
;29175  ;       BEN0/F0,
;29176  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;29177  ;       BEN2/F2,
;29178  ;       NAD/DIAG.IDLE
;29179  ;-------------------------------------------------------------------------
;29180  ;01F:
;29181  ;=111
;29182  ;
;29183  ;       BEN0/CRDY.L,
;29184  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;29185  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;29186  ;-------------------------------------------------------------------------
;29187  ;079:
;29188  ;=0*1
;29189  ;
;29190  ;       NAD/GROUP1
;29191  ;-------------------------------------------------------------------------
;29192  ;182:
;29193  ;=0**
;29194  ;GROUP1:
;29195  ;
;29196  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;29197  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;29198  ;                                       ; FUNCTION BITS
;29199  ;-------------------------------------------------------------------------
;29200  ;186:
;29201  ;=1**
;29202  ;
;29203  ;       BEN0/F0,
;29204  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;29205  ;       BEN2/F2,
;29206  ;       NAD/GROUP1.F0
;29207  ;-------------------------------------------------------------------------
;29208  ;02C:
;29209  ;=100
;29210  ;USET.ATTN:
;29211  ;
;29212  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
;29213  ;                               ;INTERRUPTS
;29214  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
;29215  ;-------------------------------------------------------------------------
;29216  ;1D8:
;29217  ;XFER.REQ:
;29218  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;29219  ;       NAD/DIAG.WAIT
```

```
                ;29220  ;-------------------------------------------------------------------------
                ;29221  ;1D7:
                ;29222  ;DIAG.WAIT:
                ;29223  ;
                ;29224  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;29225  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;29226  ;-------------------------------------------------------------------------
                ;29227  ;159:
                ;29228  ;=*0*
                ;29229  ;DIAG.WAIT1:
                ;29230  ;
                ;29231  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;29232  ;                               ; COMMAND FROM THE CPU
                ;29233  ;-------------------------------------------------------------------------
                ;29234  ;15B:
                ;29235  ;=*1*
                ;29236  ;DIAG.WAIT2:
                ;29237  ;
                ;29238  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;29239  ;                               ; WAIT SOME MORE
                ;29240  ;-------------------------------------------------------------------------
                ;29241  WAIT.IDC.T33.1:
U 1816, DB00,1A ;29242          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1817, 0981,94 ;29243          JMP [IDC.DONE.T33.1]                    ;XFER REQ SET
U 1818, 0981,64 ;29244          JMP [WAIT.IDC.T33.1]                    ;WAIT SOME MORE
                ;29245
                ;29246  IDC.DONE.T33.1:
U 1819, B700,15 ;29247          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 181A, 17A0,15 ;29248          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 181B, 90FA,15 ;29249          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;29250
                ;29251  READ.CSR.T33.2:
U 181C, 9090,15 ;29252          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 181D, 9780,15 ;29253          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 181E, 3B32,15 ;29254          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;29255                                                  ; SAVE IT IN  LS
U 181F, B610,15 ;29256          MOV LS[T8] TO WR[0]
U 1820, BE88,15 ;29257          MOV WR[0] TO LS[ADDRESS.DATA]           ;PUT DRIVE NUM IN OTHER DATA
U 1821, 3732,15 ;29258          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1822, B612,95 ;29259          MOV LS[T9] TO WR[1]                     ;SET UP THE EXPECTED DATA
U 1823, 0869,3C ;29260          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1824, 0984,64 ;29261          JMP [LOOP.T33.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;29262
U 1825, FF82,15 ;29263          INC LS[ERROR.NUMBER]                    ;NEXT ERROR NUMBER
                ;29264
U 1826, 3611,15 ;29265          MOV LS[T8] TO WR[2]                     ;GET THE CURRENT DRIVE NUMBER
U 1827, 4051,15 ;29266          ADD LS[#100] TO WR[2]                   ;SELECT THE NEXT DRIVE NUMBER
                ;29267          CMP LS[#400] WITH WR[2],                ;DONE?
U 1828, CE55,35 ;29268           DT(LONG)&SET.ALU.CC
U 1829, 8983,89 ;29269          JMP.IF[EQL] TO [CHK.CLR.T33]            ;JUMP IF DONE
                ;29270
U 182A, BE11,15 ;29271          MOV WR[2] TO LS[T8]                     ;SAV THE NEW DRIVE SELECT
                ;29272          CMP LS[#100] WITH WR[2],                ;DRIVE 1 SELECTED?
U 182B, 4E51,35 ;29273           DT(LONG)&SET.ALU.CC
U 182C, 8983,01 ;29274          JMP.IF[NEQ] TO [NXT.EXP.T33.1]          ;JMP IF NOT
```

```
                ;29275
U 182D, B7BE,15 ;29276          MOV LS[#30000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 182E, BE12,15 ;29277          MOV WR[0] TO LS[T9]                     ;SAV EXP DATA IN LS[T9]
U 182F, 8980,C4 ;29278          JMP [TST.NXT.T33]                       ;GO TEST NEXT PAT
                ;29279
                ;29280  NXT.EXP.T33.1:
                ;29281          CMP LS[#200] WITH WR[2],                ;DRIVE 2 SELECTED?
U 1830, CE53,35 ;29282           DT(LONG)&SET.ALU.CC
U 1831, 8983,51 ;29283          JMP.IF[NEQ] TO [NXT.EXP.T33.2]          ;JMP IF NOT
                ;29284
U 1832, B7C0,15 ;29285          MOV LS[#70000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 1833, BE12,15 ;29286          MOV WR[0] TO LS[T9]                     ;SAV EXP DATA IN LS[T9]
U 1834, 8980,C4 ;29287          JMP [TST.NXT.T33]                       ;GO TEST NXT PAT
                ;29288
                ;29289  NXT.EXP.T33.2:
U 1835, 37C2,15 ;29290          MOV LS[#F0000] TO WR[0]                 ;SET THE EXP DAT FOR DRV 3
U 1836, BE12,15 ;29291          MOV WR[0] TO LS[T9]                     ;SAV IN LS[T9]
U 1837, 8980,C4 ;29292          JMP [TST.NXT.T33]                       ;GO TEST NEXT PAT
                ;29293
                ;29294  CHK.CLR.T33:
U 1838, 3792,15 ;29295          MOV LS[#6] TO WR[0]                     ;ERROR 6
U 1839, BE82,15 ;29296          MOV WR[0] TO LS[ERROR.NUMBER]
                ;29297
                ;29298                                                  ;BIT 28 PREVENTS IDC TIMEOUTS
U 183A, 3678,15 ;29299          MOV LS[BIT28] TO WR[0]                  ;WRITE ZEROS TO CSR<19:16>
U 183B, 17A0,15 ;29300          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; AND CHECK THAT ATTN<3:0>
                ;29301                                                  ; REMAIN SET
                ;29302  READ.CSR.T33.3:
U 183C, 9090,15 ;29303          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 183D, 9780,15 ;29304          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 183E, 3B32,15 ;29305          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;29306                                                  ; SAVE IT IN  LS
U 183F, 3732,15 ;29307          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1840, B612,95 ;29308          MOV LS[T9] TO WR[1]                     ;SET UP THE EXPECTED DATA
U 1841, 2F85,15 ;29309          CLR WR[2]
U 1842, 3E89,15 ;29310          MOV WR[2] TO LS[ADDRESS.DATA]           ;CLR OTHER DATA
U 1843, 086C,3C ;29311          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1844, 8984,84 ;29312          JMP [LOOP.T33.6]                        ;LOOP HERE IF ERR & LOE IS SET
                ;29313
U 1845, 0986,24 ;29314          JMP [CLEANUP.T33]                       ;CLEANUP AND END TEST
                ;29315
                ;29316
                ;29317  LOOP.T33.2:
U 1846, 8872,EC ;29318          JSR [DIAG.CODE]                         ;INIT THE IDC TO CLR ATTN BITS
U 1847, 8980,64 ;29319          JMP [LOOP1.T33.2]                       ;LOOP ON ERROR
                ;29320
                ;29321
                ;29322  LOOP.T33.6:
                ;29323  ;SET ALL ATTN BITS
U 1848, B715,95 ;29324          MOV LS[SETCSR.DS0] TO WR[3]
                ;29325
                ;29326  SET.ATTN.T33:
                ;29327  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE
                ;29328
U 1849, 370E,15 ;29329          MOV LS[SETCSR.F7] TO WR[0]
```

```
U 184A, 17A0,15 ;29330          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;29331                                                   ;MAINT=0,CRDY=0,F<2:0>=111
                ;29332  ;CONTINUE TO BRANCH
U 184B, 379E,15 ;29333          MOV LS[SETCSR.R80] TO WR[0]              ;SET UP THE CSR TO CONTINUE TO
U 184C, B708,95 ;29334          MOV LS[SETCSR.F4] TO WR[1]               ; BRANCH TO THE CORRECT ROUTINE
U 184D, AEC2,15 ;29335          BIS WR[1] TO WR[0]
U 184E, 2EC6,15 ;29336          BIS WR[3] TO WR[0]                       ;INCLUDE THE DRIVE SELECT
U 184F, 17A0,15 ;29337          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;29338
                ;29339  ;USET.ATTN....drive number selected by CSR <9:8>
                ;29340  ;-------------------------------------------------------------------------------
                ;29341  ;-------------------------------------------------------------------------------
                ;29342  ;                                *******
                ;29343  ;                                * IDC *
                ;29344  ;                                *******
                ;29345  ;-------------------------------------------------------------------------------
                ;29346  ;018:
                ;29347  ;=000
                ;29348  ;DIAG.IDLE:
                ;29349  ;
                ;29350  ;       BEN0/F0,
                ;29351  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;29352  ;       BEN2/F2,
                ;29353  ;       NAD/DIAG.IDLE
                ;29354  ;-------------------------------------------------------------------------------
                ;29355  ;01F:
                ;29356  ;=111
                ;29357  ;
                ;29358  ;       BEN0/CRDY.L,
                ;29359  ;       BEN2/MAINT,              ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;29360  ;       NAD/TEST.FUNC7           ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;29361  ;-------------------------------------------------------------------------------
                ;29362  ;079:
                ;29363  ;=0*1
                ;29364  ;
                ;29365  ;       NAD/GROUP1
                ;29366  ;-------------------------------------------------------------------------------
                ;29367  ;182:
                ;29368  ;=0**
                ;29369  ;GROUP1:
                ;29370  ;
                ;29371  ;       BEN2/R80.FORMAT.H,               ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;29372  ;       NAD/GROUP1                       ; TO NEXT WORD AND THEN BRANCH ON THE
                ;29373  ;                                        ; FUNCTION BITS
                ;29374  ;-------------------------------------------------------------------------------
                ;29375  ;186:
                ;29376  ;=1**
                ;29377  ;
                ;29378  ;       BEN0/F0,
                ;29379  ;       BEN1/F1,                 ;BRANCH ON THE CSR F<2:0> BITS
                ;29380  ;       BEN2/F2,
                ;29381  ;       NAD/GROUP1.F0
                ;29382  ;-------------------------------------------------------------------------------
                ;29383  ;02C:
                ;29384  ;=100
```

```
                ;29385  ;USET.ATTN:
                ;29386  ;
                ;29387  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
                ;29388  ;                               ;INTERRUPTS
                ;29389  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
                ;29390  ;-------------------------------------------------------------------------
                ;29391  ;1D8:
                ;29392  ;XFER.REQ:
                ;29393  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;29394  ;       NAD/DIAG.WAIT
                ;29395  ;-------------------------------------------------------------------------
                ;29396  ;1D7:
                ;29397  ;DIAG.WAIT:
                ;29398  ;
                ;29399  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;29400  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;29401  ;-------------------------------------------------------------------------
                ;29402  ;159:
                ;29403  ;=*0*
                ;29404  ;DIAG.WAIT1:
                ;29405  ;
                ;29406  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;29407  ;                               ; COMMAND FROM THE CPU
                ;29408  ;-------------------------------------------------------------------------
                ;29409  ;15B:
                ;29410  ;=*1*
                ;29411  ;DIAG.WAIT2:
                ;29412  ;
                ;29413  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;29414  ;                               ; WAIT SOME MORE
                ;29415  ;-------------------------------------------------------------------------
                ;29416  WAIT.IDC.T33.2:
U 1850, DB00,1A ;29417          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1851, 8985,34 ;29418          JMP [IDC.DONE.T33.2]                    ;XFER REQ SET
U 1852, 8985,04 ;29419          JMP [WAIT.IDC.T33.2]                    ;WAIT SOME MORE
                ;29420
                ;29421  IDC.DONE.T33.2:
U 1853, B700,15 ;29422          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1854, 17A0,15 ;29423          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1855, 90FA,15 ;29424          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;29425
U 1856, C051,95 ;29426          ADD LS[#100] TO WR[3]                   ;SELECT THE NEXT DRIVE
                ;29427          CMP LS[#400] WITH WR[3],                ;ALL BITS BEEN SET?
U 1857, 4E55,B5 ;29428           DT(LONG)&SET.ALU.CC
U 1858, 0984,91 ;29429          JMP.IF[NEQ] TO [SET.ATTN.T33]           ;JMP IF NO
                ;29430
U 1859, 3678,15 ;29431          MOV LS[BIT28] TO WR[0]                  ;WRITE ZERO TO CSR <19:16>
                ;29432                                                  ; BIT 28 PREVENTS IDC TIMEOUTS
U 185A, 17A0,15 ;29433          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
                ;29434
                ;29435  READ.CSR.T33.4:
U 185B, 9090,15 ;29436          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 185C, 9780,15 ;29437          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 185D, 3B32,15 ;29438          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;29439                                                  ; SAVE IT IN  LS
```

```
U 185E, 3732,15 ;29440          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 185F, B7C2,95 ;29441          MOV LS[#F0000] TO WR[1]                 ;SET UP EXPECTED DATA
U 1860, 0869,3C ;29442          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1861, 8984,84 ;29443          JMP [LOOP.T33.6]                        ;LOOP HERE ON ERR & LOE IS SET
                ;29444
                ;29445  CLEANUP.T33:
U 1862, 8875,3C ;29446          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET BY
                ;29447                                                  ; THIS TEST
                ;29448  END.T33:                                        ;END TEST
                ;29449
                ;29450
                ;29451
```

```
;29452  .PAGE  "Test 34  ATTENTION REGISTER TEST 2 (M8388 IDC MODULE)"
;29453  ;++
;29454  ;
;29455  ; Test Description:
;29456  ;
;29457  ;       This test is designed to test the Attention Register PAL. The
;29458  ;       Attention bits <3:0> are CSR bits <19:16>. These bits will be set
;29459  ;       by IDC microcode. After all attention bits are set, each will be
;29460  ;       cleared one at a time beginning with  attention bit <3>. All bits will
;29461  ;       be checked each time to verify that they are in the correct state.
;29462  ;       Then all bits will again be set by IDC microcode and an INIT of the
;29463  ;       IDC will be performed. The Attention bits will be checked to insure
;29464  ;       that they are all cleared by INIT.
;29465  ;
;29466  ; Assumptions:
;29467  ;
;29468  ;       It is assumed ATTENTION REG TEST 1 has been run successfully.
;29469  ;
;29470  ; Test Steps:
;29471  ;
;29472  ;       1. Set up error mask, error number and module number in LS
;29473  ;          (for error printouts) and clear the previous error number in LS.
;29474  ;       2. Force the IDC microcode to DIAG.IDLE.
;29475  ;       3. Select each drive and set the associated ATTENTION BITS.
;29476  ;       4. Clear Attention bit <3>.
;29477  ;       5. Check CSR <19:16>.
;29478  ;       6. Clear the next Attention bit.
;29479  ;       7. Check CSR <19:16>.
;29480  ;       8. Execute Steps 6 and 7 until all Attention bits have been cleared.
;29481  ;       9. Increment the error number.
;29482  ;      10. Select each drive and the associated ATTENTION BITS.
;29483  ;      11. Clear IDC.
;29484  ;      12. Check CSR <19:16> = 0000.
;29485  ;      13. Clear IDC.
;29486  ;      14. End test.
;29487  ;
;29488  ; Errors:
;29489  ;
;29490  ;                   Printout:
;29491  ;                           EXPECTED          RECEIVED          OTHER DATA
;29492  ;                             CSR               CSR          DRV NUM SELECTED
;29493  ;                                                               WR[2]
;29494  ;
;29495  ;       ERROR 1 - The Attention bits did not clear independently.
;29496  ;
;29497  ;       ERROR 2 - INIT did not clear the ATTENTION BITS.
;29498  ;
;29499  ; Debug:
;29500  ;
;29501  ; ERROR 1 -
;29502  ;       ATTN BITS <3:0> are all set. The CPU will then issue a
;29503  ;       PORT.WRITE PORT.ADRS[CSR] instruction with BIT <19> = 1.
;29504  ;       This instruction will be decoded by the PORT RD/WR DECODE PAL
;29505  ;       and will assert WRITE CSR L. The inputs to the ATTN REG PAL will be:
;29506  ;               WRITE CSR L = L
```

```
                ;29507  ;               BUS IO 19 H = H
                ;29508  ;               BUS IO 18 H = L
                ;29509  ;               BUS IO 17 H = L
                ;29510  ;               BUS IO 16 H = L
                ;29511  ;       At the next P2 CLOCK L, ATTN BIT <3> should be cleared and <2:0> should
                ;29512  ;       remain set. The CPU will then issue a PORT.READ PORT.ADRS[CSR] which
                ;29513  ;       will be decoded by the PORT INTERFACE REG PAL and DECODER and will
                ;29514  ;       assert SEL CSR L. SEL CSR L is the enable for the ATTN REG PAL and
                ;29515  ;       allows BUS IO <19:16> to be read as CSR <19:16>.
                ;29516  ;
                ;29517  ;       ATTN BIT <2> is then cleared by writing a one to CSR <18>.
                ;29518  ;       ATTN BIT <3> should remain clear and ATTN <1:0> should remain set.
                ;29519  ;
                ;29520  ;       ATTN BIT <1> is then cleared by writing a one to CSR <17>.
                ;29521  ;       ATTN BITS <3:2> should remain clear and ATTN BIT <0> should remain set.
                ;29522  ;
                ;29523  ;       ATTN BIT <0> is then cleared by writing a one to CSR <16>.
                ;29524  ;       ATTN BITS <3:1> should remain clear.
                ;29525  ;
                ;29526  ; ERROR 2 -
                ;29527  ;       ATTN BITS <3:0> are all set.
                ;29528  ;       The CPU issues a series of PORT.CONTROL [CLEAR.IDC] instructions which
                ;29529  ;       are decoded by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L.
                ;29530  ;       At the next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the
                ;29531  ;       next clock INIT H is asserted. INIT H is an input to the ATTN REG PAL
                ;29532  ;       and when it asserts ATTN BITS <3:0> will be cleared.
                ;29533  ;--
                ;29534  ;*******************************************************************************
                ;29535  T.34:
U 1863, B65E,15 ;29536          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;29537                                                  ; CONTROL AND STATUS WORD
U 1864, 3E80,15 ;29538          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;29539                                                  ; STATUS WORD - BIT 15
                ;29540                                                  ; INDICATES START OF TEST TO
                ;29541                                                  ; CONSOLE
U 1865, 10E0,15 ;29542          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;29543  WAIT.T34.0:
U 1866, 8986,64 ;29544          JMP [WAIT.T34.0]                        ;LOOP HERE WAITING FOR
                ;29545                                                  ; CONSOLE TO RESPOND
                ;29546
U 1867, 65A0,15 ;29547          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;29548                                                  ; IN LS
                ;29549
U 1868, B64A,15 ;29550          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1869, 3E8C,15 ;29551          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;29552
                ;29553
U 186A, B640,15 ;29554          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 186B, BE82,15 ;29555          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;29556
U 186C, 37BC,15 ;29557          MOV LS[#FFF0FFFF] TO WR[0]              ;GET THE MASK TO CHECK
U 186D, 3E8A,15 ;29558          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <19:16>
                ;29559
U 186E, B670,15 ;29560          MOV LS[OTHER.DATA] TO WR[0]             ;SET UP TO PRINT OTHER DATA
U 186F, 3E80,15 ;29561          MOV WR[0] TO LS[CONTROL.STATUS]         ; IF ERROR
```

```
                ;29562
                ;29563
U 1870, 8872,EC ;29564          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;29565
                ;29566  LOOP.T34.1:
                ;29567  ;SET ALL ATTN BITS
                ;29568
U 1871, B715,95 ;29569          MOV LS[SETCSR.DS0] TO WR[3]             ;SELECT DRIVE 0
                ;29570
                ;29571  SET.ATTN.T34:
                ;29572
U 1872, 370E,15 ;29573          MOV LS[SETCSR.F7] TO WR[0]
U 1873, 17A0,15 ;29574          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;29575                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;29576  ;CONTINUE TO BRANCH
U 1874, 379E,15 ;29577          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 1875, B708,95 ;29578          MOV LS[SETCSR.F4] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 1876, AEC2,15 ;29579          BIS WR[1] TO WR[0]
U 1877, 2EC6,15 ;29580          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE SELECT
U 1878, 17A0,15 ;29581          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;29582                                                  ;F<2:0> = 100
                ;29583  ;USET ATTN...DRIVE SELECTED BY CSR <9:8>
                ;29584  ;-------------------------------------------------------------------------
                ;29585  ;-------------------------------------------------------------------------
                ;29586  ;                               *******
                ;29587  ;                               * IDC *
                ;29588  ;                               *******
                ;29589  ;-------------------------------------------------------------------------
                ;29590  ;018:
                ;29591  ;=000
                ;29592  ;DIAG.IDLE:
                ;29593  ;
                ;29594  ;       BEN0/F0,
                ;29595  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;29596  ;       BEN2/F2,
                ;29597  ;       NAD/DIAG.IDLE
                ;29598  ;-------------------------------------------------------------------------
                ;29599  ;01F:
                ;29600  ;=111
                ;29601  ;
                ;29602  ;       BEN0/CRDY.L,
                ;29603  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;29604  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;29605  ;-------------------------------------------------------------------------
                ;29606  ;079:
                ;29607  ;=0*1
                ;29608  ;
                ;29609  ;       NAD/GROUP1
                ;29610  ;-------------------------------------------------------------------------
                ;29611  ;182:
                ;29612  ;=0**
                ;29613  ;GROUP1:
                ;29614  ;
                ;29615  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;29616  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
```

```
                ;29617  ;                                       ; FUNCTION BITS
                ;29618  ;-------------------------------------------------------------------------
                ;29619  ;186:
                ;29620  ;=1**
                ;29621  ;
                ;29622  ;       BEN0/F0,
                ;29623  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;29624  ;       BEN2/F2,
                ;29625  ;       NAD/GROUP1.F0
                ;29626  ;-------------------------------------------------------------------------
                ;29627  ;02C:
                ;29628  ;=100
                ;29629  ;USET.ATTN:
                ;29630  ;
                ;29631  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
                ;29632  ;                               ;INTERRUPTS
                ;29633  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
                ;29634  ;-------------------------------------------------------------------------
                ;29635  ;1D8:
                ;29636  ;XFER.REQ:
                ;29637  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;29638  ;       NAD/DIAG.WAIT
                ;29639  ;-------------------------------------------------------------------------
                ;29640  ;1D7:
                ;29641  ;DIAG.WAIT:
                ;29642  ;
                ;29643  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;29644  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;29645  ;-------------------------------------------------------------------------
                ;29646  ;159:
                ;29647  ;=*0*
                ;29648  ;DIAG.WAIT1:
                ;29649  ;
                ;29650  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;29651  ;                               ; COMMAND FROM THE CPU
                ;29652  ;-------------------------------------------------------------------------
                ;29653  ;15B:
                ;29654  ;=*1*
                ;29655  ;DIAG.WAIT2:
                ;29656  ;
                ;29657  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;29658  ;                               ; WAIT SOME MORE
                ;29659  ;-------------------------------------------------------------------------
                ;29660  WAIT.IDC.T34.1:
U 1879, DB00,1A ;29661          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 187A, 0987,C4 ;29662          JMP [IDC.DONE.T34.1]                    ;XFER REQ SET
U 187B, 0987,94 ;29663          JMP [WAIT.IDC.T34.1]                    ;WAIT SOME MORE
                ;29664
                ;29665  IDC.DONE.T34.1:
U 187C, B700,15 ;29666          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 187D, 17A0,15 ;29667          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 187E, 90FA,15 ;29668          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;29669
                ;29670
U 187F, C051,95 ;29671          ADD LS[#100] TO WR[3]                   ;SELECT THE NEXT DRIVE
```

```
                    ;29672          CMP LS[#400] WITH WR[3],                ;ALL BITS BEEN SET?
U 1880, 4E55,B5     ;29673           DT(LONG)&SET.ALU.CC
U 1881, 8987,21     ;29674          JMP.IF[NEQ] TO [SET.ATTN.T34]           ;JMP IF NO
                    ;29675
                    ;29676  ;LS[T8] WILL HOLD THE WRITE DATA FOR BITS <19:16> OF THE CSR
                    ;29677
U 1882, 3789,15     ;29678          MOV LS[#3] TO WR[2]                     ;USE AS A LOOP COUNTER
                    ;29679
U 1883, 3666,15     ;29680          MOV LS[#80000] TO WR[0]                 ;SET UP BITS <19:16>
U 1884, 3E10,15     ;29681          MOV WR[0] TO LS[T8]                     ;SAVE IN LS[T8]
                    ;29682
U 1885, B7C0,15     ;29683          MOV LS[#70000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 1886, BE12,15     ;29684          MOV WR[0] TO LS[T9]                     ; SAVE EXP DATA IN LS[T9]
                    ;29685
                    ;29686  TST.NXT.T34:
U 1887, B610,15     ;29687          MOV LS[T8] TO WR[0]                     ;GET THE DATA TO WRITE
U 1888, 4778,15     ;29688          BIS LS[BIT28] TO WR[0]                  ;BIT 28 PREVENTS TIMEOUTS
U 1889, 17A0,15     ;29689          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR(ATTENTION BITS)
                    ;29690
                    ;29691  READ.CSR.T34.1:
U 188A, 9090,15     ;29692          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 188B, 9780,15     ;29693          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 188C, 3B32,15     ;29694          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;29695                                                  ; SAVE IT IN  LS
                    ;29696
                    ;29697                                                  ;GET THE DRIVE NUMBER SELECTED
U 188D, 3E89,15     ;29698          MOV WR[2] TO LS[ADDRESS.DATA]           ; TO PRINT OUT AS OTHER DATA
                    ;29699
U 188E, 3732,15     ;29700          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 188F, B612,95     ;29701          MOV LS[T9] TO WR[1]                     ;SET UP THE EXPECTED DATA
U 1890, 0869,3C     ;29702          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1891, 8987,14     ;29703          JMP [LOOP.T34.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;29704
                    ;29705          TST WR[2],                              ;DONE?
U 1892, 2005,35     ;29706           DT(LONG)&SET.ALU.CC
U 1893, 098A,A9     ;29707          JMP.IF[EQL] TO [TST.INIT.T34]           ;JMP IF DONE
                    ;29708
U 1894, B788,15     ;29709          MOV LS[#3] TO WR[0]
                    ;29710          CMP WR[0] WITH WR[2],                   ;TESTING ATTN BIT 2 NEXT?
U 1895, 2641,35     ;29711           DT(LONG)&SET.ALU.CC
U 1896, 0989,D1     ;29712          JMP.IF[NEQ] TO [NXT.BIT.T34.1]          ;JMP IF NOT
                    ;29713
U 1897, B664,15     ;29714          MOV LS[#40000] TO WR[0]                 ;SETUP THE CSR WRITE DATA
U 1898, 3E10,15     ;29715          MOV WR[0] TO LS[T8]                     ; SAVE IT IN LS[T8]
                    ;29716
U 1899, B7BE,15     ;29717          MOV LS[#30000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 189A, BE12,15     ;29718          MOV WR[0] TO LS[T9]                     ;SAVE IT iN LS[T9]
                    ;29719
U 189B, 2105,15     ;29720          DEC WR[2]                               ;DECREMENT THE LOOP CNTR
                    ;29721
U 189C, 8988,74     ;29722          JMP [TST.NXT.T34]                       ;GO TEST NEXT BIT
                    ;29723
                    ;29724  NXT.BIT.T34.1:
                    ;29725          CMP LS[#2] WITH WR[2],                  ;TESTING ATTN BIT 1 NEXT?
U 189D, 4E43,35     ;29726           DT(LONG)&SET.ALU.CC
```

```
U 189E, 898A,51 ;29727          JMP.IF[NEQ] TO [NXT.BIT.T34.2]          ;JMP IF NOT
                ;29728
U 189F, B662,15 ;29729          MOV LS[#20000] TO WR[0]                 ;SET UP THE CSR WRITE DATA
U 18A0, 3E10,15 ;29730          MOV WR[0] TO LS[T8]                     ;SAVE IT IN LS[T8]
                ;29731
U 18A1, 3660,15 ;29732          MOV LS[#10000] TO WR[0]                 ;SET UP THE EXPECTED DATA
U 18A2, BE12,15 ;29733          MOV WR[0] TO LS[T9]                     ;SAVE THE EXP DATA IN LS[T9]
                ;29734
U 18A3, 2105,15 ;29735          DEC WR[2]                               ;DECREMENT THE LOOP CNTR
                ;29736
U 18A4, 8988,74 ;29737          JMP [TST.NXT.T34]                       ;GO TEST NEXT BIT
                ;29738
                ;29739  NXT.BIT.T34.2:
U 18A5, 3660,15 ;29740          MOV LS[#10000] TO WR[0]                 ;SET UP THE CSR WRT DATA TO
U 18A6, 3E10,15 ;29741          MOV WR[0] TO LS[T8]                     ; TEST ATTN BIT <0>
                ;29742
U 18A7, 6512,15 ;29743          CLR LS[T9]                              ;SET UP THE EXPECTED DATA
                ;29744
U 18A8, 2105,15 ;29745          DEC WR[2] '                             ;DECREMENT THE LOOP CNTR
U 18A9, 8988,74 ;29746          JMP [TST.NXT.T34]                       ;GO TEST THE NEXT BIT
                ;29747
                ;29748  TST.INIT.T34:
                ;29749  ;SET ALL ATTN BITS
                ;29750
U 18AA, FF82,15 ;29751          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
U 18AB, B715,95 ;29752          MOV LS[SETCSR.DS0] TO WR[3]
                ;29753
                ;29754  SET.ATTN.T34.2:
                ;29755
U 18AC, 370E,15 ;29756          MOV LS[SETCSR.F7] TO WR[0]
U 18AD, 17A0,15 ;29757          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;29758                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;29759  ;CONTINUE TO BRANCH
U 18AE, 379E,15 ;29760          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 18AF, B708,95 ;29761          MOV LS[SETCSR.F4] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 18B0, AEC2,15 ;29762          BIS WR[1] TO WR[0]
U 18B1, 2EC6,15 ;29763          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE SELECT
U 18B2, 17A0,15 ;29764          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;29765                                                  ;F<2:0> = 100
                ;29766  ;USET ATTN...DRIVE SELECTED BY CSR <9:8>
                ;29767  ;-------------------------------------------------------------------------------
                ;29768  ;-------------------------------------------------------------------------------
                ;29769  ;                               *******
                ;29770  ;                               * IDC *
                ;29771  ;                               *******
                ;29772  ;-------------------------------------------------------------------------------
                ;29773  ;018:
                ;29774  ;=000
                ;29775  ;DIAG.IDLE:
                ;29776  ;
                ;29777  ;       BEN0/F0,
                ;29778  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;29779  ;       BEN2/F2,
                ;29780  ;       NAD/DIAG.IDLE
                ;29781  ;-------------------------------------------------------------------------------
```

```
;29782  ;01F:
;29783  ;=111
;29784  ;
;29785  ;       BEN0/CRDY.L,
;29786  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;29787  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;29788  ;-----------------------------------------------------------------------
;29789  ;079:
;29790  ;=0*1
;29791  ;
;29792  ;       NAD/GROUP1
;29793  ;-----------------------------------------------------------------------
;29794  ;182:
;29795  ;=0**
;29796  ;GROUP1:
;29797  ;
;29798  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;29799  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;29800  ;                                       ; FUNCTION BITS
;29801  ;-----------------------------------------------------------------------
;29802  ;186:
;29803  ;=1**
;29804  ;
;29805  ;       BEN0/F0,
;29806  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;29807  ;       BEN2/F2,
;29808  ;       NAD/GROUP1.F0
;29809  ;-----------------------------------------------------------------------
;29810  ;02C:
;29811  ;=100
;29812  ;USET.ATTN:
;29813  ;
;29814  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
;29815  ;                               ;INTERRUPTS
;29816  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
;29817  ;-----------------------------------------------------------------------
;29818  ;1D8:
;29819  ;XFER.REQ:
;29820  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;29821  ;       NAD/DIAG.WAIT
;29822  ;-----------------------------------------------------------------------
;29823  ;1D7:
;29824  ;DIAG.WAIT:
;29825  ;
;29826  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;29827  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;29828  ;-----------------------------------------------------------------------
;29829  ;159:
;29830  ;=*0*
;29831  ;DIAG.WAIT1:
;29832  ;
;29833  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;29834  ;                               ; COMMAND FROM THE CPU
;29835  ;-----------------------------------------------------------------------
;29836  ;15B:
```

```
                ;29837  ;=*1*
                ;29838  ;DIAG.WAIT2:
                ;29839  ;
                ;29840  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;29841  ;                               ; WAIT SOME MORE
                ;29842  ;-------------------------------------------------------------------------
                ;29843  WAIT.IDC.T34.2:
U 18B3, DB00,1A ;29844          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 18B4, 098B,64 ;29845          JMP [IDC.DONE.T34.2]                    ;XFER REQ SET
U 18B5, 098B,34 ;29846          JMP [WAIT.IDC.T34.2]                    ;WAIT SOME MORE
                ;29847
                ;29848  IDC.DONE.T34.2:
U 18B6, B700,15 ;29849          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 18B7, 17A0,15 ;29850          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 18B8, 90FA,15 ;29851          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;29852
U 18B9, C051,95 ;29853          ADD LS[#100] TO WR[3]                   ;SELECT THE NEXT DRIVE
                ;29854          CMP LS[#400] WITH WR[3],                ;ALL BITS BEEN SET?
U 18BA, 4E55,B5 ;29855           DT(LONG)&SET.ALU.CC
U 18BB, 898A,C1 ;29856          JMP.IF[NEQ] TO [SET.ATTN.T34.2]         ;JMP IF NO
                ;29857
                ;29858  LOOP.T34.2:
U 18BC, 17CC,15 ;29859          PORT.CONTROL [CLEAR.IDC]                ;INIT THE IDC
U 18BD, 17CC,15 ;29860          PORT.CONTROL [CLEAR.IDC]
U 18BE, 17CC,15 ;29861          PORT.CONTROL [CLEAR.IDC]
                ;29862
                ;29863  READ.CSR.T34.2:
U 18BF, 9090,15 ;29864          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 18C0, 9780,15 ;29865          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 18C1, 3B32,15 ;29866          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;29867                                                  ; SAVE IT IN  LS
U 18C2, 3732,15 ;29868          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 18C3, 2F82,95 ;29869          CLR WR[1]                               ;SET UP EXPECTED DATA
U 18C4, 6588,15 ;29870          CLR LS[ADDRESS.DATA]                    ;CLR OTHER DATA
U 18C5, 0869,3C ;29871          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 18C6, 098B,C4 ;29872          JMP [LOOP.T34.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;29873
U 18C7, 8875,3C ;29874          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS
                ;29875                                                  ; SET BY THIS TEST
                ;29876  END.T34:                                        ;END TEST
                ;29877
                ;29878
                ;29879
```

```
;29880  .PAGE  "Test 35  CSR OPERATION INCOMPLETE (OPI)  BITS TEST (M8388 IDC MODULE)"
;29881  ;++
;29882  ;
;29883  ; Test Description:
;29884  ;
;29885  ;       This test will verify that CSR bits <10>, <12> and <15>
;29886  ;       will set when the IDC issues a SET.OPI. It will also verify that
;29887  ;       CSR bit <10> clears when CSR <CRDY> is cleared or when INIT is
;29888  ;       issued.
;29889  ;
;29890  ; Assumptions:
;29891  ;
;29892  ;       It is assumed that all previous tests have run successfully.
;29893  ;
;29894  ; Test Steps:
;29895  ;
;29896  ;       1. Set up error mask, error number and module number in LS
;29897  ;          (for error printouts) and clear the previous error number in LS.
;29898  ;       2. Force the IDC microcode to DIAG.IDLE.
;29899  ;       3. Set up the CSR to branch to the correct IDC microcode routine that
;29900  ;          will clear match.
;29901  ;
;29902  ;
;29903  ;                                       *******
;29904  ;                                       * IDC *
;29905  ;                                       *******
;29906  ;                 IDC1. UCLR MATCH.
;29907  ;                 IDC2. Send XFER REQ to flag the CPU.
;29908  ;
;29909  ;       4. Wait for XFER REQ from IDC.
;29910  ;       5. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;29911  ;       6. Set up the CSR to branch to the IDC routine that will SET OPI.
;29912  ;
;29913  ;                                       *******
;29914  ;                                       * IDC *
;29915  ;                                       *******
;29916  ;
;29917  ;                 IDC3. Execute an instruction with UCM <2:0> = 2, SET.OPI.
;29918  ;                 IDC4. Issue XFER.REQ to flag the CPU.
;29919  ;
;29920  ;       7. Wait for a XFER.REQ from IDC.
;29921  ;       8. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;29922  ;       9. Check CSR bits <15> <12> <10>.
;29923  ;      10. Increment the error number.
;29924  ;      11. Clear CSR <CRDY>.
;29925  ;      12. Check CSR bits <10>.
;29926  ;      13. Increment the error number.
;29927  ;      14. Set OPI.
;29928  ;      15. INIT the IDC.
;29929  ;      16. Check CSR bit <10>.
;29930  ;      17. Clear IDC.
;29931  ;      18. End test.
;29932  ;
;29933  ; Errors:
;29934  ;
```

```
                ;29935  ;                   Printout:
                ;29936  ;                                EXPECTED          RECEIVED
                ;29937  ;                                  CSR               CSR
                ;29938  ;
                ;29939  ;
                ;29940  ;       ERROR 1 - The CSR OPI bits did not set when a SET.OPI was issued.
                ;29941  ;
                ;29942  ;       ERROR 2 - CSR OPI did not clear when CSR <CRDY> was cleared.
                ;29943  ;
                ;29944  ;       ERROR 3 - CSR OPI did not clear when the IDC was INITed.
                ;29945  ;
                ;29946  ;
                ;29947  ; Debug:
                ;29948  ;
                ;29949  ; ERROR 1 -
                ;29950  ;       The IDC will first branch to a routine that will CLEAR.MATCH
                ;29951  ;       (MISMATCH L = L) which will allow CSR bit <12> to be tested.
                ;29952  ;       The IDC microcode will then branch to an instruction with
                ;29953  ;       UCMD <2:0> =010. These bits will be decoded by the CONTROL STATUS
                ;29954  ;       REG PAL and at the next P2 CLOCK L will assert OPI L. These in
                ;29955  ;       turn will assert OPI + DLT L. OPI L = L is inverted to become
                ;29956  ;       CSR bit <10>. OPI + DLT L is gated with MISMATCH L and will assert
                ;29957  ;       CSR bit <12>. OPI + DLT L is also inverted to become COMP ERR H which
                ;29958  ;       is CSR bit <15>.
                ;29959  ;
                ;29960  ; ERROR 2 -
                ;29961  ;       OPI L will be asserted. A PORT.WRITE PORT.ADRS[CSR] will be issued
                ;29962  ;       with CRDY (bit 7) cleared. This instruction will be decoded by the
                ;29963  ;       PORT RD/WR DECODE PAL and will assert WRITE CSR L.
                ;29964  ;       WRITE CSR L = L and BUS IO 7 H = L are inputs to the CONTROL STATUS
                ;29965  ;       REG PAL and at the next P2 CLOCK L will deassert OPI L. (OPI L = H).
                ;29966  ;       OPI L = H is inverted to become CSR <10>.
                ;29967  ;
                ;29968  ; ERROR 3 -
                ;29969  ;       OPI l will be asserted (see ERROR 1).
                ;29970  ;       The CPU issues a series of PORT.CONTROL [CLEAR.IDC] instructions which
                ;29971  ;       are decoded by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L.
                ;29972  ;       At the next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the
                ;29973  ;       next clock INIT H is asserted. INIT H is inverted to INIT L. This is
                ;29974  ;       an input to the CONTROL STATUS REG PAL and when INIT L asserts, OPI L
                ;29975  ;       will clear and this will clear OPI + DLT L.
                ;29976  ;--
                ;29977  ;*******************************************************************************
                ;29978  T.35:
U 18C8, B65E,15 ;29979          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;29980                                                  ; CONTROL AND STATUS WORD
U 18C9, 3E80,15 ;29981          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;29982                                                  ; STATUS WORD - BIT 15
                ;29983                                                  ; INDICATES START OF TEST TO
                ;29984                                                  ; CONSOLE
U 18CA, 10E0,15 ;29985          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;29986  WAIT.T35.0:
U 18CB, 098C,B4 ;29987          JMP [WAIT.T35.0]                        ;LOOP HERE WAITING FOR
                ;29988                                                  ; CONSOLE TO RESPOND
                ;29989
```

```
U 18CC, 65A0,15 ;29990          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;29991                                                  ; IN LS
                ;29992
U 18CD, B64A,15 ;29993          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 18CE, 3E8C,15 ;29994          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;29995
                ;29996
U 18CF, B640,15 ;29997          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 18D0, BE82,15 ;29998          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;29999
U 18D1, B7C6,15 ;30000          MOV LS[#FFFF6BFF] TO WR[0]              ;SET UP THE MASK TO CHECK
U 18D2, 3E8A,15 ;30001          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <15> <12> <10>
                ;30002
U 18D3, 8872,EC ;30003          JSR [DIAG.CODE]                         ;FORCE THE IDC TO DIAG.IDLE
                ;30004                                                  ; AND INIT THE IDC
                ;30005
U 18D4, 370E,15 ;30006          MOV LS[SETCSR.F7] TO WR[0]              ;BRANCH TO THE IDC ROUTINE THAT
U 18D5, 17A0,15 ;30007          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WILL CLEAR A MATCH CONDITION
                ;30008
                ;30009  ;CONTINUE TO BRANCH
                ;30010
U 18D6, 379E,15 ;30011          MOV LS[SETCSR.R80] TO WR[0]
U 18D7, 3700,95 ;30012          MOV LS[SETCSR.F0] TO WR[1]
U 18D8, AEC2,15 ;30013          BIS WR[1] TO WR[0]
U 18D9, 17A0,15 ;30014          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30015                                                  ;F<2:0> = 000
                ;30016  ;UCLR MATCH
                ;30017  ;-------------------------------------------------------------------------------
                ;30018  ;-------------------------------------------------------------------------------
                ;30019  ;                               *******
                ;30020  ;                               * IDC *
                ;30021  ;                               *******
                ;30022  ;-------------------------------------------------------------------------------
                ;30023  ;018:
                ;30024  ;=000
                ;30025  ;DIAG.IDLE:
                ;30026  ;
                ;30027  ;       BEN0/F0,
                ;30028  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30029  ;       BEN2/F2,
                ;30030  ;       NAD/DIAG.IDLE
                ;30031  ;-------------------------------------------------------------------------------
                ;30032  ;01F:
                ;30033  ;=111
                ;30034  ;
                ;30035  ;       BEN0/CRDY.L,
                ;30036  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;30037  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;30038  ;-------------------------------------------------------------------------------
                ;30039  ;079:
                ;30040  ;=0*1
                ;30041  ;
                ;30042  ;       NAD/GROUP1
                ;30043  ;-------------------------------------------------------------------------------
                ;30044  ;182:
```

```
;30045  ;=0**
;30046  ;GROUP1:
;30047  ;
;30048  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;30049  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;30050  ;                                       ; FUNCTION BITS
;30051  ;-------------------------------------------------------------------------
;30052  ;186:
;30053  ;=1**
;30054  ;
;30055  ;       BEN0/F0,
;30056  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;30057  ;       BEN2/F2,
;30058  ;       NAD/GROUP1.F0
;30059  ;-------------------------------------------------------------------------
;30060  ;028:
;30061  ;=000
;30062  ;GROUP1.F0:
;30063  ;
;30064  ;CLR.MATCH.1:
;30065  ;
;30066  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;30067  ;       NAD/TEST.MATCH.1
;30068  ;-------------------------------------------------------------------------
;30069  ;1F6:
;30070  ;TEST.MATCH.1:
;30071  ;
;30072  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;30073  ;       NAD/BEN2.1
;30074  ;-------------------------------------------------------------------------
;30075  ;1A0:
;30076  ;=0**
;30077  ;BEN2.1:
;30078  ;
;30079  ;       INCR.DAR/ON,                    ;INCR DAR
;30080  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;30081  ;-------------------------------------------------------------------------
;30082  ;1A4:
;30083  ;=1**
;30084  ;BEN2.2:
;30085  ;
;30086  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;30087  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;30088  ;-------------------------------------------------------------------------
;30089  ;1D8:
;30090  ;XFER.REQ:
;30091  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;30092  ;       NAD/DIAG.WAIT
;30093  ;-------------------------------------------------------------------------
;30094  ;1D7:
;30095  ;DIAG.WAIT:
;30096  ;
;30097  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;30098  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;30099  ;-------------------------------------------------------------------------
```

```
                ;30100  ;159:
                ;30101  ;=*0*
                ;30102  ;DIAG.WAIT1:
                ;30103  ;
                ;30104  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;30105  ;                               ; COMMAND FROM THE CPU
                ;30106  ;-------------------------------------------------------------------------
                ;30107  ;15B:
                ;30108  ;=*1*
                ;30109  ;DIAG.WAIT2:
                ;30110  ;
                ;30111  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;30112  ;                               ; WAIT SOME MORE
                ;30113  ;-------------------------------------------------------------------------
                ;30114  WAIT.IDC.T35.1:
U 18DA, DB00,1A ;30115          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 18DB, 898D,D4 ;30116          JMP [IDC.DONE.T35.1]                    ;XFER REQ SET
U 18DC, 098D,A4 ;30117          JMP [WAIT.IDC.T35.1]                    ;WAIT SOME MORE
                ;30118
                ;30119  IDC.DONE.T35.1:
U 18DD, B700,15 ;30120          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 18DE, 17A0,15 ;30121          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 18DF, 90FA,15 ;30122          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;30123
                ;30124  LOOP.T35.1:
                ;30125  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE THAT WILL SET OPI
                ;30126
U 18E0, 370E,15 ;30127          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR
U 18E1, 17A0,15 ;30128          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30129                                                  ; MAINT=0,CRDY=0,F<2:0>=111
                ;30130  ;CONTINUE TO BRANCH
U 18E2, 379E,15 ;30131          MOV LS[SETCSR.R80] TO WR[0]
U 18E3, B70E,95 ;30132          MOV LS[SETCSR.F7] TO WR[1]
U 18E4, AEC2,15 ;30133          BIS WR[1] TO WR[0]
U 18E5, 3712,95 ;30134          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO ALLOW OPI.L
U 18E6, AEC2,15 ;30135          BIS WR[1] TO WR[0]
U 18E7, 17A0,15 ;30136          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30137                                                  ;F<2:0>=111
                ;30138  ;SET.OPI
                ;30139  ;-------------------------------------------------------------------------
                ;30140  ;-------------------------------------------------------------------------
                ;30141  ;                               *******
                ;30142  ;                               * IDC *
                ;30143  ;                               *******
                ;30144  ;-------------------------------------------------------------------------
                ;30145  ;018:
                ;30146  ;=000
                ;30147  ;DIAG.IDLE:
                ;30148  ;
                ;30149  ;       BEN0/F0,
                ;30150  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30151  ;       BEN2/F2,
                ;30152  ;       NAD/DIAG.IDLE
                ;30153  ;-------------------------------------------------------------------------
                ;30154  ;01F:
```

```
;30155  ;=111
;30156  ;
;30157  ;       BEN0/CRDY.L,
;30158  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;30159  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;30160  ;-------------------------------------------------------------------------
;30161  ;079:
;30162  ;=0*1
;30163  ;
;30164  ;       NAD/GROUP1
;30165  ;-------------------------------------------------------------------------
;30166  ;182:
;30167  ;=0**
;30168  ;GROUP1:
;30169  ;
;30170  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;30171  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;30172  ;                                       ; FUNCTION BITS
;30173  ;-------------------------------------------------------------------------
;30174  ;186:
;30175  ;=1**
;30176  ;
;30177  ;       BEN0/F0,
;30178  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;30179  ;       BEN2/F2,
;30180  ;       NAD/GROUP1.F0
;30181  ;-------------------------------------------------------------------------
;30182  ;02F:
;30183  ;=111
;30184  ;
;30185  ;       UCMD/SET.OPI,           ;SET OPI FOR CSR OPI TEST
;30186  ;
;30187  ;       FUNC/SET.SSE,           ;SET SKIP SECTOR ERROR
;30188  ;       NAD/OPI.BR.TST          ;USED FOR OPI.L BRANCH TEST...DOES NOT AFFECT
;30189  ;                               ; SET SSE OR SET.OPI
;30190  ;-------------------------------------------------------------------------
;30191  ;02B:
;30192  ;=011
;30193  ;OPI.BR.TST:
;30194  ;
;30195  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
;30196  ;       NAD/BEN2.1
;30197  ;-------------------------------------------------------------------------
;30198  ;1A0:
;30199  ;=0**
;30200  ;BEN2.1:
;30201  ;
;30202  ;       INCR.DAR/ON,                    ;INCR DAR
;30203  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;30204  ;-------------------------------------------------------------------------
;30205  ;1A4:
;30206  ;=1**
;30207  ;BEN2.2:
;30208  ;
;30209  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
```

```
                ;30210  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;30211  ;-------------------------------------------------------------------------
                ;30212  ;1D8:
                ;30213  ;XFER.REQ:
                ;30214  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;30215  ;       NAD/DIAG.WAIT
                ;30216  ;-------------------------------------------------------------------------
                ;30217  ;1D7:
                ;30218  ;DIAG.WAIT:
                ;30219  ;
                ;30220  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;30221  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;30222  ;-------------------------------------------------------------------------
                ;30223  ;159:
                ;30224  ;=*0*
                ;30225  ;DIAG.WAIT1:
                ;30226  ;
                ;30227  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;30228  ;                               ; COMMAND FROM THE CPU
                ;30229  ;-------------------------------------------------------------------------
                ;30230  ;15B:
                ;30231  ;=*1*
                ;30232  ;DIAG.WAIT2:
                ;30233  ;
                ;30234  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;30235  ;                               ; WAIT SOME MORE
                ;30236  ;-------------------------------------------------------------------------
                ;30237  WAIT.IDC.T35.2:
U 18E8, DB00,1A ;30238          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 18E9, 898E,B4 ;30239          JMP [IDC.DONE.T35.2]                    ;XFER REQ SET
U 18EA, 898E,84 ;30240          JMP [WAIT.IDC.T35.2]                    ;WAIT SOME MORE
                ;30241
                ;30242  IDC.DONE.T35.2:
U 18EB, B700,15 ;30243          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 18EC, 3712,95 ;30244          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 18ED, AEC2,15 ;30245          BIS WR[1] TO WR[0]
U 18EE, 17A0,15 ;30246          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 18EF, 90FA,15 ;30247          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;30248
                ;30249  READ.CSR.T35.1:
U 18F0, 9090,15 ;30250          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 18F1, 9780,15 ;30251          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 18F2, 3B32,15 ;30252          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;30253                                                  ; SAVE IT IN  LS
U 18F3, 3732,15 ;30254          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 18F4, B7C8,95 ;30255          MOV LS[#9400] TO WR[1]                  ;SET UP EXPECTED DATA
U 18F5, 0869,3C ;30256          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 18F6, 098E,04 ;30257          JMP [LOOP.T35.1]                        ;LOOP HERE ERROR &  LOE IS SET
                ;30258
                ;30259
U 18F7, FF82,15 ;30260          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;30261
U 18F8, 37E0,15 ;30262          MOV LS[#FFFFFBFF] TO WR[0]              ;SET UP THE MASK TO CHECK
U 18F9, 3E8A,15 ;30263          MOV WR[0] TO LS[ERROR.MASK]             ; BIT <10>
                ;30264
```

```
                ;30265  LOOP.T35.2:
U 18FA, 3678,15 ;30266          MOV LS[BIT28] TO WR[0]                  ;CLR CSR CRDY
                ;30267                                                  ; BIT 28 PREVENTS IDC TIMEOUTS
U 18FB, 17A0,15 ;30268          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR TO CLR CRDY
                ;30269
                ;30270  READ.CSR.T35.2:
U 18FC, 9090,15 ;30271          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 18FD, 9780,15 ;30272          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 18FE, 3B32,15 ;30273          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;30274                                                  ; SAVE IT IN  LS
U 18FF, 3732,15 ;30275          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1900, 2F82,95 ;30276          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1901, 0869,3C ;30277          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1902, 898F,A4 ;30278          JMP [LOOP.T35.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;30279
U 1903, FF82,15 ;30280          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 3
                ;30281
                ;30282  ;SET OPI
                ;30283
                ;30284
U 1904, 370E,15 ;30285          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR
U 1905, 17A0,15 ;30286          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30287                                                  ; MAINT=0,CRDY=0,F<2:0>=111
                ;30288  ;CONTINUE TO BRANCH
U 1906, 379E,15 ;30289          MOV LS[SETCSR.R80] TO WR[0]
U 1907, B70E,95 ;30290          MOV LS[SETCSR.F7] TO WR[1]
U 1908, AEC2,15 ;30291          BIS WR[1] TO WR[0]
U 1909, 3712,95 ;30292          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO ALLOW OPI.L
U 190A, AEC2,15 ;30293          BIS WR[1] TO WR[0]
U 190B, 17A0,15 ;30294          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30295                                                  ;F<2:0>=111
                ;30296  ;SET.OPI
                ;30297  ;-------------------------------------------------------------------------------
                ;30298  ;-------------------------------------------------------------------------------
                ;30299  ;                               *******
                ;30300  ;                               * IDC *
                ;30301  ;                               *******
                ;30302  ;-------------------------------------------------------------------------
                ;30303  ;018:
                ;30304  ;=000
                ;30305  ;DIAG.IDLE:
                ;30306  ;
                ;30307  ;       BEN0/F0,
                ;30308  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30309  ;       BEN2/F2,
                ;30310  ;       NAD/DIAG.IDLE
                ;30311  ;-------------------------------------------------------------------------
                ;30312  ;01F:
                ;30313  ;=111
                ;30314  ;
                ;30315  ;       BEN0/CRDY.L,
                ;30316  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;30317  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;30318  ;-------------------------------------------------------------------------
                ;30319  ;079:
```

```
;30320  ;=0*1
;30321  ;
;30322  ;       NAD/GROUP1
;30323  ;-------------------------------------------------------------------------------
;30324  ;182:
;30325  ;=0**
;30326  ;GROUP1:
;30327  ;
;30328  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;30329  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;30330  ;                                       ; FUNCTION BITS
;30331  ;-------------------------------------------------------------------------------
;30332  ;186:
;30333  ;=1**
;30334  ;
;30335  ;       BEN0/F0,
;30336  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;30337  ;       BEN2/F2,
;30338  ;       NAD/GROUP1.F0
;30339  ;-------------------------------------------------------------------------------
;30340  ;02F:
;30341  ;=111
;30342  ;
;30343  ;       UCMD/SET.OPI,           ;SET OPI FOR CSR OPI TEST
;30344  ;
;30345  ;       FUNC/SET.SSE,           ;SET SKIP SECTOR ERROR
;30346  ;       NAD/OPI.BR.TST          ;USED FOR OPI.L BRANCH TEST...DOES NOT AFFECT
;30347  ;                               ; SET SSE OR SET.OPI
;30348  ;-------------------------------------------------------------------------------
;30349  ;02B:
;30350  ;=011
;30351  ;OPI.BR.TST:
;30352  ;
;30353  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
;30354  ;       NAD/BEN2.1
;30355  ;-------------------------------------------------------------------------------
;30356  ;1A0:
;30357  ;=0**
;30358  ;BEN2.1:
;30359  ;
;30360  ;       INCR.DAR/ON,                    ;INCR DAR
;30361  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;30362  ;-------------------------------------------------------------------------------
;30363  ;1A4:
;30364  ;=1**
;30365  ;BEN2.2:
;30366  ;
;30367  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;30368  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;30369  ;-------------------------------------------------------------------------------
;30370  ;1D8:
;30371  ;XFER.REQ:
;30372  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;30373  ;       NAD/DIAG.WAIT
;30374  ;-------------------------------------------------------------------------------
```

```
                ;30375  ;1D7:
                ;30376  ;DIAG.WAIT:
                ;30377  ;
                ;30378  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;30379  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;30380  ;-------------------------------------------------------------------
                ;30381  ;159:
                ;30382  ;=*0*
                ;30383  ;DIAG.WAIT1:
                ;30384  ;
                ;30385  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;30386  ;                               ; COMMAND FROM THE CPU
                ;30387  ;-------------------------------------------------------------------
                ;30388  ;15B:
                ;30389  ;=*1*
                ;30390  ;DIAG.WAIT2:
                ;30391  ;
                ;30392  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;30393  ;                               ; WAIT SOME MORE
                ;30394  ;-------------------------------------------------------------------
                ;30395  WAIT.IDC.T35.3:
U 190C, DB00,1A ;30396          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 190D, 0990,F4 ;30397          JMP [IDC.DONE.T35.3]                    ;XFER REQ SET
U 190E, 0990,C4 ;30398          JMP [WAIT.IDC.T35.3]                    ;WAIT SOME MORE
                ;30399
                ;30400  IDC.DONE.T35.3:
U 190F, B700,15 ;30401          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1910, 3712,95 ;30402          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 1911, AEC2,15 ;30403          BIS WR[1] TO WR[0]
U 1912, 17A0,15 ;30404          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1913, 90FA,15 ;30405          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;30406
                ;30407  LOOP.T35.3:
U 1914, 17CC,15 ;30408          PORT.CONTROL [CLEAR.IDC]                ;INIT THE IDC
U 1915, 17CC,15 ;30409          PORT.CONTROL [CLEAR.IDC]
U 1916, 17CC,15 ;30410          PORT.CONTROL [CLEAR.IDC]
                ;30411
                ;30412
                ;30413  READ.CSR.T35.3:
U 1917, 9090,15 ;30414          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1918, 9780,15 ;30415          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1919, 3B32,15 ;30416          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;30417                                                  ; SAVE IT IN  LS
U 191A, 3732,15 ;30418          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 191B, 2F82,95 ;30419          CLR WR[1]                               ;SET UP EXPECTED DATA
U 191C, 0869,3C ;30420          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 191D, 0991,44 ;30421          JMP [LOOP.T35.3]                        ;LOOP HERE IF ERR & LOE IS SET
                ;30422
U 191E, 8875,3C ;30423          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY
                ;30424                                                  ; THIS TEST
                ;30425  END.T35:                                        ;END TEST
                ;30426
                ;30427
```

```
;30428  .PAGE  "Test 36  OPERATION INCOMPLETE BRANCH TEST (M8388 IDC MODULE)"
;30429  ;++
;30430  ; Test Description:
;30431  ;
;30432  ;       This test is designed to insure that the BEN2/OPI.L branch condition
;30433  ;       operates correctly. This is done by first setting OPI.L by issuing a
;30434  ;       SET.OPI.L from the IDC microcode. BEN2/OPI.L is then selected by the
;30435  ;       IDC microcode. If OPI.L is asserted the DAR will be incremented
;30436  ;       once and if OPI.L is not asserted the DAR will be incremented twice.
;30437  ;       The CPU will then read and check the the DAR = 1.
;30438  ;       CSR <CRDY> will then be cleared which will clear OPI.L. BEN2/OPI.L
;30439  ;       will again be selected. If OPI.L is not asserted, the DAR will be
;30440  ;       incremented twice and if OPI.L is asserted the DAR will be incremented
;30441  ;       once. The CPU will then read and check the DAR = 2.
;30442  ;
;30443  ; Assumptions:
;30444  ;
;30445  ;       It is assumed that the CSR OPERATIONS INCOMPLETE BITS TEST has
;30446  ;       previously been run successfully.
;30447  ;
;30448  ; Test Steps:
;30449  ;
;30450  ;       1. Set up error mask, error number and module number in LS
;30451  ;          (for error printouts) and clear the previous error number in LS.
;30452  ;       2. Force the IDC to DIAG.IDLE.
;30453  ;       3. Clear the DAR.
;30454  ;       4. Set up the CSR to branch to the correct IDC routine.
;30455  ;
;30456  ;                                       *******
;30457  ;                                       * IDC *
;30458  ;                                       *******
;30459  ;
;30460  ;               IDC1. Execute an instruction with UCM <2:0> = 2, SET.OPI.
;30461  ;               IDC2. Select BEN2/OPI L.
;30462  ;               IDC3. Increment the DAR once if OPI L is asserted.
;30463  ;                     Increment the DAR twice is OPI L is NOT asserted.
;30464  ;               IDC4. Send XFER REQ to flag the CPU.
;30465  ;
;30466  ;       5. Wait for XFER REQ from IDC.
;30467  ;       6. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;30468  ;       7. Check the DAR = 1.
;30469  ;       8. Increment the error number.
;30470  ;       9. Clear the DAR.
;30471  ;      10. Clear CSR <CRDY> to clear OPI L.
;30472  ;      11. Set up the CSR to branch to the IDC routine that will select
;30473  ;          BEN2/OPI L.
;30474  ;
;30475  ;                                       *******
;30476  ;                                       * IDC *
;30477  ;                                       *******
;30478  ;
;30479  ;               IDC6. Select BEN2/OPI L.
;30480  ;               IDC7. Increment the DAR once if OPI L is asserted.
;30481  ;                     Increment the DAR twice is OPI L is NOT asserted.
;30482  ;               IDC8. Send XFER REQ to flag the CPU.
```

```
                ;30483  ;
                ;30484  ;       12. Wait for XFER REQ from IDC.
                ;30485  ;       13. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
                ;30486  ;       14. Check the DAR = 2.
                ;30487  ;       15. Clear IDC.
                ;30488  ;       16. End test.
                ;30489  ;
                ;30490  ; Errors:
                ;30491  ;
                ;30492  ;                       Printout:
                ;30493  ;                               EXPECTED        RECEIVED
                ;30494  ;                                 DAR             DAR
                ;30495  ;
                ;30496  ;
                ;30497  ;       ERROR 1 - BEN2/OPI L failed when asserted.
                ;30498  ;
                ;30499  ;       ERROR 2 - BEN2/OPI L failed when NOT asserted.
                ;30500  ;
                ;30501  ; Debug:
                ;30502  ;
                ;30503  ; ERROR 1 -
                ;30504  ;       The DAR is cleared. The IDC will branch to an instruction with
                ;30505  ;       UCMD <2:0> = 010, SET.OPI.L. The IDC mirocode will then select
                ;30506  ;       BEN2/OPI.L, (BEN2 S2 H = L, BEN2 S1 H = H, BEN2 S0 H = H). OPI L
                ;30507  ;       will be asserted so NUA 2 H = L and the microcode will branch to
                ;30508  ;       a series of instructions that will increment the DAR once.
                ;30509  ;
                ;30510  ; ERROR 2 -
                ;30511  ;       OPI L will be asserted. The DAR is cleared. A PORT.WRITE PORT.ADRS[CSR]
                ;30512  ;       will be issued with CRDY (bit 7) cleared. This instruction will be
                ;30513  ;       decoded by the PORT RD/WR DECODE PAL and will assert WRITE CSR L.
                ;30514  ;       WRITE CSR L = L and BUS IO 7 H = L are inputs to the CONTROL STATUS
                ;30515  ;       REG PAL and on the next P2 CLOCK L will  deassert OPI L. (OPI L = H).
                ;30516  ;       The IDC microcode will branch to an instruction that will select
                ;30517  ;       BEN2/OPI.L (BEN2 S2 H = L, BEN2 S1 H = H, BEN2 S0 H = H).
                ;30518  ;       OPL L will be H so NUA 2 H = H and the IDC microcode will branch to a
                ;30519  ;       series of instructions that will increment the DAR twice.
                ;30520  ;--
                ;30521  ;*******************************************************************************
                ;30522  T.36:
U 191F, B65E,15 ;30523          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;30524                                                          ; CONTROL AND STATUS WORD
U 1920, 3E80,15 ;30525          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;30526                                                          ; STATUS WORD - BIT 15
                ;30527                                                          ; INDICATES START OF TEST TO
                ;30528                                                          ; CONSOLE
U 1921, 10E0,15 ;30529          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;30530  WAIT.T36.0:
U 1922, 0992,24 ;30531          JMP [WAIT.T36.0]                                ;LOOP HERE WAITING FOR
                ;30532                                                          ; CONSOLE TO RESPOND
                ;30533
U 1923, 65A0,15 ;30534          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
                ;30535                                                          ; IN LS
                ;30536
U 1924, B64A,15 ;30537          MOV LS[IDC] TO WR[0]                            ;STORE MODULE CODE IN LS TO
```

```
U 1925, 3E8C,15 ;30538          MOV WR[0] TO LS[MODULE.NUM]                ; INDICATE IDC MODULE
                ;30539
                ;30540
U 1926, B640,15 ;30541          MOV LS[#1] TO WR[0]                        ;SET WR0 = 1
U 1927, BE82,15 ;30542          MOV WR[0] TO LS[ERROR.NUMBER]              ;SET UP ERROR NUMBER = 1 IN LS
                ;30543
U 1928, 3776,15 ;30544          MOV LS[DAR.MASK] TO WR[0]
U 1929, 3E8A,15 ;30545          MOV WR[0] TO LS[ERROR.MASK]                ;SET UP MASK TO CHECK <18:0>
                ;30546
U 192A, 8872,EC ;30547          JSR [DIAG.CODE]                            ;INIT THE IDC AND FORCE IT TO
                ;30548                                                     ; DIAG.IDLE
                ;30549
                ;30550  LOOP.T36.1:
U 192B, 2F80,15 ;30551          CLR WR[0]
U 192C, 97A4,15 ;30552          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]       ;CLEAR THE DAR
                ;30553
                ;30554  ;SET UP THE CSR TO BRANCH TO THE CORRECT IDC ROUTINE THAT WILL SET OPI
                ;30555
U 192D, 370E,15 ;30556          MOV LS[SETCSR.F7] TO WR[0]                 ;SET UP THE CSR
U 192E, 17A0,15 ;30557          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]       ;WRITE THE CSR
                ;30558                                                     ; MAINT=0,CRDY=0,F<2:0>=111
                ;30559  ;CONTINUE TO BRANCH
U 192F, 379E,15 ;30560          MOV LS[SETCSR.R80] TO WR[0]
U 1930, B70E,95 ;30561          MOV LS[SETCSR.F7] TO WR[1]
U 1931, AEC2,15 ;30562          BIS WR[1] TO WR[0]
U 1932, 3712,95 ;30563          MOV LS[SETCSR.CRDY] TO WR[1]               ;SET CRDY TO ALLOW OPI.L
U 1933, AEC2,15 ;30564          BIS WR[1] TO WR[0]
U 1934, 17A0,15 ;30565          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]       ;WRITE THE CSR
                ;30566                                                     ;F<2:0>=111
                ;30567  ;SET.OPI AND THEN SELECT BEN2/OPI.L
                ;30568  ;-------------------------------------------------------------------------------
                ;30569  ;-------------------------------------------------------------------------------
                ;30570  ;                                  *******
                ;30571  ;                                  * IDC *
                ;30572  ;                                  *******
                ;30573  ;-------------------------------------------------------------------------
                ;30574  ;018:
                ;30575  ;=000
                ;30576  ;DIAG.IDLE:
                ;30577  ;
                ;30578  ;       BEN0/F0,
                ;30579  ;       BEN1/F1,                   ;BRANCH ON THE CSR F<2:0> BITS
                ;30580  ;       BEN2/F2,
                ;30581  ;       NAD/DIAG.IDLE
                ;30582  ;-------------------------------------------------------------------------
                ;30583  ;01F:
                ;30584  ;=111
                ;30585  ;
                ;30586  ;       BEN0/CRDY.L,
                ;30587  ;       BEN2/MAINT,                ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;30588  ;       NAD/TEST.FUNC7             ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;30589  ;-------------------------------------------------------------------------
                ;30590  ;079:
                ;30591  ;=0*1
                ;30592  ;
```

```
;30593  ;       NAD/GROUP1
;30594  ;-------------------------------------------------------------------------
;30595  ;182:
;30596  ;=0**
;30597  ;GROUP1:
;30598  ;
;30599  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;30600  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;30601  ;                                       ; FUNCTION BITS
;30602  ;-------------------------------------------------------------------------
;30603  ;186:
;30604  ;=1**
;30605  ;
;30606  ;       BEN0/F0,
;30607  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;30608  ;       BEN2/F2,
;30609  ;       NAD/GROUP1.F0
;30610  ;-------------------------------------------------------------------------
;30611  ;02F:
;30612  ;=111
;30613  ;
;30614  ;       UCMD/SET.OPI,           ;SET OPI FOR CSR OPI TEST
;30615  ;
;30616  ;       FUNC/SET.SSE,           ;SET SKIP SECTOR ERROR
;30617  ;       NAD/OPI.BR.TST          ;USED FOR OPI.L BRANCH TEST...DOES NOT AFFECT
;30618  ;                               ; SET SSE OR SET.OPI
;30619  ;-------------------------------------------------------------------------
;30620  ;02B:
;30621  ;=011
;30622  ;OPI.BR.TST:
;30623  ;
;30624  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
;30625  ;       NAD/BEN2.1
;30626  ;-------------------------------------------------------------------------
;30627  ;1A0:
;30628  ;=0**
;30629  ;BEN2.1:
;30630  ;
;30631  ;       INCR.DAR/ON,                    ;INCR DAR
;30632  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;30633  ;-------------------------------------------------------------------------
;30634  ;1A4:
;30635  ;=1**
;30636  ;BEN2.2:
;30637  ;
;30638  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;30639  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;30640  ;-------------------------------------------------------------------------
;30641  ;1D8:
;30642  ;XFER.REQ:
;30643  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;30644  ;       NAD/DIAG.WAIT
;30645  ;-------------------------------------------------------------------------
;30646  ;1D7:
;30647  ;DIAG.WAIT:
```

```
                ;30648  ;
                ;30649  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;30650  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;30651  ;-------------------------------------------------------------------------
                ;30652  ;159:
                ;30653  ;=*0*
                ;30654  ;DIAG.WAIT1:
                ;30655  ;
                ;30656  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;30657  ;                               ; COMMAND FROM THE CPU
                ;30658  ;-------------------------------------------------------------------------
                ;30659  ;15B:
                ;30660  ;=*1*
                ;30661  ;DIAG.WAIT2:
                ;30662  ;
                ;30663  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;30664  ;                               ; WAIT SOME MORE
                ;30665  ;-------------------------------------------------------------------------
                ;30666  WAIT.IDC.T36.1:
U 1935, DB00,1A ;30667          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1936, 8993,84 ;30668          JMP [IDC.DONE.T36.1]                    ;XFER REQ SET
U 1937, 0993,54 ;30669          JMP [WAIT.IDC.T36.1]                    ;WAIT SOME MORE
                ;30670
                ;30671  IDC.DONE.T36.1:
U 1938, B700,15 ;30672          MOV LS[SETCSR\F0] TO WR[0]              ;CLEAR THE FUNC BITS
U 1939, 17A0,15 ;30673          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WRITE THE DATA TO IDC CSR
U 193A, 90FA,15 ;30674          MISC2 [TRANSFER.GRANT]                  ;SEND TRANSFER GRANT
                ;30675
                ;30676  READ.DAR.T36.1:
U 193B, 9090,15 ;30677          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 193C, 1784,15 ;30678          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 193D, 3B32,15 ;30679          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;30680                                                  ; SAVE IT IN  LS
U 193E, 3732,15 ;30681          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 193F, 3640,95 ;30682          MOV LS[#1] TO WR[1]                     ;SET UP EXPECTED DATA
U 1940, 0869,3C ;30683          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1941, 0992,B4 ;30684          JMP [LOOP.T36.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;30685
U 1942, FF82,15 ;30686          INC LS[ERROR.NUMBER]                    ;ERROR 2
                ;30687
                ;30688  LOOP.T36.2:
U 1943, 2F80,15 ;30689          CLR WR[0]
U 1944, 97A4,15 ;30690          PORT.WRITE PORT.ADRS[DAR] WITH WR[0]    ;CLEAR THE DAR
U 1945, 4778,15 ;30691          BIS LS[BIT28] TO WR[0]                  ;SET THE TIMEOUT INHIBIT BIT
                ;30692                                                  ; BEFORE WRITING TO THE CSR
U 1946, 17A0,15 ;30693          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;CLR CSR <CRDY> TO CLR OPI.L
                ;30694
                ;30695  ;SET UP THE CSR TO SELECT BEN2/OPI.L
                ;30696
U 1947, 370E,15 ;30697          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR
U 1948, 17A0,15 ;30698          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30699                                                  ; MAINT=0,CRDY=0,F<2:0>=111
                ;30700  ;CONTINUE TO BRANCH
U 1949, 379E,15 ;30701          MOV LS[SETCSR.R80] TO WR[0]
U 194A, 3706,95 ;30702          MOV LS[SETCSR.F3] TO WR[1]
```

```
U 194B, AEC2,15 ;30703          BIS WR[1] TO WR[0]
U 194C, 17A0,15 ;30704          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30705                                                  ;F<2:0>=011
                ;30706  ;-------------------------------------------------------------------------------
                ;30707  ;-------------------------------------------------------------------------------
                ;30708  ;                               *******
                ;30709  ;                               * IDC *
                ;30710  ;                               *******
                ;30711  ;-------------------------------------------------------------------------------
                ;30712  ;018:
                ;30713  ;=000
                ;30714  ;DIAG.IDLE:
                ;30715  ;
                ;30716  ;       BEN0/F0,
                ;30717  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30718  ;       BEN2/F2,
                ;30719  ;       NAD/DIAG.IDLE
                ;30720  ;-------------------------------------------------------------------------------
                ;30721  ;01F:
                ;30722  ;=111
                ;30723  ;
                ;30724  ;       BEN0/CRDY.L,
                ;30725  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;30726  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;30727  ;-------------------------------------------------------------------------------
                ;30728  ;079:
                ;30729  ;=0*1
                ;30730  ;
                ;30731  ;       NAD/GROUP1
                ;30732  ;-------------------------------------------------------------------------------
                ;30733  ;182:
                ;30734  ;=0**
                ;30735  ;GROUP1:
                ;30736  ;
                ;30737  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;30738  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;30739  ;                                       ; FUNCTION BITS
                ;30740  ;-------------------------------------------------------------------------------
                ;30741  ;186:
                ;30742  ;=1**
                ;30743  ;
                ;30744  ;       BEN0/F0,
                ;30745  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30746  ;       BEN2/F2,
                ;30747  ;       NAD/GROUP1.F0
                ;30748  ;-------------------------------------------------------------------------------
                ;30749  ;02B:
                ;30750  ;=011
                ;30751  ;OPI.BR.TST:
                ;30752  ;
                ;30753  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
                ;30754  ;       NAD/BEN2.1
                ;30755  ;-------------------------------------------------------------------------------
                ;30756  ;1A0:
                ;30757  ;=0**
```

```
                ;30758  ;BEN2.1:
                ;30759  ;
                ;30760  ;       INCR.DAR/ON,                    ;INCR DAR
                ;30761  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;30762  ;-------------------------------------------------------------------------
                ;30763  ;1A4:
                ;30764  ;=1**
                ;30765  ;BEN2.2:
                ;30766  ;
                ;30767  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;30768  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;30769  ;-------------------------------------------------------------------------
                ;30770  ;1D8:
                ;30771  ;XFER.REQ:
                ;30772  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;30773  ;       NAD/DIAG.WAIT
                ;30774  ;-------------------------------------------------------------------------
                ;30775  ;1D7:
                ;30776  ;DIAG.WAIT:
                ;30777  ;
                ;30778  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;30779  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;30780  ;-------------------------------------------------------------------------
                ;30781  ;159:
                ;30782  ;=*0*
                ;30783  ;DIAG.WAIT1:
                ;30784  ;
                ;30785  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;30786  ;                               ; COMMAND FROM THE CPU
                ;30787  ;-------------------------------------------------------------------------
                ;30788  ;15B:
                ;30789  ;=*1*
                ;30790  ;DIAG.WAIT2:
                ;30791  ;
                ;30792  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;30793  ;                               ; WAIT SOME MORE
                ;30794  ;-------------------------------------------------------------------------
                ;30795  WAIT.IDC.T36.2:
U 194D, DB00,1A ;30796          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 194E, 0995,04 ;30797          JMP [IDC.DONE.T36.2]                    ;XFER REQ SET
U 194F, 0994,D4 ;30798          JMP [WAIT.IDC.T36.2]                    ;WAIT SOME MORE
                ;30799
                ;30800  IDC.DONE.T36.2:
U 1950, B700,15 ;30801          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1951, 17A0,15 ;30802          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1952, 90FA,15 ;30803          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;30804
                ;30805  READ.DAR.T36.2:
U 1953, 9090,15 ;30806          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1954, 1784,15 ;30807          PORT.READ PORT.ADRS[DAR]                ;SET UP TO READ THE DAR
U 1955, 3B32,15 ;30808          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM DAR AND
                ;30809                                                  ; SAVE IT IN  LS
U 1956, 3732,15 ;30810          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1957, B642,95 ;30811          MOV LS[#2] TO WR[1]                     ;SET UP EXPECTED DATA
U 1958, 0869,3C ;30812          JSR [CHECK.RESULT]                      ;CHECK THE DATA
```

```
U 1959, 8994,34 ;30813          JMP [LOOP.T36.2]                    ;LOOP HERE IF ERR & LOE IS SET
                ;30814
U 195A, 8875,3C ;30815          JSR [CLEANUP]                       ;CLEANUP THE CONDITIONS SET
                ;30816                                              ; BY THIS TEST
                ;30817  END.T36:                                    ;END TEST
                ;30818
                ;30819
                ;30820
```

```
;30821  .PAGE  "Test 37  CSR DATA LATE (DLT) BITS TEST (M8388 IDC MODULE)"
;30822  ;++
;30823  ;
;30824  ; Test Description:
;30825  ;
;30826  ;       This test is designed to verify the CSR bits <12>, and CSR <15>
;30827  ;       set when the IDC issues a SET.DLT.
;30828  ;
;30829  ;
;30830  ; Assumptions:
;30831  ;
;30832  ;       It is assumed that all previous tests have run successfully.
;30833  ;
;30834  ; Test Steps:
;30835  ;
;30836  ;       1. Set up error mask, error number and module number in LS
;30837  ;          (for error printouts) and clear the previous error number in LS.
;30838  ;       2. Force the IDC microcode to DIAG.IDLE and INIT the IDC.
;30839  ;       3. Clear MATCH to assert MISMATCH L to test BIT <12>.
;30840  ;       4. Set up the CSR to branch to the correct IDC microcode routine.
;30841  ;
;30842  ;                                       *******
;30843  ;                                       * IDC *
;30844  ;                                       *******
;30845  ;
;30846  ;               IDC1. Execute an instruction with UCM <2:0> = 3, SET.DLT.
;30847  ;               IDC2. Issue XFER.REQ to flag the CPU.
;30848  ;
;30849  ;
;30850  ;       5. Wait for a XFER.REQ from IDC.
;30851  ;       6. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;30852  ;       7. Check CSR BIT <15> = 1, and CSR BIT <12> = 1.
;30853  ;       8. Increment the error number
;30854  ;       9. Clear CRDY.
;30855  ;      10. Check CSR BIT <12> = 0.
;30856  ;      11. Set DLT.
;30857  ;      12. INIT the IDC.
;30858  ;      13. Check CSR BIT <12> = 0.
;30859  ;      14. Clear IDC.
;30860  ;      15. End test.
;30861  ;
;30862  ; Errors:
;30863  ;
;30864  ;                       Printout:
;30865  ;                               EXPECTED        RECEIVED
;30866  ;                                 CSR             CSR
;30867  ;
;30868  ;
;30869  ;       ERROR 1 - The CSR DLT bits <15> <12> did not set when the IDC issued
;30870  ;                 SET.DLT.
;30871  ;
;30872  ;       ERROR 2 - CSR bit <12> did not clear when CSR <CRDY> was cleared.
;30873  ;
;30874  ;       ERROR 3 - CSR bit <12> did not clear when the IDC was INITed.
;30875  ;
```

```
                ;30876  ; Debug:
                ;30877  ;
                ;30878  ; ERROR 1 -
                ;30879  ;       The IDC will branch to an instruction that will CLR.MATCH. This
                ;30880  ;       will assert MISMATCH L at the DSK RD SEQ REG PAL. This is done so
                ;30881  ;       that CSR bit <12> can be tested.
                ;30882  ;       The IDC will then branch to an instrcution with UCMD<2:0> = 011.
                ;30883  ;       These bits will be decoded by the CONTROL STATUS REG PAL and will
                ;30884  ;       assert DLT L, which then asserts OPI + DLT L. These signal is gated
                ;30885  ;       with MISMATCH L = L which will assert CSR <12>. OPI + DLT L is also
                ;30886  ;       gated with some other signals and in this time is inverted to become
                ;30887  ;       CSR <15>.
                ;30888  ;
                ;30889  ; ERROR 2 -
                ;30890  ;       CSR bit <12> is set. Then a PORT.WRITE PORT.ADRS[CSR] is issued by the
                ;30891  ;       CPU with bit <7> (CRDY) cleared. This instructionis decoded by the
                ;30892  ;       PORT RD/WR DECODE PAL and will assert WRITE CSR L. WRITE CSR L = L
                ;30893  ;       and BUS IO 07 H = L are inputs to the CONTROL STATUS REG PAL. This
                ;30894  ;       combination of inputs will clear DLT L which will then clear
                ;30895  ;       OPI + DLT L.
                ;30896  ;
                ;30897  ; ERROR 3 -
                ;30898  ;       CSR bit <12> is set.
                ;30899  ;       The CPU issues a series of PORT.CONTROL [CLEAR.IDC] instructions which
                ;30900  ;       are decoded by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L.
                ;30901  ;       At the next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the
                ;30902  ;       next clock INIT H is asserted. INIT H is inverted to INIT L. This is
                ;30903  ;       an input to the CONTROL STATUS REG PAL and when INIT L asserts, DLT L
                ;30904  ;       will clear and this will clear OPI + DLT L.
                ;30905  ;--
                ;30906  ;*******************************************************************************
                ;30907  T.37:
U 195B, B65E,15 ;30908          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;30909                                                  ; CONTROL AND STATUS WORD
U 195C, 3E80,15 ;30910          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;30911                                                  ; STATUS WORD - BIT 15
                ;30912                                                  ; INDICATES START OF TEST TO
                ;30913                                                  ; CONSOLE
U 195D, 10E0,15 ;30914          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;30915  WAIT.T37.0:
U 195E, 8995,E4 ;30916          JMP [WAIT.T37.0]                        ;LOOP HERE WAITING FOR
                ;30917                                                  ; CONSOLE TO RESPOND
                ;30918
U 195F, 65A0,15 ;30919          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;30920                                                  ; IN LS
                ;30921
U 1960, B64A,15 ;30922          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1961, 3E8C,15 ;30923          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;30924
                ;30925
U 1962, B640,15 ;30926          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1963, BE82,15 ;30927          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;30928
U 1964, B7CA,15 ;30929          MOV LS[#FFFF6FFF] TO WR[0]              ;SET UP THE MASK TO CHECK
U 1965, 3E8A,15 ;30930          MOV WR[0] TO LS[ERROR.MASK]             ; BITS <15> <12>
```

```
                ;30931
U 1966, 8872,EC ;30932          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE THE
                ;30933                                                  ;IDC TO DIAG.IDLE
                ;30934
U 1967, 370E,15 ;30935          MOV LS[SETCSR.F7] TO WR[0]              ;BRANCH TO THE IDC ROUTINE THAT
U 1968, 17A0,15 ;30936          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; WILL CLEAR A MATCH CONDITION
                ;30937
                ;30938  ;CONTINUE TO BRANCH
                ;30939
U 1969, 379E,15 ;30940          MOV LS[SETCSR.R80] TO WR[0]
U 196A, 3700,95 ;30941          MOV LS[SETCSR.F0] TO WR[1]
U 196B, AEC2,15 ;30942          BIS WR[1] TO WR[0]
U 196C, 17A0,15 ;30943          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;30944                                                  ;F<2:0> = 000
                ;30945  ;UCLR MATCH
                ;30946  ;-------------------------------------------------------------------------
                ;30947  ;-------------------------------------------------------------------------
                ;30948  ;                               *******
                ;30949  ;                               * IDC *
                ;30950  ;                               *******
                ;30951  ;-------------------------------------------------------------------------
                ;30952  ;018:
                ;30953  ;=000
                ;30954  ;DIAG.IDLE:
                ;30955  ;
                ;30956  ;       BEN0/F0,
                ;30957  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;30958  ;       BEN2/F2,
                ;30959  ;       NAD/DIAG.IDLE
                ;30960  ;-------------------------------------------------------------------------
                ;30961  ;01F:
                ;30962  ;=111
                ;30963  ;
                ;30964  ;       BEN0/CRDY.L,
                ;30965  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;30966  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;30967  ;-------------------------------------------------------------------------
                ;30968  ;079:
                ;30969  ;=0*1
                ;30970  ;
                ;30971  ;       NAD/GROUP1
                ;30972  ;-------------------------------------------------------------------------
                ;30973  ;182:
                ;30974  ;=0**
                ;30975  ;GROUP1:
                ;30976  ;
                ;30977  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;30978  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;30979  ;                                       ; FUNCTION BITS
                ;30980  ;-------------------------------------------------------------------------
                ;30981  ;186:
                ;30982  ;=1**
                ;30983  ;
                ;30984  ;       BEN0/F0,
                ;30985  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
```

```
;30986  ;       BEN2/F2,
;30987  ;       NAD/GROUP1.F0
;30988  ;-------------------------------------------------------------------------
;30989  ;028:
;30990  ;=000
;30991  ;GROUP1.F0:
;30992  ;
;30993  ;CLR.MATCH.1:
;30994  ;
;30995  ;       UCON/CLR.MATCH,         ;CLR THE MATCH CONDITION
;30996  ;       NAD/TEST.MATCH.1
;30997  ;-------------------------------------------------------------------------
;30998  ;1F6:
;30999  ;TEST.MATCH.1:
;31000  ;
;31001  ;       BEN2/MISMATCH.L,                ;IS MATCH ASSERTED?
;31002  ;       NAD/BEN2.1
;31003  ;-------------------------------------------------------------------------
;31004  ;1A0:
;31005  ;=0**
;31006  ;BEN2.1:
;31007  ;
;31008  ;       INCR.DAR/ON,                    ;INCR DAR
;31009  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;31010  ;-------------------------------------------------------------------------
;31011  ;1A4:
;31012  ;=1**
;31013  ;BEN2.2:
;31014  ;
;31015  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;31016  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;31017  ;-------------------------------------------------------------------------
;31018  ;1D8:
;31019  ;XFER.REQ:
;31020  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;31021  ;       NAD/DIAG.WAIT
;31022  ;-------------------------------------------------------------------------
;31023  ;1D7:
;31024  ;DIAG.WAIT:
;31025  ;
;31026  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;31027  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;31028  ;-------------------------------------------------------------------------
;31029  ;159:
;31030  ;=*0*
;31031  ;DIAG.WAIT1:
;31032  ;
;31033  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
;31034  ;                               ; COMMAND FROM THE CPU
;31035  ;-------------------------------------------------------------------------
;31036  ;15B:
;31037  ;=*1*
;31038  ;DIAG.WAIT2:
;31039  ;
;31040  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
```

```
                ;31041  ;                                   ; WAIT SOME MORE
                ;31042  ;-----------------------------------------------------------------------
                ;31043  WAIT.IDC.T37.1:
U 196D, DB00,1A ;31044          SKIP.IF[NO.FAST.INTERRUPT]                  ;WAIT FOR XFER REQ FROM IDC
U 196E, 8997,04 ;31045          JMP [IDC.DONE.T37.1]                        ;XFER REQ SET
U 196F, 8996,D4 ;31046          JMP [WAIT.IDC.T37.1]                        ;WAIT SOME MORE
                ;31047
                ;31048  IDC.DONE.T37.1:
U 1970, B700,15 ;31049          MOV LS[SETCSR.F0] TO WR[0]                  ;CLEAR CSR F<2:0>
U 1971, 17A0,15 ;31050          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
U 1972, 90FA,15 ;31051          MISC2 [TRANSFER.GRANT]                      ;SEND GRANT TO CLR THE XFER REQ
                ;31052
                ;31053
                ;31054  ;SET UP THE CSR TO BRANCH TO THE ROUTINE THAT WILL SET.DLT
                ;31055  LOOP.T37.1:
U 1973, B70C,15 ;31056          MOV LS[SETCSR.F6] TO WR[0]                  ;SET UP THE CSR
U 1974, B720,95 ;31057          MOV LS[SETCSR.MAINT] TO WR[1]
U 1975, AEC2,15 ;31058          BIS WR[1] TO WR[0]
U 1976, 17A0,15 ;31059          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]        ;WRITE THE CSR
                ;31060                                                      ;MAINT=1,CRDY=0,F<2:0>=110
                ;31061  ;SET.DLT
                ;31062  ;-----------------------------------------------------------------------
                ;31063  ;-----------------------------------------------------------------------
                ;31064  ;                                   *******
                ;31065  ;                                   * IDC *
                ;31066  ;                                   *******
                ;31067  ;-----------------------------------------------------------------------
                ;31068  ;018:
                ;31069  ;=000
                ;31070  ;DIAG.IDLE:
                ;31071  ;
                ;31072  ;       BEN0/F0,
                ;31073  ;       BEN1/F1,                    ;BRANCH ON THE CSR F<2:0> BITS
                ;31074  ;       BEN2/F2,
                ;31075  ;       NAD/DIAG.IDLE
                ;31076  ;-----------------------------------------------------------------------
                ;31077  ;01E:
                ;31078  ;=110
                ;31079  ;
                ;31080  ;       BEN0/CRDY.L,
                ;31081  ;       BEN2/MAINT,                 ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;31082  ;       NAD/TEST.FUNC6              ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;31083  ;-----------------------------------------------------------------------
                ;31084  ;077:
                ;31085  ;=1*1
                ;31086  ;TEST.F6:
                ;31087  ;                                   ;DO NOT INCR DAR BETWEEN HERE AND
                ;31088  ;                                   ; DIAG.IDLE OR DIAG.WAIT
                ;31089  ;
                ;31090  ;       LOAD.LOOP.CNTR.[00],        ;LOAD LOOP CNTR WITH 00
                ;31091  ;
                ;31092  ;       UCMD/SET.DLT,               ;SET DLT FOR DLT TEST
                ;31093  ;
                ;31094  ;       FUNC/SET.INT,               ;SET INT FOR INTERRUPT TEST
                ;31095  ;
```

```
                ;31096  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;31097  ;-------------------------------------------------------------------------
                ;31098  ;1D8:
                ;31099  ;XFER.REQ:
                ;31100  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;31101  ;       NAD/DIAG.WAIT
                ;31102  ;-------------------------------------------------------------------------
                ;31103  ;1D7:
                ;31104  ;DIAG.WAIT:
                ;31105  ;
                ;31106  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;31107  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;31108  ;-------------------------------------------------------------------------
                ;31109  ;159:
                ;31110  ;=*0*
                ;31111  ;DIAG.WAIT1:
                ;31112  ;
                ;31113  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;31114  ;                               ; COMMAND FROM THE CPU
                ;31115  ;-------------------------------------------------------------------------
                ;31116  ;15B:
                ;31117  ;=*1*
                ;31118  ;DIAG.WAIT2:
                ;31119  ;
                ;31120  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;31121  ;                               ; WAIT SOME MORE
                ;31122  ;-------------------------------------------------------------------------
                ;31123  WAIT.IDC.T37.2:
U 1977, DB00,1A ;31124          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1978, 8997,A4 ;31125          JMP [IDC.DONE.T37.2]                    ;XFER REQ SET
U 1979, 0997,74 ;31126          JMP [WAIT.IDC.T37.2]                    ;WAIT SOME MORE
                ;31127
                ;31128  IDC.DONE.T37.2:
U 197A, B700,15 ;31129          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 197B, 3712,95 ;31130          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY SO DLT DOES NOT CLR
U 197C, AEC2,15 ;31131          BIS WR[1] TO WR[0]
U 197D, 17A0,15 ;31132          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 197E, 90FA,15 ;31133          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;31134
                ;31135  READ.CSR.T37.1:
U 197F, 9090,15 ;31136          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1980, 9780,15 ;31137          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1981, 3B32,15 ;31138          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;31139                                                  ; SAVE IT IN  LS
U 1982, 3732,15 ;31140          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1983, 37CC,95 ;31141          MOV LS[#9000] TO WR[1]                  ;SET UP EXPECTED DATA
U 1984, 0869,3C ;31142          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1985, 8997,34 ;31143          JMP [LOOP.T37.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;31144
U 1986, FF82,15 ;31145          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                ;31146
U 1987, 37CE,15 ;31147          MOV LS[#FFFFEFFF] TO WR[0]              ;SET UP THE MASK TO CHECK
U 1988, 3E8A,15 ;31148          MOV WR[0] TO LS[ERROR.MASK]             ; BIT <12>
                ;31149
                ;31150  LOOP.T37.2:
```

```
U 1989, 3678,15 ;31151          MOV LS[BIT28] TO WR[0]                  ;CLR CRDY (BIT 7)
                ;31152                                                  ;BIT 28 PREVENTS IDC TIMEOUTS
U 198A, 17A0,15 ;31153          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;31154
                ;31155  READ.CSR.T37.2:
U 198B, 9090,15 ;31156          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 198C, 9780,15 ;31157          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 198D, 3B32,15 ;31158          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;31159                                                  ; SAVE IT IN  LS
U 198E, 3732,15 ;31160          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 198F, 2F82,95 ;31161          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1990, 0869,3C ;31162          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1991, 8998,94 ;31163          JMP [LOOP.T37.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;31164
U 1992, FF82,15 ;31165          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 3
                ;31166
                ;31167
                ;31168  ;SET UP THE CSR TO SET DLT
                ;31169
U 1993, B70C,15 ;31170          MOV LS[SETCSR.F6] TO WR[0]              ;SET UP THE CSR
U 1994, B720,95 ;31171          MOV LS[SETCSR.MAINT] TO WR[1]
U 1995, AEC2,15 ;31172          BIS WR[1] TO WR[0]
U 1996, 17A0,15 ;31173          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;31174                                                  ;MAINT=1,CRDY=0,F<2:0>=110
                ;31175  ;SET.DLT
                ;31176  ;-------------------------------------------------------------------------------
                ;31177  ;-------------------------------------------------------------------------------
                ;31178  ;                               *******
                ;31179  ;                               * IDC *
                ;31180  ;                               *******
                ;31181  ;-------------------------------------------------------------------------------
                ;31182  ;018:
                ;31183  ;=000
                ;31184  ;DIAG.IDLE:
                ;31185  ;
                ;31186  ;       BEN0/F0,
                ;31187  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;31188  ;       BEN2/F2,
                ;31189  ;       NAD/DIAG.IDLE
                ;31190  ;-------------------------------------------------------------------------------
                ;31191  ;01E:
                ;31192  ;=110
                ;31193  ;
                ;31194  ;       BEN0/CRDY.L,
                ;31195  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;31196  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;31197  ;-------------------------------------------------------------------------------
                ;31198  ;077:
                ;31199  ;=1*1
                ;31200  ;TEST.F6:
                ;31201  ;                               ;DO NOT INCR DAR BETWEEN HERE AND
                ;31202  ;                               ; DIAG.IDLE OR DIAG.WAIT
                ;31203  ;
                ;31204  ;       LOAD.LOOP.CNTR.[00],    ;LOAD LOOP CNTR WITH 00
                ;31205  ;
```

```
                ;31206  ;       UCMD/SET.DLT,                   ;SET DLT FOR DLT TEST
                ;31207  ;
                ;31208  ;       FUNC/SET.INT,                   ;SET INT FOR INTERRUPT TEST
                ;31209  ;
                ;31210  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                ;31211  ;-------------------------------------------------------------------------
                ;31212  ;1D8:
                ;31213  ;XFER.REQ:
                ;31214  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;31215  ;       NAD/DIAG.WAIT
                ;31216  ;-------------------------------------------------------------------------
                ;31217  ;1D7:
                ;31218  ;DIAG.WAIT:
                ;31219  ;
                ;31220  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;31221  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;31222  ;-------------------------------------------------------------------------
                ;31223  ;159:
                ;31224  ;=*0*
                ;31225  ;DIAG.WAIT1:
                ;31226  ;
                ;31227  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;31228  ;                               ; COMMAND FROM THE CPU
                ;31229  ;-------------------------------------------------------------------------
                ;31230  ;158:
                ;31231  ;=*1*
                ;31232  ;DIAG.WAIT2:
                ;31233  ;
                ;31234  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;31235  ;                               ; WAIT SOME MORE
                ;31236  ;-------------------------------------------------------------------------
                ;31237  WAIT.IDC.T37.3:
U 1997, DB00,1A ;31238          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1998, 0999,A4 ;31239          JMP [IDC.DONE.T37.3]                    ;XFER REQ SET
U 1999, 8999,74 ;31240          JMP [WAIT.IDC.T37.3]                    ;WAIT SOME MORE
                ;31241
                ;31242  IDC.DONE.T37.3:
U 199A, B700,15 ;31243          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 199B, 3712,95 ;31244          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY AS NOT TO CLR DLT
U 199C, AEC2,15 ;31245          BIS WR[1] TO WR[0]
U 199D, 17A0,15 ;31246          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 199E, 90FA,15 ;31247          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;31248
                ;31249  LOOP.T37.3:
U 199F, 17CC,15 ;31250          PORT.CONTROL [CLEAR.IDC]                ;INIT THE IDC
U 19A0, 17CC,15 ;31251          PORT.CONTROL [CLEAR.IDC]
U 19A1, 17CC,15 ;31252          PORT.CONTROL [CLEAR.IDC]
                ;31253
                ;31254  READ.CSR.T37.3:
U 19A2, 9090,15 ;31255          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 19A3, 9780,15 ;31256          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 19A4, 3B32,15 ;31257          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;31258                                                  ; SAVE IT IN  LS
U 19A5, 3732,15 ;31259          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 19A6, 2F82,95 ;31260          CLR WR[1]                               ;SET UP EXPECTED DATA
```

```
U 19A7, 0869,3C ;31261          JSR [CHECK.RESULT]                  ;CHECK THE DATA
U 19A8, 0999,F4 ;31262          JMP [LOOP.T37.3]                    ;LOOP HERE IF ERR & LOE IS SET
                ;31263
U 19A9, 8875,3C ;31264          JSR [CLEANUP]                       ;CLEANUP THE CONDITIONS SET
                ;31265                                              ; BY THIS TEST
                ;31266  END.T37:                                    ;END TEST
                ;31267
                ;31268
                ;31269
```

```
;31270  .PAGE  "Test 38  SKIP SECTOR ERROR FLAG TEST (M8388 IDC MODULE)"
;31271  ;++
;31272  ;
;31273  ; Test Description:
;31274  ;
;31275  ;       This test will verify the Skip Sector Error Flag, CSR bit <23> and
;31276  ;       INH SSE, CSR bit <22> interact correctly.
;31277  ;       Both bits will first be cleared by writing to the CSR.
;31278  ;       Then a USET.SSE will be executed from the IDC microcode. The CPU
;31279  ;       will then read the CSR and check that bit <23> is set and bit <22>
;31280  ;       is clear. Bit <23> will then be cleared by writing to the CSR.
;31281  ;       A USET.SSE will then be executed with CSR <22> (INH SSE) set and
;31282  ;       the CPU will read and check that bit <23> (SSE FLAG) did not get
;31283  ;       latched up and that bit <22> remained set.
;31284  ;
;31285  ; Assumptions:
;31286  ;
;31287  ;       It is assumed that the CSR test has run successfully.
;31288  ;
;31289  ; Test Steps:
;31290  ;
;31291  ;       1. Set up error mask, error number and module number in LS
;31292  ;          (for error printouts) and clear the previous error number in LS.
;31293  ;       2. Force the IDC microcode to DIAG.IDLE.
;31294  ;       3. Clear CSR <23:22>.
;31295  ;       4. Set up the CSR to branch to the correct IDC microcode routine.
;31296  ;
;31297  ;
;31298  ;                                       *******
;31299  ;                                       * IDC *
;31300  ;                                       *******
;31301  ;
;31302  ;               IDC1. Execute an instruction with UFUNC <3:0> = 1000,
;31303  ;                     USET.SSE.
;31304  ;               IDC2. Issue an XFER.REQ to flag the CPU and go to DIAG.WAIT.
;31305  ;
;31306  ;       5. Wait for a XFER REQ from IDC.
;31307  ;       6. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;31308  ;       7. Check CSR <23> = 1 and CSR <22> = 0.
;31309  ;       8. Increment the error number.
;31310  ;       9. Clear CSR <23>.
;31311  ;      10. Set CSR <22>, INH SSE.
;31312  ;      11. Set up the CSR to branch to the correct microcode routine.
;31313  ;
;31314  ;
;31315  ;                                       *******
;31316  ;                                       * IDC *
;31317  ;                                       *******
;31318  ;
;31319  ;               IDC3. Perform Steps IDC1 - IDC2.
;31320  ;
;31321  ;      12. Wait for a XFER REQ from IDC.
;31322  ;      13. Clear CSR F<2:0> and send XFER GRANT to clear the XFER REQ.
;31323  ;      14. Check CSR <23> = 0 and CSR <22> = 1.
;31324  ;      15. Clear IDC.
```

```
                ;31325  ;      16. End test.
                ;31326  ;
                ;31327  ; Errors:
                ;31328  ;
                ;31329  ;                 Printout:
                ;31330  ;                         EXPECTED          RECEIVED
                ;31331  ;                           CSR               CSR
                ;31332  ;
                ;31333  ;
                ;31334  ;       ERROR 1 - When a USET.SSE was done from the IDC microcode, either
                ;31335  ;                 Bit <23> did not set or bit <22> did not remain clear.
                ;31336  ;
                ;31337  ;       ERROR 2 - Bit <23> was latched  by a USET.SSE when INH SSE
                ;31338  ;                 <22> was set.
                ;31339  ;
                ;31340  ;
                ;31341  ; Debug:
                ;31342  ;
                ;31343  ; ERROR 1 -
                ;31344  ;       First CSR <23:22> are written to zeros.
                ;31345  ;       Then the IDC branches to a microinstrcution with UFUNC<3:0> = 1000.
                ;31346  ;       These bits are decoded and will assert USET SSE L. This is an input
                ;31347  ;       to the ONLINE REG PAL and at the next P2 CLOCK L, SSE FLAG L will
                ;31348  ;       assert. SSE FLAG L will reamin latched as long as INH SSE L is not
                ;31349  ;       asserted. SSE FLAG L becomes bit 23 of the CSR.
                ;31350  ;
                ;31351  ; ERROR 2 -
                ;31352  ;       The CPU issues a PORT.WRITE PORT.ADRS[CSR] with bits <23:22> = 01.
                ;31353  ;       This instruction is decoded by the PORT RD/WR DECODE PAL and asserts
                ;31354  ;       WRITE CSR L. The inputs to the ONLINE REG PAL should be:
                ;31355  ;               WRITE CSR L = L
                ;31356  ;               BUS IO 23 H = L
                ;31357  ;               BUS IO 22 H = H
                ;31358  ;       This will assert INH SSE L. The IDC will then branch to an instruction
                ;31359  ;       that will assert USET SSE L (see ERROR 1), however since INH SSE L is
                ;31360  ;       asserted, SSE FLAG L will not be latched.
                ;31361  ;--
                ;31362  ;*******************************************************************************
                ;31363  T.38:
U 19AA, B65E,15 ;31364          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;31365                                                  ; CONTROL AND STATUS WORD
U 19AB, 3E80,15 ;31366          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;31367                                                  ; STATUS WORD - BIT 15
                ;31368                                                  ; INDICATES START OF TEST TO
                ;31369                                                  ; CONSOLE
U 19AC, 10E0,15 ;31370          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;31371  WAIT.T38.0:
U 19AD, 899A,D4 ;31372          JMP [WAIT.T38.0]                        ;LOOP HERE WAITING FOR
                ;31373                                                  ; CONSOLE TO RESPOND
                ;31374
U 19AE, 65A0,15 ;31375          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;31376                                                  ; IN LS
                ;31377
U 19AF, B64A,15 ;31378          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 19B0, 3E8C,15 ;31379          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
```

```
                    ;31380
                    ;31381
U 19B1, B640,15 ;31382          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 19B2, BE82,15 ;31383          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                    ;31384
U 19B3, B7E8,15 ;31385          MOV LS[#FF3FFFFF] TO WR[0]
U 19B4, 3E8A,15 ;31386          MOV WR[0] TO LS[ERROR.MASK]             ;SET MASK TO CHECK <23> <22>
                    ;31387
                    ;31388
U 19B5, 8872,EC ;31389          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT
                    ;31390                                              ; TO DIAG.IDLE
                    ;31391  LOOP.T38.1:
U 19B6, 370E,15 ;31392          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 19B7, 17A0,15 ;31393          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                    ;31394
                    ;31395  ;CONTINUE TO BRANCH
U 19B8, 379E,15 ;31396          MOV LS[SETCSR.R80] TO WR[0]
U 19B9, B70E,95 ;31397          MOV LS[SETCSR.F7] TO WR[1]
U 19BA, AEC2,15 ;31398          BIS WR[1] TO WR[0]
U 19BB, 17A0,15 ;31399          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;31400                                              ;BITS<23:22> = 00
                    ;31401  ;SET.SSE
                    ;31402  ;-------------------------------------------------------------------------
                    ;31403  ;-------------------------------------------------------------------------
                    ;31404  ;                                  *******
                    ;31405  ;                                  * IDC *
                    ;31406  ;                                  *******
                    ;31407  ;-------------------------------------------------------------------------
                    ;31408  ;018:
                    ;31409  ;=000
                    ;31410  ;DIAG.IDLE:
                    ;31411  ;
                    ;31412  ;       BEN0/F0,
                    ;31413  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                    ;31414  ;       BEN2/F2,
                    ;31415  ;       NAD/DIAG.IDLE
                    ;31416  ;-------------------------------------------------------------------------
                    ;31417  ;01F:
                    ;31418  ;=111
                    ;31419  ;
                    ;31420  ;       BEN0/CRDY.L,
                    ;31421  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                    ;31422  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                    ;31423  ;-------------------------------------------------------------------------
                    ;31424  ;079:
                    ;31425  ;=0*1
                    ;31426  ;
                    ;31427  ;       NAD/GROUP1
                    ;31428  ;-------------------------------------------------------------------------
                    ;31429  ;182:
                    ;31430  ;=0**
                    ;31431  ;GROUP1:
                    ;31432  ;
                    ;31433  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                    ;31434  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
```

```
;31435  ;                                       ; FUNCTION BITS
;31436  ;-------------------------------------------------------------------------
;31437  ;186:
;31438  ;=1**
;31439  ;
;31440  ;       BEN0/F0,
;31441  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;31442  ;       BEN2/F2,
;31443  ;       NAD/GROUP1.F0
;31444  ;-------------------------------------------------------------------------
;31445  ;02F:
;31446  ;=111
;31447  ;
;31448  ;       UCMD/SET.OPI,           ;SET OPI FOR CSR OPI TEST
;31449  ;
;31450  ;       FUNC/SET.SSE,           ;SET SKIP SECTOR ERROR
;31451  ;       NAD/OPI.BR.TST          ;USED FOR OPI.L BRANCH TEST...DOES NOT AFFECT
;31452  ;                               ; SET SSE OR SET.OPI
;31453  ;-------------------------------------------------------------------------
;31454  ;02B:
;31455  ;=011
;31456  ;OPI.BR.TST:
;31457  ;
;31458  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
;31459  ;       NAD/BEN2.1
;31460  ;-------------------------------------------------------------------------
;31461  ;1A0:
;31462  ;=0**
;31463  ;BEN2.1:
;31464  ;
;31465  ;       INCR.DAR/ON,                    ;INCR DAR
;31466  ;       NAD/XFER.REQ                    ;FLAG THE CPU
;31467  ;-------------------------------------------------------------------------
;31468  ;1A4:
;31469  ;=1**
;31470  ;BEN2.2:
;31471  ;
;31472  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
;31473  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
;31474  ;-------------------------------------------------------------------------
;31475  ;1D8:
;31476  ;XFER.REQ:
;31477  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;31478  ;       NAD/DIAG.WAIT
;31479  ;-------------------------------------------------------------------------
;31480  ;1D7:
;31481  ;DIAG.WAIT:
;31482  ;
;31483  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;31484  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;31485  ;-------------------------------------------------------------------------
;31486  ;159:
;31487  ;=*0*
;31488  ;DIAG.WAIT1:
;31489  ;
```

```
                    ;31490  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;31491  ;                               ; COMMAND FROM THE CPU
                    ;31492  ;-------------------------------------------------------------------------
                    ;31493  ;15B:
                    ;31494  ;=*1*
                    ;31495  ;DIAG.WAIT2:
                    ;31496  ;
                    ;31497  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;31498  ;                               ; WAIT SOME MORE
                    ;31499  ;-------------------------------------------------------------------------
                    ;31500  WAIT.IDC.T38.1:
U 19BC, DB00,1A     ;31501          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 19BD, 899B,F4     ;31502          JMP [IDC.DONE.T38.1]                    ;XFER REQ SET
U 19BE, 899B,C4     ;31503          JMP [WAIT.IDC.T38.1]                    ;WAIT SOME MORE
                    ;31504
                    ;31505  IDC.DONE.T38.1:
                    ;31506  ;READ THE CSR AND SAVE THE DATA IN LS
                    ;31507
U 19BF, 9090,15     ;31508          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 19C0, 9780,15     ;31509          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 19C1, 3B32,15     ;31510          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;31511                                                  ; SAVE IT IN  LS
                    ;31512
                    ;31513  ;SEND XFER GRANT TO CLEAR THE XFER REQ
U 19C2, B700,15     ;31514          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 19C3, 17A0,15     ;31515          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 19C4, 90FA,15     ;31516          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                    ;31517
U 19C5, 3732,15     ;31518          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 19C6, 366E,95     ;31519          MOV LS[BIT23] TO WR[1]                  ;SET UP EXPECTED DATA
U 19C7, 0869,3C     ;31520          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 19C8, 899B,64     ;31521          JMP [LOOP.T38.1]                        ;LOOP HERE IF ERR AND LOE SET
                    ;31522
U 19C9, FF82,15     ;31523          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                    ;31524
                    ;31525  LOOP.T38.2:
U 19CA, 370E,15     ;31526          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 19CB, 17A0,15     ;31527          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ; THE CORRECT IDC ROUTINE
                    ;31528
                    ;31529  ;CONTINUE TO BRANCH
U 19CC, 379E,15     ;31530          MOV LS[SETCSR.R80] TO WR[0]
U 19CD, B70E,95     ;31531          MOV LS[SETCSR.F7] TO WR[1]
U 19CE, AEC2,15     ;31532          BIS WR[1] TO WR[0]
U 19CF, 476C,15     ;31533          BIS LS[BIT22] TO WR[0]                  ;SET INH SSE
U 19D0, 17A0,15     ;31534          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;31535                                                  ;BIT<23>=0 BIT<22>=1
                    ;31536  ;SET.SSE
                    ;31537  ;-------------------------------------------------------------------------
                    ;31538  ;-------------------------------------------------------------------------
                    ;31539  ;                               *******
                    ;31540  ;                               * IDC *
                    ;31541  ;                               *******
                    ;31542  ;-------------------------------------------------------------------------
                    ;31543  ;018:
                    ;31544  ;=000
```

```
;31545  ;DIAG.IDLE:
;31546  ;
;31547  ;       BEN0/F0,
;31548  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;31549  ;       BEN2/F2,
;31550  ;       NAD/DIAG.IDLE
;31551  ;-------------------------------------------------------------------------
;31552  ;01F:
;31553  ;=111
;31554  ;
;31555  ;       BEN0/CRDY.L,
;31556  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;31557  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;31558  ;-------------------------------------------------------------------------
;31559  ;079:
;31560  ;=0*1
;31561  ;
;31562  ;       NAD/GROUP1
;31563  ;-------------------------------------------------------------------------
;31564  ;182:
;31565  ;=0**
;31566  ;GROUP1:
;31567  ;
;31568  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;31569  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;31570  ;                                       ; FUNCTION BITS
;31571  ;-------------------------------------------------------------------------
;31572  ;186:
;31573  ;=1**
;31574  ;
;31575  ;       BEN0/F0,
;31576  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;31577  ;       BEN2/F2,
;31578  ;       NAD/GROUP1.F0
;31579  ;-------------------------------------------------------------------------
;31580  ;02F:
;31581  ;=111
;31582  ;
;31583  ;       UCMD/SET.OPI,           ;SET OPI FOR CSR OPI TEST
;31584  ;
;31585  ;       FUNC/SET.SSE,           ;SET SKIP SECTOR ERROR
;31586  ;       NAD/OPI.BR.TST          ;USED FOR OPI.L BRANCH TEST...DOES NOT AFFECT
;31587  ;                               ; SET SSE OR SET.OPI
;31588  ;-------------------------------------------------------------------------
;31589  ;02B:
;31590  ;=011
;31591  ;OPI.BR.TST:
;31592  ;
;31593  ;       BEN2/OPI.L,             ;IS OPI ASSERTED?
;31594  ;       NAD/BEN2.1
;31595  ;-------------------------------------------------------------------------
;31596  ;1A0:
;31597  ;=0**
;31598  ;BEN2.1:
;31599  ;
```

```
                ;31600  ;       INCR.DAR/ON,                    ;INCR DAR
                ;31601  ;       NAD/XFER.REQ                    ;FLAG THE CPU
                ;31602  ;-------------------------------------------------------------------
                ;31603  ;1A4:
                ;31604  ;=1**
                ;31605  ;BEN2.2:
                ;31606  ;
                ;31607  ;       INCR.DAR/ON,                    ;INCR DAR IF BEN2 CONDITION ASSERTED
                ;31608  ;       NAD/BEN2.1                      ;INCR DAR AGAIN IF BEN2 COND ASSERTED
                ;31609  ;-------------------------------------------------------------------
                ;31610  ;1D8:
                ;31611  ;XFER.REQ:
                ;31612  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;31613  ;       NAD/DIAG.WAIT
                ;31614  ;-------------------------------------------------------------------
                ;31615  ;1D7:
                ;31616  ;DIAG.WAIT:
                ;31617  ;
                ;31618  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;31619  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;31620  ;-------------------------------------------------------------------
                ;31621  ;159:
                ;31622  ;=*0*
                ;31623  ;DIAG.WAIT1:
                ;31624  ;
                ;31625  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;31626  ;                               ; COMMAND FROM THE CPU
                ;31627  ;-------------------------------------------------------------------
                ;31628  ;15B:
                ;31629  ;=*1*
                ;31630  ;DIAG.WAIT2:
                ;31631  ;
                ;31632  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;31633  ;                               ; WAIT SOME MORE
                ;31634  ;-------------------------------------------------------------------
                ;31635  WAIT.IDC.T38.2:
U 19D1, DB00,1A ;31636          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 19D2, 099D,44 ;31637          JMP [IDC.DONE.T38.2]                    ;XFER REQ SET
U 19D3, 099D,14 ;31638          JMP [WAIT.IDC.T38.2]                    ;WAIT SOME MORE
                ;31639
                ;31640  IDC.DONE.T38.2:
U 19D4, 9090,15 ;31641          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 19D5, 9780,15 ;31642          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 19D6, 3B32,15 ;31643          MOV PORT TO LS[PORTO]                   ;READ THE DATA FROM CSR AND
                ;31644                                                  ; SAVE IT IN  LS
                ;31645  ;SEND XFER GRANT TO CLEAR THE XFER REQ
U 19D7, B700,15 ;31646          MOV LS[SETCSR.FO] TO WR[0]              ;CLEAR CSR F<2:0>
U 19D8, 17A0,15 ;31647          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 19D9, 90FA,15 ;31648          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;31649
U 19DA, 3732,15 ;31650          MOV LS[PORTO] TO WR[0]                  ;SET UP RECEIVED DATA
U 19DB, B66C,95 ;31651          MOV LS[BIT22] TO WR[1]                  ;SET UP EXPECTED DATA
U 19DC, 0869,3C ;31652          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 19DD, 099C,A4 ;31653          JMP [LOOP.T38.2]                        ;LOOP HERE IF ERR AND LOE SET
                ;31654
```

```
U 19DE, 8875,3C ;31655          JSR [CLEANUP]                          ;CLEANUP THE CONDITIONS SET BY
                ;31656                                                 ; THIS TEST
                ;31657
                ;31658  END.T38:                                       ;END TEST
                ;31659
                ;31660
                ;31661
```

```
;31662  .PAGE  "Test 39 INTERRUPT REQUEST TEST 1 (M8388 IDC MODULE)"
;31663  ;++
;31664  ;
;31665  ; Test Description:
;31666  ;
;31667  ;       This test is designed to insure that the IDC interrupt request at BR 5
;31668  ;       logic is working correctly. This will be accomplished by executing an
;31669  ;       IDC microinstruction with FUNC<35:32> = 0C, SET.INT with CSR <INT.IE>
;31670  ;       set and CRDY set. The CPU will check the interrupt line to be sure that
;31671  ;       the interrupt was issued. The CPU will then issue a RESET BR Port
;31672  ;       Instruction and will check that the interrupt request was cleared.
;31673  ;       SET.INT will then be issued with CRDY clear and CSR <INT.IE> set.
;31674  ;       The CPU will check that the interrupt was not received.
;31675  ;       CSR <INT.IE> will then be cleared and CRDY will be set. An IDC
;31676  ;       microinstruction with FUNC<35:32> = 0C, SET.INT will then be executed.
;31677  ;       The CPU will check to insure that the interrupt did not occur.
;31678  ;
;31679  ; Assumptions:
;31680  ;
;31681  ;       It is assumed that all previous tests have run successfully.
;31682  ;
;31683  ; Test Steps:
;31684  ;
;31685  ;       1. Set up error mask, error number and module number in LS
;31686  ;          (for error printouts) and clear the previous error number in LS.
;31687  ;       2. Force IDC microcode to DIAG.IDLE.
;31688  ;       3. Lower the IPL to 0. ( CLR LS[PSL.HW] )
;31689  ;       4. Set bit <INTERUPT.EN> of the LS[CONTROL.STATUS] and allow time
;31690  ;          any pending interrupts to clear.
;31691  ;       5. Set IDC CSR <INT.IE>, interrupt enable and set CSR CRDY.
;31692  ;       6. Set up the CSR to branch to the correct IDC microcode routine.
;31693  ;
;31694  ;
;31695  ;                                       *******
;31696  ;                                       * IDC *
;31697  ;                                       *******
;31698  ;
;31699  ;               IDC1. Execute an instruction with FUNC <35:32> = 0C, SET.INT.
;31700  ;               IDC2. Issue XFER.REQ to flag the CPU.
;31701  ;
;31702  ;       7. Wait for XFER.REQ from the IDC.
;31703  ;       8. Clear CSR F<2:0> and send XFER GRANT to clear the XFER.REQ.
;31704  ;       9. If the hardware register (Interrupt Vector does not decode a BR5
;31705  ;          logic code, then issue error 6 (this is an added error report for
;31706  ;          fault insertion enhancement).
;31707  ;      10. Check the IR bit of CSR, it should be set, if not issue error 7
;31708  ;          (this is an added error report for fault insertion enhancement).
;31709  ;      11. If Interrupt Request is not set then issue ERROR 1.
;31710  ;      12. Increment the error number to ERROR 2.
;31711  ;      13. Issue port instruction to clear the BR 5.
;31712  ;      14. Check the IR bit of CSR, it should be reset, if not issue error 8
;31713  ;          (this is an added error report for fault insertion enhancement).
;31714  ;      15. If Interrupt Request is still asserted then issue ERROR.
;31715  ;      16. Increment the error number.
;31716  ;      17. Clear CSR CRDY and set CSR <INT.IE>.
```

```
;31717  ;       18. Set up the CSR to branch to the correct IDC microcode routine.
;31718  ;
;31719  ;
;31720  ;                                       *******
;31721  ;                                       * IDC *
;31722  ;                                       *******
;31723  ;
;31724  ;               IDC3. Execute an instruction with FUNC <35:32> = 0C, SET.INT.
;31725  ;               IDC4. Issue XFER.REQ to flag the CPU.
;31726  ;
;31727  ;       19. Wait for XFER.REQ from the IDC.
;31728  ;       20. Clear CSR F<2:0> and send XFER GRANT to clear the XFER.REQ.
;31729  ;       21. If Interrupt Request is asserted then issue error.
;31730  ;       22. Increment the error number.
;31731  ;       23. Clear CSR <INT.IE> and set CSR CRDY.
;31732  ;       24. Set up the CSR to branch to the correct IDC microcode routine.
;31733  ;
;31734  ;
;31735  ;
;31736  ;
;31737  ;
;31738  ;
;31739  ;                                       *******
;31740  ;                                       * IDC *
;31741  ;                                       *******
;31742  ;
;31743  ;               IDC5. Execute an instruction with FUNC <35:32> = 0C, SET.INT.
;31744  ;               IDC6. Issue XFER.REQ to flag the CPU.
;31745  ;
;31746  ;       25. Clear CSR F<2:0> and send XFER GRANT to clear XFER.REQ.
;31747  ;       26. If Interrupt Request is asserted then issue ERROR.
;31748  ;       27. Increment the error number.
;31749  ;       28. Set Interrupt Request.
;31750  ;       29. INIT the IDC.
;31751  ;       30. If Interrupt Request is asserted then issue error.
;31752  ;       31. Clear IDC.
;31753  ;       32. End test.
;31754  ;
;31755  ; Errors:
;31756  ;
;31757  ;       ERROR 1 - IDC did not assert the interrupt request.
;31758  ;
;31759  ;       ERROR 2 - Interrupt Request did not clear when RESET BR was issued.
;31760  ;
;31761  ;       ERROR 3 - Interrupt Request asserted when CRDY was cleared.
;31762  ;
;31763  ;       ERROR 4 - Interrupt Request asserted when not enabled.
;31764  ;
;31765  ;       ERROR 5 - Interrupt Request was asserted after IDC INIT.
;31766  ;
;31767  ;       ERROR 6 - BR5 Interrupt was not seen by cpu after SET.INT was asserted.
;31768  ;
;31769  ;       ERROR 7 - IR bit of CSR was not set after SET.INT was asserted.
;31770  ;
;31771  ;       ERROR 8 - IR was not cleared after clearing the Interrupt Request.
```

```
;31772  ;
;31773  ; Debug:
;31774  ;
;31775  ; ERROR 1-
;31776  ;       Any pending interrupts are cleared and the IPL is lowered to 0.
;31777  ;       CSR <CRDY> and CSR <IE> are set. The IDC microcode then branches to
;31778  ;       a microinstruction with UFUNC<3:0>=1100 which is decoded and will
;31779  ;       assert USET INT L. This is an input to the ATTN REG PAL.
;31780  ;       USET INT L is gated through the PAL and will assert SET INT REQ H.
;31781  ;       This signal is an input to the FIFO A ADRS CNTR LO PAL. The inputs at
;31782  ;       this time should be:
;31783  ;               SET INT REQ H = H
;31784  ;               RESET BR L = H
;31785  ;               IE H = H
;31786  ;               CRDY H = H
;31787  ;       This combination of inputs will assert INT REQ DIN H. This is an input
;31788  ;       to the INIT FF and at the next P2 CLOCK L will assert INT REQ H.
;31789  ;       INT REQ H is inverted and leaves the board as UBUS BR5 L.
;31790  ;
;31791  ; ERROR 2-
;31792  ;       The CPU will issue a PORT.CONTROL [RESET.BR] to the IDC which
;31793  ;       will clear the BR 5. The instruction is decoded by the PORT RD/WR
;31794  ;       DECODE PAL. The inputs should be:
;31795  ;               CSR 17 H = H
;31796  ;               CSR 14 H = H
;31797  ;               CSR 12 H = L
;31798  ;               CSR 11 H = L
;31799  ;               CSR 10 H = H
;31800  ;               PORT INSTR H = H
;31801  ;       This combination of inputs will assert RESET BR L. This is an input to
;31802  ;       the FIFOA ADRS CNTR LO PAL and will clear INT REQ DIN H. This signal
;31803  ;       is gated through the INIT FF at the next P2 CLOCK L forcing
;31804  ;       INT REQ H = L. INT REQ H = L is inverted and leaved the board as
;31805  ;       UBUS BR5 L = H.
;31806  ;
;31807  ; ERROR 3-
;31808  ;       The IDC is set up to branch to a microinstruction with UFUNC<3:0>=1100
;31809  ;       which is decoded and will assert USET INT L. This is an input to the
;31810  ;       ATTN REG PAL. USET INT L is gated through the PAL and will assert
;31811  ;       SET INT REQ H.
;31812  ;       This signal is an input to the FIFO A ADRS CNTR LO PAL. The inputs at
;31813  ;       this time should be:
;31814  ;               SET INT REQ H = H
;31815  ;               RESET BR L = H
;31816  ;               IE H = H
;31817  ;               CRDY H = L
;31818  ;       Since CRDY is clear at this time, INT REQ DIN H will not assert.
;31819  ;
;31820  ; ERROR 4 -
;31821  ;       The IDC is set up to branch to a microinstruction with UFUNC<3:0>=1100
;31822  ;       which is decoded and will assert USET INT L. This is an input to the
;31823  ;       ATTN REG PAL. USET INT L is gated through the PAL and will assert
;31824  ;       SET INT REQ H.
;31825  ;       This signal is an input to the FIFO A ADRS CNTR LO PAL. The inputs at
;31826  ;       this time should be:
```

```
                ;31827  ;               SET INT REQ H = H
                ;31828  ;               RESET BR L = H
                ;31829  ;               IE H = L
                ;31830  ;               CRDY H = H
                ;31831  ;       Since interrupts are not enabled at this time (IE H = L), INT REQ DIN H
                ;31832  ;       will not assert.
                ;31833  ;
                ;31834  ; ERROR 5 -
                ;31835  ;       INT REQ H is first set.
                ;31836  ;       The CPU issues a series of PORT.CONTROL [CLEAR.IDC] instructions which
                ;31837  ;       are decoded by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L.
                ;31838  ;       At the next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the
                ;31839  ;       next clock INIT H is asserted. This is an input to the ATTN REG PAL
                ;31840  ;       and when INIT H asserts, SET INT REQ H will clear.
                ;31841  ;
                ;31842  ; ERROR 6 -
                ;31843  ;       BR5 Interrupt was not seen by cpu after USET INT L is asserted. The BR5
                ;31844  ;       logic should be checked such as SET INT REQ, IE, INT REQ for a possible
                ;31845  ;       stuck low and USET INT for a possible stuck high.
                ;31846  ;
                ;31847  ; ERROR 7 -
                ;31848  ;       Check the IR bit of CSR bit <24>, it should be high when USET INT is
                ;31849  ;       enabled.
                ;31850  ;
                ;31851  ; ERROR 8 -
                ;31852  ;       Check the IR bit of CSR bit <24>, it should be low when Interrupt is
                ;31853  ;       cleared.
                ;31854  ;
                ;31855  ;--
                ;31856  ;*******************************************************************************
                ;31857  T.39:
U 19DF, B65E,15 ;31858          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;31859                                                  ; CONTROL AND STATUS WORD
U 19E0, 3E80,15 ;31860          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;31861                                                  ; STATUS WORD - BIT 15
                ;31862                                                  ; INDICATES START OF TEST TO
                ;31863                                                  ; CONSOLE
U 19E1, 10E0,15 ;31864          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;31865  WAIT.T39.0:
U 19E2, 099E,24 ;31866          JMP [WAIT.T39.0]                        ;LOOP HERE WAITING FOR
                ;31867                                                  ; CONSOLE TO RESPOND
                ;31868
U 19E3, 65A0,15 ;31869          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;31870                                                  ; IN LS
                ;31871
                ;31872
U 19E4, 3660,15 ;31873          MOV LS[INTERUPT.EN] TO WR[0]            ;CLEAR ANY PENDING INTERRUPTS
U 19E5, 3E80,15 ;31874          MOV WR[0] TO LS[CONTROL.STATUS]
                ;31875
U 19E6, 10E0,15 ;31876          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;31877  WAIT.T39.1:
U 19E7, 099E,74 ;31878          JMP [WAIT.T39.1]                        ;LOOP HERE WAITING FOR
                ;31879                                                  ; CONSOLE TO RESPOND
                ;31880
U 19E8, B64A,15 ;31881          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
```

```
U 19E9, 3E8C,15 ;31882          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;31883
U 19EA, 8872,EC ;31884          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT TO
                ;31885                                                  ; DIAG.IDLE
                ;31886
U 19EB, 2F80,15 ;31887          CLR WR[0]
U 19EC, BFFE,15 ;31888          MOV WR[0] TO LS[PSL.HW]                 ;LOWER THE IPL TO 0
                ;31889
                ;31890  LOOP.T39.1:
U 19ED, 370E,15 ;31891          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 19EE, B720,95 ;31892          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE CORRECT IDC ROUTINE
U 19EF, AEC2,15 ;31893          BIS WR[1] TO WR[0]
U 19F0, 3712,95 ;31894          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 19F1, AEC2,15 ;31895          BIS WR[1] TO WR[0]
U 19F2, B710,95 ;31896          MOV LS[SETCSR.IE] TO WR[1]              ;SET INTERRUPT ENABLE
U 19F3, AEC2,15 ;31897          BIS WR[1] TO WR[0]
U 19F4, 17A0,15 ;31898          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;31899                                                  ;MAINT=1,CRDY=1,F<2:0>=111
                ;31900  ;SET.INT
                ;31901  ;-------------------------------------------------------------------------------
                ;31902  ;-------------------------------------------------------------------------------
                ;31903  ;                               *******
                ;31904  ;                               * IDC *
                ;31905  ;                               *******
                ;31906  ;-------------------------------------------------------------------------
                ;31907  ;018:
                ;31908  ;=000
                ;31909  ;DIAG.IDLE:
                ;31910  ;
                ;31911  ;       BEN0/F0,
                ;31912  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;31913  ;       BEN2/F2,
                ;31914  ;       NAD/DIAG.IDLE
                ;31915  ;-------------------------------------------------------------------------
                ;31916  ;01F:
                ;31917  ;=111
                ;31918  ;
                ;31919  ;       BEN0/CRDY.L,
                ;31920  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;31921  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;31922  ;-------------------------------------------------------------------------
                ;31923  ;07C:
                ;31924  ;=1*0
                ;31925  ;SET.INT:
                ;31926  ;
                ;31927  ;       FUNC/SET.INT,           ;SET INT FOR INT TEST...CRDY MUST
                ;31928  ;                               ; BE SET IN CSR
                ;31929  ;       NAD/XFER.REQ
                ;31930  ;-------------------------------------------------------------------------
                ;31931  ;1D8:
                ;31932  ;XFER.REQ:
                ;31933  ;       UCMD/SET.XFER.RQST,     ;SEND XFER REQ TO THE CPU
                ;31934  ;       NAD/DIAG.WAIT
                ;31935  ;-------------------------------------------------------------------------
                ;31936  ;1D7:
```

```
                ;31937  ;DIAG.WAIT:
                ;31938  ;
                ;31939  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;31940  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;31941  ;-------------------------------------------------------------------
                ;31942  ;159:
                ;31943  ;=*0*
                ;31944  ;DIAG.WAIT1:
                ;31945  ;
                ;31946  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;31947  ;                               ; COMMAND FROM THE CPU
                ;31948  ;-------------------------------------------------------------------
                ;31949  ;15B:
                ;31950  ;=*1*
                ;31951  ;DIAG.WAIT2:
                ;31952  ;
                ;31953  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;31954  ;                               ; WAIT SOME MORE
                ;31955  ;-------------------------------------------------------------------
                ;31956  WAIT.IDC.T39.1:
U 19F5, DB00,1A ;31957          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 19F6, 899F,84 ;31958          JMP [IDC.DONE.T39.1]                    ;XFER REQ SET
U 19F7, 099F,54 ;31959          JMP [WAIT.IDC.T39.1]                    ;WAIT SOME MORE
                ;31960
                ;31961  IDC.DONE.T39.1:
U 19F8, B700,15 ;31962          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 19F9, 3712,95 ;31963          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 19FA, AEC2,15 ;31964          BIS WR[1] TO WR[0]
U 19FB, B710,95 ;31965          MOV LS[SETCSR.IE] TO WR[1]              ;SET INT ENABLE
U 19FC, AEC2,15 ;31966          BIS WR[1] TO WR[0]
U 19FD, 17A0,15 ;31967          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 19FE, 90FA,15 ;31968          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
U 19FF, 89A1,C7 ;31969          JMP.IF[NO.INTERRUPT] TO [ERROR.T39.1]   ;JMP IF NO INTERRUPT (ERROR)
U 1A00, 3792,15 ;31970          MOV LS[#6] TO WR[0]                     ;SET UP ERROR NUMBER = 6
U 1A01, BE82,15 ;31971          MOV WR[0] TO LS[ERROR.NUMBER]
U 1A02, 37EA,15 ;31972          MOV LS[#FFFFFFE3] TO WR[0]              ;MASK FOR BITS 4,3 & 2
U 1A03, 3E8A,15 ;31973          MOV WR[0] TO LS[ERROR.MASK]
U 1A04, 36FC,15 ;31974          MOV LS[INTERRUPT.VEC] TO WR[0]          ;FETCH THE INTER. HARDWARE REG.
U 1A05, B648,95 ;31975          MOV LS[#10] TO WR[1]                    ;EXP BR5 CODES SET IN H.D. REG.
U 1A06, 0869,3C ;31976          JSR [CHECK.RESULT]                      ;CHECK IF BR5 LOGIC SEEN BY CPU
U 1A07, 099E,D4 ;31977          JMP [LOOP.T39.1]                        ;LOOP HERE IF LOOP IS SET
                ;31978
U 1A08, 9090,15 ;31979          MISC [SET.PORT.I.0]                     ;SELECT FROM PORT TO BUS
U 1A09, 9780,15 ;31980          PORT.READ PORT.ADRS[CSR]                ;READ CSR BACK
U 1A0A, 3B32,15 ;31981          MOV PORT TO LS[PORT0]                   ;SAVE IT FOR LATER
U 1A0B, FF82,15 ;31982          INC LS[ERROR.NUMBER]                    ;SET UP ERROR NUMBER = 7
U 1A0C, 37EC,15 ;31983          MOV LS[#FEFFFFFF] TO WR[0]              ;MASK FOR BIT 24
U 1A0D, 3E8A,15 ;31984          MOV WR[0] TO LS[ERROR.MASK]
U 1A0E, 3732,15 ;31985          MOV LS[PORT0] TO WR[0]                  ;RECEIVED IR BIT FROM CSR
U 1A0F, 3670,95 ;31986          MOV LS[BIT24] TO WR[1]                  ;EXP. STATE OF CSR IR BIT
U 1A10, 0869,3C ;31987          JSR [CHECK.RESULT]                      ;SEE IF IR BIT IS SET
U 1A11, 099E,D4 ;31988          JMP [LOOP.T39.1]                        ;LOOP HERE IF LOOP IS SET
                ;31989
U 1A12, B640,15 ;31990          MOV LS[#1] TO WR[0]
U 1A13, BE82,15 ;31991          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
```

```
                    ;31992
U 1A14, B66E,15 ;31993          MOV LS[NA.EXP.REC] TO WR[0]             ;EXP AND REC DATA ARE NOT
U 1A15, 3E80,15 ;31994          MOV WR[0] TO LS[CONTROL.STATUS]         ; APPLICABLE
                    ;31995
U 1A16, E58A,15 ;31996          CLR LS[ERROR.MASK]                      ;TO FORCE ERRORS
                    ;31997
U 1A17, 2F80,15 ;31998          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1A18, 2F82,95 ;31999          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1A19, 0869,3C ;32000          JSR [CHECK.RESULT]                      ; ERRORS
U 1A1A, 099E,D4 ;32001          JMP [LOOP.T39.1]                        ;LOOP HERE IF LOOP IS SET
                    ;32002
U 1A1B, 89A2,04 ;32003          JMP [TST.RESET.T39]                     ;OK...CONTINUE TESTING
                    ;32004
                    ;32005  ERROR.T39.1:
U 1A1C, 2F80,15 ;32006          CLR WR[0]                               ;FORCE AN ERROR
U 1A1D, 3640,95 ;32007          MOV LS[#1] TO WR[1]
U 1A1E, 0869,3C ;32008          JSR [CHECK.RESULT]                      ;GO REPORT THE ERROR
U 1A1F, 099E,D4 ;32009          JMP [LOOP.T39.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;32010
                    ;32011  TST.RESET.T39:
U 1A20, FF82,15 ;32012          INC LS[ERROR.NUMBER]                    ;SET UP FOR ERROR 2
                    ;32013
                    ;32014  LOOP.T39.2:
U 1A21, 97C4,15 ;32015          PORT.CONTROL [RESET.BR]                 ;CLEAR THE INTERRUPT REQUEST
                    ;32016
U 1A22, B788,15 ;32017          MOV LS[#3] TO WR[0]                     ;WAIT FOR THE INTERRUPT TO CLR
                    ;32018
                    ;32019  WAIT.CLR.BR.T39:
                    ;32020          DEC WR[0],                          ;WAIT SOME MORE
U 1A23, A100,35 ;32021           DT(LONG)&SET.ALU.CC
U 1A24, 89A2,31 ;32022          JMP.IF[NEQ] TO [WAIT.CLR.BR.T39]        ;WAIT SOME MORE
                    ;32023
U 1A25, 89A2,A7 ;32024          JMP.IF[NO.INTERRUPT] TO [RESET.OK.T39]  ;JMP IF INTERRUPT CLEARED (OK)
U 1A26, 2F80,15 ;32025          CLR WR[0]                               ;FORCE AN ERROR
U 1A27, 3640,95 ;32026          MOV LS[#1] TO WR[1]
U 1A28, 0869,3C ;32027          JSR [CHECK.RESULT]                      ;REPORT THE ERROR
U 1A29, 09A2,14 ;32028          JMP [LOOP.T39.2]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;32029
                    ;32030  RESET.OK.T39:
U 1A2A, 2F80,15 ;32031          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1A2B, 2F82,95 ;32032          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1A2C, 0869,3C ;32033          JSR [CHECK.RESULT]                      ; ERRORS
U 1A2D, 09A2,14 ;32034          JMP [LOOP.T39.2]                        ;LOOP HERE IF LOOP IS SET
                    ;32035
                    ;32036  RESET.OK.T39.1:
U 1A2E, 9090,15 ;32037          MISC [SET.PORT.I.0]                     ;SELECT FROM PORT TO BUS
U 1A2F, 9780,15 ;32038          PORT.READ PORT.ADRS[CSR]                ;READ CSR BACK
U 1A30, 3B32,15 ;32039          MOV PORT TO LS[PORT0]                   ;SAVE IT FOR LATER
U 1A31, B646,15 ;32040          MOV LS[#8] TO WR[0]                     ;SET UP ERROR NUMBER = 8
U 1A32, BE82,15 ;32041          MOV WR[0] TO LS[ERROR.NUMBER]
U 1A33, 37EC,15 ;32042          MOV LS[#FEFFFFFF] TO WR[0]              ;MASK FOR BIT 24
U 1A34, 3E8A,15 ;32043          MOV WR[0] TO LS[ERROR.MASK]
U 1A35, E580,15 ;32044          CLR LS[CONTROL.STATUS]
U 1A36, 3732,15 ;32045          MOV LS[PORT0] TO WR[0]                  ;RECEIVED IR BIT FROM CSR
U 1A37, 2F82,95 ;32046          CLR WR[1]                               ;EXP. STATE OF CSR IR BIT
```

```
U 1A38, 0869,3C ;32047          JSR [CHECK.RESULT]                      ;SEE IF IR BIT IS SET
U 1A39, 09A2,E4 ;32048          JMP [RESET.OK.T39.1]                    ;LOOP HERE IF LOOP IS SET
                ;32049
U 1A3A, B788,15 ;32050          MOV LS[#3] TO WR[0]
U 1A3B, BE82,15 ;32051          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 3
U 1A3C, B66E,15 ;32052          MOV LS[NA.EXP.REC] TO WR[0]             ;EXP AND REC DATA ARE NOT
U 1A3D, 3E80,15 ;32053          MOV WR[0] TO LS[CONTROL.STATUS]          ; APPLICABLE
                ;32054
U 1A3E, E58A,15 ;32055          CLR LS[ERROR.MASK]                      ;TO FORCE ERRORS
                ;32056
                ;32057  LOOP1.T39.3:
                ;32058
                ;32059  ;SET UP THE CSR TO BRANCH TO THE ROUTINE THAT WILL SET.INTERRUPT WITH
                ;32060  ; CSR CRDY CLR
                ;32061
U 1A3F, B70C,15 ;32062          MOV LS[SETCSR.F6] TO WR[0]              ;SET UP THE CSR
U 1A40, B720,95 ;32063          MOV LS[SETCSR.MAINT] TO WR[1]
U 1A41, AEC2,15 ;32064          BIS WR[1] TO WR[0]
U 1A42, B710,95 ;32065          MOV LS[SETCSR.IE] TO WR[1]              ;SET INTERRUPT ENABLE
U 1A43, AEC2,15 ;32066          BIS WR[1] TO WR[0]
U 1A44, 17A0,15 ;32067          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;32068                                                  ;MAINT=1,CRDY=0,F<2:0>=110
                ;32069  ;SET.INT WITH CSR<CRDY> =0
                ;32070  ;-------------------------------------------------------------------------------
                ;32071  ;-------------------------------------------------------------------------------
                ;32072  ;                               *******
                ;32073  ;                               * IDC *
                ;32074  ;                               *******
                ;32075  ;-------------------------------------------------------------------------------
                ;32076  ;018:
                ;32077  ;=000
                ;32078  ;DIAG.IDLE:
                ;32079  ;
                ;32080  ;       BEN0/F0,
                ;32081  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;32082  ;       BEN2/F2,
                ;32083  ;       NAD/DIAG.IDLE
                ;32084  ;-------------------------------------------------------------------------------
                ;32085  ;01E:
                ;32086  ;=110
                ;32087  ;
                ;32088  ;       BEN0/CRDY.L,
                ;32089  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;32090  ;       NAD/TEST.FUNC6          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;32091  ;-------------------------------------------------------------------------------
                ;32092  ;077:
                ;32093  ;=1*1
                ;32094  ;TEST.F6:
                ;32095  ;                               ;DO NOT INCR DAR BETWEEN HERE AND
                ;32096  ;                               ; DIAG.IDLE OR DIAG.WAIT
                ;32097  ;
                ;32098  ;       LOAD.LOOP.CNTR.[00],    ;LOAD LOOP CNTR WITH 00
                ;32099  ;
                ;32100  ;       UCMD/SET.DLT,           ;SET DLT FOR DLT TEST
                ;32101  ;
```

```
                    ;32102  ;       FUNC/SET.INT,                   ;SET INT FOR INTERRUPT TEST
                    ;32103  ;
                    ;32104  ;       NAD/XFER.REQ                    ;SEND XFER REQ TO FLAG THE CPU
                    ;32105  ;-------------------------------------------------------------------------
                    ;32106  ;1D8:
                    ;32107  ;XFER.REQ:
                    ;32108  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                    ;32109  ;       NAD/DIAG.WAIT
                    ;32110  ;-------------------------------------------------------------------------
                    ;32111  ;1D7:
                    ;32112  ;DIAG.WAIT:
                    ;32113  ;
                    ;32114  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                    ;32115  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                    ;32116  ;-------------------------------------------------------------------------
                    ;32117  ;159:
                    ;32118  ;=*0*
                    ;32119  ;DIAG.WAIT1:
                    ;32120  ;
                    ;32121  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;32122  ;                               ; COMMAND FROM THE CPU
                    ;32123  ;-------------------------------------------------------------------------
                    ;32124  ;158:
                    ;32125  ;=*1*
                    ;32126  ;DIAG.WAIT2:
                    ;32127  ;
                    ;32128  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;32129  ;                               ; WAIT SOME MORE
                    ;32130  ;-------------------------------------------------------------------------
                    ;32131  WAIT.IDC.T39.2:
U 1A45, DB00,1A     ;32132          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1A46, 09A4,84     ;32133          JMP [IDC.DONE.T39.2]                    ;XFER REQ SET
U 1A47, 89A4,54     ;32134          JMP [WAIT.IDC.T39.2]                    ;WAIT SOME MORE
                    ;32135
                    ;32136  IDC.DONE.T39.2:
U 1A48, B700,15     ;32137          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1A49, B710,95     ;32138          MOV LS[SETCSR.IE] TO WR[1]              ;ENABLE INTERRUPTS
U 1A4A, AEC2,15     ;32139          BIS WR[1] TO WR[0]
U 1A4B, 17A0,15     ;32140          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1A4C, 90FA,15     ;32141          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
U 1A4D, DB00,15     ;32142          NOP                                     ;ALLOW XFER REQ TO CLEAR
U 1A4E, DB00,15     ;32143          NOP
U 1A4F, DB00,15     ;32144          NOP
U 1A50, DB00,15     ;32145          NOP
U 1A51, 09A5,67     ;32146          JMP.IF[NO.INTERRUPT] TO [CRDY.OK.T39]   ;JMP IF OK
U 1A52, 2F80,15     ;32147          CLR WR[0]                               ;FORCE AN ERROR
U 1A53, 3640,95     ;32148          MOV LS[#1] TO WR[1]
U 1A54, 0869,3C     ;32149          JSR [CHECK.RESULT]                      ;REPORT THE ERROR
U 1A55, 89A9,D4     ;32150          JMP [LOOP.T39.3]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;32151
                    ;32152  CRDY.OK.T39:
U 1A56, 2F80,15     ;32153          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1A57, 2F82,95     ;32154          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1A58, 0869,3C     ;32155          JSR [CHECK.RESULT]                      ; ERRORS
U 1A59, 89A9,D4     ;32156          JMP [LOOP.T39.3]                        ;LOOP HERE IF LOOP IS SET
```

```
                ;32157
U 1A5A, FF82,15 ;32158          INC LS[ERROR.NUMBER]                    ;ERROR 4
                ;32159
                ;32160  LOOP.T39.4:
                ;32161
U 1A5B, 97C4,15 ;32162          PORT.CONTROL [RESET.BR]                 ;CLEAR ANY INTERRUPT REQUEST
                ;32163
U 1A5C, B788,15 ;32164          MOV LS[#3] TO WR[0]                     ;WAIT FOR THE INTERRUPT TO CLR
                ;32165
                ;32166  WAIT.BR.T39.2:
                ;32167          DEC WR[0],                              ;WAIT SOME MORE
U 1A5D, A100,35 ;32168           DT(LONG)&SET.ALU.CC
U 1A5E, 89A5,D1 ;32169          JMP.IF[NEQ] TO [WAIT.BR.T39.2]          ;WAIT SOME SOME
                ;32170
                ;32171  ;SET UP THE CSR TO BRANCH TO THE ROUTINE THAT WILL SET.INT WITH
                ;32172  ; IDC CSR INTERRUPT ENABLE NOT ASSERTED
                ;32173
U 1A5F, 370E,15 ;32174          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 1A60, B720,95 ;32175          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE CORRECT IDC ROUTINE
U 1A61, AEC2,15 ;32176          BIS WR[1] TO WR[0]
U 1A62, 3712,95 ;32177          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 1A63, AEC2,15 ;32178          BIS WR[1] TO WR[0]
U 1A64, 17A0,15 ;32179          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;32180                                                  ;MAINT=1,CRDY=1,F<2:0>=111
                ;32181  ;SET.INT
                ;32182  ;-------------------------------------------------------------------------
                ;32183  ;-------------------------------------------------------------------------
                ;32184  ;                               *******
                ;32185  ;                               * IDC *
                ;32186  ;                               *******
                ;32187  ;-------------------------------------------------------------------------
                ;32188  ;018:
                ;32189  ;=000
                ;32190  ;DIAG.IDLE:
                ;32191  ;
                ;32192  ;       BEN0/F0,
                ;32193  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;32194  ;       BEN2/F2,
                ;32195  ;       NAD/DIAG.IDLE
                ;32196  ;-------------------------------------------------------------------------
                ;32197  ;01F:
                ;32198  ;=111
                ;32199  ;
                ;32200  ;       BEN0/CRDY.L,
                ;32201  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;32202  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;32203  ;-------------------------------------------------------------------------
                ;32204  ;07C:
                ;32205  ;=1*0
                ;32206  ;SET.INT:
                ;32207  ;
                ;32208  ;       FUNC/SET.INT,                   ;SET INT FOR INT TEST...CRDY MUST
                ;32209  ;                                       ; BE SET IN CSR
                ;32210  ;       NAD/XFER.REQ
                ;32211  ;-------------------------------------------------------------------------
```

```
                ;32212  ;1D8:
                ;32213  ;XFER.REQ:
                ;32214  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;32215  ;       NAD/DIAG.WAIT
                ;32216  ;-------------------------------------------------------------------------
                ;32217  ;1D7:
                ;32218  ;DIAG.WAIT:
                ;32219  ;
                ;32220  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;32221  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;32222  ;-------------------------------------------------------------------------
                ;32223  ;159:
                ;32224  ;=*0*
                ;32225  ;DIAG.WAIT1:
                ;32226  ;
                ;32227  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;32228  ;                               ; COMMAND FROM THE CPU
                ;32229  ;-------------------------------------------------------------------------
                ;32230  ;15B:
                ;32231  ;=*1*
                ;32232  ;DIAG.WAIT2:
                ;32233  ;
                ;32234  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;32235  ;                               ; WAIT SOME MORE
                ;32236  ;-------------------------------------------------------------------------
                ;32237  WAIT.IDC.T39.3:
U 1A65, DB00,1A ;32238          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1A66, 89A6,84 ;32239          JMP [IDC.DONE.T39.3]                    ;XFER REQ SET
U 1A67, 09A6,54 ;32240          JMP [WAIT.IDC.T39.3]                    ;WAIT SOME MORE
                ;32241
                ;32242  IDC.DONE.T39.3:
U 1A68, B700,15 ;32243          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1A69, 3712,95 ;32244          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO ALLOW INTERRUPTS
U 1A6A, AEC2,15 ;32245          BIS WR[1] TO WR[0]
U 1A6B, 17A0,15 ;32246          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1A6C, 90FA,15 ;32247          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
U 1A6D, DB00,15 ;32248          NOP                                     ;ALLOW XFER REQ TO CLEAR
U 1A6E, DB00,15 ;32249          NOP
U 1A6F, DB00,15 ;32250          NOP
U 1A70, 89A7,57 ;32251          JMP.IF[NO.INTERRUPT] TO [IE.OK.T39]     ;JMP IF INT REQ DID NOT ASSERT
U 1A71, 2F80,15 ;32252          CLR WR[0]                               ;FORCE AN ERROR
U 1A72, 3640,95 ;32253          MOV LS[#1] TO WR[1]
U 1A73, 0869,3C ;32254          JSR [CHECK.RESULT]                      ;REPORT THE ERROR
U 1A74, 89A5,B4 ;32255          JMP [LOOP.T39.4]                        ;LOOP HERE IF ERR & LOE IS SET
                ;32256
                ;32257  IE.OK.T39:
U 1A75, 2F80,15 ;32258          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1A76, 2F82,95 ;32259          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1A77, 0869,3C ;32260          JSR [CHECK.RESULT]                      ; ERRORS
U 1A78, 89A5,B4 ;32261          JMP [LOOP.T39.4]                        ;LOOP HERE IF LOOP IS SET
                ;32262
U 1A79, FF82,15 ;32263          INC LS[ERROR.NUMBER]                    ;ERROR 5
                ;32264
                ;32265  ;SET INTERRUPT REQUEST
                ;32266
```

```
U 1A7A, 370E,15 ;32267          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
U 1A7B, B720,95 ;32268          MOV LS[SETCSR.MAINT] TO WR[1]           ; THE CORRECT IDC ROUTINE
U 1A7C, AEC2,15 ;32269          BIS WR[1] TO WR[0]
U 1A7D, 3712,95 ;32270          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 1A7E, AEC2,15 ;32271          BIS WR[1] TO WR[0]
U 1A7F, B710,95 ;32272          MOV LS[SETCSR.IE] TO WR[1]              ;SET INTERRUPT ENABLE
U 1A80, AEC2,15 ;32273          BIS WR[1] TO WR[0]
U 1A81, 17A0,15 ;32274          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;32275                                                  ;MAINT=1,CRDY=1,F<2:0>=111
                ;32276  ;SET.INT
                ;32277  ;-------------------------------------------------------------------------------
                ;32278  ;-------------------------------------------------------------------------------
                ;32279  ;                               *******
                ;32280  ;                               * IDC *
                ;32281  ;                               *******
                ;32282  ;-------------------------------------------------------------------------------
                ;32283  ;018:
                ;32284  ;=000
                ;32285  ;DIAG.IDLE:
                ;32286  ;
                ;32287  ;       BEN0/F0,
                ;32288  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;32289  ;       BEN2/F2,
                ;32290  ;       NAD/DIAG.IDLE
                ;32291  ;-------------------------------------------------------------------------------
                ;32292  ;01F:
                ;32293  ;=111
                ;32294  ;
                ;32295  ;       BEN0/CRDY.L,
                ;32296  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;32297  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;32298  ;-------------------------------------------------------------------------------
                ;32299  ;07C:
                ;32300  ;=1*0
                ;32301  ;SET.INT:
                ;32302  ;
                ;32303  ;       FUNC/SET.INT,                   ;SET INT FOR INT TEST...CRDY MUST
                ;32304  ;                                       ; BE SET IN CSR
                ;32305  ;       NAD/XFER.REQ
                ;32306  ;-------------------------------------------------------------------------------
                ;32307  ;1D8:
                ;32308  ;XFER.REQ:
                ;32309  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;32310  ;       NAD/DIAG.WAIT
                ;32311  ;-------------------------------------------------------------------------------
                ;32312  ;1D7:
                ;32313  ;DIAG.WAIT:
                ;32314  ;
                ;32315  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;32316  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;32317  ;-------------------------------------------------------------------------------
                ;32318  ;159:
                ;32319  ;=*0*
                ;32320  ;DIAG.WAIT1:
                ;32321  ;
```

```
                    ;32322  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                    ;32323  ;                               ; COMMAND FROM THE CPU
                    ;32324  ;-------------------------------------------------------------------------
                    ;32325  ;15B:
                    ;32326  ;=*1*
                    ;32327  ;DIAG.WAIT2:
                    ;32328  ;
                    ;32329  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                    ;32330  ;                               ; WAIT SOME MORE
                    ;32331  ;-------------------------------------------------------------------------
                    ;32332  WAIT.IDC.T39.4:
U 1A82, DB00,1A     ;32333          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1A83, 89A8,54     ;32334          JMP [IDC.DONE.T39.4]                    ;XFER REQ SET
U 1A84, 09A8,24     ;32335          JMP [WAIT.IDC.T39.4]                    ;WAIT SOME MORE
                    ;32336
                    ;32337  IDC.DONE.T39.4:
U 1A85, B700,15     ;32338          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1A86, 3712,95     ;32339          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 1A87, AEC2,15     ;32340          BIS WR[1] TO WR[0]
U 1A88, B710,95     ;32341          MOV LS[SETCSR.IE] TO WR[1]              ;SET INT ENABLE
U 1A89, AEC2,15     ;32342          BIS WR[1] TO WR[0]
U 1A8A, 17A0,15     ;32343          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1A8B, 90FA,15     ;32344          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                    ;32345
                    ;32346  LOOP.T39.5:
U 1A8C, 17CC,15     ;32347          PORT.CONTROL [CLEAR.IDC]                ;INIT THE IDC
U 1A8D, 17CC,15     ;32348          PORT.CONTROL [CLEAR.IDC]
U 1A8E, 17CC,15     ;32349          PORT.CONTROL [CLEAR.IDC]
U 1A8F, DB00,15     ;32350          NOP                                     ;ALLOW TIME FOR THE INTERRUPT
U 1A90, DB00,15     ;32351          NOP                                     ; TO CLEAR
U 1A91, DB00,15     ;32352          NOP
U 1A92, DB00,15     ;32353          NOP
U 1A93, 89A9,87     ;32354          JMP.IF[NO.INTERRUPT] TO [GOOD.LOOP.T39] ;JMP IF INTERRUPT REQ CLEARED
U 1A94, 2F80,15     ;32355          CLR WR[0]                               ;FORCE AN ERROR
U 1A95, 3640,95     ;32356          MOV LS[#1] TO WR[1]
U 1A96, 0869,3C     ;32357          JSR [CHECK.RESULT]                      ;REPORT THE ERROR
U 1A97, 89A8,C4     ;32358          JMP [LOOP.T39.5]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;32359
                    ;32360  GOOD.LOOP.T39:
U 1A98, 2F80,15     ;32361          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1A99, 2F82,95     ;32362          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1A9A, 0869,3C     ;32363          JSR [CHECK.RESULT]                      ; ERRORS
U 1A9B, 89A8,C4     ;32364          JMP [LOOP.T39.5]                        ;LOOP HERE IF LOOP IS SET
                    ;32365
U 1A9C, 89AA,24     ;32366          JMP [CLEANUP.T39]
                    ;32367
                    ;32368
                    ;32369
                    ;32370  LOOP.T39.3:
U 1A9D, 97C4,15     ;32371          PORT.CONTROL [RESET.BR]                 ;CLEAR THE INTERRUPT REQUEST
                    ;32372
U 1A9E, B788,15     ;32373          MOV LS[#3] TO WR[0]                     ;WAIT FOR THE INTERRUPT TO CLR
                    ;32374
                    ;32375  WAIT.BR.T39.1:
                    ;32376          DEC WR[0],                              ;WAIT SOME MORE
```

```
U 1A9F, A100,35 ;32377          DT(LONG)&SET.ALU.CC
U 1AA0, 09A9,F1 ;32378          JMP.IF[NEQ] TO [WAIT.BR.T39.1]          ;WAIT SOME SOME
U 1AA1, 09A3,F4 ;32379          JMP [LOOP1.T39.3]                       ;ERROR LOOP
                ;32380
                ;32381
                ;32382  CLEANUP.T39:
                ;32383
U 1AA2, 97C4,15 ;32384          PORT.CONTROL [RESET.BR]                 ;CLEAR ALL INTERRUPT REQUESTS
                ;32385
U 1AA3, B788,15 ;32386          MOV LS[#3] TO WR[0]                     ;WAIT FOR THE INTERRUPT TO CLR
                ;32387
                ;32388  WAIT.BR.T39.3:
                ;32389          DEC WR[0],                              ;WAIT SOME MORE
U 1AA4, A100,35 ;32390           DT(LONG)&SET.ALU.CC
U 1AA5, 89AA,41 ;32391          JMP.IF[NEQ] TO [WAIT.BR.T39.3]          ;WAIT SOME SOME
                ;32392
U 1AA6, DB00,15 ;32393          NOP
U 1AA7, DB00,15 ;32394          NOP
U 1AA8, DB00,15 ;32395          NOP
U 1AA9, 8875,3C ;32396          JSR [CLEANUP]                           ;CLEANUP CONDITIONS SET BY
                ;32397                                                  ; THIS TEST
                ;32398  END.T39:                                        ;END TEST
                ;32399
                ;32400
                ;32401
                ;32402
```

```
;32403  .PAGE  "Test 3A  INTERRUPT REQUEST TEST 2 (M8388 IDC MODULE)"
;32404  ;++
;32405  ;
;32406  ; Test Description:
;32407  ;
;32408  ;       This test is designed to insure that any of the Attention bits setting
;32409  ;       will cause an interrupt if interrupts are enabled and CRDY is set.
;32410  ;
;32411  ; Assumptions:
;32412  ;
;32413  ;       It is assumed that all previous tests have run successfully.
;32414  ;
;32415  ; Test Steps:
;32416  ;
;32417  ;       1. Set up error mask, error number and module number in LS
;32418  ;          (for error printouts) and clear the previous error number in LS.
;32419  ;       2. Force IDC microcode to DIAG.IDLE.
;32420  ;       3. Set bit <INTERUPT.EN> of the LS[CONTROL.STATUS] and allow time
;32421  ;          any pending interrupts to clear.
;32422  ;       4. Lower the IPL to 0. ( CLR LS[PSL.HW] )
;32423  ;       5. Set IDC CSR <INT.IE>, interrupt enable and set CSR CRDY.
;32424  ;       6. Select Drive 0.
;32425  ;       7. Clear all of the attention bits.
;32426  ;       8. Set up the CSR to branch to the correct IDC microcode routine.
;32427  ;
;32428  ;
;32429  ;                                       *******
;32430  ;                                       * IDC *
;32431  ;                                       *******
;32432  ;
;32433  ;               IDC1. Execute an instruction with FUNC/SET.ATTN.
;32434  ;               IDC2. Issue XFER.REQ to flag the CPU.
;32435  ;
;32436  ;       8. Wait for XFER.REQ from the IDC.
;32437  ;       9. Clear CSR F<2:0> and send XFER GRANT to clear the XFER.REQ.
;32438  ;      10. If Interrupt Request is not set then issue ERROR.
;32439  ;      11. Issue port instruction to clear the BR 5.
;32440  ;      12. Select the next drive number and go to Step 7 until all ATTN bits
;32441  ;          have been tested.
;32442  ;      13. Increment the error number.
;32443  ;      14. Set all the Attention bits to set interrupt request.
;32444  ;      15. INIT the IDC.
;32445  ;      16. Check that the interrupt request cleared.
;32446  ;      17. Clear IDC.
;32447  ;      18. End test.
;32448  ;
;32449  ; Errors:
;32450  ;
;32451  ;       Printout:
;32452  ;                EXPECTED          RECEIVED          OTHER DATA
;32453  ;                 N/A               N/A          ATTENTION BIT NUMBER
;32454  ;
;32455  ;
;32456  ;       ERROR 1 - Setting the Attention bit did not set interrupt request.
;32457  ;
```

```
                ;32458  ;       ERROR 2 - IDC INIT did not clear the interrupt request.
                ;32459  ;
                ;32460  ; Debug:
                ;32461  ;
                ;32462  ; ERROR 1-
                ;32463  ;       Any pending interrupts are cleared and the IPL is lowered to 0.
                ;32464  ;       One Attention Bit is set with CSR <CRDY>=1 and interrupts are enbled by
                ;32465  ;       setting CSR <IE> bit 6. This will assert SET INT REQ H at the ATTN REG
                ;32466  ;       PAL. This is an input to the FIFOA ADRS CNTR LO PAL. The inputs to this
                ;32467  ;       PAL should now be:
                ;32468  ;               SET INT REQ H = H
                ;32469  ;               RESET BR L = H
                ;32470  ;               IE H = H
                ;32471  ;               CRDY H = H
                ;32472  ;       This combination of inputs will assert INT REQ DIN H. This is an input
                ;32473  ;       to the INIT FF and at the next P2 CLOCK L, INT REQ H asserts. INT REQ H
                ;32474  ;       is inverted and leaved the board as UBUS BR5 L.
                ;32475  ;       This process is repeated with setting each of the ATTENTON BITS.
                ;32476  ;
                ;32477  ; ERROR 2-
                ;32478  ;       The CPU issues PORT.CONTROL [CLEAR.IDC] instructions which are decoded
                ;32479  ;       by the PORT RD/WR DECODE PAL. This will assert CLEAR IDC L. At the
                ;32480  ;       next P2 CLOCK L, the INIT FF will assert INIT SYNC 1 H. At the next
                ;32481  ;       clock INIT H is asserted. This is an input to the ATTN REG PAL and when
                ;32482  ;       INIT H asserts, SET INT REQ H will clear.
                ;32483  ;
                ;32484  ;--
                ;32485  ;*******************************************************************************
                ;32486  T.3A:
U 1AAA, B65E,15 ;32487          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;32488                                                  ; CONTROL AND STATUS WORD
U 1AAB, 3E80,15 ;32489          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;32490                                                  ; STATUS WORD - BIT 15
                ;32491                                                  ; INDICATES START OF TEST TO
                ;32492                                                  ; CONSOLE
U 1AAC, 10E0,15 ;32493          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;32494  WAIT.T3A.0:
U 1AAD, 89AA,D4 ;32495          JMP [WAIT.T3A.0]                        ;LOOP HERE WAITING FOR
                ;32496                                                  ; CONSOLE TO RESPOND
                ;32497
U 1AAE, 65A0,15 ;32498          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;32499                                                  ; IN LS
                ;32500
U 1AAF, B64A,15 ;32501          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1AB0, 3E8C,15 ;32502          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;32503
                ;32504
U 1AB1, B640,15 ;32505          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1AB2, BE82,15 ;32506          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;32507
U 1AB3, E58A,15 ;32508          CLR LS[ERROR.MASK]                      ;TO FORCE ERRORS
                ;32509
U 1AB4, 8872,EC ;32510          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT
                ;32511                                                  ; TO DIAG.IDLE
                ;32512
```

```
U 1AB5, 3660,15 ;32513          MOV LS[INTERUPT.EN] TO WR[0]              ;CLEAR ANY PENDING INTERRUPTS
U 1AB6, 3E80,15 ;32514          MOV WR[0] TO LS[CONTROL.STATUS]
                ;32515
U 1AB7, 10E0,15 ;32516          MISC [SET.CP.ATTN]                        ;ISSUE CPU ATTN TO CONSOLE
                ;32517  WAIT.T3A.1:
U 1AB8, 09AB,84 ;32518          JMP [WAIT.T3A.1]                          ;LOOP HERE WAITING FOR
                ;32519                                                    ; CONSOLE TO RESPOND
                ;32520
U 1AB9, B670,15 ;32521          MOV LS[OTHER.DATA] TO WR[0]               ;SET UP TO PRINT OTHER DATA
U 1ABA, 3E80,15 ;32522          MOV WR[0] TO LS[CONTROL.STATUS]
                ;32523
U 1ABB, B66E,15 ;32524          MOV LS[NA.EXP.REC] TO WR[0]               ;EXP AND REC DATA ARE NOT
U 1ABC, 6D80,15 ;32525          BIS WR[0] TO LS[CONTROL.STATUS]           ; APPLICABLE
                ;32526
                ;32527
U 1ABD, 2F80,15 ;32528          CLR WR[0]
U 1ABE, BFFE,15 ;32529          MOV WR[0] TO LS[PSL.HW]                   ;LOWER THE IPL TO 0
                ;32530
                ;32531  ;WR[3] WILL SAVE THE DRIVE NUMBER FOR PRINTOUTS
                ;32532  ;WR[2] WILL HAVE THE DRIVE SELECT IN BITS<9:8>
                ;32533
U 1ABF, 2F87,95 ;32534          CLR WR[3]                                 ;SAV DRV NUM FOR PRINTOUTS
U 1AC0, 3715,15 ;32535          MOV LS[SETCSR.DS0] TO WR[2]               ;SELECT DRIVE 0
                ;32536
                ;32537  ;SET UP THE CSR TO SET ATTN WITH INTERRUPTS ENABLED
                ;32538  LOOP.T3A.1:
                ;32539  TST.NXT.T3A:
                ;32540
U 1AC1, 370E,15 ;32541          MOV LS[SETCSR.F7] TO WR[0]
U 1AC2, B7D6,95 ;32542          MOV LS[#000F0000] TO WR[1]                ;CLEAR ALL ATTN BITS
U 1AC3, AEC2,15 ;32543          BIS WR[1] TO WR[0]
U 1AC4, 17A0,15 ;32544          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
                ;32545                                                    ;MAINT=0,CRDY=0,F<2:0>=111
                ;32546  ;CONTINUE TO BRANCH
U 1AC5, 379E,15 ;32547          MOV LS[SETCSR.R80] TO WR[0]               ;SET UP THE CSR TO CONTINUE TO
U 1AC6, B708,95 ;32548          MOV LS[SETCSR.F4] TO WR[1]                ; BRANCH TO THE CORRECT ROUTINE
U 1AC7, AEC2,15 ;32549          BIS WR[1] TO WR[0]
U 1AC8, AEC4,15 ;32550          BIS WR[2] TO WR[0]                        ;INCLUDE THE DRIVE SELECT
U 1AC9, 3712,95 ;32551          MOV LS[SETCSR.CRDY] TO WR[1]              ;SET CRDY TO ALLOW INTERRUPTS
U 1ACA, AEC2,15 ;32552          BIS WR[1] TO WR[0]
U 1ACB, B710,95 ;32553          MOV LS[SETCSR.IE] TO WR[1]                ;ENABLE INTERRUPTS
U 1ACC, AEC2,15 ;32554          BIS WR[1] TO WR[0]
U 1ACD, 17A0,15 ;32555          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
                ;32556                                                    ;F<2:0>=100
                ;32557  ;USET ATTN
                ;32558  ;---------------------------------------------------------------------------
                ;32559  ;---------------------------------------------------------------------------
                ;32560  ;                                  *******
                ;32561  ;                                  * IDC *
                ;32562  ;                                  *******
                ;32563  ;---------------------------------------------------------------------------
                ;32564  ;018:
                ;32565  ;=000
                ;32566  ;DIAG.IDLE:
                ;32567  ;
```

```
;32568  ;       BEN0/F0,
;32569  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;32570  ;       BEN2/F2,
;32571  ;       NAD/DIAG.IDLE
;32572  ;-------------------------------------------------------------------------
;32573  ;01F:
;32574  ;=111
;32575  ;
;32576  ;       BEN0/CRDY.L,
;32577  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
;32578  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
;32579  ;-------------------------------------------------------------------------
;32580  ;079:
;32581  ;=0*1
;32582  ;
;32583  ;       NAD/GROUP1
;32584  ;-------------------------------------------------------------------------
;32585  ;182:
;32586  ;=0**
;32587  ;GROUP1:
;32588  ;
;32589  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
;32590  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
;32591  ;                                       ; FUNCTION BITS
;32592  ;-------------------------------------------------------------------------
;32593  ;186:
;32594  ;=1**
;32595  ;
;32596  ;       BEN0/F0,
;32597  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
;32598  ;       BEN2/F2,
;32599  ;       NAD/GROUP1.F0
;32600  ;-------------------------------------------------------------------------
;32601  ;02C:
;32602  ;=100
;32603  ;USET.ATTN:
;32604  ;
;32605  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
;32606  ;                               ;INTERRUPTS
;32607  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
;32608  ;-------------------------------------------------------------------------
;32609  ;1D8:
;32610  ;XFER.REQ:
;32611  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
;32612  ;       NAD/DIAG.WAIT
;32613  ;-------------------------------------------------------------------------
;32614  ;1D7:
;32615  ;DIAG.WAIT:
;32616  ;
;32617  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
;32618  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
;32619  ;-------------------------------------------------------------------------
;32620  ;159:
;32621  ;=*0*
;32622  ;DIAG.WAIT1:
```

```
                ;32623  ;
                ;32624  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;32625  ;                               ; COMMAND FROM THE CPU
                ;32626  ;-------------------------------------------------------------------
                ;32627  ;15B:
                ;32628  ;=*1*
                ;32629  ;DIAG.WAIT2:
                ;32630  ;
                ;32631  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;32632  ;                               ; WAIT SOME MORE
                ;32633  ;-------------------------------------------------------------------
                ;32634  WAIT.IDC.T3A.1:
U 1ACE, DB00,1A ;32635          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1ACF, 09AD,14 ;32636          JMP [IDC.DONE.T3A.1]                    ;XFER REQ SET
U 1AD0, 89AC,E4 ;32637          JMP [WAIT.IDC.T3A.1]                    ;WAIT SOME MORE
                ;32638
                ;32639  IDC.DONE.T3A.1:
U 1AD1, B700,15 ;32640          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1AD2, 3712,95 ;32641          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY TO ALLOW INTERRUPTS
U 1AD3, AEC2,15 ;32642          BIS WR[1] TO WR[0]
U 1AD4, B710,95 ;32643          MOV LS[SETCSR.IE] TO WR[1]              ;SET INT ENABLE
U 1AD5, AEC2,15 ;32644          BIS WR[1] TO WR[0]
U 1AD6, 17A0,15 ;32645          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1AD7, 90FA,15 ;32646          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;32647
U 1AD8, 89AD,F7 ;32648          JMP.IF[NO.INTERRUPT] TO [ERROR.T3A.1]   ;JMP IF INT NOT ASSERTED(ERROR)
                ;32649
U 1AD9, 2F80,15 ;32650          CLR WR[0]                               ;CALL CHECK RESULT WITH GOOD
U 1ADA, 2F82,95 ;32651          CLR WR[1]                               ; DATA TO LOCK IN INTERMITTANT
U 1ADB, BE89,95 ;32652          MOV WR[3] TO LS[ADDRESS.DATA]           ; ERRORS
U 1ADC, 0869,3C ;32653          JSR [CHECK.RESULT]                      ;
U 1ADD, 89AC,14 ;32654          JMP [LOOP.T3A.1]                        ;LOOP HERE IF LOOP IS SET
                ;32655
U 1ADE, 09AE,44 ;32656          JMP [INT.OK.T3A]                        ;JMP IF OK
                ;32657
                ;32658  ERROR.T3A.1:
U 1ADF, 2F80,15 ;32659          CLR WR[0]                               ;FORCE AN ERROR
U 1AE0, 3640,95 ;32660          MOV LS[#1] TO WR[1]
U 1AE1, BE89,95 ;32661          MOV WR[3] TO LS[ADDRESS.DATA]           ;PRINT THE ATTN BIT NUMBER
U 1AE2, 0869,3C ;32662          JSR [CHECK.RESULT]                      ;REPORT THE ERROR
U 1AE3, 89AC,14 ;32663          JMP [LOOP.T3A.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;32664
                ;32665  INT.OK.T3A:
U 1AE4, 97C4,15 ;32666          PORT.CONTROL [RESET.BR]                 ;CLEAR THE INTERRUPT
U 1AE5, B788,15 ;32667          MOV LS[#3] TO WR[0]                     ;WAIT FOR INT TO CLR
                ;32668  WAIT.BR.T3A:
                ;32669          DEC WR[0],                              ;WAIT SOME MORE
U 1AE6, A100,35 ;32670           DT(LONG)&SET.ALU.CC
U 1AE7, 89AE,61 ;32671          JMP.IF[NEQ] TO [WAIT.BR.T3A]            ;WAIT SOME MORE
                ;32672
U 1AE8, 2047,95 ;32673          INC WR[3]                               ;INCREMENT THE ATTEN BIT NUMBER
                ;32674          CMP LS[#4] WITH WR[3],                  ;DONE?
U 1AE9, CE45,B5 ;32675           DT(LONG)&SET.ALU.CC
U 1AEA, 89AE,D9 ;32676          JMP.IF[EQL] TO [TST.INIT.T3A]           ;JMP IF DONE
                ;32677
```

```
                ;32678
U 1AEB, 4051,15 ;32679          ADD LS[#100] TO WR[2]                   ;SELECT THE NEXT DRIVE
U 1AEC, 89AC,14 ;32680          JMP [TST.NXT.T3A]                       ;GO TEST THE NEXT BIT
                ;32681
                ;32682  TST.INIT.T3A:
                ;32683
U 1AED, 3642,15 ;32684          MOV LS[#2] TO WR[0]
U 1AEE, BE82,15 ;32685          MOV WR[0] TO LS[ERROR.NUMBER]           ;ERROR 2
                ;32686
U 1AEF, B715,95 ;32687          MOV LS[SETCSR.DS0] TO WR[3]
                ;32688
                ;32689  SET.ATTN.T3A:
                ;32690  ;SET ALL THE ATTENTION BITS
                ;32691
U 1AF0, 370E,15 ;32692          MOV LS[SETCSR.F7] TO WR[0]
U 1AF1, 17A0,15 ;32693          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;32694                                                  ;MAINT=0,CRDY=0,F<2:0>=111
                ;32695  ;CONTINUE TO BRANCH
U 1AF2, 379E,15 ;32696          MOV LS[SETCSR.R80] TO WR[0]             ;SET UP THE CSR TO CONTINUE TO
U 1AF3, B708,95 ;32697          MOV LS[SETCSR.F4] TO WR[1]              ; BRANCH TO THE CORRECT ROUTINE
U 1AF4, AEC2,15 ;32698          BIS WR[1] TO WR[0]
U 1AF5, 3712,95 ;32699          MOV LS[SETCSR.CRDY] TO WR[1]            ;SET CRDY
U 1AF6, AEC2,15 ;32700          BIS WR[1] TO WR[0]
U 1AF7, B710,95 ;32701          MOV LS[SETCSR.IE] TO WR[1]              ;ENABLE INTERRUPTS
U 1AF8, AEC2,15 ;32702          BIS WR[1] TO WR[0]
U 1AF9, 2EC6,15 ;32703          BIS WR[3] TO WR[0]                      ;INCLUDE THE DRIVE SELECT
U 1AFA, 17A0,15 ;32704          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;32705                                                  ;F<2:0>=100
                ;32706  ;USET ATTN
                ;32707  ;-------------------------------------------------------------------------------
                ;32708  ;-------------------------------------------------------------------------------
                ;32709  ;                               *******
                ;32710  ;                               * IDC *
                ;32711  ;                               *******
                ;32712  ;-------------------------------------------------------------------------------
                ;32713  ;018:
                ;32714  ;=000
                ;32715  ;DIAG.IDLE:
                ;32716  ;
                ;32717  ;       BEN0/F0,
                ;32718  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;32719  ;       BEN2/F2,
                ;32720  ;       NAD/DIAG.IDLE
                ;32721  ;-------------------------------------------------------------------------------
                ;32722  ;01F:
                ;32723  ;=111
                ;32724  ;
                ;32725  ;       BEN0/CRDY.L,
                ;32726  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;32727  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;32728  ;-------------------------------------------------------------------------------
                ;32729  ;079:
                ;32730  ;=0*1
                ;32731  ;
                ;32732  ;       NAD/GROUP1
```

```
                ;32733  ;-------------------------------------------------------------------------
                ;32734  ;182:
                ;32735  ;=0**
                ;32736  ;GROUP1:
                ;32737  ;
                ;32738  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;32739  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;32740  ;                                       ; FUNCTION BITS
                ;32741  ;-------------------------------------------------------------------------
                ;32742  ;186:
                ;32743  ;=1**
                ;32744  ;
                ;32745  ;       BEN0/F0,
                ;32746  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;32747  ;       BEN2/F2,
                ;32748  ;       NAD/GROUP1.F0
                ;32749  ;-------------------------------------------------------------------------
                ;32750  ;02C:
                ;32751  ;=100
                ;32752  ;USET.ATTN:
                ;32753  ;
                ;32754  ;       FUNC/SET.ATTN,          ;SET ATTENTION BE SURE CRDY SET TO ALLOW
                ;32755  ;                               ;INTERRUPTS
                ;32756  ;       NAD/XFER.REQ            ;SEND XFER REQ TO FLAG THE CPU
                ;32757  ;-------------------------------------------------------------------------
                ;32758  ;1D8:
                ;32759  ;XFER.REQ:
                ;32760  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;32761  ;       NAD/DIAG.WAIT
                ;32762  ;-------------------------------------------------------------------------
                ;32763  ;1D7:
                ;32764  ;DIAG.WAIT:
                ;32765  ;
                ;32766  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;32767  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;32768  ;-------------------------------------------------------------------------
                ;32769  ;159:
                ;32770  ;=*0*
                ;32771  ;DIAG.WAIT1:
                ;32772  ;
                ;32773  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;32774  ;                               ; COMMAND FROM THE CPU
                ;32775  ;-------------------------------------------------------------------------
                ;32776  ;15B:
                ;32777  ;=*1*
                ;32778  ;DIAG.WAIT2:
                ;32779  ;
                ;32780  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;32781  ;                               ; WAIT SOME MORE
                ;32782  ;-------------------------------------------------------------------------
                ;32783  WAIT.IDC.T3A.2:
U 1AFB, DB00,1A ;32784          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1AFC, 89AF,E4 ;32785          JMP [IDC.DONE.T3A.2]                    ;XFER REQ SET
U 1AFD, 89AF,B4 ;32786          JMP [WAIT.IDC.T3A.2]                    ;WAIT SOME MORE
                ;32787
```

```
                    ;32788  IDC.DONE.T3A.2:
U 1AFE, B700,15     ;32789          MOV LS[SETCSR.F0] TO WR[0]                ;CLEAR CSR F<2:0>
U 1AFF, 3712,95     ;32790          MOV LS[SETCSR.CRDY] TO WR[1]              ;SET CRDY
U 1B00, AEC2,15     ;32791          BIS WR[1] TO WR[0]
U 1B01, B710,95     ;32792          MOV LS[SETCSR.IE] TO WR[1]                ;ENABLE INTERRUPTS
U 1B02, AEC2,15     ;32793          BIS WR[1] TO WR[0]
U 1B03, 17A0,15     ;32794          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]      ;WRITE THE CSR
U 1B04, 90FA,15     ;32795          MISC2 [TRANSFER.GRANT]                    ;SEND GRANT TO CLR THE XFER REQ
                    ;32796
U 1B05, C051,95     ;32797          ADD LS[#100] TO WR[3]                     ;SELECT THE NEXT DRIVE
                    ;32798          CMP LS[#400] WITH WR[3],                  ;ALL BITS BEEN SET?
U 1B06, 4E55,B5     ;32799           DT(LONG)&SET.ALU.CC
U 1B07, 09AF,01     ;32800          JMP.IF[NEQ] TO [SET.ATTN.T3A]             ;JMP IF NO
                    ;32801
                    ;32802  LOOP.T3A.2:
U 1B08, 17CC,15     ;32803          PORT.CONTROL [CLEAR.IDC]                  ;INIT THE IDC
U 1B09, 17CC,15     ;32804          PORT.CONTROL [CLEAR.IDC]
U 1B0A, 17CC,15     ;32805          PORT.CONTROL [CLEAR.IDC]
                    ;32806
U 1B0B, B788,15     ;32807          MOV LS[#3] TO WR[0]                       ;WAIT FOR INT TO CLR
                    ;32808  WAIT.INIT.T3A:
                    ;32809          DEC WR[0],                                ;WAIT SOME MORE
U 1B0C, A100,35     ;32810           DT(LONG)&SET.ALU.CC
U 1B0D, 89B0,C1     ;32811          JMP.IF[NEQ] TO [WAIT.INIT.T3A]            ;WAIT SOME MORE
                    ;32812
                    ;32813
U 1B0E, 89B1,47     ;32814          JMP.IF[NO.INTERRUPT] TO [GOOD.LOOP.T3A]   ;JMP IF OK
U 1B0F, 2F80,15     ;32815          CLR WR[0]                                 ;FORCE AN ERROR
U 1B10, 3640,95     ;32816          MOV LS[#1] TO WR[1]
U 1B11, 6588,15     ;32817          CLR LS[ADDRESS.DATA]                      ;CLEAR OTHER DATA
U 1B12, 0869,3C     ;32818          JSR [CHECK.RESULT]                        ;REPORT THE ERROR
U 1B13, 09B0,84     ;32819          JMP [LOOP.T3A.2]                          ;LOOP HERE ON ERR & LOE IS SET
                    ;32820  GOOD.LOOP.T3A:
                    ;32821
U 1B14, 2F80,15     ;32822          CLR WR[0]                                 ;CALL CHECK RESULT WITH GOOD
U 1B15, 2F82,95     ;32823          CLR WR[1]                                 ; DATA TO LOCK IN INTERMITTANT
U 1B16, 6588,15     ;32824          CLR LS[ADDRESS.DATA]                      ; ERRORS
U 1B17, 0869,3C     ;32825          JSR [CHECK.RESULT]
U 1B18, 09B0,84     ;32826          JMP [LOOP.T3A.2]                          ;LOOP HERE IF LOOP IS SET
                    ;32827
                    ;32828  CLEANUP.T3A:
U 1B19, 97C4,15     ;32829          PORT.CONTROL [RESET.BR]                   ;CLEAR ALL INTERRUPTS
U 1B1A, B788,15     ;32830          MOV LS[#3] TO WR[0]                       ;WAIT FOR INT TO CLR
                    ;32831  WAIT.BR.T3A.1:
                    ;32832          DEC WR[0],                                ;WAIT SOME MORE
U 1B1B, A100,35     ;32833           DT(LONG)&SET.ALU.CC
U 1B1C, 89B1,B1     ;32834          JMP.IF[NEQ] TO [WAIT.BR.T3A.1]            ;WAIT SOME MORE
                    ;32835
U 1B1D, 8875,3C     ;32836          JSR [CLEANUP]                             ;CLEANUP THE CONDITIONS SET
                    ;32837                                                    ; BY THIS TEST
                    ;32838  END.T3A:                                          ;END TEST
                    ;32839
                    ;32840
                    ;32841
                    ;32842
```

```
;32843  .PAGE  "Test 3B  AUTOMODE TEST (M8388 IDC MODULE)"
;32844  ;++
;32845  ;
;32846  ; Test Description:
;32847  ;
;32848  ;       This test is designed to insure that when in automode, after one READ
;32849  ;       DATA instruction, the IDC continues to send the CPU new read data when
;32850  ;       a MOV PORT TO LS [] instruction is issued. It will also verify that
;32851  ;       when automode is cleared, one more MOV PORT TO LS[] reads new data and
;32852  ;       then the IDC does not continue to send new read data.
;32853  ;       Automode can only do longword reads.
;32854  ;       The data in FIFO A will be:
;32855  ;               Address 0 - 3:   11111111
;32856  ;               Address 4 - 7:   22222222
;32857  ;               Address 8 - B:   33333333
;32858  ;               Address C - F:   44444444
;32859  ;               Address 10 - 13: 55555555
;32860  ;
;32861  ;       Automode will be enabled and then the first longword read (11111111)
;32862  ;       will be done by first issuing a READ.DATA WORD  and then doing a
;32863  ;       MOV.PORT to LS[]. Then a MOV.PORT to LS[] instruction will be issued.
;32864  ;       This should move the next longword of data (22222222) from FIFO A to
;32865  ;       LS[]. Another MOV.PORT TO LS[] will be issued to insure that automode
;32866  ;       enabled all necessary conditions. This should move the next longword of
;32867  ;       data (33333333) from FIFO A to LS[].
;32868  ;       Automode will then be disabled. A MOV.PORT TO LS[] instruction will be
;32869  ;       issued. This should read the  next longword of data (44444444). Then
;32870  ;       one more MOV.PORT to LS[] will be issued and the next longword
;32871  ;       (55555555) should not be read.
;32872  ;       The CPU will then read the data in LS to insure that automode worked
;32873  ;       correctly.
;32874  ;
;32875  ; Assumptions:
;32876  ;
;32877  ;       It is assumed that all previous tests have run successfully.
;32878  ;
;32879  ; Test Steps:
;32880  ;
;32881  ;       1. Set up error mask, error number and module number in LS
;32882  ;          (for error printouts) and clear the previous error number in LS.
;32883  ;       2. INIT the IDC and force it to DIAG.IDLE.
;32884  ;       3. Write the data to the FIFO.
;32885  ;       4. Set automode.
;32886  ;       5. Read the first location of the FIFO and MOV.PORT TO LS[].
;32887  ;       6. Issue 2 MOV PORT TO LS[] instructions.
;32888  ;       7. Clear automode.
;32889  ;       8. Issue 2 MOV PORT TO LS[] instructions.
;32890  ;       9. Check the five locations in LS.
;32891  ;      10. Clear IDC.
;32892  ;      11. End test.
;32893  ;
;32894  ;
;32895  ; Errors:
;32896  ;
;32897  ;                       Printout:
```

```
;32898  ;                          EXPECTED          RECEIVED
;32899  ;                          FIFO A            FIFO A
;32900  ;
;32901  ;       ERROR 1 - The IDC did not continue to send new read data when in
;32902  ;                 automode.
;32903  ;
;32904  ;       ERROR 2 - The IDC did not continue to send new read data when in
;32905  ;                 automode.
;32906  ;
;32907  ;       ERROR 3 - The IDC did not continue to send new read data when in
;32908  ;                 automode.
;32909  ;
;32910  ;       ERROR 4 - The IDC did not continue to send new read data when in
;32911  ;                 automode.
;32912  ;
;32913  ;       ERROR 5 - Automode did not clear.
;32914  ;
;32915  ; Debug:
;32916  ;
;32917  ; ERRORS 1 - 4:
;32918  ;       The data is first written to FIFO A.
;32919  ;               Address 0 - 3:   11111111
;32920  ;               Address 4 - 7:   22222222
;32921  ;               Address 8 - B:   33333333
;32922  ;               Address C - F:   44444444
;32923  ;               Address 10 - 13: 55555555
;32924  ;       The CPU then issues at SET.AUTOMODE. This instruction is decoded by
;32925  ;       the PORT INTERFACE REG PAL. The inputs at this time should be
;32926  ;               CSR 17 H = H
;32927  ;               CSR 14 H = H
;32928  ;               READ PORT L = H
;32929  ;               CSR 12 H = H
;32930  ;               CSR 11 H = L
;32931  ;               CSR 10 H = L
;32932  ;               PORT INSTR H = H
;32933  ;               CPU P2 H = H
;32934  ;       The SET.AUTO instruction will be clocked by CPU CLOCK H and AUTOMODE H
;32935  ;       will assert. AUTOMODE H is input to the PORT RD/WR DECODE PAL.
;32936  ;       The CPU then selects the IDC with a MISC [SET PORT.I.O] instruction.
;32937  ;       The CPU then does one PORT.READ PORT.ADRS[DATA.WORD] instruction that
;32938  ;       will read the first longword of data from address 0 of FIFO A. The CPU
;32939  ;       issues a MOV PORT TO LS[] instruction to enable the data onto the
;32940  ;       IO BUS and then through the XCVRS and onto the Y BUS to LS.
;32941  ;       Now whenever a MOV PORT TO LS[] instruction is issued by the CPU,
;32942  ;       a longword of data will be read. The MOV PORT TO LS[] instruction is
;32943  ;       decoded by the PORT INTERFACE REG PAL and the DECODER and asserts
;32944  ;       SEL WORD L. This signal is input to a NOR gate which will then assert
;32945  ;       ENB OUTREG L. The PORT RD/WR DECODE PAL then decodes these signals and
;32946  ;       asserts READ DATA L. The inputs to the PORT RD/WR DECODE PAL at this
;32947  ;       time should be:
;32948  ;               AUTOMODE H = H
;32949  ;               ENB OUTREG L = L
;32950  ;               CPU P2 H = H
;32951  ;       The FIFO CNTR is then incremented by the PORT USEQ A PAL so that
;32952  ;       each subsequent time a MOV PORT TO LS[] instruction is issued, a
```

```
                ;32953  ;       new longword of data is read.
                ;32954  ;
                ;32955  ; ERROR 5:
                ;32956  ;       AUTOMODE is cleared when the CPU issues a CLEAR.AUTO instrcution.
                ;32957  ;       This instruction will be decoded in the PORT INTERFACE REG PAL.
                ;32958  ;       The inputs should be:
                ;32959  ;               CSR 17 H = H
                ;32960  ;               CSR 14 H = H
                ;32961  ;               CSR 12 H = H
                ;32962  ;               CSR 11 H = L
                ;32963  ;               CSR 10 H = H
                ;32964  ;               PORT INSTR H = H
                ;32965  ;               CPU P2 H = H
                ;32966  ;       This will deassert AUTOMODE H, and new data should not be returned
                ;32967  ;       when only a MOV PORT TO LS[] is issued.
                ;32968  ;--
                ;32969  ;*****************************************************************************
                ;32970  T.3B:
U 1B1E, B65E,15 ;32971          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;32972                                                  ; CONTROL AND STATUS WORD
U 1B1F, 3E80,15 ;32973          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;32974                                                  ; STATUS WORD - BIT 15
                ;32975                                                  ; INDICATES START OF TEST TO
                ;32976                                                  ; CONSOLE
U 1B20, 10E0,15 ;32977          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;32978  WAIT.T3B.0:
U 1B21, 89B2,14 ;32979          JMP [WAIT.T3B.0]                        ;LOOP HERE WAITING FOR
                ;32980                                                  ; CONSOLE TO RESPOND
                ;32981
U 1B22, 65A0,15 ;32982          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;32983                                                  ; IN LS
                ;32984
U 1B23, B64A,15 ;32985          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1B24, 3E8C,15 ;32986          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;32987
                ;32988
                ;32989
U 1B25, E58A,15 ;32990          CLR LS[ERROR.MASK]                      ;SET UP ERROR MASK TO CHECK
                ;32991                                                  ; ALL BITS
U 1B26, 8872,EC ;32992          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT TO
                ;32993                                                  ; DIAG.IDLE
U 1B27, 17D8,15 ;32994          PORT.CONTROL [SEL.FIFO.A]               ;SELECT FIFO A
U 1B28, 17C0,15 ;32995          PORT.CONTROL [CLEAR.FIFO.CNTR]          ;SET ADDRESS = 0
                ;32996
U 1B29, 37D0,15 ;32997          MOV LS[#11111111] TO WR[0]              ;WRITE THE FIRST DATA
U 1B2A, 17AC,15 ;32998          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE A LONGWORD OF DATA
                ;32999
U 1B2B, B7D2,15 ;33000          MOV LS[#22222222] TO WR[0]              ;WRITE NEXT LONGWORD OF DATA
U 1B2C, 17AC,15 ;33001          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE A LONGWORD OF DATA
                ;33002
U 1B2D, B6C4,15 ;33003          MOV LS[#33333333] TO WR[0]              ;WRITE NEXT LONGWORD OF DATA
U 1B2E, 17AC,15 ;33004          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE A LONGWORD OF DATA
                ;33005
U 1B2F, B7D4,15 ;33006          MOV LS[#44444444] TO WR[0]              ;WRITE NEXT LONGWORD OF DATA
U 1B30, 17AC,15 ;33007          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE A LONGWORD OF DATA
```

```
                    ;33008
U 1B31, 369A,15     ;33009          MOV LS[#55555555] TO WR[0]                  ;WRITE NEXT LONGWORD OF DATA
U 1B32, 17AC,15     ;33010          PORT.WRITE PORT.ADRS[DATA.WORD] WITH WR[0]  ;WRITE A LONGWORD OF DATA
                    ;33011
                    ;33012  LOOP.T3B.1:
                    ;33013
U 1B33, B640,15     ;33014          MOV LS[#1] TO WR[0]                         ;SET WR0 = 1
U 1B34, BE82,15     ;33015          MOV WR[0] TO LS[ERROR.NUMBER]               ;SET UP ERROR NUMBER = 1 IN LS
                    ;33016
U 1B35, 17C0,15     ;33017          PORT.CONTROL [CLEAR.FIFO.CNTR]              ;SET ADDRESS = 0
                    ;33018
U 1B36, 97D0,15     ;33019          PORT.CONTROL [SET.AUTO]                     ;SET AUTOMODE TO CONTINUE READS
                    ;33020
U 1B37, 9090,15     ;33021          MISC [SET.PORT.I.O]                         ;SELECT THE IDC
U 1B38, 978C,15     ;33022          PORT.READ PORT.ADRS[DATA.WORD]              ;SET UP TO READ A LONGWORD
U 1B39, DB00,15     ;33023          NOP                                         ;ALLOW TIME FOR IDC TO ASSEMBLE
                    ;33024                                                      ; A LONGWORD OF DATA
U 1B3A, 3B34,15     ;33025          MOV PORT TO LS[PORT1]                       ;READ THE DATA FROM FIFO AND
U 1B3B, DB00,15     ;33026          NOP                                         ; SAVE IT IN  LS
U 1B3C, BB36,15     ;33027          MOV PORT TO LS[PORT2]                       ;READ THE NEXT LONGWORD
U 1B3D, DB00,15     ;33028          NOP
U 1B3E, 3B38,15     ;33029          MOV PORT TO LS[PORT3]                       ;READ THE NEXT LONGWORD
U 1B3F, DB00,15     ;33030          NOP
U 1B40, 17D4,15     ;33031          PORT.CONTROL [CLEAR.AUTO]                   ;CLEAR AUTOMODE
                    ;33032
U 1B41, BB3A,15     ;33033          MOV PORT TO LS[PORT4]                       ;SHOULD READ ONE MORE WORD
U 1B42, DB00,15     ;33034          NOP
U 1B43, BB3C,15     ;33035          MOV PORT TO LS[PORT5]                       ;SHOULD NOT SEND NEW DATA
                    ;33036
                    ;33037  ;CHECK THE DATA THAT WAS READ
                    ;33038
U 1B44, 3734,15     ;33039          MOV LS[PORT1] TO WR[0]                      ;SET UP THE RECEIVED DATA
U 1B45, B7D0,95     ;33040          MOV LS[#11111111] TO WR[1]                  ;SET UP THE EXPECTED DATA
U 1B46, 0869,3C     ;33041          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1B47, 89B3,34     ;33042          JMP [LOOP.T3B.1]                            ;LOOP HERE IF ERR & LOE IS SET
                    ;33043
                    ;33044
U 1B48, FF82,15     ;33045          INC LS[ERROR.NUMBER]                        ;ERROR 2
                    ;33046
U 1B49, B736,15     ;33047          MOV LS[PORT2] TO WR[0]                      ;SET UP THE RECEIVED DATA
U 1B4A, 37D2,95     ;33048          MOV LS[#22222222] TO WR[1]                  ;SET UP THE EXPECTED DATA
U 1B4B, 0869,3C     ;33049          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1B4C, 89B3,34     ;33050          JMP [LOOP.T3B.1]                            ;LOOP HERE IF ERR & LOE IS SET
                    ;33051
                    ;33052
U 1B4D, FF82,15     ;33053          INC LS[ERROR.NUMBER]                        ;ERROR 3
                    ;33054
U 1B4E, 3738,15     ;33055          MOV LS[PORT3] TO WR[0]                      ;SET UP THE RECEIVED DATA
U 1B4F, 36C4,95     ;33056          MOV LS[#33333333] TO WR[1]                  ;SET UP THE EXPECTED DATA
U 1B50, 0869,3C     ;33057          JSR [CHECK.RESULT]                          ;CHECK THE DATA
U 1B51, 89B3,34     ;33058          JMP [LOOP.T3B.1]                            ;LOOP HERE IF ERR & LOE IS SET
                    ;33059
                    ;33060
U 1B52, FF82,15     ;33061          INC LS[ERROR.NUMBER]                        ;ERROR 4
                    ;33062
```

```
U 1B53, B73A,15 ;33063          MOV LS[PORT4] TO WR[0]                  ;SET UP THE RECEIVED DATA
U 1B54, 37D4,95 ;33064          MOV LS[#44444444] TO WR[1]              ;SET UP THE EXPECTED DATA
U 1B55, 0869,3C ;33065          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B56, 89B3,34 ;33066          JMP [LOOP.T3B.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;33067
                ;33068
U 1B57, FF82,15 ;33069          INC LS[ERROR.NUMBER]                    ;ERROR 5
                ;33070
U 1B58, B73C,15 ;33071          MOV LS[PORT5] TO WR[0]                  ;SET UP THE RECEIVED DATA
U 1B59, 37D4,95 ;33072          MOV LS[#44444444] TO WR[1]              ;SET UP THE EXPECTED DATA
U 1B5A, 0869,3C ;33073          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B5B, 89B3,34 ;33074          JMP [LOOP.T3B.1]                        ;LOOP HERE IF ERR & LOE IS SET
                ;33075
U 1B5C, 8875,3C ;33076          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                ;33077                                                  ;BY THIS TEST
                ;33078  END.T3B:                                        ;END TEST
                ;33079
                ;33080
                ;33081
```

```
;33082  .PAGE  "Test 3C  TIMEOUT TEST 1 (M8388 IDC MODULE)"
;33083  ;++
;33084  ;
;33085  ; Test Description:
;33086  ;
;33087  ;       This test will check that the timeout counter times out within the
;33088  ;       specified amount of time which is 150 ms +50ms and -50ms  after CSR
;33089  ;       <CRDY> is cleared.
;33090  ;       This test will also insure that a UCDM/CLEAR.TIMEOUT clears
;33091  ;       timeouts.
;33092  ;       It will also check that a timeout causes the IDC to JAM and return
;33093  ;       to the IDC Microcode Idle Loop.
;33094  ;
;33095  ;       This test cannot be single-stepped because the timeout is generated
;33096  ;       from a one-shot.
;33097  ;
;33098  ; Assumptions:
;33099  ;
;33100  ;       It is assumed that all previous tests have been run successfully.
;33101  ;
;33102  ; Test Steps:
;33103  ;
;33104  ;       1. Set up error mask, error number and module number in LS
;33105  ;          (for error printouts) and clear the previous error number in LS.
;33106  ;       2. Force the IDC to DIAG.IDLE.
;33107  ;       3. Clear CSR <CRDY> to start timer.
;33108  ;       4. Set up a loop to wait 200 ms.
;33109  ;       5. Check CSR <OPI> (bit 10) = 1 to insure that IDC timed out.
;33110  ;       6. Increment the error number.
;33111  ;       7. To insure that the IDC did JAM when it timed out,
;33112  ;          check CSR <CRDY> = 1. (The IDC microcode should JAM, clear the
;33113  ;          timeout, then set CSR <CRDY> and then return to the IDC IDLE LOOP).
;33114  ;       8. Increment the error number.
;33115  ;       9. Clear CSR <CRDY> with CSR <MAINT> set to clear OPI.
;33116  ;      10. Check CSR <OPI> (bit 10) remains clear to insure that
;33117  ;          timeout cleared.
;33118  ;      11. Increment the error number.
;33119  ;      12. Force the IDC to DIAG.IDLE.
;33120  ;      13. Clear CSR <CRDY>.
;33121  ;      14. Set up a loop to wait 100 ms.
;33122  ;      15. Check CSR <OPI> (bit 10) = 0 to insure that IDC did not time out.
;33123  ;      16. Clear IDC.
;33124  ;      17. End test.
;33125  ;
;33126  ; Errors:
;33127  ;
;33128  ;                   Printout:
;33129  ;                           EXPECTED          RECEIVED
;33130  ;                             CSR               CSR
;33131  ;                            <OPI>             <OPI>
;33132  ;
;33133  ;       ERROR 1 - The IDC did not timeout within the specified time after
;33134  ;                  INIT was issued and then CSR <CRDY> was cleared.
;33135  ;
;33136  ;       ERROR 2 - A timeout did not JAM the IDC.
```

```
                ;33137  ;
                ;33138  ;       ERROR 3 - UCMD/CLEAR.TIMEOUT did not clear the timeout.
                ;33139  ;
                ;33140  ;       ERROR 4 - The IDC timeout out too soon after CSR <CRDY> was cleared.
                ;33141  ;
                ;33142  ; Debug:
                ;33143  ;
                ;33144  ; ERROR 1-
                ;33145  ;       When CSR <CRDY> is cleared with URESET TIMER L = H, the one-shot
                ;33146  ;       is set up and should trigger 150ms (+50ms or -50ms) later if the
                ;33147  ;       set-up conditions remain unchanged. The test then waits 200ms for the
                ;33148  ;       timeout to occur. When the one-shot is triggered, TIMER H will assert.
                ;33149  ;       This signal is an input to the CONTROL STATUS REG PAL. This should
                ;33150  ;       assert TIMEOUT H. TIMEOUT H = H in that same PAL will assert OPI L.
                ;33151  ;       When the CPU reads the CSR, OPI L = L is fed through an 8-line DRIVER
                ;33152  ;       and becomes BUS IO 10 H = H.
                ;33153  ;
                ;33154  ; ERROR 2-
                ;33155  ;       After TIMEOUT H asserts in the CONTROL STATUS REG PAL,(see ERROR 1),
                ;33156  ;       on the next P2 CLOCK L, TIMEOUT H is fed through the INIT FF and
                ;33157  ;       JAM L should assert and is then inverted and used as JAM H. JAM H = H
                ;33158  ;       will cause the microsequencer to jam to microstate FF. The micocode
                ;33159  ;       will then select BEN2/OPI L. OPI L will be asserted so the micocode
                ;33160  ;       will branch to a state that will set CSR <CRDY> and then go to the
                ;33161  ;       IDC IDLE LOOP.
                ;33162  ;
                ;33163  ; ERROR 3-
                ;33164  ;       After the TIMEOUT has occurred and the IDC has JAMMED, the CSR will
                ;33165  ;       be set up to branch to an instruction that will clear the timeout.
                ;33166  ;       In this micro-instruction UCMD<2:0> = 111. The UCMD bits will be
                ;33167  ;       decoded in the CONTROL STATUS REG PAL and should clear TIMEOUT H
                ;33168  ;       which in turn will clear OPI L.
                ;33169  ;
                ;33170  ; ERROR 4 -
                ;33171  ;       When CSR <CRDY> is cleared with URESET TIMER L = H, the one-shot
                ;33172  ;       is set up and should trigger 150ms (+50ms or -50ms) later if the
                ;33173  ;       set-up conditions remain unchanged. The test then waits 100ms for the
                ;33174  ;       timeout to occur. If the one-shot is triggered, TIMER H will assert.
                ;33175  ;       CSR <OPI> is then checked to insure that the one-shot did not trigger
                ;33176  ;       too soon. (See ERROR 1)
                ;33177  ;--
                ;33178  ;*******************************************************************************
                ;33179  T.3C:
U 1B5D, B65E,15 ;33180          MOV LS[BEGIN.TEST] TO WR[0]                     ;SET BIT 15 IN WR[0] FOR
                ;33181                                                          ; CONTROL AND STATUS WORD
U 1B5E, 3E80,15 ;33182          MOV WR[0] TO LS[CONTROL.STATUS]                 ;SET BIT 15 IN CONTROL AND
                ;33183                                                          ; STATUS WORD - BIT 15
                ;33184                                                          ; INDICATES START OF TEST TO
                ;33185                                                          ; CONSOLE
U 1B5F, 10E0,15 ;33186          MISC [SET.CP.ATTN]                              ;ISSUE CPU ATTN TO CONSOLE
                ;33187  WAIT.T3C.0:
U 1B60, 89B6,04 ;33188          JMP [WAIT.T3C.0]                                ;LOOP HERE WAITING FOR
                ;33189                                                          ; CONSOLE TO RESPOND
                ;33190
U 1B61, 65A0,15 ;33191          CLR LS[PREVIOUS.ERROR]                          ;CLEAR PREVIOUS ERROR NUMBER
```

```
                ;33192                                                  ; IN LS
                ;33193
U 1B62, B64A,15 ;33194          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1B63, 3E8C,15 ;33195          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;33196
                ;33197
                ;33198
U 1B64, 37E0,15 ;33199          MOV LS[#FFFFFBFF] TO WR[0]              ;MASK TO CHECK BIT <10>
U 1B65, 3E8A,15 ;33200          MOV WR[0] TO LS[ERROR.MASK]
                ;33201
                ;33202  LOOP.T3C.1:
                ;33203  LOOP.T3C.2:
                ;33204
U 1B66, 8872,EC ;33205          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT
                ;33206                                                  ; TO DIAG.IDLE WITH TIMEOUTS
                ;33207                                                  ; DISABLED
                ;33208
U 1B67, B7E4,15 ;33209          MOV LS[#10000080] TO WR[0]              ;SET CRDY WITH TIMEOUTS
                ;33210                                                  ; DISABLED
U 1B68, 17A0,15 ;33211          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;33212
                ;33213  LOOP.T3C.3:
U 1B69, B640,15 ;33214          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1B6A, BE82,15 ;33215          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;33216
                ;33217
U 1B6B, 2F80,15 ;33218          CLR WR[0]                               ;CLR CRDY WITH TIMEOUTS ENABLED
U 1B6C, 17A0,15 ;33219          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1B6D, 37DE,95 ;33220          MOV LS[#5A6C2] TO WR[1]                 ;SET UP TO LOOP 200ms
                ;33221  WAIT.T3C.200:
                ;33222          DEC WR[1],
U 1B6E, A102,B5 ;33223           DT(LONG)&SET.ALU.CC
U 1B6F, 09B6,E1 ;33224          JMP.IF[NEQ] TO [WAIT.T3C.200]           ;WAIT SOME MORE
                ;33225
                ;33226
                ;33227  ;The IDC should timeout which will cause a JAM.
                ;33228  ;-------------------------------------------------------------------------
                ;33229  ;-------------------------------------------------------------------------
                ;33230  ;                                *******
                ;33231  ;                                * IDC *
                ;33232  ;                                *******
                ;33233  ;-------------------------------------------------------------------------
                ;33234  ;=111111111
                ;33235  ;
                ;33236  ;JAM:
                ;33237  ;
                ;33238  ;       UCMD/CLR.TIMEOUT,
                ;33239  ;       BEN2/OPI.L,             ;JAM TO THIS STATE ON POWER UP
                ;33240  ;       NAD/PWR.FAIL            ;OR TIMEOUT.
                ;33241  ;-------------------------------------------------------------------------
                ;33242  ;=
                ;33243  ;=0**
                ;33244  ;
                ;33245  ;TIMEOUT:
                ;33246  ;
```

```
                    ;33247  ;       UCMD/SET.CRDY,          ;SIGNAL END OF TRANSFER.
                    ;33248  ;       FUNC/SET.INT,
                    ;33249  ;       NAD/IDLE
                    ;33250  ;-------------------------------------------------------------------------
                    ;33251
                    ;33252  READ.CSR.T3C.1:
U 1B70, 9090,15     ;33253          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1B71, 9780,15     ;33254          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1B72, 3B32,15     ;33255          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;33256                                                  ; SAVE IT IN  LS
U 1B73, 3732,15     ;33257          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1B74, 3654,95     ;33258          MOV LS[BIT10] TO WR[1]                  ;SET UP EXPECTED DATA
U 1B75, 0869,3C     ;33259          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B76, 89B6,64     ;33260          JMP [LOOP.T3C.1]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;33261
U 1B77, FF82,15     ;33262          INC LS[ERROR.NUMBER]                    ;ERROR 2
U 1B78, B7E2,15     ;33263          MOV LS[#FFFFFF7F] TO WR[0]              ;SET UP THE ERROR MASK TO
U 1B79, 3E8A,15     ;33264          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK BIT 7
U 1B7A, 3732,15     ;33265          MOV LS[PORT0] TO WR[0]                  ;GET THE RECEIVED CSR DATA
U 1B7B, B64E,95     ;33266          MOV LS[BIT7] TO WR[1]                   ;SET EXPECTED DATA
U 1B7C, 0869,3C     ;33267          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B7D, 89B6,64     ;33268          JMP [LOOP.T3C.2]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;33269
U 1B7E, FF82,15     ;33270          INC LS[ERROR.NUMBER]                    ;ERROR 3
U 1B7F, 37E0,15     ;33271          MOV LS[#FFFFFBFF] TO WR[0]              ;SET UP THE ERROR MASK TO CHECK
U 1B80, 3E8A,15     ;33272          MOV WR[0] TO LS[ERROR.MASK]             ; BIT 10
                    ;33273
                    ;33274  ;IDC SHOULD BE LOOPING IN THE IDC IDLE LOOP
                    ;33275
U 1B81, 3720,15     ;33276          MOV LS[SETCSR.MAINT] TO WR[0]           ;GET DATA TO SET CSR MAINT BIT
                    ;33277                                                  ; CRDY = 0 AND MAINT = 1
U 1B82, 17A0,15     ;33278          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE TO THE IDC CSR
                    ;33279
U 1B83, B730,15     ;33280          MOV LS[#1A] TO WR[0]                    ;SET UP A COUNTER TO NOP TO
                    ;33281                                                  ; ALLOW TIME TO BRANCH FROM
                    ;33282                                                  ; IDLE TO DIAG.IDLE
                    ;33283  WAIT.BRANCH.T3C:
U 1B84, 2100,15     ;33284          DEC WR[0]                               ; IDC COMPLETES ITS OPERATION
                    ;33285          CMP WR[0] WITH LS[ZERO],
U 1B85, 4F9C,35     ;33286           DT(LONG)&SET.ALU.CC
U 1B86, 89B8,41     ;33287          JMP.IF[NEQ] TO [WAIT.BRANCH.T3C]
                    ;33288
                    ;33289
                    ;33290  ;CLEARING CSR <CRDY> WOULD HAVE CLEARED CSR <OPI> AND IF TIMEOUT HAS CLEARED,
                    ;33291  ;CSR <OPI> WILL REMAIN CLEAR
                    ;33292
                    ;33293  READ.CSR.T3C.2:
U 1B87, 9090,15     ;33294          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1B88, 9780,15     ;33295          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1B89, 3B32,15     ;33296          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;33297                                                  ; SAVE IT IN  LS
U 1B8A, 3732,15     ;33298          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1B8B, 2F82,95     ;33299          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1B8C, 0869,3C     ;33300          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B8D, 89B6,94     ;33301          JMP [LOOP.T3C.3]                        ;LOOP HERE IF ERR & LOE IS SET
```

```
                    ;33302
U 1B8E, FF82,15     ;33303          INC LS[ERROR.NUMBER]                    ;ERROR 4
                    ;33304
U 1B8F, 8872,EC     ;33305          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE
                    ;33306                                                  ; IT TO DIAG.IDLE WITH
                    ;33307                                                  ; TIMEOUTS DISABLED
U 1B90, B7E4,15     ;33308          MOV LS[#10000080] TO WR[0]              ;SET CRDY WITH TIMEOUTS
                    ;33309                                                  ;DISABLED
U 1B91, 17A0,15     ;33310          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                    ;33311
                    ;33312  LOOP.T3C.4:
                    ;33313
U 1B92, 2F80,15     ;33314          CLR WR[0]                               ;CLR CRDY WITH TIMEOUTS ENABLED
U 1B93, 17A0,15     ;33315          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1B94, B7DA,95     ;33316          MOV LS[#28AEE] TO WR[1]                 ;SET UP TO LOOP 100ms
                    ;33317  WAIT.T3C.100:
                    ;33318          DEC WR[1],
U 1B95, A102,B5     ;33319           DT(LONG)&SET.ALU.CC
U 1B96, 89B9,51     ;33320          JMP.IF[NEQ] TO [WAIT.T3C.100]           ;WAIT SOME MORE
                    ;33321
                    ;33322  READ.CSR.T3C.3:
U 1B97, 9090,15     ;33323          MISC [SET.PORT.I.0]                     ;SELECT THE IDC
U 1B98, 9780,15     ;33324          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1B99, 3B32,15     ;33325          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                    ;33326                                                  ; SAVE IT IN  LS
U 1B9A, 3732,15     ;33327          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1B9B, 2F82,95     ;33328          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1B9C, 0869,3C     ;33329          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1B9D, 09B9,24     ;33330          JMP [LOOP.T3C.4]                        ;LOOP HERE IF ERR & LOE IS SET
                    ;33331
U 1B9E, 8875,3C     ;33332          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                    ;33333                                                  ;BY THIS TEST
                    ;33334  END.T3C:                                        ;END TEST
                    ;33335
                    ;33336
                    ;33337
                    ;33338
```

```
;33339  .PAGE  "Test 3D  TIMEOUT TEST 2 (M8388 IDC MODULE)"
;33340  ;++
;33341  ;
;33342  ; Test Description:
;33343  ;
;33344  ;       This test will check that the timeout counter times out within the
;33345  ;       specified amount of time which is 150 ms +50ms and -50ms after
;33346  ;       UCMD/RESET.TIMER has been issued with CSR <CRDY> clear.
;33347  ;
;33348  ;       This test cannot be single-stepped because the timeout is generated
;33349  ;       from a one-shot.
;33350  ;
;33351  ; Assumptions:
;33352  ;
;33353  ;       It is assumed that all previous tests have been run successfully.
;33354  ;
;33355  ; Test Steps:
;33356  ;
;33357  ;       1. Set up error mask, error number and module number in LS
;33358  ;          (for error printouts) and clear the previous error number in LS.
;33359  ;       2. Force the IDC to DIAG.IDLE.
;33360  ;       3. Clear CSR <CRDY> with timeouts enabled to start the timer.
;33361  ;       4. Let timer go 100ms.
;33362  ;       5. Set up the CSR to branch to the correct IDC routine.
;33363  ;
;33364  ;                                       *******
;33365  ;                                       * IDC *
;33366  ;                                       *******
;33367  ;
;33368  ;               IDC1. FUNC/RESET.TIMER.
;33369  ;               IDC2. Send XFER REQ to flag the CPU.
;33370  ;
;33371  ;       6. Wait for a XFER REQ from IDC.
;33372  ;       7. Set up a loop to wait 200 ms.
;33373  ;       8. Check CSR <OPI> (bit 10) = 1 to insure that the IDC timed out.
;33374  ;       9. Increment the error number.
;33375  ;      10. INIT the IDC and force the IDC to DIAG.IDLE.
;33376  ;      11. Clear CSR <CRDY> to start the timer.
;33377  ;      12. Let the timer go 100ms.
;33378  ;      13. Set up the CSR to branch to the correct IDC routine.
;33379  ;
;33380  ;
;33381  ;                                       *******
;33382  ;                                       * IDC *
;33383  ;                                       *******
;33384  ;
;33385  ;               IDC3. FUNC/RESET.TIMER.
;33386  ;               IDC4. Send XFER REQ to flag the CPU.
;33387  ;
;33388  ;      14. Wait for a XFER REQ from the IDC.
;33389  ;      15. Set up a loop to wait 100 ms.
;33390  ;      16. Check CSR <OPI> (bit 10) = 0 to insure that IDC did not timeout.
;33391  ;      17. Clear the IDC.
;33392  ;      18. End test.
;33393  ;
```

```
                ;33394  ; Errors:
                ;33395  ;
                ;33396  ;                   Printout:
                ;33397  ;                           EXPECTED          RECEIVED
                ;33398  ;                             CSR               CSR
                ;33399  ;                            <OPI>             <OPI>
                ;33400  ;
                ;33401  ;       ERROR 1 - The IDC did not timeout within the specified time after
                ;33402  ;                 FUNC/RESET.TIMER was executed and then CSR <CRDY> was
                ;33403  ;                 cleared.
                ;33404  ;       ERROR 2 - The IDC timed out too soon after a FUNC/RESET.TIMER was
                ;33405  ;                 executed and with CSR <CRDY> clear.
                ;33406  ;
                ;33407  ; Debug:
                ;33408  ;
                ;33409  ;       When CSR <CRDY> is cleared with URESET TIMER L = H, the one-shot
                ;33410  ;       is set up and should trigger 150ms (+50ms or -50ms) later if the
                ;33411  ;       set-up conditions remain unchanged. However, in this test after 100ms
                ;33412  ;       a URESET TIMER L is issued. In the microstate that the reset occurs in,
                ;33413  ;       UFUNC <3:0> = 0011 will be decoded to URESET TIMER L = L. This signal
                ;33414  ;       will reset the one-shot and the one-shot should trigger 150ms (+50 -50)
                ;33415  ;       after the reset.
                ;33416  ;
                ;33417  ;--
                ;33418  ;*******************************************************************************
                ;33419  T.3D:
U 1B9F, B65E,15 ;33420          MOV LS[BEGIN.TEST] TO WR[0]             ;SET BIT 15 IN WR[0] FOR
                ;33421                                                  ; CONTROL AND STATUS WORD
U 1BA0, 3E80,15 ;33422          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET BIT 15 IN CONTROL AND
                ;33423                                                  ; STATUS WORD - BIT 15
                ;33424                                                  ; INDICATES START OF TEST TO
                ;33425                                                  ; CONSOLE
U 1BA1, 10E0,15 ;33426          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;33427  WAIT.T3D.0:
U 1BA2, 09BA,24 ;33428          JMP [WAIT.T3D.0]                        ;LOOP HERE WAITING FOR
                ;33429                                                  ; CONSOLE TO RESPOND
                ;33430
U 1BA3, 65A0,15 ;33431          CLR LS[PREVIOUS.ERROR]                  ;CLEAR PREVIOUS ERROR NUMBER
                ;33432                                                  ; IN LS
                ;33433
U 1BA4, B64A,15 ;33434          MOV LS[IDC] TO WR[0]                    ;STORE MODULE CODE IN LS TO
U 1BA5, 3E8C,15 ;33435          MOV WR[0] TO LS[MODULE.NUM]             ; INDICATE IDC MODULE
                ;33436
                ;33437
U 1BA6, B640,15 ;33438          MOV LS[#1] TO WR[0]                     ;SET WR0 = 1
U 1BA7, BE82,15 ;33439          MOV WR[0] TO LS[ERROR.NUMBER]           ;SET UP ERROR NUMBER = 1 IN LS
                ;33440
U 1BA8, 37E0,15 ;33441          MOV LS[#FFFFFBFF] TO WR[0]              ;SET UP THE ERROR MASK TO
U 1BA9, 3E8A,15 ;33442          MOV WR[0] TO LS[ERROR.MASK]             ; CHECK BIT 10
                ;33443
                ;33444
                ;33445  LOOP.T3D.1:
U 1BAA, 8872,EC ;33446          JSR [DIAG.CODE]                         ;INIT THE IDC AND FORCE IT
                ;33447                                                  ; TO DIAG.IDLE
U 1BAB, B7E4,15 ;33448          MOV LS[#10000080] TO WR[0]              ;SET CRDY WITH TIMEOUTS
```

```
                ;33449                                                  ; DISABLED
U 1BAC, 17A0,15 ;33450          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;33451
U 1BAD, 2F80,15 ;33452          CLR WR[0]
U 1BAE, 17A0,15 ;33453          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;CLR CRDY TO START TIMER AND
                ;33454                                                  ;ENABLE TIMEOUTS
                ;33455
U 1BAF, B7DA,95 ;33456          MOV LS[#28AEE] TO WR[1]                 ;SET UP TO WAIT 100ms
                ;33457  WAIT.T3D.100.1:
                ;33458          DEC WR[1],
U 1BB0, A102,B5 ;33459           DT(LONG)&SET.ALU.CC
U 1BB1, 09BB,01 ;33460          JMP.IF[NEQ] TO [WAIT.T3D.100.1]         ;WAIT SOME MORE
                ;33461
                ;33462
                ;33463  ;SET UP THE CSR TO BRANCH TO THE IDC ROUTINE THAT WILL RESET.TIMER
                ;33464
U 1BB2, 370E,15 ;33465          MOV LS[SETCSR.F7] TO WR[0]              ;SET UP THE CSR TO BRANCH TO
                ;33466                                                  ; THE CORRECT IDC ROUTINE
U 1BB3, C578,15 ;33467          BIC LS[BIT28] TO WR[0]                  ;ENABLE TIMEOUTS
                ;33468
U 1BB4, 17A0,15 ;33469          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]
                ;33470
                ;33471  ;CONTINUE TO BRANCH
U 1BB5, 379E,15 ;33472          MOV LS[SETCSR.R80] TO WR[0]             ;CRDY REMAINS CLR
U 1BB6, 370A,95 ;33473          MOV LS[SETCSR.F5] TO WR[1]
U 1BB7, AEC2,15 ;33474          BIS WR[1] TO WR[0]
U 1BB8, C578,15 ;33475          BIC LS[BIT28] TO WR[0]                  ;ENABLE TIMEOUTS
U 1BB9, 17A0,15 ;33476          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;33477                                                  ;F<2:0>=110
                ;33478  ;FUNC/RESET.TIMER
                ;33479  ;-------------------------------------------------------------------------------
                ;33480  ;-------------------------------------------------------------------------------
                ;33481  ;                               *******
                ;33482  ;                               * IDC *
                ;33483  ;                               *******
                ;33484  ;-------------------------------------------------------------------------------
                ;33485  ;018:
                ;33486  ;=000
                ;33487  ;DIAG.IDLE:
                ;33488  ;
                ;33489  ;       BEN0/F0,
                ;33490  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;33491  ;       BEN2/F2,
                ;33492  ;       NAD/DIAG.IDLE
                ;33493  ;-------------------------------------------------------------------------------
                ;33494  ;01F:
                ;33495  ;=111
                ;33496  ;
                ;33497  ;       BEN0/CRDY.L,
                ;33498  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;33499  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;33500  ;-------------------------------------------------------------------------------
                ;33501  ;079:
                ;33502  ;=0*1
                ;33503  ;
```

```
                ;33504  ;       NAD/GROUP1
                ;33505  ;-------------------------------------------------------------------------
                ;33506  ;182:
                ;33507  ;=0**
                ;33508  ;GROUP1:
                ;33509  ;
                ;33510  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;33511  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;33512  ;                                       ; FUNCTION BITS
                ;33513  ;-------------------------------------------------------------------------
                ;33514  ;186:
                ;33515  ;=1**
                ;33516  ;
                ;33517  ;       BEN0/F0,
                ;33518  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;33519  ;       BEN2/F2,
                ;33520  ;       NAD/GROUP1.F0
                ;33521  ;-------------------------------------------------------------------------
                ;33522  ;02D:
                ;33523  ;=101
                ;33524  ;RESET.TIMER:
                ;33525  ;
                ;33526  ;       FUNC/RESET.TIMER,       ;RESET THE TIMEOUT COUNTER...BE SURE CRDY
                ;33527  ;       NAD/XFER.REQ            ; IS SET
                ;33528  ;-------------------------------------------------------------------------
                ;33529  ;1D8:
                ;33530  ;XFER.REQ:
                ;33531  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;33532  ;       NAD/DIAG.WAIT
                ;33533  ;-------------------------------------------------------------------------
                ;33534  ;1D7:
                ;33535  ;DIAG.WAIT:
                ;33536  ;
                ;33537  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;33538  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;33539  ;-------------------------------------------------------------------------
                ;33540  ;159:
                ;33541  ;=*0*
                ;33542  ;DIAG.WAIT1:
                ;33543  ;
                ;33544  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;33545  ;                               ; COMMAND FROM THE CPU
                ;33546  ;-------------------------------------------------------------------------
                ;33547  ;15B:
                ;33548  ;=*1*
                ;33549  ;DIAG.WAIT2:
                ;33550  ;
                ;33551  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;33552  ;                               ; WAIT SOME MORE
                ;33553  ;-------------------------------------------------------------------------
                ;33554  WAIT.IDC.T3D.1:
U 1BBA, DB00,1A ;33555          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1BBB, 89BB,D4 ;33556          JMP [IDC.DONE.T3D.1]                    ;XFER REQ SET
U 1BBC, 09BB,A4 ;33557          JMP [WAIT.IDC.T3D.1]                    ;WAIT SOME MORE
                ;33558
```

```
                ;33559  IDC.DONE.T3D.1:
U 1BBD, B700,15 ;33560          MOV LS[SETCSR.F0] TO WR[0]               ;CLEAR CSR F<2:0>
U 1BBE, C578,15 ;33561          BIC LS[BIT28] TO WR[0]                   ;ENABLE TIMEOUTS
U 1BBF, 17A0,15 ;33562          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
U 1BC0, 90FA,15 ;33563          MISC2 [TRANSFER.GRANT]                   ;SEND GRANT TO CLR THE XFER REQ
                ;33564
U 1BC1, B7DC,95 ;33565          MOV LS[#5A6BF] TO WR[1]                  ;SET UP TO WAIT 200ms
                ;33566  WAIT.T3D.200:
                ;33567          DEC WR[1],
U 1BC2, A102,B5 ;33568           DT(LONG)&SET.ALU.CC
U 1BC3, 09BC,21 ;33569          JMP.IF[NEQ] TO [WAIT.T3D.200]            ;WAIT SOME MORE
                ;33570
                ;33571  READ.CSR.T3D.1:
U 1BC4, 9090,15 ;33572          MISC [SET.PORT.I.O]                      ;SELECT THE IDC
U 1BC5, 9780,15 ;33573          PORT.READ PORT.ADRS[CSR]                 ;SET UP TO READ THE CSR
U 1BC6, 3B32,15 ;33574          MOV PORT TO LS[PORT0]                    ;READ THE DATA FROM CSR AND
                ;33575                                                   ; SAVE IT IN  LS
U 1BC7, 3732,15 ;33576          MOV LS[PORT0] TO WR[0]                   ;SET UP RECEIVED DATA
U 1BC8, 3654,95 ;33577          MOV LS[BIT10] TO WR[1]                   ;SET UP EXPECTED DATA
U 1BC9, 0869,3C ;33578          JSR [CHECK.RESULT]                       ;CHECK THE DATA
U 1BCA, 89BA,A4 ;33579          JMP [LOOP.T3D.1]                         ;LOOP HERE IF ERR & LOE IS SET
                ;33580
U 1BCB, FF82,15 ;33581          INC LS[ERROR.NUMBER]                     ;ERROR 2
                ;33582
                ;33583  LOOP.T3D.2:
U 1BCC, 8872,EC ;33584          JSR [DIAG.CODE]                          ;INIT THE IDC AND FORCE
                ;33585                                                   ; IT TO DIAG.IDLE WITH
                ;33586                                                   ; TIMEOUTS DISABLED
                ;33587
U 1BCD, B7E4,15 ;33588          MOV LS[#10000080] TO WR[0]               ;SET CRDY WITH TIMEOUTS
                ;33589                                                   ;DISABLED
U 1BCE, 17A0,15 ;33590          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;WRITE THE CSR
                ;33591
                ;33592
U 1BCF, 2F80,15 ;33593          CLR WR[0]
U 1BD0, 17A0,15 ;33594          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;CLR CRDY TO START TIMER AND
                ;33595                                                   ;ENABLE TIMEOUTS
                ;33596
U 1BD1, B7DA,95 ;33597          MOV LS[#28AEE] TO WR[1]                  ;SET UP TO WAIT 100ms
                ;33598  WAIT.T3D.100.2:
                ;33599          DEC WR[1],
U 1BD2, A102,B5 ;33600           DT(LONG)&SET.ALU.CC
U 1BD3, 89BD,21 ;33601          JMP.IF[NEQ] TO [WAIT.T3D.100.2]          ;WAIT SOME MORE
                ;33602
                ;33603  ;SET UP THE CSR TO BRANCH TO THE IDC ROUTINE THAT WILL RESET.TIMER
                ;33604
U 1BD4, 370E,15 ;33605          MOV LS[SETCSR.F7] TO WR[0]               ;SET UP THE CSR TO BRANCH TO
                ;33606                                                   ; THE CORRECT IDC ROUTINE
U 1BD5, C578,15 ;33607          BIC LS[BIT28] TO WR[0]                   ;ENABLE TIMEOUTS
                ;33608
U 1BD6, 17A0,15 ;33609          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]     ;CRDY WILL BE CLEAR AND TIMER
                ;33610                                                   ;WILL START
                ;33611  ;CONTINUE TO BRANCH
U 1BD7, 379E,15 ;33612          MOV LS[SETCSR.R80] TO WR[0]              ;CRDY REMAINS  CLR
U 1BD8, 370A,95 ;33613          MOV LS[SETCSR.F5] TO WR[1]
```

```
U 1BD9, AEC2,15 ;33614          BIS WR[1] TO WR[0]
U 1BDA, C578,15 ;33615          BIC LS[BIT28] TO WR[0]                  ;ENABLE TIMEOUTS
U 1BDB, 17A0,15 ;33616          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
                ;33617                                                  ;F<2:0>=101
                ;33618  ;RESET.TIMER
                ;33619  ;-------------------------------------------------------------------------
                ;33620  ;-------------------------------------------------------------------------
                ;33621  ;                               *******
                ;33622  ;                               * IDC *
                ;33623  ;                               *******
                ;33624  ;-------------------------------------------------------------------------
                ;33625  ;018:
                ;33626  ;=000
                ;33627  ;DIAG.IDLE:
                ;33628  ;
                ;33629  ;       BEN0/F0,
                ;33630  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;33631  ;       BEN2/F2,
                ;33632  ;       NAD/DIAG.IDLE
                ;33633  ;-------------------------------------------------------------------------
                ;33634  ;01F:
                ;33635  ;=111
                ;33636  ;
                ;33637  ;       BEN0/CRDY.L,
                ;33638  ;       BEN2/MAINT,             ;BRANCH TO THE CORRECT IDC MICROCODE ROUTINE
                ;33639  ;       NAD/TEST.FUNC7          ; DEPENDENT ON CSR <CRDY> AND <MAINT>
                ;33640  ;-------------------------------------------------------------------------
                ;33641  ;079:
                ;33642  ;=0*1
                ;33643  ;
                ;33644  ;       NAD/GROUP1
                ;33645  ;-------------------------------------------------------------------------
                ;33646  ;182:
                ;33647  ;=0**
                ;33648  ;GROUP1:
                ;33649  ;
                ;33650  ;       BEN2/R80.FORMAT.H,              ;WHEN THE R80 FORMAT BIT SETS..BRANCH
                ;33651  ;       NAD/GROUP1                      ; TO NEXT WORD AND THEN BRANCH ON THE
                ;33652  ;                                       ; FUNCTION BITS
                ;33653  ;-------------------------------------------------------------------------
                ;33654  ;186:
                ;33655  ;=1**
                ;33656  ;
                ;33657  ;       BEN0/F0,
                ;33658  ;       BEN1/F1,                ;BRANCH ON THE CSR F<2:0> BITS
                ;33659  ;       BEN2/F2,
                ;33660  ;       NAD/GROUP1.F0
                ;33661  ;-------------------------------------------------------------------------
                ;33662  ;02D:
                ;33663  ;=101
                ;33664  ;RESET.TIMER:
                ;33665  ;
                ;33666  ;       FUNC/RESET.TIMER,       ;RESET THE TIMEOUT COUNTER...BE SURE CRDY
                ;33667  ;       NAD/XFER.REQ            ; IS SET
                ;33668  ;-------------------------------------------------------------------------
```

```
                ;33669  ;1D8:
                ;33670  ;XFER.REQ:
                ;33671  ;       UCMD/SET.XFER.RQST,             ;SEND XFER REQ TO THE CPU
                ;33672  ;       NAD/DIAG.WAIT
                ;33673  ;-------------------------------------------------------------------------
                ;33674  ;1D7:
                ;33675  ;DIAG.WAIT:
                ;33676  ;
                ;33677  ;       BEN1/XFER.REQ,          ;WAIT FOR THE CPU TO ISSUE XFER GRANT
                ;33678  ;       NAD/DIAG.WAIT1          ; BEFORE RETURNING TO DIAG.IDLE
                ;33679  ;-------------------------------------------------------------------------
                ;33680  ;159:
                ;33681  ;=*0*
                ;33682  ;DIAG.WAIT1:
                ;33683  ;
                ;33684  ;       NAD/DIAG.IDLE           ;RETURN TO DIAG.IDLE TO WAIT FOR NEXT COMMAND
                ;33685  ;                               ; COMMAND FROM THE CPU
                ;33686  ;-------------------------------------------------------------------------
                ;33687  ;15B:
                ;33688  ;=*1*
                ;33689  ;DIAG.WAIT2:
                ;33690  ;
                ;33691  ;       NAD/DIAG.WAIT           ;XFER GRANT HAS NOT BEEN ISSUED....
                ;33692  ;                               ; WAIT SOME MORE
                ;33693  ;-------------------------------------------------------------------------
                ;33694  WAIT.IDC.T3D.2:
U 1BDC, DB00,1A ;33695          SKIP.IF[NO.FAST.INTERRUPT]              ;WAIT FOR XFER REQ FROM IDC
U 1BDD, 09BD,F4 ;33696          JMP [IDC.DONE.T3D.2]                    ;XFER REQ SET
U 1BDE, 09BD,C4 ;33697          JMP [WAIT.IDC.T3D.2]                    ;WAIT SOME MORE
                ;33698
                ;33699  IDC.DONE.T3D.2:
U 1BDF, B700,15 ;33700          MOV LS[SETCSR.F0] TO WR[0]              ;CLEAR CSR F<2:0>
U 1BE0, C578,15 ;33701          BIC LS[BIT28] TO WR[0]                  ;ENABLE TIMEOUTS
U 1BE1, 17A0,15 ;33702          PORT.WRITE PORT.ADRS[CSR] WITH WR[0]    ;WRITE THE CSR
U 1BE2, 90FA,15 ;33703          MISC2 [TRANSFER.GRANT]                  ;SEND GRANT TO CLR THE XFER REQ
                ;33704
U 1BE3, B7DA,95 ;33705          MOV LS[#28AEE] TO WR[1]                 ;SET UP TO WAIT 100ms
                ;33706  WAIT.T3D.100:
                ;33707          DEC WR[1],
U 1BE4, A102,B5 ;33708           DT(LONG)&SET.ALU.CC
U 1BE5, 89BE,41 ;33709          JMP.IF[NEQ] TO [WAIT.T3D.100]           ;WAIT SOME MORE
                ;33710
                ;33711  READ.CSR.T3D.2:
U 1BE6, 9090,15 ;33712          MISC [SET.PORT.I.O]                     ;SELECT THE IDC
U 1BE7, 9780,15 ;33713          PORT.READ PORT.ADRS[CSR]                ;SET UP TO READ THE CSR
U 1BE8, 3B32,15 ;33714          MOV PORT TO LS[PORT0]                   ;READ THE DATA FROM CSR AND
                ;33715                                                  ; SAVE IT IN  LS
U 1BE9, 3732,15 ;33716          MOV LS[PORT0] TO WR[0]                  ;SET UP RECEIVED DATA
U 1BEA, 2F82,95 ;33717          CLR WR[1]                               ;SET UP EXPECTED DATA
U 1BEB, 0869,3C ;33718          JSR [CHECK.RESULT]                      ;CHECK THE DATA
U 1BEC, 89BC,C4 ;33719          JMP [LOOP.T3D.2]                        ;LOOP HERE IF ERR & LOE IS SET
                ;33720
                ;33721
U 1BED, 8875,3C ;33722          JSR [CLEANUP]                           ;CLEANUP THE CONDITIONS SET
                ;33723                                                  ; BY THIS TEST
```

```
;33724  END.T3D:
;33725
```

```
                ;33726  .PAGE
                ;33727
                ;33728  END.SECTION:
U 1BEE, 365C,15 ;33729          MOV LS[BIT14] TO WR[0]                  ;SET UP WR 0 FOR END OF SECTION
U 1BEF, 3E80,15 ;33730          MOV WR[0] TO LS[CONTROL.STATUS]         ;SET UP CONTROL AND STATUS
                ;33731                                                  ; WORD TO REPORT END OF SECTION
U 1BF0, 10E0,15 ;33732          MISC [SET.CP.ATTN]                      ;ISSUE CPU ATTN TO CONSOLE
                ;33733  WAIT.EOS:
U 1BF1, 09BF,14 ;33734          JMP [WAIT.EOS]                          ;LOOP HERE WAITING FOR CONSOLE
                ;33735                                                  ; TO RESPOND
                ;33736
                ;33737
                ;33738
                ;33739
                ;33740
```

Cross Reference Listing - Field Names and Defined Values

Cross Reference Listing - Macro Names

Cross Reference Listing - Expression Names

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
C 0000	2453:	2454:	2455:	2456:	2457:	2458:	2459:	2460:
C 0008	2461:	2462:	2463:	2464:	2465:	2466:	2467:	2468:
C 0010	2472:	2473:	2474:	2475:	2476:	2477:	2478:	2479:
C 0018	2480:	2481:	2482:	2483:	2484:	2485:	2486:	2487:
C 0020	2496:	2497:	2498:	2499:	2500:	2501:	2502:	2503:
C 0028	2504:	2505:	2506:	2507:	2508:	2509:	2510:	2511:
C 0030	2512:	2513:	2514:	2515:	2516:	2517:	2518:	2519:
C 0038	2520:	2521:	2522:	2523:	2524:	2525:	2526:	2527:
C 0040	2536:	2537:	2538:	2539:	2540:	2541:	2542:	2543:
C 0048	2544:	2545:	2546:	2547:	2548:	2549:	2550:	2551:
C 0050	2552:	2553:	2554:	2555:	2556:	2557:	2558:	2559:
C 0058	2560:	2561:	2562:	2563:	2564:	2565:	2566:	2567:
C 0060	2575:	2576:	2577:	2578:	2579:	2580:	2581:	2582:
C 0068	2583:	2584:	2585:	2586:	2587:	2588:	2589:	2590:
C 0070	2591:	2592:	2593:	2594:	2595:	2596:	2597:	2598:
C 0078	2599:	2600:	2601:	2602:	2603:	2604:	2605:	2606:
C 0080	2613:	2615:	2617:	2619:	2622:	2624:	2626:	2628:
C 0088	2631:	2633:	2635:	2637:	2640:	2642:	2644:	2646:
C 0090	2649:	2651:	2653:	2655:	2658:	2660:	2662:	2664:
C 0098	2667:	2669:	2671:	2673:	2676:	2678:	2680:	2682:
C 00A0	2685:	2687:	2689:	2691:	2694:	2696:	2698:	2700:
C 00A8	2703:	2705:	2707:	2709:	2712:	2714:	2716:	2718:
C 00B0	2721:	2723:	2725:	2727:	2730:	2732:	2734:	2736:
C 00B8	2739:	2741:	2743:	2745:	2748:	2750:	2752:	2754:
C 00C0	2762:	2763:	2764:	2765:	2766:	2767:	2768:	2769:
C 00C8	2772:	2773:	2774:	2775:	2776:	2777:	2778:	2779:
C 00D0	2782:	2783:	2784:	2785:	2786:	2787:	2788:	2789:
C 00D8	2792:	2793:	2794:	2795:	2796:	2797:	2798:	2799:
C 00E0	2803:	2804:	2805:	2806:	2807:	2808:	2809:	2810:
C 00E8	2812:	2813:	2814:	2815:	2816:	2817:	2818:	2819:
C 00F0	2823:	2824:	2825:	2826:	2827:	2828:	2829:	2830:
C 00F8	2833:	2834:	2835:	2836:	2837:	2838:	2839:	2840:
C 0100	2848:	2849:	2850:	2851:	2853:	2854:	2855:	2856:
C 0108	2858:	2859:	2860:	2861:	2863:	2864:	2865:	2866:
C 0110	2869:	2870:	2871:	2872:	2874:	2875:	2876:	2877:
C 0118	2879:	2880:	2881:	2882:	2884:	2885:	2886:	2887:
C 0120	2890:	2891:	2892:	2893:	2895:	2896:	2897:	2898:
C 0128	2900:	2901:	2902:	2903:	2905:	2906:	2907:	2908:
C 0130	2911:	2912:	2913:	2914:	2916:	2917:	2918:	2919:
C 0138	2921:	2922:	2923:	2924:	2926:	2927:	2928:	2929:
C 0140	2932:	2933:	2934:	2935:	2937:	2938:	2939:	2940:
C 0148	2942:	2943:	2944:	2945:	2947:	2948:	2949:	2950:
C 0150	2953:	2954:	2955:	2956:	2958:	2959:	2960:	2961:
C 0158	2963:	2964:	2965:	2966:	2968:	2969:	2970:	2971:
C 0160	2974:	2975:	2976:	2977:	2979:	2980:	2981:	2982:
C 0168	2984:	2985:	2986:	2987:	2989:	2990:	2991:	2992:
C 0170	2995:	2996:	2997:	2998:	3000:	3001:	3002:	3003:
C 0178	3005:	3006:	3007:	3008:	3010:	3011:	3012:	3013:
C 0180	3023:	3024:	3025:	3026:	3028:	3029:	3030:	3031:
C 0188	3033:	3034:	3035:	3036:	3038:	3039:	3040:	3041:
C 0190	3044:	3045:	3046:	3047:	3049:	3050:	3051:	3052:
C 0198	3054:	3055:	3056:	3057:	3059:	3060:	3061:	3062:
C 01A0	3065:	3066:	3067:	3068:	3070:	3071:	3072:	3073:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
C 01A8	3075:	3076:	3077:	3078:	3080:	3081:	3082:	3083:
C 01B0	3086:	3087:	3088:	3089:	3091:	3092:	3093:	3094:
C 01B8	3096:	3097:	3098:	3099:	3101:	3102:	3103:	3104:
C 01C0	3107:	3108:	3109:	3110:	3112:	3113:	3114:	3115:
C 01C8	3117:	3118:	3119:	3120:	3122:	3123:	3124:	3125:
C 01D0	3128:	3129:	3130:	3131:	3133:	3134:	3135:	3136:
C 01D8	3138:	3139:	3140:	3141:	3143:	3144:	3145:	3146:
C 01E0	3149:	3150:	3151:	3152:	3154:	3155:	3156:	3157:
C 01E8	3159:	3160:	3161:	3162:	3164:	3165:	3166:	3167:
C 01F0	3170:	3171:	3172:	3173:	3175:	3176:	3177:	3178:
C 01F8	3180:	3181:	3182:	3183:	3185:	3186:	3187:	3188:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0000	4788:	4669:	4670:	4671:	4672:	4673:	4674:	4675:
U 0008	4676:	4677:	4678:	4679:	4680:	4681:	4682:	4683:
U 0010	4684:	4685:	4686:	4687:	4688:	4689:	4690:	4691:
U 0018	4692:	4693:	4694:	4695:	4696:	4697:	4698:	4699:
U 0020	4700:	4701:	4702:	4703:	4704:	4705:	4706:	4707:
U 0028	4708:	4709:	4710:	4711:	4712:	4713:	4714:	4715:
U 0030	4716:	4717:	4718:	4719:	4720:	4721:	4722:	4723:
U 0038	4724:	4725:	4726:	4727:	4728:	4729:	4730:	4732:
U 0040	4734:	4736:	4738:	4740:	4742:	4744:	4746:	4748:
U 0048	4750:	4752:	4754:	4756:	4758:	4760:	4762:	4764:
U 0050	4797:	4799:	4801:	4804:	4807:	4811:	4813:	4815:
U 0058	4817:	4819:	4821:	4823:	4825:	4827:	4829:	4831:
U 0060	4833:	4835:	4837:	4839:	4841:	4843:	4844:	4845:
U 0068	4846:	4847:	4848:	4849:	4850:	4851:	4852:	4853:
U 0070	4883:	4885:	4887:	4888:	4890:	4891:	4893:	4894:
U 0078	4896:	4897:	4899:	4900:	4902:	4903:	4905:	4906:
U 0080	4908:	4909:	4911:	4912:	4914:	4915:	4917:	4918:
U 0088	4920:	4921:	4923:	4924:	4926:	4927:	4929:	4930:
U 0090	4932:	4933:	4935:	4936:	4938:	4939:	4941:	4942:
U 0098	4944:	4945:	4947:	4948:	4950:	4951:	4953:	4954:
U 00A0	4956:	4957:	4959:	4960:	4962:	4963:	4965:	4966:
U 00A8	4968:	4969:	4971:	4972:	4974:	4975:	4977:	4978:
U 00B0	4980:	4981:	4983:	4984:	4986:	4987:	4989:	4990:
U 00B8	4992:	4993:	4995:	4996:	4998:	4999:	5001:	5002:
U 00C0	5004:	5005:	5007:	5008:	5010:	5011:	5013:	5014:
U 00C8	5016:	5017:	5019:	5020:	5022:	5023:	5025:	5026:
U 00D0	5028:	5029:	5031:	5032:	5034:	5035:	5037:	5038:
U 00D8	5040:	5041:	5043:	5044:	5046:	5047:	5049:	5050:
U 00E0	5052:	5053:	5055:	5056:	5058:	5059:	5061:	5062:
U 00E8	5064:	5065:	5067:	5068:	5070:	5071:	5073:	5074:
U 00F0	5076:	5077:	5079:	5080:	5082:	5083:	5085:	5086:
U 00F8	5088:	5089:	5091:	5092:	5094:	5095:	5097:	5098:
U 0100	5100:	5101:	5103:	5104:	5106:	5107:	5109:	5110:
U 0108	5112:	5113:	5115:	5116:	5118:	5119:	5121:	5122:
U 0110	5124:	5125:	5127:	5128:	5130:	5131:	5133:	5134:
U 0118	5136:	5137:	5139:	5140:	5142:	5143:	5145:	5146:
U 0120	5148:	5149:	5151:	5152:	5154:	5155:	5157:	5158:
U 0128	5160:	5161:	5163:	5164:	5166:	5167:	5169:	5170:
U 0130	5172:	5173:	5175:	5176:	5178:	5179:	5181:	5182:
U 0138	5184:	5185:	5187:	5188:	5190:	5191:	5193:	5194:
U 0140	5196:	5197:	5199:	5200:	5202:	5203:	5205:	5206:
U 0148	5208:	5209:	5211:	5212:	5214:	5215:	5217:	5218:
U 0150	5220:	5221:	5223:	5224:	5226:	5227:	5229:	5230:
U 0158	5232:	5233:	5235:	5236:	5238:	5239:	5241:	5242:
U 0160	5244:	5245:	5254:	5256:	5258:	5259:	5261:	5262:
U 0168	5264:	5265:	5267:	5268:	5270:	5271:	5273:	5274:
U 0170	5276:	5277:	5279:	5280:	5282:	5283:	5285:	5286:
U 0178	5288:	5289:	5291:	5292:	5294:	5295:	5297:	5298:
U 0180	5300:	5301:	5303:	5304:	5306:	5307:	5309:	5310:
U 0188	5312:	5313:	5315:	5316:	5318:	5319:	5321:	5322:
U 0190	5324:	5325:	5327:	5328:	5330:	5331:	5333:	5334:
U 0198	5336:	5337:	5339:	5340:	5342:	5343:	5345:	5346:
U 01A0	5348:	5349:	5351:	5352:	5354:	5355:	5357:	5358:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 01A8	5360:	5361:	5363:	5364:	5366:	5367:	5369:	5370:
U 01B0	5372:	5373:	5375:	5376:	5378:	5379:	5381:	5382:
U 01B8	5384:	5385:	5387:	5388:	5390:	5391:	5393:	5394:
U 01C0	5396:	5397:	5399:	5400:	5402:	5403:	5405:	5406:
U 01C8	5408:	5409:	5411:	5412:	5414:	5415:	5417:	5418:
U 01D0	5420:	5421:	5423:	5424:	5426:	5427:	5429:	5430:
U 01D8	5432:	5433:	5435:	5436:	5438:	5439:	5441:	5442:
U 01E0	5444:	5445:	5447:	5448:	5450:	5451:	5453:	5454:
U 01E8	5456:	5457:	5459:	5460:	5462:	5463:	5465:	5466:
U 01F0	5468:	5469:	5471:	5472:	5474:	5475:	5477:	5478:
U 01F8	5480:	5481:	5483:	5484:	5486:	5487:	5489:	5490:
U 0200	5492:	5493:	5495:	5496:	5498:	5499:	5501:	5502:
U 0208	5504:	5505:	5507:	5508:	5510:	5511:	5513:	5514:
U 0210	5516:	5517:	5519:	5520:	5522:	5523:	5525:	5526:
U 0218	5528:	5529:	5531:	5532:	5534:	5535:	5537:	5538:
U 0220	5540:	5541:	5543:	5544:	5546:	5547:	5549:	5550:
U 0228	5552:	5553:	5555:	5556:	5558:	5559:	5561:	5562:
U 0230	5564:	5565:	5567:	5568:	5570:	5571:	5573:	5574:
U 0238	5576:	5577:	5579:	5580:	5582:	5583:	5585:	5586:
U 0240	5588:	5589:	5591:	5592:	5594:	5595:	5597:	5598:
U 0248	5600:	5601:	5603:	5604:	5606:	5607:	5609:	5610:
U 0250	5612:	5613:	5615:	5616:				
U 0258 - 05FF Unused								
U 0600	5639:	5640:	5642:	5645:	5646:	5647:	5661:	5662:
U 0608	5723:	5725:	5727:	5729:	5730:	5785:	5786:	5788:
U 0610	5790:	5792:	5795:	5797:	5798:	5799:	5803:	5804:
U 0618	5805:	5809:	5810:	5811:	5813:	5816:	5817:	5872:
U 0620	5874:	5875:	5878:	5880:	5884:	5886:	5890:	5896:
U 0628	5898:	5899:	5905:	5907:	5909:	5910:	5911:	5917:
U 0630	5918:	5919:	5920:	5921:	5922:	5923:	5926:	5928:
U 0638	5929:	5933:	5983:	5985:	5987:	5989:	5992:	5993:
U 0640	5995:	5996:	6051:	6053:	6054:	6057:	6059:	6063:
U 0648	6065:	6069:	6075:	6077:	6078:	6084:	6085:	6086:
U 0650	6087:	6088:	6089:	6092:	6142:	6144:	6147:	6149:
U 0658	6152:	6153:	6155:	6156:	6204:	6209:	6211:	6213:
U 0660	6214:	6215:	6265:	6267:	6270:	6274:	6276:	6277:
U 0668	6316:	6317:	6318:	6321:	6322:	6323:	6326:	6327:
U 0670	6328:	6331:	6332:	6333:	6336:	6337:	6341:	6342:
U 0678	6343:	6382:	6383:	6384:	6388:	6389:	6390:	6394:
U 0680	6395:	6396:	6400:	6401:	6405:	6406:	6410:	6413:
U 0688	6415:	6462:	6463:	6464:	6465:	6466:	6513:	6514:
U 0690	6515:	6516:	6517:	6585:	6587:	6590:	6591:	6593:
U 0698	6595:	6596:	6597:	6599:	6603:	6605:	6607:	6611:
U 06A0	6612:	6615:	6616:	6618:	6620:	6621:	6623:	6625:
U 06A8	6630:	6631:	6633:	6635:	6636:	6642:	6643:	6646:
U 06B0	6647:	6648:	6653:	6654:	6656:	6657:	6659:	6661:
U 06B8	6662:	6664:	6666:	6668:	6670:	6672:	6679:	6680:
U 06C0	6682:	6685:	6698:	6699:	6701:	6702:	6703:	6704:
U 06C8	6705:	6706:	6707:	6708:	6709:	6713:	6716:	6717:
U 06D0	6718:	6719:	6720:	6721:	6722:	6723:	6724:	6725:
U 06D8	6726:	6727:	6728:	6729:	6730:	6731:	6734:	6737:
U 06E0	6740:	6742:	6743:	6744:	6745:	6748:	6751:	6754:
U 06E8	6756:	6757:	6758:	6760:	6761:	6762:	6764:	6766:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 06F0	6767:	6768:	6769:	6772:	6773:	6776:	6778:	6779:
U 06F8 - 06FF Unused								
U 0700	6832:	6833:	6836:	6837:	6839:	6841:	6842:	6845:
U 0708	6846:	6848:	6849:	6850:	6851:	6854:	6855:	6857:
U 0710	6859:	6860:	6862:	6863:	6867:	6868:	6869:	6871:
U 0718	6873:	6875:	6880:	6881:	6884:	6885:	6887:	6889:
U 0720	6892:	6893:	6895:	6896:	6898:	6900:	6901:	6903:
U 0728	6905:	6906:	6908:	6912:	6914:	6916:	6966:	6967:
U 0730	6968:	6969:	6970:	6972:	6973:	6975:	6980:	6982:
U 0738	6983:	6984:	6985:	6987:	6991:	7040:	7041:	7042:
U 0740	7043:	7045:	7046:	7047:	7049:	7050:	7201:	7202:
U 0748	7203:	7208:	7209:	7210:	7211:	7212:	7213:	7214:
U 0750	7215:	7216:	7217:	7260:	7262:	7263:	7264:	7322:
U 0758	7324:	7328:	7330:	7332:	7335:	7336:	7337:	7339:
U 0760	7340:	7342:	7346:	7347:	7348:	7349:	7350:	7351:
U 0768	7353:	7354:	7355:	7356:	7357:	7358:	7360:	7361:
U 0770	7362:	7363:	7364:	7365:	7367:	7368:	7369:	7370:
U 0778	7371:	7372:	7374:	7375:	7376:	7377:	7378:	7379:
U 0780	7381:	7382:	7383:	7384:	7385:	7386:	7461:	7463:
U 0788	7467:	7469:	7472:	7473:	7474:	7476:	7477:	7478:
U 0790	7479:	7485:	7486:	7489:	7490:	7492:	7493:	7494:
U 0798	7495:	7496:	7498:	7500:	7503:	7504:	7507:	7508:
U 07A0	7511:	7512:	7514:	7515:	7516:	7517:	7518:	7520:
U 07A8	7522:	7525:	7526:	7529:	7530:	7531:	7533:	7536:
U 07B0	7538:	7539:	7541:	7542:	7543:	7544:	7545:	7546:
U 07B8	7548:	7552:	7553:	7554:	7555:	7557:	7671:	7673:
U 07C0	7677:	7679:	7682:	7685:	7686:	7687:	7690:	7691:
U 07C8	7693:	7694:	7697:	7698:	7699:	7700:	7701:	7702:
U 07D0	7703:	7704:	7705:	7706:	7710:	7711:	7712:	7713:
U 07D8	7714:	7715:	7716:	7717:	7718:	7719:	7720:	7721:
U 07E0	7723:	7724:	7725:	7726:	7849:	7851:	7855:	7857:
U 07E8	7860:	7863:	7864:	7866:	7867:	7869:	7870:	7873:
U 07F0	7875:	7876:	7879:	7880:	7881:	7882:	7883:	7886:
U 07F8	7887:	7888:	7890:	7891:	7892:	7893:	7897:	7898:
U 0800	7899:	7900:	7901:	7904:	7905:	7906:	7908:	7909:
U 0808	7910:	7911:	7915:	7916:	7917:	7918:	7919:	7922:
U 0810	7923:	7924:	7926:	7927:	7928:	7929:	7933:	7934:
U 0818	7935:	7936:	7937:	7940:	7941:	7942:	7944:	7945:
U 0820	7946:	7947:	7951:	7952:	7953:	7954:	7955:	7958:
U 0828	7959:	7960:	7962:	7963:	7964:	7965:	7969:	7970:
U 0830	7971:	7972:	7973:	7976:	7977:	7978:	7980:	7981:
U 0838	7982:	7983:	7986:	7989:	7990:	7991:	7992:	7993:
U 0840	7994:	7995:	7996:	7998:	7999:	8000:	8001:	8002:
U 0848	8146:	8148:	8152:	8154:	8157:	8160:	8161:	8163:
U 0850	8164:	8166:	8167:	8170:	8172:	8173:	8175:	8178:
U 0858	8181:	8182:	8183:	8185:	8186:	8187:	8188:	8191:
U 0860	8194:	8197:	8198:	8199:	8201:	8202:	8203:	8204:
U 0868	8207:	8210:	8213:	8214:	8215:	8217:	8218:	8219:
U 0870	8220:	8223:	8226:	8229:	8230:	8231:	8233:	8234:
U 0878	8235:	8236:	8239:	8242:	8245:	8246:	8247:	8249:
U 0880	8250:	8251:	8252:	8255:	8256:	8257:	8260:	8261:
U 0888	8262:	8263:	8264:	8265:	8266:	8267:	8268:	8269:
U 0890	8271:	8272:	8273:	8274:	8277:	8278:	8279:	8282:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0898	8283:	8284:	8285:	8286:	8287:	8288:	8289:	8290:
U 08A0	8291:	8293:	8294:	8295:	8296:	8298:	8299:	8300:
U 08A8	8301:	8304:	8477:	8479:	8483:	8485:	8487:	8489:
U 08B0	8490:	8493:	8494:	8496:	8498:	8501:	8503:	8504:
U 08B8	8506:	8507:	8509:	8510:	8512:	8514:	8516:	8517:
U 08C0	8554:	8555:	8556:	8557:	8558:	8559:	8560:	8561:
U 08C8	8562:	8564:	8565:	8567:	8568:	8569:	8570:	8571:
U 08D0	8572:	8573:	8576:	8577:	8578:	8581:	8582:	8583:
U 08D8	8584:	8585:	8586:	8587:	8588:	8589:	8590:	8593:
U 08E0	8594:	8595:	8598:	8599:	8600:	8601:	8602:	8603:
U 08E8	8604:	8605:	8606:	8607:	8610:	8611:	8612:	8615:
U 08F0	8616:	8617:	8618:	8619:	8620:	8621:	8622:	8623:
U 08F8	8624:	8626:	8725:	8727:	8731:	8733:	8736:	8739:
U 0900	8740:	8743:	8744:	8746:	8747:	8752:	8756:	8757:
U 0908	8759:	8761:	8762:	8763:	8796:	8797:	8798:	8800:
U 0910	8801:	8802:	8803:	8804:	8805:	8806:	8808:	8811:
U 0918	8815:	8816:	8818:	8820:	8821:	8822:	8854:	8855:
U 0920	8856:	8858:	8859:	8860:	8861:	8862:	8864:	8865:
U 0928	8867:	8869:	8873:	8874:	8876:	8878:	8879:	8880:
U 0930	8913:	8914:	8916:	8917:	8918:	8919:	8920:	8922:
U 0938	8923:	8925:	9026:	9028:	9032:	9034:	9037:	9040:
U 0940	9041:	9042:	9045:	9046:	9048:	9049:	9050:	9052:
U 0948	9055:	9056:	9057:	9058:	9090:	9091:	9092:	9093:
U 0950	9094:	9095:	9097:	9099:	9100:	9101:	9102:	9105:
U 0958	9106:	9107:	9108:	9110:	9111:	9112:	9114:	9116:
U 0960	9117:	9118:	9119:	9122:	9123:	9124:	9125:	9128:
U 0968	9129:	9130:	9131:	9134:	9246:	9248:	9252:	9254:
U 0970	9257:	9260:	9261:	9265:	9266:	9268:	9270:	9273:
U 0978	9274:	9276:	9279:	9280:	9282:	9283:	9284:	9286:
U 0980	9287:	9288:	9289:	9291:	9293:	9295:	9296:	9297:
U 0988	9300:	9302:	9303:	9304:	9305:	9341:	9342:	9343:
U 0990	9345:	9346:	9347:	9351:	9352:	9353:	9355:	9356:
U 0998	9357:	9358:	9361:	9362:	9364:	9502:	9504:	9508:
U 09A0	9510:	9513:	9516:	9517:	9520:	9521:	9523:	9524:
U 09A8	9526:	9529:	9530:	9532:	9535:	9574:	9575:	9576:
U 09B0	9578:	9579:	9580:	9582:	9583:	9584:	9586:	9587:
U 09B8	9588:	9589:	9591:	9594:	9595:	9597:	9598:	9599:
U 09C0	9600:	9602:	9603:	9649:	9650:	9651:	9653:	9654:
U 09C8	9655:	9658:	9659:	9660:	9662:	9663:	9664:	9665:
U 09D0	9667:	9670:	9671:	9673:	9674:	9676:	9677:	9729:
U 09D8	9730:	9731:	9733:	9734:	9735:	9737:	9738:	9739:
U 09E0	9741:	9742:	9743:	9744:	9746:	9802:	9804:	9808:
U 09E8	9810:	9813:	9816:	9817:	9820:	9821:	9823:	9824:
U 09F0	9828:	9829:	9830:	9832:	9834:	9836:	9837:	9842:
U 09F8	9845:	9846:	9849:	9850:	9851:	9853:	9854:	9855:
U 0A00	9856:	9858:	9960:	9962:	9966:	9968:	9971:	9974:
U 0A08	9975:	9978:	9979:	9981:	9982:	9984:	9985:	9987:
U 0A10	9990:	9992:	9993:	9997:	9998:	10000:	10001:	10002:
U 0A18	10003:	10004:	10077:	10078:	10079:	10082:	10083:	10084:
U 0A20	10087:	10088:	10089:	10091:	10093:	10096:	10097:	10098:
U 0A28	10101:	10102:	10103:	10105:	10106:	10107:	10108:	10109:
U 0A30	10111:	10112:	10113:	10116:	10117:	10119:	10226:	10228:
U 0A38	10232:	10234:	10237:	10240:	10241:	10244:	10245:	10247:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0A40	10248:	10250:	10253:	10254:	10255:	10257:	10290:	10291:
U 0A48	10295:	10296:	10297:	10298:	10299:	10300:	10340:	10341:
U 0A50	10342:	10343:	10344:	10345:	10347:	10348:	10349:	10351:
U 0A58	10352:	10353:	10354:	10356:	10359:	10360:	10362:	10364:
U 0A60	10365:	10366:	10367:	10368:	10369:	10409:	10410:	10411:
U 0A68	10412:	10413:	10415:	10416:	10417:	10419:	10420:	10421:
U 0A70	10422:	10423:	10532:	10534:	10538:	10540:	10543:	10546:
U 0A78	10547:	10552:	10554:	10555:	10556:	10557:	10558:	10559:
U 0A80	10560:	10562:	10566:	10567:	10569:	10570:	10572:	10574:
U 0A88	10575:	10578:	10579:	10581:	10582:	10583:	10586:	10588:
U 0A90	10589:	10591:	10592:	10594:	10596:	10597:	10598:	10599:
U 0A98	10602:	10603:	10604:	10606:	10607:	10609:	10610:	10611:
U 0AA0	10612:	10613:	10615:	10617:	10621:	10622:	10624:	10626:
U 0AA8	10628:	10629:	10630:	10632:	10633:	10635:	10637:	10638:
U 0AB0	10640:	10642:	10643:	10645:	10647:	10648:	10650:	10653:
U 0AB8	10656:	10658:	10659:	10660:	10661:	10662:	10663:	10667:
U 0AC0	10669:	10670:	10671:	10672:	10673:	10674:	10675:	10677:
U 0AC8	10682:	10684:	10685:	10687:	10688:	10690:	10692:	10694:
U 0AD0	10696:	10697:	10699:	10702:	10704:	10708:	10709:	10711:
U 0AD8	10712:	10714:	10716:	10718:	10720:	10723:	10725:	10726:
U 0AE0	10728:	10729:	10731:	10732:	10734:	10735:	10737:	10738:
U 0AE8	10740:	10746:	10747:	10749:	10752:	10952:	10954:	10958:
U 0AF0	10960:	10963:	10966:	10967:	10971:	10972:	10974:	10975:
U 0AF8	10977:	10980:	10982:	10983:	10985:	10988:	10992:	10994:
U 0B00	10995:	10996:	10997:	10999:	11003:	11004:	11006:	11007:
U 0B08	11008:	11009:	11077:	11078:	11079:	11082:	11083:	11084:
U 0B10	11087:	11088:	11090:	11092:	11093:	11094:	11095:	11096:
U 0B18	11097:	11098:	11139:	11142:	11143:	11145:	11146:	11149:
U 0B20	11150:	11151:	11152:	11153:	11157:	11158:	11160:	11161:
U 0B28	11163:	11165:	11167:	11168:	11171:	11172:	11174:	11175:
U 0B30	11177:	11178:	11179:	11180:	11181:	11186:	11187:	11189:
U 0B38	11190:	11191:	11193:	11194:	11197:	11198:	11200:	11201:
U 0B40	11203:	11204:	11205:	11206:	11207:	11211:	11212:	11213:
U 0B48	11214:	11215:	11219:	11416:	11418:	11422:	11424:	11427:
U 0B50	11430:	11431:	11435:	11437:	11438:	11440:	11441:	11445:
U 0B58	11447:	11448:	11450:	11453:	11457:	11459:	11460:	11462:
U 0B60	11463:	11465:	11467:	11468:	11471:	11472:	11475:	11476:
U 0B68	11477:	11481:	11482:	11485:	11486:	11489:	11490:	11493:
U 0B70	11496:	11498:	11499:	11500:	11501:	11502:	11568:	11569:
U 0B78	11570:	11573:	11574:	11575:	11578:	11579:	11581:	11583:
U 0B80	11584:	11585:	11586:	11587:	11588:	11589:	11630:	11633:
U 0B88	11634:	11636:	11637:	11640:	11641:	11642:	11643:	11644:
U 0B90	11647:	11648:	11651:	11652:	11654:	11656:	11658:	11659:
U 0B98	11662:	11663:	11665:	11666:	11668:	11669:	11670:	11671:
U 0BA0	11672:	11675:	11676:	11678:	11679:	11680:	11683:	11685:
U 0BA8	11688:	11689:	11692:	11693:	11695:	11696:	11697:	11698:
U 0BB0	11699:	11703:	11704:	11705:	11706:	11707:	11711:	11932:
U 0BB8	11934:	11938:	11940:	11943:	11946:	11947:	11951:	11953:
U 0BC0	11954:	11956:	11957:	11961:	11963:	11964:	11966:	11970:
U 0BC8	11974:	11976:	11977:	11978:	11979:	11981:	11985:	11986:
U 0BD0	11988:	11989:	11990:	11991:	12057:	12058:	12059:	12062:
U 0BD8	12063:	12064:	12066:	12067:	12068:	12069:	12130:	12131:
U 0BE0	12132:	12134:	12135:	12136:	12141:	12142:	12144:	12146:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0BE8	12147:	12148:	12149:	12150:	12151:	12152:	12194:	12197:
U 0BF0	12198:	12200:	12201:	12203:	12204:	12205:	12206:	12207:
U 0BF8	12211:	12212:	12215:	12216:	12218:	12220:	12222:	12223:
U 0C00	12226:	12227:	12229:	12230:	12232:	12233:	12234:	12235:
U 0C08	12236:	12240:	12241:	12243:	12244:	12245:	12247:	12249:
U 0C10	12252:	12253:	12256:	12257:	12259:	12260:	12261:	12262:
U 0C18	12263:	12268:	12269:	12270:	12271:	12272:	12276:	12491:
U 0C20	12493:	12497:	12499:	12502:	12505:	12506:	12510:	12512:
U 0C28	12513:	12515:	12516:	12520:	12522:	12523:	12525:	12529:
U 0C30	12533:	12534:	12535:	12537:	12538:	12540:	12542:	12543:
U 0C38	12546:	12547:	12550:	12551:	12552:	12555:	12556:	12559:
U 0C40	12560:	12563:	12564:	12567:	12570:	12572:	12573:	12574:
U 0C48	12575:	12576:	12643:	12644:	12645:	12648:	12649:	12650:
U 0C50	12652:	12653:	12654:	12655:	12715:	12716:	12717:	12719:
U 0C58	12720:	12721:	12725:	12726:	12728:	12730:	12731:	12732:
U 0C60	12733:	12734:	12735:	12736:	12777:	12780:	12781:	12783:
U 0C68	12784:	12787:	12788:	12789:	12790:	12791:	12794:	12795:
U 0C70	12798:	12799:	12801:	12803:	12805:	12806:	12809:	12810:
U 0C78	12813:	12814:	12816:	12817:	12818:	12819:	12820:	12824:
U 0C80	12825:	12827:	12828:	12830:	12832:	12835:	12836:	12838:
U 0C88	12839:	12840:	12842:	12843:	12844:	12845:	12846:	12850:
U 0C90	12851:	12852:	12853:	12854:	12857:	13107:	13109:	13113:
U 0C98	13115:	13118:	13121:	13122:	13126:	13128:	13129:	13131:
U 0CA0	13132:	13136:	13138:	13139:	13141:	13145:	13149:	13151:
U 0CA8	13152:	13153:	13154:	13156:	13160:	13162:	13163:	13164:
U 0CB0	13165:	13166:	13234:	13235:	13236:	13239:	13240:	13241:
U 0CB8	13244:	13245:	13247:	13249:	13250:	13251:	13253:	13254:
U 0CC0	13298:	13301:	13302:	13304:	13305:	13307:	13308:	13309:
U 0CC8	13310:	13311:	13313:	13314:	13318:	13319:	13321:	13323:
U 0CD0	13325:	13327:	13330:	13331:	13334:	13335:	13337:	13338:
U 0CD8	13339:	13340:	13341:	13345:	13346:	13348:	13349:	13351:
U 0CE0	13353:	13354:	13357:	13358:	13360:	13361:	13362:	13365:
U 0CE8	13366:	13367:	13368:	13369:	13371:	13372:	13374:	13375:
U 0CF0	13378:	13384:	13385:	13435:	13438:	13439:	13441:	13442:
U 0CF8	13445:	13446:	13447:	13448:	13449:	13450:	13453:	13454:
U 0D00	13455:	13456:	13457:	13458:	13461:	13462:	13463:	13464:
U 0D08	13465:	13470:	13712:	13714:	13718:	13720:	13723:	13726:
U 0D10	13727:	13731:	13733:	13734:	13736:	13737:	13740:	13742:
U 0D18	13743:	13745:	13749:	13753:	13754:	13755:	13757:	13758:
U 0D20	13760:	13762:	13763:	13766:	13767:	13770:	13771:	13773:
U 0D28	13776:	13777:	13780:	13781:	13784:	13785:	13788:	13791:
U 0D30	13793:	13794:	13795:	13796:	13797:	13865:	13866:	13867:
U 0D38	13870:	13871:	13872:	13876:	13877:	13879:	13881:	13882:
U 0D40	13883:	13885:	13886:	13929:	13932:	13933:	13937:	13938:
U 0D48	13941:	13942:	13943:	13944:	13945:	13948:	13949:	13953:
U 0D50	13954:	13955:	13957:	13959:	13961:	13963:	13966:	13967:
U 0D58	13970:	13971:	13973:	13974:	13975:	13976:	13977:	13981:
U 0D60	13982:	13984:	13985:	13987:	13989:	13991:	13994:	13995:
U 0D68	13998:	13999:	14000:	14003:	14004:	14005:	14006:	14007:
U 0D70	14009:	14010:	14013:	14014:	14018:	14022:	14023:	14073:
U 0D78	14076:	14077:	14081:	14082:	14085:	14086:	14087:	14088:
U 0D80	14089:	14090:	14094:	14095:	14096:	14097:	14098:	14101:
U 0D88	14102:	14103:	14104:	14105:	14109:	14373:	14375:	14379:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0D90	14381:	14384:	14387:	14388:	14392:	14394:	14395:	14397:
U 0D98	14398:	14401:	14403:	14404:	14406:	14411:	14415:	14417:
U 0DA0	14418:	14419:	14420:	14422:	14426:	14428:	14430:	14431:
U 0DA8	14432:	14433:	14499:	14500:	14501:	14504:	14505:	14506:
U 0DB0	14508:	14509:	14510:	14511:	14570:	14571:	14572:	14574:
U 0DB8	14575:	14576:	14580:	14581:	14583:	14585:	14586:	14587:
U 0DC0	14589:	14590:	14633:	14636:	14637:	14642:	14643:	14646:
U 0DC8	14647:	14648:	14649:	14650:	14654:	14655:	14657:	14658:
U 0DD0	14660:	14662:	14664:	14666:	14669:	14670:	14673:	14674:
U 0DD8	14677:	14678:	14679:	14680:	14681:	14684:	14685:	14688:
U 0DE0	14689:	14691:	14694:	14695:	14698:	14699:	14703:	14704:
U 0DE8	14705:	14709:	14710:	14711:	14712:	14713:	14715:	14716:
U 0DF0	14718:	14719:	14723:	14727:	14728:	14778:	14781:	14782:
U 0DF8	14784:	14785:	14788:	14789:	14790:	14791:	14792:	14793:
U 0E00	14797:	14798:	14799:	14800:	14801:	14806:	14807:	14808:
U 0E08	14809:	14810:	14814:	15074:	15076:	15080:	15082:	15085:
U 0E10	15088:	15089:	15093:	15095:	15096:	15098:	15099:	15102:
U 0E18	15104:	15105:	15107:	15111:	15115:	15116:	15117:	15119:
U 0E20	15120:	15122:	15124:	15125:	15128:	15129:	15132:	15133:
U 0E28	15135:	15138:	15139:	15142:	15143:	15146:	15147:	15150:
U 0E30	15153:	15155:	15156:	15157:	15158:	15159:	15226:	15227:
U 0E38	15228:	15231:	15232:	15233:	15235:	15236:	15237:	15238:
U 0E40	15297:	15298:	15299:	15301:	15302:	15303:	15307:	15308:
U 0E48	15310:	15312:	15313:	15314:	15316:	15317:	15360:	15363:
U 0E50	15364:	15366:	15367:	15370:	15371:	15372:	15373:	15374:
U 0E58	15377:	15378:	15382:	15383:	15384:	15386:	15388:	15390:
U 0E60	15391:	15394:	15395:	15398:	15399:	15402:	15403:	15404:
U 0E68	15405:	15406:	15410:	15411:	15413:	15414:	15416:	15419:
U 0E70	15420:	15423:	15424:	15426:	15427:	15428:	15432:	15433:
U 0E78	15434:	15435:	15436:	15438:	15439:	15441:	15442:	15446:
U 0E80	15450:	15451:	15501:	15504:	15505:	15507:	15508:	15511:
U 0E88	15512:	15513:	15514:	15515:	15516:	15520:	15521:	15522:
U 0E90	15523:	15524:	15528:	15529:	15530:	15531:	15532:	15535:
U 0E98	15688:	15690:	15694:	15696:	15699:	15702:	15703:	15705:
U 0EA0	15706:	15708:	15709:	15711:	15712:	15714:	15716:	15719:
U 0EA8	15720:	15722:	15723:	15724:	15725:	15788:	15789:	15790:
U 0EB0	15793:	15794:	15795:	15797:	15799:	15800:	15801:	15802:
U 0EB8	15878:	15879:	15880:	15883:	15884:	15885:	15889:	15890:
U 0EC0	15891:	15893:	15894:	15895:	15896:	15897:	15898:	15900:
U 0EC8	15902:	15903:	15904:	15905:	15906:	15907:	15972:	15973:
U 0ED0	15974:	15977:	15979:	15980:	15981:	15983:	15984:	15985:
U 0ED8	15986:	16062:	16063:	16064:	16067:	16068:	16069:	16072:
U 0EE0	16073:	16074:	16076:	16077:	16078:	16079:	16080:	16082:
U 0EE8	16083:	16084:	16086:	16087:	16090:	16091:	16093:	16094:
U 0EF0	16095:	16096:	16100:	16101:	16102:	16104:	16105:	16106:
U 0EF8	16107:	16173:	16174:	16175:	16178:	16179:	16180:	16183:
U 0F00	16184:	16185:	16186:	16262:	16263:	16264:	16267:	16268:
U 0F08	16269:	16271:	16272:	16273:	16275:	16276:	16277:	16278:
U 0F10	16279:	16280:	16283:	16286:	16287:	16290:	16291:	16292:
U 0F18	16295:	16297:	16298:	16299:	16302:	16414:	16416:	16420:
U 0F20	16422:	16425:	16428:	16429:	16432:	16433:	16435:	16436:
U 0F28	16438:	16440:	16441:	16443:	16447:	16451:	16453:	16454:
U 0F30	16455:	16456:	16458:	16462:	16463:	16464:	16465:	16466:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 0F38	16467:	16468:	16469:	16470:	16552:	16553:	16554:	16557:
U 0F40	16558:	16559:	16562:	16563:	16564:	16566:	16567:	16568:
U 0F48	16569:	16574:	16575:	16576:	16578:	16579:	16581:	16584:
U 0F50	16586:	16587:	16590:	16591:	16594:	16595:	16597:	16600:
U 0F58	16601:	16604:	16605:	16608:	16609:	16612:	16615:	16617:
U 0F60	16618:	16619:	16620:	16621:	16622:	16623:	16624:	16625:
U 0F68	16707:	16708:	16709:	16712:	16713:	16714:	16717:	16718:
U 0F70	16719:	16721:	16722:	16723:	16724:	16727:	16844:	16846:
U 0F78	16850:	16852:	16855:	16858:	16859:	16862:	16863:	16865:
U 0F80	16866:	16868:	16870:	16871:	16873:	16877:	16881:	16883:
U 0F88	16884:	16885:	16886:	16888:	16892:	16893:	16895:	16896:
U 0F90	16897:	16898:	16899:	16900:	16901:	16902:	16984:	16985:
U 0F98	16986:	16989:	16990:	16991:	16994:	16995:	16996:	16998:
U 0FA0	16999:	17000:	17001:	17003:	17006:	17007:	17009:	17010:
U 0FA8	17011:	17012:	17013:	17014:	17015:	17097:	17098:	17099:
U 0FB0	17102:	17103:	17104:	17107:	17108:	17109:	17111:	17112:
U 0FB8	17113:	17114:	17116:	17219:	17221:	17225:	17227:	17230:
U 0FC0	17233:	17234:	17237:	17238:	17240:	17241:	17243:	17247:
U 0FC8	17248:	17250:	17251:	17254:	17255:	17256:	17257:	17258:
U 0FD0	17350:	17351:	17352:	17355:	17356:	17357:	17360:	17361:
U 0FD8	17362:	17364:	17365:	17366:	17367:	17369:	17372:	17373:
U 0FE0	17375:	17376:	17379:	17380:	17381:	17382:	17475:	17476:
U 0FE8	17477:	17480:	17481:	17482:	17485:	17486:	17487:	17489:
U 0FF0	17490:	17491:	17492:	17494:	17739:	17741:	17745:	17747:
U 0FF8	17750:	17753:	17754:	17757:	17758:	17760:	17761:	17763:
U 1000	17764:	17766:	17769:	17771:	17772:	17774:	17776:	17777:
U 1008	17779:	17780:	17781:	17782:	17783:	17846:	17847:	17848:
U 1010	17851:	17852:	17853:	17855:	17857:	17858:	17862:	17865:
U 1018	17866:	17868:	17870:	17871:	17872:	17874:	17875:	17877:
U 1020	17878:	17879:	17880:	17881:	17953:	17954:	17955:	17958:
U 1028	17959:	17960:	17963:	17964:	17965:	17967:	17969:	17970:
U 1030	17971:	17972:	17974:	17976:	17977:	17981:	17983:	17984:
U 1038	17986:	17988:	17989:	17990:	17993:	17994:	17996:	17997:
U 1040	17998:	17999:	18000:	18063:	18064:	18065:	18068:	18069:
U 1048	18070:	18072:	18073:	18074:	18076:	18077:	18149:	18150:
U 1050	18151:	18154:	18155:	18156:	18159:	18160:	18161:	18163:
U 1058	18164:	18165:	18167:	18168:	18169:	18170:	18172:	18173:
U 1060	18175:	18176:	18179:	18181:	18182:	18183:	18184:	18186:
U 1068	18188:	18189:	18190:	18191:	18193:	18194:	18197:	18198:
U 1070	18199:	18200:	18201:	18202:	18204:	18205:	18277:	18278:
U 1078	18279:	18282:	18283:	18284:	18287:	18288:	18289:	18292:
U 1080	18293:	18294:	18295:	18296:	18297:	18300:	18302:	18306:
U 1088	18307:	18310:	18311:	18313:	18315:	18316:	18318:	18321:
U 1090	18322:	18324:	18325:	18326:	18327:	18328:	18391:	18392:
U 1098	18393:	18396:	18397:	18398:	18401:	18402:	18403:	18405:
U 10A0	18406:	18478:	18479:	18480:	18483:	18484:	18485:	18488:
U 10A8	18489:	18490:	18493:	18494:	18495:	18496:	18497:	18499:
U 10B0	18501:	18502:	18503:	18506:	18507:	18508:	18509:	18510:
U 10B8	18573:	18574:	18575:	18578:	18579:	18580:	18582:	18583:
U 10C0	18585:	18589:	18590:	18662:	18663:	18664:	18667:	18668:
U 10C8	18669:	18672:	18673:	18674:	18677:	18678:	18679:	18680:
U 10D0	18681:	18682:	18683:	18686:	18851:	18853:	18857:	18859:
U 10D8	18862:	18865:	18866:	18869:	18870:	18872:	18873:	18875:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 10E0	18876:	18878:	18882:	18884:	18885:	18887:	18889:	18890:
U 10E8	18892:	18893:	18894:	18895:	18896:	18959:	18960:	18961:
U 10F0	18964:	18965:	18966:	18968:	18970:	18971:	18975:	18976:
U 10F8	18977:	18978:	18979:	19044:	19045:	19046:	19049:	19050:
U 1100	19051:	19055:	19056:	19115:	19116:	19117:	19120:	19121:
U 1108	19122:	19126:	19127:	19129:	19131:	19132:	19134:	19138:
U 1110	19139:	19141:	19142:	19143:	19144:	19145:	19217:	19218:
U 1118	19219:	19222:	19223:	19224:	19227:	19228:	19229:	19231:
U 1120	19232:	19233:	19234:	19235:	19237:	19239:	19240:	19244:
U 1128	19245:	19246:	19247:	19323:	19324:	19325:	19328:	19329:
U 1130	19330:	19332:	19335:	19536:	19538:	19542:	19544:	19547:
U 1138	19550:	19551:	19554:	19555:	19557:	19558:	19560:	19562:
U 1140	19564:	19566:	19568:	19569:	19570:	19571:	19574:	19575:
U 1148	19576:	19578:	19579:	19580:	19581:	19584:	19585:	19586:
U 1150	19587:	19588:	19592:	19593:	19594:	19595:	19596:	19600:
U 1158	19601:	19602:	19603:	19604:	19609:	19611:	19613:	19616:
U 1160	19618:	19620:	19621:	19622:	19623:	19626:	19627:	19628:
U 1168	19630:	19631:	19632:	19633:	19636:	19637:	19638:	19639:
U 1170	19640:	19644:	19645:	19646:	19647:	19648:	19652:	19653:
U 1178	19654:	19655:	19656:	19661:	19732:	19734:	19738:	19740:
U 1180	19743:	19746:	19747:	19750:	19751:	19754:	19755:	19758:
U 1188	19759:	19760:	19763:	19764:	19765:	19766:	19769:	19770:
U 1190	19772:	19773:	19776:	19777:	19780:	19781:	19782:	19784:
U 1198	19785:	19786:	19787:	19788:	19789:	19791:	19792:	19796:
U 11A0	19797:	19798:	19799:	19802:	19803:	19805:	19806:	19809:
U 11A8	19810:	19813:	19814:	19815:	19817:	19818:	19819:	19820:
U 11B0	19821:	19822:	19824:	19825:	19829:	19830:	19831:	19835:
U 11B8	19836:	19839:	19840:	19841:	19843:	19844:	19847:	19848:
U 11C0	19851:	19852:	19853:	19855:	19856:	19857:	19858:	19859:
U 11C8	19860:	19862:	19863:	19865:	19868:	19869:	19873:	19874:
U 11D0	19875:	19878:	19879:	19882:	19883:	19884:	19886:	19887:
U 11D8	19890:	19891:	19894:	19895:	19896:	19898:	19899:	19900:
U 11E0	19901:	19902:	19903:	19905:	19906:	19908:	19911:	19912:
U 11E8	19914:	19986:	19988:	19992:	19994:	19997:	20000:	20001:
U 11F0	20004:	20005:	20008:	20009:	20012:	20013:	20017:	20018:
U 11F8	20019:	20020:	20023:	20024:	20026:	20027:	20030:	20031:
U 1200	20034:	20035:	20036:	20038:	20039:	20040:	20041:	20042:
U 1208	20043:	20045:	20046:	20050:	20051:	20052:	20053:	20056:
U 1210	20057:	20059:	20060:	20063:	20064:	20067:	20068:	20069:
U 1218	20071:	20072:	20073:	20074:	20075:	20076:	20078:	20079:
U 1220	20083:	20084:	20085:	20089:	20090:	20093:	20094:	20095:
U 1228	20097:	20098:	20101:	20102:	20105:	20106:	20107:	20109:
U 1230	20110:	20111:	20112:	20113:	20114:	20116:	20117:	20119:
U 1238	20122:	20123:	20127:	20128:	20129:	20132:	20133:	20136:
U 1240	20137:	20138:	20140:	20141:	20144:	20145:	20148:	20149:
U 1248	20150:	20152:	20153:	20154:	20155:	20156:	20157:	20159:
U 1250	20160:	20162:	20165:	20166:	20168:	20302:	20304:	20308:
U 1258	20310:	20313:	20316:	20317:	20320:	20321:	20323:	20326:
U 1260	20327:	20330:	20331:	20333:	20334:	20336:	20339:	20340:
U 1268	20341:	20342:	20344:	20345:	20346:	20347:	20351:	20352:
U 1270	20353:	20354:	20355:	20359:	20360:	20361:	20362:	20363:
U 1278	20367:	20368:	20369:	20370:	20371:	20374:	20376:	20377:
U 1280	20378:	20379:	20380:	20384:	20385:	20386:	20387:	20388:

Location / Line Number Index

:Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 1238	20391:	20611:	20613:	20617:	20619:	20622:	20625:	20626:
U 1290	20629:	20630:	20632:	20633:	20636:	20637:	20638:	20639:
U 1298	20640:	20641:	20642:	20643:	20644:	20645:	20648:	20649:
U 12A0	20650:	20652:	20653:	20654:	20655:	20656:	20658:	20758:
U 12A8	20760:	20764:	20766:	20769:	20772:	20773:	20776:	20777:
U 12B0	20779:	20780:	20782:	20783:	20788:	20789:	20793:	20794:
U 12B8	20796:	20800:	20803:	20804:	20806:	20807:	20810:	20818:
U 12C0	20819:	20820:	20823:	20824:	20826:	20828:	20829:	20830:
U 12C8	20841:	20842:	20845:	20848:	20852:	20853:	20855:	20856:
U 12D0	20858:	20859:	20861:	20862:	20864:	20866:	20867:	20869:
U 12D8	20870:	20871:	20872:	20873:	20875:	20876:	20877:	20879:
U 12E0	20880:	20881:	20882:	20883:	20884:	20886:	20887:	20890:
U 12E8	20893:	20894:	20896:	20897:	20900:	20902:	20903:	20905:
U 12F0	20906:	20907:	20908:	20909:	20910:	20912:	20920:	20921:
U 12F8	20926:	20927:	20929:	20934:	21037:	21039:	21043:	21045:
U 1300	21048:	21051:	21052:	21055:	21056:	21058:	21059:	21061:
U 1308	21062:	21067:	21068:	21072:	21073:	21075:	21078:	21081:
U 1310	21082:	21085:	21086:	21090:	21098:	21099:	21100:	21103:
U 1318	21104:	21106:	21108:	21109:	21110:	21119:	21120:	21123:
U 1320	21126:	21130:	21131:	21133:	21134:	21136:	21137:	21139:
U 1328	21140:	21142:	21144:	21145:	21147:	21148:	21150:	21151:
U 1330	21152:	21155:	21156:	21157:	21159:	21160:	21161:	21162:
U 1338	21163:	21164:	21166:	21167:	21169:	21172:	21173:	21175:
U 1340	21176:	21179:	21181:	21182:	21184:	21185:	21186:	21187:
U 1348	21188:	21189:	21191:	21197:	21198:	21203:	21204:	21206:
U 1350	21210:	21360:	21362:	21366:	21368:	21371:	21374:	21375:
U 1358	21378:	21379:	21381:	21382:	21384:	21386:	21387:	21393:
U 1360	21394:	21396:	21397:	21400:	21401:	21403:	21404:	21406:
U 1368	21407:	21408:	21409:	21410:	21411:	21412:	21484:	21485:
U 1370	21486:	21489:	21490:	21491:	21494:	21495:	21496:	21498:
U 1378	21499:	21501:	21502:	21506:	21507:	21508:	21509:	21510:
U 1380	21514:	21515:	21516:	21517:	21518:	21522:	21523:	21524:
U 1388	21525:	21526:	21529:	21534:	21535:	21537:	21538:	21539:
U 1390	21541:	21542:	21543:	21544:	21624:	21625:	21626:	21629:
U 1398	21630:	21631:	21635:	21636:	21637:	21639:	21640:	21642:
U 13A0	21643:	21645:	21731:	21733:	21737:	21739:	21742:	21745:
U 13A8	21746:	21749:	21750:	21752:	21753:	21755:	21757:	21760:
U 13B0	21761:	21765:	21766:	21768:	21769:	21771:	21773:	21774:
U 13B8	21776:	21777:	21854:	21855:	21856:	21859:	21860:	21861:
U 13C0	21864:	21865:	21868:	21869:	21870:	21872:	21873:	21874:
U 13C8	21875:	21877:	21879:	21880:	21882:	22002:	22004:	22008:
U 13D0	22010:	22012:	22016:	22018:	22019:	22021:	22022:	22024:
U 13D8	22025:	22028:	22030:	22031:	22033:	22036:	22040:	22042:
U 13E0	22043:	22044:	22045:	22047:	22052:	22053:	22054:	22055:
U 13E8	22057:	22058:	22061:	22062:	22064:	22065:	22215:	22217:
U 13F0	22218:	22220:	22221:	22223:	22224:	22225:	22226:	22230:
U 13F8	22231:	22232:	22234:	22236:	22237:	22238:	22240:	22241:
U 1400	22242:	22244:	22245:	22248:	22249:	22250:	22252:	22253:
U 1408	22254:	22255:	22258:	22365:	22367:	22371:	22373:	22375:
U 1410	22378:	22379:	22381:	22382:	22384:	22385:	22388:	22390:
U 1418	22391:	22393:	22396:	22400:	22402:	22403:	22404:	22405:
U 1420	22407:	22411:	22412:	22413:	22415:	22416:	22418:	22421:
U 1428	22422:	22423:	22425:	22426:	22428:	22431:	22432:	22433:

Location / Line Number Index

:Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 1430	22435:	22436:	22439:	22442:	22443:	22444:	22446:	22447:
U 1438	22449:	22452:	22453:	22454:	22456:	22457:	22460:	22558:
U 1440	22560:	22564:	22566:	22569:	22572:	22573:	22576:	22577:
U 1448	22579:	22583:	22584:	22586:	22587:	22588:	22589:	22590:
U 1450	22591:	22648:	22649:	22650:	22653:	22654:	22655:	22659:
U 1458	22660:	22661:	22663:	22664:	22665:	22666:	22673:	22674:
U 1460	22676:	22677:	22678:	22679:	22680:	22682:	22683:	22684:
U 1468	22685:	22690:	22691:	22692:	22693:	22694:	22695:	22808:
U 1470	22809:	22810:	22813:	22814:	22815:	22818:	22819:	22820:
U 1478	22822:	22823:	22824:	22825:	22829:	22960:	22962:	22966:
U 1480	22968:	22971:	22974:	22975:	22979:	22980:	22982:	22985:
U 1488	22986:	22988:	22989:	22990:	22991:	22992:	22993:	23051:
U 1490	23052:	23053:	23056:	23057:	23058:	23061:	23062:	23063:
U 1498	23064:	23065:	23066:	23067:	23072:	23073:	23076:	23077:
U 14A0	23078:	23079:	23084:	23085:	23086:	23087:	23088:	23089:
U 14A8	23185:	23186:	23187:	23190:	23191:	23192:	23195:	23196:
U 14B0	23197:	23198:	23199:	23200:	23201:	23203:	23205:	23206:
U 14B8	23208:	23318:	23320:	23324:	23326:	23329:	23332:	23333:
U 14C0	23337:	23338:	23341:	23344:	23345:	23346:	23347:	23348:
U 14C8	23350:	23351:	23353:	23354:	23355:	23356:	23357:	23361:
U 14D0	23362:	23363:	23364:	23365:	23366:	23468:	23469:	23470:
U 14D8	23473:	23474:	23475:	23478:	23479:	23480:	23482:	23483:
U 14E0	23484:	23485:	23487:	23488:	23493:	23495:	23496:	23498:
U 14E8	23499:	23502:	23503:	23504:	23505:	23508:	23509:	23510:
U 14F0	23511:	23512:	23513:	23594:	23595:	23596:	23599:	23600:
U 14F8	23601:	23605:	23606:	23607:	23609:	23610:	23611:	23612:
U 1500	23614:	23615:	23616:	23620:	23770:	23772:	23776:	23778:
U 1508	23781:	23784:	23785:	23789:	23790:	23793:	23798:	23799:
U 1510	23801:	23802:	23803:	23804:	23805:	23806:	23807:	23865:
U 1518	23866:	23867:	23870:	23871:	23872:	23875:	23876:	23877:
U 1520	23879:	23880:	23881:	23882:	23884:	23885:	23887:	23889:
U 1528	23890:	23891:	23892:	23893:	23895:	23896:	23897:	23898:
U 1530	23903:	23904:	23905:	23906:	23907:	24020:	24021:	24022:
U 1538	24025:	24026:	24027:	24031:	24032:	24033:	24035:	24036:
U 1540	24037:	24038:	24044:	24046:	24048:	24049:	24051:	24052:
U 1548	24055:	24056:	24058:	24059:	24062:	24063:	24064:	24065:
U 1550	24070:	24071:	24072:	24073:	24074:	24155:	24156:	24157:
U 1558	24160:	24161:	24162:	24165:	24166:	24167:	24169:	24170:
U 1560	24171:	24172:	24175:	24176:	24179:	24180:	24181:	24182:
U 1568	24183:	24184:	24185:	24190:	24191:	24192:	24193:	24194:
U 1570	24288:	24294:	24295:	24296:	24297:	24300:	24301:	24302:
U 1578	24304:	24305:	24306:	24307:	24309:	24438:	24440:	24444:
U 1580	24446:	24449:	24452:	24453:	24457:	24458:	24461:	24463:
U 1588	24464:	24466:	24469:	24473:	24475:	24476:	24477:	24479:
U 1590	24481:	24486:	24487:	24488:	24489:	24490:	24491:	24494:
U 1598	24495:	24497:	24498:	24499:	24500:	24501:	24502:	24560:
U 15A0	24561:	24562:	24565:	24566:	24567:	24569:	24570:	24571:
U 15A8	24572:	24576:	24577:	24578:	24579:	24580:	24581:	24582:
U 15B0	24676:	24677:	24678:	24681:	24682:	24683:	24686:	24687:
U 15B8	24688:	24690:	24691:	24692:	24693:	24695:	24696:	24697:
U 15C0	24702:	24704:	24705:	24707:	24708:	24709:	24710:	24712:
U 15C8	24714:	24716:	24717:	24718:	24719:	24722:	24723:	24724:
U 15D0	24725:	24726:	24727:	24728:	24822:	24823:	24824:	24827:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 15D8	24828:	24829:	24833:	24834:	24835:	24837:	24838:	24839:
U 15E0	24840:	24842:	24843:	24845:	24961:	24963:	24967:	24969:
U 15E8	24972:	24975:	24976:	24979:	24980:	24983:	24984:	24991:
U 15F0	24993:	24994:	24997:	25003:	25005:	25006:	25007:	25009:
U 15F8	25011:	25014:	25016:	25017:	25018:	25019:	25020:	25022:
U 1600	25023:	25024:	25025:	25029:	25030:	25031:	25032:	25033:
U 1608	25034:	25136:	25137:	25138:	25141:	25142:	25143:	25146:
U 1610	25148:	25153:	25154:	25155:	25156:	25157:	25158:	25271:
U 1618	25272:	25273:	25276:	25277:	25278:	25281:	25285:	25286:
U 1620	25287:	25288:	25292:	25293:	25294:	25295:	25296:	25297:
U 1628	25298:	25400:	25401:	25402:	25405:	25406:	25407:	25410:
U 1630	25411:	25414:	25415:	25416:	25418:	25419:	25420:	25421:
U 1638	25422:	25424:	25549:	25551:	25555:	25557:	25560:	25563:
U 1640	25564:	25567:	25568:	25570:	25571:	25573:	25575:	25576:
U 1648	25578:	25581:	25585:	25587:	25588:	25589:	25590:	25592:
U 1650	25595:	25596:	25599:	25600:	25601:	25602:	25703:	25704:
U 1658	25705:	25708:	25709:	25710:	25713:	25715:	25717:	25718:
U 1660	25719:	25720:	25722:	25726:	25727:	25730:	25731:	25732:
U 1668	25733:	25734:	25927:	25928:	25929:	25932:	25933:	25934:
U 1670	25937:	25938:	25939:	25941:	25942:	25943:	25944:	25945:
U 1678	25950:	25951:	25954:	25955:	25956:	25957:	26058:	26059:
U 1680	26060:	26063:	26064:	26065:	26067:	26173:	26175:	26179:
U 1688	26181:	26184:	26187:	26188:	26191:	26192:	26194:	26195:
U 1690	26197:	26199:	26200:	26202:	26205:	26209:	26211:	26212:
U 1698	26213:	26214:	26216:	26219:	26221:	26223:	26224:	26225:
U 16A0	26226:	26228:	26232:	26233:	26236:	26237:	26238:	26239:
U 16A8	26240:	26432:	26433:	26434:	26437:	26438:	26439:	26443:
U 16B0	26444:	26448:	26449:	26452:	26453:	26454:	26455:	26556:
U 16B8	26557:	26558:	26561:	26562:	26563:	26566:	26567:	26568:
U 16C0	26570:	26571:	26572:	26573:	26575:	26716:	26718:	26722:
U 16C8	26724:	26727:	26730:	26731:	26734:	26735:	26737:	26738:
U 16D0	26740:	26742:	26743:	26745:	26748:	26752:	26754:	26755:
U 16D8	26756:	26757:	26759:	26763:	26764:	26766:	26767:	26768:
U 16E0	26769:	26870:	26871:	26872:	26875:	26876:	26877:	26879:
U 16E8	26880:	26882:	26883:	26884:	26885:	26887:	26891:	26892:
U 16F0	26894:	26895:	26896:	26897:	26898:	27091:	27092:	27093:
U 16F8	27096:	27097:	27098:	27101:	27102:	27103:	27105:	27106:
U 1700	27107:	27108:	27110:	27115:	27116:	27118:	27119:	27120:
U 1708	27121:	27222:	27223:	27224:	27227:	27228:	27229:	27232:
U 1710	27233:	27235:	27236:	27237:	27238:	27240:	27244:	27245:
U 1718	27247:	27248:	27249:	27250:	27251:	27444:	27445:	27446:
U 1720	27449:	27450:	27451:	27454:	27455:	27456:	27458:	27459:
U 1728	27460:	27461:	27462:	27466:	27467:	27469:	27470:	27471:
U 1730	27472:	27573:	27574:	27575:	27578:	27579:	27580:	27583:
U 1738	27707:	27709:	27713:	27715:	27718:	27721:	27722:	27725:
U 1740	27726:	27728:	27729:	27731:	27733:	27734:	27736:	27739:
U 1748	27743:	27745:	27746:	27747:	27748:	27750:	27753:	27754:
U 1750	27755:	27759:	27760:	27763:	27764:	27765:	27766:	27867:
U 1758	27868:	27869:	27872:	27873:	27874:	27876:	27877:	27879:
U 1760	27880:	27881:	27882:	27884:	27888:	27889:	27891:	27892:
U 1768	27893:	27894:	27895:	28088:	28089:	28090:	28093:	28094:
U 1770	28095:	28098:	28099:	28100:	28102:	28103:	28104:	28105:
U 1778	28106:	28110:	28111:	28115:	28119:	28120:	28121:	28123:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 1780	28126:	28127:	28129:	28130:	28131:	28132:	28233:	28234:
U 1788	28235:	28238:	28239:	28240:	28243:	28364:	28366:	28370:
U 1790	28372:	28375:	28378:	28379:	28382:	28383:	28385:	28386:
U 1798	28388:	28389:	28391:	28393:	28394:	28396:	28399:	28403:
U 17A0	28405:	28406:	28407:	28408:	28410:	28416:	28417:	28418:
U 17A8	28419:	28420:	28424:	28425:	28428:	28429:	28430:	28431:
U 17B0	28532:	28533:	28534:	28537:	28538:	28539:	28543:	28544:
U 17B8	28545:	28546:	28547:	28549:	28550:	28554:	28555:	28558:
U 17C0	28559:	28560:	28561:	28562:	28563:	28564:	28777:	28778:
U 17C8	28779:	28782:	28783:	28784:	28787:	28788:	28789:	28791:
U 17D0	28792:	28794:	28796:	28797:	28799:	28801:	28802:	28805:
U 17D8	28806:	28809:	28810:	28811:	28812:	28813:	28817:	28818:
U 17E0	28819:	28820:	28821:	28824:	28825:	28828:	28829:	28830:
U 17E8	28831:	28932:	28933:	28934:	28937:	28938:	28939:	28941:
U 17F0	29096:	29098:	29102:	29104:	29107:	29110:	29111:	29113:
U 17F8	29114:	29117:	29118:	29120:	29121:	29124:	29129:	29130:
U 1800	29131:	29133:	29134:	29135:	29136:	29137:	29141:	29142:
U 1808	29144:	29145:	29146:	29147:	29150:	29151:	29154:	29156:
U 1810	29157:	29158:	29159:	29160:	29161:	29162:	29242:	29243:
U 1818	29244:	29247:	29248:	29249:	29252:	29253:	29254:	29256:
U 1820	29257:	29258:	29259:	29260:	29261:	29263:	29265:	29266:
U 1828	29268:	29269:	29271:	29273:	29274:	29276:	29277:	29278:
U 1830	29282:	29283:	29285:	29286:	29287:	29290:	29291:	29292:
U 1838	29295:	29296:	29299:	29300:	29303:	29304:	29305:	29307:
U 1840	29308:	29309:	29310:	29311:	29312:	29314:	29318:	29319:
U 1848	29324:	29329:	29330:	29333:	29334:	29335:	29336:	29337:
U 1850	29417:	29418:	29419:	29422:	29423:	29424:	29426:	29428:
U 1858	29429:	29431:	29433:	29436:	29437:	29438:	29440:	29441:
U 1860	29442:	29443:	29446:	29536:	29538:	29542:	29544:	29547:
U 1868	29550:	29551:	29554:	29555:	29557:	29558:	29560:	29561:
U 1870	29564:	29569:	29573:	29574:	29577:	29578:	29579:	29580:
U 1878	29581:	29661:	29662:	29663:	29666:	29667:	29668:	29671:
U 1880	29673:	29674:	29678:	29680:	29681:	29683:	29684:	29687:
U 1888	29688:	29689:	29692:	29693:	29694:	29698:	29700:	29701:
U 1890	29702:	29703:	29706:	29707:	29709:	29711:	29712:	29714:
U 1898	29715:	29717:	29718:	29720:	29722:	29726:	29727:	29729:
U 18A0	29730:	29732:	29733:	29735:	29737:	29740:	29741:	29743:
U 18A8	29745:	29746:	29751:	29752:	29756:	29757:	29760:	29761:
U 18B0	29762:	29763:	29764:	29844:	29845:	29846:	29849:	29850:
U 18B8	29851:	29853:	29855:	29856:	29859:	29860:	29861:	29864:
U 18C0	29865:	29866:	29868:	29869:	29870:	29871:	29872:	29874:
U 18C8	29979:	29981:	29985:	29987:	29990:	29993:	29994:	29997:
U 18D0	29998:	30000:	30001:	30003:	30006:	30007:	30011:	30012:
U 18D8	30013:	30014:	30115:	30116:	30117:	30120:	30121:	30122:
U 18E0	30127:	30128:	30131:	30132:	30133:	30134:	30135:	30136:
U 18E8	30238:	30239:	30240:	30243:	30244:	30245:	30246:	30247:
U 18F0	30250:	30251:	30252:	30254:	30255:	30256:	30257:	30260:
U 18F8	30262:	30263:	30266:	30268:	30271:	30272:	30273:	30275:
U 1900	30276:	30277:	30278:	30280:	30285:	30286:	30289:	30290:
U 1908	30291:	30292:	30293:	30294:	30396:	30397:	30398:	30401:
U 1910	30402:	30403:	30404:	30405:	30408:	30409:	30410:	30414:
U 1918	30415:	30416:	30418:	30419:	30420:	30421:	30423:	30523:
U 1920	30525:	30529:	30531:	30534:	30537:	30538:	30541:	30542:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 1928	30544:	30545:	30547:	30551:	30552:	30556:	30557:	30560:
U 1930	30561:	30562:	30563:	30564:	30565:	30667:	30668:	30669:
U 1938	30672:	30673:	30674:	30677:	30678:	30679:	30681:	30682:
U 1940	30683:	30684:	30686:	30689:	30690:	30691:	30693:	30697:
U 1948	30698:	30701:	30702:	30703:	30704:	30796:	30797:	30798:
U 1950	30801:	30802:	30803:	30806:	30807:	30808:	30810:	30811:
U 1958	30812:	30813:	30815:	30908:	30910:	30914:	30916:	30919:
U 1960	30922:	30923:	30926:	30927:	30929:	30930:	30932:	30935:
U 1968	30936:	30940:	30941:	30942:	30943:	31044:	31045:	31046:
U 1970	31049:	31050:	31051:	31056:	31057:	31058:	31059:	31124:
U 1978	31125:	31126:	31129:	31130:	31131:	31132:	31133:	31136:
U 1980	31137:	31138:	31140:	31141:	31142:	31143:	31145:	31147:
U 1988	31148:	31151:	31153:	31156:	31157:	31158:	31160:	31161:
U 1990	31162:	31163:	31165:	31170:	31171:	31172:	31173:	31238:
U 1998	31239:	31240:	31243:	31244:	31245:	31246:	31247:	31250:
U 19A0	31251:	31252:	31255:	31256:	31257:	31259:	31260:	31261:
U 19A8	31262:	31264:	31364:	31366:	31370:	31372:	31375:	31378:
U 19B0	31379:	31382:	31383:	31385:	31386:	31389:	31392:	31393:
U 19B8	31396:	31397:	31398:	31399:	31501:	31502:	31503:	31508:
U 19C0	31509:	31510:	31514:	31515:	31516:	31518:	31519:	31520:
U 19C8	31521:	31523:	31526:	31527:	31530:	31531:	31532:	31533:
U 19D0	31534:	31636:	31637:	31638:	31641:	31642:	31643:	31646:
U 19D8	31647:	31648:	31650:	31651:	31652:	31653:	31655:	31858:
U 19E0	31860:	31864:	31866:	31869:	31873:	31874:	31876:	31878:
U 19E8	31881:	31882:	31884:	31887:	31888:	31891:	31892:	31893:
U 19F0	31894:	31895:	31896:	31897:	31898:	31957:	31958:	31959:
U 19F8	31962:	31963:	31964:	31965:	31966:	31967:	31968:	31969:
U 1A00	31970:	31971:	31972:	31973:	31974:	31975:	31976:	31977:
U 1A08	31979:	31980:	31981:	31982:	31983:	31984:	31985:	31986:
U 1A10	31987:	31988:	31990:	31991:	31993:	31994:	31996:	31998:
U 1A18	31999:	32000:	32001:	32003:	32006:	32007:	32008:	32009:
U 1A20	32012:	32015:	32017:	32021:	32022:	32024:	32025:	32026:
U 1A28	32027:	32028:	32031:	32032:	32033:	32034:	32037:	32038:
U 1A30	32039:	32040:	32041:	32042:	32043:	32044:	32045:	32046:
U 1A38	32047:	32048:	32050:	32051:	32052:	32053:	32055:	32062:
U 1A40	32063:	32064:	32065:	32066:	32067:	32132:	32133:	32134:
U 1A48	32137:	32138:	32139:	32140:	32141:	32142:	32143:	32144:
U 1A50	32145:	32146:	32147:	32148:	32149:	32150:	32153:	32154:
U 1A58	32155:	32156:	32158:	32162:	32164:	32168:	32169:	32174:
U 1A60	32175:	32176:	32177:	32178:	32179:	32238:	32239:	32240:
U 1A68	32243:	32244:	32245:	32246:	32247:	32248:	32249:	32250:
U 1A70	32251:	32252:	32253:	32254:	32255:	32258:	32259:	32260:
U 1A78	32261:	32263:	32267:	32268:	32269:	32270:	32271:	32272:
U 1A80	32273:	32274:	32333:	32334:	32335:	32338:	32339:	32340:
U 1A88	32341:	32342:	32343:	32344:	32347:	32348:	32349:	32350:
U 1A90	32351:	32352:	32353:	32354:	32355:	32356:	32357:	32358:
U 1A98	32361:	32362:	32363:	32364:	32366:	32371:	32373:	32377:
U 1AA0	32378:	32379:	32384:	32386:	32390:	32391:	32393:	32394:
U 1AA8	32395:	32396:	32487:	32489:	32493:	32495:	32498:	32501:
U 1AB0	32502:	32505:	32506:	32508:	32510:	32513:	32514:	32516:
U 1AB8	32518:	32521:	32522:	32524:	32525:	32528:	32529:	32534:
U 1AC0	32535:	32541:	32542:	32543:	32544:	32547:	32548:	32549:
U 1AC8	32550:	32551:	32552:	32553:	32554:	32555:	32635:	32636:

Location / Line Number Index

;Location	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F
U 1AD0	32637:	32640:	32641:	32642:	32643:	32644:	32645:	32646:
U 1AD8	32648:	32650:	32651:	32652:	32653:	32654:	32656:	32659:
U 1AE0	32660:	32661:	32662:	32663:	32666:	32667:	32670:	32671:
U 1AE8	32673:	32675:	32676:	32679:	32680:	32684:	32685:	32687:
U 1AF0	32692:	32693:	32696:	32697:	32698:	32699:	32700:	32701:
U 1AF8	32702:	32703:	32704:	32784:	32785:	32786:	32789:	32790:
U 1B00	32791:	32792:	32793:	32794:	32795:	32797:	32799:	32800:
U 1B08	32803:	32804:	32805:	32807:	32810:	32811:	32814:	32815:
U 1B10	32816:	32817:	32818:	32819:	32822:	32823:	32824:	32825:
U 1B18	32826:	32829:	32830:	32833:	32834:	32836:	32971:	32973:
U 1B20	32977:	32979:	32982:	32985:	32986:	32990:	32992:	32995:
U 1B28	32995:	32997:	32998:	33000:	33001:	33003:	33004:	33006:
U 1B30	33007:	33009:	33010:	33014:	33015:	33017:	33019:	33021:
U 1B38	33022:	33023:	33025:	33026:	33027:	33028:	33029:	33030:
U 1B40	33031:	33033:	33034:	33035:	33039:	33040:	33041:	33042:
U 1B48	33045:	33047:	33048:	33049:	33050:	33053:	33055:	33056:
U 1B50	33057:	33058:	33061:	33063:	33064:	33065:	33066:	33069:
U 1B58	33071:	33072:	33073:	33074:	33076:	33180:	33182:	33186:
U 1B60	33188:	33191:	33194:	33195:	33199:	33200:	33205:	33209:
U 1B68	33211:	33214:	33215:	33218:	33219:	33220:	33223:	33224:
U 1B70	33253:	33254:	33255:	33257:	33258:	33259:	33260:	33262:
U 1B78	33263:	33264:	33265:	33266:	33267:	33268:	33270:	33271:
U 1B80	33272:	33276:	33278:	33280:	33284:	33286:	33287:	33294:
U 1B88	33295:	33296:	33298:	33299:	33300:	33301:	33303:	33305:
U 1B90	33308:	33310:	33314:	33315:	33316:	33319:	33320:	33323:
U 1B98	33324:	33325:	33327:	33328:	33329:	33330:	33332:	33420:
U 1BA0	33422:	33426:	33428:	33431:	33434:	33435:	33438:	33439:
U 1BA8	33441:	33442:	33446:	33448:	33450:	33452:	33453:	33456:
U 1BB0	33459:	33460:	33465:	33467:	33469:	33472:	33473:	33474:
U 1BB8	33475:	33476:	33555:	33556:	33557:	33560:	33561:	33562:
U 1BC0	33563:	33565:	33568:	33569:	33572:	33573:	33574:	33576:
U 1BC8	33577:	33578:	33579:	33581:	33584:	33588:	33590:	33593:
U 1BD0	33594:	33597:	33600:	33601:	33605:	33607:	33609:	33612:
U 1BD8	33613:	33614:	33615:	33616:	33695:	33696:	33697:	33700:
U 1BE0	33701:	33702:	33703:	33705:	33708:	33709:	33712:	33713:
U 1BE8	33714:	33716:	33717:	33718:	33719:	33722:	33729:	33730:
U 1BF0	33732:	33734:						

C-code Microword Summary

	Words not in bounds
ENKCF	512
Used	512
Remaining	

Total microwords used in memory C: 512
Total microwords remaining in memory C: 0
Highest address used in memory C: 180 (hex)

U-code Microword Summary

	Words not in bounds
ENKCF	6206
Used	6206
Remaining	

Total microwords used in memory U: 6206
Total microwords remaining in memory U: 0
Highest address used in memory U: 1BF1 (hex)

; The file used in this assembly is:
ENKCF.MIC

Pass 1 warnings: 0 Pass 2 warnings: 0
Pass 1 errors: 0 Pass 2 errors: 0